

Chapter 1 GROUND HANDLING

LIST OF CONTENTS

| | Para. | | Para. |
|---|-------|--|-------|
| <i>Tools and equipment</i> | 1 | <i>Picketing points</i> | 6 |
| <i>Alighting gear ground locks</i> | 2 | <i>Lashings</i> | 7 |
| <i>Towing</i> | 3 | <i>Covers and blanks</i> | 8 |
| <i>Parking and picketing</i> | | <i>Fire break-in panels</i> | 9 |
| <i>General information</i> | 4 | <i>Salvaging a crashed aircraft</i> | 10 |
| <i>Inflating the canopy seal</i> | 5 | <i>Warning pennants</i> | 11 |

LIST OF TABLES

| | Table |
|--|-------|
| <i>Picketing requirements</i> | 1 |
| <i>Aircraft covers and blanks</i> | 2 |
| <i>Tools and equipment</i> | 3 |

LIST OF ILLUSTRATIONS

| | Fig. | | Fig. |
|---|------|--|------|
| <i>Alighting gear safety locks</i> | 1 | <i>Salvaging a crashed aircraft (jacking method)</i> ... | 5 |
| <i>Towing</i> | 2 | <i>Salvaging a crashed aircraft (slinging method)</i> | 6 |
| <i>Picketing</i> | 3 | <i>Towing – adaptable tow bar</i> | 7 |
| <i>Covers, blanks and warning pennants</i> | 4 | | |

WARNING

The relevant safety precautions detailed on the **LETHAL WARNING** marker card must always be observed before entering the cockpit or performing any operations upon the aircraft.

Tools and equipment

1. For tools and equipment used in the following operations refer to Table 3.

Alighting gear ground locks (fig.1)

2. Ground locks must always be fitted to the alighting gear during ground handling. Each main undercarriage is locked by inserting a quick-release pin through a hole in the down-lock jack; the nose undercarriage is secured with a clamp-type ground lock; a warning pennant is attached to each lock.

Note . . .


Whenever a nose undercarriage malfunction is indicated or suspected, a heavy duty ground lock Ref.No.26DK/95711 should be fitted before the aircraft is moved.

Towing (fig.2 and 7)

3. The aircraft is normally towed forward, using a towing arm secured to the nose-wheel axle by an adapter. The towing arm embodies a safety-break mechanism which must be set to operate at 5500 lb (*detail A*) and locked in this position. Alternatively the aircraft may be towed using an adaptable tow bar secured to the nose-wheel axle (*fig.7*). This towing arm embodies a shear pin which fractures at 5200 lb load and is coloured green. Indication that the shear pin has fractured is provided by the appearance of a red band at the towing eye location. When the shear pin fractures, towing is to cease until a new shear pin is fitted. To ensure no damage has been caused to the nose strut lock plunger, the nose strut is to be removed and the plunger examined for distortion damage. A retraction test must be accomplished to ensure the correct functioning of the nose undercarriage lock plunger (*Sect.3 Chap.5*). Rearward towing is permissible, using a 35 ft bridle connected by shackles to towing eyes screwed into the main-wheel axles (*detail C*). The steering arm and adapter must be connected to the nose-wheel axle (*detail B*). The cockpit must always be occupied during towing, and a minimum of 2000 lb/in² hydraulic pressure must be available for braking. The minimum permissible turning radius is six feet, measured outboard (towards the wing tip) from the inner main wheel of the turn. Any smaller radius could incur damage to the main undercarriage legs.


UK RESTRICTED

RADIUS ROD




QUICK-RELEASE
PIN


MAIN-UNDERCARRIAGE GROUND LOCK
LOCATED AT KNUCKLE JOINT OF PORT
AND STARBOARD RADIUS RODS



NOSE-UNDERCARRIAGE
GROUND LOCK - FOR
USE IN THE EVENT
OF DOWNLOCK FAILURE





NOSE-UNDERCARRIAGE
GROUND LOCK - FOR
NORMAL USE



NOSE-UNDERCARRIAGE GROUND
LOCK FITTED. VIEW LOOKING AFT
IN NOSE-WHEEL WELL

FIG. 1. ALIGHTING GEAR SAFETY LOCKS



NOTE 1...
THE STEERING ARM MUST ALWAYS BE
FITTED DURING REARWARD TOWING TO
PREVENT CASTERING THROUGH 170 DEG.

NOTE 2...
BEFORE TOWING OR TURNING THE AIRCRAFT
THE NOSE WHEEL DOOR LINKAGES MUST BE
CONNECTED.





FIG. 2. TOWING

Parking and picketing

General information

4. The aircraft must be parked with all covers and blanks fitted (*Table 2 and fig.4*), the wheels chocked fore-and-aft and with brakes applied; in wet weather the canopy seal must be kept inflated (*para.5*) to prevent ingress of moisture to the cockpit. Depending upon wind velocity (*Table 1*) picketing may also be necessary. The flying control surfaces are power-operated and external locks are not required; the controls must, however, be left in the neutral position. General picketing instructions are contained in A.P.1464G, Vol.1, Part 2, Sect.5, Chap.2.

Inflating the canopy seal

5. The canopy seal inflation system (*Sect.3, Chap.8C*) incorporates an air storage cylinder which, when fully charged, contains sufficient pressure to inflate the seal five times plus an allowance to compensate for slight leakages. The cylinder is normally charged by the engine compressors at 170-190 lb/in² during engine running; for ground charging, a connection and a pressure gauge are provided behind access panel 25P the gauge being visible through a window in the panel. When the pressure falls below 30 lb/in², ◀ recharge the system using a foot pump.

Picketing points (fig.3)

6. Two main and two secondary picketing points are provided. The former are located one in each main wheel bay (*detail A*), where a hole in rib 11B accepts a shackle. The secondary points (*details B and C*) are one at the nose-

wheel fork where a hole is provided for a shackle and one aft of frame 59 on the underside of the fuselage. Removal of a plug in the skin at this point permits an eyebolt to be screwed into a threaded hole in a bracket attached to the frame.

Lashings

7. All rope lashings are of 2 in. hemp and the three chains on the picketing base are standard picketing chains secured by six shackles. The secondary lashings must be tensioned as instructed in A.P.1464G, Vol.1, Part 2, Sect.5, Chap.2, but the main lashings must be allowed slack 3 in. in excess of these requirements. The chains must have 3 in. of slack. ▶

Covers and blanks (fig.4)

8. When the aircraft is to be parked or picketed, the covers and blanks listed in Table 2 must be fitted.

TABLE 1

Picketing requirements

| Wind velocity (knots) | Picketing |
|-----------------------|------------------------------|
| 0-60 | none |
| 60-80 | secondary points only |
| above 80 | primary and secondary points |

Note...

The position of the aircraft in relation to wind direction is immaterial.

TABLE 2

Aircraft covers and blanks

| Covers | Ref/Part No. |
|-----------------------------|--------------|
| Main wheels | 27D/3091 |
| Nose wheel | 27D/3092 |
| Cockpit | 27D/3248 |
| ◀ Engine intake | 27D/3247 ▶ |
| Generator cooling duct | 27D/3920 |
| Inward vent pipe, port | 27D/3221 |
| Inward vent pipe, starboard | 27D/3222 |
| Spine | 27D/3249 |
| Pitot head | 27D/3224 |
| Jet pipe | 27D/3276 |
| Stand-by pitot head | 27D/3322 |
| I.F.F. and TACAN aerials | 26DK/95785 |
| Blanks | |
| Plug assembly, generator | |
| reheat pipe turbine | 27D/3359 |
| Blank, static vent | 26DK/95841 |

Fire break-in panels

9. Six small circular panels, coloured red, are located in the skin along the starboard side of the fuselage (*Chap.4, Table 3 and fig.2*). The panels give access to the engine bays and can be readily dislodged with the nozzles of the fire-fighting equipment.

Salvaging a crashed aircraft

10. Two methods of salvaging an aircraft are detailed in this paragraph and illustrated, together with the equipment required, in fig.5 and 6.




FIG. 3. PICKETING

RESTRICTED




FIG. 4. COVERS, BLANKS AND WARNING PENNANTS

C2020-2

RESTRICTED

Jacking method

Fit the main-plane jacking pad to the secondary jacking point as follows:-

(1) Locate the pip-pin in the under-side of the main-plane, inboard of the aft end of the undercarriage pivot.

◀ (2) Using the screwdriver-end of the pip-pin extractor, turn the grubscrew clockwise into the body of the pip-pin until the ball catches unlock

(3) Screw the bolt-end of the extractor into the threaded hole left by the grubscrew and pull to remove the pip-pin.

(4) Fit the jacking pad to the jacking point.

(5) Refer to fig.5 for the remaining jacking operations.

*Slinging method***Note...**

1. *It is not possible to sling the aircraft with overwing tanks fitted.*

2. *To sling the aircraft with the undercarriage down it is necessary to remove the main undercarriage forward fairing flaps.*

To prepare each eyebolt and rear slinging beam position:-

(1) Remove the forward fairing flap hinge bolts, disconnect the operating rod at the lower attachment and remove the fairing flap.

(2) Using the extractor, remove the pip-pins.

(3) Locate the closing plug on the upper surface of the main plane, directly above the pip-pin position, unlock the plug by turning the central screw and remove it from the main plane.

To prepare each forward slinging pad position:-

(1) Locate the junction of the leading-edge tank, outboard end, and the leading-edge panel, on the under-surface of the main plane.

(2) Count inboard to the fifth and ninth countersunk bolts securing the tank to the spar 1 (*fig.6, detail B*) and, using an Allen key, remove the bolts.

To fit the slinging bolts and beam brackets:-

(1) Insert the slinging eyebolts into the main plane slinging points (*fig.6, detail A*), with the eye-end on the top main plane surface. Note that the bolts are handed.

(2) Fit the rear beam brackets to the underside of the main planes by screwing them onto the protruding portion of the slinging bolts.

Note...

At this stage do not tighten the brackets hard up against the skin.

(3) Fix the front beam leveling pad brackets using bolts Part No. A295E outboard and A258E inboard.

To fit the slinging beams:-

(1) Ensure that the rear beam brackets are correctly aligned fore and aft, and that both front and rear brackets are tightened until the felt pads are lightly compressed against the main planes.

(2) Manhandle the port and starboard beams into position on the rear and front brackets and secure with the ½ in. dia. B.S.F. bolts and stiffnuts. ▶

(3) Tighten all fastenings and check that:-

(a) The eye-end of the slinging bolt is inclined forward facing fore-and-aft.

(b) The threaded portion of the bolt protrudes through the rear beam brackets (*fig.6, detail A*).


To assemble and attach the sling:-

(1) Attach the remaining portion of the sling assembly, consisting of the lateral beam and upper and lower cables, to the hook of the crane. The longer pair of cables must be forward when the sling is over the aircraft.


(2) Position the crane either port or

RESTRICTED


STAGE 1 LEVEL THE AIRCRAFT BY APPLYING ITEMS 5 AND SUITABLE PACKINGS AT THE MAIN AND SECONDARY JACKING POINTS, ALTERNATELY. USE ITEM 1 AT THE MAIN JACKING POINT, AND ITEM 3 AT THE SECONDARY (WING SLINGING) POINT.



STAGE 2 RAISE THE MAIN PLANES EVENLY BY ALTERNATE USE OF ITEMS 5 AND SUITABLE PACKINGS, UNTIL ITEMS 7 CAN BE POSITIONED AT THE MAIN JACKING POINTS.




| EQUIPMENT REQUIRED | | | |
|--------------------|------------|------------------------------|----------|
| ITEM | REF.NO. | DESCRIPTION | QTY. |
| 1 | 26DK/95004 | WING JACKING PAD | 2 |
| 2 | 26DK/95005 | NOSE JACKING BEAM | 1 |
| 3 | 26DK/95110 | WING JACKING PAD | 2 |
| 4 | 26DK/95139 | NOSE JACKING PAD | 2 |
| 5 | 4Q/1045836 | HYDRAULIC JACK, 8-TON | 4 |
| | 4Q/2663 | ADAPTER HEAD, MK.104 | |
| ITEM | REF.NO. | DESCRIPTION | QTY. |
| 6 | 4Q/2232 | JACK BODY, 5-TON | 1 |
| | 4Q/2261 | TRESTLE, MK.1 | |
| 7 | 4Q/1045835 | JACK BODY, 10-TON | |
| | 4Q/2294 | TRESTLE, MK.1 | 2 |
| | 4Q/2661 | ADAPTER HEAD, MK.105 | |
| 8 | | SPREADER PLATES | AS REQD. |
| 9 | | BOLSTERS | AS REQD. |
| 10 | 26DK/95088 | PIP PIN EXTRACTOR. (PARA.10) | 1 |



STAGE 3 FIT ITEMS 4 TO THE NOSE JACKING POINT AND RAISE THE NOSE, USING ITEMS 5 UNTIL ITEM 6 CAN BE POSITIONED. USE ITEM 9, AT THE NOSE UNDERCARRIAGE PIVOT PIN POSITION, TO SUPPORT THE FUSELAGE WHILE CHANGING OVER JACKS.



NOTE:- ITEM 6 TO BE USED WITH ITEM 2.




STAGE 4 RAISE THE AIRCRAFT EVENLY AND LOWER THE ALIGHTING GEAR OR, IF THIS IS NOT POSSIBLE, LOWER THE AIRCRAFT ON THE SALVAGE TROLLEY.

FIG.5. SALVAGING A CRASHED AIRCRAFT (JACKING METHOD)

5-8105-1



POSITION CRANE SQUARE TO LEADING EDGE WITH HOOK DIRECTLY OVER POINT OF LIFT



| EQUIPMENT REQUIRED | | |
|--------------------|--------------------|-----|
| REF No. | DESCRIPTION | QTY |
| 26DK/1503965 | SLING COMPLETE A/C | 1 |
| 26DK/95088 | EXTRACTOR PIP.PIN | 1 |

THESE BOLTS ARE INSERTED IN THE 5th AND 9th TANK ATTACHMENT BOLT POSITIONS AFTER REMOVING THE LATTER BOLTS




FIG. 6. SALVAGING A CRASHED AIRCRAFT (SLINGING METHOD)

◀ MOD. GE 8037 ▶

RESTRICTED

starboard as convenient and square to the main-plane leading edge.

(3) Manoeuvre the crane hook directly over the point of lift and lower the sling for connection to the slinging points.

(4) Ensure that the fastenings are secure.

To sling the aircraft:-

(1) Elevate the jib until the cables are taut and recheck that the crane hook is positioned centrally when viewed

from the front and rear of the aircraft and that in the side view the lateral slinging beam is in the correct position to impart equal tension to the four lifting cables.

(2) Chock the main wheels and start to lift.

(3) Whilst the shock-absorbers are extending check the balance of the aircraft and during the lift restrain at the nose or tail to prevent swinging. In the case of an overturned aircraft, the nose can be lifted off the ground ► using the salvaging sling fitted forward ◀

of the windscreen to support the nose between frames 4 and 6.

Note...

Damage to the upper bay structure is inevitable during this operation.

Warning pennants (fig.4)

11. Red warning pennants indicate that certain items must be either removed or fitted before flight and their use must not be interpreted as indicating a general rule that the associated system is either safe or unsafe, If in doubt refer to the relevant chapter in this Volume or to the N.C.O. in charge of servicing.



RESTRICTED

TABLE 3

Tools and equipment

| Ref.No. | Part No. | Description | Application/remarks |
|--------------|-------------|-------------------------|--|
| 26DK/95032 | EB1.88.2171 | Pin, quick-release | Main undercarriage lock |
| 26DK/95033 | EB2.88.4061 | Lock, ground | Nose undercarriage |
| 26DK/95711 | EB3.88.155 | Lock, ground | Nose undercarriage (with a downlock failure) |
| 4GB/4409994 | — | Arm, towing | Forward towing |
| 26DK/95001 | EB2.88.307 | Adapter | |
| ◀4GB/12204 | — | Tow bar, adaptable ▶ | |
| 4GB/4409986 | — | Bridle, towing 35 ft | Rearward towing |
| 26DK/95003 | EB1.88.607 | Eye, towing | Nose-wheel steering |
| 26DK/95002 | EB1.88.605 | Arm, steering | |
| 26DK/95001 | EB2.88.307 | Adapter | |
| 4G/3743 | — | Pump, foot | Canopy seal inflation |
| 26DK/95041 | EB2.88.2471 | Shackle | Main-plane picketing |
| 26DK/95040 | EB2.88.5643 | Shackle | Nose picketing |
| 26DK/95042 | EB2.88.3745 | Shackle | Tail picketing |
| 4G/1500 | — | Chains | Picketing base |
| 4G/1501 | — | Shackle | |
| 26DK/95088 | EB1.88.951 | Extractor, pip-pin | Jacking points access |
| 26DK/95110 | EB2.88.2481 | Pad, jacking | Main plane jacking |
| 26DK/95715 | EF3.88.1493 | Sling, nose | Aircraft salvage |
| 26DK/95729 | EB2.88.6785 | Bracket, rear (port) | Slinging aircraft complete |
| 26DK/95730 | EB2.88.6786 | Bracket, rear (stbd) | |
| — | EB2.88.6515 | Bracket, front (port) | |
| — | EB2.88.6516 | Bracket, front (stbd) | |
| — | EB2.88.6509 | Beam, main-plane (port) | |
| — | EB2.88.6510 | Beam, main-plane (stbd) | |
| 26DK/1503965 | EF3.88.2547 | Sling, assembly | |

RESTRICTED



NOTE . . .
BEFORE TOWING OR TURNING
THE AIRCRAFT THE NOSE
WHEEL DOOR LINKAGES MUST
BE CONNECTED





FIG. 7. TOWING - ADAPTABLE TOW BAR

RESTRICTED