

Chapter 4 GENERAL SERVICING

LIST OF CONTENTS

	Para.		Para.		Para.
<i>Introduction</i> ...	1	<i>Jacking, trestling and slinging</i> ...	6	<i>Miscellaneous drain points</i> ...	11
<i>Standard and special ground equipment</i> ...	2	<i>Access doors and panels</i> ...	7	<i>Cleaning cabin hood</i> ...	12
<i>Special tools</i> ...	3	<i>Toggle fasteners</i> ...	8	<i>Cleaning cabin</i> ...	13
<i>Order of dismantling and assembly</i> ...	4	<i>Rigging of fixed surfaces</i> ...	10	<i>Pipe lines</i> ...	14
				<i>Hot air ductings</i> ...	15 ►

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
<i>Major components</i> ...	1	<i>Access panels</i> ...	3	<i>Dorsal fin access panels attachment fixings</i> ...	6
<i>Jacking, trestling and slinging</i> ...	2	<i>Toggle fasteners</i> ...	4		
		<i>Rigging diagram</i> ...	5		

LIST OF TABLES

	Table		Table
<i>Standard and special ground equipment</i> ...	1	<i>Special tools</i> ...	2
		<i>Packing dimensions</i> ...	3

WARNING

AIRCREW EJECTION SEATS ARE FITTED
TO THIS AIRCRAFT

Before attempting to enter the cabin ensure that the instructions detailed on the LETHAL WARNING marker card at the front of the handbook have been complied with. This is very important.

ENGINE

The air intake safety guards should be fitted at all times when engine is being ground run except when it is intended to take off after running up. It is essential that personnel are aware of the air intake depression and jet efflux danger areas as shown in Sect.2, Chap.2.

RESTRICTED**Introduction**

1. This chapter contains information on the general servicing of the complete aircraft, together with tables listing the Standard and Special Ground Equipment and the Special Tools required for the operations described. This special equipment has been designed to eliminate any possibility of damage and distortion occurring during servicing and should, therefore, be used in preference to other

types of similar equipment, as otherwise the efficiency of the aircraft may be seriously impaired. When carrying out servicing operations, ensure that the air-intake and jet-pipe blanking boards are in position. Other covers or protective devices should also be fitted, provided that they do not impede the progress of the work in hand. Servicing, dismantling and lubricating information applicable to particular assemblies and installations is

covered in the appropriate chapters of Sections 3, 4, 5, 6 and 7. The servicing procedure for the standard components installed in this aircraft will be found in the relevant Air Publications listed at the beginning of this volume, or mentioned in the text.

Standard and special ground equipment

2. The ground equipment provided for use when servicing this aircraft is listed in Table 1 below:-

TABLE 1
Standard and special ground equipment

Subject	Ref.No.	Part No.	Description	No.off	Application
TOWING AND STEERING	4GB/3071	—	Arm forward steering	1	Steering from spools on nose wheel
	26FX/95612	D.218657	Adapter, towing arm	1	
	4GB/4174	—	Towing arm long Mk.2	1	Used with D.218657
	4GB/4138	—	Bridle, towing	1	Backward towing from main undercarriage
JACKING EQUIPMENT	4Q/2617	—	Jack, lifting, 5-ton	3	
	4Q/2620	—	Trestle Mk.3	2	Main jacking under wing, used with 4Q/2617
	4Q/2618	—	Trestle Mk.1	1	Main jacking under nose, used with 4Q/2617
	4Q/2655	—	Jack adapter head, Mk.102	3	For use with 4Q/2617
	4Q/2667	—	Jack, pillar, hydraulic 8-ton	1	Wheel changing, nose and main
	4Q/2807	—	Jack adapter head, Mk.113	1	For use with 4Q/2667
	26FX/95606	B.205909	Pads, jacking, wing	2	
	26FX/95607	B.208925	Pads, jacking nose	1	
	26FX/95608	A.205912	Bracket jacking nose undercarriage	1	Nose wheel changing
	26FX/95609	B.205914	Bracket jacking main undercarriage	1	Main wheel changing
TRESTLING EQUIPMENT	—	—	U.J. Trestle No.1	2	Component trestling
	—	—	U.J. Trestle No.6	4	Component trestling, wing
	26FX/95041	C.190878	Cradle, trestle, forward rear fuselage	1	
	26FX/	C.232866	Cradle, trestle, aft rear fuselage	1	

TABLE 1 - continued

Subject	Ref.No.	Part No.	Description	No.off	Application
TRESTLING EQUIPMENT (continued)	26FX/95613 26FX/95614 26FX/95020 26FX/95615 26FX/95368 26FX/95052 26FX/ 26FX/95234 26FX/95022 26FX/95023	C.220364 C.220363 C.190377 B.220361 B.206954 A.189921 A.230750 B.199253 D.194044 D.194045	Cradle, trestle, forward front fuselage Beam, trestle, rear front fuselage Crutch, trestle, centre fuselage Strut, bracing, front fuselage cradle Strut, bracing, rear fuselage cradle Clip, anchorage, nose wheel leg Link, nose wheel anchorage clip Strut, bracing, rear fuselage Cradle, trestling, wing inboard Cradle, trestling, wing outboard	1 1 2 2 2 1 1 1 2 2	For use with U.J. Trestle No.1 For use with U.J. Trestle No.1 For use with U.J. Trestle No.1 For use when removing gun installation (Mk.8 aircraft only)
SLINGING EQUIPMENT	26FX/95011 26FX/95877 26FX/95370 26FX/95049 26FX/95611 26FX/95367 26FX/95366 26FX/95014 26FX/95222 26FX/95016 26FX/95610 26FX/95720	D.188575 E.248990 D.206952 C.190378 C.220365 B.207188 C.206953 C.188900 C.199388 B.190526 D.222260 B.229927	Sling, complete aircraft Sling, aircraft salvaging, fuselage Sling, aircraft salvaging, fuselage Sling, centre fuselage Sling, front fuselage (without gun and ammunition) Sling, rear fuselage with tail unit Sling, rear fuselage less tail unit Sling, outer wing Sling, outer wing, vertical position Sling, tailplane, fin and rudder 2 Sling, windscreens Sling, cockpit canopy	1 1 1 1 1 1 1 1 1 1 1 1	Without engine With engine For use with C.220363-4
ENGINE REMOVAL AND REPLACEMENT	4GC/5377 4GC/5348 26FX/95216 26FX/95046	GM.9161 J.53558 C.200213 B.191737	Sling, engine change unit Sling engine Trolley, engine Rail, engine, detachable	1 1 1 1	Avon E.C.U. and stand Avon engine

RESTRICTED

TABLE 1 - continued

Subject	Ref.No.	Part No.	Description	No.off	Application
RIGGING EQUIPMENT	26FX/95736	D.231154	Base clinometer at tailplane	1	
	26FX/95644	C.224263	Gauge, incidence, mainplane	1	
	26FX/95006	A.192534	Gauge dihedral, mainplane and tailplane	1	
	26FX/95007	B.201624	Gauge, incidence, tailplane	1	
	26FX/95792	D.232208	Rigging fixture	1	For retaining control surfaces in neutral position
	26FX/95220	A.201222	Bar, levelling	1	
	26FX/95143	F.198704	Spigot, levelling	2	
	26FX/95633	D.228419	Board, elevator movement checking	1	
MISCELLANEOUS	26FX/95617	A.218961	Guard, safety, air-intake, port	1	
SPECIAL EQUIPMENT	26FX/95618	A.218962	Guard, safety, air-intake, starboard	1	
	26FX/95604	C.213633	Blanking cover assy, air-intake, port and starboard	1	
	26FX/95552	C.218417	Cover, jet pipe	1	
	26FX/95029	C.191636	Lock, safety, main undercarriage	2	
	26FX/95616	B.214206	Lock, safety, nose undercarriage	1	
	26FX/95303	Dunlop A.10054	Extractor, main wheel	1	
	26FX/95032	Dunlop A.5826	Extractor, nose wheel	1	
	27G/5062	Dunlop A.10039	Brake alignment fixture	1	
	26FX/95728	D.227026	Nose wheel UP microswitch setting jig	1	
	26FX/95513	B.214835	Nose wheel UP microswitch setting gauge	1	
	26FX/95508	C.210921	Nose wheel DOWN microswitch setting gauge	1	
	26FX/95733	B.227016	Nose wheel door sequence valve setting jig	1	
	26FX/-	C.235557	Hood lock jack microswitch gauge	1	
	26FX/95860	A.249091	Gauge checking main undercarriage rear lock	1	

RESTRICTED

TABLE 1 - continued

Subject	Ref.No.	Part No.	Description	No.off	Application
MISCELLANEOUS	26FX/95861	A.249092	Gauge checking main undercarriage front lock	1	
SPECIAL EQUIPMENT (continued)	—	A.204974	Wheel bay, guard for spigot	2	
	26FX/95741	C.229925	Trolley, tail empennage	1	
	26FX/95603	D.213985	Pilots ladder	2	Access to cockpit
	26FX/95421	A.214536	Position indicator, aileron booster adjustment unit	1	
	26FX/95715	A.227530	Dial spanner, aileron booster adjustment unit	1	
	27D/3082	B.214119	Weather cover, cockpit	1	
	27D/3177		Weather cover, pressure head	1	
	26FX/95217	C.200177	Weather cover, centre fuselage, port	1	
	26FX/95218	C.200178	Weather cover, centre fuselage, starboard	1	
	26FX/20089	B.K.871	Computor, weight and C.G. (with case)	1	
	26FX/95527	A.208035	Adapter for external air supply	1	For use with Air Trolley (Service Supply)
	26FX/95427	C.208502	Fuel system ground pressure testing	1	
	26FX/95725	B.230207	Strut, jury, for hood	1	To hold hood in open position.
	26FX/95727	C.230908	Cover, protection of J.B. on floor starboard	1	
	26FX/95726	C.230909	Cover, protection of J.B. on floor port	1	
	26FX/95797	C.231754	Defuelling equipment, wheels UP, assembly	1	
	26FX/	B.274018	Cover, ground, for airstream direction detector probe	1	
	26FX/20591	DGA/G/121/120	Tool, canopy release unit stop	1	
MISCELLANEOUS	4F/	—	Trolley, hydraulic servicing	1	
STANDARD EQUIPMENT	4F/1913	—	Trolley, electrical testing, Mk.4	1	
	4F/1714	—	Trolley, pressure-testing, Mk.1C	1	
	4F/1715 or 1856	—	Trolley servicing instrument Mk.1A or 1B	1	
	4G/4220	—	Trolley, oxygen charging, Mk.2	1	

RESTRICTED

TABLE 1 — continued

Subject	Ref. No.	Part No.	Description	No.off	Application
MISCELLANEOUS	4G/	—	Trolley, radar cooling and testing	1	
STANDARD	4G/4221	—	Trolley, H.P. air charging, Mk.2	1	
EQUIPMENT	4G/4342	—	Mats, main plane	2	
(continued)	◀ 4G/2051053	—	Ladder, flat top	2 ▶	
	4G/4857 or 4858	—	Trolley E.C.U. servicing Mk.1 or 2	1	
	105G/11	—	Adapter, for use with Type 37 rectifier	1	
	5P/2908	—	Rectifier, metal transportable, Type 37	1	
PICKETING AND CONTROL LOCKING EQUIPMENT	—	D.191910	Picketing fitting, main undercarriage	2	Main picketing and rearward towing from main undercarriage (embalmed aircraft only)
	—	A.191716	Picketing fitting, nose undercarriage	1	Main picketing at nose wheel (embalmed aircraft only)
	26FX/95203	F.159908	Picketing fitting, rear fuselage	1	
	26FX/95205	A.176437	Shackle, picketing, main undercarriage	2	
	26FX/95204	A.176434	Shackle, picketing, nose undercarriage	1	
	26FX/95605	B.219222	Flying controls locking gear	1	
	26FX/95137	C.189263	Aileron locking gear	2	
	26FX/95138	C.192836	Elevator locking gear	2	
	26FX/95139	B.189267	Rudder lock	1	
	26FX/95307	A.201031	Aileron and rudder rigging locks	2	
	26FX/95306	A.201030	Elevator rigging lock	1	

Special tools

3. The special tools provided for use when servicing this aircraft are given in table 2 below:-

TABLE 2
Special tools

Ref.No.	Part No.	Description	No.off
26FX/95058	A.191552	Extractor, main spar joint pins	1
26FX/95059	A.191655	Extractor, rear spar joint pins	1
26FX/95140	B.198963	Extractor, for front spar wing joint bush	1
26FX/95141	C.198962	Extractor, for rear spar wing joint bush	1
26FX/95080	B.191654	Tool for undercarriage UP lock	1
26FX/2726	A.195020	Adapter for connection of pressure gauge	1
26FX/95086	A.194464	Guide for fuel tank vent connector (also used as bung when pressure testing tanks)	2
26FX/95390	A.212332	Key for hydraulic reservoir	1
26FX/95223	B.200521	Tool for assembly of rear transport joint spigot	1
26FX/95228	Z.4948	Spanner for rear transport joint nuts	1
26FX/95308	B.204866	Spanner for front fuselage attachment nuts	1
26FX/95309	A.204865	Distance piece, special, for use at front fuselage attachment nuts	1
26FX/95087	A.194634	Spanner for Dunlop brake adjustment	1
26FX/95085	A.194578	Spanner for inverted-flight valve connection	1
26FX/95081	B.194717	Spanner for refuelling valve in forward tanks	1
26FX/95425	A.190295	Spanner for fuel system	1
26FX/95503	B.209815	Spanner for fuel system in wings	1
26FX/95504	B.209816	Spanner for fuel system in wings	1

RESTRICTED

TABLE 2 – continued

Ref. No.	Part No.	Description	
26FX/95226	A.201955	Spanner for main fuel delivery joint	1
26FX/95163	A.197766	Spanner for hydraulics in centre fuselage	1
26FX/95165	A.197767	Spanner for hydraulics in centre fuselage	1
26FX/95166	A.197768	Spanner for hydraulics in centre fuselage	1
26FX/95164	F.199124	Spanner for hydraulics in centre fuselage	1
26FX/95304	F.199406	Spanner for elevator outer hinge lock nut	1
26FX/95305	F.199407	Spanner for elevator outer hinge bolt	1
26FX/95311	A.209612	Spanner for flap hinge bolts	1
26FX/95645	B.224080	Spanner crutching for pylons	1
26FX/	F.261597	Stud for Pt.No.F.261598	8
26FX/	F.261598	Block for adjustment of undercarriage door spigot	
		Identical to items authorized by STI/Hunter/263	2

Note . . .

Special tools for gun servicing on Mk.8 aircraft are listed in Sect.7, Chap.3.

TABLE 3
Packing Dimensions (fig.1)

Component	Height	Width	Length	Weight (lb)
Nose piece	2 ft 5 in.	2 ft 8 in.	2 ft 4½ in.	20
Front fuselage	6 ft 0 in.	5 ft 1¼ in.	15 ft 5¼ in.	900
Centre fuselage	5 ft 10 in.	10 ft 0 in.	16 ft 0 in.	1425
Rear fuselage	6 ft 9½ in.	4 ft 2½ in.	17 ft 1 in.	600
Tail cone	3 ft 6½ in.	3 ft 2 in.	4 ft 1 in.	75
Wing	2 ft 1 in.	11 ft 4 in.	19 ft 8 in.	972
Rudder	5 ft 2 in.	0 ft 8 in.	2 ft 0 in.	35
Fin	6 ft 0 in.	0 ft 7½ in.	4 ft 10 in.	60
Tail plane	0 ft 6½ in.	7 ft 11 in.	11 ft 10 in.	206
Elevator	0 ft 9 in.	1 ft 11 in.	7 ft 8 in.	67½
Aileron	0 ft 5 in.	2 ft 7 in.	8 ft 8 in.	75
Flap	0 ft 5 in.	2 ft 7 in.	7 ft 6 in.	70
Wing tip	0 ft 7 in.	0 ft 11 in.	5 ft 2¼ in.	6
Hood	2 ft 4 in.	4 ft 4 in.	4 ft 10 in.	150
Ammunition box	2 ft 7 in.	9½ in.	2 ft 0 in.	40
Bullet fairing	0 ft 10½ in.	0 ft 9 in.	3 ft 5½ in.	5

Dimensions given are to the nearest quarter of an inch. The weight of a component is for a single item only.

Order of dismantling and assembly

4. The breakdown points for dismantling the aircraft are shown in fig.1. The recommended order of dismantling is as follows:-

- (1) Jack up the aircraft (fig.2) and retract the alighting gear.
- (2) Position the component trestles to fully support the aircraft.
- (3) Remove the outer wings (Sect.3, Chap.2) after removing any external stores which may be fitted.

Note . . .

The flaps, ailerons and pylons, if fitted, may be removed after the wings have been dismantled from the fuselage.

- (4) Remove the rear fuselage (Sect.3, Chap.1).

Note . . .

The rudder, elevators and tail plane (Sect.3, Chap.3) may be removed before or after the rear fuselage is removed from the centre fuselage

- (5) Remove the engine (Sect.4, Chap.1).

- (6) Remove the front fuselage (Sect.3, Chap.1).

- (7) Remove the fuselage nose portion if necessary (Sect.3, Chap.1).

5. The assembly of the principal components is, in general, a direct reversal of the procedure given in para.4.




Fig. 1. Major components

RESTRICTED

	AIR DIAGRAM 7513D/MIN HUNTER T MK 8, 8B & 8C
ISSUE 2	PREPARED BY MINISTRY OF AVIATION FOR PROMULGATION BY ADMIRALTY

13960




FIG. 2 Jacking, trestling and slinging
RESTRICTED




Fig. 3 Access panels

13962

RESTRICTED

KEY TO FIG.3 (ACCESS PANELS)

1	Radar scanner (Mk.8), General access (Mk 8B & 8C)	43	Hydraulic reservoir filler	87	Armament door (Mk.8), General access (Mk 8B & 8C)
2	Detachable nose piece	44	Rear spar pin joint & flying controls	88	Flying controls
3	Camera servicing	45	Aileron controls	89	Nose wheel jack
4	Pilot's foot step	46	Electrical connections	90	Nose wheel pivot pin
5	Control column - cabin floor	47	Aileron outer hinge	91	Radar cooling connection (ground use only)
6	Flying controls - cabin floor	48	Aileron trim tab actuator	92	Nose wheel doors
7	External emergency hood release	49	General access	93	General access
8	Hood locking & jettison gear	50	General access	94	Oxygen bottles
9	Hydraulic equipment	51	Pylon crutching	95	Gun pack (Mk.8), General access (Mk 8B & 8C)
10	General access	52	General access	96	Radio & electrical bay
11	Flying controls	53	Rocket projectile mountings	97	Fuel pump
12	Pylon crutching	54	Aileron controls	98	Detachable leading edge
13	General access	55	Sling socket	99	General access
14	General access	56	General access	100	General access
15	Navigation lamp window	57	Aileron controls	101	Fuel & air connections
16	Fuel level switches	58	General access	102	Rocket projectile mountings
17	Detachable wing tip	59	Flap jack	103	Fuel system
18	Fuel vent connections	60	Flap jack anchorage	104	General access
19	Suction relief valve	61	Flap jack greaser	105	Main spar pin joint
20	Duct to engine bleed valve	62	Flap synchronizing jack	106	Engine starter
21	Defuelling pressure connection	63	Aileron controls	107	General access
22	Cold air unit & dipstick	64	Drum switch - flap control	108	General access
23	Fairing for flying controls	65	Undercarriage jack attachment bolt	109	Gear box & gear box filler
24	Transport joint butt strap	66	Wing pin joint	110	Engine access
25	Flying controls lever	67	Sling socket	111	Gear box shaft coupling and engine mounting
26	Flying controls pivot bolt	68	Main spar pin joint	112	Oil level sighting
27	Hydraulic accumulator; pressure gauge & electrics	69	Manual undercarriage release	113	Hydraulic filter
28	Flying controls	70	Aileron booster unit	114	Igniter plug
29	Tail plane actuator	71	By-pass valve; fuel & air connections	115	Electrical connections
30	Rudder controls	72	Aileron booster unit	116	General access
31	Detachable tip	73	General access	117	Tele-briefing plug
32	Rudder controls	74	Pylon crutching	118	Tail plane actuator
33	Tail plane & elevator hinges	75	Aileron controls	119	Elevator booster unit
34	General access	76	General access	120	Detachable tail cone
35	Tail plane hinge	77	Elevator feel unit	121	Elevator lever
36	Selector valve & elevator power controls	78	General access	122	Detachable bullet fairing
37	Elevator control lever	79	Pylon crutching	123	Elevator inner hinge
38	Elevator outer hinge	80	General access	124	Flying controls & micronic filter
39	Jet pipe thermocouples	81	Main wheel bay access	125	Elevator feel unit
40	Jet pipe rear mounting	82	Brake bleed screw	126	Rudder trim tab actuator
41	Electrical connections	83	Wheel brake	127	General access
42	Electrical connections	84	Main undercarriage door	128	General access
		85	Fuel transfer pipe & pressure relief valve		
		86	General access		

Jacking, trestling and slinging

6. The methods to be employed and the jacks, trestles, etc., to be used when jacking, slinging and trestling the complete aircraft for servicing are illustrated in fig.2. It should be noted that the fuselage jacking pad has a concave bearing surface and must not be interchanged with the wing jacking pad, which has a flat bearing surface.

Note . . .


It is adviseable to check the charging of the main undercarriage legs before lowering the aircraft off the trestles (A.P.1803E, Vol.1, Sect.2).

Access doors and panels


7. The positions of the access doors and removable panels are shown in fig.3, the components to which they give access being given in the key. When handling the doors and panels, care should be taken to ensure that they are not damaged or distorted in any way. When re-fitting them, ensure that they fit flush with the surrounding surface and that they are secure and effectively locked. Screws removed from access panels must be replaced by screws of the same length, after first ensuring that fouling has not already taken place, otherwise damage to components, pipe lines or structure in the vicinity of the panel may occur.

◀ Note . . .

The screws and bolts required for the attachment of the dorsal fin panels are detailed in fig.6. ▶



normal type



arctic type

Fig.4 Toggle Fasteners

Toggle fasteners

8. Certain removable panels are secured in position by toggle fasteners (fig.4). To open these fasteners, the catch lever (1) marked PUSH is depressed with the fore-finger (*do not use tools*) causing the hook integral with this lever to disengage from pin (2) in the toggle lever (3), withdrawing it from the housing and disengaging the fastener. For re-engagement, the hooks on the end of the toggle lever are engaged in the recess and the lever pressed home with the palm of the hand. Adjustment is accomplished by screwing up or unscrewing the links (4), after first slackening off the grub screw (5) in the side face of the links. One turn of the thread on the links gives 0.036 in. of adjustment and the total adjustment available is 0.5 in. When adjustment is satisfactory, the grub screw must be re-tightened.

Note . . .

The grub screw must be slackened off before adjustment as otherwise the threads will be damaged. The grub screw must be re-tightened after adjustment.

9. Certain access doors in the under-surface of the fuselage are secured by Arctic type toggle fasteners fig.4. To open these fasteners, the knurled safety catch plate (1) is depressed and the lever (2) ejected sufficiently to enable it to be easily withdrawn from the housing

(3) For re-engagement, the lever is engaged with the housing and then pressed home with the palm of the hand. Adjustment is accomplished by removing the split pin and then screwing up or unscrewing the links. One turn of the thread on the links gives 0.036 in. and the total adjustment available is 0.5 in. When adjustment is satisfactory, lock with a split pin.

Rigging of fixed surfaces

10. When checking the alignment of the structure by means of the diagonal dimensions given in fig.5, there is no need to trestle the aircraft. When the incidence and dihedral are being checked, the aircraft must be trestled in the flying position, with the equipment shown in fig.2. The procedure for rigging is as follows:—

- (1) Check the alignment of the structure.
- (2) Jack up the aircraft and level it transversely, by means of a straight edge and spirit level placed across the fuselage side members against the windscreen arch.
- (3) Place a levelling spigot (Ref.26FX/95143) into each of the levelling points attached to the fuselage structure in the port wheel bay and level the aircraft longitudinally with a straight edge and spirit level placed across these two spigots. The trestle at frame 55 is to be adjusted to take the

weight of the rear fuselage after the aircraft has been levelled longitudinally.

- (4) Check the incidence and dihedral of the wings, using the gauges quoted in Table 1.
- (5) Check the incidence and dihedral of the tail plane, using the gauges quoted in Table 1.
- (6) When checking the variable incidence of the tailplane use a clinometer with the clinometer base Pt.No.D.231154 (fig.5). To fit the base, remove the port top tailplane fairing, locate the lugs between the front and rear tailplane spars, with the side of the base painted red facing outboard and secure to the appropriate anchor nuts normally used for the tailplane fairing.

The adjustment of the individual control surfaces is described in Sect.3, Chap.4.

Miscellaneous drain points

11. A series of small holes, extending from frame 19 (Sect.3, Chap.1) to the tail end, are provided in the undersurface of the fuselage to allow any moisture and surplus fuel which may accumulate between these frames to drain away. Surplus fuel from the high pressure cock, combustion chambers and the exhaust unit is conducted through pipes to eject at the bottom of the fuselage. All the drain holes should be inspected periodically to ensure that they are

not blocked, otherwise an accumulation of fuel, with its resultant fire may arise. Small cocks are provided at the lowest points of the fuel system, together with a drain plug in the engine fuel filter casing, to enable any water or sediment to be drained from the fuel (Sect.2, Chap.2). Moisture drain traps are also provided in the pitot installation (Sect.5, Chap.2).

Cleaning cabin hood

12. When cleaning or polishing the cabin hood, care must be taken to ensure that no rags that have been in contact with trichlorethylene are used, as rags so contaminated will cause serious damage to the surface. Refer to A.P.1464D, Vol.1, Part 2, Sect.5, Chap.5, for detailed instructions on the care of transparent plastic panels.

Cleaning cabin

13. When wiping over those portions of the instrument panels, shelves, etc., which contain labels, only clean dry rags should be used. Many of these labels will be damaged if rags impregnated with fuel, grease solvent or thinners are used.

Pipe lines


14. Before the assembly of pipe lines of the fuel system, hydraulic system and air conditioning system (*not the oxygen system*), the threads of all pipe couplings should be lubricated with anti-seize compound ZX-28G. When reassembling pipe lines, ensure that the arrows on the pipes, non-return valves and other components, point in the direction of flow. Tighten the unions by hand first and examine the lay of the pipe to ensure that the maximum clearance from other pipes, components or structure is obtained to eliminate the possibility of chafing. After final tightening, ensure that the clearance has been maintained.

RESTRICTED

LEVELLING AIRCRAFT

FOR TRANSVERSE LEVELLING, USE A STRAIGHT-EDGE ACROSS THE COCKPIT HOOD RAILS AND AGAINST THE WINDSCREEN FRAME, SEE BELOW

FOR LONGITUDINAL LEVELLING SPIGOTS ARE PROVIDED ON THE FUSELAGE SKIN IN THE PORT WHEEL BAY 4 IN. BELOW THE FUSELAGE DATUM



SYMMETRY CHECK

CHECKING POINTS

LIMITS

● TOLERANCE AT WING ROOT AND TIP \pm 0 DEG. 20 MIN.
A COMBINATION OF A POSITIVE ERROR AT ONE WING
TIP WITH A NEGATIVE ERROR AT THE OTHER MUST NOT
GIVE A TWIST OF MORE THAN 0 DEG. 25 MIN.

CHECKING POINTS	LIMITS
A — NOSE WHEEL DOOR CUT-OUT TO OUTBOARD END OF AILERON	0.50 IN.
B — OUTBOARD END OF AILERON TO OUTBOARD END OF ELEVATOR	0.50 IN.
C — UNDERCARRIAGE WHEEL HUB TO TRAILING EDGE OF FIN	0.50 IN.
D — TIP OF FIN TO OUTBOARD END OF ELEVATOR	0.25 IN

Fig. 5. Rigging diagram




Fig.6 Dorsal fin access panels attachment fixings

RESTRICTED

◀ **Hot air ductings**

15. Every opportunity must be taken to examine hot air ductings throughout the life of the aircraft, particular attention being given to the following :—

- (1) Damage to, or discolouration of, ducts, pipes, wiring or structure adjacent to hot air ductings, which may be indicative of gas leakages.
- (2) Security and condition of all duct joints.
- (3) Duct lagging for sign of damage.
- (4) Visible portions of duct metalwork, particularly in the vicinity of welds for signs of cracking. ▶

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

