

on the cables in the aircraft, but are shown in every terminal connection through which the wire may pass, by means of a label or wiring diagram. It will assist when reading theoretical and routeing diagrams to refer to the cable assembly layout in Group A.3 and to note that all positive cables are given in an even reference number, while all negative cables bear an odd number.

7. Unless indicated otherwise all the routeing and theoretical diagrams are drawn with the circuits in the condition found when the aircraft is at rest on the ground with its alighting gear down, the throttle closed, the engine stopped and electrical power off.

*Method of reading a theoretical diagram*

F.S./2

**Introduction**

1. This group contains a general description of the electrical system as a whole, together with wiring details and general servicing information. Tables

F.S./1

**Introduction**

**Description**

the switch is closed, the heater element will be supplied with current and will thus heat the pressure head.

*Method of reading a routeing diagram*

10. Routeing charts are divided into a number of columns, and all circuits commence from the fuse or circuit breaker shown in one of the shelf, panel, or termination columns. As an example of how to read a routeing chart, consider the pressure head heater circuit given in fig.2.

11. From fuse number 5, on the leg panel, the positive supply is conducted by a unipren 12 cable, referenced P.2, to terminal 2 of the pressure head switch, which is also mounted on this panel. From termi-

attached to the box. Cable assembly C7 mates with this plug and runs to the port wing plug and socket break.

13. After this break, the cable assembly number changes to P.1 and the unipren 12 cable, still referenced P.4, is connected to pin H of the socket on this cable assembly and continues to terminal 2 of T.B.22 in the port wing-tip. From this terminal the red core of the pressure head heater cable continues the supply to the heater element.

14. The negative return from the heater is the blue core. It is connected to terminal 1 of T.B.22 and a unipren 12 cable, referenced P.1 from the terminal block enters

craft. The majority of the cable assemblies are provided with fully weatherproof multi-pole plug and socket breakdown points. Whenever possible the cable connections to the plug and socket pins

cable type, together with all break points and terminations. A plug and socket connection is shown by a small semi-circle embracing a black dot; the semi-circle denotes the socket insert and the black

**Group A.1**

**SYSTEM DETAILS**

**LIST OF CONTENTS**

Para.

Para.

Para.

Radio relay box	...	...	...	...	...	...	...	26
Cabin port shelves	...	...	...	...	...	...	27	

Servicing of panels and shelves	...	44
---------------------------------	-----	----

Cable assemblies...	...	46
---------------------	-----	----

SERVICE	MAX. LOAD IN AMPS				REMARKS	MAX. FLIGHT LOAD IN AMPS				AVERAGE POWER CONSUMPTION IN AMP. MINUTES														
	CODE	LEG	PORT COCKPIT SHELF	STD COCKPIT SHELF	SUPPLY PANEL	ENGINE START TO TAKE OFF DAY	TAKE OFF TO LANDING APPROACH NIGHT	LANDING APPROACH TO ENGINE STOP DAY	10 MIN. UP TO 1/2 HOUR FLIGHT NIGHT	1/2 HOUR FLIGHT DAY	1 HOUR FLIGHT NIGHT	1 HOUR FLIGHT DAY	2 HOUR FLIGHT NIGHT	2 HOUR FLIGHT DAY	3 HOUR FLIGHT NIGHT	3 HOUR FLIGHT DAY	10 MIN. APPROACH AND LANDING NIGHT							
AILERON TRIM INDICATOR	AD	-	-	-	0.15	ON ALL THE TIME	0.15	0.15	0.15	0.15	0.15	1.50	1.50	4.50	4.50	9.00	9.00	18.00	18.00	27.00	27.00	1.50	1.50	
AILERON TRIM CONTROL	A	-	.55	-	-	OCCASIONAL USE 10% OF FLIGHT	0.55	0.55	0.55	0.55	0.55	0.55	0.55	1.65	1.65	3.30	3.30	6.60	6.60	9.90	9.90	.55	.55	
AIR BRAKE CONTROL	AB	-	1.10	-	-	IN USE FOR 15% OF FLIGHT	-	-	1.10	1.10	1.10	-	-	4.45	4.45	9.90	9.90	19.80	19.80	29.70	29.70	11.00	11.00	
A.C. SUPPLIES PANEL	CH	-	-	15.00	-	1 INVERTER ON ALL TIME & 1 ON 50% OF FLIGHT	15.00	15.00	15.00	15.00	15.00	118.75	118.75	337.50	337.50	675.00	675.00	1350.00	1350.00	2025.00	2025.00	118.75	118.75	
ARTIFICIAL HORIZON INSTALLN.	H	-	-	-	-	ON ALL THE TIME A.C. SUPPLIED FROM INVERTERS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AUTO-STABILIZER (Pn. Mod. 1026)	AS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
CABIN LIGHTING	M	-	1.60	-	-	NIGHT ONLY 75% IN USE ALL THE TIME	-	1.60	-	1.60	-	1.60	-	12.00	-	34.80	-	72.00	-	144.00	-	216.00	-	12.00
CABIN PRESSURE & TEMP. CONTL.	CP	-	3.20	-	-	ON-OFF ONCE PER FLIGHT	-	-	3.20	3.20	3.20	-	-	6.40	6.40	6.40	6.40	6.40	6.40	6.40	6.40	-	-	
CAMERA GUN G.90.	CG	4.0	-	-	-	2 AMP HEATER - 2 AMP WHILE RUNNING	2.00	2.00	2.00	2.00	2.00	2.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	
CAMERA RECORDER	C	-	0.55	-	-	ON FOR MOST OF FLIGHT	0.55	0.55	0.55	0.55	0.55	0.55	5.50	5.50	16.50	16.50	33.00	33.00	66.00	66.00	99.00	99.00	5.50	5.50
COMPASS INSTALLATION G.4F	C	-	-	-	-	ON ALL THE TIME A.C. SUPPLIED FROM INVERTERS	0.13	0.13	0.13	0.13	0.13	0.13	1.30	1.30	3.90	3.90	7.80	7.80	15.60	15.60	23.40	23.40	1.30	1.30
DROP TANK-OUTBOARD, EMPTY IND.	FC	-	-	0.12	-	ON FOR FIRST HOUR OF FLIGHT	0.12	0.12	0.12	0.12	0.12	0.12	1.20	1.20	3.60	3.60	-	-	-	-	-	-	-	-
REAR TANKS EXPLOSION SUPPRESSION	EX	-	-	-	-	A.C. SUPPLIED FROM INVERTERS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
ENGINE TEMP. CONTROL	ET	-	1.00	-	-	ON FOR 30 SEC. AT TAKE-OFF ONLY	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
ENGINE ANTI-icing	EA	-	-	1.25	-	OCCASIONAL USE 15 MIN. PER FLIGHT	1.25	1.25	1.25	1.25	1.25	-	18.75	18.75	18.75	18.75	18.75	18.75	18.75	18.75	18.75	18.75	18.75	-
LIQUID FUEL STARTER	S	-	-	-	-	DIRECT BATTERY LOAD AT START ONLY	212.00	212.00	-	-	-	28.25	28.25	-	-	-	-	-	-	-	-	-	-	-
ENGINE STARTER CONTROL	SA	-	-	-	5.90	AT START AND RELIGHT ONLY	5.90	5.90	5.90	5.90	5.90	5.90	-	-	5.90	5.90	5.90	5.90	5.90	5.90	5.90	5.90	5.90	5.90
ENGINE SPEED INDICATOR	RA	-	-	-	-	SUPPLIES ITS OWN POWER	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
FUEL LOW LEVEL	PL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
FLAP ANGLE INDICATOR	FD	-	-	-	0.01	ON ALL THE TIME	0.01	0.01	0.01	0.01	0.01	0.01	0.03	0.03	0.30	0.30	0.60	0.60	1.20	1.20	1.80	1.80	0.03	0.03
FIRE WARNING & EXTINGUISHER	FW & F	-	-	-	1.26	OCCASIONAL USE ONLY EMERGENCY	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
FUEL CONTENTS GAUGE	FC	-	-	-	4.4	ON ALL THE TIME	4.40	4.40	4.40	4.40	4.40	4.40	44.00	44.00	132.00	132.00	264.00	264.00	528.00	528.00	792.00	792.00	44.00	44.00
FUEL TANK PUMP	BP	-	-	35.00	-	ON ALL THE TIME EXCEPT FOR BALANCING	35.00	35.00	35.00	35.00	35.00	35.00	350.00	350.00	1050.00	1050.00	2100.00	2100.00	4200.00	4200.00	6300.00	6300.00	350.00	350.00
FUEL LOW PRESSURE WARNING LT.	FP	-	-	0.12	-	INDICATES LOSS OF FUEL PRESSURE	0.12	0.12	0.12	0.12	0.12	0.12	-	-	0.60	0.60	0.60	0.60	1.25	1.25	1.25	1.25	1.25	1.25
FUEL FILTER DE-icing	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
GENERATOR & ACCUMULATOR	GA	-	-	-	-	SOURCE OF ALL POWER SUPPLY REF. ONLY	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
GENERATOR FAILURE WARNING	GA	-	-	-	-	0.37 AMP DIRECT BATTERY LOAD WHEN GEN'S FAIL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.37	0.37	
GYRO-GUNSIGHT	GS	-	4.00	-	-	ON FOR MOST OF FLIGHT	4.00	4.00	4.00	4.00	4.00	4.00	40.00	40.00	120.00	120.00	240.00	240.00	480.00	480.00	720.00	720.00	-	-
GUN VENTILATION	GY	-	-	-	2.10	ON FOR 15 SEC. PER GUN BURST	-	-	2.10	2.10	-	-	-	4.20	4.20	4.20	4.20	4.20	4.20	4.20	4.20	-	-	
GUN FIRING	GF	-	-	-	4.3	ON FOR 8 SEC. PER FLIGHT	-	-	4.33	4.33	-	-	-	0.54	0.54	0.54	0.54	0.54	0.54	0.54	0.54	-	-	
HOOD CONTROL	HC	-	10.0	-	-	ON FOR TAKE OFF & LANDING	10.00	10.00	-	10.00	10.00	5.00	5.00	-	-	-	-	-	-	-	-	5.00	5.00	
HYDRAULIC POWER FAILURE	HP	-	-	0.16	-	ON ONLY WHEN HYDRAULICS FAIL	0.16	0.16	0.16	0.16	0.16	0.16	-	-	-	-	-	-	-	-	-	1.60	1.60	
JET TEMPERATURE GAUGE	ET	-	-	-	-	SELF-GENERATING	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
LANDING FLAPS	F	-	0.40	-	-	2 VALVES, 1 ON ALL THE TIME	0.40	0.40	0.40	0.40	0.40	0.40	4.00	4.00	12.00	12.00	24.00	24.00	48.00	48.00	72.00	72.00	4.00	4.00
NAVIGATION LIGHTS	N	-	2.20	-	-	ON ALL THE TIME AT NIGHT	2.20	2.20	-	2.20	-	22.00	-	66.00	-	132.00	-	264.00	-	396.00	-	792.00	-	
OIL PRESSURE GAUGE	OP	-	-	-	-	ON ALL THE TIME A.C. SUPPLIED FROM INVERTERS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
OXYGEN FLOW INDICATOR	OX	-	-	0.06	-	-	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	0.06	
POWER ASSISTED CONTROLS	PA & PE	-	1.00	-	-	ON POWER CONTROLS OFF	1.00	1.00	1.00	1.00	1.00	1.00	10.00	10.00	30.00	30.00	60.00	60.00	120.00	120.00	180.00	180.00	10.00	10.00
PRESSURE HEAD HEATER	P	6.00	-	-	-	ON ALL THE TIME	6.00	6.00	6.00	6.00	6.00	6.00	60.00	60.00	180.00	180.00	360.00	360.00	720.00	720.00	1080.00	1080.00	60.00	60.00
PRESSURE RE-FUELLING	PR	-	-	1.20	-	ON WHILE REFUELING ONLY	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
R.P. INSTALLATION	-	-	-	12.00	-	SPECIAL SERVICE SHOCK CHARACTERISTIC	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
RUDDER TRIM CONTROL	R	-	0.55	-	-	OCCASIONAL USE, 10% OF FLIGHT	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	0.55	
RUDDER TRIM INDICATOR	RD	-	-	0.15	-	ON ALL THE TIME	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	
SEPARATING LAMPS	L	0.26	-	-	0.26	NOT USED IN FLIGHT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
SUB-MIN. RADIO COMPASS	T	-	-	3.00	-	OCCASIONAL USE 50% OF FLIGHT	3.00	3.00	3.00	3.00	3.00	3.00	15.00	15.00	45.00	45.00	90.00	90.00	180.00	180.00	270.00	270.00	15.00	15.00
TAIL PLANE ACTUATOR & INDR.	TD	-	12.0	-	0.08	FREQUENT USE 30% OF FLIGHT	12.08	12.08	12.08	12.08	12.08	12.08	36.24	36.24	108.72	108.72	217.44	217.44	434.88	434.88	652.32	652.32	36.24	36.24
TURN AND SLIP INDICATOR	TS	0.25	-	-	-	ON ALL THE TIME	0.25	0.25	0.25	0.25	0.25	0.25	2.50	2.50	7.50	7.50	15.00	15.00	30.00	30.00	45.00	45.00	2.50	2.50
UNDERCARRIAGE CONTROL	UC	-	0.41	-	-	2 VALVES, EITHER ONE ON ALL THE TIME	0.41	0.41	0.41	0.41	0.41	0.41	2.00	2.00	6.00	6.00	12.00	12.00	24.00	24.00	36.00	36.00	2.00	2.00
UNDERCARRIAGE INDICATOR	U	-	0.30	-	-	ON FOR TAKE-OFF & LANDING	0.30	0.30	-	0.30	0.30	0.30	5.00	5.00	12.00	-	-	-	-	-	-	5.00	5.00	
D.M.E.	DM	-	-	-	-	ON ALL THE TIME	6.00	6.00	6.00	6.00	6.00	6.00	60.00	60.00	180.00	180.00	360.00	360.00	720.00	720.00	1080.00	1080.00	60.00	60.00
U.F.F. RADAR SET MK.10	IF	-	-	-	-	ON JUST BEFORE AIRBORNE	33.30	33.30	33.30	33.30	33.30	33.30	330.00	330.00	999.00	999.00	1998.00	1998.00	3996.00	3996.00	3994.00	3994.00	333.00	333.00
U.H.F. & STDBY U.H.F. RADIO	RT	-	-	12.00	-	ON ALL THE TIME	12.00	12.00	12.00	12.00	12.00	12.00	120.00	120.00	380.00	380.00	720.00	720.00	1440.00	1440.00	2160.00	2160.00	120.00	120.00
RADIO V.H.F. IN LIEU OF U.H.F.	RT	-	7.50	-	2 SETS, 1 ON ALL THE TIME	7.50	7.50	7.50	7.50	7.50	7.50	82.50	82.50	165.00	165.00	330.00</								

aircraft. They are, however, shown at every terminal connection in the aircraft by means of a label or wiring diagram. The code letters will also be found on the theoretical and routeing diagrams in the various groups of this chapter, because each section of a particular circuit is also referenced by a number preceded by the circuit code letters, e.g. FW2, FW4, etc. A list of the various circuits employed in this aircraft, together with their code letters and the chapters and group references of this Section is given in Table 1.

#### Cable abbreviations

16. Table 2 should be used in conjunction with the cable type and size column on the routeing charts to define the type of cable employed in the various circuits of this aircraft.

#### Loading chart and circuit index

17. This chart (fig.3) contains the loading for each circuit and remarks giving the duration of load, together with the total power available. An analysis of the maximum load and the power used during the duration of flight is also given. The chart may also be used as a circuit index as it gives the circuit letters and codes.

#### Junction box, panel, and shelf wiring diagrams

18. To facilitate servicing, each junction box, equipment panel, and shelf of this aircraft contains a diagram of its electrical

wiring. These diagrams give the cable size, terminal numbers and plug references, together with the fuse numbers, ratings and the services that they serve. A record of the modification state of the box or panel is also included on the diagram.

#### Junction, control, and distribution boxes

19. These are of welded aluminium, waterproof constructions with the insides suede finished to obviate chafing and condensation. They contain terminal blocks and certain other equipment. Junction boxes are referenced numerically, with the exception of those which are labelled according to the circuits they feed, the numbers being preceded by the letters J.B. Each box contains a wiring diagram. The terminals in the boxes are numbered and may be identified by reference to the wiring diagrams, spare terminals being starred on the diagrams to denote that they are spares. When a cable passes through a box without connecting to a terminal, the cable is wired pin to pin between its associated plugs, i.e. pin A to pin A or pin B to pin B, etc. The cable outlets on the junction boxes are either multi-pole plugs and sockets or rubber grommets.

20. Junction box 1 is the major box and is located at the bottom of the centre fuselage on the rear face of the main spar. Junction box 2 is located in the front fuselage above the cabin port shelf between frames 11 and 12 and is used mainly for distribution to the equipment

on the port side of the cabin. Junction box 3 is mounted on the engine auxiliary gearbox access door and is used to interconnect the engine starting equipment. Junction box 4 is situated in the cabin on the starboard side of the floor behind the seat, and is employed in the a.c. supplies circuit.

21. The A.C. junction box is mounted aft of the cabin starboard shelf, and is used to supply the flight instruments and radar installation. The G4F compass and autostabilizer junction box is mounted in the fin between frames 51 and 52 just above the tailplane actuator, and is used to feed the G4F compass and the auto-stabilizer circuits. The power controls junction box is located in the front fuselage, on the starboard side under the cabin floor between frames 11 and 12, being mounted on the aft end of the cabin well. It contains a terminal block and fuses, which are part of the elevator and aileron power control circuit.

22. The R.P.J.B. is located on the forward face of the starboard fuel tank access panel on frame 19, above the battery platform. The bomb/R.P. release and camera J.B. is mounted aft of the cabin port shelf. The bomb/R.P. selector J.B. is mounted in the fairing aft of the hood. All these junction boxes are used as breakdown and distribution points for the armament services.

TABLE 1

## Circuit codes and group references

Circuit	Code	Chapter	Group	Circuit	Code	Chapter	Group
A.C. supplies	CH	1	E.1	Exhaust gas thermometer			
Aileron trim controls	A	1	D.1	and top temperature			
Aileron trim indicators	AD	2	3.B	control	ET	2	2.B
Aileron power controls	PA	1	D.2	Fatigue meter	FM	2	5.A
Alighting gear control	UC	1	D.7	Fire warning	FW	1	C.2
Alighting gear control	U	2	5.A	Fire extinguisher	FE	1	C.2
Air brake control	AB	1	D.7	Flap control	F	1	D.4
Artificial horizon	AH	2	3.B	Flap position indicator	FD	2	3.B
Autostabilizer( <i>Pre Mod. 1026</i> )	AS	1	D.9	Fuel content gauges	FC		2.A
Bomb fusing and SSD				Fuel filter de-icing	EFD	1	C.5
control	BF	1	G.1	Fuel transfer pressure			
Bomb jettison and drop				warning	FP	2	2.A
tank jettison	BJ	1	G.1	Fuel low level warning	FL	2	2.A
Bomb release	BR	1	G.1	Generators and batteries	GA	1	B.1
B <sup>+</sup> distribution	B <sup>+</sup>	1	B.1	Gyro compass	GC	2	3.B
Cabin lighting	M	1	F.1	Gyro gun sight and			
Cabin pressurization				camera recorder	GS	2	4.A
and temperature				▶ ◀			
control	CP	1	D.6	Gun firing	GF	1	G.1
Camera gun	CG	1	G.1	Gun ventilation	GV	1	G.1
D.M.E. radio	DM	1	H.1	Hood control	HC	1	D.5
Drop tank empty warning	FC	2	2.A	Hydraulic pressure			
Drop tank jettison	BJ	1	G.1	warning	HP	2	5.A
Explosion suppression ( <i>Pre Mod. 1271</i> ) EX	1		C.6	I.F.F. radio	IF	1	H.1
Ejector release	BR & BJ	1	G.1	L <sup>+</sup> distribution	L <sup>+</sup>	1	A.1
Engine anti-icing	EA	1	C.4	Navigation lamps	N	1	F.2
Engine starting and control	S & SA	1	C.1	Oil pressure gauge	OP	2	2.C
Elevator power controls	PE	1	D.2				

RESTRICTED

T.P. (E) 9185

TABLE 1  
Circuit codes and group references (Continued)

Circuit	Code	Chapter	Group	Circuit	Code	Chapter	Group
Oxygen flow indicator	OX	2	5.A	Spare wiring	*	1	A.1
Pressure head heater	P	2	3.A	Tachometer	RA	2	2.C
Pressure refuelling	PR	1	C.3	Tail plane control	T	1	D.3
Parachute brake	TC	1	D.8	Tail plane position indicator	TD	2	3.B
Radar ranging	RS	1	H.1	Tank pumps	BP	1	C.3
Radio compass	RC	1	H.1	Target towing	TT	1	G.2
R.P. firing	RP	1	G.1				
Rudder trim controls	R	1	D.1	Turn and slip indicator	TS	1	3.B
Rudder trim indicators	RD	2	3.B				
Service lamps	L	1	F.3	V.H.F. and U.H.F. radio	RT	1	H.1

TABLE 2  
Cable Abbreviations

Abbreviation	Definition	Abbreviation	Definition
U/P	Unipren	D/PM	Duprenment
D/P	Dupren	T/PM	Triprene
T/P	Tripen	U/NYP	Uninypren
D/P SHEATH	Duprensheat	U/FIRE	Unifire
T/P SHEATH	Tripensheat	D/CS	Ducralsil
Q/P SHEATH	Quinprensheat	D/CV	Ducralvin
U/PM	Uniprenmet	MIN.2C etc.	Miniature cables 2C (etc.)

23. The A.C. distribution box is located on the starboard side of the cabin aft of the pilot's seat and is mounted on the upper surface of the longeron tie member at frame 13. Internally it contains terminal blocks and fuses, while mounted on the lid, externally, is a suppressor. Its function is to distribute the a.c. supply to the engine temperature control and the autostabilizer circuits. The top temperature a.c. control box is mounted on the port side of the front fuselage at frame 17A in the radio bay above the radio sets. It contains a torque switch and relay, both of which are employed in the engine top temperature control circuit. The air-

Brake relay control box containing the relays employed in the airbrake control circuit, is situated in the cabin over the port shelf between frames 10 and 11.

#### **Leg panel**

24. This panel is in the form of a box, being bolted to the cabin floor, below the centre instrument panel and just forward of the control column. It is provided with a hinged door on the port side and a sloping plate carrying the plugs for the cable assemblies on its forward face. The rear face carries the oil pressure gauge, generator power failure warning lamps, ignition and starter switches, together with the gyro gun sight circuit breaker and a number of control switches. The box contains relays, terminal blocks and fuse blocks, these latter components being mounted on the inside face of the door for easy accessibility.

#### **Generator control and supply panels**

25. These two panels are located together between frames 16 and 19 on the starboard side of the radio bay in the front fuselage. The supply panel is outboard of the generator control panel and is curved to conform with the inside contour of the fuselage skin, being attached by studs on frames 17 and 18, which engage with channel members on the panel. The panel carries a number of terminal blocks, fuse boxes and relays, together with plugs for the cable assemblies to and from the panel.

The generator control panel is hinged to the top longeron and fits over the supply panel to form a lid, being attached to the latter panel by four Dzus fasteners along the lower edge. The panel contains all the generator control components, fuse boxes and testing equipment. When raised for access to the supply panel, the generator control panel may be retained in the up position by a hook attached to a length of chain secured to the radio mounting structure.

#### **Radio relay box**

26. This box is mounted on the underside of the top radio mounting structure and contains the radio supply fuses and control relays, together with a number of plugs for the radio connectors to and from the box. For further details of this box, reference should be made to Sect.6, Chap.1 of this volume.

#### **Cabin port shelves**

27. The cabin port shelf, as a whole, extends between frames 8 and 12, and the two portions about to be described form removable parts of this structure. The forward portion is located just inboard of the throttle lever at the forward end of the structure, while the rear portion extends aft from just behind the throttle lever to the end of the structure. Each portion is attached to the fixed structure by a number of screws and Dzus fasteners and is in the form of a panel with a side member. The rear portion is also provided with an end plate which carries the plugs for connection

with the cable assemblies to and from this shelf. The panels carry the radio controllers, control switches, warning lamps and indicators, while below a hinged door, in the top surface of the rear portion, are a number of terminals and fuse blocks supplying the equipment.

#### **Cabin starboard shelf**

28. This shelf, of which the removable portion about to be described is the major part, extends between frames 8 and 12. The removable portion is attached to the fixed structure by a number of Dzus fasteners and is in the form of a panel with a side member and end plate. The end plate carries the plugs for the cable assemblies to and from the shelf and the panel incorporates a number of switches and circuit breakers, together with the fuel content gauges. Below a hinged door, at rear end of the panels are a number of fuse and terminal blocks supplying the equipment.

#### **Gun-firing panel**

29. This panel is bolted below the radio mounting structure on the port side of the front fuselage and carries the gun-firing equipment, consisting of a number of relays, together with terminal and fuse blocks supplying the equipment.

#### **Cable assemblies**

30. These consist of a number of cables assembled together, most of which are fitted at each end with multi-pole plugs or sockets. The assemblies are referenced

numerically, the number being prefixed with a letter denoting their location in the aircraft, or with special circuits, the service which they supply. Front fuselage cable assemblies are prefixed by the letter F, centre fuselage assemblies by the letter C and rear fuselage assemblies with the letter R. Cable assemblies in the port wing are prefixed by the letter P, while those in the starboard wing carry the letter S. The artificial horizon, GM-4F compass and armament cable assemblies are prefixed with the letters AH, GC and A respectively. The cable assemblies in the engine bay hot zones consist of Nypren insulated cables.

#### Cables

31. The ends of each cable are identified, in one of two ways, by means of rubber sleeves. At the equipment, the sleeve gives the item and terminal to which the cable core is connected, while at the terminal blocks the sleeve gives the equipment and terminal from where the cable core originated. For the type of cable employed in the various circuits, reference should be made to the routeing diagrams and the table of cable abbreviations.

#### Multi-pole plugs and sockets

32. Plessey standard and pressure-proof plugs and sockets, together with the Mk.4 miniature types, are used on the cable assemblies, junction boxes and panels, etc. These are fully described in A.P.

4343C, Vol.1, Book 3, Sect.5, Chap.1 and 8, and consist of internal mouldings, holding the plug pins and socket inserts, which float in fully weather-proof metal housings. The plug pins and socket inserts are each identified by a letter or number on the internal moulding and are arranged in a pattern so as to prevent incorrect assembly with their associated component, thus preventing cross-connection or short-circuiting.

33. Those plugs and sockets fitted to cable assemblies outside junction boxes and panels etc., are provided with rubber sleeves and bungs, which seal the cable entry to prevent the ingress of moisture. The sleeves and bungs are retained in position by inner and outer ferrules locked by a coupling nut. Each socket may be identified by the cable assemblies to which it is attached, the reference being printed on the rubber sleeve or P.V.C. conduit. Each plug is also identified by its associated cable assembly reference or colour which is painted on the junction box or panel to which the plug is attached. Where two or more identical plugs or sockets are situated together, they are coloured for easy identification.

#### Fuses

34. The circuit fuses are contained in quick-release fuse blocks in the A.C. junction box and attached to the various panels and cabin shelves carrying the electrical equipment. They are referenced

A.P.101B-1307-1, Sect.5, Chap.1, Group A1  
A.L.208, Sept.74.

numerically, each panel and shelf having its own series of numbers. In most instances, these numbers, together with the fuse rating and the code letters of the circuit it serves, appear on the associated wiring diagram in the box concerned. In certain instances this information is given on a photographic label attached to the appropriate fuse block. The majority of the fuses are of the type S series, but a few Type 33 fuses are used on the gun firing panel and reference should be made to Table 3 for the rating and fuse numbers. The fuses should be examined periodically to ensure that they are serviceable and of the correct value.

#### Circuit breakers

35. All the circuit breakers, apart from those on and below the generator control panel and that on the gun-firing panel, which are located in the radio bay, are accessible from the cabin. They are not referenced, but may be identified by the name of the circuit which they protect, this being given adjacent to each breaker. Table 4 lists the circuit breakers together with their ratings and References.

#### Relays

36. The relays are located in the junction boxes and on the various panels and shelves carrying the electrical equipment. They are referenced alphabetically, the letters being given adjacent to each unit and on the wiring diagrams.

#### Terminal blocks

37. Apart from those inside junction

TABLE 3 - FUSES

Location	Fuse	Size (Amp.)	Service	Location	Fuse	Size (Amp.)	Service
Supply panel	1	2.5	Hydraulic pressure warning	A.C. junction box	1	-	Dummy
"	2	10	Ignition (starboard)	"	2	2.5	Compass d.c. bias
"	3	10	Ignition (port)	"	3	5	Altimeter inverter d.c. supply
"	4	2.5	Engine top temperature control.	"	4	10	No.2 inverter supply
"	5	2.5	Service lamps	"	5	2.5	Radar ranging blue phase
"	6	5	IFF/SSR relay	"	6	2.5	Radar ranging red phase
"	7	2.5	Flap position indicator	"	7	5	Radar ranging d.c. bias and indicator
"	8	5	Pressure refuelling	"	8	2.5	Main altimeter supply
"	9	5	Fire warning	"	9	2.5	Oil pressure blue phase
"	10	10	Fuel filter de-icing	"	10	2.5	Temperature amplifier blue phase
"	11	5	Fuel filter de-icing	"	11	2.5	Artificial horizon blue phase
"	12	5	IFF/SSR test socket	"	12	2.5	Compass blue phase
"	13	10	IFF/SSR relay	"	13	2.5	Oil pressure red phase
"	14	2.5	Tail plane position indicator	"	14	2.5	Temperature amplifier red phase
"	15	2.5	Aileron trim indicator	"	15	2.5	Artificial horizon red phase and vibrator unit
"	16	2.5	Rudder trim indicator	"	16	2.5	Compass red phase
"	17	5	IFF/SSR transponder	Cabin port shelf	1	-	Dummy
"	18	5	IFF/SSR relay	"	2	2.5	Alighting gear control
"	19	10	Gun firing	"	3	5	Gyro gun sight
"	20	5	R.P. reset	"	4	-	Dummy
"	21	5	Fuel content gauges	"	5	5	Tail plane control
"	22	5	Fuel content gauges	"	6	20	Tail plane control
"	23	2.5	Tank pumps	"	7	2.5	Tail plane control
"	24	2.5	Tank pumps	"	8	10	Tail parachute control
"	25	20	Fire extinguisher	"	9	5	Aileron power controls
"	26	5	Fire extinguisher	"	10	5	Hood control
"	27	10	Target towing (Mod.1046 only)	"	11	2.5	Aileron trim control
"	28	5	Target towing (Mod.1046 only)	"	12	-	Dummy
"	29	5	Power controls	"	13	-	Dummy
"	30	2.5	Oxygen regulator				
"	31	2.5	Artificial horizon				
"	32	5	Elevator power controls				

RESTRICTED

T.P.(E) 22987

TABLE 3 - FUSES (Continued)

Location	Fuse	Size (Amp.)	Service	Location	Fuse	Size (Amp.)	Service
Cabin port shelf	14	—	Dummy	Generator control			
"	15	—	Dummy	panel	1	5	Generator test socket No.2
"	16	—	Tail parachute control	"	2	5	Generator test socket No.2
"	17	5	Engine top temperature control	"	3	5	Generator test socket No.1
"	18	2.5	Alighting gear indicator	"	4	5	Generator test socket No.1
"	19	5	Alighting gear control	"	5	5	Power failure indicator No.2
"	20	5	Flap control	"	6	5	Power failure indicator No.1
"	21	5	Cabin pressurization control	"	7	10	A.C. supplies
"	22	5	Cabin pressurization control	"	8	—	Dummy
"	23	5	Cabin pressurization control	Leg panel	1	2.5	Nose wheel bay service lamp
"	24	5	Airbrake control	"	2	10	Fire extinguisher
Cabin starboard shelf	1	5	Navigation lamps	"	3	2.5	Turn and slip indicator
"	2	5	Fuel low level indicator	"	4	2.5	Turn and slip indicator
"	3	2.5	Port outboard drop tanks	"	5	10	Pressure head heater
"	4	2.5	Starboard outboard drop tanks	"	6	10	G.90 camera gun
"	5	2.5	Cabin panel lamps	"	7	—	Dummy
"	6	2.5	Cabin lamps (starboard)	"	8	—	Dummy
"	7	2.5	Cabin lamps (port)	"	9	—	Dummy
"	8	5	Engine anti-icing	"	10	—	Dummy
"	9	2.5	Fuel pressure	"	11	—	Dummy
"	10	10	A.C. supplies	"	12	—	Dummy
"	11	5 HRC	IFF/SSR (Mod.1369)	"	13	5	Engine starter
"	12	5	Radio compass	"	14	2.5	G.G.S. caging
"	13	—	Dummy	"	15	20	Engine starter
"	14	5 HRC	IFF/SSR (Mod.1369)	Bomb/R.P. selection	16	—	Dummy
"	15	2.5	Fuel contents	Junction box	1	5	Tail fuzing
"	16	2.5	Fuel contents	"	2	5	Nose fuzing

TABLE 3 - FUSES (Continued)

Location	Fuse	Size (Amp.)	Service	Location	Fuse	Size (Amp.)	Service
A.C. distribution				Radio relay box	10	-	Dummy
box	1	-	Spare	"	11	-	Dummy
"	2	2	Engine top temperature control	"	12	2.5	Set selection
"	3	2	Engine top temperature control	Gun firing panel	1	2 H.R.C.	Starboard outer gun
"	4	-	Spare	"	2	2 H.R.C.	Starboard inner gun
"	5	-	Spare	"	3	2 H.R.C.	Port inner gun
				"	4	2 H.R.C.	Port outer gun
				"	5		Gun ventilation
Radio relay box	1	10	Standby battery supply	"	6	5	Gun selection
"	2	5	Tele-briefing	Tail cone front former	0.5		Parachute brake test circuit
"	3	20	Standby set supply <i>(Dummy when V.H.F. is fitted)</i>	Power controls			
"	4	-	Dummy	Junction box	-	2.5	Elevator indicator
"	5	10	Test Circuit	"	-	2.5	Aileron indicator
"	6	-	Dummy	Target towing			
"	7	-	Dummy <i>(20 amp. when V.H.F. fitted)</i>	control box	1	10	Port release unit
"	8	-	Dummy <i>(20 amp. when V.H.F. fitted)</i>	"	2	10	Port release unit
"	9	10	Standby set supply	"	3	10	Starboard release unit
				"	4	10	Starboard release unit
				Top instrument panel	-	7	Target towing

boxes and on the panels carrying electrical equipment, terminal blocks are also used as distribution and breakdown points throughout the aircraft. These are of the Plessey quick-release 2, 3, 5, 10 and 20-way types together with a few Air Ministry 2 and 3 way types. The blocks are referenced numerically, the numbers being preceded by the letters T.B. Each terminal carries a coding plate on which is marked the terminal numbers quoted in the wiring diagrams. The terminal blocks may be located

on the cable assembly layout and location diagrams contained in Group A.3 of this chapter.

◀ Note . . .

*Terminal Blocks 11, 22, 24, 32, 42, 43, 44, 45, 46, 47, 48, 73, 79, 87, 97, 98 should not be fitted with perspex covers (introduced by STIs 182A and 262).*

**Filament lamps**

38. When renewing filament lamps, reference should be made to Table 5 to ensure that the correct type is used.

**Earth points**

39. Apart from the guns, engine starter, inverters, suppressors and radio sets, which are earthed internally or adjacent to their mountings, all the other earth leads are grouped, for ease of servicing and in-

**RESTRICTED**

F.S./8

sulation resistance testing, and connected to the aircraft structure a number of stud-type main earth points. All the main earth points are numbered and may be located on the cable assembly layout in Group A.3 and on the supply and earth routeing chart (fig.1) of this group.

**SERVICING****External supply socket**

40. This is mounted on the battery support structure below the batteries; access is gained by opening the radio access panel. It is used to connect an external supply to the aircraft services by means of a standard plug and it is most important that, when servicing, the external supply is used to prevent the aircraft batteries from being discharged. When the external supply is in use, the generators are automatically isolated to prevent a reverse feed (Group B.1) and it is recommended that the battery master switch, located on the leg panel, is placed in the OFF position to prevent discharge of the aircraft batteries should the external supply voltage fall below that of the batteries.

**Rendering aircraft electrically safe**

41. When not required for flight, and during any servicing operations not requiring the electrical supply, the aircraft must be rendered electrically safe to eliminate the possibility of a short-circuit resulting in the accidental operation of the guns, hydraulic units, etc., with consequent damage to the aircraft or injury to person-

*A.P.101B-1307-1, Sect.5, Chap.1, Group A.1  
A.L.203, Feb.74*

**TABLE 4**  
**Circuit Breakers**

Circuit	Rating (Amp)	Ref.No.
Gun-firing panel	5	5CY/2559
Parachute brake	6	
Gun sight	10	5CY/2560
No.1 generator, field	15	5CY/2561
No.2 generator, field	15	5CY/2561
D.M.E.	10	5CY/2560
Flight instrument control		
Normal	15	5CY/2561
Stand-by	15	5CY/2561
Tail plane control	24	5CY/5312
Hood Control	15	5CY/2561
U.H.F. main supply (ARC.52)	25	5CY/ 9992777
Tank pumps	25	5CY/2562
	25	5CY/2562
Armament supply	45	5CY/2564
R.P. Service	18	5CY/5330
Bomb service	12	5CY/5311
Guns service	12	5CY/5311
Jettison 1 service	12	5CY/5311
Jettison 2 service	12	5CY/5311
Engine starting	45	5CY/2564
U.H.F. services	45	5CY/2564
Radar ranging	45	5CY/2564
► I.F.F. (pre Mod.1369 only)	45	5CY/2564 ►
No.1 generator, main	200	5CY/2853
No.2 generator, main	200	5CY/2853

nel... When electrical power is required, during servicing, an external supply should

be used. To render safe, it is recommended that the leads from the batteries be disconnected, as operation of the battery master switch will not render the system completely safe. Also ensure that the external supply is disconnected.

**Servicing of junction, distribution and control boxes.**

42. A regular examination of these boxes should be carried out to ensure that they are correctly supported, clean and undamaged. All the components in the boxes should also be examined for security and an examination of the wiring and terminals made for damage and corrosion.

43. The boxes are provided with readily detachable lids and have been designed for ease of removal, being supported on quick-release mountings. When major servicing is necessary, it is recommended that the boxes are removed from the aircraft and replaced with fully serviced components, thus reducing the time in which the aircraft is unserviceable. The faulty boxes should then be made serviceable, on the bench, and returned to store to be held as spares. The method of removing the boxes is described in Group A.2 of this chapter.

**Servicing of panels and shelves**

44. The equipment panels and cabin shelves should be regularly examined to ensure that they are correctly supported, clean and undamaged. All the components should likewise be examined for security, and an examination of the wiring and

TABLE 5  
Filament Lamps

Lamp	Circuit	No.off	Voltage	Wattage	Ref.
Failure warning	IFF/SSR	1	28	3.5	5L/9951273
Parachute indicator	Parachute brake	2	28	3.5	5L/9951273
Power failure warning	Generators and batteries	2	28	3.5	5L/9951273
Fuel pressure warning	Fuel pressure	1	28	3.5	5L/9951273
Cabin pressure warning	Cabin pressurization and temperature control	1	28	3.5	5L/9951273
Alighting gear indicator	Alighting gear indicator	9	28	2.5	5L/9951286
Alighting gear warning	Alighting gear indicator	1	28	3.5	5L/9951273
Ultra-violet lamps	Cabin lighting	2	12	7.5	5L/9952261
Red lamps	Cabin lighting	9	24	2.8	5L/9951263
Red stand-by lamps	Cabin lighting	2	24	2.8	5L/9951263
Wing-tip navigation	Navigation lamps	2	28	24	5L/9952431
Tail navigation	Navigation lamps	1	24	10	5L/9952276
Service lamps	Service lamps	2	24	6	5L/9952254
Gun sight	Gun sight	4	22	12	5L/9951260
Radar locked-on and range	Gun sight (Post Mod.378 and 700 only)	2	28	1.1	5L/9959118
Hydraulic pressure	Hydraulic pressure indicator	1	28	3.5	5L/9951273
U.H.F. control	U.H.F.	2	28	1.1	5L/9959118
Tele-briefing	U.H.F.	1	28	3.5	5L/9951273
Radar locked-on	Radar ranging and supply	1	28	3.5	5L/9951273
Fire warning	Fire warning and extinguisher	1	28	3.5	5L/9951272
Refuelling indicator	Pressure refuelling	6	24	2.4	5L/9959211
Tank pump	Tank pumps	2	28	3.5	5L/9951273
E.2B compass	Cabin lighting	1	28	1.1	5L/9959121
Fuel low level	Fuel contents	2	28	3.5	5L/9951273

terminals made for signs of damage and corrosion. The Dzus fasteners securing these panels and shelves should also be examined to ensure that they are correctly engaged and not damaged or distorted in any way, paying particular attention to the springs. Any fasteners found to be unlocked must be re-engaged and any found defective renewed as described in the relevant equipment servicing A.P.

45. When major servicing is necessary to these panels and shelves, it is recommended that they are removed from the aircraft and replaced with fully serviceable components, thus reducing the time in which the aircraft is unserviceable. The faulty panel or shelf should then be serviced, on the bench, and returned to store to be held as a spare. The method of removing these components is given in Group A.2 of this chapter.

#### Cable assemblies

46. A periodical examination of the cable assemblies should be made for signs of oil soaking and to ensure that they are properly supported and not chafing, cut or damaged in any way. Damaged cables must be renewed or repaired as described in the relevant equipment servicing A.P., and all slack support-clips retightened.

#### Multi-pole plugs and sockets

47. The plugs and sockets should be examined periodically for signs of corrosion which, if found, must be removed.

When removing corrosion, care must be taken not to damage the plated surface of the plug pins or socket inserts or early re-corrosion will result. The importance of cleanliness and the need for regular lubrication of the plug and socket screw threads cannot be over-emphasized if seizing of these threads is to be avoided. Grease MS-4 (Ref. 33H/9424829) is to be used and the excess wiped off. On no account should a lubricant with a graphite base be employed. When it is required to examine or service the cable connections to plugs and sockets incorporating rubber sleeves and bungs, access may be gained by releasing the sleeve at the coupling nut and rolling it back until clear of the connections.

#### Circuit breakers

48. The interior of the circuit breakers is inaccessible and servicing is therefore restricted to the functional and insulation tests given in A.P.4343B, Vol.1, Book 2, Sect.10, Chap.6.

#### Note . . .

The starter and booster pump circuit breakers and those below the generator control panel are fitted with rubber packing at their mountings to prevent tripping due to vibration (S.T.I/Hunter/290). When replacing these circuit breakers ensure that this packing is re-fitted.

#### Dummy fuses

49. Dummy fuses are fitted in NOT IN USE circuits to prevent inadvertent operation of the circuit. These fuses, in red

plastic, are identifiable by feel by their square section centre and corrugated sides. One side is embossed "NOT IN USE". Whenever a live fuse is removed while servicing it is to be temporarily replaced by a dummy fuse fitted with a 9 inch by 1 inch streamer. Dummy fuses are referenced:-

2 amp. size fuse dummy	10H/21790
2.5 amp. size fuse dummy	10H/21791
5 amp. size fuse dummy	10H/21792
10 amp. size fuse dummy	10H/21793

#### Relays

50. Relays should be inspected at regular intervals to ensure that the contacts are kept clean and that the units are undamaged and secure. They should also be subjected periodically to the functional test given in A.P.4343C, Vol.1, Book 2, Sect.3.

#### Note . . .

Relays that are operating correctly are best left alone and it is, therefore, recommended that the covers are not removed or the contacts cleaned, unless absolutely necessary.

#### Switches

51. The switches employed in this aircraft are sealed units and cannot be readily dismantled for servicing, they should, however, be examined for cracks and signs of strain, paying particular attention to the

switch dollies.

#### Insulation resistance testing

52. As an interim measure, pending the introduction of a full insulation resistance test, the following procedure, which only covers the minimum requirements, should be carried out.

- (1) Remove all lamps.
- (2) Disconnect the inverters.
- (3) Disconnect earth points (1 to 20).
- (4) Remove the white compass plug from the A.C. junction box.
- (5) Remove the red and green radar plugs from the A.C. junction box.
- (6) Remove the plugs from the fire extinguishers.
- (7) Remove the supply plug to both fuel contents gauge amplifiers.
- (8) Disconnect the gun sight suppressor F5.
- (9) Remove the voltmeter, if this has been fitted.
- (10) Remove the lamps from the Type A cut-outs.
- (11) Bridge all other suppressors.
- (12) Remove the engine igniter plugs.
- (13) Disconnect the Rebecca Mk.8
- (14) Place all switches to the ON position.
- (15) Connect a 250-volt insulation resistance tester to positive terminal and to an earth point of the aircraft.

#### Note . . .

It is not necessary to disconnect the suppressors if an insulation resistance tester, Type C (Ref. No. 5G/152) is used.





Fig.4 Available spare wiring

RESTRICTED






Fig.6. Available spare wiring-Armament (wings and pylons)

RESTRICTED

T.P. (E) 9192

**Bonding checks**

53. It is not required to carry out bonding checks on those parts of the airframe, or airframe systems which are capable of movement, or of being moved over an electrically conductive bearing (e.g. control columns, rudder bars, etc.), physical examination that these items are correctly bonded being sufficient. The following items should, however, be checked using a Safety Ohmmeter Ref.5G/1006388 or other suitable Safety Ohmmeter:-

- (1) Metal frames of radio and radar equipment.
- (2) Aerial mounting brackets
- (3) Electrical control and distribution panel.
- (4) Fuel pipelines
- (5) Hydraulic pipelines.
- (6) Engine.
- (7) Jet pipe.

With the battery master switched OFF and the external supply disconnected, check each item from an aircraft main earth point. The maximum permissible resistance is 4.5 ohms.

**Use of spare cables for emergency servicing**

54. Fig.4, 5 and 6 show the spare cables available in the cable assemblies. These are provided for future modifications and additions to the existing installations, but may also be used, in an emergency, to replace a defective cable. Under this

condition, having found the defective portion of cable, refer to the spare wiring figures to find a similar cable, which can be used. At suitable points, modify the existing cable run to use the spare cable and isolate the defective cable. Amend the junction box, panel and shelf wiring diagrams to agree and note the fact of this change in the aircraft log book, with the instruction that the cable assembly containing the defective cable must be changed or repaired at the next available opportunity. ►

**Note . . .**

*The above procedure is only to be adopted as a temporary measure to keep the aircraft operational and must not be allowed to carry on indefinitely.*

**Electrical cables on throttle lever**

55. The engine throttle lever carries the gyro gun sight ranging twist grip control unit, which incorporates the radio press-to-transmit and air brake control switches. The cables from these switches are clamped to the throttle lever and pass through a grommet in the cabin port shelf. To avoid accidental operation of the hood control switch due to fouling by these cables, it is important that all excessive slack be eliminated as follows:-

- (1) With the throttle lever fully forward i.e. throttle open, draw the cables through the grommet on the cabin port shelf so that all slack between the throttle lever and grommet is taken up. Care must be taken during

this operation to avoid kinking the cables at the clamp block on the throttle lever.

- (2) Reposition the cable strapping to clear the guard on the hood control switch box.


**Main undercarriage electrical cables-replacement**

56. When replacing the electrical cable looms from the compression microswitches on each main undercarriage leg, as called for during Major Servicing, the following points must be observed:-



- (1) The run and strapping of the cables is to be in accordance with fig.7. ►
- (2) Uninyvin 20 cable must not be used in this connection, because of its lack of flexibility. Unintersil 20 cable should be used.
- (3) Hellerman Twin Grip Ring Tags (Ref. 5X/7553) should be fitted to the cable terminations at the microswitches when the cable looms are changed.

**REMOVAL AND ASSEMBLY****Disconnection of sockets**

57. Before an attempt is made to remove a Plessey standard or pressure-proof socket from its associated plug, the coupling nut, retaining the sleeve and bung or ferrule and P.V.C. assembly to the socket, must be slackened. This is necessary as




PORT LEG




DETAIL OF STD. 840 CLIP  
MAKE FROM 22 G. L.A.

STD. 840.13 L=1.3 IN.  
STD. 840.20 L=2.0 IN.  
HOLES MORSE No.10



STARBOARD LEG



CABLES TO PASS ON OUTBOARD  
SIDE OF HYDRAULIC PIPES AND  
TO BE STRAPPED TO ONE OF THEM

CABLES CLIPPED TO SWITCH AT TOP FORWARD HOLE IN  
SWITCH USING CLIP STD. 840.13 BOLT A.25.10.B.  
NUT AGS.2002. B.I. AND  
WASHER S.P.15.B.  
(ON OUTSIDE OF SWITCH).  
CLIP BETWEEN LEG AND  
BACK OF SWITCH

CABLES STRAPPED WHERE SHOWN WITH  
HELLERMAN STRAPS AND STUDS, HV.3341  
(1/2 IN. WIDE) AND HV.3342 ON POST MOD.  
178 OR MOD. 197 AIRCRAFT.  
ON PRE MOD. AIRCRAFT CABLES CLIPPED  
TO SWITCH AS SHOWN BUT STRAPPED TO  
FLEXIBLE HYDRAULIC PIPES AS BEFORE

Fig. 7 Clipping of cables from undercarriage compression switch

RESTRICTED

the coupling nut also serves to lock the socket when it is mating with its plug. It should also be noted that this nut should be slackened before fitting the socket and the socket screwed in by hand, being assisted home by pushing on the back. A spanner or undue force must *not* be used, or damage will result.

#### Refitting earth leads

58. When refitting earth leads, care must be taken to ensure that the surfaces in contact are perfectly clean and in particular, free from grease and paint. Completed assemblies should be protected against corrosion by applying one coat of blue oil-base paint to D.T.D. Spec.827.

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

A close-up photograph of an aircraft's fuselage. The upper portion is painted red with several small, dark rivets visible. A vertical strip of blue material, possibly a cover or a different panel, runs diagonally across the frame. On this blue panel, the text 'LIGHTNING MK. 1', 'COVER PILOT HEAD', and 'EB2-88-5711' is printed in black. To the right of the blue panel is a small, dark, rectangular plaque with four small white dots at its corners. The overall lighting is somewhat dim, suggesting an indoor or shaded environment.

LIGHTNING MK. 1  
COVER PILOT HEAD  
EB2-88-5711