

Chapter 4

GENERAL SERVICING

LIST OF CONTENTS

	Para.		Para.		Para.
<i>Introduction</i>	1	<i>Access doors and panels</i>	6	<i>Miscellaneous drain points</i>	11
<i>Standard and special ground equipment</i> ...	2	<i>Toggle fasteners</i>	7	<i>Cleaning sliding hood</i>	12
<i>Special tools</i>	3	<i>Jacking, trestling and slinging</i>	9	<i>Cleaning cabin</i>	13
<i>Order of dismantling and assembly</i> ...	4	<i>Rigging of fixed surfaces</i>	10	<i>Pipe lines</i>	14
				◀ <i>Hot air ductings</i> ...	15 ▶

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
<i>Major components</i>	1	<i>Access panels</i>	3	<i>Rigging diagram</i>	5
<i>Jacking, trestling and slinging</i> ...	2	<i>Toggle fasteners</i>	4	<i>Dorsal fin access panels attachment fixings</i> ..	6

LIST OF TABLES

	Table		Table		Table
<i>Standard and special ground equipment</i> ...	1	<i>Special tools</i>	2	<i>Packing dimensions</i>	3

WARNING

AN AIRCREW EJECTION SEAT IS
FITTED TO THIS AIRCRAFT.

Before attempting to enter the cabin ensure
that the instructions detailed on the LETHAL
WARNING marker card at the front of this
Handbook have been complied with.

THIS IS VERY IMPORTANT

ENGINE

When the aircraft is being manoeuvred on
the ground with the engine running, or when
the engine is being run for any purpose it is
essential that all personnel keep well clear of
the air intakes and jet exhausts. To remain
in proximity is hazardous to safety.
The air intake safety guards must be fitted
at all times when the engine is being ground
run.

Introduction

1. This chapter contains information on the
general servicing of the complete aircraft,
together with tables listing the Standard and
Special Ground Equipment and the Special
Tools required for the operations described.
This special equipment has been designed to
eliminate any possibility of damage and dis-
tortion occurring during servicing and should,
therefore, be used in preference to other types

RESTRICTED

RESTRICTED

F.S./2

A.P.4347L & S, Vol. 1, Book 1, Sect. 2, Chap. 4
A.L.56, Aug. 67

of similar equipment, as otherwise the efficiency of the aircraft may be seriously impaired. When carrying out servicing operations, ensure that the air intake and jet pipe blanking boards are in position. Other covers or protective devices should also be fitted, provided they do not impede the pro-

gress of the work in hand. Servicing, dismantling and lubricating information applicable to particular assemblies and installations is covered in the appropriate chapters of Sections 3, 4, 5, 6 and 7. The servicing procedure for the standard components installed in this aircraft will be found in the

relevant Air Publication mentioned in the text.

Standard and special ground equipment

2. The ground equipment provided for use when servicing this aircraft is given in Table 1:

TABLE I

Standard and special ground equipment

Subject	Ref. No.	Part No.	Description	No. off	Application
Towing and Steering Equipment	4GB/4175	—	Arm, towing, short, Mk. 1	1	<i>Towing from spools on nose wheel</i>
	4GB/4138	—	Bridle towing, 35 ft.	1	<i>Backward towing from main undercarriage</i>
	4GB/5612	—	Fork unit, adjustable, Mk. 3	2	<i>Used with 4GB/3070 and 4GB/4175</i>
	4GB/3070	—	Unit, steering short	1	<i>Steering from spools on nose wheel</i>
Jacking and Trestling Equipment	4Q/2021	—	Adapter head, Mk. 2 (Mod. 241)	1	<i>For use with 4Q/2604</i>
	4Q/2594	—	Adapter head, Mk. 42 (Pre-mod. 241)	1	<i>For use with 4Q/2604</i>
	4Q/2807	—	Adapter head, Mk. 113	1	<i>For use with 4Q/2667</i>
	4Q/2655	—	Adapter head, Mk. 102	3	<i>For use with 4Q/2617</i>
	26FX/95019	C.189917	Beam, aft trestle, centre fuselage	1	<i>For use with U.J. trestle No. 1</i>
	26FX/95052	A.189921	Clip at nose wheel leg	1	—
	26FX/95022	D.194044	Cradle, inboard	2	<i>Wing trestling for use with U.J. trestle No. 6</i>
	26FX/95023	D.194045	Cradle, outboard	2	<i>Wing trestling for use with U.J. trestle No. 6</i>
	26FX/95020	C.190377	Cradle, centre fuselage	2	<i>For use with U.J. trestle No. 1</i>
	26FX/95041	C.190878	Cradle, forward	1	<i>Rear fuselage</i>
	26FX/20087	C.232866	Cradle, aft	1	<i>Rear fuselage for use with U.J. trestle No. 1</i>
	—	C.233561	Cradle, forward	1	<i>Front fuselage. Use with U.J. trestle No. 1</i>
	26FX/95609	B.205914	Extension jacking (Mod. 241)	1	<i>Main wheel changing</i>
	26FX/95004	F.191165	Extension jacking (Pre-mod. 241)	1	<i>Main wheel changing</i>
	4Q/2604	—	Jack, pillar, 4-ton, hydraulic	1	<i>Wheel changing, main and nose. (Alt. to 4Q/2667)</i>
	4Q/2667	—	Jack, pillar, 8-ton, hydraulic	1	<i>Wheel changing, main and nose. (Alt. to 4Q/2604)</i>
	4Q/2617	—	Jack, body, 5-ton, hydraulic	3	—
	26FX/95053	A.189922	Link, nosewheel anchorage clip	1	—
	—	B.205907	Pad, jacking, at frame 11 (Mod. 241)	1	—
	26FX/95002	B.191156	Pad, jacking, at frame 11 (Pre-mod. 241)	1	—
	26FX/95606	B.205909	Pad, jacking, at wing (Mod. 241)	2	—
	26FX/95300	B.206725	Pad, jacking, at wing (Pre-mod. 241)	2	—
	26FX/95608	A.205912	Pad, jacking, nose undercarriage (Mod. 241)	1	<i>Nose wheel changing</i>
	26FX/95003	A.188133	Pad, jacking, nose undercarriage (Pre-mod. 241)	1	<i>Nose wheel changing</i>
	26FX/95050	B.189929	Strut, bracing	2	<i>Front fuselage cradles</i>
	26FX/95368	B.206954	Strut, bracing	2	<i>Rear fuselage cradles</i>
	26FX/95234	B.199253	Strut, bracing	1	◀ <i>For use when bomb pack and ejection seat are removed</i>
4Q/2618 4Q/2620 4GB/ 4GB/	—	—	Trestle, Mk. 1	1	<i>Main jacking under nose. Use with 4Q/2617</i>
	—	—	Trestle, Mk. 3	2	<i>Main jacking under wing. Use with 4Q/2617</i>
	—	—	Trestle, U.J. No. 1	6	<i>Component trestling</i>
	—	—	Trestle, U.J. No. 6	4	<i>Component trestling</i>

RESTRICTED

TABLE 1
Standard and special ground equipment (Contd.)

Subject	Ref. No.	Part No.	Description	No. off	Application
Slinging Equipment	26FX/95011	D.188575	Sling, complete aircraft	1	—
	26FX/95369	D.206951	Sling, fuselage	1	Without engine
	26FX/95370	D.206952	Sling, fuselage	1	With engine
	26FX/95049	C.190378	Sling, centre fuselage	1	—
	26FX/95015	C.189918	Sling, front fuselage	1	—
	26FX/95366	C.206953	Sling, rear fuselage	1	Without tail unit
	26FX/95367	B.207188	Sling, rear fuselage	1	With tail unit
	26FX/95014	C.188900	Sling, outer wing	1	—
	26FX/95222	C.199388	Sling, outer wing	1	Lifting with chord vertical
	26FX/95016	B.190526	Sling, tailplane, fin and rudder	1	—
	4GC/5377	—	Sling, engine	1	Avon E.C.U. and stand
	26FX/95037	C.177141	Sling, for bomb pack	1	—
	26FX/95036	B.177142	Spigot assembly for hoist attachment	2	For bomb pack
	26FX/95046	B.191737	Rail, engine, detachable	1	—
	26FX/95216	C.200213	Trolley, engine	1	—
	G.E.6004-Sht. 1		Stand, Avon engine type B	1	—
	G.E.6004-Sht. 2		Adapter, for Avon engine stand	1	—
Rigging Equipment	26FX/95220	A.201222	Bar, levelling, longitudinal	1	—
	26FX/95142	B.199011	Bar, levelling, transverse	1	—
	26FX/95736	D.231154	Base, clinometer for tailplane	1	—
	26FX/95633	D.228419	Board, elevator movement checking	1	For aircraft with Mod. 390 embodied
	26FX/95144	D.199059	Fixture, rigging	1	For retaining controls in the neutral position
	26FX/95644	C.224263	Gauge, incidence, mainplane	1	—
	26FX/95007	B.201624	Gauge, incidence, tail plane	1	—
	26FX/95006	A.192534	Gauge, dihedral, mainplane and tailplane	1	—
	26FX/95306	A.201030	Lock, rigging	1	For elevator control tube
	26FX/95307	A.201031	Lock, rigging	2	For aileron and rudder control tubes
	26FX/95143	F.198704	Spigot levelling	2	—
Miscellaneous Special Equipment	26FX/	B.274018	Cover, ground, for airstream direction detector probe	1	Mod. 1301 ▶
	26FX/95413	D.211231	Guard, safety for air intake, port	1	—
	26FX/95414	D.211232	Guard, safety for air intake, starboard	1	—
	26FX/95136	D.202713	Ladder, pilot's	1	Access to cabin
	26FX/95839	C.207507	Pipe, defuelling, wheels up	1	—
	26FX/95427	C.208502	Test equipment for fuel system	1	—
	26FX/95215	C.200058	Trolley for tail unit removal	1	—
	26FX/95741	C.229925	Trolley, rear fuselage handling	1	—
	26FX/20337	B.252863	Hoist lifting for tacan A.C. supply panel	1	—
	26FX/95161	B.192253	Bar, front gun sight alignment	1	—
	26FX/95162	B.192254	Bar, rear gun sight alignment	1	—
	26FX/9598	E.234625	Stand, for nose piece	1	PR Mk. 11 only
Miscellaneous Standard Equipment	105G/11	—	Adapter	1	For use with type 37 Rectifier
	4G/3966	—	Mats, mainplane, type B	2	—
	5P/2908	—	Rectifier, type 37	1	—
	4F/1685	—	Trolley, servicing, hydraulic, Mk. 2	1	—
	4F/1913	—	Trolley, servicing, electrical, Mk. 4	1	—
	4F/1714	—	Trolley, servicing, cabin pressure testing, Mk. 1C	1	—

RESTRICTED

F.S./3

A.P.101B-1309-1A, Sect.2, Chap.4

A.L.86, Oct.74

TABLE 1
Standard and special ground equipment (Contd.)

Subject	Ref. No.	Part No.	Description	No. off	Application
	4G/4220	—	Trolley, oxygen charging, Mk. 2	1	—
	4G/4221	—	Trolley, H.P. air charging, Mk. 2	1	—
	4GC/3360	—	Hoist, type C	3	For bomb pack
	4GC/4233	—	No. 4 attachment	3	For use with hoist, type C
	4GC/3363	—	Tube assemblies	3	For use with hoist, type C
	4G/5584	—	Cradle (4G/5584 modified)	1	For bomb pack
► 4G/2051053	—	—	Ladder, flat top	2	— ►
Picketing Equipment	26FX/95428	B.214194	Cover blanking, air intake	1	set
	26FX/95552	C.218417	Cover, sealing, for jet pipe	1	—
	27D/3022	B.214258	Cover, cabin canopy	1	—
	27D/2999	—	Cover, centre fuselage	1	—
	27D/2917	—	Cover, gun package	1	—
	27D/3177	—	Cover, pressure head	1	—
	26FX/95217	C.200177	Cover, centre fuselage ducts, port	1	—
	26FX/95218	C.200178	Cover, centre fuselage ducts, starboard	1	—
	26FX/95203	F.159908	Fitting, picketing, rear fuselage	1	—
	26FX/	A.191716	Fitting, picketing, nose undercarriage	1	Embalmed aircraft only
	26FX/	B.191910	Fitting, main undercarriage	2	Picketing and rearward towing. Embalmed aircraft only
	26FX/95030	B.188480	Ground lock for nosewheel	1	—
	26FX/95135	B.188483	Ground locking gear, cabin flying controls	1	—
	26FX/95137	C.189263	Ground locking gear, aileron	2	—
	26FX/95138	C.192836	Ground locking gear, elevator	2	—
	26FX/95139	B.189267	Ground locking gear, rudder	1	—
	26FX/95204	A.176434	Shackle, picketing, nose undercarriage	1	—
	26FX/95205	A.176437	Shackle, picketing, main undercarriage	2	and for rearward towing
	26FX/95029	C.191636	Sleeve, locking, main undercarriage	2	—

Special tools

3. The special tools provided for use when servicing this aircraft are given in the following Table 2:—

TABLE 2
Special tools

Ref. No.	Part No.	Description	No. off
26FX/95527	A.208035	Adapter for external air supply	1
26FX/95058	A.191552	Extractor for front spar joint pin	1
26FX/95059	A.191655	Extractor for rear spar joint pin	1
26FX/95140	B.198963	Extractor for main spar wing joint bush	1
26FX/95141	C.198962	Extractor for rear spar wing joint bush	1
26FX/95032	Dunlop A.5826	Extractor for nose wheel	1
26FX/95303	Dunlop A.10054	Extractor for main wheels	1

RESTRICTED

TABLE 2
Special tools (Contd.)

Ref. No.	Part No.	Description	No. off
27G/5062	Dunlop A.10039	Fixture brake alignment	1
26FX/95388	A.210992	Gauge for undercarriage lever setting, port (Pre-mod. 1021)	1
26FX/95389	A.210993	Gauge for undercarriage lever setting, starboard (Pre-mod. 1021)	1
26FX/95860	A.249091	Gauge checking main undercarriage rear lock (Mod. 1021)	1
26FX/95861	A.249092	Gauge checking main undercarriage front lock (Mod. 1021)	1
26FX/95677	B.223910	Brace for tacan A.C. supply panel hoist	1
26FX/95513	B.214835	Gauge, setting, micro-switch, nosewheel leg up	1
26FX/95508	A.210921	Gauge, setting, micro-switch, nosewheel leg down	1
26FX/	A.204974	Guard for spigot in wheel bay	1
26FX/95086	A.194464	Guide for fuel tank vent connector (also used as a bung when pressure testing tanks)	2
26FX/95421	A.214536	Indicator, position, for adjustment of aileron booster unit	1
26FX/95505	D.210928	Jig, setting-up, micro-switch, nose undercarriage	1
26FX/95506	D.210929	Jig, setting, nosewheel door sequence valve	1
26FX/95390	A.212332	Key for hydraulic reservoir	1
26FX/95309	A.204865	Piece distance at front fuselage attachment nuts	1
26FX/95081	B.194717	Spanner for refuelling valve	1
26FX/95164	F.199124	Spanner for hydraulic system	1
26FX/95087	A.194634	Spanner for brake adjustment	1
26FX/95085	A.194578	Spanner for inverted flight valve connector	1
26FX/95304	F.199406	Spanner for elevator outer hinge lock-nut	1
26FX/95305	F.199407	Spanner for elevator outer hinge bolt	1
26FX/95308	B.204866	Spanner for front fuselage attachment nuts	1
26FX/95311	A.209612	Spanner for flap hinge bolts	1
26FX/95425	A.190295	Spanner for fuel system	1
26FX/95503	B.209815	Spanner for wing fuel system	1
26FX/95504	B.209816	Spanner for wing fuel system	1
26FX/95715	A.227530	Spanner, dial, for aileron booster unit adjustment (Mod. 703)	1
26FX/95645	B.224080	Spanner, crutching, for pylons (Mod. 663)	1
26FX/95163	A.197766	Spanner for hydraulic system	1
26FX/95165	A.197767	Spanner for hydraulic system	1
26FX/95166	A.197768	Spanner for hydraulic system	1
26FX/95226	A.201955	Spanner for main fuel delivery joint	1
26FX/95228	Britool Z.4948	Spanner for rear fuselage transport joint nuts	1
26FX/95080	B.191654	Tool for undercarriage up lock	1
26FX/95509	A.213921	Tool cocking for hood rear latch	1
26FX/95223	B.200521	Tool for assembly of rear transport joint spigot	1
26FX/	A.236181	Tool, manual release for hood lock control rod (Mod. 882)	1
26FX/95044	B.183954	Tool, locking for bomb pack	2
26FX/ —	F.261598	Block, undercarriage door spigot adjustment	2
26FX/ —	F.261597	Studs for Pt. No. F.261598	8
		<i>identical to parts authorized by S.T.I./Hunter/263</i>	

RESTRICTED

19877-22731

TABLE 3
Packing dimensions (fig. 1)

Component	Height	Width	Length	Weight (lb.)
Nose piece	2 ft. 5 in.	2 ft. 8 in.	2 ft. 4½ in.	20
Front fuselage	6 ft. 0 in.	5 ft. 1½ in.	15 ft. 5½ in.	900
Centre fuselage	5 ft. 10 in.	10 ft. 0 in.	16 ft. 0 in.	1425
Rear fuselage	6 ft. 9½ in.	4 ft. 2½ in.	17 ft. 1 in.	600
Tail cone	3 ft. 6½ in.	3 ft. 2 in.	4 ft. 1 in.	75
Wing	2 ft. 1 in.	11 ft. 4 in.	19 ft. 8 in.	972
Rudder	5 ft. 2 in.	0 ft. 8 in.	2 ft. 0 in.	35
Fin	6 ft. 0 in.	0 ft. 7½ in.	4 ft. 10 in.	60
Tail plane	0 ft. 6½ in.	7 ft. 11 in.	11 ft. 10 in.	206
Elevator	0 ft. 9 in.	1 ft. 11 in.	7 ft. 8 in.	67½
Aileron	0 ft. 5 in.	2 ft. 7 in.	8 ft. 8 in.	75
Flap	0 ft. 5 in.	2 ft. 7 in.	7 ft. 6 in.	70
Wing tip	0 ft. 7 in.	0 ft. 11 in.	5 ft. 2½ in.	6
Hood	2 ft. 4 in.	4 ft. 4 in.	4 ft. 10 in.	150
Ammunition box	2 ft. 7 in.	0 ft. 9½ in.	2 ft. 0 in.	40
Bullet fairing	0 ft. 10½ in.	0 ft. 9 in.	3 ft. 5½ in.	5

Dimensions given are to the nearest quarter of an inch. The weight of a component is for a single item only.

Order of dismantling and assembly

4. The breakdown points for dismantling the aircraft are shown in fig. 1, the dimensions and weights of the principal components are given in Table 3. The recommended order of dismantling is as follows:—

- (1) Jack up the aircraft (fig. 2) and retract the alighting gear.
- (2) Position the component trestles to fully support the aircraft.
- (3) Remove the outer wings (Sect. 3, Chap. 2), after removing any external stores which may be fitted.

Note . . .

The flaps, ailerons and pylons, if fitted, may be removed after the wings have been dismantled from the fuselage.

- (4) Remove the rear fuselage (Sect. 3, Chap. 1).

Note . . .

The rudder, elevators and tail plane (Sect. 3, Chap. 3) may be removed before or after the rear fuselage is removed from the centre fuselage.

- (5) Remove the engine (Sect. 4, Chap. 1).
- (6) Remove the front fuselage (Sect. 3, Chap. 1).
- (7) Remove the fuselage nose portion if necessary (Sect. 3, Chap. 1).

- (8) The assembly of the principal components is, in general, a direct reversal of the above procedure.

Access doors and panels

5. The position of the access doors and removable panels are shown in fig. 3, the components to which they give access being given in the key. When handling the doors and panels, care should be taken to ensure that they are not damaged or distorted in any way. When re-fitting them, ensure that they fit flush with the surrounding surface and that they are secure and effectively locked.

Note . . .

Screws removed from access panels must be replaced by screws of the same length, after first ensuring that fouling has not already taken place, otherwise damage to components or pipe lines in the vicinity of the panel may occur. The screws and bolts required for the attachment of the dorsal fin panels are detailed in fig. 6. ►




Fig. 1 Major components

RESTRICTED

	AIR DIAGRAM 7600C/MIN. HUNTER GA MK.11 & PR.MK.11
ISSUE 2	PREPARED BY MINISTRY OF AVIATION FOR PROMULGATION BY MINISTRY OF DEFENCE

T.P.15291/1




Fig.2 Jacking, trestling and slinging




Fig.3 Access panels

15293-21947

« 60 A. added »

KEY TO FIG.3 (ACCESS PANELS)

1. PYLON CRUTCHING	40. AILERON TRIM TAB ACTUATOR	77. WHEEL BRAKE
2. GENERAL ACCESS	41. AILERON CONTROLS	78. MAIN WHEEL BAY ACCESS
3. STARBOARD NAVIGATION LIGHT	42. AILERON CONTROLS	79. FUEL TRANSFER PIPE AND PRESSURE
4. DETACHABLE WING TIP	43. AILERON CONTROLS	RELIEF VALVE
5. FLYING CONTROLS, AND PRESSURIZATION EQUIPMENT	44. AILERON CONTROLS	80. FUEL AND HYDRAULIC PIPES
6. GENERAL ACCESS	45. FLAP JACK ANCHORAGE	81. FUEL TANK FLOAT SWITCH
7. FUEL LEVEL SWITCH	46. FLAP JACK GREASER	82. MAIN SPAR PIN JOINT
8. FUEL VENT CONNECTION	47. FLAP SYNCHRONIZING JACK	83. NOSE WHEEL BAY ACCESS
9. TANK RELIEF VALVE	48. AILERON CONTROLS	84. NOSE WHEEL BAY ACCESS
10. DEFUELLING PRESSURE CONNECTION	49. DRUM SWITCH FLAP CONTROL	85. NOSE UNDERCARRIAGE LEG PIVOT
11. DUCT TO ENGINE BLEED VALVE	50. GEARBOX DRIVE PORT CENTRE	PIN
12. PRESSURIZATION	FUSELAGE	86. NOSE UNDERCARRIAGE JACK
13. FLYING CONTROLS	51. REAR SPAR PIN JOINT AND FLYING	87. GENERAL ACCESS
14. TRANSPORT JOINT BUTT STRAP	CONTROLS	88. BOMB PACK ▶
15. FLYING CONTROLS	52. DETACHABLE WING NOSING	89. RADIO AND ELECTRICAL
16. FLYING CONTROLS	53. WING PIN JOINT	90. FUEL PUMP
17. HYDRAULIC ACCUMULATOR, AND ELECTRICS	54. SLINGING POINT	91. GENERAL ACCESS
18. ELEVATOR OUTER HINGE	55. MAIN SPAR PIN JOINT	92. GENERAL ACCESS
19. FLYING CONTROLS	56. RADIO AND ELECTRICAL	93. MAIN WHEEL BAY ACCESS
20. RUDDER CONTROLS	57. TACAN ACCESS	94. GENERAL ACCESS
21. RUDDER CONTROLS	58. EXTERNAL EMERGENCY HOOD RELEASE	95. AILERON CONTROLS
22. FIN DETACHABLE PORTION	59. GENERAL ACCESS	96. ELECTRICS
23. GENERAL ACCESS	60. PILOT'S FOOTSTEP	97. ENGINE STARTER
24. DETACHABLE BULLET FAIRING	60A. NOSE PIECE	98. GENERAL ACCESS
25. TAIL PLANE HINGE	61. CAMERA SERVICING (NOT P.R. MK.11) ▶	99. GEARBOX AND FILLER
26. ELEVATOR CONTROL LEVER	62. CONTROL COLUMN MECHANISM,	
27. SELECTOR VALVE AND ELEVATOR CONTROLS	CABIN FLOOR	
28. TAIL PLANE ACTUATOR	63. FLYING CONTROLS, CABIN FLOOR	100. ENGINE
29. DETACHABLE TAIL CONE	64. AILERON BOOSTER UNIT	101. ENGINE MOUNTING
30. JET PIPE THERMOCOUPLES	65. AILERON CONTROL MICROSWITCH	102. OIL LEVEL SIGHTING
31. JET PIPE REAR MOUNTING	66. GENERAL ACCESS	103. GENERAL ACCESS
32. JET PIPE THERMOCOUPLES	67. DROP TANK FUEL AND AIR	104. HYDRAULIC FILTER
33. ELECTRICAL CONNECTIONS	CONNECTIONS	105. IGNITER PLUG
34. HYDRAULIC RESERVOIR FILLER	68. R.P. ELECTRICAL CONNECTIONS	106. JET PIPE THERMOCOUPLES
35. DETACHABLE WING TIP	69. GENERAL ACCESS	107. TELE-BRIEFING PLUG
36. R.P. MOUNTINGS	70. GENERAL ACCESS	108. JET PIPE THERMOCOUPLE
37. PORT NAVIGATION LIGHT	71. R.P. MOUNTINGS	109. ELEVATOR BOOSTER UNIT
38. GENERAL ACCESS	72. AILERON CONTROLS	ATTACHMENTS
39. PYLON CRUTCHING (OUTBOARD)	73. ELECTRICAL CONNECTIONS	110. ELEVATOR CONTROL LEVER
	74. GENERAL ACCESS	111. ELEVATOR FEEL UNIT
	75. MAIN WHEEL BAY ACCESS	112. TAIL PLANE HINGE
	76. MAIN WHEEL BAY ACCESS	113. ELEVATOR FEEL UNIT
		114. RUDDER TRIM TAB ACTUATOR

Toggle fasteners

7. Certain removable panels are secured in position by toggle fasteners (fig. 4). To open these fasteners, the catch lever (1) marked PUSH is depressed with the forefinger (*do not use tools*) causing the hook integral with this lever to disengage from pin (2) in the toggle lever (3), withdrawing it from the housing and disengaging the fastener. For re-engagement, the hooks on the end of the toggle lever are engaged in the recess and the lever pressed home with the palm of the hand. Adjustment is accomplished by screwing up or unscrewing the links (4), after first slackening off the grub screw (5) in the side face of the links. One turn of the thread on the links gives 0.036 in. of adjustment, and the total adjustment available is 0.5 in. When adjustment is satisfactory, the grub screw must be re-tightened.

Note . . .

The grub screw must be slackened off before adjustment as otherwise the threads will be damaged. The grub screw must be re-tightened after adjustment.

8. Certain access doors are secured by Arctic type toggle fasteners (fig. 4). To open these fasteners, the knurled safety catch plate (1) is depressed and the lever (2) ejected sufficiently to enable it to be easily withdrawn from the housing (3). For re-engagement, the lever is engaged with the housing and then pressed home with the palm of the hand. Adjustment is accomplished by removing the split pin and then screwing up or unscrewing the links. One turn of the thread on the links gives 0.036 in., adjustment available is 0.5 in. When adjustment is satisfactory, lock with a split pin.




Fig. 4 Toggle fasteners

RESTRICTED

Jacking, trestling and slinging

9. The methods to be employed and the jacks, trestles and support beams, etc., to be used when jacking, trestling and slinging the complete aircraft for servicing are illustrated in fig. 2. It should be noted that the fuselage jacking pad has a concave bearing surface and must not be interchanged with the wing jacking pad which has a flat bearing surface.

Rigging of fixed surfaces


10. When checking the alignment of the structure by means of the diagonal dimensions given in fig. 5, there is no need to trestle the aircraft. When the incidence and dihedral are being checked, the aircraft must be trestled in the rigging position, with the equipment provided (fig. 2). The procedure for rigging is as follows:—

- (1) Check the alignment of the structure.
- (2) Jack up the aircraft and level it transversely, by means of the levelling bar Pt. No. B.199011 (*Ref. 26FX/95142*) and spirit level placed across the hood rails.
- (3) Place a levelling spigot Pt. No. F.198704 (*Ref. 26FX/95143*) into each of the levelling points attached to the fuselage structure in the port wheel bay and level the aircraft longitudinally with a straight edge and spirit level placed across these two spigots. The trestle at frame 55 is to be adjusted to take the weight of the rear fuselage after the aircraft has been levelled longitudinally.
- (4) Check the incidence and dihedral of the wings (*using gauges quoted in Table 1*).
- (5) Check the incidence and dihedral of the tailplane (*using gauges quoted in Table 1*).

LEVELLING AN AIRCRAFT

FOR TRANSVERSE LEVELLING, USE THE LEVELLING BAR, PART NO. B.1990II, AND A SPIRIT LEVEL PLACED ACROSS THE HOOD RAILS, SEE BELOW.

FOR LONGITUDINAL LEVELLING, SPIGOTS, PART NO. F.198704, ARE PROVIDED FOR INSERTION INTO THE LEVELLING POINTS IN THE PORT WHEEL BAY, 4 INCHES BELOW THE FUSELAGE DATUM.



● TOLERANCE AT WING ROOT AND TIP \pm 0 DEG. 20 MIN.
A COMBINATION OF A POSITIVE ERROR AT ONE WING
TIP WITH A NEGATIVE ERROR AT THE OTHER MUST NOT
GIVE A TWIST OF MORE THAN 0 DEG. 25 MIN.

SYMMETRY CHECK

CHECKING POINTS

		LIMITS
A	NOSE WHEEL DOOR CUT-OUT TO OUTBOARD END OF AILERON	0.50 IN.
B	OUTBOARD END OF AILERON TO OUTBOARD END OF ELEVATOR	0.50 IN.
C	UNDERCARRIAGE WHEEL HUB TO TRAILING EDGE OF FIN	0.50 IN.
D	TIP OF FIN TO OUTBOARD END OF ELEVATOR	0.25 IN.

RESTRICTED

(6) When checking the variable incidence of the tailplane use a clinometer with the clinometer base Part No. D.231154 (fig. 5). To fit the base, remove the port top tailplane fairing, locate the lugs between the front and rear tailplane spars, with the side of the base painted red facing outboard and secure to the appropriate anchor nuts normally used for the tailplane fairing.

The adjustment of the individual control surfaces is described in Sect. 3, Chap. 4.

Miscellaneous drain points

11. A series of small holes, extending from frame 19 (Sect. 3, Chap. 1) to the tail end, are provided in the undersurface of the fuselage to allow any moisture and surplus fuel which may accumulate between these frames to drain away. Surplus fuel from the high pressure cock, combustion chambers and the exhaust unit is conducted through pipes to eject at the bottom of the fuselage. All the drain holes should be inspected periodically to ensure that they are not blocked, otherwise an accumulation of fuel, with its resultant fire may arise. Small cocks are provided at the lowest point of the fuel system, together with a drain plug in the engine fuel filter casing, to enable any water or sediment to be drained from the fuel (*for their location and method of use, reference should be made to Sect. 2, Chap. 2*). Moisture drain taps are also provided in the pressure head installation (*described in Sect. 5, Chap. 2*).

Cleaning hood

12. When cleaning or polishing the cabin hood, care must be taken to ensure that no rags that have been in contact with trichloroethylene are used, as rags so contaminated will cause serious damage to the surface. Refer to A.P.1464D, Vol. 1, for detailed instructions on the care of transparent plastic panels.

Cleaning cabin

13. When wiping over those portions of the cabin instrument panels, shelves, etc., which contain labels, only clean dry rags should be used. Many of these labels will be damaged if rags impregnated with fuel, grease solvent or thinners are used.

◆ Pipe lines

14. Before the assembly of pipe lines of the fuel system, hydraulic system and air conditioning system (NOT the oxygen system), the threads of all pipe couplings should be lubricated with anti-seize compound ZX-28G. When reassembling pipe lines, ensure that the arrows on the pipes, non-return valves and other components, point in the direction of flow; tighten the unions by hand first and examine the lay of the pipe to ensure that maximum clearance from other pipes, components or structure is obtained to eliminate the possibility of chafing. After final tightening, ensure that the clearance has been maintained. ►




Fig.6 Dorsal fin access panels attachment fixings

RESTRICTED

RESTRICTED

◀ **Hot air ductings**

15. Every opportunity must be taken to examine hot air ductings throughout the life of the aircraft, particular attention being given to the following :—

- (1) Damage to, or discolouration of, ducts, pipes, wiring or structure adjacent to hot air ductings, which may be indicative of gas leakages.
- (2) Security and condition of all duct joints.
- (3) Duct lagging for sign of damage.
- (4) Visible portions of duct metalwork, particularly in the vicinity of welds for signs of cracking. ►

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

