

**GROUP B.1**  
**GENERATORS AND BATTERIES (CODE GA)**

**LIST OF CONTENTS**

<b>DESCRIPTION</b>	<b>Para.</b>	<b>Para.</b>
<b>Introduction</b> ... ... ... ... ... ... 1		
<b>Equipment details</b>		
<i>Main Supply</i> ... ... ... ... ... 2		
<i>Automatic off-loading</i> ... ... ... 5		
<i>Standby supply</i> ... ... ... ... 6		
<i>Distribution and earth return</i> ... ... 7		
<b>Operation</b>		
<i>General</i> ... ... ... ... ... ... 8		
<b>Generation</b> ... ... ... ... ... ... 10		
<b>Power failure</b> ... ... ... ... ... ... 14		
<b>Batteries</b> ... ... ... ... ... ... 15		
<b>Off-loading</b> ... ... ... ... ... ... 16		
<b>External supply</b> ... ... ... ... ... ... 17		
<b>Test sockets</b> ... ... ... ... ... ... 18		
<b>Standby supply</b> ... ... ... ... ... ... 19		
<b>SERVICING</b>		
<b>General</b> ... ... ... ... ... ... 20		
<b>Servicing main batteries</b> ... ... ... ... 21		
<b>Servicing standby batteries</b> ... ... ... 23		
<b>Parallelling of generators</b> ... ... ... 24		
<b>REMOVAL AND ASSEMBLY</b>		
<b>General</b> ... ... ... ... ... ... ... 25		
<b>Changing the main batteries</b> ... ... ... 26		
<b>Removal of standby batteries</b> ... ... ... 27		
<b>Refitting generators</b> ... ... ... ... ... 28 ►		

**LIST OF ILLUSTRATIONS**

<i>Fig.</i>
<b>Generators and batteries</b>
<i>(theoretical)</i> ... ... ... ... ... 1
<b>Generators and batteries</b>
<i>(routeing)</i> ... ... ... ... ... 2
<b>Standby (B+) distribution</b> ... ... ... 3

**TABLE**

<i>Table</i>
<b>Equipment type and Air Publication</b>
<b>reference</b> ... ... ... ... ... ... 1

**RESTRICTED**




Fig. 1 Generators and batteries (theoretical)

RESTRICTED

**Introduction**

I. This group contains the description and operation, of the generators and batteries circuit of this aircraft, together with information on the servicing required to maintain the equipment in an efficient condition. Routing and theoretical circuit diagrams are also included. For a description of the aircraft electrical system, reference should be made to Groups A1, A2 and A3 of this chapter. Detailed information on the standard items of equipment used in the circuit will be found in the Air Publications listed in Table 1.

**DESCRIPTION****Equipment details****Main supply**

2. Two d.c. generators, mounted on and driven by the engine accessories gearbox, supply the power for all the electrical services. The generators operate in parallel with a load-balancing line and charge two 24-volt batteries, which are also connected in parallel and are mounted on a platform in the radio bay. To minimise radio interference, the main and field supplies from each generator are

taken through a suppressor and another suppressor is connected in the load-balancing line from each generator. The four suppressors are located, one pair on each side, in the centre fuselage just aft of the generators. To enable an earth return system to be used, the generator negative leads, after passing through the main suppressors, are connected to the aircraft structure at earth points 10 and 16 adjacent to the generators.

3. Generator controls are mounted on a panel in the radio bay, hinged to the top

TABLE 1

## Equipment type and Air Publication reference

Equipment	Air Publication
Generators, Type 515A; 24 volt, 6 Kilowatt	A.P.4343A, Vol.1, Sect.3
Suppressors, Type B4 (Generator load balance line) and X3 (Generator main)	A.P.4343C, Vol.1, Book 3, Sect.5
Batteries, Type J; 24 volt, 25 amp-hr. (Main)	A.P.4343A, Vol.1, Sect.11
Batteries, 12 volt, 4 amp-hr. (Standby)	A.P.4343B, Vol.1, Book 1, Sect.1
Voltage regulators, Type 94	A.P.4343B, Vol.1, Book 1, Sect.1
Differential cut-outs, Type A. Mk.2	A.P.4343B, Vol.1, Book 2, Sect.10
Circuit breakers, Type D; 200 amp. (Generator main)	A.P.4343B, Vol.1, Book 2, Sect.10
Circuit breakers, Type A2; 10 amp. (Generator field)	A.P.4343B, Vol.1, Book 3, Sect.20
Voltage trimmers, remote, Type 3; 5 ohm (Voltage regulators)	A.P.4343B, Vol.1, Book 3, Sect.20
Relays, Type R (Battery)	A.P.4343B, Vol.1, Book 2, Sect.3
Relays, Type S. No.3 (Crash and hold-off)	A.P.4343E, Vol.1, Sect.18
Switches, magnetic, Type 9B, No.1 (Voltage regulators)	A.P.4343C, Vol.1, Book 1, Sect.1
Warming lamps, Smiths Type 38 C.F.P. (Power failure)	
Indicators, magnetic, Type A.2 (Power failure)	
Tumbler switches, Type XD.779/3	




Fig.2 Generators and batteries (routing)

RESTRICTED

starboard longeron and anchored to the supply panel by four Dzus fasteners. The control equipment for each generator comprises:-

- (1) Voltage regulator with external trimmer.
- (2) Differential cut-out.
- (3) Circuit breakers for main output and generator field windings.
- (4) Re-set switch.
- (5) Control relays (*Crash, regulator, hold-off and batteries*).
- (6) Power failure magnetic indicator.
- (7) Test equipment for the generator circuit consisting of a voltmeter socket and an ammeter socket with a shunt in the generator main output circuit.

Two eight-way fuse blocks, carrying the control circuit fuses are also mounted on the control panel, together with a ten-way terminal block which is used for linking together the earth leads of the control equipment.

4. A battery master switch, marked BATTERY ON/OFF, is fitted to the leg panel in the pilot's cabin. In the OFF position, this switch isolates the aircraft batteries from all the electrical services except the essential load line and the fire extinguisher circuit. Two generator power

failure warning lamps are also mounted on the leg panel. An external supply socket is mounted on the battery support structure. Access to this socket is gained via the port radio access panel. It is most important that an external supply is used whenever an electrical supply is required for servicing, thus preventing the aircraft batteries being discharged. A voltmeter socket for use in testing the aircraft main batteries is fitted at the forward end of the underside of the main battery platform.

#### *Automatic off-loading*

5. In the event of a crash landing, the generators and batteries are automatically isolated from the electrical system to prevent the possibility of fire. Each generator is off-loaded by the operation of its own crash relay, which when energized by the operation of the fire extinguisher relay, breaks the supply to its voltage regulator operating coil. The operation of the fire extinguisher relay also isolates the batteries from all but the essential load line i.e. the fire extinguisher bottle. The fire extinguisher relay is energized by the operation of two series connected inertia switches (Group C.2).

#### *Standby supply*

6. Two 12 volt, 4 amp. hour batteries, connected in series and carried in a battery box mounted on the starboard side of frame 16 in the radio bay provide a standby 24-volt supply. This supply is available, in the event of main battery and power failures, for operation of the cabin emergency lighting, described in Group F1 of

this chapter, and the turn and slip indicator, described in Group 3B of Chapter 2. The batteries are brought into use by the operation of the appropriate control switches for the services concerned. The standby supply (B+) distribution is illustrated in fig.3.

#### *Distribution and earth return*

7. The distribution of power from the positive bus-bar (L+), located above the supply panel between frames 16 and 17A, is indicated on the supply and earth routing chart given in Group A.1 of this chapter. The earth return leads from the various electrical services and wires back from the equipment to the junction boxes and panels where they are connected to a limited number of main earth points. All the main earth points are numbered and may be located on the supply and earth routing chart and on the location illustrations contained in Group A.3 of this chapter.

#### *Operation*

##### *General*

8. When two generators are operating in parallel it is essential, to ensure equal load sharing and stable operation, that they are regulated and aligned so that their outputs are as near equal as possible under all operating conditions. Each generator is, therefore, provided with its own control equipment and, although it operates as an independent unit having its own characteristic, when correctly regulated and aligned, it will tend to




Fig.3 B + distribution

RESTRICTED

operate in conjunction with the other generator to share the load.

9. To bring a generator into operation on a line to which another generator is already connected, it is necessary to momentarily boost the regulator controlled voltage of the incoming generator so as to overcome the electromotive force of the first generator, which tends to oppose the current flow from the incoming generator. This boost is automatically obtained by increasing the resistance in series with the operating coil of the voltage regulator and consequently the resistance in series with the generator field windings. This operation is effected by a trimmer resistance in the voltage regulator, which is only in circuit prior to operation of the generator on the line. During operation of the generator, contacts 5 and 6 of the regulator relay, which are closed because the relay is energized, automatically short-circuit the trimmer. During alignment of the generators, this trimmer may be short-circuited by use of the re-set switch (para.24). Additionally, contacts 3 and 4 of the relay serve to complete the load balancing line when the relay is closed (para.12).

#### Generation

10. The theoretical circuit is illustrated in fig.1 and the routeing is shown in fig.2. As each generator control circuit is duplicated, it is only necessary to follow the operation of one generator and its control equipment to understand the circuit. When a generator commences to rotate, an

increasing voltage is developed across the output terminals, due to the residual magnetism in the field. This output is fed to the differential coil of the cut-out and the operating coil of the voltage regulator, via the normally closed contacts (2 and 2a) of the generator crash relay, (para.16) and to the generator field windings, via the carbon-pile resistance in the voltage regulator. The generator field windings receive extra energization by this current which permits the output voltage to rise rapidly and this voltage builds up in opposition to the battery current passing through the differential coil windings and ballast lamp in the cut-out.

11. The differential coil windings are such that, when the generator output rises to a figure of 0.35 to 0.75 volts above that of the batteries, the current in the operating coil polarizes the armature sufficiently to cause it to move over and so close the contacts. This action energizes the closing coil of the main circuit breaker, via the re-set switch and hold-off relays, thus closing the main contacts so that the differential coil and ballast lamp are shorted out. The current now flows from the generator, through the series coil which holds the armature in the contacts-closed position, and the polarizing magnets also bias the armature to this position.

12. At the same time, the auxiliary contacts of the circuit breaker are opened, thus inserting the hold-in coil into circuit

and breaking the circuit to the power failure warning lamp and magnetic indicator. As the circuit breaker main contacts close, a supply is fed to energize the regulator relay, thus removing the regulator voltage boost (para.9) and completing the circuit of the load balancing coil in the voltage regulator, when the second generator is also on the line. The load balancing coils are connected in series between the inner ends of the generator interpole windings.

13. The action of the operating coil in the voltage regulator is to adjust the resistance of the carbon-pile in series with the generator field windings, relative to the current drain and thus maintain the voltage constant throughout the range of operating speed and output. The function of the load balancing coil is such that it acts on the carbon-pile to reduce the voltage of the generator when it is overloaded in relation to the other generator and to increase the voltage when it is underloaded, thus the output is varied according to the load imposed and the load is shared more or less equally between the two generators.

#### Power failure

14. Power failure is indicated by one warning lamp and one magnetic indicator for each generator. When the generator voltage falls below that of the batteries, a reverse current flows in the series coil of the cut-out and this reverses the polarity of the armature and opens the contacts. This action de-energizes the hold-in coil

of the circuit breaker and breaks the main contacts, thus disconnecting the generator from the batteries. The contacts feeding the power failure warning lamp and magnetic indicator are made when the main contacts break and the lamp and indicator operate to indicate failure. At the same time, the regulator relay is de-energized to break the load balancing line and connect into circuit the trimmer in the voltage regulator, thus providing voltage boost, which, if the fault was of a temporary nature, will enable the generator to re-commence operation in the normal manner. When the generator is shut-down, i.e., engine stopped and batteries isolated the armature of the cut-out is biased in the open position by the polarizing magnets.

#### *Batteries*

15. The main batteries are connected to the positive bus-bars via the battery relay which is energized from the battery essential load line and controlled by the fire extinguisher relay and battery master switch. Placing the master switch in the ON position, with the fire extinguisher relay de-energized, i.e., in its normal condition, energizes the closing coil of the battery relay and causes the main contacts to close and the auxiliary contacts to open. The batteries are thus connected to the bus-bar through the main contacts while the hold-on coil of the battery relay is energized by the breaking of the auxiliary contacts.

#### *Off-loading*

16. In the event of a crash landing, the

inertia switches in the fire extinguisher circuit (Group C.2) will operate and energize the fire extinguisher relay, which apart from operating the fire extinguisher will also break the supply to the battery master switch and battery relay, thus opening the main contacts of the battery relay and isolating the batteries from all but the essential load line and fire extinguisher circuit. At the same time the fire extinguisher relay makes the supply to the generator crash relays, which becomes energized and breaks the supply to the voltage regulator operating coils, thus off-loading the generators.

#### *External supply*

17. When an external supply is connected to the external plug for testing the aircraft electrical equipment, the coils of the hold-off relays are fed from the external supply, via a "loose" positive link, before the main positive connection is made. The hold-off relays are thus energized and break the feeds to the generator circuit breakers, the main contacts of which open to isolate the generators so preventing the external supply from attempting to "motor" the generators. It is also advisable to place the battery master switch to the OFF position when the external supply is connected, to prevent the aircraft batteries being discharged should the external supply voltage fall below that of the batteries.

#### *Test sockets*

18. Voltmeter and ammeter test sockets,

together with an ammeter shunt, are provided for each generator for use when adjusting the circuit as described in para.24.

#### *Standby supply*

19. The operation of the standby supply circuit (B+) will be obvious, once reference is made to the theoretical diagram given in fig.3 of this group and to Group F.1 of this chapter. Reference should also be made to Section 5, Chapter 2, Group 3.B for a description of the standby battery supply to the turn and slip indicator.

## **SERVICING**

#### *General*

20. For general servicing information, reference should be made to Group A.1 of this chapter. Absolute cleanliness of all parts, particularly the generator brush gear and commutator, together with the immediate remedy of any defects, however small, is essential for the reliable operation of the circuit. The contacts of the cut-outs, circuit breakers and relays must be kept clean and the terminals of all components must be kept tight and free from corrosion. For functional tests and detailed servicing of the standard components used, reference should be made to the appropriate Air Publications quoted in Table 1.

#### *Servicing main batteries*

21. The state of charge of the main batteries installed in this aircraft is determined by voltage, as no check of specific

gravity is possible. A small three-pole test socket is located on the underside of the battery platform for this purpose. When using this socket, it is essential to check one battery at a time and this may be accomplished by removing the Cannon plug from one of the batteries while checking the other and vice versa. After test, ensure that both Cannon plugs are reconnected to the batteries.

22. The open circuit voltage of a fully-charged battery is 25.8 to 25.1 volts, a quarter to half-discharged battery is 25.1 to 24.5 volts and a half discharged battery is 24.5 to 24.2 volts. To obtain more definite information on the state of charge, an off-load reading should be taken immediately after taking a reading with the battery connected to a load of approximately 20 amp. for 15 seconds, i.e., radio, navigation lamps and cabin lamps switched on. The increase in reading from on load to off load should be approximately 1 volt. If the aircraft is not flown or the engine is not run-up for more than two weeks, the batteries must be removed and sent to the Battery Charging Bay. Under no circumstances should the batteries be left installed in aircraft beyond the normal battery servicing period or serious deterioration will result. For detailed servicing of the batteries, reference should be made to the Air Publication quoted in Table 1.

#### Servicing standby batteries

23. As with the main batteries, the state of charge of the standby batteries should be determined by a voltage check. These batteries

are not included in the battery charging circuit of the aircraft. They should be checked at the servicing periods laid down in the aircraft Servicing Schedule.

#### Paralleling of generators

24. The generating circuits should always be ensured parallel after the fitment of a new generator, a new voltage regulator, a new cut-out or after any servicing which may have disturbed the alignment of the circuits and also when a check is indicated as being necessary. Using a Multimeter Type 12889 or similar test equipment, the procedure for checking the generator control system is as follows:-

Note . . .

*Before commencing operations, ensure the aircraft batteries are at least 80% charged.*

(1) Start the engine in accordance with the instructions detailed in AP 101B-1309-12 (*Ground handling notes*). Ensure both generator failure warning lamps extinguish at an engine speed of 3 000 rev/min  $\pm$  200 rev/min and that the power failure magnetic indicators operate correctly.

(2) Run the engine at the normal cruising speed of 7 800 rev/min.

(3) Select No. 1 generator re-set switch to RE-SET, (*No. 1 generator off-load, warning lamp illuminated, power failure magnetic indicator indicating white*), connect the testmeter to No. 1 volts test socket and ensure a voltage of 27.5V d.c.  $+0.5$  V d.c., adjusting the external voltage trimmer as necessary to obtain this figure. Select No. 1 generator re-set switch to NORMAL, checking that the regulated voltage momentarily rises by approximately 1 volt as the generator output is boosted to enable it to come on line. Disconnect the testmeter from the test socket.

Note . . .

*The voltage boost is removed immediately the main contactor closes and is therefore evident for a very short period. Some testmeters may not respond quickly enough to fully show the temporary increase.*

(4) Select No. 2 generator re-set switch to RE-SET, (*No. 2 generator off-load, warning lamp illuminated, power failure magnetic indicator indicating white*), connect the testmeter to No. 2 volts test socket and ensure a voltage of 27.5V d.c.  $+0.5$  V d.c., adjusting the external voltage trimmer as necessary to obtain this figure. Select No. 2 generator re-set switch to NORMAL, checking that the regulated voltage momentarily rises by approximately 1 volt as the generator comes on line. Disconnect the testmeter from the test socket.

## RESTRICTED

◆ (5) Increase the engine speed to maximum and repeat sub-para. (3) and (4) ensuring a voltage of 27.5V d.c.  $^{+0}_{-0.5}$  V d.c. Reduce the engine speed to 3 700 rev/min.

(6) With the testmeter disconnected from the volts test sockets and both generator re-set switches selected to NORMAL, connect ammeters to the ammeter test sockets. Ensure a load of at least 50 amp, including battery charging, is imposed on the L+ bus-bar. Increase the engine speed to maximum, checking that the load current difference between No. 1 and No. 2 generators does not exceed 10 amp throughout the engine speed range.

**Note . . .**

*If this figure is exceeded, the procedure detailed in sub-para.(2), (3) and (4) should be repeated followed by a further load sharing check.*

(7) With the ammeters still connected, reduce the engine speed to idling. Shut down the engine and as the speed reduces through approximately 2 950 rev/min, ensure the cut-out contacts open, illuminating the power failure warning lamps and operating the power failure magnetic indicators. During this period, check that the reverse current reading

on the ammeters is between 15 amp and 25 amp. The generating circuits are now aligned and the ammeters may be removed from the ammeter test sockets. ►

(2) Disconnect the vent pipes from each battery.

(3) Remove the Cannon plugs from each battery and place in such a position so that the pins will not short on the aircraft structure.

(4) Disengage the special quick-release bolts securing each battery and carefully remove the batteries from their mounting platforms.

(5) Examine the replacement batteries to ensure that their voltage is within  $\pm 0.5$  volts of each other. Place the replacement batteries on the platforms and reverse the procedure in sub-para. (2) to (4).

**Note . . .**

*Before attempting to connect the batteries, ensure that the Cannon plugs are not shorting against the aircraft structure.*

### Changing main batteries

26. The two main batteries are carried on a platform located on frame 19 in the radio bay and access may be gained via the radio access doors (Sect. 2, Chap. 4). The procedure for changing the batteries is as follows:-

(1) Ensure that the battery master switch is in the OFF position.

### Removal of standby batteries

27. These batteries are carried in a box located on the starboard side of frame 16 in the radio bay and access may be gained by opening the radio access doors. To remove the batteries, proceed as follows:-

(1) Render the aircraft electrically safe, as described in Group A.1 of this chapter.

- (2) Disconnect cable assembly PC.13 from cable assembly PC.17 at the plug and socket connection on the side of the battery box.
- (3) Withdraw the two draw bolts at the top of the box from the mounting structure and lift the box upwards to disengage its lower mountings.
- (4) Remove the box and batteries from the aircraft.
- (5) The batteries may be removed from the box by opening the lid and disconnecting the leads of cable assembly PC.13 from the battery terminals.

**Refitting generators**

28. When refitting generators, reference should be made to the accessories gearbox installation instructions given in Book 1, Sect. 4, Chap. 1. If cable assembly C.31 extending from No. 2 generator to its suppressor has been disturbed, care must be taken to ensure that the P-clips securing the cable to the hydraulic external supply valves support bracket are facing aft, i.e. the cable is laying aft of the rear face of the bracket. This is necessary to prevent the possibility of a foul between the cable and the engine throttle linkage (*Ref. S.T.I./Hunter/280*). To prevent chafing of the cable by the engine access door it is also important to ensure that the cable passes in front of the engine low pressure fuel filter drain pipe (*S.T.I./Hunter/299*).





This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.