Chapter 24D

TOP WHEELCASE, DISMANTLING

Contents

		Page		Page
	General	2	Ghost 48 Mk. 2	
(Ghost 48 Mk. 1 and 48 Mk. 2		Miscellaneous details	- 9
	Starter drive assembly	2	Generator drive casing	7
	Dismantling the planet gear assembly	2	Idler gear	7
	Removing the planet gear assembly	2	Miscellaneous details	7
(Ghost 48 Mk. 1		Vertical drive shaft and gears	9
	Air compressor drive housing assembly	3	Port and starboard generator drives	6
	Miscellaneous	6	Removing and dismantling the gear	
	Removing the gear drive assemblies	3	assemblies	10
	Air compressor drive	5	Dismantling the air compressor drive	
	Generator and alternator drives Generator idler gear	5	gears	10
	Spare drive	5	Dismantling the idler gear	11
	Spare drive/starter idler	5	Dismantling the tachometer drive gear	10
	Starter/generator idler	6	Removing the air compressor and	
	Tachometer drive	5	tachometer gear assemblies	10
	Removing the plain bearings	6	Starter drive assembly	6
		Illustra	tions	<i>T</i> '
	To a late to the transfer of	Fig.	Press block group T.77683 and adapter	Fig.
	Top wheelcase bolted to dismantling-and-rebuilding stand T.74978	- 1	T.77684 for pressing port generator drive gear clear of the housing	10
	Vice block T.74821, with planet gear	2	Press block T.77683 and adapter T.77686	
	assembled	2	for pressing out bearings and spacers	11
	Split bush T.74822, pot fixture T.74823, and adapter T.74824, for removing		Top wheelcase arrangement	12
	planet gear carrier cover	3	Extractor T.77677 for removing the idler gear, outer roller bearing, spacers, and	
	Top wheelcase arrangement	4	inner roller race from the gear	13
	Tachometer drive gear locking-plate T.75555	5	Extractor T.77690 for removing the oil separating breather chamber	14
	Split bush T.74774, pot fixture T.74775,		Vice block T.77207 for facilitating removal	
	and adapter T.74777, for removing idler		of split pin and slotted nut from air compressor drive	15
	gear spindle	6	Press block T.77660 and three-pin adapter	
	Pot fixture T.74776 and extractor T.74778 for pressing out lower ball bearing	7	T.77661 for pressing off bearings and housing from tachometer gear	16
			Pot fixture T.77662 and adapter T.77663	10
	Top wheelcase attached to hydraclamp	8	for pressing out second ball bearing	17
	Press block T.77681 and three-pin adapter T.77682 for partly removing housing		from tachometer drive gear housing Adapter T.77221 for pressing out remain-	17
	and bearings from port generator drive		ing ball bearing from tachometer drive	
	gear	9	gear housing	1.8

This chapter, which is applicable to both the Ghost 48 Mk. 1 and the Ghost 48 Mk. 2, contains instructions for dismantling the top wheelcase, starter gear, air compressor drive housing assembly, and (48 Mk. 2 only) the generator drive assembly, after they have been removed from the engine in accordance with the instructions given in chapter 23. The starter drive gear assembly is identical on both the 48 Mk. 1 and 48 Mk. 2 engines. The 48 Mk. 1 has a separate compressor gear housing, and the 48 Mk. 2 is provided with a detachable generator drive gear assembly; and, therefore, the remainder of this chapter deals separ-

ately with each Mark of engine. Fig. 4 and 12 illustrate respectively, the 48 Mk. 1 and the 48 Mk. 2 top wheelcase, and the figures in parenthesis given in the text relate to components in the appropriate illustration. To facilitate reassembly, all adjusting washers should be secured to their respective components. All ball, needle, and roller bearings should be wrapped in grease-proof paper. Small parts should be placed in a box marked with the engine number. The general information contained in chapter 22 should be referred to as necessary.

GHOST 48 Mk. 1 and 48 Mk. 2

STARTER DRIVE ASSEMBLY

Removing the planet gear assembly

- Using four slave bolts, washers and nuts, assemble the top wheelcase to dismantling-andbuild stand T.74978, Fig. 1.
- Remove blanking cover T.74976 from the starter dog face.
- Remove the two countersunk screws that secure the starter drive casing top cover and remove the cover.
- Remove the plain nuts and spring washers which secure the six studs to the base of the starter drive gear casing and remove the complete starter gear from the top wheelcase.
- 5. Remove the eight securing set-screws and

separate the casing from the bottom cover; the cover will be removed complete with the starter dog and planet gear assembly.

The friction ring in the bottom cover is not to be treated as a seal and must not be removed on overhaul. Mod. 1132 introduced two steel dowel pins to lock this ring in position.

 Withdraw the planet gear assembly and, using stud box T.70473 remove the six studs which secure the annulus gear to the casing.

Dismantling the planet gear assembly

 Position the planet gear assembly in vice block T.74821, Fig. 2; turn down the tabs of the locking washers and remove the three planet gear carrier cover retaining bolts. Remove the




Fig. 1. Top wheelcase bolted to dismantling-and-rebuilding stand T.74978.

assembly from the vice block.

- 2. Position the split fixture T.74822 under the lip of the carrier cover and place the carrier on pot fixture T.74823, Fig. 3.
- 3. Pass adapter T.74824 through the bore of the carrier and press off complete with the ball bearing and bearing retaining circlip.
- 4. Remove the washers, planet gears, roller needles and spindles.
- 5. Pass the internal expanding extractor T.74825 through the bore of the sun gear and tighten the small nut on the extractor to expand the split collet at its location in the end of the sun gear. Tighten the larger nut on the extractor and withdraw the sun gear together




Fig. 2. Vice block T.74821, with planet gear assembly installed.




Fig. 3. Split bush T.74822 pot fixture T.74823, and adapter T.74824, for removing planet gear carrier cover.

with the ball bearing; remove the circlip from the sun gear.

 Position the split bush T.74826 under the ball bearing so that it locates on the inner race. Place the assembly, complete with split bush on pot fixture T.74827; using adapter T.74828 press out the sun gear.

GHOST 48 Mk. 1 TOP WHEELCASE

AIR COMPRESSOR DRIVE HOUSING ASSEMBLY

- Remove the six plain nuts, spring and plain washers which secure the air compressor drive housing assembly (9) to the wheelcase and remove the assembly, Fig. 4.
- Unscrew and remove the six plain nuts and spring washers which secure the compressor housing adapter (63) to the compressor housing assembly; remove the adapter and laminum washer.
- Using Seeger pliers, remove the Seeger circlips which secure the vertical and horizontal gears; withdraw the gears and plain washers.
- Unlock and remove the locking pegs and tab washers which secure the vertical and hori-

zontal gear bushes; remove the bushes and their adjusting washers.

Remove the plain nuts, spring and plain washers which secure the remaining blanking covers; remove the blanking covers.

REMOVING THE GEAR DRIVE ASSEMBLIES

Spare drive

- Remove the circlip from the upper end of the double spare drive gear (25) shank and withdraw the gear.
- Unlock and remove the four plain ¼ in. B.S.F. nuts, tab washers and special bolts

KEY TO FIG. 4

- 1. Oil feed banjo
- 2. Top wheelcase
- 3. Air compressor driving gear shaft circlip
- 4. Air compressor drive gear flange splined sleeve
- 5. Air compressor drive gear flange circlip
- 6. Air compressor driving shaft
- 7. Air compressor drive gear flange washer
- 8. Air compressor drive gear flange circlip
- 9. Air compressor housing
- 10. Tachometer drive gear bearing
- 11. Tachometer drive retaining bolt
- 12. Spare drive gear flange circlip
- 13. Spare drive bearing
- 14. Spare drive starter idler gear ball bearing
- 15. Idler gear shaft cup-washer
- 16. Idler gear shaft ring nut
- 17. Idler gear shaft
- 18. Idler gear distance piece
- 19. Spare drive | starter idler gear
- 20. Spare drive gear tab-washer
- 21. Spare drive gear nut
- 22. Spare drive gear bolt
- 23. Spare drive gear flange
- 24. Spare drive small gear
- 25. Spare drive large gear
- 26. Tachometer drive small gear
- 27. Tachometer drive retaining nut
- 28. Tachometer drive retaining nut tab-washer
- Tachometer drive gear bolt
- 30. Tachometer drive gear nut
- 31. Tachometer drive gear nut tab-washer
- 32. Tachometer drive gear flange
- 33. Tachometer drive large gear
- 34. Air compressor driving shaft
- 35. Air compressor drive gear bearing
- 36. Air compressor drive gear retaining bolt
- 37. Air compressor drive gear retaining nut
- 38. Air compressor drive gear retaining bolt tabwasher
- 39. Air compressor drive gear flange
- 40. Air compressor drive gear
- 41. Starter casing/top cover, joint washer
- 42. Starter casing top cover
- 43. Planet gear
- 44. Planet gear spindle
- 45. Planet gear carrier cover
- 46. Planet gear washer
- 47. Sun gear
- 48. Sun gear ball bearing washer
- 49. Sun gear ball bearing

- 50. Planet gear carrier bolt
- 51. Planet gear carrier tab-washer
- 52. Starter drive annulus gear
- 53. Starter casing
- 54. Adjusting washer
- 55. Starter/generator idler gear shaft
- Starter | generator idler gear distance piece
- Idler gear bearing 57.
- Idler gear retaining bolt 58.
- 59. Generator drive distance piece
- 60. Generator driving gear circlip
- 61. Generator driving gear
- 62. Generator driving gear bearing
- 63. Air compressor housing adapter
- 64. Air compressor housing adapter adjusting washer
- 65. Air compressor housing adapter bush locating
- Air compressor housing bevel gear bush 66 locating peg tab-washer
- 67. Oil pressure gauge connection
- 63. Air compressor housing oil filler cap assembly
- 69. Air compressor housing oil filler assembly
- 70. Air compressor housing adapter bush
- 71. Air compressor housing bevel gear circlip
- 72. Air compressor housing bevel gear bush
- 73. Air compressor housing bevel gear adjusting washer
- 74. Air compressor housing bevel gear circlip
- 75. Air compressor housing bevel gear washer
- 76. Air compressor housing bevel gear
- 77. Air compressor housing bevel gear bush locating peg
- 78. Generator idler gear retaining bolt washer
- 79. Generator idler gear retaining bolt washer
- 80. Generator idler gear retaining bolt split pin
- 81. Generator idler gear retaining bolt nut
- 82. Generator idler gear
- 83. Starter/generator idler gear ball bearing
- 84. Starter/generator idler gear ring nut
- 85. Starter/generator idler gear cup-washer
- 35. Starter/generator idler gear
- 87. Sun gear ball bearing circlip
- 88. Starter dog retaining nut
- 89. Starter dog
- 90. Planet gear carrier
- 91. Starter dog seal circlip
- 92. Starter dog seal
- 93. Bottom cover and bearing assembly
- 94. Planet gear needle bearings
- 95. Generator driving gear





Fig. 4. Ghost 48 Mk. 1 top wheelcase arrangement.







Fig. 5. Tachometer drive gear locking plate T.75555.



Air compressor drive

- Remove the internal sleeve and quill shaft from the bore of the air compressor drive gear (40).
- Unlock and remove the four plain ¼ in. B.S.F. nuts, tab washers and special bolts which secure the two gears together; separate the gears.

Tachometer drive

- Assemble locking plate T.75555 to the wheelcase with its cruciform slots located over the four nuts of the tachometer gear (26 and 33) and secure it in position with the four special bolts and nuts, Fig. 5.
- Unlock and remove the plain nut and tab washer which secures the centre retaining bolt. Withdraw the retaining bolt and the gears.
- Unlock and remove the four plain ¼ in. B.S.F. nuts, tab washers and special bolts which secure the two gears together; separate the gears.

Generator idler gear

- Turn down the tabs of the locking washers and remove the two plain nuts and tab washers which secure the generator idler gear (82) bearing inside the top wheelcase. Remove the gear assembly complete.
- Position the gear assembly in vice block T.74819; remove the retaining bolt split pin, and castellated nut from the centre bolt. Withdraw the centre bolt and double gear; tie all the loose parts together.

Generator and alternator drives

 Remove the two countersunk screws which secure the square flanged generator drive

- distance piece to the upper side of the top wheelcase. Remove the distance piece and the sealing ring.
- Using Seeger pliers remove the Seeger circlips from the generator driving gear (95) Withshank. draw the gear and remove the internal circlip, plain washer, splined sleeve and quill shaft from the bore of the gear (61).




Fig. 6.
Split bush T.74774, pot fixture T.74775, and adapter T.74777, for removing idler gear spindle.




Fig. 7.
Pot fixture T.74776 and extractor T.74778, for pressing out lower ball bearing.

 Using the same sequence of operations, dismantle the alternator drive gear assembly.

Spare drive/starter idler (19)

- Open up the cup locking washer. Use spanner T.73026 to remove the ring nut and remove the cup locking washer.
- Unlock and remove the four ¼ in, B.S.F. nuts and tab washers which secure the gear spindle and remove the spindle.
- Position split bush T.74774 between the double idler gear and the flange of the gear spindle. Place the assembly with the split bush in position, on pot fixture T.74775. Use adapter T.74777 to press out the spindle, Fig. 6.
- 4. Place the double idler gear on pot fixture T.74776; pass expanding extractor T.74778 through the bore of the first ball bearing so that it locates in the bore of the second ball bearing. Tighten the centre nut of the extractor to expand the collet in the bore, thus gripping the bearing inner race; press out the bearing, Fig. 7.
- 5. Remove the distance piece and reverse the

gear assembly on the pot fixture; using adapter T.74779, press out the second ball bearing. Tie all loose parts to the spindle.

Starter/generator idler

1. To dismantle the starter/generator idler single gear assembly (86) using split bush T.74780 in place of T.74774, proceed as for the spare drive/starter idler described above. Tie all loose parts to the gear spindle.

REMOVING THE PLAIN BEARINGS

 Unlock and remove the two plain ¼ in. B.S.F. nuts and tab washers which secure each of the following bearings:—

Spare drive	(13)	
Air compressor drive	(35)	
Tachometer drive	(10)	
Generator drive	(95)	
Alternator drive	(61)	

Remove the bearings and place them in a box marked with the engine number.

MISCELLANEOUS

 Cut the wire locking all the hexagonal blank plugs (introduced by mod. 1097) and remove the plugs and washers.

- Unscrew and remove the cap nut which secures the oil feed banjo to the starboard side of the wheelcase, adjacent to the air compressor drive; remove the banjo, the two washers, and the banjo pillar.
- Remove the oil pressure gauge union adapter which is situated on the port side of the wheelcase adjacent to the alternator driving gear location; remove the joint washer.
- Unscrew and remove the cap nut which secures the hydraulic pump oil feed banjo to the banjo pillar screwed into the oil gallery. Remove the banjo, the two washers, and the banjo pillar.
- Clamp the compressor housing in vice block T.74801 and secure the vice block in a bench vice.
- Using spanner T.74803 remove the oil filler; remove the vice block from the vice and the compressor housing from the vice block.
- Remove the wheelcase from the dismantlingand-assembly stand.

GHOST 48 Mk. 2 TOP WHEELCASE

STARTER DRIVE ASSEMBLY

- Bolt hydraclamp (type H.S.S.A.) to a suitable bench.
- Using two set-screws, secure adapter T.78397 to the hydraclamp.
- 3. Using two slave bolts and nuts, secure the wheelcase to the adapter, Fig. 8.
- Remove and dismantle the planet gear assembly, applying the same sequence of operations given on page 2.

PORT AND STARBOARD GENERATOR DRIVES


1. Remove the circlip from the groove in the serrated end of the gear; withdraw the drive coupling (63) and the driving shaft (56).

Mod, 1176 introduced a 16 in. dia. hole, drilled through the shaft of each drive gear in line with the circlip groove to facilitate removal of the circlip.

 Position the gear on vice block T.77228 and secure the vice block in a vice. Open up the cup locking washer and use spanner T.72554

to remove the ring nut; remove the cup locking washer and the bearing washer.

Unlock and remove the four plain ¼ in. B.S.F. nuts and tab washers which secure the ball bearing retaining plate in position; remove the retaining plate.






Fig. 9. Press block T.77681 and three-pin adapter T.77682 for partly removing housing and bearings from port generator drive gear.

- 4. Remove the assembly from the vice block and place it on press block T.77681 with the bevel gear uppermost; using three-pin adapter T.77682 press off the housing, complete with the ball and roller bearing, to the limit of the pin length, Fig 9. Remove the assembly from the press block.
- 5. Assemble split bush of press block group T.77683 around the gear in the gap between the gear and the housing; place the assembly, gear downwards, on the press block and using adapter T.77684, press the gear clear of the housing, Fig. 10.
- Place the housing on press block T.77683 and use adapter T.77686 to press out both bearings and spacers, Fig. 11.
- Repeat the above instructions to dismantle the starboard generator gear assembly.

GENERATOR DRIVE CASING

Miscellaneous details

- Cut the wire locking the breather banjo cap on the top cover. Remove the cap nut, two washers and the banjo from the banjo pillar; unlock and remove the banjo pillar with its tab washer.
- Cut the wire locking the oil feed union to the generator casing and remove the union and joint washer.
- Remove the eight plain 4 in. B.S.F. nuts, spring and plain washers which secure the top cover to the generator gear casing; remove the top cover.

Two locking tabs replace two of the plain washers and these accommodate locking wire from the breather banjo in the top cover and the oil feed union in the generator casing.




Fig. 10. Press block group T.77683 and adapter T.77684 for pressing port generator drive gear clear of the housing.




Fig. 11. Press block T.77683 and adapter T.77686 for pressing out bearings and spacers.

Idler gear


- 1. Remove the circlip from the gear spindle (39) and the bearing retaining ring from the bore of the idler gear (38).
- 2. Place the centre-screw pad spigot of extractor

KEY TO FIG. 12

- 1. Oil filler cap
- 2. Oil filler assembly
- 3. Air compressor driving gear bush locating peg and washer
- 4. Air compressor driving gear
- 5. Air compressor driving gear bush
- 6. Air compressor drive housing breather plug and washer
- 7. Air compressor drive pinion gear
- 8. Air compressor drive pinion gear bush
- Air compressor drive pinion gear bush locating peg and washer
- 10. Tachometer drive bearing housing
- 11. Tachometer drive, ball bearings
- 12. Tachometer drive, bearing retaining circlip
- 13. Tachometer drive, bearing spacer ring
- 14. Tachometer drive, bearing retaining rings
- 15. Tachometer and generator drive idler gear
- 16. Locating roller bearing
- 17. Roller bearing
- 18. Roller bearing, inner race
- 19. Tachometer and generator drive idler gear
- 20. Adjusting washer
- 21. Bottom cover and bearing assembly
- 22. Starter casing/top cover joint washer
- 23. Starter casing
- 24. Starter casing top cover
- 25. Planet gear carrier bolt
- 26. Planet gear carrier bolt, tab-washer
- 27. Planet gear carrier cover
- 28. Sun gear ball bearing
- 29. Sun gear
- 30. Sun gear washer
- 31. Sun gear bearing circlip
- 32. Planet gear
- 33. Planet gear needle bearing
- 34. Planet gear spindle
- 35. Planet gear washers
- 36. Starter drive annulus gear
- 37. Generator casing joint ring
- 38. Generator drive idler pinion
- 39. Generator drive idler pinion shaft
- 40. Generator drives casing
- 41. Generator vertical drive shaft
- 42. Generator vertical drive bevel gear
- 43. Generator drive top bearing housing seal
- 44. Generator drive adjusting washer
- 45. Generator drive vertical shaft housing
- 46. Generator drive cover gasket
- 47. Generator drive vertical shaft top bearing housing
- 48. Generator drive top bearing retaining cover
- 49. Generator drive vertical shaft top ball bearing
- 50. Breather separating chamber

- 51. Vertical drive shaft ring nut cup locking
- 52. Vertical drive shaft ring nut
- 53. Generator drive cover breather banjo
- 54. Generator drives casing cover
- 55. Generator drive shaft retaining circlip
- 56. Generator drive shaft
- Generator drive bevel gear
- 58. Generator drive roller bearing outer race
- 59. Generator drive roller bearing
- 60. Generator drive bearing housing
- 61. Inner distance piece
- 62. Outer distance piece
- 63. Generator drive coupling
- 64. Generator gears adjusting washer
- 65. Generator drive ball bearing
- 66. Generator drive bevel gear ring nut
- 67. Generator drive bevel gear ring nut cuplocking washer
- 68. Generator drive coupling retaining circlip
- 69. Bearing washer
- 70. Bearing retaining plate
- 71. Generator drive bottom bearing housing
- 72. Bearing retaining ring
- 73. Generator drive bottom bearing outer race
- 74. Generator drive bottom bearing

- 75. Generator drive gear76. Top roller bearing77. Top roller bearing inner race
- 78. Outer bearing spacer
- 79. Inner bearing spacer
- 80. Bearing retaining ring
- 81. Bottom roller bearing82. Bearing retaining circlip
- 83. Starter dog seal assembly
- 84. Starter dog seal assembly circlip
- 85. Starter dog
- 86. Planet gear carrier
- 87. Starter dog retaining nut
- 88. Bearing outer spacer
- 89. Bearing inner spacer
- 90. Bearing retaining circlip
- 91. Bearing retaining ring
- 92. Tachometer drive gear assembly
- 93. Air compressor drive pinion adjusting washer
- 94. Air compressor drive bearing housing
- 95. Top wheelcase
- 96. Air compressor drive gear
- 97. Adjusting washer
- 98. Air compressor adapter
- 99. Air compressor driving gear retaining circlip washer
- 100. Air compressor driving gear retaining circlip
- 101. Oil supply banjos
- 102. Oil feed banjo to compressor housing
- 103. Oil pressure gauge connection



SECTION A-A




Fig. 12. Ghost 48 Mk. 2 top wheelcase arrangement.

T.77677 in the bore of the gear spindle and engage the three claws under the outer gear web clear of the teeth, Fig. 13. Turn the tommy bar of the extractor in a clockwise direction and draw the idler gear, outer roller bearing, spacers and inner roller race off the gear spindle.

3. Adjust extractor T.77680 so that the centrescrew pad spigot fits in the bore of the gear spindle and the two claws engage under the inner race of the inner roller bearing left on the spindle at the completion of Op. 2. Turn the tommy bar in a clockwise direction and draw off the race.

Vertical drive shaft and gears

- Position locking fixture T.77199 to the bottom drive spur gear; using slave nuts, secure the bridge of the fixture to the generator casing; the nuts are located inside the casing.
- Open up the cup locking washers (51) at both ends of the vertical drive shaft (41); using spanner T.77272 remove both ring nuts (52); remove the two cup locking washers.
- Remove the two slave nuts inside the casing and the locking fixture.
- 4. Place the three support legs of extractor T.77690 on the top ball bearing housing; adjust the centre screw until the three claws of the extractor are positioned under the flange of the oil separating breather chamber. Turn the tommy bar anti-clockwise and draw the breather chamber off the vertical shaft, Fig. 14.
- 5. Using a hammer and soft metal drift, tap the upper end of the vertical shaft through the oil separating breather chamber and the ball bearing. From the bottom of the generator casing remove the vertical shaft with the spur gear and the lower, inner, roller race in posi-




Fig. 13. Extractor T.77677 for removing the idler gear, outer roller bearing, spacers, and inner roller race off the gear.




Fig. 14. Extractor T.77690 for removing the oil separating breather chamber.

tion on the spur gear shank.

- Remove the spur gear from the vertical shaft together with the inner roller race.
- 7. Use claw extractor T.77687 to remove the inner roller race from the spur gear shank.
- Remove the lower vertical drive bearing housing retaining ring.
- Unlock and remove the four plain ¼ in. B.S.F. nuts and tab washers which secure the bearing housing to the bottom wheelcase; remove the housing.
- Position the housing on press block T.77688 and using adapter T.77689, press the outer roller race out of the housing.
- Unlock and remove the four plain ¼ in. B.S.F. nuts and tab washers which secure the upper ball bearing housing.
- Remove the bevel gear, ball bearing, and the housings from the wheelcase; remove the adjusting washer.
- 13. Place the gear, bevel uppermost, on press block T.77691 and using three-pin adapter T.77692, press out the bearing and its housing.
- Position the flange of the ball bearing housing on press block T.77693 and using adapter T.77694, press the ball bearing out of the housing.

MISCELLANEOUS DETAILS

- Position the wheelcase so that the air compressor housing is uppermost.
- Disconnect the split rings from each end of the oil filler and remove the oil filler cap and chain.
- 3. After removing slave nuts, washers and dis-

tance pieces where applicable, remove the following blanks :—

Part No.	Description
T.77216	 Generator housing face
19138/3	 Tachometer drive face
49237	 Compressor drive face

- Remove the two set-screws which secure the adapter to the air compressor housing; remove the adapter and the adjusting washer and tie the adjusting washer to the adapter.
- Turn the wheelcase through 180 deg. and remove the four slave nuts which secure blanking cover T.77215 to the bottom face of the wheelcase. Remove the blanking cover.

REMOVING AND DISMANTLING THE GEAR ASSEMBLIES

Removing the air compressor and tachometer gear assemblies

- Unlock and remove the eight ¹/₄ in. B.S.F. nuts and tab washers which secure the compressor and tachometer drive gear assembly (96 and 92).
- 2. Remove the two assemblies simultaneously.
- Unlock and remove the four ¼ in, plain B.S.F. nuts and tab washers which secure the idler gear assembly (19).

Dismantling the compressor drive gears

- Using Seeger pliers remove the retaining circlip and washer from the compressor gear assembled to the compressor drive adapter and withdraw the gear.
- Unlock and remove the locating peg and tab washer which secures the compressor gear bush to the adapter; remove the bush.
- Unlock and remove the four plain ¼ in. B.S.F. nuts and tab washers which secure the com-




Fig. 15. Vice block T.77207 for facilitating removal of split pin and slotted nut from air compressor drive.




Fig. 16. Press block T.77660 and three-pin adapter T.77661 for pressing off bearings and housing from tachometer gear.

pressor drive (96) to the compressor drive housing (94).

- Secure vice block T.77207 in a vice and clamp the compressor drive gear in it, (Fig. 15). Withdraw the split pin and remove the slotted nut and plain washer from the bevel gear extension.
- Remove the gear from the vice block and separate the gears. The spur drive gear is internally splined to accommodate the splined male extension of the bevel gear.
- Unlock and remove the locating peg and tab washer which secure the bush; remove the bush.

Dismantling the tachometer drive gear (92)

- Using Seeger pliers remove the circlip from the tachometer gear shank.
- Position the assembly, small gear downwards, on press block T.77660 and using three-pin adapter T.77661, press off the housing and the two ball bearings, Fig. 16.
- Place the housing and the two ball bearings on pot fixture T.77662 flange uppermost.
- 4. Pass the collet of expanding adapter T.77663 through the bore of the nearest ball bearing and locate it inside the bore of the second one; utilising the centre bolt, expand the collet. Press the bearing out of the housing, Fig. 17.
- 5. Remove the two retaining rings and spacer




Fig. 17. Pot fixture T.77662 and adapter T.77663 for pressing out second ball bearing from tachometer drive gear housing.

from the housing. Reverse the housing on the press block and using adapter T.77221, press out the remaining ball bearing, Fig. 18.

Dismantling the idler gear

- 1. Using Seeger pliers remove the circlip from the idler gear spindle (15).
- Position the assembly, large gear uppermost, on press block T.77718 and using adapter T.77661, press the gear and roller bearings of the spindle.




Fig. 18. Adapter T.77221 for pressing out remaining ball bearing from tachometer drive gear housing.

- 3. Remove the roller bearing retaining ring from the bore of the gear.
- 4. Place the roller bearing and gear assembly, small gear downwards, on pot fixture T.77660 and using adapter T.77721, press the roller bearings and spacers out of the gear bore.

