

Chapter 2

CONTROLS

ENTRY AND EXIT

WARNING

Before leaning into, or entering, the cockpit, refer to the LETHAL WARNING card at the beginning of this book.

Entry, normal method

1. Entry to the cockpit is by way of the canopy. The external canopy-operating controls (*fig.1*) are located behind a panel labelled CANOPY EXTERNAL RELEASE HANDLES, in the port side of the spine, aft of the cockpit. Opening the canopy is effected by pulling the locking handle and then pushing the nearby spring-loaded tumbler switch. The locking handle controls inflation of the canopy seal and in the unlocked position a CANOPY warning indicator in the cockpit is illuminated whilst operation




Fig.1. Canopy external controls

RESTRICTED

of the canopy switch actuates a warning buzzer. Closing and locking of the canopy is effected externally by reversal of the operations described.

Note...

Low hydraulic services accumulator pressure (rectifiable by use of the hand pump, Chap.4) would be a likely cause of failure of the canopy to open.

Entry, stand-by method

2. In the event of the canopy remaining in the closed or partially-open position due to electrical or hydraulic system failure, opening is effected by first pulling the tumbler switch, then ensuring that the canopy is closed and pushing the locking handle into the locked position. The top of the red emergency release handle is then depressed and the canopy prised open and lifted manually.

Exit, normal method

3. The canopy is opened from inside the cockpit by pulling up the canopy control handle at the port side of the seat and operating the exposed control switch upwards to OPEN. The controls are inter-connected with the external controls so that visual and audible warnings are given in the appropriate circumstances.

Exit, stand-by method

4. In the event of the canopy remaining in the closed or partially-open




Fig.2. Canopy external jettisoning control

position due to electrical or hydraulic system failure, opening is effected by first operating the control switch downwards to CLOSE, then ensuring that the canopy is closed and pushing the canopy control handle downwards to the locked position. The EMERGENCY CANOPY JACK RELEASE lever (located beneath the port canopy sill) is then operated and the canopy control handle pulled upwards. The canopy is then raised manually.

Emergency methods

5. In emergency entry or exit the canopy is jettisoned by pulling outwards the T-shaped handle on the external emergency canopy-jettison panel, or pulling upwards the spade-grip handle on the cockpit floor at the port side of the seat, respectively.

WARNING...

The canopy will fall aft of the aircraft, if the latter is standing level, and ground personnel must be warned to stand clear.

CONTROLS AND INSTRUMENTS

6. For location of controls and instruments refer to fig.4 and the key in this chapter. Engine and fuel system cockpit controls are illustrated in Chapter 5.

1941




Fig.3. Control column handle




Fig. 4.

RESTRICTED

KEY TO FIG.4

1943

- 1 CANOPY CONTROL HANDLE
- 2 CANOPY-JETTISON HANDLE
- 3 SEAT-HEIGHT ADJUSTMENT SWITCH
- 4 RUDDER TRIM SWITCHES
- 5 RAIN DISPERSAL/DE-ICING SWITCH
- 6 AIR BRAKES SELECTOR SWITCH
- 7 WHEEL-BRAKE LEVER
- 8 HYDRAULIC FEEL SELECTOR SWITCH
- 9 EMERGENCY CANOPY JACK RELEASE HANDLE
- 10 THREE-AXIS TRIM AND AIR BRAKE POSITION INDICATOR
- 11 AUTOPILOT TRIM INDICATOR
- 12 FLAPS SELECTOR SWITCH
- 13 ALIGHTING GEAR CONTROL AND INDICATOR
- 14 TWO-AXIS TRIM SWITCH
- 15 FLAPS POSITION INDICATOR
- 16 FIRE EXTINGUISHER SWITCHES/WARNING LIGHTS
- 17 WHEEL BRAKES ACCUMULATOR PRESSURE GAUGE
- 18 STANDARD WARNING INDICATOR UNIT
- 19 SERVICES HYDRAULIC PRESSURE GAUGE
- 20 EJECTOR SEAT/CANOPY SAFETY PIN STOWAGE (behind shroud)
- 21 INVERTER SWITCH
- 22 INVERTER CHANGE-OVER INDICATOR
- 23 ATTITUDE INDICATOR
- 24 RUDDER BAR ADJUSTER LOCK RELEASE HANDLE
- 25 OXYGEN CONTENTS INDICATOR
- 26 CANOPY UNLOCKED WARNING INDICATOR
- 27 AUXILIARY WARNINGS PANEL
- 28 AUXILIARY WARNINGS PANEL TEST SWITCH
- 29 TAXYING LIGHT SWITCH
- 30 FLIGHT CONTROL SYSTEM - PILOT'S CONTROLLER
- 31 BATTERY SWITCH
- 32 OXYGEN DEMAND REGULATOR
- 33 ANTI-G AIR SHUT-OFF COCK
- 34 ANTI-G VALVE
- 35 INSTRUMENT MASTER SWITCH
- 36 EMERGENCY OXYGEN SUPPLY CONTROL

