

SECTION 3

AIRFRAME

LIST OF CHAPTERS

Note.—A list of contents appears at the beginning of each chapter

- 1 Fuselage
- 2 Main plane
- 3 Tail unit
- 4 Flying controls
- 5 Alighting gear
- 6 Hydraulic system
- 7 *(Not applicable to this aircraft)*
- 8 A Air conditioning system
B Air ventilated suit system *(post Mod.3243 –
B (1) Mk.6 aircraft only)*
C De-misting systems
- 9 *(Not applicable to this aircraft)*
- 10 Oxygen system
- 11 Emergency equipment

RESTRICTED

Chapter 1 FUSELAGE

LIST OF CONTENTS

	<i>Para.</i>		<i>Para.</i>		<i>Para.</i>
<i>Introduction</i>	1	<i>Main spar centre section</i>	16	REMOVAL AND ASSEMBLY	
DESCRIPTION		REAR FUSELAGE			
<i>General</i>	2	<i>General</i>	17	◀ <i>General information</i> ▶	30
FRONT FUSELAGE		<i>Survival pack stowages</i>	18	Canopy	
<i>General</i>	3	<i>Tail plane attachments</i>	19	Removal	31
<i>Nose fairing</i>	4	<i>Fin stub and fin attachments</i>	20	Assembly	32
<i>Pressure bulkhead</i>	5	<i>Rudder stub</i>	21	Fitting a new canopy	33
<i>Canopy</i>	6	<i>Rear fairing</i>	22	Fitting a canopy D.V. window	34
<i>Crew escape hatch</i>	7	SERVICING		Crew escape hatch	
<i>Crew escape hatch (post Mod.3706)</i>	8	<i>Bomb/flare door jack adjustment</i>		Removal	35
<i>Equipment compartments</i>	9	Forward jack	23	Assembly	36
<i>Seat guide rails</i>	10	Aft jack	24	Fitting a crew entrance door	37
CENTRE FUSELAGE		<i>Bomb/flare door adjustment</i>	25	<i>Nose fairing</i>	39
<i>General</i>	11	<i>Bomb/flare door stay adjustment</i>	26	<i>Pressure head</i>	40
<i>Fuel tanks compartment</i>	12	<i>Lubrication</i>	27	<i>Bomb/flare door jack</i>	41
<i>Bomb bay</i>	13	◀ <i>Ballast weights (pre Mod.3484)</i>	28	<i>Bomb/flare door</i>	42
<i>Bomb and flare doors</i>	15	<i>Ballast weights (post Mod.3484)</i>	29 ▶	<i>Slinging</i>	43

LIST OF ILLUSTRATIONS

	<i>Fig.</i>		<i>Fig.</i>		<i>Fig.</i>
<i>Key diagram</i>	1	<i>Nose fairing removal</i>	8	<i>Rear fuselage removal</i>	13
<i>Front fuselage</i>	2	<i>Bomb/flare door removal and installation</i>	9	<i>Rear fairing removal</i>	14
<i>Centre fuselage</i>	3	<i>Front fuselage removal</i>	10	<i>Canopy removal and assembly</i>	15
<i>Rear fuselage</i>	4	<i>Attachment bolt details - front</i>		<i>Crew escape hatch removal</i>	16
<i>Bomb/flare door adjustment</i>	5	to centre fuselage	11	<i>Slinging - front and centre fuselage</i>	17
◀ <i>Ballast weights</i>	5A ▶	<i>Attachment bolt details - rear</i>		<i>Slinging - rear fuselage</i>	18
<i>Bomb/flare door retaining cable</i>	6	to centre fuselage	12	<i>Hatch locking pin settings</i>	19
<i>Position of special canopy bolts</i>	7				




Fig. 1. Key diagram

Introduction

1. This chapter gives a general description of the fuselage structure, together with the procedure for dismantling the structure into its main components.

DESCRIPTION

General

2. The all-metal fuselage is circular in section and of stressed-skin construction throughout. Transport joints at frames 12 and 31 divide the fuselage into three sections, front, centre and rear. Except at the transport joints and elsewhere where reinforcement is necessary, the structure is supported by flanged channel-section frames, which are cut-away on their outer edges to accommodate the fore-and-aft stringers. Fig. 1 illustrates the disposition of the fuselage sections and frames within the structure.

FRONT FUSELAGE

General (fig. 2)

3. The front fuselage comprises a transparent plastic nose fairing, a pressure cabin sealed by a pressure bulkhead, and a nose undercarriage well and three equipment compartments positioned between the

pressure bulkhead and the transport joint. The main floor of the cabin extends from the pressure bulkhead to frame 1, where an extension ramp into the nose is fitted; a built-up structure at the pilot's station forms the pilot's floor and raises his seat above the level of the main floor. A horizontal diaphragm, aft of the pressure bulkhead, divides the area between the bulkhead and the transport joint into an upper equipment bay and a lower compartment, the latter being divided by two vertical diaphragms into the nose undercarriage well and flanking equipment compartments. The structure forward of the pressure bulkhead is cut away and suitably reinforced on the starboard side to accommodate the entrance door, and on the top to allow for the canopy and crew escape hatch, the canopy hatch being reinforced by a circular-section coaming tube. S.T.I./Canberra/120 introduces two 1/8in. dia. drain holes, one on the port side, and one on the starboard side of the

coaming tube at the lowest points. These holes which facilitate the periodical draining of any water accumulation, are plugged with self-tapping screws rolled in Bostik to prevent loss of cabin pressure. Windows are provided in the port side at the navigator's position and in the underside of the nose at the air bomber's action station. Aft of the pressure bulkhead, openings are provided in the structure to accommodate a hatch in the fuselage top, for access to the upper equipment bay, and the nose undercarriage doors in the underside. Access doors are also fitted to the equipment compartments which flank the nose undercarriage well; these, like the undercarriage doors, are hinged to the structure. Static vent plates are fitted, one on either side of the front fuselage.

Nose fairing

4. The nose fairing consists of inner and outer transparent plastic sheets forming a




Fig. 2. Front fuselage

sandwich, incorporating a flat toughened-glass sighting panel slightly offset to starboard. It is secured to the forward end of the structure by retaining ring segments and screws; it may be readily removed to facilitate servicing forward of the instrument panels. The pitot head mounting is situated in the centre of the nose.

Pressure bulkhead

5. The pressure bulkhead is inclined aft across the fuselage from between frames 7 and 8 at the bottom to frame 10 at the top; it completely seals off the pressure cabin from the remainder of the fuselage. The bulkhead is reinforced on its rear face by vertical and horizontal channel-section

members.

Canopy

6. The canopy consists of two blown transparent plastic sheets forming a sandwich and separated by an edge spacing piece. Two aerials are suppressed within the sandwich, and a hinged direct-vision

RESTRICTED




Fig. 3. Centre fuselage

window of laminated glass is fitted to the forward face, offset slightly to port. The canopy is secured by 32 attachment bolts to the coaming tube surrounding the fuselage aperture.

◀ Crew escape hatch

7. The navigator's escape hatch is of metal construction reinforced on the inside by two channel-section cross-members and angle-section stringers, and is secured to

the fuselage cut-away section boundary member by 34 explosive attachment bolts. The hatch is provided with two flush-fitted transparent plastic windows.

Crew escape hatch (post Mod.3706)

8. Mod.3706 introduces a metal hatch which supersedes the frangible hatch introduced by Mod.2633 or 2634. The new metal hatch is secured to the fuselage in a manner similar to that described in para.7: provision is made for mounting a periscopic sextant. ▶

Equipment compartments

9. Three equipment compartments are located between the pressure bulkhead and the transport joint frame 12. The upper compartment is above the nose undercarriage well, the well roof forming the compartment floor, access to this compartment is by a removable hatch on the top of the fuselage. The other compartments, one on each side of the nose undercarriage well, are formed by the sides of the well

and the fuselage skin; each compartment is fitted with an access door, which is hinged at its lower edge to the fuselage side.

Seat guide rails

10. The pilot's ejection seat guide rail is attached to two longitudinal channel-section members on the pilot's floor and to two brackets on the canopy coaming cross-tube. The air-bomber's and navigator's ejection seat guide rails are bolted to the front face of the pressure bulkhead and anchored to angle-section brackets on the cabin floor.

CENTRE FUSELAGE

General (fig.3)

11. The centre fuselage consists of upper and lower compartments. The upper compartment houses the main fuel tanks, while the lower compartment forms the bomb bay. The effective structure consists of the portion above the floor, which is of double-skinned stressed-skin construction with rolled Z-section stringers stiffening both the outer and inner skins. Transverse channel-section girders, the ends of which form the bomb bay, skirt contour, provide the main support for the arched fuel tank floor while secondary support is provided by fore-and-aft channel-section members. Two attachment lugs, each having a 2 B.A. tapped blind hole, are provided on the underside of the fuselage at frames 12 and 29 for the purpose of locating sighting rods for compass alignment. To enable visual inspection of the main plane forward pick-up points, inspection panels, introduced by Mod.3710, are riveted to the fuselage skin in the main wheel wells aft of frame 17.

Fuel tanks compartment

12. The fuel tanks compartment occupies

the upper half of the centre fuselage and extends from frame 12 to frame 29. Divided at the spar frame by a bulkhead, the front portion houses two rigid self-sealing fuel tanks and the rear portion a collapsible fuel bag. The floor of the forward portion is lined to prevent chafing of the fuel tanks against the floor rivets. In the top of the double-skin structure are seven small reinforced cut-away sections, four of which accommodate fuel tank access panels, while the other three house the fuel tank filler caps.

Bomb bay

13. The bomb bay, extending from frame 13 to frame 29, is formed by the lower half of the fuselage. Frames 13 and 29 are of extruded channel-section, the lower portion of these frames carrying a bulkhead plate reinforced by channel-section stiffeners. The transverse girders supporting the fuel tank compartment floor are extended downwards and reinforce the skirt along which the longerons run. The transverse girders at frames 17 to 21, provide support for the longitudinal bomb beam, while those at alternate frames from 15 to 27 are channelled at the ends to accommodate the bomb door rollers. An access panel, introduced by Mod.1199 on to frame 29 bulkhead, provides for visual inspection of the bomb bay without opening the bomb doors. Mod. 1913 introduces to B(I) Mk.6 aircraft an inspection panel on both the port and starboard sides of the bomb bay skirt at frame 16. A mirror, positioned immediately above each panel, enables visual inspection of the bomb bay to be made when the gun pack is fitted and the flare doors are closed.

14. On B(I) Mk.6 aircraft embodying Mod. 3154, provision is made in the bomb bay for a stores deflector plate which is in-

stalled when the aircraft is employed in the L.A.B.S. role. The honeycomb-sandwiched light-alloy plate slopes downwards and aft from frame 27, where its fork-end attachments employ the same pick-up points as the gun pack rear attachments, to frame 29, where two additional lugs protrude through the bulkhead to mate with the deflector plates lower attachment points.

Bomb and flare doors

15. The bomb doors are of light gauge duralumin construction, each door consisting of an inner and outer skin reinforced by two longitudinal channel-section members, internal stringers and ribs. Each door is supported at the ends by forged light-alloy hinged brackets, and by rollers operating in the channelled ends of the transverse girders of the fuselage at seven stations along its length. On B(I) Mk.6 aircraft when a gun pack is installed, flare doors are fitted in replacement of the bomb doors, and are cut away at the aft end to allow for the gun pack, which projects below the level of the closed doors.

Main spar centre section

16. Two reinforced frames, interspaced by vertical channel-section members and skinned to form a double plate bulkhead, continue the main spar through the fuselage. They are bounded by extruded angle-section members and carry between them the main plane main spar pick-ups, which have forked ends for the boom attachments and an extruded centre for the attachment of the spar web.

REAR FUSELAGE

General (fig.4)

17. At the bottom of the rear fuselage, between frames 31B and 33, a hatch is




Fig. 4. Rear fuselage

hinged to a small cut-away section reinforced by an angle-section boundary member. The hatch opens outwards and provides access to No.3 fuel tank, camera bay, bomb bay inspection panel (Mod.1199), and the elevator and rudder push-pull tubes in the rear fuselage; a hand rope suspended from the upper portion of frame 32 facilitates entry. A safety strap attached to the hatch and the aircraft structure prevents the edge of the hatch, when open, from making contact with the ground should the aircraft be heavily


loaded. A picketing eye-bolt stowage, attached to frame 32, is positioned on the port side immediately above the hatch frame, and a stowage for six engine starter cartridges is on the starboard side between frames 31B and 32. Mod.3224 introduces, to B(I) Mk.6 aircraft, a stowage for the wing pylon cover plates, between frames 32 and 33 on the starboard side. A tail bumper, on which is mounted a moulded rubber pad, is fitted to the bottom of the fuselage between frames 40 and 42.

Survival pack stowages

18. Mod.2186 introduces stowage racks for three survival packs, fitted one between frames 31B and 33, and two between frames 36 and 37. The position of the stowages is indicated on the outer surface of the fuselage skin.

Tail plane attachments

19. An extension to the lower half of the fuselage, aft of frame 42 and extending to frame 46, forms a platform for carrying the



'A'	FORWARD DIMENSION	53.50" ± 0.5"
	AFT DIMENSION	45.00" ± 0.5"
'B'	DIMENSION	43.75" ± 0.5"
'C'	FORWARD JACK	18.625" ± 0.25"
	AFT	18.50" ± 0.25"

Fig.5. Bomb/flare door adjustment

RESTRICTED

variable-incidence tail plane and its electrical actuator; it is braced by a diagonal strut extending from the top of frame 42 to the rear of the extension. Attached to the rear of frame 42 are two brackets which carry the tail plane pivot pins, while on each side of the fuselage, extending forward of frame 42, is a narrow, integral tail plane leading-edge stub.

Fin stub and fin attachments

20. Attached to the top of the fuselage

structure, between frames 37 and 42 are eight diaphragms forming the structure of the fin stub, the four diaphragms above frames 39 and 42 being reinforced by longitudinal angle-section members. The diaphragm at frame 42 carries the fin post attachment lug, secondary attachment points for the fin being provided on the diaphragms at frames 39 to 42A.

Rudder stub

21. The top of the fuselage structure is extended aft of frame 42 to form the rudder

stub. The extension is formed by six angle-sectioned webbed frames and four longitudinal angle-section members; the resulting box is plated with skinning on each side.

Rear fairing

22. The rear fairing is a detachable structure to which the metal skin covering for the rear fuselage extension is attached. It is built up to form one complete section and is attached to the rear fuselage at frames 42F and 46.

SERVICING

Bomb/flare door jack adjustment

Forward jack (fig.5)

23. The distance between the pin centres of the forward jack, measured between the jack attachment lug and the guide link attachment point on the jack piston rod link end, should be 18.625 in. \pm 0.25 in. (*dimension 'C'*) when the jack is fully contracted; this is a manufacturer's setting which should not normally need alteration. If, however, adjustment should be necessary:

- (1) Remove the jack (*para.41*).
- (2) Remove the locking wire from the locknut on the jack piston-rod and slacken the locknut
- (3) Adjust the link end of the piston-rod until the distance between the centres of the guide link attachment point and jack attachment lug is 18.625 in. \pm 0.25 in.
- (4) Tighten and wire-lock the locknut on the jack piston-rod.

(5) Replace the jack and bleed the circuit.

Aft jack

24. The adjustment of the aft jack is the same as for the forward jack (*para. 23*), except that the distance between the pin centres, measured between the jack attachment lug and the guide link attachment point on the jack piston rod link end, should be 18.50 in \pm 0.25 in. (*dimension 'C'*).

Bomb/flare door adjustment (fig.5)

25. The pin centres of the bomb door actuating links are nominally set at 13.37in. At this setting the bomb doors, when fully open should be 53.50 in. \pm 0.50in. apart at the forward end, and 45.00in. \pm 0.50in. apart at the rear end, measured inside the metal faces of the door edges (*dimension A*). When the doors are fully closed the hydraulic jacks must be fully, extended and there should be a clearance of 0.20 in. \pm 0.06 in. between the metal faces of the door edges. The actuating link setting (13.37 in.) re-

mains the same when flare doors are fitted to B(I) Mk.6 aircraft with a gun pack installed. When fully open, the flare doors should be 53.50 in. \pm 0.50 in. apart at the forward end, and 43.75 in. \pm 0.50 in. apart at the aft end (*dimension 'B'*), measured inside the metal faces of the door edges. With the flare doors fully closed there should be a clearance of 0.35 in. \pm 0.15 in. around the gun pack. To adjust the bomb/flare door actuating links:

- (1) Fully open the bomb/flare doors and fit retaining cables (*Ref.No.26FZ/95012*) (*fig.6*) to the brackets on the front and rear hinge brackets.
- (2) Remove the quick-release pip-pin from the door actuating link to be adjusted.
- (3) Slacken the locknut on the actuating link and turn the fork end as required until the pin centres are 13.37 in. \pm 0.25 in. apart.

RESTRICTED

PRE - MOD. 3484		
PERMANENT BALLAST		
APPROX. WEIGHT (LB)	PART NO.	
1 48.0	EA3.84.25	
2 48.0	EA3.84.25	
3 48.0	EA3.84.25	
4 18.0	EA3.84.23	

INCLUDED IN BASIC WEIGHT

POST MOD. 3484			
ADJUSTABLE BALLAST			ALTERNATIVE WOOD BLOCK PART NO.
APPROX. WEIGHT (LB)	PART NO.		
1 48.0	EA3.84.25		EA3.84.29
2 48.0	EA3.84.25		EA3.84.29
3 48.0	EA3.84.25		EA3.84.29
4 18.0	EA3.84.23		EA3.84.27
5 61.0	EB6.84.37		
6 62.0	EB6.84.39		
7 62.0	EB6.84.39		
8 55.0	EB6.84.41		




Fig. 5A. Ballast weights
◀ (New illustration) ▶

RESTRICTED




Fig. 6. Bomb/flare door retaining cable

◀ (Title amended) ▶

(4) Tighten the locknut on the actuating link, and reconnect the actuating link to the hinge bracket by fitting the pip-pin.

(5) Remove the retaining cables and check the operation of the bomb/flare doors.

Bomb/flare door stay adjustment (fig.5)

26. The pin centres of the bomb/flare door forward and aft stays are nominally set at 15.035 in \pm 0.235 in and 15.835 in \pm 0.215 in respectively. These are manufacturer's settings which should not normally need alteration. If, however, adjustment should be necessary:

(1) Fully open the bomb/flare doors and fit retaining cables Ref. No. 26FZ/95012 (fig.6) to the brackets on the front and rear hinge brackets.

(2) Disconnect the fork end of the stay from the eyebolt on the bomb/flare door hinge bracket.

(3) Slacken the locknut on the stay and turn the fork end of the stay, as required, until the distance between the pin centres is 15.035 in \pm 0.235 in (forward stays) and 15.835 in \pm 0.215 in (aft stays).

(4) Tighten the locknut on the stay and connect the fork end of the stay to the eye-bolt on the bomb/flare door hinge bracket.

(5) Remove the retaining cables and check the operation of the bomb/flare doors.

Lubrication

27. The hinges of all access doors, the

entrance door hinges and locking plungers, and the bomb door and battery tray rollers are lubricated with grease XG-278. The entrance door locking handle and seat height adjustment mechanisms are lubricated with oil OX-14. The bearings of the bomb/flare doors operating mechanism are pre-packed on assembly with grease XG-278.

Ballast weights (pre Mod.3484)

28. To help maintain the C.G. position within the C.G. range (Sect.2, Chap.3), five lead ballast weights with fittings, totalling approximately 287 lb (for individual weight values refer to fig.5A), are permanently fitted on the starboard side of the aircraft between frames 1 and 2, beneath the air bomber's ramp. They include a base weight, bolted to the floor, surmounted by a box in which the remaining four weights are carried and clamped in position by a metal strap.

Ballast weights (post Mod.3484)

29. Upon the introduction of Mod.3484 to B(I)Mk.6 aircraft, the ballast referred to in para.28, with the exception of the base weight and ballast box, becomes adjustable and four additional adjustable weights (for individual weight values refer to fig.5A), giving an overall maximum adjustable weight of 402 lb, are provided for fitting into a box located forward of frame 1, beneath the forward section of the air bomber's ramp. Wooden blocks of similar form to the adjustable ballast weights item 1, 2, 3 and 4 are provided and must be fitted when a weight is removed. On removal of ballast weights item 5, 6, 7 or 8 wooden blocks of similar form and of local manufacture must be fitted. Having determined the amount of ballast required for the aircraft role (Sect.2, Chap.3B), ballast weights to agree to that weight must be fitted.

Note...

Any permutation of ballast weights may be ▶

◀ fitted to attain the required amount of ballast. A tolerance of ± 10 lb to the calculated adjustable weight required is permissible. ▶

REMOVAL AND ASSEMBLY

General information

30. The procedure for dismantling the fuselage into its main components is given pictorially in fig.8 to 16. Only the dismantling operations are given in detail since assembly is generally a reversal of this detail; where this is not the case the fact is noted.

Canopy (fig.15)

Removal

31. To remove the canopy:

WARNING

Before proceeding with the removal of the canopy, ensure that the jettison master switch is in the SAFE position. Remove the detonator circuit fuses and disconnect the internal service batteries, the emergency batteries, and any external electrical supply.

- (1) Disconnect the two aerial plugs.
- (2) Disconnect the two D.V. window plugs.
- (3) Remove the six 2 B.A. screws securing the canopy fairing; and remove the fairing, sliding clear of the section attached to the crew escape hatch.
- (4) Unfasten the cockpit lighting panel, which is secured by self-tapping screws to the coaming tube, and allow it to hang with its weight supported by slings made from soft wire.
- (5) Disconnect the hot air diffuser pipe at its control on the port side, unscrew the

self-tapping screws and remove the pipe and forward blast shield. Blank off the exposed end of the hot air pipe.

(6) Disconnect and blank off the three de-misting hoses, and remove the two air-driers (Sect.3, Chap.8).

(7) From the navigator's compartment remove any equipment from the cross-tube that is likely to hinder canopy removal.

(8) Remove the eight blast plates which are secured to the coaming tube.

(9) Remove the detonators from the explosive bolts (A.P.1661F, Vol.1, Sect.6).

(10) Unscrew and remove the 32 explosive bolts.

(11) Raise the forward end of the canopy, lift clear of the rear hinge and remove the canopy from the aircraft.

(12) Remove the seal and all traces of sealant from the coaming tube and around the seating pads. Any white spots approx. 0.25 in dia. which may be painted on the coaming tube, must not be obliterated.

Assembly

32. Before finally assembling the canopy the clearance between the canopy edge members and the coaming tube pads must be checked (A.P.101B-0400-6, Part 1, Chap.2). To assemble the canopy:

- (1) Fit a new rubber sealing strip

A.P.101B-0400-6, Part 1, Chap.2.

Note...

No adhesive is to be used between the canopy and the Linatex sealing strip.

(2) Offer up the canopy and align it by inserting four locating pins Ref.No. 26FZ/95491 in the following positions:— forward centre, aft centre, port centre and starboard centre.

(3) When correctly positioned, withdraw each pin in turn and fit slave bolts Ref. No. 26FZ/95490. Fit the slave bolts to the remaining 28 bolt holes.

(4) Tighten diametrically opposite bolts in turn, to a torque loading of 150 lb in.

(5) Remove each slave bolt and its diametrical opposite in turn, and fit and tighten the 32 explosive bolts. The torque loading of 150 lb in must not be exceeded.

Note...

(a) The threads of the explosive bolts must be lightly lubricated with grease
◀ XG-278, before fitting. ▶

(b) Where a white spot approx. 0.25 in dia. has been painted on the coaming tube, a washer Ref.No.28W/12442 must be fitted between the shoulder of the bolt and the lower bush of the coaming tube.

(c) Special bolts Ref.No. 26FZ/1594

are fitted to bolt holes No. 2 and 3 from the centre line of the forward port side of the canopy (fig.7). Do not count that bolt hole which is on the centre line of the aircraft,

- (6) Refit the canopy fairing, tighten the six 2 B.A. screws, and lock by centre-punching the edge of the slots.
- (7) Refit the eight blast plates.
- (8) Refit the equipment, if any, removed in operation (7), para.31.
- (9) Refit the two air-driers and connect the three de-misting hoses (Sect.3, Chap.8).
- (10) Refit the hot air diffuser and the forward blast shield, and secure by fitting the self-tapping screws.
- (11) Connect the diffuser to the hot-air




Fig. 7. Position of special canopy bolts

pipe at its control on the port side.

(12) Position the cockpit lighting panel, remove the temporary slings, and secure by fitting the self-tapping screws.

(13) Pressure test the cabin (Sect.3, Chap.8).

(14) Fit the detonators into the explosive bolts (A.P.1661F, Vol.1, Sect.6).

Note...

(1) It is important that the detonator Ref. No. 12G/1278, the distance tube Ref. No. 26FZ/1806 for the standard canopy bolt, or Ref.No. 26FZ/1808 for the special-to-type canopy bolt and the spring Ref. No. 26FZ/1579 be assembled as shown in fig. 15. Prior to inserting the spring and screwing the cap home, using a gauge of local manufacture, check the dimension between the distance tube and the end of the bolt; this should be 0.38 in \pm 0.04 in for the standard bolt and 0.78 in \pm 0.04 in for the special-to-type bolt.

(2) If the position of any detonator lead is disturbed, ensure that at no point is it to run closer than two inches to the run of the V.H.F. aerial connector. At any point where it is necessary for the detonator leads to cross the aerial connector, the cross-over is to be at 90 deg to the run of the connector.

- (15) Connect the two D.V. window heating plugs.
- (16) Connect the two aerial plugs.
- (17) Reconnect the electrical supplies.

Fitting a new canopy

33. The procedure for fitting a new canopy is described in A.P.101B-0400-6, Chap.2.

Fitting a canopy D.V. window

34. When fitting a D.V. window ensure that the window fits correctly on its seating. This can be ascertained by using a marking medium on the seat, and closing the window. A 100 per cent marking must be obtained. An incorrect seating can be rectified by the addition or subtraction of shims between the hinge bracket and canopy. Pressure test the cabin (Sect.3, Chap.8) after any adjustment has been made.

Crew escape hatch (fig.16)

Removal

35. The procedure for the removal of the crew hatch is detailed in the following operations. Where the removal is undertaken in order to fit a new crew hatch, the removal operations are fully described in A.P. 101B-0400-6, Chap.2.

WARNING

Before any work on the crew hatch is undertaken the safety precautions detailed on the LETHAL WARNING marker card must be observed.

- ◀ (1) On aircraft embodying Mod.3776 disconnect, from the rear of the hatch the ejection seat secondary firing-cables. ▶
- (2) Remove the canopy aft fairing (detail A).
- (3) Remove the 68 - 1/4 in attachment screws securing the hatch to the bolt frame (detail B).
- (4) Remove the hatch by easing it up-

RESTRICTED






Fig. 8. Nose fairing removal

RESTRICTED

wards at the forward end to allow the screwed spigots to clear the sockets in the bulkhead.

Assembly

36. The procedure for the assembly of the crew hatch is detailed in the following operations. When a new crew hatch is being assembled the fitting operations are fully described in A.P.101B-0400-6, Chap.2.

(1) Ensure that the sealing strip and pressure seal are secure and in good condition (*detail B*).

(2) Place the hatch in position on the bolt frame (*detail C*) and, taking care not to trap the seal irregularly, secure the hatch with the 68 screws in sequence, aft centre, front centre, outwards to the sides of the hatch, and finally along the longitudinal edges.

(3) When all screws have been fitted finally tighten using equal pressure.

(4) *Pre.Mod.3706* — On aircraft hatches pre Mod.3706 (*fig.16*), check, and adjust if necessary, the two screwed spigots on the hatch which engage the slotted holes on the pressure bulkhead. The clearance between the end of each spigot and the rear edge of the sealing collar must be 0.44 in \pm 0.01 in; this dimension can be checked by removing the spigot housing and rubber seal, accessible from within the upper equipment compartment. Wire-lock the spigot housing on reassembly; tighten the spigot locknuts.

Post Mod.3706 (a) The screwed spigots of the post Mod.3706 hatches are to be screwed down until the shoulder of the spigot butts firmly against the forward face of the pressure bulkhead; do not over-

tighten spigots when tightening locknuts.

(b) Check and, if necessary, adjust and align the butt connector (*fig.16*) until there is a 12lb/in² pressure between the faces. This can be measured with a spring balance.

(5) Refit the canopy aft fairing (*detail A*).

◀ (6) On aircraft embodying Mod.3776 re-connect the secondary firing-cables to the hatch. ▶

(7) Pressure test the cabin as detailed in Sect.3, Chap 8.

Note...

(1) Whenever the explosive bolts have to be replaced, lubricate the threads with a thin coating of grease XG.278. Ensure that the correct securing nut, Part No. AGS. 2002/L/1, is fitted to the explosive bolt and that the appropriate distance tubes are used for any given position as instructed in A.P.101B-0400-6, Chap.2. The torque required to tighten the bolts is 130 lb in.

(2) Whenever fitting detonators into the explosive bolts (A.P.1661F, Vol.1, Sect.6, Chap.6 refers), it is important that the detonator Ref.No.12G/1278, the distance tube Ref.No.26FZ/1807, and the spring Ref.No.26FZ/1579 be assembled as shown in *fig.16*. Prior to inserting the spring and screwing the cap home, using a gauge of local manufacture check the dimension between the distance tube and the end of the bolt; this should be 0.38 in \pm 0.04in.

(3) Ensure that the detonator leads are not trapped between the bolt retaining

nuts and the adjacent structure.

Fitting a crew entrance door

37. To fit an entrance door:

(1) Rotate the door jettison handle to its full extent in a clockwise direction.

(2) Line up the free hinge-pin cups so that their slots are in line with the slots in the hinge-pin cups on the shaft.

(3) Offer up the door to the fuselage, and insert the hinge pins into the hinge-pin cups.

WARNING

Before securing the entrance door, ensure that the hinge-pin cups are rotated fully to the safe position. The door jettison handle must be rotated approximately four complete turns from the jettison to the safe positions.

(4) Rotate the jettison handle in an anti-clockwise direction to its full extent and secure the jettison handle with its securing strap.

38. The procedure for fitting a new crew entrance door is fully described in A.P.101B-0400-6, Chap.2.

Nose fairing (*fig.8*)

39. To remove the nose fairing:

(1) Release the two hose clips (1) from the cabin pressure pipe slide-on connection.

(2) Remove the rubber tube (2) from the air drier connection on the nose fairing.

RESTRICTED

(3) Disconnect the pressure-head pipe at the connection (3).

(4) Disconnect the electrical cable (4) from the terminal block (5).

(5) Remove the 2 B.A. screws (6) and (7) attaching the side portions of the retaining ring (8) to the plastic nose (9) and frame B.

(6) With the exception of those at the ends and in the centre, remove the 2 B.A. screws attaching the upper and lower portions of the retaining ring (10) and (11) to the plastic nose and to frame B.

(7) With the plastic nose adequately supported, remove the remaining 2 B.A. screws from the upper and lower portions of the retaining ring.

(8) Remove the plastic nose from the fuselage.

Reassembly notes...

(1) When fitting the nose fairing it is important that the inner sealing strip (12), the outer sealing strip (13), and the bearing strip (14) are fitted securely.

(2) When tightening the attachment screws (6) and (7), the maximum torque must not exceed 25 lb. in.

Pressure head

40. To remove the pressure head from the nose fairing:

(1) Disconnect the union nut securing the pitot piping to the pressure head assembly and blank off the apertures.

(2) Disconnect the electrical leads to

the pressure head at the terminal block on frame A.

(3) Remove the locking wire securing the ring nut to the adapter tube and remove the ring nut, washer and rubber sealing ring.

(4) Remove the pressure head from the nose fairing.

Reassembly notes...

(1) Before replacing the ring nut, a thin coating of grease XG.278 is to be applied to the threads of the ring nut and the pressure head adapter.

(2) When finally tightening the ring nut, a maximum torque of 120lb in is to be applied.

(3) To ensure an airtight joint, *Boscoprene 2100 sealant Ref.No.33H/2202388* is to be applied round the periphery of the pressure head adapter at the junction with the front face of the nose fairing. Full instructions for the application of this sealant are given in *A.P.1464B, Vol.1, Part 2*.

Bomb/flare door jack (fig.5)

41. To remove either of the two bomb/flare door jacks:

(1) Fully open the bomb/flare doors and fit retaining cables Ref.No. 26FZ/95012 (fig.6) to the brackets on the front and rear hinge brackets.

(2) Ensure that the hydraulic system is exhausted of all hydraulic pressure (Sect.3, Chap.6), and disconnect the hydraulic pipes from the jack.

(3) Remove the split pins and collars from the actuating link pivot pins and remove the pivot pins.

(4) Remove the split pin and collar from the guide link pivot pin and remove the pivot pin.

(5) Remove the split pin and collar from the jack attachment pin, withdraw the attachment pin and remove the jack.

Note...

When reassembling the jack it is important that the actuating link pivot pins are inserted with the heads of the pins facing towards the nose of the aircraft, and that the lower banjo connection is correctly angled to prevent heavy fouling of the flexible pipe (pre Mod.2121) against the jack mounting. After reassembly, bleed the circuit through the jack bleed screws and check operation of bomb doors (Sect.3, Chap.6).

Bomb/flare door (fig.9)

42. To remove a bomb/flare door:

(1) Remove the microswitches from their mounting bracket.

(2) Remove the microswitch actuating plate.

(3) Support the weight of the door and remove the pip-pins from the hinge brackets and actuating links.

(4) Remove the bomb/flare door.

Reassembly notes...

(1) When refitting a bomb/flare door, guide it into the 'OPEN' position using

a metal shim to protect the bomb bay skirt and sealing strip (fig.9).

(2) To ensure that a foul does not occur during the assembly of a new bomb/flare door, the hinged flap covering the door centre hinge roller bearings (fig.9) must be

bent inwards to conform with the contour of the bomb/flare door skin.

Slinging

43. The methods of slinging the fuselage sections are illustrated in fig.17 and 18.

Trestling

44. The method of trestling the fuselage sections is illustrated in Sect.2, Chap.4. The Ref.No. and Part No. of these trestles is also given in that chapter.

RESTRICTED








Fig. 9. Bomb/flare door removal and installation

RESTRICTED




Fig. 10. Front fuselage removal

KEY TO FIG. 10 (FRONT FUSELAGE REMOVAL)

To remove the front fuselage from the centre fuselage:—

- (1) Jack and trestle the aircraft (*Sect.2, Chap.4*).
- (2) Remove the equipment compartment hatch and attach the sling to the front fuselage as shown in fig.17. Take up any slackness in the sling by the hoist.
◀ *Alternatively, raise the nose undercarriage and position the trolley (Ref.No.26FZ/95016) (Sect.2, Chap.4) beneath the front fuselage. Take the weight of the front fuselage on the trolley.*
- (3) Disconnect the battery leads and remove the batteries.
- (4) Disconnect all electrical cables entering the equipment compartment from the centre fuselage. L.A.B.S. (*B(1) Mk.6 aircraft*) and tail trim cables should be unstrapped and pulled through from rear fuselage.
- (5) Disconnect and blank off the following hydraulic system connections:—
 - (a) Wheel brakes accumulator.
 - (b) Port and starboard wheel brakes connections.
 - (c) Nose wheel ground selector.
 - (d) Suction and return pipes.

- (e) Pressure pipe.
- (6) Disconnect and blank off the pressure head and static vent pipes.
- (7) Disconnect the connections of the following controls, services and systems:—
 - (a) Flying controls push-pull tubes.
 - (b) Engine control push-pull tubes.
 - (c) Fire extinguisher system pipe.
 - (d) Alighting gear and bomb/flare door emergency release cables.
 - (e) Cabin pressure pipe.
 - (f) Air filter (*bomb sight computer*).

Note...

All controls, services and systems are to be disconnected at the points illustrated.

- (8) Refer to fig.11 and remove the 31 bolts attaching the end floor member of the centre fuselage to the equipment bay bulkhead.

- (9) Remove the two bolts from the centre vertical stiffeners on the upper portion of the equipment bay bulkhead (*bolt X, fig.11*).
- (10) Remove the 84 intermediate attachment bolts.
- (11) Remove the 84 stringer attachment bolts.
- (12) Remove the two attachment bolts from each longeron. The front fuselage is then free and should be slung and placed on the trolley (*Sect.2, Chap.4*) unless the trolley has already been utilised (*operation(2)*). All electrical cables should be neatly coiled.

Note...

(1) Before re-assembly, apply pigmented varnish jointing compound (Ref.No.33H/2202110) to the faces of the transport joint between the inner edges of the frames and the bolt holes, and Bostik glazing compound (Ref.No.33H/185) between the outer edges of the frames and the bolt holes. No jointing compound or Bostik must enter the bolt holes.

(2) The fork end fittings of flying control rods are machined with a counterbored recess, on the outer face of the lugs, at the bolt hole. This recess is designed to take the nut when the control tubes are assembled.




Fig. 11. Attachment bolt details - front to centre fuselage

◀ (Alternative stringer readings added) ▶

RESTRICTED




Fig. 15. Canopy removal and assembly

RESTRICTED




Fig. 16. Navigator's hatch removal

◀ (Inset re butt connector added) ▶


RESTRICTED

NOTE...
* ALTERNATIVE STRINGER
READING (1) TO (40)

FOR ATTACHMENT DETAILS REFER TO FIG.13

- 66-5/16 IN. BOLTS.
- 90-1/4 IN. BOLTS.
- 4-1/2 IN. BOLTS.
- A-74-1/4 IN. LIGHT ALLOY WASHERS.
- B-16-5/16 IN. LIGHT ALLOY WASHERS.

NOTE:-
G.K.N. LOCKNUTS USED THROUGHOUT.



DETAIL 'A'
LONGERON ATTACHMENT




Fig. 12. Attachment bolt details – rear to centre fuselage

◀ (Alternative stringer readings added) ▶

RESTRICTED




Fig. 13. Rear fuselage removal

RESTRICTED

KEY TO FIG.13 (REAR FUSELAGE REMOVAL)

To remove the rear fuselage from the centre fuselage:—

- (1) Jack and trestle the aircraft (Sect.2, Chap.4).
- (2) Attach the sling to the rear fuselage as shown on fig.18; take up the slackness on the sling.
- (3) Disconnect all electrical supplies.

Note...

Access to all connections and attachment bolt is gained through the camera access hatch in the underside of the rear fuselage. Should difficulty be experienced when closing and securing the camera hatch, it is recommended that the hatch be secured by first engaging the fasteners nearest to the hinge line and then working across the fuselage to the hatch outer edge.

- (4) Disconnect the electrical cables at the plug and socket connections on the bulk-

head at frame 29 and stow them carefully in the rear fuselage.

(5) Disconnect the elevator and rudder control tubes at the rear of the centre fuselage and at the first connection point in the rear fuselage. Remove and retain the disconnected portions of the control tubes.

(6) Refer to fig.12 and remove the locknuts and washers from the 80 frame attachment bolts between the stringers, and remove the bolts.

(7) With the exception of those at stringer 1 and stringers 8 port and starboard, remove the locknuts and washers from the 74 frame attachment bolts on each side of the stringers, and remove the bolts.

(8) Remove the locknuts and washers from the frame attachment bolts on each side of stringer 1 and stringers 8 port and starboard, and remove the bolts.

(9) Remove the locknuts and washers from each longeron and withdraw the bolts. The rear fuselage is then free and should be slung and placed on trestles (Sect.2, Chap.4).

Note...

(1) Before re-assembly, apply pigmented varnish jointing compound (Ref.No.33H/2202110) to the face of the transport joint between the inner edge of the frame and the bolt holes and Bostik glazing compound (Ref.No.33H/185) between the outer edge of the frame and the bolt holes. No jointing compound or Bostik must enter the bolt holes.

(2) The fork end fittings of flying control rods are machined with a counterbored recess, on the outer face of the lugs, at the bolt hole. This recess is designed to take the nut when the control tubes are assembled.

Note...

Mod. Can. 2125 introduces a modified tail plane actuator with restricted travel. With this modification embodied a flight trim check must be made as detailed in Sect.3, Chap.4, Appendix 1 or 2, whenever the rear fuselage is removed and replaced, to ensure that the aircraft trim is within the limits laid down. Should the aircraft trim be outside the limits specified, a new elevator trailing-edge strip should be fitted and the flight trim checks and subsequent trailing-edge strip adjustments made.




Fig. 14. Rear fairing removal

RESTRICTED




Fig. 17. Slinging - front and centre fuselage

RESTRICTED




Fig. 18. Slinging - rear fuselage

RESTRICTED




Fig. 19. Hatch locking pin settings

◀ (new illustration) ▶

RESTRICTED

Chapter 2 MAIN PLANE

(Completely revised)

LIST OF CONTENTS

	Para.		Para.		Para.
Introduction	1	Wing tips... ..	10	Main plane	19
DESCRIPTION		Ailerons	11	Aileron	20
General information	2	Aileron spring tabs.. . . .	12	Aileron tab	23
Spar... ..	3	Flaps	13	Flaps	25
Rear wall	4	Air brakes	14	Flap jack... ..	27
Ribs... ..	5	Vortex generators	15	Air brakes	29
Stringers	8	REMOVAL AND ASSEMBLY		Air brakes hydraulic jack	30
Skinning	9	General information	16	Wing tips... ..	31
		Main-plane sling	17		

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
Key diagram	1	Main plane clearances	5	Flap removal	8
Main plane	2	Main plane removal	6	Flap jack removal and assembly... ..	9
Main plane component parts... ..	3	Aileron and aileron tab removal	7	Air brake removal	10
Main plane slinging	4			Wing-tip removal	11

Introduction

1. This chapter gives a general description of the main plane structure and pictori-

ally describes the removal and assembly of certain components. The disposition of the

spars and ribs within the structure is illustrated in fig.1.

General information (fig.2)

2. The main plane is a single-spar, cantilever structure with a sectional rear wall, and is built in port and starboard units. There is no conventional centre section, the units being mounted direct on the sides of the fuselage with the spar continuation through the fuselage maintained by reinforced spar frames. In plan form the main

plane units have a parallel-chord centre portion extending to the outboard side of the engine bay, from which point they taper to the wing tip; the leading and trailing edges are straight. The basic structure consists of a torsion box, formed by the spar and rear wall with the rib and stringer system and between-spar skinning. To this is added the inner and outer leading edge assemblies,

the detachable wing tip, the air-brake installation and the aileron and flaps, the latter being carried on hinges mounted on the aft face of the rear wall. The outer leading edge assemblies embody integral fuel tanks which are located between ribs 2 and 6. To enable the carriage of wing pylons each rib 3 is cut to accommodate a pylon casting; the forward end of which bolts to

the main spar, and the aft end to rib 3 web. A strengthening butt strap is riveted chord-wise beneath the rib to the jointing skins. The pylons are bolted to the castings and when pylons are not required cover plates are used.

Spar

3. The spar is a built-up beam extending from the root to the tip; it has a plate web and machined light-alloy booms, the cross-section of which changes from a complex

stepped-T at the root to a plain T at the tip. Lightning holes in the web are reinforced with ring plates, except in the tip portion where they have integral pressed flanges. To accommodate the engine jet pipe, which passes through the spar, the web is cut off square on each side of the aperture, leaving the booms as continuous members, and to the ends of the web so formed are bolted Y-section fittings which form an anchorage for large, forged, light-alloy reinforcing ring-plates bolted to the arms of the Y-

section fittings at the front and rear of the spar. A rolled, carbon-steel firewall is fitted to the forward face of the ring-plate at the front of the spar.

Rear wall

4. The rear wall is divided into three sections, an inboard section extending from the root to the inboard side of the jet pipe bay, a centre section extending from the outboard side of the jet pipe bay to the rib at the inboard end of the aileron gap, and




Fig. 1. Key diagram

RESTRICTED




Fig. 2. Main plane

RESTRICTED

an outboard section extending the length of the aileron. The inboard and centre sections are joined by a forged light-alloy I-section ring, through which the jet pipe passes. Each section is built-up of plate webs stiffened by vertical angle-section members and T-section extruded flanges. The web of the outboard section is curved to form the front wall of the aileron pressure-balance box.

Ribs

5. Outboard of the jet pipe bay the spar and the rear wall are joined by a system of main full-depth ribs, flanked on either side by secondary ribs which, instead of being the full depth of the main plane, are made shallow to allow the spanwise stringers to pass outside their flanges. The main ribs have flat, plate webs with flanged lightening holes and extruded T-section booms. Those secondary ribs in the area bounded by the engine ribs and rib 4 have extruded bulb-angle-section booms; those between rib 4 and rib 8 have plain pressed flanges.

6. Forward of the spar is a similar system of main and secondary ribs which match up those aft of the spar but which are at right angles to the leading edge. The secondary ribs do not extend as far forward as the main ribs but are cut off some inches short of the leading edge proper. The forward ends of each pair of secondary ribs are joined together and to their main ribs by a nose beam passed through the main rib webs. From rib 2 to rib 6, forward of the main spar, the main and secondary ribs and the stringers are covered on the top, around the leading edge and on the underside by a one-piece sheet-metal skin which, with the rear, the outboard and the inboard tank walls, form a fuel tank within the main plane structure. The tank section is located by spigots on the web of the main spar and is secured to the top and bottom flange sections of the spar boom, around the outboard flange of

rib 2 and the inboard flange of rib 6 by countersunk bolts. The tank section may be removed without removing the main plane.

7. Inboard of the jet pipe bay, the main ribs aft of the spar are similar to those outboard of the bay, but the pressed-flange secondary ribs are of full main-plane depth. Forward of the spar the leading edge houses the main undercarriage unit when retracted; it is divided spanwise by a diaphragm which forms the front wall of the wheel well and extends from the engine bay inboard rib to the fuselage. Forward of the diaphragm, the ribs are constructed with plate webs and angle flanges; aft of the diaphragm the ribs are closed top-hat-section members. On either side of the engine and jet pipe bays special ribs are built up with plate webs and angle-section frames.

Stringers

8. Outboard of the engine and jet pipe bays, the spanwise stringers, of bulb-angle section, lie intercostal with the main ribs but pass outside the secondary ribs. Inboard of these bays the stringers pass through the main and secondary ribs alike.

Skinning

9. The skin plating aft of the spar is in sheets with chordwise butt joints on the centre lines of the main ribs, reinforcing strips being interposed between the rib flanges and the skin. Spanwise joints are made on bulb-T section extrusions running from the outer side of the jet pipe bay to the tip. The leading edge panels are wrapped chordwise round the leading edge.

Wing tips (fig.3)

10. A detachable wingtip is carried on an extension to the main plane structure at outboard rib 8. The skin covering is attached to a pressed flanged rib and pressed flanged spanwise ribs, the complete assembly being

attached to the leading and trailing edges of outboard rib 8, the spar extension rib and the two spanwise ribs of the main plane extension. Navigation and taxiing lamps are installed in the nose of the leading edge, the skin of which is moulded transparent plastic sheeting.

Ailerons (fig.3)

11. The ailerons are carried on a centre main hinge and on pin-and-socket hinges at their extremities. The skin covering is attached to press ribs which have flanged lightening holes. The ribs are flanged on their lower edge and have a separate angle-section extruded flange on the upper edge. The aileron spar, to which the ribs are attached, has a plate web with flanged lightening holes and carries the D-shaped nose ribs and beaks. Aileron shroud plates, which may be opened to facilitate servicing of the aileron operating mechanism, are mounted on piano-type hinges on the main plane rear wall. Mass balance of the surface is effected by heavy-alloy strips riveted between the beak ribs. Between the inboard end and rib 7 the trailing edge of the aileron is cut away to accommodate the spring tab; the ribs between these points are shortened and carry a curved rear web which forms the front wall of the spring tab pressure-balance box.

Aileron spring tabs (fig.3)

12. The aileron spring tabs are hinged to the aileron by a main centre hinge and pin-and-socket hinges at their extremities. The skin covering is attached to pressed flanged ribs and the tubular spar. The spar is reinforced at the centre hinge point by an inner tube and each end of the spar houses a socket in which the hinge pin is secured. Extensions to the upper and lower skins forward of, and riveted to, the spar, form a beak in which triangular wood alignment blocks are inserted at intervals. At the apex




Fig.3. Main plane component parts

of the beak the upper and lower skins are continued forward to form a flat plate extension, terminating in a 60 degree extrusion.

Flaps (fig.3)

13. The split trailing-edge flaps are single spar structures of triangular cross section, carried on pin-and-socket hinges. Pressed, flanged nose, and trailing edge ribs are attached to the spar, the whole structure being covered with a light-alloy skin riveted to the spar and ribs. Flanged lightening holes are cut in the upper skin surfaces.

Air brakes (fig.10)

14. The hydraulically-operated air brakes consist of 21 drag channels housed inside each main plane, aft of the main spar. In the out position, nine of the channels protrude through the upper skin surface and twelve through the lower surface; in the in position the ends of all drag channels lie flush with the skin surfaces. The drag channels are attached to the ends of centrally-pivoted rocker arm assemblies, which are attached to a spanwise torque tube constructed in three portions and connected together at outboard ribs 3A and 3B; the tube is carried in bearings at its centre and ends. Annular plates attached to the webs of outboard ribs 2 and 4 accommodate the end bearings; the centre bearing, at rib 3, consists of three rollers, one of which is adjustable to facilitate removal and assembly of the torque tube. A lever in the centre and integral with a rocker arm assembly, is connected to the hydraulic operating jack mounted on the rear of the main spar.

Vortex generators

15. Vortex generators are fitted to both the wing tips and the wing tip tanks. The generators, eight in number, are fitted two to the underside of each wing tip forward of the main spar, inboard of rib 8 and inclined 10 deg to the main plane chord line, and two to the inboard face of each wing tip tank.

Note...

To obtain the benefit of the vortex

generators, both the wing tips and the wing tip tanks must be modified. Although it is possible to fit an unmodified tank to a modified wing tip and vice versa, no benefit from the modified member will be obtained thereby.

REMOVAL AND ASSEMBLY

Note...

After the removal and re-assembly of any component which may affect the longitudinal trim of the aircraft, carry out flight trim checks as detailed in Sect.3, Chap.4, Appendix 1 or 2.

General information

16. The following paragraphs describe the removal and assembly operations of the main plane and its principal components. Only the removal operations are described, since the assembly is generally the reverse of these operations; where this is not the case, the fact is noted. The recommended sequence of operations is given, although in some cases it will be clear that it is not essential to adhere rigidly to this sequence. The necessary ground equipment is listed in Sect.2, Chap.4.

Main-plane sling (fig.4)

17. The main-plane sling, which can only be used when the engine and jet pipe are removed, is a triangular tubular frame, which is attached to the main plane by a beam at the engine rear mounting brackets, by a hook at the rear wall connecting ring and by an eyebolt at the slinging point in the upper surface of the main plane (Sect.2, Chap.4). It is designed to sling both the port and the starboard main planes by reversal of the cable assemblies on the frame. Three eyes, for attachment to the crane-hook shackle, are provided in the slinging cables and are used in different order to maintain the balance of the component with or without flaps and ailerons. When the complete main plane is being slung the crane-hook shackle is attached to the single eye (marked X) to which all three cables are spliced. All three eyes are attached

to the hook shackle when the main plane is slung less aileron and flaps. Both conditions are illustrated in fig.4.

Note...

1. Integral tank and wing tip tank fuel must be drained and the wing tip tank must be removed (Sect.4, Chap.2) before a main plane is slung.

2. During main-plane removal, and more particularly during assembly, great care must be taken to prevent any damage to the upper and lower main spar skin attachment flanges. These flanges, if subjected to excessive loads, are liable to crack and this condition may occur if fouling of the flanges with the main plane attachment lugs takes place. It is therefore essential that the main plane is balanced in the correct attitude, relative to the fuselage, before it is offered up. Although the main-plane sling will balance it in approximately the correct position it is imperative that final adjustments are made by ballasting. ▶

18. To attach the sling to a main plane:-
(1) Remove the caps from both the engine rear mounting brackets.

(2) Place the slinging beam across the engine bay with the spherical ends of the beam resting in the lower halves of the engine mounting brackets. Refit the caps on the engine mounting brackets.

(3) Insert the eyebolt in the slinging point in the upper surface of the main plane.

(4) Assemble the slinging frame to suit the main plane being lifted and attach the sling to the hoist by the slinging eye, or eyes (para.17).

(5) Adjust the hoist until the cable at the forward apex of the frame can be attached to the centre of the slinging beam, pass the hook on the cable at the rear apex of the frame under the rear wall connecting ring, and the hook on the cable at the outboard apex of the frame through the slinging eye in the main plane.




FIG. 4. MAIN-PLANE SLINGING

RESTRICTED




FIG. 5. MAIN-PLANE CLEARANCES

◀CLEARANCES AMENDED, SECTION G-G▶

RESTRICTED

Main plane

19. The procedure for the removal of a main plane is given in the key to fig.6.

Aileron

20. The procedure for the removal of an aileron is given in the key to fig.7.

Note...

Ailerons must neither be removed nor refitted while wing tip fuel tanks are fitted to the aircraft.

21. Before fitting a new aileron, make the following check and adjust, if necessary, to line up the centre hinge bearing:-

- (1) Offer up the aileron to the main plane and engage the inboard and outboard hinge pins.
- (2) Check the clearance between the aileron hinge bracket and the forward face of the aileron spar.
- (3) Remove the aileron and attach a shim, Part No.E.A1.24.901 (*supplied with a new aileron*), of the thickness required at operation (2), to the forward face of the aileron spar, using the hinge-bracket attachment screws.

Note...

A maximum of two shims (0.10 in.) may be fitted.

- (4) With the end holes of the shim as guides, mark out and drill two holes 0.0785 in. dia. (*drill No.47*), in the aileron spar and secure the assembly with P.K. screws (*2R 3/16 in. S.971*).
- (5) Remove the attachment screws used at operation (3).

22. After fitting a new aileron check for clearance (*fig.5*) and, if necessary, make the following adjustments:-

- (1) To obtain the correct clearance between the aileron beak and the main plane rear wall in the critical area one inch either side of the main plane chord line (*Section F-F*), it is permissible to have a clearance of 0.015 in min to 0.10 in max between the beak and wall over the remainder of the travel. Should the aileron beak foul the fabric over the shroud hinges, trim the fabric locally to clear.
- (2) To obtain the correct clearance between the two aileron shroud screens and the aileron beak at the centre hinge (*Section G-G*):-
 - (a) Open the aileron upper shrouds and remove the sealing strips from the aileron beak. The lower shrouds support the screens and are to be opened only as necessary to obtain the required clearance between the aileron shroud screens and aileron beak.
 - (b) Sandwich the clearance gauge (*S.I./CAN/123 fig.1*) between either of the screens and the beak; hold it in position by applying hand-pressure to the screen and gently close the corresponding upper and lower shrouds. Check that the pegs on the screen enter the holes in the shrouds, if they do not, remove the clearance gauge and carry out a repair in accordance with A.P. 101B-0400-6, Part 2.
 - (c) Remove the clearance gauge and repeat ops. (a) and (b) on the other screen.
 - (d) Re-open the upper shroud at either

of the screens. Using the clearance gauge, check that the correct clearance between the beak and screen is maintained and secure the screen in position using the appropriate centre screen locating jig (*S.I./CAN/123 fig.2*) by locating the two upper pegs of the screen in the corresponding holes in the jig and bolting the aft end of the jig to the shroud angle attachment bracket. Remove the clearance gauge.

(e) Assemble the sealing strip to the aileron beak, unlock the ailerons and obtain the correct clearance over the full range of aileron movement.

(f) Remove the locating jig and close the aileron shroud.

(g) Repeat ops. (a),(b),(c),(d),(e) and (f) at the other screen.

(3) To obtain the correct clearance between the aileron inboard shroud screen and the aileron beak (*Section D-D*):-

(a) Open the aileron upper inboard shroud, and remove the sealing strip from the aileron beak inboard edge.

(b) Position the inboard screen locating jig stamped (*S.I./CAN/123 fig.3*), on top of the screen by mating the screen peg with the jig and the point of the jig pointing aft. Mark off and drill a hole in the screen flange using the end hole in the locating jig as a template, and bolt the two items together at this position.

(c) Close the shroud so that the shroud takes on its normal position and, using a pencil, mark the position of the aft point of the locating jig onto the aileron. Re-open the shroud.

(d) Align the aft point of the locating jig with the pencilled mark on the aileron and, while held in this position, bolt the second (movable) leg of the jig to the shroud angle attachment bracket.

(e) Using a feeler gauge, measure the clearance between the screen and aileron, this should be 0.15 in. \pm 0.07 in; if the clearance is incorrect, carry out a repair in accordance with A.P. 101B-0400-6, Part 2.

(f) Assemble the sealing strip to the aileron beak, unlock the ailerons and obtain the correct clearance over the full range of aileron movement.

(g) Remove the locating jig.

(4) To obtain the correct clearance between the aileron outboard shroud screen and the aileron beak (*Section E-E*):-

(a) Slacken the sealing strip attachment screws and adjust the strip.

(b) Tighten the attachment screws after adjustment.

(5) Check the alignment of the aileron shrouds (*Section F-F*); they must be in true alignment with the main plane and aileron contours \pm 1/32 in. measured along the upper and lower surfaces at the trailing edges of the shrouds at F. Adjust their alignment by the shims on the aileron shroud angle brackets at ribs 4, 6 and 8.

(6) If there is not sufficient clearance between the aileron shrouds and the aileron (*Section F-F*), file the edges of the shroud, leaving a minimum of 0.025 in. between the rivet heads and the edge

of the shroud; do not adjust this clearance by reshimming the aileron shrouds. Apply protective treatment (A.P. 101A-0600-6) to filed surfaces. ▶

Aileron tab

23. The procedure for the removal of an aileron tab is given in the key to fig. 7.

24. After fitting a new tab to an aileron, check for correct clearances (*fig. 5*) and, if necessary, make the following adjustments:-

(1) If the clearance between the tab beak and the rear web of the aileron ◀ (*Section C-C*) is incorrect, it may be adjusted by filing the tab beak. ▶

(2) If the clearance between the tab ◀ shrouds and the tab (*Section C-C*) is incorrect it may be adjusted by filing the edges of the shrouds. The correct ◀ protective treatment (A.P. 101A-0600-6) must be applied to all filed surfaces. ▶

Flaps

25. The procedure for the removal of the flaps is given in fig. 8.

26. After fitting a new flap to a main plane, check for correct clearances (*fig. 5*). If the clearance between the leading edge of the flap and the main ◀ plane is incorrect (*Section A-A*), it may be adjusted by filing the leading edge of the flap. Ensure that the 45 deg chamfer is maintained on the leading edge of the flap. Protective treatment ◀ (A.P. 101A-0600-6) must be applied to all filed surfaces. ▶

Flap jack (*fig. 9*)

Removal

27. With the flaps in the fully down position:-

(1) Exhaust the system of hydraulic pressure (*Chap. 6*).

(2) Disconnect the two hydraulic pipes from the jack, and blank off the pipelines and the jack connections (3).

(3) Remove the split pin and washer from the connecting pin securing the jack connecting rod to the flap mechanism and remove the connecting pins (1).

(4) Remove the six 2 B.A. bolts and nuts securing each of the two cover plates to the ribs adjacent to the jack body, and remove the plates (2).

(5) Remove the two 3/8 in. B.S.F. nuts and bolts securing the flanged end of the jack to the mounting bracket and the two 5/16 in. bolts securing the ring mounting to the bracket at the opposite end (4).

(6) Remove the jack from the main plane.

Assembly

28. The procedure for the assembly of the flap jack is the reverse of that given in para. 27.

Note...

1. When the jack is refitted to the mounting bracket in the aircraft, it is essential that the washers fitted to the mounting bolts at the flanged end of the jack are correctly positioned (*fig. 9*).

2. Bleed the jack and pipelines, and test the functioning of the flaps as detailed in *Chap. 6*.

3. If necessary, adjust the fork ends of the jack connecting rod to connect with the flap mechanism push-rods (the fork end at the flanged end of the jack first). After making this adjustment, check the dimension between the pin centre and the nearest face of the cylinder flange; this must be within 3.13 in. \pm 0.25 in. When final adjustment of the opposite fork-end is com-

pleted, check the dimension between the jack pin centres; this should be 18.3 in. \pm 0.25 in. For checking purposes, jack travel is 3.90 in. \pm 0.015 in. After adjustment, wire-lock both fork-ends, spanner grips and locknuts.

Air brakes

29. The procedure for the removal of the

air brakes is given in the key to fig.10. After assembling the air brakes into the main plane set the mechanism in the manner described in Sect.3, Chap.4.

Air brakes hydraulic jack

30. When an air brakes hydraulic jack is removed and a replacement jack fitted, it is essential that the standard locknut and tab

washer are removed from the jack piston rod, and a special locknut, Part No.EA3-73-303 and tab washer, Part No.EA3-73-305 are fitted.

Wing tips

31. The procedure for the removal of the wing tips is given in fig.11.

RESTRICTED




Fig. 6. Main plane removal

RESTRICTED

KEY TO FIG.6 (MAIN PLANE REMOVAL)

- (1) Remove the engine (*Sect.4, Chap.1*).
- (2) Jack and trestle the aircraft (*Sect.2, Chap.4*) and attach the sling to the main plane as instructed in para.18. Take the weight of the main plane on the sling.
- (3) Remove the main undercarriage door and undercarriage unit (*Sect.3, Chap.5A*).
- (4) Remove the access panels (16), (22), (29) and (40).
- (5) Remove the closing strips (17) and (25).
- (6) Remove the screws securing the leading-edge skin to the fuselage attachment angle (42).
- (7) Disconnect the fuselage main plane connections of the following controls and services:
 - (a) Engine controls (32) from (43).
 - (b) Hydraulic pipes, suction and delivery (33) from (41).
 - (c) Hot air delivery pipe to camera bay (31) from (44).
 - (d) Cabin air delivery pipe (34) from (1) (*port side only*).
 - (e) Pitot and static pipes (3) to the A.M.U. (*port side only*).
 - (f) Fuel delivery pipe (35) from (5).
 - (g) Fire protection pipe (39).
 - (h) Hydraulic pipes (30) from (8).
 - (i) Hydraulic pipe (14) from (10).
 - (j) Aileron control tube (15) from (11).

- (k) Wing-tip fuel tank air-pipes (28) from (12).
 - (l) Air brake hydraulic pipes (27) from (13).
 - (m) Wing-tip fuel tank full transfer pipe (24) from (19).
 - (n) Flap hydraulic pipes (23) from (21).
 - (o) Cabin air delivery pipe, primary cooler to mixing valve, (26) from (38).
 - (p) A.R.I.5885 connection (36).
 - (q) I.L.S. aerial connection (37).
- (8) Ensure that all electrical plugs and cables have been disconnected (*Sect.5, Chap.1*).
- (9) Remove the split pin, nut and washer (4) from the bolt (45) at the forward attachment point (2). Retain any packings (*S.T.I./CAN/347 refers*) and withdraw the bolt. ▶
- (10) Remove the locking collar (20) from the rear attachment bolt (18) and withdraw the bolt.
- (11) Remove the split pins, nuts and washers from the seven shear bolts (9) and withdraw the bolts.
- (12) Remove the split pins, nuts and washers from the four main attachment bolts (6) and (7) and, using an extractor Ref. No. 26FZ/95047, remove the bolts. The main plane is then free and should be lifted clear and placed on trestles.
- Reassembly notes**
- (1) Before assembling the main plane to the fuselage, ensure that the sealing blocks,

Part No. EA1.20.2879 (*upper*) and EA3.20.135 (*lower*), are securely attached with rubber-resin cement Ref. No. 33H/72 within the forks of the centre section spar fitting as shown in the detail.

(2) Before fitting the spar lower attachment bolts (6), lubricate the bolt threads and nut faces, and when tightening the nuts, apply a torque of 1500 lb in, using a torque wrench. Tighten the nuts alternately.

(3) After assembling the main plane to the fuselage, and before fitting the shear bolts (9), attach with rubber-resin cement a sealing block, Part No. EA1.20.2899. The block must be hard up to the forward face of the spar lower boom and the fuselage side, as shown in the detail.

(4) When securing the main-plane skin to the fuselage attachment angle, the sixty-eight 2 B.A. screws securing the leading-edge skin, from the main spar on the upper surface to the forward edge of the main undercarriage bay, must be fully tightened and then slackened off one quarter of a turn; this ensures freedom of movement between the wing and the fuselage.

◀ (5) When fitting a new main plane refer to A.P.101B-0400-6, Part 1. ▶

Note...

A flight trim check must be made as detailed in Sect.3, Chap.4, Appendix 1 or 2, whenever a main plane is removed and replaced, to ensure that the aircraft trim is within the limits laid down. Should the aircraft trim be outside the limits specified, a new elevator trailing-edge strip should be fitted and the flight trim checks and subsequent trailing-edge strip adjustments carried out.









Fig. 7. Aileron and aileron tab removal

RESTRICTED

KEY TO FIG. 7 (AILERON AND AILERON TAB REMOVAL)

To remove an aileron:-

(1) Open all aileron shrouds by removing the countersunk screws at the extremities of each shroud.

(2) Disconnect the aileron control tube from the aileron lever (*detail E*).

(3) Remove the access panel from the underside of the wing tip (*detail B*).

◀ (4) Remove the four $\frac{1}{4}$ in. dia. bolts attaching the centre hinge bracket to the aileron (*detail D*) and note the number of shims. To facilitate the removal of these bolts, the centre shroud attachment brackets may be removed (*detail D*).

Note...

In the event of the centre hinge shroud attachment brackets being removed, note the number and position of shims Ref.No.26FZ/6143. During reassembly, check the shroud and attachment bracket bolt holes for

alignment and fit shims as necessary to ensure that no gap exists between the aileron centre hinge and shroud attachment brackets.

(5) Lower the flaps, support the aileron at its extremities, remove the nut and bolt from the inboard hinge pin, and using the extractor, Ref.No.26FZ/95104, withdraw the hinge pin (*detail A*).

(6) Remove the nut and bolt from the outboard hinge pin, and using the extractor, Ref.No.26FZ/95104, withdraw the hinge pin (*detail B*).

(7) Remove the aileron.

To remove an aileron tab:-

(1) Remove the two countersunk screws attaching the control rod fairing to the aileron and remove the fairing (*detail G*).

(2) Remove the four 2 B.A. bolts and

the two countersunk screws attaching the centre hinge bracket to the tab (*detail G*).

(3) Remove the locking wire from the inboard hinge pin and, with the tab adequately supported, remove the hinge pin (*detail C*).


(4) Remove the tab from its outboard hinge pin by drawing the tab inboard (*detail F*).

Note...

A flight trim check must be made as detailed in Sect.3, Chap.4, Appendix 1 or 2, whenever an aileron or aileron tab is removed and replaced or adjusted, to ensure that the aircraft trim is within the limits laid down. Should the aircraft trim be outside the limits specified, a new elevator trailing-edge strip should be fitted and the flight trim checks and subsequent trailing-edge strip adjustments made.

RESTRICTED

NOTE...
THE OPERATING MECHANISM GREASE NIPPLES MUST FACE OUTBOARD AND AFT ON PORT SIDE AND INBOARD AND AFT ON STARBOARD SIDE



REMOVAL INSTRUCTIONS

- 1 SELECT FLAPS DOWN.
- 2 SUPPORT THE FLAP AND REMOVE THE ATTACHMENT PIN 'B' FROM BOTH OPERATING MECHANISMS. RETAIN THE ATTACHMENT PIN, BEVEL WASHERS, WASHER AND SLOTTED NUT.
- 3 WITH THE FLAP ADEQUATELY SUPPORTED AT ITS CENTRE AND EXTREMITIES, REMOVE THE HINGE PIN 'A' FROM BOTH HINGE BRACKETS. RETAIN THE HINGE PIN, SLOTTED NUT AND WASHER.
- 4 MOVE THE FLAP AFT AND DOWNWARDS AND REMOVE.

ASSEMBLY NOTE

THE BEVEL WASHERS REMOVED IN OPERATION 2 MUST BE REFITTED IN THE SAME WAY, OTHERWISE DAMAGE WILL RESULT WHEN ATTEMPTING TO INSERT THE ATTACHMENT PIN

PORT INNER FLAP ILLUSTRATED

REMOVAL AND ASSEMBLY PROCEDURE IS COMMON FOR ALL FLAPS




FIG. 8. FLAP REMOVAL

RESTRICTED





Fig. 9. Flap jack removal and assembly

RESTRICTED





Fig. 10. Air brake removal

RESTRICTED

KEY TO FIG.10 (AIR BRAKES REMOVAL)

To remove an air brake:—

- (1) Remove the access panel in the lower surface of the main plane (*Sect.2, Chap.4*).
- (2) Disconnect the hydraulic jack at the lever on the rocker arm assembly.
- (3) Remove all drag channels from their rocker arms by unlocking and removing their attachment nuts (*detail D*).
- (4) Remove the nipples and spokes from all rocker arm assemblies and joint tubes (*detail C*).
- (5) Slacken the lock nut on the adjustable roller on the bearing on rib 3 and lower the roller to its full extent (*detail A*).
- (6) Remove the nut from the end of the torque tube at rib 2, and the bearing on that rib, after removing the screws securing its annular plate (*detail B*).
- (7) Slide the inner and centre portions of the torque tube inboard, toward rib.1, removing the rocker arm assemblies and the joint tube from the main plane as they are released.
- (8) Separate the centre and inner portions of the torque tube, removing the rocker arm assemblies and joint tube as they are released.
- (9) Move the centre portion of the tube to rib 3 and, pivoting it on the adjustable roller, remove it from the main plane.
- (10) Move the inner portion of the torque tube to rib 3 and remove it from the main plane as for the centre portion.
- (11) Remove the outer portion of the torque tube from the main plane in a similar manner, removing the remaining rocker arm assemblies as they are freed.



- TO REMOVE THE WING TIP**
1. REMOVE ACCESS PANEL IN TOP SKIN (POST MOD.4152)
 2. DISCONNECT ELECTRICAL CABLES FROM TERMINAL BLOCK IN LEADING EDGE
 3. REMOVE BOLTS ATTACHING TRAILING EDGE OF RIB 8 TO WING TIP
 4. REMOVE COUNTERSUNK ATTACHMENT BOLTS ATTACHING WING TIP TO MAIN PLANE EXTENSION
 5. REMOVE WING TIP

Fig. 11. Wing tip removal
 ◀ (Mod.4152 incorporated) ▶

RESTRICTED

Chapter 3 TAIL UNIT

(Completely revised)

LIST OF CONTENTS

Introduction	Para. 1
DESCRIPTION	
Tail plane	2

Elevators	Para. 3
Elevator spring and balance tabs ...	4
Fin	5
Rudder	6
Rudder spring tab	7

REMOVAL AND ASSEMBLY	
General	Para. 8
Shroud clearances	9
Slings	10
Tail plane seal adjustment	11

LIST OF ILLUSTRATIONS

Key diagram	Fig. 1
Tail plane, elevators, and tabs	2
Fin	3
Rudder and rudder tab	4

Slings - tail plane	Fig. 5
Tail plane seals (post Mod.1277) ...	6
Tail plane removal	7
Elevator and elevator tab removal ...	8

Rudder and rudder tab removal	Fig. 9
Fin removal	10
Tail plane clearances	11
Fin, rudder and elevator clearances ...	12




Fig. 1. Key diagram

RESTRICTED




Fig. 2. Tail plane, elevators, and tabs

RESTRICTED

Elevators (fig. 2)

3. Each elevator, which is hinged to the tail plane at its centre and extremities, has a D-section spar, forming the leading edge, with flanged plate ribs and a light-alloy skin covering behind the spar and over the horn. The inboard ribs are cut away at their trailing edges and are bounded by a plate web to which the tab hinge brackets are attached, the skin being extended beyond the web to form a shroud over the leading edge of the tab. Interconnection of the elevators is effected by vertical torque levers riveted to flanges at the root of each spar, the levers being joined at their ends by a coupling link. The elevators are mass-balanced by bob weights mounted on tubular arms projecting from the leading edge into the interior of the tail plane. On the underside of the elevators, at the centre hinge positions, Mod. 4160 introduces an access panel, secured by rivets, for examination and replacement of the centre hinge brackets.

Elevator spring and balance tabs (fig. 2)

4. The elevator spring and balance tabs are hinged to the elevators by end hinges and two intermediate hinge pins, the spring tab being mounted on the port elevator and the balance tab on the starboard elevator. The skin covering is attached to a tubular spar and pressed flanged ribs, the tabs being balanced by spanwise mild steel tubes attached to the spar and protruding into the elevator interior.

Fin (fig. 3)

5. The fin is a composite structure of

wood and metal, built around a single light-alloy spar consisting of T-section booms and a plate web reinforced by angle sections. The leading-edge structure is formed by wooden ribs, with stiffeners, and a laminated spruce leading-edge member, the whole being covered with a plywood skin, which is reduced at its aft edge to the outside of the T-section booms forward of the spar web. On B(I) Mk. 6 aircraft embodying Mod. 3726, the fin leading edge is covered with a metal strip. Aft of the spar the structure is entirely of metal construction, consisting of flanged plate ribs, with angle-section stiffeners, and a curved rear wall forming the rudder shroud. The rudder upper hinge plate is attached to rib 6 at the top of the shroud.

Rudder (fig. 4)

6. The rudder is of all-metal construction of a built-up spar, flanged plate ribs aft of the spar and D-shaped leading-edge ribs. At the upper end, a horn extends forward of the spar and this together with the upper edge of the rudder, is built up with vertical diaphragms. Ribs 1 to 11 are shortened at their trailing edges and are bounded by a plate web, to which is attached the tab centre hinge bracket; the tab upper hinge socket is mounted on rib 12 and the lower hinge bracket is attached to the underside of rib 1. The whole structure is covered with a light-alloy skin which extends beyond the trailing-edge plate web to form the tab shroud. The rudder is hinged to the fin rear wall at its upper end, and in a bearing in the rudder stub of the rear fuselage

at its lower end, and is mass-balanced by two weights, one mounted in the rudder horn and the other attached to an arm at the bottom of the spar.

Rudder spring tab (fig. 4)

7. The rudder spring tab is similar in construction to the elevator spring and balance tabs (para. 4), and is hinged to the rudder by upper and centre hinge pins and a lower hinge bracket. The tab is balanced by weights carried on arms attached to the spar and protruding into the rudder interior.

REMOVAL AND ASSEMBLY**Note...**

After the removal or reassembly or adjustment of any component which may affect the longitudinal trim of the aircraft, carry out flight trim checks as detailed in Sect. 3, Chap. 4, Appendix 1 or 2.

General

8. The methods of removing and assembling the components of the tail unit are given in the keys to fig. 7 to 10. Only the removal operations are given in detail since the assembly is generally a reversal of this detail; where this is not the case the fact is noted.

Shroud clearances (fig. 12)

9. After fitting a new rudder to the fin, or a tab to either the rudder or elevator, the gap between the shroud and the leading edge of the component must be checked, it should be 0.05 ± 0.02 in. (details C and B). After fitting a new elevator to the tail plane, the gap

between the shroud and the leading edge of the elevator should be $0.05 \begin{smallmatrix} +0.03 \\ -0.02 \end{smallmatrix}$ in. (detail A). If these measurements are not obtained the edges of the shroud may be trimmed by filing. The correct protective treatment as detailed in A.P. 101A-0600-6, must be applied to all filed surfaces.


Slings (fig.5)

10. The method of slinging the tail plane is illustrated in fig.5, using the tail plane sling Ref.No. 26FZ/95009. The cables of the sling are identified for the fore or aft positions by tags attached to the cables. It should be noted that only 6 in. lift is permissible above the installed position and care should be taken not to foul the underside of the rudder stub when lifting. The rudder and fin are slung by passing a suitable strap through the holes at the positions indicated in Sect. 2, Chap. 4; these holes on the fin are normally covered with fabric patches but on the rudder they are closed by spring-loaded plugs which may be removed by screwing a 4 B.A. bolt into the hole in the plug and pulling outwards.


Tail plane seal adjustment (fig.6)

11. When Mod. 1277 is embodied the clearance between the tail-plane fairing and the sealing strip is to be adjusted by means of the 10 adjusting screws, five on each side of the tail plane stub. On no account must these screws be fully tightened.

WHEN USING TOWING CRANE,
TYPE A, REF.NO.4L/2023,
MAX. HEIGHT OF LIFT IS 6 IN.
ABOVE INSTALLED POSITION



THIS ASSEMBLY USED
FOR SLINGING TAIL PLANE
WITH OR WITHOUT ELEVATORS



TAIL PLANE SLING
REF.NO.26FZ/95009

NOTE:-

STEADY TAIL PLANE BY
HAND WHILE SLINGING

Fig.5. Slings - tail plane




FIG. 6. TAIL PLANE SEALS (POST MOD. 1277)

KEY TO FIG. 7 (TAIL PLANE REMOVAL (POST MOD. 1277))

The tail plane may be removed with or without the elevators fitted. To remove the tail plane with the elevators removed:-

(1) Jack and trestle the aircraft (Sect. 2, Chap. 4), and attach the sling to the tail plane. Take up the slackness in the sling.

(2) Remove the tail plane actuator (Sect. 3, Chap. 4).

(3) Remove the ten adjusting bolts from the tail plane stubs (five each side) which secure the sealing plates.

(4) Remove the circular access panel on the port side of the fin stub (Sect. 2, Chap. 4). This panel gives access to the bracing strut upper attachment.

(5) Remove the split pin, nut, and washer from the bolt (4) attaching the bracing strut (3) to the lug (5) on the rear of frame 42, and remove the bolt.

(6) Move the tail plane to its minimum incidence by lifting with the sling.

(7) Remove the split pin, nut and washer from the bolt (2) attaching the bracing strut (3) to the lug (1) on the rear fuselage.

(8) Remove the bolt (2) and withdraw the strut (3).

(9) Remove the split pin, nut, and washer from each hinge pin (8).

(10) Withdraw the hinge pins (8) from the lugs on the spar centre section (6), and hinge brackets (7) on the rear fuselage. The tail plane is then free to be removed.

To remove the tail plane with the elevators attached:-

(1) Jack and trestle the aircraft (Sect. 2, Chap. 4), and attach a sling to the tail plane. Take up the slackness in the sling.

(2) Remove the box fairing and the rear fairing (Sect. 3, Chap. 1).

(3) Disconnect the control tube from the port elevator lever and at the lever on the bulkhead at fuselage frame 42.

(4) Remove and retain the disconnected section of the control tube.

(5) Proceed as instructed in operation (2) to (10) for the removal of the tail plane with the elevators removed.

Assembly details (fig. 11)

The following instructions are applicable when fitting a new tail plane:-

(1) Before commencing to fit a tail plane to the rear fuselage, ensure that the lower cover plate, on the port side of the rudder stub, is securely positioned (access to this plate is not possible with the tail plane in position).

(2) Check the clearance between the sealing plate on the underside of the tail plane and the closing strip on the fuselage, before the installation of the tail plane actuator, as follows:-

(a) Ensure that the lower micro-switch tappet is screwed back fully.

(b) Set the tail plane to 5 deg 42 min incidence measured at the starboard inboard rigging position - at this incidence the sealing plate and the closing strip are adjacent over practically their whole length, and the clearance can be ascertained.

(c) Check the clearance, which should be 0.1 ± 0.005 in. (detail B).

(3) With the tail plane actuator installed, set the tail plane to 3 deg 15 min incidence - measured at the starboard inboard rigging position, or at the take-off position on the cockpit gauge - and check the following clearances:-

(a) Between the tail plane and the tail plane stub; this should be

0.1 ± 0.05 in. (pre Mod. 2334) or 0.1 ± 0.05 in. (post Mod. 2334) (detail A). If this dimension is not obtained the clearance may be adjusted by adding extra packing, or facing-off existing packing on the tail plane, as required.

(b) Between the tail plane and the forward face of the rear cone, this should be 0.1 ± 0.05 in. (position F).

(c) Between the trailing edges of the stub, and the leading edges of the tail plane; this should be 0.05 ± 0.005 in. (detail C).

(d) Between the tail plane box fairing and the fuselage; this should be 0.2 ± 0.05 in. (detail B).

Note...

The minimum gap at this point, between the tail plane seal rivets (post Mod. 1277) and the fin, is 0.080 in. (fig. 11, detail B).

(4) Set the tail plane in line with tail plane stub, and adjust the sealing strips to give the following clearances:-

(a) Between the sealing strips (two bolt position) and the tail plane stub - 0.04 in. minimum (detail D).

(b) Between the sealing strips (three bolt position) and the tail plane stub - 0.02 in. minimum (detail E).

(5) Ensure that there is complete freedom of movement throughout full range of tail plane travel.

Note...

Whenever a tail plane has been replaced or adjusted, a flight trim check must be made as detailed in Sect. 3, Chap. 4, Appendix 1 to ensure that the aircraft trim is within the limits laid down. Should the aircraft trim be outside the limits specified, a new trailing edge strip should be fitted and the flight trim checks, and subsequent trailing edge strip adjustments carried out.




FIG.7. TAIL PLANE REMOVAL

KEY TO FIG. 8 (ELEVATOR AND ELEVATOR TAB REMOVAL)

To remove the elevators:-

- (1) Set the tail plane to its mid-travel position.
- (2) Remove the box fairing and the rear fairing as instructed in Sect. 3, Chap. 1.
- (3) Disconnect the control tube (15) from the lever (16).
- (4) Remove the access panel (5) from the upper surface of the starboard elevator. This panel gives access to the connecting screw (3) on the operating lever (4) of the starboard tab.
- (5) Disconnect the starboard tab-operating lever at the connecting screw (3).
- (6) Remove the split pin, nut and washer from each balance weight arm (18) and withdraw the balance weights and arms from the elevator spars (17).
- (7) Disconnect the coupling link (1) from the starboard elevator.
- (8) Remove the split pin, nut and washer from the inboard hinge pin (2) of the port elevator.
- (9) Remove the port elevator from its hinges by moving it outboard, until it is clear of the centre and inboard hinges, and then aft.
- (10) Proceed as instructed in operations (8) and (9) with the starboard elevator.

Assembly details

To enable the alignment of the centre and outboard hinges to be checked during reassembly, apertures, closed by spring-loaded sealing plugs (6), are provided on the underside of the elevators at these hinge points. To remove, screw a 4 B.A. bolt (7) into the hole in the plug and pull outwards; to replace,

remove the bolt, insert the plug in the aperture and press it home. Ensure that the plug is flush with the elevator skin.

To remove an elevator tab:-

- (1) Remove the access panel (11), port, (4), starboard and, at this point, disconnect the tab connecting-rod (8) from the lever by removing the connecting screw (3), in the case of the starboard tab, and by removing the connecting bolt (14) in the case of the port tab.
- (2) Disconnect the tab connecting-rod (8) from the tab, and move the connecting rod clear of the attachment lugs.
- (3) Remove the inboard hinge bracket (13).
- (4) Raise the tab and remove it by moving it inboard until it is clear of the outboard and intermediate hinges, and then aft.

Note...

If new tabs are to be fitted it will be necessary to remove the inboard hinge pin (12). The pin is to be wire-locked on reassembly.

Assembly notes...

1. Before assembly, inspect the extreme end of the tab connecting-rod (8) and the surface between the two lugs of the tab hinge fitting (10). Where a foul has occurred clear it by lightly filing a small flat between the two lugs at the point of contact, so that a minimum clearance of 0.005 in. is obtained. The width of the slot is not to exceed the width of the rod end, and the amount of metal removed should not exceed 0.010 in. in depth.
2. When assembling an elevator tab, ensure that the tab connecting-rod (8) is connected to its attachment lugs with bolt Pt.No. EA1.31.65, and that

no load is placed on the operating rod attachment lugs when the nut is tightened, by fitting the plain and shim washers as follows:-

For the port tab (detail A) the thin plain washer Pt.No. SP.15/C, and shim Pt.No. EA1.31.277, must be positioned between the ball race and the outboard bracket, and the plain washer Pt.No. SP.16/C, between the nut and the inboard bracket. For the starboard (detail B) the thin plain washer must be positioned between the ball race and the outboard bracket, the shim between the ball race and the inboard bracket, and the other plain washer between the nut and the inboard bracket. Lock the nut with a new split pin. It may be necessary to tap the bolt through the ball race in the tab connecting-rod; the tapping must be as light as possible to avoid any possibility of fracturing the attachment lugs.

3. To ensure correct adjustment of the starboard tab the connecting screw (3) must be screwed into the operating lever and the connecting-rod simultaneously.

4. After fitting a new elevator, the clearance between the elevator horn and the tail plane must be checked; it is to be 0.25 ± 0.1 in. (fig. 12).

5. After fitting a new tab to the elevator, the clearance between the outboard end of the tab and the elevator must be checked; it is to be 0.2 ± 0.11 in. (fig. 12).

Note...

A flight trim check must be made whenever an elevator or elevator tab is removed and replaced or adjusted (Sect. 3, Chap. 4, Appendix 1).




FIG. 8. ELEVATOR AND ELEVATOR TAB REMOVAL

◀ WASHER PART NO. AMENDED ▶

KEY TO FIG. 9 (RUDDER AND RUDDER TAB REMOVAL)

To remove a rudder:-

(1) Screw a 4 B.A. bolt into the spring-loaded plugs (4) on the port and starboard sides of the rudder and remove the plugs by pulling the bolts outwards. Removal of these plugs permits a sling Ref.No. 26FZ/95054 to be passed through the rudder at this point.

(2) Remove the cover plates (12) at the base of the rudder, and the access panels (14) at the base of the fin.

(3) Disconnect the control tube (10) from the rudder lever (11) (detail B).

(4) Disconnect the electrical cables (15) from the rudder tab electrical actuator.

(5) Turn the rudder to port and remove the port closing plate (1).

(6) Turn the rudder to starboard and remove the starboard closing plate (2).

(7) Remove the circular access panel (13) on the port side of the rudder stub.

(8) Remove the split pin, nut and washer from the lower hinge (16).

(9) Turn the rudder to port and remove the three bolts from the port side of the upper hinge plate (3).

(10) Turn the rudder to starboard and remove the three bolts from the starboard side of the upper hinge plate (3). The rudder is then free to be removed by lifting.

Note...

Care must be taken when lifting the rudder to ensure that the lower mass-balance weight does not foul the underside of the fin trailing edge.

Assembly details

After assembling a rudder, refer to fig.12 and check the clearances:-

(1) Between the top of the fin and the rudder horn.

(2) Between the base of the rudder and the rudder stub.

If these clearances are not obtained, remove the shim Pt.No.EA1.12.201 situated between the rudder lower bearing housing and the stub, and substitute a solid packing of the same overall dimensions and material (L.73) but of a thickness between 17 s.w.g. and 12 s.w.g. as required.

(3) When fitting a new rudder, it is permissible to reduce the 0.50 in. depth of either trailing-edge spoiler to suit the characteristics of the aircraft.

To remove a rudder tab:-

(1) Remove the rudder tab control rod cowl (5).

(2) Remove the split pin, nut and washer from the bolt attaching the control rod (8) to the lugs (9) on the tab spar, and remove the bolt (detail A).

(3) Remove the three 2 B.A. bolts attaching the lower hinge bracket (6) to the rudder.

(4) Remove the tab from its hinges by lowering it slightly and moving it outwards.

Note...

If a new tab is to be fitted, remove and retain the hinge pin (7) from the hinge bracket (6). Upon reassembly, the hinge pin is to be locked with wire.

After fitting a new rudder tab, refer to fig.12 and check the clearances:-

(1) Between the top of the tab and the rudder.

(2) Between the bottom of the tab and the rudder stub.

Note...

An additional axial tab movement of 0.02 in. in respect of these dimensions is permissible.




FIG.9. RUDDER AND RUDDER TAB REMOVAL

KEY TO FIG. 10 (FIN REMOVAL AND ASSEMBLY)

To remove a fin:-

- (1) Remove the rudder (fig.9).
- (2) Remove the access panel (7) and disconnect the coaxial cable (13) to the A.R.I. aerial. Withdraw the cable from the aerial conduit.
- (3) Remove the leading edge cover plate (3) and remove the six 2 B.A. bolts attaching the forward attachment former (1) to the stub angle (2).
- (4) Remove the ten 2 B.A. bolts attaching the rear diaphragm (4) to the stub angle (5).
- (5) Remove the one-hundred-and-two 2 B.A. countersunk bolts (9) attaching the fin skin to the skin of the fin stub.
- (6) Remove the cover plates (8) from each side of the fin.
- (7) Remove the port and starboard bolts (10) and (14) securing the fin

post lugs (11) and (15) to the fin attachment lugs (12) and (18).

- (8) Remove the fin.

Note...

The fin may be slung by removing the fabric patch (6) from each side of the fin and passing a sling through the fin at this point.

To assemble a fin:-

- (1) Offer up the fin and insert the A.R.I. aerial coaxial cable (13) through the conduit. Connect the cable.
- (2) Insert the port and starboard bolts (10) and (14). Do not tighten them.
- (3) Secure the forward attachment former (1) to the stub angle (2) using the six 2 B.A. bolts.

Note...

When fitting a new fin it will be

necessary at this stage to mark off and remove the fin for drilling, dimpling and trimming.

- (4) Secure the rear diaphragm (4) to the stub angle (5) using the ten 2 B.A. bolts.
- (5) Secure the fin skin to the skin of the fin stub using the one-hundred-and-two 2 B.A. countersunk bolts (9).
- (6) Screw home the port fin post lug attachment bolt (10). Do not over-tighten.
- (7) Screw home the starboard fin post lug attachment bolt (14) to a point where the nut (16) is drawn against the inboard lug (18) of the fin post, and obtain a clearance of 0.0015 in. between the head of the bolt and the lug.
- (8) Fit the access panel and cover plates (3), (7) and (8).
- (9) Fit the rudder (fig.9). ▶

RESTRICTED

A.P. 101B-0406-1, Sect. 3, Chap. 3
A.L. 139, Feb. 69










FIG.10. FIN REMOVAL AND ASSEMBLY

9010

RESTRICTED

RESTRICTED



NOTE
ALL DIMENSIONS SHOWN
ARE IN INCHES

FIG. 11. TAIL PLANE CLEARANCES

RESTRICTED




Fig. 12. Fin, rudder and elevator clearances

◀ DETAIL A AMENDED ▶

RESTRICTED

Chapter 4 FLYING CONTROLS

LIST OF CONTENTS

DESCRIPTION	Para.	DESCRIPTION	Para.
General information	1	Air brakes control	17
Control column	2	Flaps control	18
Rudder bar	3	SERVICING	
Aileron control	4	Control neutral rigging locks.. . . .	19
Elevator control	5	Control rigging	
Rudder control	6	Aileron.. . . .	20
Pressure box	7	Elevator	21
Tail plane incidence control.. . . .	8	Rudder...	22
Aileron bias control.	9	Aileron bias	23
Spring tab mechanisms...	10	Starboard elevator ground-set tab.. . . .	24
Rudder spring tab mechanism.	11	Rudder trim actuator setting.. . . .	25
Aileron spring tab mechanism	14	Tail plane actuator setting	27
Port elevator spring tab mechanism	15	Air brakes setting...	28
Rudder trim actuator	16	Flaps setting...	29
		Static friction loads.	30
		Lubrication	31
		REMOVAL AND ASSEMBLY	
		General information.	32
		Control column.	33
		Rudder bar.	34
		Spring tab mechanisms	
		Aileron.. . . .	35
		Elevator	36
		Rudder...	37
		Aileron bias actuator	38
		Rudder trim actuator	39
		Tail plane actuator	
		Removal.	40
		Assembly	41
		Flying control rod assemblies	42
		Limits on Fairey roller guides	43

LIST OF ILLUSTRATIONS

DESCRIPTION	Fig.	DESCRIPTION	Fig.
Control column.	1	Fuselage levelling – for tail plane	
Control wheel – interdictor...	2	actuator setting...	11
Aileron bias control.	3	Tail plane actuator settings.. . . .	12
Pressure box	4	Tail plane actuator.. . . .	13
Rudder spring tab mechanism	5	Air brakes setting...	14
Aileron spring tab mechanism	6	Flap movement.	15
Port elevator spring tab mechanism	7	Aileron control rigging...	16
Air brakes control...	8	Elevator control rigging (pre Mod.2182)	17
Flaps control...	9	Elevator control rigging (post Mod.2182)	18
Control neutral rigging locks.	10	Rudder control rigging	19
		Lubrication diagram.	20
		Aileron spring tab mechanism removal	
		(pre Mod.1441)	21
		Aileron spring tab mechanism removal	
		(post Mod.1441)...	22
		Part elevator spring tab mechanism	
		removal.	23
		Rudder spring tab mechanism removal.. . . .	24
		◀ Control lever rigging ▶	25

LIST OF APPENDICES

DESCRIPTION	Appendix
Flight trim check B Mk.6 aircraft.. . . .	1
Flight trim check B(1) Mk.6 aircraft	2

RESTRICTED

DESCRIPTION

General information

1. The flying controls are conventional in operation, the control runs consisting of push-pull tubes and levers, with adjustable ends fitted to the tubes on each control run. Tabs in the trailing edges of the ailerons, port elevator, and rudder, are operated automatically through torque tubes and blow-back rods incorporated in the structure of the control surfaces. The starboard elevator tab operates as a balance tab, and can only be set on the ground. Adjustable trim strips are fitted to the trailing edges of the elevators. The upper trailing edge of the rudder is fitted with spoilers which may be adjusted if necessary to suit the characteristics of individual aircraft; they are pre-set by the manufacturer and should not normally require alteration. An electrical control permits the rudder tab to be used additionally as a trim tab in flight. Trim tabs are not fitted to the ailerons, but aileron bias is provided which is effected electrically. The variable incidence tail plane is electrically actuated and controlled; the flaps and airbrakes are also electrically controlled, but are hydraulically operated.

Control column (fig.1)

2. The control column, situated on the port side of the cabin centre line, is a tubular member which moves fore-and-aft on its support housing under the pilot's floor. At this housing it is coupled with a tubular shaft running laterally outboard to a bracket on the port side: a lever attached to the end of this shaft is connected to the elevator control run. Forward of this lever, and on the same shaft, is a shorter lever connected to the snatch rod of the snatch unit (Sect.3, Chap.11). At its upper end the control column carries a horn-type

control wheel, the shaft of which passes into the interior of the column where a bevel gear, integral with the shaft, meshes with a toothed segment at the top of the torque tube contained within the control column. The torque tube is supported in a bearing at the upper end of the column, and terminates at its lower end in a universal joint, which links it with a short shaft carried in the support casting; a lever at the end of this shaft is connected with the aileron control run. Mounted on the control handwheel are the wheel brakes operating lever, the airbrakes selector switch, and various other switches (fig.1). Controls mounted on the interdictor handwheel are shown in fig.2.

Rudder bar

3. The rudder pedals are fitted at each end of a centrally-pivoted horizontal cross-tube, and are fitted with alignment linkage giving them parallel fore-and-aft movement. The cross tube is attached to a short vertical torque shaft which protrudes through the pilot's floor, and is linked to an adjusting screw mechanism by which the pedals can be set to suit the pilot's leg reach. Movement of the rudder pedals is transmitted via the torque shaft and a horizontal lever at the bottom of the shaft, to a push-pull rudder control tube. Attached to this horizontal lever is a connecting rod to the brake relay control valve, which controls differential braking. The movement of the rudder pedals is limited by two adjustable stops on the pressure bulkhead acting on the control tube lever.

Aileron control

4. The movement of the aileron is controlled by the control column handwheel, movement of which rotates the inner torque tube of the control column, and the aileron

control lever at its lower end converts the rotary movement into a fore-and-aft movement, which is transmitted to the ailerons by push-pull tubes and levers. From the aileron control lever the control passes aft along the port side of the cabin to the inboard one of three levers mounted in the pressure box just aft of the pressure bulkhead. The control run continues from this lever through the V.H.F. equipment compartment and along the bomb bay roof to just aft of the main spar where, via a bell-crank lever, the controls enter the main planes. Here further bell-crank levers connect the control tubes to the aileron levers. The control tubes are carried along the fuselage by roller guides and are supported in the main planes by bell-crank levers and the aileron levers. Adjustable stops are provided on the pressure bulkhead in line with the aileron lever, these limit handwheel movement, while the control surface movement is limited by stops at the aileron inboard hinges.

Elevator control

5. The elevators are controlled by a fore-and-aft movement of the control column, this movement being transmitted, by a lever attached to the outboard end of the lateral tube at the bottom of the control column, to the port elevator by push-pull tubes and levers. From this control lever, the control tube passes aft, along the port side of the cabin to the outboard one of the three levers mounted in the pressure box just aft of the pressure bulkhead. From this lever the control continues, through the V.H.F. equipment compartment, along the roof of the bomb bay and through the rear fuselage, to a lever on the rear bulkhead at frame 42. The port elevator lever is connected to the lever by a further control tube, and the port and starboard




Fig.1. Control column

RESTRICTED




Fig. 2. Control wheel - interdictor

◀ (Mod. 3930 embodied) ▶

elevators are connected together by a coupling link joining the levers on the inboard ends of both elevator spars. The control tubes are carried in roller guides suitably positioned in the fuselage structure, and are provided with couplings at the fuselage transport joint positions. Adjustable stops, located on the pressure bulkhead in line with the elevator lever, limit control column movement, and control surface limit stops are provided at the starboard elevator link lever.

Rudder control

6. The rudder is controlled by movement of the rudder pedals, this movement being transmitted to the rudder by a horizontal lever at the bottom of the rudder torque shaft, and push-pull tubes and levers. From the rudder torque shaft lever the control tube passes aft along the port side of the cabin, to the centre one of the three levers mounted in the pressure box just aft of the pressure bulkhead. The control run continues from this lever through the V.H.F. equipment compartment, along the roof of the bomb bay and through the rear fuselage to the lower end of a lever on the bulkhead at frame 42. From the opposite end of this lever, a further control tube is connected to a lever at the bottom of the rudder. The control tubes are carried in roller guides, suitably positioned in the aircraft structure, and are provided with couplings at the fuselage transport joint positions. Adjustable stops located on the pressure bulkhead in line with the rudder lever, limit rudder bar movement. The rudder surface movement is limited by rubber stops at its lower hinge.

Pressure box (fig. 1)

7. The point at which the flying controls pass through the pressure bulkhead is




Fig.3. Aileron bias control




Fig. 4. Pressure box

◀(Illustration amended)▶

VIEW LOOKING AFT—NAVIGATOR'S
FLOOR AND DUST COVER REMOVED
FOR CLARITY

8012

called the pressure box. The box is of reinforced alloy construction and is bolted, over a rubber pressure seal, to the pressure bulkhead. On entering the pressure box from the cabin the flying control tubes connect to the lower attachment points of individual, centrally pivoted levers, which are pressure sealed about their pivot points. The upper portion of the three levers connect to the control tubes which continue through the V.H.F. equipment compartment. Stop-bolts, mounted on two channel section members, act on the levers in the pressure box and limit the movement of the pilot's controls; these stops are adjustable, and the correct dimensions and method of setting is given in the relevant control rigging diagram and key.

Tail plane incidence control

8. The variable incidence tail plane is hinged at its main spar centre section on two brackets attached to the rear fuselage at frame 42; and at its false spar, near the trailing edge, is connected to the rear fuselage by a two-speed electrical actuator. In this installation only the slow speed motor of the actuator is used. The actuator forms a strut between the tail plane and fuselage, the length of which may be varied in flight under the control of the pilot; extension of the actuator decreases the tail plane incidence. It is controlled on the B Mk.6, aircraft, by a three-position switch on the right handgrip of the control column handwheel: a cut-in switch mounted on the same handgrip has first to be depressed before electrical power is supplied to the actuator. The control on the B(I) Mk.6 aircraft is slightly different, the cut-in switch being in the form of a spring safety flap which must be raised before the three-position control switch can be operated. The com-

bined switch is situated on the aft face of the right handgrip.

Aileron bias control (fig.3)

9. Aileron trim is effected by a bias gear connected to the aileron control lever at the lower end of the control column, there being no independent aileron trim tab. The gear is operated by an electrical actuator which at one end is attached to a floor member, and at the other to a bias actuator lever pivoted on a floor member adjacent to the control column. A bias spring lever, integral with the bias actuator lever, is connected to the aileron control lever at the lower end of the control column by a tension spring. The relationship of the two levers is such that when the actuator is at its mid-position, i.e. half extended, the spring is at its minimum tension when the control handwheel is at neutral, and an equal load will be applied to the control when the handwheel is moved to port or starboard. Operation of the actuator either in or out, will increase the effect of the spring in one direction and decrease it in the other, and bias the control accordingly. The actuator is controlled by a spring-loaded centre-off position switch on the pilot's console, and an aileron trim indicator, operated by the movement of the actuator, is mounted on the instrument flying panel.

Spring tab mechanisms

10. The rudder, port elevator, and both ailerons are fitted with spring tabs complete with blow-back rod and torque tube mechanisms, which, in addition to their normal function when operated by the flying controls, have an entirely separate automatic operation. Their normal function is to relieve the pilot of heavy physical

loads on the controls, normally occasioned by major changes of direction at high speed; their automatic operation prevents the application of excessive control surface movement. With the exception of the rudder mechanism, which is fitted with two concentric torque tubes and has, in addition, electrical trim actuation, the mechanisms

differ only in size. The double torque tubes on the rudder mechanism act as one tube, but as they tend to make it appear slightly more complicated than those fitted for the aileron and elevator tabs, the rudder mechanism will be described in full. The description however, is equally applicable to all three.




Fig.5. Rudder spring tab mechanism

RESTRICTED




Fig. 6. Aileron spring tab mechanism

Rudder spring tab mechanism (fig. 5)

11. During normal flight the electrical actuator acts as a strut with fixed centres anchoring the actuator lever to the rudder structure through the mass balance arm. The actuator's function when used as a strut with variable pin centres is described in para. 16.

12. Consider a normal turn to starboard. The pilot pushes on the starboard rudder pedal and the control tube moves aft, rotating the rudder control lever in an anti-clockwise direction. The torque applied by the control lever is transmitted

through the inner and outer torque tubes to the actuator lever which, through the actuator, moves the rudder over to starboard. Assuming that there is no air load on the rudder and that the rudder hinges are frictionless, the actuator lever and consequently the rudder will rotate through the same angle as the control lever. During flight, the air load on the rudder resists the rudder rotation, and since the torque tubes are torsion springs, they twist under the pilot's effort; consequently the control lever moves through a greater angle than the actuator lever and the rudder. The

control lever has now rotated in an anti-clockwise direction relative to the rudder, as has also the tab actuating lever, due to the rotation of the blow-back rod which, at its lower end, is attached to the control lever. This rotation of the tab actuating lever is transmitted to the tab by the tab actuating rod and moves the tab to port, the air load on the tab then moves the rudder to starboard.

13. In addition to its function as a driving shaft between the control lever and the tab actuating lever, the blow-back rod has a safety role. The maximum movements of the rudder and tab, as regulated by their stops, are required for control at low speeds. If it were possible for the pilot to move the rudder through these maximum angles at high speed, prohibitive loads would be imposed on the aircraft structure. In flight, the angle of the rudder is determined by the angle of the tab, so that by restricting the tab movement during high speeds excessive loads on the structure are avoided. This restriction of tab movement is imposed by the blow-back rod, which under the influence of the high air load imposed by the application of large tab angles at high speed, twists in the direction opposite to that applied by the pilot to the control lever, with consequent reduction of tab and rudder angles. A stop-bolt, attached to the rudder spar, operates in a slot in the control lever in order to prevent the pilot applying excessive twist to the torque tubes. In flight, when the control lever is moved relative to the rudder and so moves the tab, one end of the slot will momentarily approach the stop-bolt but the applied tab movement will cause the rudder to turn in the same direction as the control lever, and the bolt will move away from the end of the slot.

Aileron spring tab mechanism (fig. 6)

14. The spring tab blow-back rod and torque tube mechanism is mounted laterally, forward of the aileron spar. The operation of the mechanism is similar to that of the rudder spring tab (para. 11).

Port elevator spring tab mechanism (fig. 7)

15. The spring tab blow-back rod and torque tube mechanism is mounted laterally, aft of the port elevator spar. The operation of the mechanism is similar to that of the rudder spring tab (para. 11).




Fig. 7. Port elevator spring tab mechanism

◀ BOLT REVERSED ▶

Rudder trim actuator

16. The rudder trim tab actuator forms a strut between the outer torque tube of the spring tab mechanism and the mass balance arm at the base of the rudder. Operation of the actuator alters the position of the spring tab mechanism relative to the rudder and moves the rudder tab to an angle corresponding to the rudder angle required, thus enabling the aircraft to be flown without applying any load at the rudder bar. The actuator switch is located on the pilot's console and a rudder trim indicator is mounted on the instrument flying panel.

Air brakes control (fig. 8)

17. The air brakes have three positions, and consist of 21 finger-type drag channels installed in each main plane, situated outboard of the engines and just aft of the main spar. In the out position nine of the drag channels protrude through the upper skin surface, and twelve through the lower skin surface of each main plane. They are operated by a single hydraulic jack in each main plane, and are controlled electrically by a switch mounted on top of the control column marked IN-MID-OUT. The air brake mechanism is described in Sect. 3, Chap. 2, and the hydraulic circuit in Sect. 3, Chap. 6.

Flaps control (fig. 9)

18. The flaps are operated by four double-ended hydraulic jacks, one jack to each flap. They are controlled electrically by a selector switch mounted on the alighting gear sloping panel.

SERVICING**Control neutral rigging locks (fig. 10)**

19. Three neutral rigging locks are provided for use when rigging the flying controls. They are:

- (1) *Aileron lock* — The lock is clamped to the control column so that the lock horns contact the underside of the hand wheel.
- (2) *Elevator lock* — The lock is clamped to the control column and an adjustable tie-rod terminating in a spade end, passes through the engine starting panel and is locked in position by a quick-release pin.
- (3) *Rudder lock* — The lock fits over the





Fig. 8. Air brakes control




Fig. 9. Flaps control

rudder bar star-wheel spindle and is secured to the pilot's floor by four bolts. The front plate of the lock fits hard against the star-wheel, which is prevented from rotating by two bolts protruding through the plate.

Control rigging

Aileron

20. The method of rigging the aileron controls is given in the key to fig. 16.

Elevator

21. The method of rigging the elevator controls is given in the key to fig. 17 and 18.

Rudder

22. The method of rigging the rudder controls is given in the key to fig. 19.

Aileron bias

23. No adjustment is provided in the aileron bias mechanism. The actuator pin centre distance is set by the manufacturers and will not need further adjustment.

Starboard elevator ground-set tab

24 To adjust the starboard elevator ground-set tab:

- (1) Lock the elevator in its neutral position by clamping the elevator horn to the tail plane.
- (2) Remove the elevator tab control access panel on the upper surface of the elevator.
- (3) Slacken the lock-nuts on the adjuster between the tab connecting rod and the end piece.
- (4) Operate the adjuster until the tab

chord line is 2 deg. 21 min. up relative to the elevator chord (*linear dimension, 0.25 in. \pm 0.05 in. between the trailing edges of the elevator and tab, measured at the outboard end of the tab*). Relock the adjuster locknuts.

(5) Remove the lock fitted in operation (1), move the elevator through its full travel in both directions and check the tab movement; it should be 17 deg. 30 min. with the elevator up or down (*linear dimension 1.85 in. \pm 0.1 in. measured as in operation (4)*).

Rudder trim actuator setting

25. The rudder trim actuator electrical stops are set to give a working stroke of 2.72 in. and the pin centres are nominally set at 7.5 in. (*fully contracted*) against an electrical stop. The mechanical stops are set to give a working stroke of 3 in. and the pin centres are nominally set at 7.425 in. (*fully contracted*) against a mechanical stop. These are manufacturer's settings and should not require any adjustment; however, should it be necessary, the pin-centres may be adjusted ± 0.125 in. as follows:-

- (1) Remove the actuator (*para.39*).
- (2) Using an 18-volt electrical supply, extend the actuator until the 1/16 in. dia. hole in the actuator arm is visible.
- (3) Slacken the locknut securing the fork-end, and screw the fork-end either inwards or outwards to adjust.
- (4) After adjustment, insert a piece of 1/16 in. dia. wire into the hole in the actuator arm. If the penetration is greater than 1/16 in. too much outward adjustment




Fig. 10. Control neutral rigging locks




Fig. 11. Fuselage levelling – for tail plane actuator setting

has been made and the fork-end must be screwed inward.

- (5) Tighten the locknut securing the fork-end.
- ◀(6) Using an 18-volt electrical supply, ▶ check that the electrical stops operate when the pin-centres are 7.5 in. and 10.22 in.
- (7) Replace the actuator in the reverse

order of removal.

26. To check the movement of the rudder tab and actuator:-

- (1) Connect a ground electrical supply to the external electrical supply socket.
- (2) With the rudder in line with the fin, and the tab in line with the rudder, operate the actuator until the pin-centres are 9.42 in. and check that the tab is moved 18 deg.

to starboard (linear dimension $1.73^{+0}_{-0.1}$ in. measured from the inboard trailing edge of the tab to the normal centre line of the rudder).

(3) Retract the actuator to obtain pin-centres of 8.37 in., and check that the tab is moved 18 deg. to port (linear dimension $1.73^{+0}_{-0.1}$ in. measured as in operation (2)).

Note...

(1) The excess of working stroke over the amount required to give full tab movement, is provided to cater for deflection of the torque tube and blow-back rod when an air load is applied to the tab.

(2) If the rudder tab movement is in excess of 18 deg., a new rudder tab operating lever stop plate (Ref.No. 26FZ/5495) (fig.24) should be fitted, and the stop-faces filed, if necessary, to obtain the desired 18 deg. movement. Similarly, if the 18 deg. movement is unobtainable, the existing stop plate may be filed.

Tail plane actuator setting

27. The following instructions for the setting of the Type 4022 Mk.1 tail plane actuator are listed in the sequence in which the setting must be carried out; no adjustment is possible on the actuator itself. For detailed information on the actuator refer to A.P.4343D, Vol.1, Book 3, Sect.14, Chap.89.

Note...

All tail plane angles are to be measured, relative to the fuselage horizontal datum, on the STARBOARD tail plane at the inboard rigging board position (using incidence gauge Ref.No. 26FZ/95115). The clinometer should not be disturbed during

the rigging operations and readings should be related to its initial setting.

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Open the camera access hatch and place the lateral levelling gauge (Ref.No. 26FZ/95093) on the levelling brackets, port and starboard, at frame 31. The port and starboard ends are indicated on the gauge (fig.11)

(3) Level the aircraft laterally (0 deg. \pm 0 min.).

Note...

It is most important that the aircraft is rigged to this degree of accuracy - both laterally and longitudinally - otherwise any deviation will have to be allowed for in the subsequent tail plane settings.

(4) With the lateral gauge in position place the longitudinal gauge (Ref.No. 26FZ/95040) on the levelling bracket on the starboard side of frame 29 bulkhead, and on the datum pad on the lateral gauge (fig.11).

(5) Level the aircraft longitudinally (0 deg. \pm 0 min.).

(6) Ensure that the microswitch tappets are screwed fully home, and that the upper and lower microswitches are set to give the minimum distance between the switches and tappets (fig.13).

(7) Retract the actuator on to its mechanical down stop and check that the tail plane up travel limit - tail plane leading edge up - is 4 deg. 7 min. \pm 13 min. relative




Fig. 12. Tail plane actuator settings

to the fuselage datum (fig.12).

Note...

As a precaution against damaging the actuator when running it on to its down stop, it is advisable to operate the motor in that direction at a reduced voltage. This is achieved by disconnecting the cable core T33L-1 (circuit C21) from the terminal A1 on the low-speed motor reversing relay in the rear fuselage, and then connecting a resistor of approximately 2.2 ohms resistance and 200-watt rating between the cable terminal and the cable. A suitable resistor would be a Painton Type 5007, of approximately 2.2 ohms resistance, and 'B' termination.

(8) Check and record the angle found in operation (7).

(9) Reduce the angle recorded in (8) by

8 min. \pm 1 min., this will give the angle at which the lower microswitch must be tripped (fig. 12).

(10) Adjust the lower tappet to operate the lower microswitch at the angle found in (9).

(11) Extend the actuator on to its mechanical stop and check that the tail plane down travel limit - tail plane leading edge down - is 2 deg. 4 min. \pm 13 min. relative to the fuselage horizontal datum (fig.12).

(12) Check and record the correct angle found in operation (fig.12).

(13) Increase the angle recorded in (12) by 8 min. \pm 1 min., this will give the angle at which the upper microswitch must be tripped (fig.12).




Fig. 13. Tail plane actuator

◀ (Mod.4287 incorporated) ▶

RESTRICTED

(14) Adjust the upper tappet to operate the upper microswitch at the angle found in (13).

(15) Re-check the operational angles of incidence at both upper and lower actuator positions, moving the actuator slowly when approaching the microswitches, and check that the tail plane indicator in the cockpit registers the take-off position when the incidence is 3 deg. 15 min. \pm 2 min.

(16) Finally, carry out flight trim checks as specified in Appendix 1 or 2.

Air brakes setting

28. To set the air brake mechanism:

(1) Remove the panels giving access to the air brake mechanism (Sect.2, Chap.4) from the underside of each main plane.

(2) Set the air brakes and flaps ground selector to GROUND and using the aircraft hand pump, fully extend the jacks.

(3) Check the dimension between the pin centres of the piston rod and jack body; this should be 24.92 in. Adjustment is effected by unlocking and rotating the eye-end of the jack piston-rod.

(4) Check that all drag-channel end plates are flush with the main plane skin.

(5) Disconnect the hydraulic pipe-lines from the starboard jack and blank off. Connect an external hand pump test rig.

(6) Slacken the securing bolts of the cam slide assembly on the jack piston-rod and move the slide a short distance along the piston-rod towards the eye-end of the rod.

(7) Retract the jack to extend the drag channels to the MID position in accordance with the dimension given in fig.16.

(8) Adjust the position of the cam slide on the piston rod to operate the microswitches at this point; tighten and wire-lock the securing bolts.

(9) Disconnect the external test rig from the starboard jack, re-connect the pipe-lines and bleed the air brake system.

(10) Fully extend the jacks, select MID and OUT, and check that the drag channel protrusion in each position agrees with the dimensions given in fig.14.

Note...

In the MID position the difference between the port and starboard drag channels must not exceed 0.5 in.

(11) Select IN, extend the jacks, lock all adjustment points and replace the access panels.




Fig. 14. Air brakes setting

(12) Set the air brakes and flaps ground selector to FLIGHT and wire-lock.

Flaps setting

29. To set the flap mechanism, proceed as follows for all flaps, using the hydraulic hand pump to operate them:

(1) Check the distance between the pin centres of the flap jack piston-rods (Chap.2, Flap jack assembly).

(2) With the flaps down, remove the locking plates from the links connecting the flaps to their operating levers, and slacken slightly all link adjustment screws (fig.9).

(3) Raise the flaps, moving them slowly when approaching the fully up position, and check that they do not bear on the underside of the main plane when the jacks are bottoming.

(4) Lower the flaps sufficiently to give access to the link adjustment screws and adjust at these points until, when the jacks are bottoming, they bear without undue pressure on the underside of the main plane.

(5) The movement of the flaps from the fully up to the fully down position is 29.28 in. \pm 0.50 in. (inboard flap) and 26.65 in. \pm 0.50 in. (outboard flap). This movement is to be measured from the trailing edge of the wing, at the outboard end of the inboard flap and at the inboard end of the outboard flap. Maximum permissible backlash is 0.3 in. (fig.15).

(6) When the correct flap settings have been obtained, check that there is a minimum clearance of 0.050 in. between the pushrod fork-ends and the flap hinge brackets throughout the full flap travel (fig.9).

Ensure that all of the 'free' lift in the flap at the hinges has been taken up when this check is made. If this clearance cannot be obtained, it is permissible to file, and remove locally, up to 0.10 in. maximum from the flap hinge bracket to clear the fowl; blend out the rebate.

Note...

The correct protective treatment (A.P. 2662B, Sect.1, Chap.3) must be applied to all filed surfaces.

Static friction loads

30. The maximum acceptable values for the static friction loads of the control runs are as follows:

Aileron.....	4 lb.
Elevator.....	6½ lb.
Rudder.....	6½ lb.

The loads are to be measured with a spring balance (*Ref.No.1A/4390 or 1H/118*) connected to the control at the point of application of the pilot's effort. The readings of the rudder and aileron runs are to be taken when the control commences to move. Due to the out-of-balance moment of the elevator control run, it is necessary to pull the control column forward by means of the spring balance, and take the maximum reading. Hold the control column in this position and zero the spring balance, then allow the control column to move back, with the spring balance held, and again

take the reading. Half the difference of the two readings will be the static friction load.

Lubrication

31. All lubrication points in the flying control system are illustrated in fig.20. With the exception of the air brakes drag channel rollers which are lubricated with oil OX-14; and the pre-packed roller bearings, all points are to be lubricated with low-temperature grease XG-275.

Note...

No grease or oil is to be applied to the roller guides of the flying control push-pull tubes.

REMOVAL AND ASSEMBLY

General information

32. The following paragraphs contain information on the removal and assembly of certain components of the flying controls. Only the removal operations are described, since the assembly is generally the reverse of these operations; where this is not the case, the fact is noted. The recommended sequence of operations is given, although in some cases it will be clear that it is not essential to adhere rigidly to this sequence. The necessary ground equipment is listed in Sect.2, Chap.4.

Control column

33. To remove the control column:

WARNING

Ensure that all relevant safety precautions as detailed on the LETHAL WARNING marker card have been observed.

(1) Disconnect all electrical supplies.

(2) Remove the pilot's seat bucket.

(3) Remove the screws securing the port foot ramp to the floor of the cockpit and remove the foot ramp.

(4) Remove the two leather dust covers from the base of the control column.

(5) Remove the two sealing cover plates, one at each side of the base of the control column.

(6) Remove the cover plate in the floor of the cockpit, forward of the control column, and the cover plate in the floor to port of the control column.

(7) Remove the access panels on the inboard face of the pilot's console (*forward end*).

(8) Disconnect the aileron control tube

from the lever at the bottom of the control column, and the elevator control tube and snatch unit from within the pilot's console (*Chap.11*).

(9) Disconnect the wheel brakes Bowden cable at the top of the control column, and remove the cable adjusters and the clips retaining the Bowden cable to the control column. Remove the cable.

(10) Disconnect the electrical cables from the terminal block beneath the cockpit floor, forward of the control column.

(11) Remove the eight 2 B.A. bolts securing the elevator torque tube bearing retaining plate to the inner face of the console.

(12) Remove the four ¼ in. bolts from the control column support casting.

(13) Partly lift the control column, release the bias spring from its attachment on the aileron control lever, move the control column slightly to starboard and remove it from the cockpit floor.

Rudder bar

34 To remove the rudder bar:

(1) Disconnect the control tube from the rudder control lever at the bottom of the rudder bar torque shaft.

(2) Disconnect the brake control valve lever from the rudder control lever.

(3) Remove the four $\frac{1}{4}$ in. nipples from the two spokes retaining the rudder control lever to the rudder torque shaft, and withdraw the spokes.

(4) Remove the rudder control lever.

(5) Remove the eight $\frac{1}{4}$ in. bolts securing the rudder bar pedestal to the cockpit floor, and remove the rudder bar.

Note...

Close-tolerance $\frac{5}{16}$ in. bolts may be fitted in lieu of the spokes (A.P.4326, Vol.6, Repair Leaflet B.2/27).

Spring tab mechanisms

Aileron

35. For the removal of a spring tab mechanism refer to fig.21 or 22.

Port elevator

36. For the removal of the spring tab mechanism refer to fig.23.

Rudder

37. For the removal of the spring tab mechanism refer to fig.24.

Aileron bias actuator (fig.3)

38. To remove the aileron bias actuator:

(1) Remove the floor cover plate forward of the control column.

(2) Disconnect the electrical cables from the actuator.

(3) Turn the control column hand wheel fully to starboard; this will give greater ease of access to the aileron bias lever.

◀ (4) Remove the split pin, nut and bolt securing the actuator ram to the actuator lever.

(5) Remove the split pin, nut and shouldered bolt securing the actuator to the floor beam, and remove the actuator. ▶

Rudder trim actuator

39. To remove the rudder trim actuator:

(1) Remove the actuator access panel on the starboard side of the fin.

(2) Disconnect the electrical cables from the actuator.

(3) Remove the split pin and nut from the bolt connecting the actuator ram to the actuator lever, and remove the bolt.

(4) Remove the split pin from the shouldered bolt attaching the actuator to the mass balance lever and remove the bolt.

(5) Remove the actuator.

Tail-plane actuator

Removal

40. To remove the tail-plane actuator:

(1) Set the tail plane to its mid-travel position.

(2) Remove the fuselage rear cone fairing and the rear fuselage fairing below the rudder (Chap.1).

(3) Disconnect the electrical cables from the actuator.




Fig. 15. Flap movement

(4) On aircraft embodying Mod. 1277 remove the five seal-adjustment bolts from each side of the tail plane.

(5) Attach sling Ref.No. 26FZ/95009 to the tail plane (Chap.3).

(6) Remove the split pin and nut from the bolt attaching the actuator to the reinforcement piece on frame 46 of the fuselage.

(7) Raise the sling until it takes the weight of the tail plane off the actuator, and withdraw the actuator attachment bolt.

(8) Remove the locking pin from the bolt connecting the actuator ram to the tail plane, and withdraw the bolt.

(9) Withdraw the actuator from the underside of the tail plane.

Note...

When the actuator has been removed, a jury strut Ref.No. 26FZ/95090 must be fitted before detaching the tail-plane sling.

Assembly

Note...

Ensure that the actuator cables T33H and T33L have a free length of 17 to 19 inches between the cable clamp at frame 46 and the tail plane actuator socket (S.T.I./CAN/340).

41. Assemble the tail plane actuator to

the aircraft in the reverse order to that given in para.40 and carry out the following checks:-

(1) On aircraft embodying Mod.1277 the tail plane must be set to the neutral position, i.e. 3 deg 56 min incidence measured at the starboard rigging position, and the sealing strips adjusted to give the following clearances:-

(a) Between the sealing strips (2-bolt position) and the tail plane stub fairing, 0.04 in. minimum.

(b) Between the sealing strips (3-bolt position) and the tail plane stub fairing, 0.02 in. minimum.

(2) Ensure complete freedom of movement throughout the full range of tail plane travel.

(3) Whenever a tail-plane actuator has been replaced or adjusted, a flight trim check as detailed in Appendix 1 or 2 must be made to ensure that the aircraft trim is within the permitted limits. Should the aircraft trim be outside these limits, fit a new trailing-edge strip and repeat the flight trim checks until a satisfactory result is obtained.

Flying control rod assemblies

42. The fork-end fittings of flying control rods are machined with a counter-bored recess on the outer face of one of the lugs concentric with the bolt hole. This recess is provided to accommo-

date the nut, when the tubes are connected. Should the bolt be reversed on assembly, i.e. fitted with the bolt head in the recess, it may foul the airframe at frame 12. An exception is at the connection of the control rods to the aileron levers, at which point the bolt must be inserted from inboard and the head must locate in the recess in the forked end (fig.16, J).

Limits on Fairey roller guides

43. During assembly of the control rods, the following procedure should be adopted to obtain the correct clearance between the control rods and the roller guides:-

(1) Assemble the control rods through the fairleads.

(2) Release the locking screw in each adjustable roller guide assembly and, at the point of maximum diameter, adjust until the three rollers in each assembly are in contact with the control rods.

(3) Tighten the locking screws and re-check the adjustment.

(4) Move the control rods to the slackest position of travel, at which point the following clearances between the rod and any one roller must not exceed 0.006 in. at the fairlead nearest to any lever motion and 0.012 in. at any other fairlead.

KEY TO FIG. 16 (AILERON CONTROL RIGGING)

To rig the aileron control:-

(1) Jack and trestle the aircraft laterally and longitudinally level (Sect. 2, Chap.4).

(2) Disconnect the aileron control tube (detail 3, point F) from the upper end of the lever, and screw back the upper and lower stop-screws on the pressure bulkhead. These operations, except for the lower limit stop-screw, can be

made through the V.H.F. equipment compartment on the port side of the fuselage. The lower limit stop-screw is on the forward face of the pressure bulkhead.

(3) Set the control column hand wheel to its neutral position, i.e. horizontal laterally, using a straight edge and clinometer applied over the top of the hand wheel. Lock the hand wheel in this position (para.19(1)).

Note...

Use the same location for the straight edge for all subsequent angular measurements of the hand wheel.

(4) With the hand wheel locked in the neutral position, set the control lever, aft of the pressure bulkhead (fig.25), to its neutral position (6.67 in., measured square from the pressure bulkhead to the upper control attachment

RESTRICTED




FIG. 16. AILERON CONTROL RIGGING

RESTRICTED

KEY TO FIG. 16 (AILERON CONTROL RIGGING) - continued

bolt centre) by adjusting the control tube at point D (fig.16, detail 3).

(5) Unlock the hand wheel, rotate to 92 deg to port and adjust the upper limit stop-screw on the pressure bulkhead (detail 3) until it contacts the upper arm of the control lever. Tighten locking nut.

Note...

To prevent the possibility of a foul occurring between the wheel brake lever and the air brake switch, the wheel brake lever must be locked in the parked position during handwheel rigging operations.

(6) Rotate the hand wheel 89 deg to starboard and adjust the lower limit stop-screw on the pressure bulkhead (detail 3) until it contacts the lower arm of the control lever. Tighten locking nut.

(7) Lock the hand wheel in its neutral position and reconnect the aileron control tube (detail 3, point F) to the upper end of the lever at the pressure bulkhead.

(8) Check that the lower arm of the bell-crank lever, aft of the main spar frame in the roof of the bomb bay, is parallel to the main spar. Adjust, if necessary, at the control tube connections at either end of the control tube (points F or G).

(9) With the stop pins in the ailerons at the aft end of the slots in the control levers, adjust both aileron control tubes at point H (detail 1) to give the ailerons a droop of 4 deg 54 min (linear dimension 1.45 in. \pm 0.1 in., measured at point C).

(10) Disconnect the aileron control tubes at the aileron levers and, with the aileron stop pins at the aft end of the slots in the control levers (detail 1), set the tabs with 15 deg droop relative to the aileron datum (linear dimension 1.38 in. \pm 0.1 in., measured

at point A). Adjust the tab control rod by removing the control rod fairing (Chap.2), slackening the locknut at the tab end of the control rod, and the locknut at the control rod connection to the tab lever (detail 2, point B), and turning the control rod as necessary.

(11) Remove the stop pin (detail 1) and ensure that the tab-setting (operation (10)) does not alter; this is to check that there is no pre-loading of the aileron spring tab torque tube. If pre-loading is found, adjustment to relieve it may be made on the torque tube bracket (inboard - post Mod.1441 B(I) Mk.6 aircraft) attachment bolts by transferring shims from one bolt position to the other.

Note...

The shims are initially fitted to a thickness of 0.040 in. between the outboard attachment bracket (inboard attachment bracket post Mod.1441), and the aileron spar at each of the two bolts. Shims removed from one bolt must be added to the other bolt, so that there remains an aggregate of 0.080 in. shimming at the two bolt positions.

(12) Move the ailerons up (manually) 15 deg (linear dimensions 4.58 in. \pm 0.2 in., measured at point C), and set the upper limit stop (detail 1).

(13) Move the ailerons down (manually) 15 deg (linear dimensions 4.58 in. \pm 0.2 in., measured at point C), and set the lower limit stop (detail 1).

(14) Reconnect the aileron control tube to the aileron lever (detail 1) and unlock the hand wheel.

Note...

The bolt 'J' must be inserted from inboard and the bolt head must locate in the recess in the forked end; to achieve this condition when adjusting the controls it may be necessary to rotate the complete rod assembly through 180 deg so that the recess faces inboard.

(15) Move the hand wheel in both directions until the movement is arrested by the down aileron limit stop. It will be noted that the down aileron reaches its limit stop in advance of the up aileron. Further movement of the hand wheel in both directions will give the ailerons and tabs their respective full movements (detail 4).

(16) Ensure that all adjustment points are securely locked and that the control tube couplings do not foul the roller guides during any position of the aileron control movement.

(17) Carry out flight trim checks as detailed in Appendix 1 or 2.

Aileron fixed trim strips

The neutral position of the aileron fixed trim strip on each aileron is in line with the aileron chord line. These strips are set by the manufacturer and the setting should not normally need alteration. If, however, adjustment is necessary, progressive adjustment to a maximum of 10 deg either up or down from the neutral position may be made on the ground, using setting tool Ref. No.26FZ/95101, and gauge Ref.No.26FZ/95100.

Note...

An adjustment of 3 deg up on one fixed trim strip and 3 deg down on the other is equivalent to five divisions on the aileron trim indicator when the aircraft is flying at 450 knots I.A.S.

* Rigging of aileron controls following replacement of control tubes and levers, frame 21 to aileron attachment (fig.16) The following method of rigging the aileron controls, port and starboard, is recommended.

(1) Set inboard adjustable control tubes bell-crank lever to lever arm at rib 4, centre wing, to nominal length (1½ turns in from the safety check hole).




FIG. 17. ELEVATOR CONTROL RIGGING (PRE-MOD. 2182)

KEY TO FIG. 16 (AILERON CONTROL RIGGING) - continued

◀ (2) Ensure that the lower arm of the bell-crank lever aft of main spar frame is parallel to the main spar.

(3) Fit control tubes as follows:-

(a) Bell-crank lever to lever arm, rib 4, centre wing.

(b) Lever arm to centre lever, engine bay.

(c) Centre lever to lever arm, rib 2, outer wing.

(d) Lever arm to hinge mounting assembly, rib 4, outer wing.

(e) Hinge mounting to aileron. Adjust for correct aileron droop. Check for safety.

Note...

Due to the fact that the control tube attachment bolt to aileron, is re-

quired to be fitted with the head in the recess in the fork end, and facing inboard, adjustment at this point can only be made in full turns in or out as required. In the event of a half turn adjustment being required, the full turn should be applied, and a half turn adjustment made in the opposite direction at the adjustable end of the bell-crank lever to lever arm control tube at rib 4, centre wing. ▶

KEY TO FIG. 17 AND 18 (ELEVATOR CONTROL RIGGING - PRE AND POST MOD. 2182)

WARNING

Before making any adjustments to the elevator stops, ensure that all relevant safety precautions detailed on the LETHAL WARNING marker card have been observed.

(1) Jack and trestle the aircraft laterally and longitudinally level (Sect. 2, Chap. 4).

(2) Disconnect the elevator control tube (detail 1, point B) from the upper end of the lever, and screw back the upper and lower stop-screws on the pressure bulkhead. These operations, except for the lower limit stop-screw, can be made through the V.H.F. equipment compartment on the port side of the fuselage. The lower limit stop-screw is on the forward face of the pressure bulkhead.

(3) Set the control column to its neutral position (6 deg 30 min forward of the vertical), using a clinometer applied to the rear of the control column. Lock the control column in this position (para. 19).

(4) Set the control lever aft of the pressure bulkhead (fig. 25), to its neutral position (6.22 in. measured from the pressure bulkhead to the upper control attachment bolt centre) by adjusting the control tube at point A or C (fig. 17).

Note...

1. Any adjustments made at the pressure bulkhead, may affect the clearances at the snatch unit sear operating lever. Check the dimensions in accordance with Chap. 11, fig. 1.

2. Unlock the control column, move it through its full travel in both directions, and ensure that the explosive collar does not foul the adjacent structure. If it is necessary to move the collar, ensure that the red line is re-painted on the tube on either side of the collar, and the existing red line is obliterated.

(5) Move the control column 16 deg forward of the vertical and adjust the upper limit stop-screw on the pressure bulkhead (detail 1) until it contacts the upper arm of the control lever. Tighten the locking nut.

(6) Move the control column 6 deg 30 min aft of the vertical and adjust the lower limit stop-screw on the pressure bulkhead (detail 1) until it contacts the lower arm of the control lever. Tighten the locking nut.

(7) Reconnect the elevator control tube (detail 1, point B) to the upper end of the lever aft of the pressure bulkhead.

(8) Disconnect the elevator control tube at point D (detail 2) from the lever on the bulkhead at frame 42; access is through the rear camera hatch.

(9) Set the tail plane in its take-off position (incidence gauge reading at starboard inboard position 3 deg 15 min).

(10) Move the elevator down (manually) and adjust the elevator lower limit stop at the starboard elevator link lever, to give the elevator horn an upward movement of 15 deg (linear dimen-

sion 8.4 ± 0.3 in., measured from the leading edge of the tail plane to the leading edge of the elevator horn (point F)).

(11) Move the elevator upwards (manually) and adjust the elevator up limit at the starboard elevator link lever to give the elevator horn a downward movement of 20 deg (linear dimension 11.16 in. ± 0.30 in. measured as for operation (10)).




Note...

The measurements given in operations (10) and (11) are obtained with the rubber stop-pads removed. With the stop-pads in position the measurements will be slightly less.


(12) With the tail plane in its take-off position (operation 9), lock the elevator in its neutral position, i.e. in line with the chord line of the tail plane, by fitting clamps between the elevator horn and the tail plane.

(13) Adjust the port tab control tube until the tab is in its neutral position, i.e., pre Mod. 2182 12 deg 30 min UP relative to the elevator (linear dimension 1.30 in. ± 0.10 in.). and post Mod. 2182 9 deg UP relative to the elevator (linear dimension 0.95 in. ± 0.10 in.). These dimensions are measured between the trailing edges of the elevator and tab (point G), with the stop pin in the centre of the slot in the tab operating lever.

(14) With the tail plane, elevator, and port tab in their neutral positions, set the



NOTE... ALL DIMENSIONS ARE IN INCHES



NOTE

AIRCRAFT IN WHICH MOD. 2182 HAS BEEN EMBODIED RETROSPECTIVELY ARE TO BE SET AS SHOWN IN DETAIL A. THESE AIRCRAFT MAY BE RECOGNISED BY THE SHORTENED TAB INBOARD MASS BALANCE ARMS (DETAIL C). THE TAB PART NUMBERS ARE:-

	PRE MOD. 4077	POST MOD. 4077
PRE MOD. 2182	EA1.31.5	EA3.31.125
POST MOD. 2182	EA9.31.7	EA9.31.105

AIRCRAFT IN WHICH MOD. 2182 HAS BEEN EMBODIED DURING CONSTRUCTION ARE TO BE SET AS SHOWN IN DETAIL B. THESE AIRCRAFT DO NOT CONTAIN TAB INBOARD MASS BALANCE. THE TAB PART NUMBERS ARE:-

	PRE MOD. 4077	POST MOD. 4077
PRE MOD. 2182	EA1.31.5	EA3.31.125
POST MOD. 2182	EA9.31.5	EA9.31.69

FIG.18. ELEVATOR CONTROL RIGGING (POST MOD. 2182)

KEY TO FIG. 17 AND 18(ELEVATOR CONTROL RIGGING - PRE AND POST MOD.2182) - *continued*

control lever on the bulkhead at frame 42 to its neutral position (6.35 in \pm 0.1 in measured square from the bulkhead to the control tube attachment bolt centre) by adjusting the control tube at point E.

(15) Lock the control column in the neutral position, reconnect the control tube at point D (*detail 2*) to the lever on the bulkhead at frame 42, adjusting the rear end of the main control tubes (*point D*) as necessary.

(16) Unlock the control column and elevators, and check the elevator and tab movement. The elevator movements should be those given in operations (10) and (11). The linear dimension of the starboard tab should be that given in para.24. Relock the port elevator and check the movement

of the port spring tab. These should be the dimensions given in fig.17, pre Mod. 2182, or fig.18, details A or B, depending upon the nature of the embodiment of Mod. 2182 (*detail C*). When Mod.2182 has been embodied immediate and retrospective, the relative tab to elevator angle is greater than 20 deg with the tab fully up. At about this position a foul occurs between the tab mass balance and the elevator skin, this is acceptable providing the minimum dimension is achieved before the foul occurs, as this tab angle never occurs in flight. However, this angle can be reached during ground checks when the control column is moved through its full travel, or when the spring tab is moved by hand to check for defective torque tube blow-back rod assemblies. Unlock the port elevator.

Note ...

When the elevator tabs are being moved to the extreme travel position the operation is to be performed gently thereby avoiding heavy contact between the balance weights and skin.






(17) Ensure that all adjustment points are securely locked and that the control tube couplings do not foul the roller guides at any point of the control column movement.

(18) Following completion of adjustments, check the operation of the control column snatch unit (*Chap.11*).

FULL ANGULAR TRAVELS ARE OBTAINED WITH CONTROL SURFACES DISCONNECTED. OPERATIONAL TRAVELS ARE REQUIRED TO GIVE FULL CONTROL SURFACE MOVEMENTS

FULL 28 DEG. 30 MIN.
OPERATIONAL 22 DEG.

FULL 26 DEG.
OPERATIONAL 19 DEG. 30 MIN.



NOTE: - ALL DIMENSIONS ARE IN INCHES

Fig. 19. Rudder control rigging

KEY TO FIG. 19 (RUDDER CONTROL RIGGING)

To rig the rudder control:

- (1) Disconnect the rudder control tube (*detail 1, point A*) from the upper end of the control lever, and screw back the upper and lower stop-screws on the pressure bulkhead. These operations, except for the lower limit stop-screw, can be made through the V.H.F. equipment compartment on the port side of the fuselage. The lower limit stop-screw is on the forward face of the pressure bulkhead.
- (2) Turn the adjustment screw on the rudder bar until the pedals are in their neutral position and the two portions of the rudder bar are in line.
- (3) Set the rudder bar in its neutral position (*at right angles to the centre line of the fuselage*) and lock it in this position (*para. 19*).
- (4) Set the control lever aft of the pressure bulkhead (*fig. 25*), to its neutral position (*6.67 in. measured square from the pressure bulkhead to the upper control attachment bolt centre*) by adjusting the control tube at point B (*fig. 19, detail 1*).
- (5) Unlock the rudder bar and apply port rudder until the port pedal is 28 deg. 30 min. forward of the neutral position. Adjust the lower control limit stop-screw on the pressure bulkhead (*detail 1*) until it contacts the lower arm of the lever. Tighten the locking nut.
- (6) Apply starboard rudder until the starboard pedal is 26 deg. forward of the neutral position and adjust the upper control limit stop-screw on the pressure bulkhead (*detail 1*) until it contacts the upper arm of the lever. Tighten the locking nut.
- (7) Re-connect the rudder control tube (*detail 1, point A*) to the upper end of the lever at the pressure bulkhead.
- (8) Lock the rudder bar at neutral.
- (9) Disconnect the control tube from the rudder lever at point E, and lock the rudder in its neutral position by applying a clamp between the lower edge of the rudder and rudder stub, forward of the spring tab.
- (10) Operate the trim tab actuator until its pin centres are set at 8.9 in. ± 0.125 in. and adjust the tab connecting rod on the starboard side of the rudder until the tab is in line with the rudder.
- (11) Set the control lever (*detail 2*) on the bulkhead at frame 42 to its neutral position (8.65 in. ± 0.1 in., measured square from the bulkhead to the control attachment bolt centre) by adjusting the control tube at point D.
- (12) Re-connect the control tube to the rudder lever at point E, adjusting the fork-end of the control tube at points C or E, as necessary.
- (13) Remove the lock from the rudder and unlock the rudder bar.
- (14) Apply port rudder until the rudder stop is contacted and check the rudder

movement; it should be 25 deg. to port (*linear dimension 23.1 in. ± 1.0 in. at point G*).

(15) Apply further port rudder until the tab has moved 18 deg. to starboard (*linear dimension measured from the inboard edge of the tab to the centre of the trailing edge of the rudder (point F) should be 1.73 in. $\begin{matrix} + 0 \\ - 0.1 \end{matrix}$ in. as shown in detail 3*).

(16) Repeat operations (14) and (15) but with starboard rudder, and check the movement of the rudder and tab; these should be the same as for the port rudder.



Note...

(1) The measurements given in operation (14) and (15) are obtained with the rubber stop pads removed. With the stop pads in position and normal force applied to the rudder bar, the linear measurement given in operation (14) should be 21.75 in. ± 1.0 in.

(2) If the rudder tab movement, operation (15), is in excess of 18 deg., a new rudder tab operating lever stop plate (Ref.No. 26FZ/5495) (*fig. 24*) should be fitted, and the stop-faces filed, if necessary, to obtain the desired 18 deg. movement. Similarly, if the 18 deg. movement is unobtainable, the existing stop plate may be filed.

(17) Ensure that all adjustment points are securely locked and that the control tube coupling does not foul the roller guides at any position of the rudder bar.

- 1 ELEVATOR OUTER HINGES (PORT AND STARB.) [□]
- 2 ELEVATOR BALANCE TAB ARM (STARB. ONLY) [□]
- 3 RUDDER UPPER HINGE [□]
- 4 FLAP HINGES (PORT AND STARB.) [□]
- 5 AILERON HINGES (PORT AND STARB.) [□]
- 6 FLAP JACK LINKAGE (EACH FLAP, PORT AND STARB.) [→□]
- 7 AIR BRAKES JACK LINKAGE (PORT AND STARB.) [□]
- 8 DRAG CHANNEL ROLLERS (PORT AND STARB.) [○]
- 9 FLAP MECHANISM (EACH FLAP, PORT AND STARB.) [→□]
10. TAIL PLANE FRONT HINGES (PORT AND STARB.) [□]
- 11 TAIL PLANE ACTUATOR CONNECTIONS [□]
- 12 ELEVATOR TAB HINGES (PORT AND STARB.) [□]
- 13 AILERON TAB HINGES (PORT AND STARB.) [□]
- 14 AILERON CONTROL JOINTS (PORT AND STARB.) [□]
- 15 RUDDER CONTROL LEVER STOP SLIDE [□]
- 16 RUDDER TRIM TAB ACTUATOR CONNECTIONS [□]
- 17 RUDDER TAB ACTUATING TUBE CONNECTIONS [□]
- 18 RUDDER TAB HINGES [□]
- 19 ELEVATOR LEVERS LINKAGE [□]
- 20 ELEVATOR TAB ACTUATING TUBE CONNECTIONS (PORT ONLY) [□]
- 21 ELEVATOR CONTROL TUBE CONNECTION [□]
- 22 ELEVATOR CONTROL LEVER STOP SLIDE [□]



- 23 ELEVATOR CONTROL CONNECTIONS [□]
- 24 AILERON CONTROL CONNECTIONS (PORT AND STARB.) [□]
- 25 AILERON TAB ACTUATING TUBE CONNECTIONS (PORT AND STARB.) [□]
- 26 RUDDER AND ELEVATOR CONTROL TUBE JOINTS (3 RUDDER, 5 ELEVATOR) [□]
- 27 AILERON, RUDDER AND ELEVATOR CONTROL TUBE JOINTS (3 JOINTS EACH) [□]
- 28 PRESSURE BOX [○] (ON BARREL)
- 29 RUDDER PEDAL LINKAGE [□]
- 30 AILERON CONTROL LEVER PIVOTS (PORT AND STARB.) [□]

ALL OTHER MOVING PARTS ARE FITTED WITH PRE-PACKED BEARINGS

KEY TO SYMBOLS

- [□] GREASE XG-275
- [○] OIL OX-14
- [→□] GREASE GUN LUBRICATION

Fig.20. Lubrication diagram

RESTRICTED




Fig. 21. Aileron spring tab mechanism removal (pre Mod.1441)

◀ (Recess shown on fork end - detail 2) ▶

RESTRICTED

KEY TO FIG. 21 (AILERON SPRING TAB MECHANISM REMOVAL - PRE MOD.1441)

To remove an aileron spring tab mechanism (pre Mod.1441):

- (1) Remove the aileron (Chap.2).
- (2) Remove the access panel from the leading edge of the aileron and disconnect the tab operating rod from the torque tube lever.
- (3) Remove the stop bolt and bush from the slot in the aileron operating lever at the inboard end of the tab operating gear assembly (detail 2).
- (4) Remove the bolt securing the tab operating lever to the blow-back rod at the outboard end of the assembly (detail 1).
- (5) Using an extractor (Ref.No.26FZ/95044) withdraw the tab operating lever from the splines of the blow-back rod (detail 1).
- (6) Remove the two bolts attaching the mounting bracket, at the outboard end of the tab operating mechanism, to the spar (detail 1).

Note...

Between the mounting bracket and the aileron spar shims are fitted which are used to adjust the spring tab mechanism (detail 1). It is important that these shims are refitted in their original positions, as

neglecting to do this may subject the torque tube assembly to undue strain.

- (7) Ease the spigot at the inboard end of the tab operating mechanism from its ballrace, and withdraw the mechanism from the aileron.

Sequence of assembly:

The assembly sequence for refitting the existing spring tab mechanism is the reverse of that given for the removal.

Assembly of a new spring tab mechanism:

- (1) Separate the mounting bracket from the original tab operating mechanism by removing the nuts from the three counter-sunk bolts.
- (2) Assemble the original mounting bracket to the new spring tab mechanism, with the flange of the bracket positioned approximately parallel to the bolt hole in the splined end of the blow-back rod.
- (3) Assemble the mechanism into the aileron and temporarily bolt the mounting bracket to the aileron spar, fitting between the mounting bracket and the spar, a shim washer at both bolt positions.
- (4) Assemble the stop bolt and bush through the slot in the aileron operating lever at the inboard end of the tab operating gear (detail 2).

- (5) Assemble the torque tube lever to the splined end of the blow-back rod, and fit the bolt, nut, saddle washers, and split pin (detail 1).

- (6) Fit the tab operating rod.

- (7) Check that with the stop bolt at the aft end of the slot in the aileron operating lever there is no pre-loading in the torque tube. If pre-loading is found, adjustment to relieve it may be made on the mounting bracket attachment bolts by transferring shims from one bolt to the other.

◀ **Note...**

The shims are initially fitted to a thickness of 0.040 in. between the outboard attachment bracket and the aileron spar at each of the two bolts. Shims removed from one bolt must be added to the other bolt, so that there remains an aggregate of 0.080 in. shimming at the two bolt positions. ▶

- (8) Adjust the tab operating rod to give the tab a 15 deg. droop.
- (9) Refit the aileron to the aircraft (Chap.2).
- (10) Carry out flight trim checks as detailed in Appendix 1.




Fig. 22. Aileron spring tab mechanism removal (pre Mod.1441)

◀(Recess shown on fork end - detail 2)▶

RESTRICTED

KEY TO FIG.22 (AILERON SPRING TAB MECHANISM REMOVAL – POST MOD.1441)

To remove an aileron spring tab mechanism (post Mod.1441):

- (1) Remove the aileron (Chap. 2).
- (2) Remove the access panels from the leading edge of the aileron and disconnect the tab operating rod from the torque tube lever.
- (3) Remove the stop bolt and bush from the slot in the aileron operating lever at the inboard end of the tab operating gear assembly (detail 2).
- (4) Remove the bolt securing the torque tube lever to the blow-back rod at the outboard end of the assembly (detail 1).
- (5) Using an extractor (Ref.No. 26FZ/95044) withdraw the tab operating lever from the splines of the blow-back rod (detail 1).
- (6) Remove the bolts attaching both the inboard and outboard mounting brackets to the aileron spar. Withdraw the operating gear.

Sequence of assembly:

The assembly sequence for refitting the existing spring tab mechanism is the reverse of that given for the removal.

Note...

Between the inboard mounting bracket and

the aileron spar shims are fitted which are used to adjust the spring tab mechanism (detail 2). It is important that these shims are refitted in their original position, as neglecting to do this may subject the torque tube assembly to undue strain.

Assembly of a new spring tab mechanism:

- (1) Assemble the original outboard mounting bracket to the new spring tab mechanism, with the flange of the bracket positioned approximately parallel to the bolt hole in the splined end of the blow-back rod.
- (2) Assemble the mechanism into the aileron and temporarily bolt the mounting brackets to the aileron spar, fitting between the inboard mounting bracket and the spar, a shim washer at both bolt positions.

Note...

If difficulty is experienced when attempting to fit the inboard mounting bracket, the inboard edge of the bracket may be filed locally until a satisfactory fit is obtained. The correct protective treatment (A.P. 2662B) must be applied to all filed surfaces.

- (3) Assemble the stop bolt and bush through the slot in the aileron operating lever at the inboard end of the tab operating gear (detail 2).
- (4) Assemble the torque tube lever to

the splined end of the blow-back rod, and fit the bolt, nut, saddle washers, and split pin (detail 1).

- (5) Fit the tab operating rod.
- (6) Check that with the stop bolt at the aft end of the slot in the aileron operating lever there is no pre-loading in the torque tube. If pre-loading is found, adjustment to relieve it may be made on the inboard mounting bracket attachment bolts by transferring shims from one bolt to the other.

Note...

◀ *The shims are initially fitted to a thickness of 0.040 in. between the inboard attachment bracket and the aileron spar at each of the two bolts. Shims removed from one bolt must be added to the other bolt, so that there remains an aggregate of 0.080 in. shimming at the two bolt positions.* ▶

- (7) Adjust the tab operating rod to give the tab a 15 deg. droop.
- (8) Refit the aileron to the aircraft (Chap.2).
- (9) Carry out flight trim checks as detailed in Appendix 2.




Fig. 23. Port elevator spring tab mechanism removal

RESTRICTED

KEY TO FIG.23 (PORT ELEVATOR SPRING TAB MECHANISM REMOVAL)

Sequence of removal:

- (1) Refer to Sect.3, Chap.3, and remove the port elevator from the aircraft.
- (2) Obtain access to the outboard end of the tab operating gear assembly by removing the panel in the top surface of the elevator.
- (3) Unfasten the nut and withdraw the bolt that secures the tab operating lever to the extreme outboard end of the tab operating gear assembly.
- (4) Remove the split pin from the shackle pin, and withdraw the shackle pin from the slots in the links at the inboard end of the tab operating gear, and allow the links to swing downwards clear of the main operating lever.
- (5) Remove the two nuts and withdraw the bolts securing the bearing bracket to the elevator main spar at the extreme inboard end of the torque tube assembly.
- (6) Break the locking wire and slacken the torque tube clamp nut which secures the outboard end of the assembly to the outboard bearing bracket; the complete torque tube assembly can then be withdrawn through the inboard end of the elevator.

Sequence of assembly:

- (1) Offer up the torque tube, the inboard bearing bracket, the blow-back rod, and the main operating lever, to the elevator.
- (2) Pass the splined end of the torque tube through the clamp nut into the tab operating lever, and fit and tighten the tab operating lever securing bolt.
- (3) Fit the two bolts which attach the inboard bearing bracket to the elevator main spar.
- (4) Tighten the torque tube clamp nut, and ensure that the gap between the outboard bearing bracket and the tab operating lever does not exceed 0.25 in. (view on arrow A).

Note...

If this dimension cannot be obtained, or when fitting a new rod, refer to repair scheme, Vol.6, Part 2, Group D, Leaflet D4/2.

- (5) Secure the links to the main operating lever by fitting the shackle pin together with its associated washers and split pin.
- (6) With the top surface of the elevator uppermost, the centres of the shackle pins must be 3.12 in apart. With the stop pin in the centre of the slot of the tab operating

lever (arrow 'A') and the tab in its neutral position (12 deg. 30 min. up), clamp together the main operating lever and the flanges of the torque tube and blow-back rod.

- (7) Check the tab movements.
- (8) From the 5/32 in. dia pilot holes in the flange of the blow-back rod, drill and ream (0.185 in dia) the main operating lever and the flange of the torque tube. Secure the assembly with four countersunk bolts, and remove the clamps fitted in operation 6.
- (9) Wire-lock the torque tube clamp nut.
- (10) Fit the access panel to the top surface of the elevator.
- (11) Refit the elevator to the aircraft (Sect.3, Chap.3).
- (12) Rig the elevator controls (fig.17 and 18).
- (13) Carry out flight trim checks as detailed in Appendix 1 or 2.

Note...

The above instructions are for fitting a new blow-back rod, torque tube, and main operating lever. If the torque tube and blow-back rod assembly is being refitted in the same elevator from which it was removed, the fitting of the clamps, drilling and reaming, will not be necessary.








Fig. 24. Rudder spring tab mechanism removal

◀ (revised) ▶

RESTRICTED

KEY TO FIG.24 (RUDDER SPRING TAB MECHANISM REMOVAL)

Sequence of removal:

- (1) Remove the rudder from the aircraft (Chap.3).
- (2) Remove the two access panels from the base of the rudder nose.
- (3) Disconnect the tab actuator and remove it from the rudder.
- ◀ (4) Remove the two 2 B.A. bolts securing the stop bracket to the rudder hinge bottom bracket.
- (5) Remove the two ¼ in. B.S.F. bolts securing the rudder hinge bottom bracket to nose rib 2 behind the rudder spar.
- (6) Remove the thirty-one 2 B.A. bolts which secure the rudder hinge bottom bracket to the rudder.

Note...

Ensure the rudder hinge bottom bracket is completely free from the rudder.

- (7) Remove the access panel at rib 6 from the rudder nose.
- (8) Unfasten the nut and withdraw the bolt that secures the tab operating lever to the splined end of the blow-back rod.
- (9) Remove two diametrically opposite bolts which secure the upper bearing housing to rib 6, and fit the special extractor (Ref.No. 26FZ/95462) (detail 2).
- (10) By operating the extractor, force out the torque tube assembly complete with

the rudder bottom hinge bracket and stop bracket, taking care to keep the main operating lever kidney slot clear from the rudder spar.

Note...

In some cases the spring tab mechanism may be extremely difficult to remove; this is generally caused by the upper and outer torque tube bearings binding in their bearing housings. If all the above operations have been correctly followed and the rudder hinge bottom bracket is free, it may be advantageous to remove the main operating lever and, although this wont actually assist in the mechanism removal, a greater twisting movement can be applied to the tab actuator lever, and this action, together with the downward force of the extractor (op.(10)) will free the mechanism from the rudder.

Dismantling procedure:

- (1) Remove the two self-tapping screws which fasten the sealing plate over the bearings at the base of the tab mechanism. Remove the sealing plate. Separate the rudder bottom hinge bracket from the tab mechanism at the bottom bearing using extractor (Part No. EB6.88.101) (detail 1).

Sequence of fitting a new rudder spring tab mechanism:

- (1) Assemble the rudder bottom hinge bracket to the new spring tab mechanism, and fit the spigot and bearings into the bottom hinge bearing housing. Ensure that the bearing housing is packed with grease XG.275.

- (2) Secure the sealing plate over the bearing housing using two self-tapping screws and jointing compound (Ref.No. 33C/1264).

- (3) At the access panel at rib 6 on the rudder nose, remove the two remaining bolts which secure the upper bearing bracket to the rib, and disconnect the tab operating lever from the tab control rod. Remove the tab operating lever and bearing housing complete.

- (4) Offer up the assembly to the rudder and fit the bolts which secure the rudder bottom hinge bracket and stop bracket.

- (5) With the actuator in its mid-position refit it to the rudder and connect the tab actuator lever to the actuator ram. This ensures that the lever and tab mechanism are located in the neutral position. If preferred, blocks may be made to fit each side of the stop bolt, and thus centralise it in the kidney slot.

- (6) Locate the tab operating lever and upper bearing housing on to the splined end of the blow-back rod, and position it with the lever mid-way between its stops.

- (7) With the tab set in its neutral position, reconnect the tab control rod to the tab operating lever. Refit the four bolts which secure the upper bearing housing.

- (8) Operate the tab, and check that the maximum travels quoted in fig.19, are obtained, and that the stops of the tab operating lever are reached before the limit

(continued)

KEY TO FIG.24 (RUDDER SPRING TAB MECHANISM REMOVAL) – *continued*

◀ stop reaches the ends of the kidney slot.

(9) Ensure that no foul occurs between the sealing plate and the bolts which secure the main operating lever, when the lever is moved through its complete travel.

(10) Through the existing holes in the tab operating lever drill a 3/16 in. dia. hole in the splined end of the blow-back rod.

(11) Secure the tab operating lever by using a new 2 B.A. nut and bolt, and the two existing saddle washers. Centre punch to lock.

(12) Replace the access panels.

(13) Refit the rudder to the aircraft (*Chap.3*).

(14) Rig the rudder controls (*fig.19*).

Note...

(1) If the rudder tab movement is in excess of 18 deg., a new rudder tab operating lever stop plate (Ref.No.26FZ/5495) should be fitted, and the stop faces filed, if necessary, to obtain the desired 18 deg. movement. Similarly, if the 18 deg. movement is unobtainable, the existing stop plate may be filed. The correct protective

treatment (A.P.2662B, Sect.1, Chap.3) must be applied to all filed surfaces. ▶

(2) The sequence for fitting a reconditioned rudder spring tab mechanism (Ref.No. 26FZ/2102) is similar to the above, except that the drilling detailed in operation (10) will already have been done when the blow-back rod was fitted to its original rudder. Should it be necessary to misalign this hole relative to the hole in the tab operating lever to obtain a condition of 'no foul', then the misalignment must be corrected by drilling through with a 1/4 in. dia. drill, and fitting a larger bolt at operation (11).




Fig. 25. Control lever rigging

◀ (New illustration) ▶

RESTRICTED

Appendix 1 FLIGHT TRIM CHECK (B Mk.6 AIRCRAFT)

LIST OF CONTENTS

	Para.		Para.		Para.
Introduction	1	Fuel load determination..	4	Adjustment procedure	
Centre of gravity	2	Flight procedure	6	Case 1... ..	7
				Case 2... ..	8

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
Fuel load determination graph	1	Lower trailing-edge strip adjustment...	2	Upper trailing-edge strip adjustment...	3

IMPORTANT

Whenever an aircraft component which affects longitudinal trim is removed, replaced, or adjusted, the flight trim checks as specified in this Appendix should be repeated. Should the aircraft trim be outside the limits specified, a new trailing-edge strip should be fitted, and the flight trim checks and subsequent trailing-edge strip adjustments carried out. Components likely to affect the longitudinal trimming, are:— Wing(s), rear fuselage, tail plane, tail plane actuator, ailerons, elevators, and aileron and elevator tabs.

Introduction

1. This Appendix details the flight trim checks, and the subsequent trimming of the elevator trailing-edge strips necessary to ensure that the aircraft trim is within the limits laid down, thus enabling the pilot to maintain control of the aircraft under any flight condition within service limits, should the tail plane actuator have run away to the maximum aircraft 'nose-down' position, i.e. the actuator on its mechanical stop.

Centre of gravity

2. During flight tests, the centre of gravity is to be maintained at 2.285 ft. \pm 0.15 ft. aft of the c.g. datum. This is achieved by a predetermined distribution of the fuel

load at engine 'start-up' which will allow for fuel consumed in taxiing, take-off, and climb to test altitude (up to 6000 ft.). Two crew members only (pilot and navigator) are to be carried; the wing-tip tanks, and all military load must be removed, and the integral wing tanks drained.

3. The weight and moment of the aircraft with undercarriage down, are to be determined with full fuselage fuel load and two crew but no stores, by weighing, calculation, or reference to the current Form 4908. These values will be used in conjunction with the graph (fig.1) to determine the reduction of the full fuel load at start-up in tanks 1 or 3 to ensure a correct c.g. position at the


commencement of the test run.

Note...

The weight and moment of the navigator at his normal station should be used.

Fuel load determination (fig.1)

4. The appropriate value of the aircraft moment is read off from the vertical axis of the graph and a horizontal line is extended from this value to intersect the aircraft weight value on, or between, the weight lines. A vertical line is then dropped from this intersection to the horizontal axis of the graph to indicate the amount of fuel to be removed from the relevant tank to give the correct trim at 'start-up'.



WEIGHED OR CALCULATED A.U.W.
WITH FULL FUEL AND CREW

EXAMPLE 1
A.U.W. 35500 LB.
MOMENT 76500 LB/FT.
FUEL TO DEDUCT FROM
NO.1 TANK 125 GALLONS

EXAMPLE 2
A.U.W. 38250 LB.
MOMENT 94000 LB/FT.
FUEL TO DEDUCT FROM
NO.3 TANK 90 GALLONS

Fig. 1. Fuel load determination graph.

RESTRICTED

Example 1 (fig.1)

Aircraft moment..... 76500 lb/ft.
All-up weight..... 35500 lb.
Amount of fuel to be deducted
from No.1 Tank..... 125 gal.
No.3 Tank..... Full.

Example 2 (fig.1)

Aircraft moment94000 lb/ft.
All-up-weight..... 38250 lb.
Amount of fuel to be deducted
from No.3 Tank.....90 gal.
No.1 TankFull.

Note...


No.2 tank is maintained with a full fuel load.

5. The test run should commence immediately on reaching test altitude. The warm-up, taxi, take-off and climb to test altitude should be made using fuel from No.1, 2, and 3 tanks, thereafter fuel from No.2 tank only should be used until completion of the test run.

Flight procedure

Notes...

- (1) All speeds quoted are I.A.S.
- (2) Before the first flight test, the elevator trailing-edge strips (Part No.EA1.31.677) should be examined and, if they are bent, kinked, or damaged, should be removed and new strips fitted. Bowing where the strip follows the line of the elevator edge is acceptable.
- (3) It is better to remove too little trailing-edge strip since, if the aircraft trim is over-adjusted, a new strip will have to be fitted and the tests re-commenced.



MAXIMUM I.A.S. AT WHICH AIRCRAFT CAN BE TRIMMED 'HANDS OFF' USING FULL AIRCRAFT NOSE DOWN TRIM

Fig. 2. Lower trailing-edge strip adjustment

(4) Take-off and climb should be normal on all three tanks, but the actual trim checks should be carried out on No.2 tank only, with No.1 and 3 tanks switched off.

(5) Tests are to be carried out in calm air and good visibility.

6. Operate the fuel system as instructed in Note (4), climb to test altitude (1013 millibars setting), and increase speed slowly until:-

(1) Case 1 - The aircraft can just be trimmed 'hands-off' in level flight with speed steady using full NOSE-DOWN trim. Record the speed. Increase the speed slowly beyond this point to ensure that a push force develops on the control column. OR

(2) Case 2 - If 450 knots is reached before the condition described in Case 1 is obtained, trim the aircraft 'hands-off' at 450 knots and, without further adjustment of the tail trimmer reduce speed slowly using elevator and throttle, and land the aircraft.


Note...

Care should be exercised when reducing speed since an aircraft 'nose-down' change of trim will generally occur as speed is reduced. The stick force to hold this change of trim may increase initially as speed is reduced, but will diminish below 350 knots. Lower the undercarriage at 190 knots, and the flaps at 160 knots. The pull force on the control column should be greatly reduced and may become a small push force when the flaps are lowered.

Adjustment procedure

Case 1

7. Refer to fig.2:



X = FULL NOSE UP T/P ANGLE ON ELECTRICAL STOPS AS MEASURED BY INCIDENCE BOARD MINUS T/P ANGLE REQUIRED TO TRIM CLEAN A/C 'HANDS OFF' AT 450 KTS

Fig.3. Upper trailing-edge strip adjustment

(1) Read off the amount of metal to be removed from the elevator strips according to the speed reached, and remove this amount from the depth of the lower strips on both elevators, along the whole length of the strips.

(2) Refuel the aircraft (para.4), repeat the flight trim check (para.6(1)), and trailing-edge strip adjustment (1) as necessary until the following trim conditions are achieved:—

The aircraft can be flown 'hands-off' at a speed between 425 and 450 knots with full NOSE-DOWN trim applied.

Typical example — Consider an aircraft which, on its first flight check, can be flown 'hands-off' at 355 knots with full aircraft NOSE-DOWN trim.

Reference to the curve (fig.2) will show that 0.16 inch must be removed from the depth of the lower strips. After the second flight, and assuming that the aircraft is now in trim at 390 knots, a further 0.1 inch should be removed from the lower strips. If on the third flight, the 'hands-off' trim speed with full aircraft NOSE-DOWN trim applied, lies between 425 and 450 knots, the trailing-edge strip adjustment is satisfactory.

Note...

(1) *There is no restriction on the amount of lower strip which may be removed; the whole of the lower strip may be removed if necessary.*

(2) *If, due to over-adjustment, the aircraft becomes 'Case 2', this condition is satis-*

factory providing the tail plane setting at 450 knots is not more than 3 minutes from the tail plane leading-edge UP electrical stop (see para.6(2) and 8(1) and (2) for the procedure in this case). If excessive over-adjustment has occurred, and the tail plane setting at 450 knots is greater than 3 minutes from the tail plane leading-edge UP electrical stop, the trailing-edge strip must be renewed and the tests re-commenced. It is not permissible to remove metal from both the upper and lower elevator strips.

Case 2

8. Refer to fig.3:

(1) Place the aircraft on a level standing and support the fuselage with a trestle. Without disturbing the tail trim setting, measure the tail plane incidence (*this was the angle found necessary to trim 'hands-off' at 450 knots*).

(2) Without removing the clinometer run the actuator on to its leading edge UP electrical stop. Record the difference in angle between the 'hands-off' at 450 knots trim position, and the electrical stop.

(3) Read off the amount of metal to be removed from the upper strips corresponding to the difference found in operation (2). Remove the required amount of metal from both elevators along the whole length of the strips.

(4) Refuel the aircraft (para.4) and repeat the flight check (para.6(2)) and trailing-edge adjustment (3) as necessary until the following trim conditions are achieved:

(a) The aircraft can be flown 'hands-off' at a speed of 450 knots with the tail plane setting not more than 3 minutes from the leading-edge UP electrical stop.

Typical example—Consider an aircraft on which the tail plane angle required to fly 'hands-off' at 450 knots was 3 deg. 52 min. and the electrical stop is found to be set at 4 deg. giving a difference of 0 deg. 8 min.

Reference to the curve (fig.3) will show that 0.08 inch must be removed from the depth of the upper strips. Assuming that the 450 knots tail plane setting is 4 minutes from the electrical stop on the 2nd flight, a further 0.04 inch must be removed from the upper strips. If, on the 3rd flight, the aircraft will fly 'hands-off' at 450 knots with the tail plane set at not more than 3 minutes from the leading-edge UP electrical stop, the trailing-edge strip adjustment is satisfactory.

Note...

(1) *The amount of metal that can be removed from the upper strips is restricted to half the depth of the strips.*

(2) *If, due to over-adjustment, the aircraft becomes 'Case 1', this condition is satisfactory providing that the aircraft can be flown 'hands-off' using full aircraft NOSE-DOWN trim at a speed not less than 425 knots. If excessive over-adjustment has occurred resulting in a 'hands-off' trim speed of less than 425 knots using full aircraft NOSE-DOWN trim, the trailing-edge strips must be renewed, and the tests re-commenced.*

Appendix 2 FLIGHT TRIM CHECK (B(I) Mk.6 AIRCRAFT)

LIST OF CONTENTS

	Para.		Para.		Para.
Introduction	1	Fuel load determination..	5	Adjustment procedure	
Centre of gravity	3	Flight procedure	7	Case 1... ..	8
				Case 2... ..	9

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
Fuel load determination graph	1	Lower trailing-edge strip adjustment	2	Upper trailing-edge strip adjustment	3

IMPORTANT

Whenever an aircraft component which affects longitudinal trim is removed, replaced, or adjusted, the flight trim checks specified in this Appendix should be repeated. Should the aircraft trim be outside the limits specified, a new trailing-edge strip should be fitted, and the flight trim checks and subsequent trailing-edge strip adjustments carried out. Components likely to affect the longitudinal trimming, are: Wing(s), rear fuselage, tail plane, tail plane actuator, ailerons, elevators and aileron and elevator tabs.

Introduction

1. This Appendix details the flight trim checks, and the subsequent trimming of the elevator trailing-edge strips necessary to ensure that the aircraft trim is within the limits laid down, thus enabling the pilot to maintain control of the aircraft under any flight condition within service limits, should the tail plane actuator have run away to the maximum aircraft 'nose-down' position, i.e. the actuator on its mechanical stop.

2. The trim requirements to be satisfied in the following paragraphs depend on the role of the aircraft (*i.e. strike or interdicator*). However, if, after completing the trim checks


in the strike configuration, the role of the aircraft is changed, then the resultant trim condition should lie close to the lower limit of the interdicator trim range *without further adjustment of the elevator trailing edge strips*. Repeat flight trim checks should not, therefore, be necessary unless significant lack of nose down trim is experienced during subsequent flying.

Centre of gravity

3. During flight tests, the centre of gravity is to be maintained at 2.285 ft. ± 0.15 ft. aft of the c.g. datum. This is achieved by a pre-determined distribution of the fuel load at engine 'start-up' which will allow for fuel

consumed in taxiing, take-off, and climb to test altitude (*up to 6000 ft.*). Two crew members only (*pilot and navigator*) are to be carried, the wing-tip tanks, and all military load must be removed, and the integral wing tanks drained.

4. The weight and moment of the aircraft with undercarriage down, are to be determined with full fuselage fuel load and two crew but no stores, by weighing, calculation, or reference to the current Form 4908. These values will be used in conjunction with the graph (*fig.1*) to determine the reduction of the full fuel load at start-up in tanks 1 or 3 to ensure a correct c.g. position at the



WEIGHED OR CALCULATED A.U.W.
WITH FULL FUEL AND CREW

EXAMPLE 1
A.U.W. 35500 LB.
MOMENT 76500 LB/FT.
FUEL TO DEDUCT FROM
NO.1 TANK 125 GALLONS

EXAMPLE 2
A.U.W. 38250 LB.
MOMENT 94000 LB/FT.
FUEL TO DEDUCT FROM
NO.3 TANK 90 GALLONS

Fig. 1. Fuel load determination graph.

RESTRICTED

commencement of the test run.

Note...

The weight and moment of the navigator at his normal station should be used.

Fuel load determination (fig.1)

5. The appropriate value of the aircraft moment is read off from the vertical axis of the graph and a horizontal line is extended from this value to intersect the aircraft weight value on or between the weight lines. A vertical line is then dropped from this intersection to the horizontal axis of the graph to indicate the amount of fuel to be removed from the relevant tank to give the correct trim at 'start-up'.

Example 1 (fig.1)

Aircraft moment.....	76500 lb/ft.
All-up weight.....	35500 lb.
Amount of fuel to be deducted	
from No.1 tank.....	125 gal.
No.3 tank.....	Full

Example 2 (fig.1)

Aircraft moment.....	94000 lb/ft.
All-up weight.....	38250 lb.
Amount of fuel to be deducted	
from No.3 tank.....	90 gal.
No.1 tank.....	Full

Note...

No.2 tank is maintained with a full fuel load.

6. The test run should commence immediately on reaching test altitude. The warm-up, taxi, take-off and climb to test altitude should be made using fuel from No.1, 2 and 3 tanks, thereafter fuel from No.2 tank only should be used until completion of the test run.

Flight procedure

Note...

(1) *All speeds quoted are I.A.S.*

(2) *Before the first flight test, the elevator trailing-edge strips (Part No.EA1.31.677) should be examined and, if they are bent, kinked, or damaged, should be removed and new strips fitted. Bowing where the strip follows the line of the elevator trailing-edge is acceptable.*

(3) *It is better to remove too little trailing edge strip since, if the aircraft trim is over-adjusted, a new strip will have to be fitted and the tests re-commenced.*

(4) *Take-off and climb should be normal on all three tanks, but the actual trim checks should be carried out on No.2 tank only, with No.1 and 3 tanks switched off.*

(5) *Tests are to be carried out in calm air and good visibility.*

(6) *The flight checks detailed below may be carried out with either the gun pack and flare doors fitted, or the standard bomb doors. The trim conditions are different for each configuration thus minimising the effect of role changes.*

7. Operate the fuel system as instructed in Note (4), and climb to test altitude (1013 millibars setting), and increase speed slowly until:

(1) *Case 1* – The aircraft can just be trimmed 'hands-off' in level flight with speed steady using full NOSE-DOWN trim. *Record the speed.* Increase the speed slowly beyond this point to ensure that a

push force develops on the control column.
OR

(2) *Case 2* – If 450 knots is reached before the condition described in Case 1, trim the aircraft 'hands-off' at 450 knots and, without further adjustment of the tail trimmer reduce speed slowly using elevator and throttle, and land the aircraft.

Note...

Care should be exercised when reducing speed since an aircraft 'nose-down' change of trim will generally occur as speed is reduced. The stick force to hold this change of trim may increase initially as speed is reduced, but will diminish below 350 knots. Lower the undercarriage at 190 knots, and the flaps at 160 knots. The pull force on the control column should be greatly reduced and may become a small push force when the flaps are lowered.

Adjustment procedure

Case 1

8. Refer to Fig.2, Curve 'A' (aircraft with gunpack and flare doors) or Curve 'B' (aircraft with standard bomb doors).

(1) Read off the amount of metal to be removed from the elevator strips according to the speed reached, and remove this amount from the depth of the lower strips on both elevators, along the whole length of the strips.

(2) Refuel the aircraft (para.5), repeat the flight trim check (para.7 (1)) and trailing-edge strip adjustment (1) as necessary until the following trim conditions are achieved:

(a) *With gunpack and flare doors fitted* – The aircraft can be flown 'hands-off' at a

speed between 425 and 450 knots with full NOSE-DOWN trim applied.


Typical example – Consider an aircraft with gun pack which, on its first flight check, can be flown ‘hands-off’ at 355 knots with full aircraft NOSE-DOWN trim:

Refer to Fig.2, Curve ‘A’. It will be found that 0.16 inch must be removed from the depth of the lower strips. After the second flight, and assuming that the aircraft is now in trim at 390 knots, a further 0.1 inch should be removed from the lower strips. If on the third flight, the ‘hands-off’ trim speed with full aircraft NOSE-DOWN trim applied, lies between 425 and 450 knots, the trailing-edge strip adjustment is satisfactory.

(b) *With standard bomb doors fitted* – The aircraft can be flown ‘hands off’ at 450 knots with the tail plane 2 min. \pm 1 min. from the electrical stop (see para. 7 (2), and 9(1) and (2) for flight check and measurement of tail plane angle at 450 knots).

Typical example – Consider an aircraft with standard bomb doors which, on its first flight check, can be trimmed ‘hands off’ at 355 knots with full aircraft NOSE-DOWN trim:


Refer to Fig.2, Curve ‘B’. It will be found that 0.2 inch must be removed from the lower strips. After the second flight, and assuming the aircraft is now in trim at 430 knots, a further 0.075 inch should be removed from the strips. If on the third flight the aircraft requires less than full aircraft NOSE-DOWN trim at 450 knots for ‘hands-off’ flight, land the aircraft without



MAXIMUM I.A.S. AT WHICH AIRCRAFT CAN BE TRIMMED ‘HANDS OFF’ USING FULL AIRCRAFT ‘NOSE DOWN’ TRIM

- CURVE (A) AIRCRAFT WITH GUN PACK AND FLARE DOORS FITTED
 CURVE (B) AIRCRAFT WITH BOMB DOORS FITTED

Fig.2. Lower trailing edge strip adjustment



X = T/P ANGLE ON ELECTRICAL STOPS MINUS T/P ANGLE REQUIRED TO TRIM A/C 'HANDS OFF' AT 450 KNOTS
(ANGLES TO BE MEASURED BY INCIDENCE BOARD)

- CURVE (A) AIRCRAFT WITH GUN PACK AND FLARE DOORS FITTED
- CURVE (B) AIRCRAFT WITH BOMB DOORS FITTED

Fig.3. Upper trailing edge strip adjustment

further adjustment of the tail plane (see para.7 (2)). Measure the angle between the 450 knots trim setting and the tail plane leading edge UP electrical stop (see para.9 (1) and (2)). The trailing-edge strip adjustment is satisfactory if this angle lies between 1 and 3 min.

Note...

(1) There is no restriction on the amount of lower strip which may be removed; the whole of the lower strip may be removed if necessary.

(2) If it is found that the strips have been over-adjusted, they must be renewed and the tests re-commenced.

Case 2

9. Refer to Fig.3, Curve 'A' (aircraft with gunpack and flare doors) or Curve 'B' (aircraft with standard bomb doors).

(1) Place the aircraft on a level standing and support the fuselage by trestle. Without disturbing the tail trim setting, measure the tail plane incidence (this was the angle found necessary to trim 'hands off' at 450 knots).

(2) Without removing the clinometer, run the actuator on to its leading edge UP electrical stop. Record the difference in angle between the 'hands off' at 450 knots trim position and the electrical stop.

(3) Read off the amount of metal to be removed from the upper strips corresponding to the difference found in operation (2). Remove the required amount of metal from both elevators along the whole length of the strips.

(4) Refuel the aircraft (para.5) and repeat

the flight check (*para.7 (2)*) and trailing-edge strip adjustment (3) as necessary until the following trim conditions are achieved:

(a) *With gunpack and flare doors fitted* — The aircraft can be flown 'hands-off' at a speed between 425 and 450 knots with full aircraft NOSE-DOWN trim applied (*see para.7 (1) for final flight check*).

Typical example — Consider an aircraft with gunpack and flare doors fitted on which the tail plane angle required to fly 'hands-off' at 450 knots was 3 deg. 50 min., and the electrical stop is found to be set at 4 deg. giving a difference of 0 deg. 10 min.

Refer to Fig.3, Curve 'A'. It will be found

that 0.1 inch must be removed from the depth of the strips. Assuming that the 450 knots tail plane setting is 2 min. from the electrical stop on the second flight, a further 0.020 inch must be removed from the upper strips. If on the third flight the aircraft will fly 'hands-off' with full aircraft NOSE-DOWN trim applied at any speed between 425 and 450 knots, the trailing-edge strip adjustment is satisfactory.

(b) *With bomb doors fitted* — The aircraft can be flown 'hands-off' at 450 knots with the tail plane 2 min. \pm 1 min. from the electrical stop.

Typical example — Consider an aircraft with bomb doors fitted, on which the tail plane angle required to fly 'hands-off' at

450 knots was 3 deg. 50 min. and the electrical stops are found to be set at 4 deg. giving a difference of 0 deg. 10 min.

Refer to Fig.3, Curve 'B'. It will be found that 0.085 inch must be removed from the depth of the upper strips. If on the second flight, the tail plane setting at 450 knots for 'hands-off' flight lies between 1 and 3 min. the trailing-edge strip adjustment is satisfactory.

(1) *The amount of metal that can be removed from the upper strips is restricted to half the depth of the strip.*

(2) *If it is found that the strips have been over-adjusted they must be renewed and the tests re-commenced.*

RESTRICTED

Chapter 5 ALIGHTING GEAR

(Completely revised)

LIST OF CONTENTS

	<i>Chapter</i>
MAIN UNDERCARRIAGE	5A
NOSE UNDERCARRIAGE	5B

Note... A detailed list of contents will be found at the beginning of each chapter.

INTRODUCTION

1. Because of its bulk, this chapter is divided into sub Chapter A (*main undercarriage*) and B (*nose undercarriage*). Each sub chapter describes, and illustrates in detail, the mechanics and disposition of the major components, the servicing operations and the major removal and assembly procedures.

2. The tricycle alighting gear consists of two main units which retract inward into bays in the main planes and a single nose unit which retracts rearward into a bay in the nose fuselage aft of the pressure bulkhead. Each main undercarriage has a single wheel mounted on an inward-facing stub axle incorporating Dunlop hydraulic copper


plate type brake units fitted to each wheel. To reduce shimmy, the nose undercarriage is fitted with twin wheels; these are smaller in diameter than the main wheels and are mounted on a common axle. Mud guards, fitted over both wheels, protect the interior of the nose-wheel bay.

3. Movement of the alighting gear is effected by hydraulic jacks (*Chap.6*) which are electrically controlled by selector push-buttons mounted on the alighting gear sloping panel on the port side of the instrument flying panel. Indicator lights, which show GREEN locked down and RED unlocked are mounted on the same panel adjacent to the selector push-buttons. Provision is made for an override UP

selection; this is accomplished by clockwise rotation (*as far as it will go*) of the knobbed sleeve of the UP push-button, followed by depression of the button. Undercarriage DOWN emergency selection is made by pulling the black-and-yellow painted handle protruding above the alighting gear sloping panel (*Chap.11*).

4. The apertures into which the alighting gear retracts are sealed upon completion of retraction by flush-fitting doors operated by hydraulic jacks. Correct retraction and lowering sequence is ensured by the incorporation of sequence valves in the hydraulic circuit, details of which are given in Chapter 6.

RESTRICTED



Alighting gear

RESTRICTED

RESTRICTED




FIG. 1. STARBOARD UNDERCARRIAGE

◀HYDRAULIC PIPE RUN AMENDED▶

RESTRICTED

DESCRIPTION

General (fig.1)

1. Each main undercarriage consists of a cantilever shock-absorber strut of the oleo pneumatic type, carrying a single wheel and retracting inwards into the main plane. In the down position the shock-absorber is braced against side loads by a knuckle-jointed side stay (*para.3*) which incorporates the undercarriage down-lock mechanism. The undercarriage jack is attached by a spherical joint to the main-plane structure and to the lock lever assembly on the side-stay assembly down-lock mechanism (*fig.6*). Spat-type fairings are attached to the shock-absorber struts to fair off the undercarriage housing when the undercarriage is retracted. The unit is fully described in A.P.1803P, Vol.1, Sect.6, Chap.4.

Shock-absorber struts

2. Each shock-absorber strut is suspended by its main pivot from large bearing bracket lugs on the front face of the main-plane main spar, one on each side of the engine inboard rib. The struts consist of two cylinders sliding one within the other, two pistons operating one within each cylinder, and an axle which is formed at the base of the inner cylinder or sliding tube. Torque links hinged to lugs on both inner and outer cylinders form a scissors-like connection between the two cylinders and transmit the torque loads from the wheel to the outer cylinder, thus preventing rotation of the sliding tube. An adapter, fitted with an oil level tube and an inflation valve, is fitted into the head of the outer cylinder.

Side stay (fig.6)

3. The side-stay assembly consists of a side stay, a side-stay link, and the undercarriage down-lock mechanism. The stay and stay link are hinged together and the hinge bolt is offset below the centre-line of the assembly; this ensures that the loading on the side stay will tend to fold it downwards, though this is resisted by a stop bolt fitted on the stay which butts against a buttress formed on the upper face of the stay link. The upper end of the side stay is attached by a spherical joint to a bracket on the front face of the main spar, and the lower end, which is the stay link fork, is attached to the spherical bearing lug on the shock-absorber strut. The side stay carries the pick-up point for the hydraulic jack piston-rod, the lock lever and rollers, the down-lock microswitch, up-latch pin, and an adjustable tappet for operating the door jack sequence valve.

Up-lock mechanism (fig.3)

4. The up-lock hook is mounted on the main-plane structure in the roof of the wheel well and is held in the engaged position by a coil spring. The underface of the hook is so shaped that when the up-latch pin in the side stay contacts it during retraction, the hook pivots to permit the pin to pass and then, under the influence of its spring, snaps back to its original position, engages the pin and retains the undercarriage in the retracted position. The UP indicator lights are actuated by the upper surface of the side-stay fork which contacts a microswitch mounted on the up-lock hook.

5. When undercarriage DOWN is selected the initial movement of the jack releases the lock. The bolt connecting the eye-end of the jack piston rod to the side stay is

fitted in slotted holes in the side-stay fork and moves across the holes as the jack extends. The eye-end of the jack contacts the end of the hook and, a protrusion above the centre-line of the eye, pushes the hook out of engagement. The undercarriage falls under gravity for the first part of its travel during which time the jack attachment bolt is returned to its former position. As the undercarriage approaches the down position, hydraulic pressure in the jack straightens the side-stay assembly and pushes the down lock lever into engagement with the hooked end of the side-stay link (*fig.6*).

Down-lock mechanism (fig.3)

6. The down-lock mechanism consists of a lever, pivoted on the up-latch pin in the side stay, which is moved into position against the lip on the end of the stay link by the action of the undercarriage jack; it is retained in position by a spring-loaded stop in the side stay. A flanged plate lever is attached to the pivot bolt and the jack attachment bolt so that it moves with the lock levers and depresses the plunger of a microswitch which operates the undercarriage DOWN indicator lights. When undercarriage UP is selected, the initial movement of the jack moves the down-lock lever out of engagement with the lip of the stay link and unlocks the unit.

Door-operating mechanism (fig.2 and 4)

7. The main undercarriage doors open downwards and inboard on two hinges attached to the fuselage side. Jointed check links, which abut when the doors are fully open, are attached to the lugs of the forward hinge; the upper check link carries a trip lever with an adjustable tappet which operates the undercarriage down sequence valve. This valve is positioned so that the




Fig. 2. Main undercarriage door-operating mechanism

door must be fully down and open before the trip lever tappet strikes it and allows hydraulic pressure to the down side of the main undercarriage jack. In the event of a mechanical failure of the check links the sequence valve is operated by an inboard movement of the undercarriage door in the airstream beyond its normal fully-open position; this further movement is transmitted to the sequence valve by a slave link mechanism attached to the door and the upper check link. The door jack is mounted vertically downwards between brackets on the fuselage skin with its piston-rod attached to a lock lever between the door forward hinge bracket lugs. On contraction of the jack the door is first retracted and, when fully up, the lock lever rotates through a small arc and operates a tie-rod, the movement of which is redirected through a bell-crank lever to two further tie-rods which operate the door latch shoot-bolts. When undercarriage DOWN is selected the jack operates the lock lever and the shoot-bolts are withdrawn as the first operation.

Engine cowl flap

8. A small flap, the movement of which is restricted by a check cable, is situated in the engine lower cowling and is mechanically connected to the undercarriage main pivot by an adjustable tie-rod. The flap allows the main undercarriage leg, when lowered, to move outboard into a recess in the skin of the engine cowling and, on retraction, fits in the recess and fairs off the cowling.

Transfer valves

9. A transfer valve installed in each main undercarriage hydraulic circuit, allows fluid expelled from the up side of the hy-

draulic jack during lowering of the undercarriage to be diverted to the down side, thus reducing the lowering time. The additional supply of fluid assists the pumps to meet the immediate demands of the undercarriage circuit, ensuring a smooth continuous lowering and preventing cavitation in the main jacks. This transfer is especially effective when an emergency lowering has to be made as the extra fluid provided for the jack down stroke reduces the number of strokes required on the aircraft hand pump. When the undercarriage is retracted the transfer valves close, ensuring that the pump supply is confined to the up side of the jack only. Each valve incorporates a thermal relief valve which, in abnormal temperatures and pressures, will relieve from the up line to the down line when the sequence valve is open. Full details and servicing of the transfer valves are given in A.P.1803D, Book 3A, Sect.9, Chapter 67.

Principle of operation (fig.3)

Raising

10. When the undercarriage is selected UP, hydraulic pressure is felt simultaneously on the up side of both the undercarriage and undercarriage door jacks, but, as the door jack sequence valve is closed, preventing a return flow of fluid from the door jack, only the undercarriage jack operates. The initial movement pulls the jack pivot bolt back along the slot in the end of the side stay and moves the down-lock lever out of engagement with the lip of the stay link. Continued retraction raises the unit and at the same time closes the mechanically-operated flap in the engine cowling (para.8). Final contraction of the main jack engages the up-latch pin with the up-latch hook in the roof of the wheel well and

brings a trip tappet on the side stay into contact with the plunger of the door jack sequence valve. The door jack sequence valve is now open allowing hydraulic pressure on the up side of the jack to raise the door. During its retraction the jack folds the check links (fig.4) closes the undercarriage main jack sequence valve, and finally locks the door in its closed position by operating the shoot-bolts.

Lowering

11. Upon application of hydraulic power to lower the undercarriage, pressure is applied to both the undercarriage and undercarriage door jacks, but since the undercarriage jack sequence valve is closed, preventing the flow of fluid from the undercarriage jack, only the door jack is operated. Initial extension of the door jack disengages the door shoot-bolts against the action of their springs and continued movement of the jack piston-rod opens the door and finally brings the sequence valve trip lever tappet on the door check links into contact with the undercarriage sequence valve plunger. With the sequence valve open, hydraulic power can now operate the undercarriage jack, and its initial movement releases the unit from the up-lock hook and closes the door sequence valve, locking the door jack in its extended position. For the first part of its travel the undercarriage falls under gravity, overrunning the hydraulic pressure but, as it approaches the down position, hydraulic pressure builds up, straightens the side stay and link, and pushes the down-lock lever into position against the lip on the end of the stay link, locking the undercarriage down.

Maxaret units

12. The Maxaret anti-skid units permit

RESTRICTED




Fig. 3. Main undercarriage/door operation

RESTRICTED

maximum braking effort to be applied under any conditions without locking the wheels. The units, which are entirely self-contained, are interposed in the hydraulic brake circuit and consist of a valve arrangement regulated by a fly-wheel housed in a rubber-tyred

shell which is rotated by direct contact with a track on the outboard side of each main wheel. Full details and servicing of the Maxaret units are given in A.P.1803S, Vol.1, Book 2, Sect.8, Chap.5.

SERVICING

WARNING

The relevant safety precautions detailed on the **LETHAL WARNING** marker card must always be observed before entering the cabin or performing any operations upon the aircraft.

General information

13. The following paragraphs provide information on checking and correcting the oleo legs oil level and air pressure.

Checking and correcting oil level

14. An inflation adapter Ref.No.4G/6246 fitted with a pressure gauge Ref.No.4G/3028 is used when checking and correcting the oil level. The following procedure must be adopted:

- (1) Jack and trestle the aircraft (*Sect.2, Chap.4*).
- (2) Ensure that the adapter air-release valve is closed by turning the knurled knob as far as it will go in a clockwise direction.
- (3) Carefully turn the gauge counter-clockwise until the stop is reached; do not strain against the stop.
- (4) Tighten the cap at the adapter inflation point to prevent air escaping.
- (5) Remove the cap from the inflation valve at the top of the shock-absorber strut and screw on the adapter assembly, taking care not to disturb the position of the gauge.
- (6) Bleed off the air pressure to zero through the air release valve in the adapter.




Fig. 4. Undercarriage door-operating mechanism

RESTRICTED




FIG. 5. LUBRICATION DIAGRAM

◀HYDRAULIC PIPE RUN AMENDED▶

RESTRICTED

(7) With the release valve still open, compress the leg fully, using a pillar jack Ref.No.4Q/2657, adapter Ref.No.4Q/2321 and bracket Ref.No. 26FZ/95413.

(8) Close the inflation valve by rotating the gauge in a counter-clockwise direction, and close the adapter air release valve.

(9) Remove the cap from the adapter inflation point, and connect an oleo charging pump Ref.No.4G/257 to the inflation point.

(10) Open the undercarriage inflation valve and pump in hydraulic fluid OM-15, allowing the leg to extend by gradually lowering the pillar jack until the sliding tube of the shock-absorber strut is exposed to the extent of between one and two inches. Close the undercarriage inflation valve, disconnect the oleo charging pump and refit the cap on the inflation point.

(11) Open the undercarriage inflation valve and expel the excess fluid, compressing the undercarriage leg by means of the pillar jack. Close the inflation valve.

Note...

(1) *If no fluid is expelled, repeat operations (7) to (11).*

(2) *Pillar jacks should be raised slowly and carefully to ensure that only excess fluid is expelled.*

(12) Carry out operations detailed in para. 15. The correct inflation pressures for varying all-up weights are given in Sect.2, Chap.2.

Checking and correcting air pressure

15. An inflation adapter Ref.No.4G/6246,

fitted with a 0-2500 lb/in² pressure gauge Ref.No.4G/3028, is used when checking and correcting the oleo leg inflation pressure. A full description of the inflation adapter, and general instructions for use are given in A.P.1464G, Vol.1, Part 2, Sect.5, Chap. 10. Before checking the air pressure, note the following:

(1) Correct air pressure is dependent upon a correct oil level (*para.14*).

(2) The oleo leg must be fully extended.

(3) The strut inflation valve is the non-return type, therefore a reading will be obtained on the adapter gauge without slackening the valve.

To check and correct the air pressure:

(1) Jack and trestle the aircraft (*Sect.2, Chap.4*).

(2) Ensure that the adapter air release valve is closed by turning the knurled knob clockwise as far as it will go.

(3) Carefully turn the gauge counter-clockwise until the stop is reached; do not strain against the stop.

(4) Tighten the cap at the adapter inflation point.

(5) Remove the cap from the inflation valve at the top of the shock-absorber strut and screw on the adapter assembly, taking care not to disturb the position of the gauge.

(6) Turn the gauge clockwise until the stop is reached and a reading obtained. For related inflation pressure/all-up-weight figures refer to Sect.2, Chap.2.

(7) Should the gauge indicate more than the required pressure, release air through the air release valve until the correct pressure is indicated.

When air pressure is low:

(8) Turn the gauge in a counter-clockwise direction until the stop is reached.

(9) Connect a high-pressure air charging trolley Ref.No. 4G/5888 to the inflation point of the adapter.

(10) Turn the pressure gauge clockwise until the stop is reached.

(11) Introduce air into the oleo leg until the required pressure is indicated on the gauge.

(12) Shut off the air supply.

(13) Turn the gauge counter-clockwise until the stop is reached.

(14) Disconnect the air supply connection from the adapter inflation point.

(15) Remove the inflation adapter from the inflation valve and refit the blanking cap.

(16) Lower the aircraft to the ground and remove the jacks and trestles.

Lubrication

16. Refer to fig.5.

ADJUSTMENTS

General information

17. The following paragraphs describe the procedure to be adopted when settings have to be checked and adjustments made. These

occasions arise during both servicing and assembly operations. After any adjustments have been made, the undercarriage must be function-tested.

Side-stay and stay-link alignment (fig.6)

18. The side-stay and stay-link are correctly aligned when the joint pin is offset downwards approximately 0.30 in measured from a straight line between the side-stay pin centre and the stay-link spherical-joint centre. This off-set is adjusted during initial assembly by setting the clearance between the down-lock lever roller and the stay-link lip at 0.004 in. Should it be found necessary to adjust the offset:

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Remove the pivot pin attaching the jack piston rod to the down-lock lever and retract the jack.

(3) Apply an upward force to the underside of the side stay until the roller on the down-lock lever is bearing hard against the stay-link lip. Adjust the side stay stop-bolt until the clearance between the stop-bolt and its abutment face on the stay-link measures 0.004 in. Tighten and wire-lock the stop-bolt locknut.

(4) Release the force applied to the underside of the side stay when it will be noted that the 0.004 in clearance now exists between the roller on the lock lever and the stay-link lip. This can be checked by depressing the spring-loaded stop in the side-stay and inserting a 0.004 in feeler gauge between the lock-lever roller and the stay-link lip.

(5) Extend the jack and refit and lock the pivot pin attaching the jack piston rod to the down-lock lever.

Jack settings

Main jack

19. The distance between the pin centres of the main jack when fully closed must not exceed 20.63 in \pm 0.25 in: the jack piston rod travel is 11.22 in \pm 0.045 in. The exact pin centre dimension is governed by the pick-up points on the aircraft structure and side stay down-lock lever. The centres must be checked following renewal, replacement, or after any servicing which may have affected its setting. The length of the jack is adjusted in the following manner:

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Remove the pivot pin attaching the jack piston rod to the down-lock lever.

(3) Check the alignment of the side-stay and stay-link (para.18), and adjust as necessary.

(4) Ensure that all hydraulic pressure is exhausted. (Chap.6). Disconnect the hydraulic pipes and connect the jack to a hydraulic test rig.

(5) Pump the jack into the fully extended position.

(6) Loosen the locknut on the piston rod and adjust the length of the fully extended jack until the distance between the jack pin centres exceeds the pick-up centres on the aircraft structure and side-stay down-lock lever by 0.15 in $\begin{matrix} +0.00 \text{ in.} \\ -0.05 \end{matrix}$.




Fig. 6. Side-stay and stay-link alignment

(7) Check that the piston rod eye-end is in safety and tighten the locknut against the spanner grip. Wire-lock the eye-end, the locknut, and the spanner grip together.

(8) Close the jack until the jack pin centre is in alignment with the pick-up centre of the down-lock lever and fit the jack pivot pin.

(9) Remove the rig and reconnect the hydraulic pipes to the jack. Prime and bleed the jack, and function test the undercarriage (Chap.6).

Door jack

20. The distance between the pin centres of the door jack when fully closed must not exceed 16.21 in \pm 0.25 in; the ram travel is 9.19 in \pm 0.06 in. The exact pin centre dimension is governed by the pick-up points on the aircraft structure and undercarriage door lock lever. The jack pin centres must be checked, and if necessary, adjusted in the following manner, following renewal, replacement, or after any servicing which may have affected its setting:

(1) Ensure that all hydraulic pressure is exhausted from the system (Chap.6).

(2) Remove the pin attaching the lower end of the door jack piston rod to the door lock lever.

(3) Check the movement of the slave link (fig.12) to ensure that 0.02 in minimum to 0.03 in maximum clearance exists between the top of the slot and the eccentric bolt shank when the door is fully down. Check the sequence valve to ensure that the plunger is depressed only to within the limits given in para.22. If the necessary

clearance does not exist at the top of the slave link slot, it can be obtained by adjustment of the eccentric bolt; adjust the sequence-valve trip screw as detailed in para.23.

Note...

There must be adequate clearance between the bottom of the slave link slot and the eccentric bolt when the door is fully up, and the link must not foul anywhere throughout its travel.

(4) Disconnect the hydraulic pipes at the door jack and connect a hydraulic test rig to the jack.

(5) Remove the locking wire from the locknut and the splined nut at the end of the jack piston rod and slacken the locknut.

(6) Disconnect the lower rear check link from the upper link.

(7) Close the door by hand and pull up the lock lever to move the shoot-bolts into the fully locked position.

(8) Pump the jack into the fully-retracted position, and check whether a minimum override of 0.125 in exists by positioning the eye-end of the piston rod between the forks of the lock lever and noting the alignment of the attachment pin hole in both components. If the override is less than the minimum required, increase it by turning the eye-end of the piston rod one half-turn at a time until the necessary dimension is obtained.

(9) Open the door, tighten the locknut on the jack piston rod, and wire-lock in position.

(10) Connect the lower rear check link to the upper link.

(11) Pump the jack into the fully extended position and, with the door held open but not sprung, check the alignment of the attachment-pin hole through the lock lever and piston rod eye-end; there should be a maximum override of 0.02 in. If the override is greater or appreciably less, adjust it by varying the amount of shimming between the two parts of the lock lever; the packing is made up of 0.003 in laminations (fig.12).

Note...

(1) After adjustment of the shimming between the two parts of the lock lever, ensure that the thread of the bolt Ref.No. 26FZ/1499, which secures the two parts of the lock lever together, protrudes by 0.06 in minimum when fully tightened. If necessary, up to three washers Ref. No. 28W/9419403, in addition to the spring washer, may be fitted beneath the head of the bolt to prevent thread binding (fig.12).

(2) Ensure that the lock-lever counter-sunk screw has been locked by centre popping.

(12) Retract the jack slightly and align the attachment pin holes in the lock lever and the end of the piston rod by moving the door. Insert the attachment pin and fully extend the jack.

(13) With the door fully open, check again that the maximum override (operation (11)) is present by applying hand pressure to the lower inside edge of the door; it should be possible to rotate the pin securing the lock lever.

(14) Disconnect the test rig, and reconnect the pipes to the jack. Prime and bleed the jack, and test the functioning of the under-carriage and door (Chap.6).

Door shoot-bolt setting (fig.7)


21. The operation and setting of the door shoot-bolts must be checked after servicing. Should adjustment be necessary:-

(1) Disconnect the door jack by removing the pin attaching the lower end of the door jack piston rod to the lock lever.

Note...

Before any adjustments are made, the door hinges must be checked for excessive wear (A.P.101B-0400-6, Part 1, Chap.3).

DOOR STOP-BOLT ADJUSTMENT



(2) Pre Mod.3333

(a) Manually close the door and slacken the locknut at the fork-end of the tie-rod between the lock lever and bell-crank lever.

(b) Disconnect the tie-rod and adjust by turning the fork-end one half-turn at a time, and connecting the tie-rod to the bell-crank lever between adjustments, until the minimum engagement of 0.50 in (fig.7) is achieved for each shoot-bolt when locked; with the door unlocked there should be a clearance of 0.11 in between the end of the shoot-bolts and the pads with which they engage.

Note...

The dimension 0.11 in is for the linkage

in an as new condition. A relaxation of this dimension to 0.006 in is permitted due to subsequent cumulative wear in the linkage. (Refer to A.P.101B-0400-6, Part 1, Chap.3 for maximum wear limits.)

(3) Post Mod.3333

(a) Disconnect the rear shoot-bolt tie-rod and adjust to its minimum length; reconnect the tie-rod, leaving the locknut slack.

(b) Manually close the door, disconnect the tie-rod between the lock lever and the bell-crank lever at the bell-crank lever end, slacken the tie-rod locknut and adjust by turning the fork-end one half-turn at a time, and connecting the tie-rod to the bell-crank lever between

DOOR SHOOT-BOLT ADJUSTMENT




Fig. 7. Door adjustment points

adjustments, until the front shoot-bolt has a minimum engagement of 0.50 in when locked. Repeat this adjustment for the rear shoot-bolt by adjusting the tie-rod between the rear shoot-bolt and bell-crank lever, with the door unlocked there should be a clearance of 0.11 in between the end of the shoot-bolts and the pads with which they engage (see sub-para.(2) (b) Note).

(4) When the correct adjustments have been made, tighten the locknut(s) on the tie-rod(s) and reconnect the tie-rod(s) to the bell-crank lever.

(5) Manually close the door and fully lock the shoot-bolts, checking that the two shoot-bolts contact their engagement pads either simultaneously or with the forward shoot-bolt slightly in advance of the rear shoot-bolt. Check also that the pins attaching the shoot-bolts to the tie-rods do not foul the shoot-bolt housings when the shoot-bolts are fully locked.

(6) Check that there is a 0.04 in clearance between the flats of the shoot-bolts and their brackets (para.22).

(7) Reconnect the door jack piston rod to the lock lever.

(8) Manually operate the door jack sequence valve and operate the hydraulic hand pump to test the operation of the door; recheck the adjustments.

Door setting (fig.7 and 12)

22. An adjustable stop-bolt is provided on the leading edge of the door to ensure that the door, when closed, is in its correct position relative to the wing contour. The

stop-bolt is adjusted to permit the leading edge of the door to move 0.08 in inside the wing contour; the door hinge shimming may also require adjustment to obtain this figure (para.35). With the door in its correct position the clearance between the door shoot-bolt flats and their bracket must be 0.04 in. This clearance can be obtained by adjustment of the shimming between the shoot-bolt housings and the door (fig.12).

Note...

It is not essential that the shoot-bolts and brackets are parallel across their flats; an additional 0.02 in is permissible along one edge providing that it does not affect the clearance of 0.04 in. at the other.




Fig. 8. Sequence-valve adjustment

Sequence-valve setting (fig.8)

23. To adjust the sequence-valve tappet slacken the locknut and screw the tappet until a 0.10 in \pm 0.05 in clearance is obtained between the striking face of the

tappet and the body of the sequence-valve when the valve plunger is depressed (fig.8). After adjustment, check the operation of the sequence-valve (Chap.6) and tighten the locknut.

Up-latch hook setting (fig.1)

24. The up-latch hook is set by the manufacturers and should not normally require alteration, the clearance between the hook and up-latch pin being obtainable by adjustment of the up-stop block (para.25). If, after renewal of the hook or undercarriage unit, it is found necessary to adjust the hook bracket, the shimming between the bracket and up-lock beam may be varied accordingly, care being taken to ensure that the attitude of the hook is not altered when doing so. To adjust the hook bracket:

(1) Disconnect the return spring from the up-latch hook and remove the hook from the bracket, ensuring no damage is done to the microswitch or its connections.

(2) Remove and discard the attachment bolts and remove the bracket from the up-lock beam.

(3) Adjust the shimming as necessary and ensure that it will not affect the original attitude of the hook.

(4) Refit the bracket to the up-lock beam using new bolts. When the hook is correctly set (para.25),peen over the bolts to lock.

(5) Refit the up-latch hook and connect the return spring.

Note...

When a new hook is fitted the up micro-switch must be adjusted (fig.9).

Up-stop block setting (fig.1)

25. A rubber or Tufnol block in the roof of the wheel well receives the impact made by the wheel axle towing eye when the undercarriage is retracted. This block is adjusted to obtain the correct clearance between the up-latch hook and up-latch pin (para.24) by varying the shims between the block and bracket. When the undercarriage is fully raised adjust the shims beneath the block to give a clearance of 0.01 in to 0.015 in between the up-latch hook and up-latch pin (fig.1). Access to the hook when the undercarriage is raised is gained through a panel in the main plane upper surface (Sect.2, Chap.4).

Torque-link tolerance and adjustment

26. The centre pivot pin of the torque links should be examined for wear during servicing operations on the undercarriage. The correct clearance at this point is 0.001 in to 0.004 in, but a maximum clearance of 0.001 in to 0.010 in is allowed due to cumulative wear (Sect.2, Chap.6, App.1). If the clearance exceeds 0.010 in, it must be rectified by adding a new washer Ref.No.26FZ/715 to bring about the original tolerance of 0.001 in. to 0.004 in.

Microswitch settings

27. After any servicing or component replacement which may have affected the microswitch settings, a thorough check, and if necessary resetting, must be made as detailed in fig.9.

Leg-fairing alignment

28. The undercarriage leg spat-type fairing is adjusted to the main-plane contours by varying the shims fitted between the fairing and the four attachment bosses on the strut. When all the undercarriage adjustments are

correct, the undercarriage raised and resting in the up-latch hook, adjust the shims until the leading-edge of the fairing is 0.05 in inside the main-plane contour and the trailing edge is flush. When a new fairing is fitted file off the trim allowance to give 0.05 in to 0.08 in clearance around the spat perimeter.

Note...

◀ Protective treatment (A.P.101A-0600-6, Scheme 9.1.2) must be applied to all filed surfaces. ▶

New engine cowl flap fitting and adjustment

29. The flap is adjusted by means of the operating rod which connects it to the top of the shock-absorber strut. Adjustment is made until the flap is flush with the engine cowl skin when the undercarriage is fully retracted. When fitting a new flap the following procedure must be adopted:

- (1) Attach the flap to the engine cowl and connect the operating rod and check cable.
- (2) Remove the rubber or Tufnol blocks.
- (3) With the engine lower rear cowl fitted and the undercarriage retracted, file the trim allowance of the flap to ensure a butt fit on the cowl skin with the flap 'out-of-wind'.

Note...

◀ Protective treatment (A.P.101A-0600-6, Scheme 9.1.2) must be applied to all filed surfaces. ▶

- (4) Remove the engine top cowl, connect the operating rod to the shock-absorber strut bracket, and adjust the operating rod until the flap is closed.

- (5) Fully slacken the check cable tension rod.

- (6) Lower the undercarriage.

- (7) Partially retract the undercarriage and fit the rubber or Tufnol blocks.

Note...

Tufnol blocks are to be filed and trimmed to suit. Rubber blocks are to be reduced if too large and packed by light-alloy strip if too small.

- (8) With the flap in the open position, adjust the check cable tension rod until it is finger-tight and then slacken back one turn. Lock the tension rod.

- (9) Tighten the nut and peen over the bolt attaching the check cable to the flap arm.

REMOVAL AND ASSEMBLY

General information

30. The following paragraphs detail the removal and assembly operations for the undercarriage and its main components. Items which do not require special instructions for removal or assembly are not included. The sequence of operations for assembling the undercarriage and door must be adhered to. Checks and subsequent adjustments referred to are to be made at the stated operations.


Undercarriage (fig.11)

Removal

31. To remove the undercarriage and its main components:

DOWN MICROSWITCH

NOTE: AFTER ANY ADJUSTMENT OF THE UP OR DOWN MICROSWITCHES AN UNDERCARRIAGE RETRACTION TEST MUST BE MADE AND THE WARNING LIGHTS CHECKED.




DOWN MICROSWITCH ADJUSTMENT

- 1 CONNECT A 24-VOLT POWER SUPPLY TO THE EXTERNAL SUPPLY SOCKET.
- 2 SLACKEN LOCKNUT (1)
- 3 SCREW STRIKER BOLT (2) AWAY FROM MICROSWITCH (3) (GREEN LIGHT OFF).
- 4 SCREW STRIKER BOLT (2) TOWARDS MICROSWITCH (3) UNTIL A DEFINITE CLICK IS HEARD (GREEN LIGHT ON) AND GIVE ANOTHER COMPLETE TURN.
- 5 TIGHTEN LOCKNUT (1) AND ENSURE THAT SOME PLUNGER MOVEMENT REMAINS.

STARBOARD OLEO LEG MICROSWITCH ADJUSTMENT

- 1 JACK AND TRESTLE THE AIRCRAFT WITH THE WHEELS CLEAR OF THE GROUND (SECT.2, CHAP.4)
- 2 INSERT A 0.090 IN FEELER GAUGE BETWEEN THE MICROSWITCH PLUNGER AND THE OLEO STRIKER PIN. THE PLUNGER SHOULD JUST BE 'BOTTOMING'.
- 3 IF THE ADJUSTMENT (OP.2) IS INCORRECT PROCEED AS FOLLOWS:
 - (a) REMOVE THE MICROSWITCH ATTACHMENT NUTS (8) AND WASHERS, AND WITHDRAW THE MICROSWITCH TOGETHER WITH LAMINATED PACKING PLATE (9)
 - (b) BY PEELING A NEW LAMINATED PACKING PLATE REF. No. 26FZ/706 ADJUST THE MICROSWITCH TO OBTAIN THE CONDITION DESCRIBED IN OP. 2.
- 4 RE-CHECK THE ADJUSTMENT AFTER HAVING FINALLY RE-FITTED THE MICROSWITCH AND TIGHTENED THE SECURING NUTS.




MICROSWITCH SHOULD BE 'BOTTOMING' WITH 0.090 IN FEELER GAUGE INSERTED AS SHOWN.

SECTIONAL VIEW ON STARBOARD TORQUE LINK

UP MICROSWITCH ADJUSTMENT

- 1 JACK AND TRESTLE THE AIRCRAFT WITH THE WHEELS CLEAR OF THE GROUND (SECT.2, CHAP.4)
- 2 CONNECT A 24-VOLT POWER SUPPLY TO THE EXTERNAL SUPPLY SOCKET.
- 3 REMOVE THE APPROPRIATE ACCESS PANEL FROM THE UPPER SURFACE OF THE MAINPLANE INNER WING (SECT.2, CHAP.4).
- 4 RAISE THE ALIGHTING GEAR (SECT.3, CHAP.6).
- 5 SLACKEN THE NUTS (4) AND MICROSWITCH ATTACHMENT BOLTS (6)
- 6 TURN THE HEADS OF THE ECCENTRIC BOLTS (7) TOGETHER IN AN ANTI-CLOCKWISE DIRECTION (RED LIGHT WILL COME ON)
- 7 TURN THE HEADS OF THE ECCENTRIC BOLTS IN THE OPPOSITE DIRECTION UNTIL A DEFINITE CLICK IS HEARD (RED LIGHT OFF).
- 8 DO NOT ALLOW THE MICROSWITCH TO MOVE AND TIGHTEN ITS ATTACHMENT BOLTS (6) AND NUTS (4)
- 9 ENSURE THAT SOME PLUNGER MOVEMENT STILL REMAINS.



UP MICROSWITCH

Fig. 9. Microswitch adjustment

RESTRICTED

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Exhaust all hydraulic pressure from both the main and brake hydraulic systems (Chap.6).

(3) Remove the wheel and if necessary the brake unit (fig.13) from the wheel axle. Blank off exposed hydraulic pipes and apertures.

Note...

Unless the brake unit is life expired or damaged, it need be removed only if a replacement strut is to be fitted. Care must be taken when handling a shock-absorber strut when the brake unit has not been removed.

(4) Remove the bolt from the oleo leg end of the flap door connecting rod (detail B).

(5) Remove the engine bottom rear cowl (Sect.4, Chap.1).

(6) Disconnect the wheel brake flexible hydraulic pipe from its connection at the bleed valve bracket on the spat fairing (fig.10). Blank off exposed pipe ends.

(7) Unclip the flexible hydraulic pipe from the top of the fairing.

(8) Disconnect the flexible hydraulic pipe from the bracket at the bottom of the fairing. Blank off exposed pipe ends.

(9) Disconnect the electrical cables from the microswitch on the upper torque link, and unclip and release the cable from the fairing (starboard undercarriage only).

(10) Remove the four fairing attachment bolts from the brackets of the shock-absorber strut, remove the fairing and retain the shimming (fig.10).

Note...

If the fairing or strut is to be replaced the four brackets must be removed from the bosses on the strut. Retain the shimming.

(11) Disconnect both flexible hydraulic pipes from the main jack (detail C). Blank off exposed pipes and apertures.

(12) Remove the split pin and nut from the jack piston rod attachment bolt (detail A), and remove the bolt.

(13) Remove the split pin and nut from the jack pivot pin (detail C), and remove the jack from the aircraft.

(14) Disconnect the electrical cables from the down lock microswitch (detail A).

(15) Unclip the hydraulic pipe and electrical cables from the side stay. Coil and stow the electrical cables.

(16) Disconnect the flexible hydraulic brake pipe from the bracket at rib B on the main spar bulkhead, and remove the pipe from the aircraft. Blank off exposed pipe ends.

(17) Remove the split nut from the stay-link bolt at the spherical joint on the shock-absorber strut casting, and withdraw the bolt (detail A).

(18) Support the side stay and link and remove the locating plate from the side stay spherical pivot bolt (detail D).

(19) Withdraw the side-stay pivot bolt and remove the side stay and link from the aircraft.

(20) Remove the split pin from the slotted nut on the shock-absorber strut main pivot bolt and, using spanner Ref. No. 26FZ/95060, remove the nut. With the nut removed, withdraw the locking plate (detail B).

(21) Support the strut and, using spanner Ref. No. 26FZ/95059, withdraw the strut pivot bolt (detail B). Remove the shock-absorber strut from the aircraft.

Note...

(1) Should difficulty be encountered when removing the main pivot bolt, it may be found advantageous to screw inserter Ref. No.26FZ/95088 (detail B) on to the thread of the pivot bolt and give the end of the inserter a sharp knock with a hide-faced mallet.

(2) Access to the head of the main pivot bolt can be gained through a panel in the main-plane undersurface (Sect.2, Chap.4).

(3) Care must be taken when handling a shock-absorber strut when the brake unit has not been removed.

Assembly (fig.11)

32. To assemble the undercarriage and its components:

(1) With inserter Ref. No. 26FZ/95088 (detail B) screwed on to the threads of the main pivot pin, assemble the shock-absorber strut, less wheel and spat-type fairing, to the main-plane pick-up point.

RESTRICTED




Fig. 10. Leg-fairing removal and assembly

7502

(2) Remove the inserter and fit the pivot bolt locking plate, slotted nut and split pin to secure the pivot bolt.

Note...

On refitment of the main pivot bolt locking plate, check that the red line (S.T.I.CAN. 313) is still visible, and that the locking plate dowel holes are aligned. If necessary, rotate the pivot bolt to enable the plate to be pushed home by hand; the dowels must not be forced home by tightening the nut. A red line painted on the end of the main pivot bolt in the same relative position as the line introduced by S.T.I.CAN.313 will enable a check to be made, before tightening the nut, to ensure that the pivot bolt and locking plate are in line.

(3) Fit a dummy sleeve and weight Part No. EA1.88.371 to the wheel axle to make up the width of the wheel hub against which the towing eye abuts.

Note...

The towing eye forms the undercarriage up-stop.

(4) Assemble the side stay and link in the reverse order of removal (para.31), fitting split-pins to lock the slotted nuts of both pivot bolts. Secure the locating plate at the side-stay pivot bolt head and wire-lock the pivot bolt grease nipple stud to the locating plate (detail D).

(5) Fit the undercarriage jack at its main spar pivot attachment and lock the slotted nut with a split pin.

(6) Connect a hydraulic test rig Ref. No. 4F/1685 to the jack and ensure that the jack is fully extended. Adjust its length

RESTRICTED








FIG. 11. UNDERCARRIAGE REMOVAL AND ASSEMBLY

◀ HYDRAULIC PIPE RUN AMENDED ▶

RESTRICTED

by screwing the piston rod eye-end either in or out to obtain the correct override past the jack pick-up point centres on the stay-link lock lever bolt (para. 19). Wire-lock the piston rod locknut.

(7) Close the jack until the pick-up centres coincide, and secure the piston rod end to the down lock lever bolt. Lock the slotted nut with a split pin.

(8) Uncouple the up-latch hook return spring.

(9) With the hydraulic test rig connected to the main jack, raise the undercarriage (2750 lb/in²) and, whilst under jack load, check the clearance between the up-latch hook and up-latch pin (fig. 1). If adjustment is required, vary the shim thickness beneath the up-stop block in the wheel-well roof (para. 24).

Note...

1. It may be necessary to adjust the up-latch hook (para. 24); ensure that the hook attitude is not altered.

2. Access to the up-latch hook, when the undercarriage is retracted, is gained through a panel in the upper surface of the inner main plane (Sect. 2, Chap. 4).

(10) Lower the undercarriage and reconnect the up-latch hook return spring.

(11) Release the locknut of the sequence valve tappet on the side-stay knuckle joint, and screw the tappet as far as possible into the casting.

(12) Raise the undercarriage and adjust the tappet so that the sequence valve plunger is depressed to the dimensions given in fig. 8. Tighten the locknut.

Note...

Access to the sequence-valve tappet when the undercarriage is raised is gained through the same panel as for the up-latch hook (operation (9), Note (2)).

(13) Check the up microswitch setting and adjust if necessary (fig. 9).

(14) Partly raise the undercarriage and attach the spat-type fairing to the shock-absorber strut in the reverse order of its removal (para. 31).

(15) With the undercarriage resting in the up-latch hook, check the skin contour dimensions around the fairing perimeter; they must be as given in para. 28. If adjustment is required, vary the shims beneath the fairing attachment brackets on the four bosses of the shock-absorber strut (fig. 10).

(16) Lower the undercarriage, remove the dummy sleeve from the wheel axle and fit the wheel (fig. 13).

(17) Reconnect and clip the brake hydraulic pipes to the side-stay and leg fairing, leaving the clips partly tightened. Wire-lock the unions.

(18) Reconnect and clip the microswitch cables to the side stay and hydraulic pipes as shown in Sect. 5, Chap. 1, Group G. Leave the clips partly tightened.

(19) Check the settings of the down-lock microswitch and, on the starboard undercarriage, the oleo leg switch; if necessary, adjust (fig. 9).

(20) Fit the rear half of the engine lower cowling, connect the flap-operating link and, if necessary, adjust to give the flap a flush fit with the cowl (para. 29) when the undercarriage is raised.

(21) Using the hydraulic test rig, raise and lower the undercarriage to check no setting has been disturbed.

(22) Disconnect the test rig and connect the hydraulic pipes to the undercarriage jack. Wire-lock the unions.

Note...

Upon completion of the wiring and piping installation and before final tightening of the securing clips.

1. Using the handpump, fully retract and lower the undercarriage (Sect. 3, Chap. 6).

2. It is essential that, at all points of travel (and with the undercarriage locked up and down), all pipes and cables are safely routed (fig. 1 and Sect. 5, Chap. 1, Group G), do not chafe and are not trapped or stretched. ▶

(23) Tighten all securing clips and tape the hydraulic pipes (S.T.I./CAN/118B).

(24) Prime and bleed the jack and brakes.

(25) Test the functioning of the undercarriage and brakes (Chap. 6).

RESTRICTED

(26) Ensure that all bolts, nuts, pins and unions are correctly locked.

Note...

If after fitting a replacement shock-absorber strut, slight oil leakage occurs from the gland area, further flights may be made to allow the seals to bed-in before rejecting the strut as unserviceable.

Fitting a replacement undercarriage unit

33. The following operations, additional to para.32, are recommended whenever a main undercarriage unit is changed.

(1) Fit the up-stop cradle and pad (fig.1) together with the special shim packing, Ref.No.26FZ/9184.

(2) Fit undercarriage up-latch bracket, with hook attached and spring connected, and the special shim, Ref.No.26FZ/18513, interposed between structure and bracket.

(3) Wrap a 0.010 - 0.015 in. lamination around the up-latch pin on the side-stay assembly and raise the undercarriage by hand pump or hydraulic rig applying full hydraulic pressure.

(4) Check that the up-latch hook is moved only by the up-latch pin. To ensure correct alignment between the up-latch hook and the up-latch pin, adjustment may be made by tapering the shim.

Note...

1. *If the towing eye on the undercarriage main wheel hits the stop pad and the door-jack sequence valve is*

operated before the up-latch hook engages correctly, further shimming, Ref.No.26FZ/5055, may be added to the up-latch hook bracket with a corresponding reduction of shimming under the stop pad.

2. *Any additional laminations required at either position must be halved and the equivalent amount removed from the other, e.g. if 0.050 in. is required under the up-latch hook bracket fit 0.025 in. and remove 0.025 in. from under the stop pad. Additional shims to the basic 10 s.w.g. L.72 packing under the stop pad may be made by adding laminations from laminated aluminium shim, Ref.No.26FZ/6166.*

(5) Check, after adjusting shims, that the initial movement of the up-latch hook is made by contact with the up-latch pin and not the lever on the side stay and that a gap of 0.010 in. to 0.015 in. between the up-latch pin and the up-latch hook (fig.1) is present on full retraction.

(6) Fit and adjust the microswitch (fig.9).

(7) Repeat the undercarriage retraction and check alignment and relevant settings.

(8) Finally, check that on retraction the undercarriage fixed fairing is correctly aligned (para.28) by adjustment of the shim packings fitted between the shock-absorber strut and the fixed fairing.

Undercarriage door (fig.12)

Removal

34. To remove an undercarriage door:-

- (1) Fully open the door.
- (2) Remove the pin connecting the door jack piston rod to the lock lever between the lugs of the front door hinge.
- (3) Remove the bolt about which the lock lever, side links and lower check-links pivot.
- (4) Remove the hinge bolt from the front and rear door hinges, and remove the door.

Assembly

35. To assemble the undercarriage door:-

Note...

Refer to A.P.101B-0400-6, Part 1, Chap.3, for fitment of a new undercarriage door. Reference should also be made to the instructions given in S.T.I.CAN.392.

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Attach the door to its hinges and fit the slave link mechanism (para.36).

Note...

The front hinge bolt acts as a pivot for the side links at their inboard end.

(3) Close the door manually and ensure that a 0.08 in. maximum skin gap exists

RESTRICTED

at the door leading-edge. File the leading-edge if necessary.

Note...

◀ *Protective treatment (A.P.101A-0600-6, Scheme 9.1.2), must be applied to all filed surfaces.*

(4) Adjust the door stop-bolt (para.21) until the door leading-edge is 0.08 in. inside the wing contour out-of-wind. If necessary adjust the shimming between the door forward hinge bracket and door (para.37).

(5) The trailing-edge of the door must be flush with the skin contour. If necessary, adjust the shimming between the door rear hinge bracket and door (para.37).

(6) Fit the bolt about which the lock lever, side links and lower check links pivot.

(7) Ensure that all pressure is exhausted from the hydraulic system (Chap.6). Disconnect the flexible pipes from the door jack and connect a hydraulic test rig to the jack.

(8) Check, and if necessary, adjust the door jack overrides (para.20).

Note...

1. *After adjustment of the shimming between the two parts of the lock lever, ensure that the thread of the bolt Ref.No.26FZ/1499 which secures the two parts of the lock lever together, protrudes by 0.06 in. minimum when fully tightened. If necessary,*

up to three washers Ref.No.28W/9419403, in addition to the spring washer, may be fitted beneath the head of the bolt to prevent thread binding (fig.12).

2. *Ensure that the lock-lever counter-sunk locating screw has been locked by centre-popping.*

(9) Check the operation of the door shoot-bolts and adjust if necessary (para.21).

(10) Check the sequence valve tappet setting and if necessary adjust (para.23).

(11) Disconnect the hydraulic test rig and recouple the flexible pipes to the door jack. Bleed the jack (Chap.6).

(12) Functionally test the undercarriage and door (Chap.6).

(13) Ensure that there is a good even fit between the door and undercarriage spat-type fairing.

(14) Check that the door shoot-bolts engage properly and in correct sequence (para.21).

(15) Ensure that all bolts, nuts, pins, and unions are correctly locked.

Door check links (fig.12)

36. The door check link mechanism should not normally require any attention apart from normal periodic lubrication. If, however, it is found necessary to remove and replace parts of, or the whole of,

the mechanism, the following assembly points must be noted and functioning checks made. The removal of the mechanism is straightforward and requires no explanation.

Assembly notes and functioning checks

(1) Jack and trestle the aircraft (Sect.2, Chap.4) and remove the main undercarriage jack lock lever bolt (para.31).

(2) Assemble the side links, but not the slave link. Set the check links and sequence valve and ensure that the sequence valve plunger is not bottoming (para.23).

Note...

1. *A foul may occur between the bolt Ref.No.26FZ/21079, about which the lock lever, side links and lower check links pivot, and the flange of the adjacent sequence-valve bracket. This bolt must be fitted with its head facing aft and, if the foul still exists the washer under the head of the bolt must be fitted under the nut.*

2. *When assembling the check links ensure that the two 3/8 in. fulcrum bolts Ref.No.26FZ/21081 are positioned with the heads on the inner faces of the links with the spacing washer between the hinge and the check links and a plain washer fitted under each nut. After fully tightening these nuts and the nuts on the check links upper and lower attachment bolts, screw them back one quarter of a turn before drilling the split-pin hole; this allows for free movement of the links.*




FIG. 12. CHECK - LINK MECHANISM AND DOOR-REMOVAL AND ASSEMBLY

◀ ECCENTRIC BOLT DETAIL AMENDED ▶




DIAGRAM SHOWING RELATIONSHIP BETWEEN HOLES IN AXLE CLAMP AND AXLE.

Fig. 13. Wheel and brake removal and assembly

RESTRICTED

(3) Fit the slave link and adjust to the dimension given on fig.12.

(4) With the door jack disconnected at the lock lever, manually close the door and check that the slave link is free throughout its movement and does not foul the door sealing strip or check link pins. Observe the clearance at the top of the slot and ensure the slot does not bottom during the whole movement, there must also be adequate clearance at the bottom of the slot when the door is fully up.

(5) Remove the two 3/8 in. bolts from the fulcrum of the check links and ensure that the slave mechanism operates the sequence valve plunger with the door pushed to the fully down position.

(6) Reconnect the door jack to the lock lever and pump the jack fully down. Check that the slave mechanism still operates the sequence valve plunger.

Note...

With the check link fulcrum bolts removed, there will be no clearance between the top of the slave link slot and the eccentric bolt shank when the door is in the down position.

(7) Pull the door in an outboard direction and ensure that the mechanism is firm and that the sequence valve plunger is still depressed.

(8) Refit the bolts in the check links fulcrum points (*operation (2) Note 2*) and, observing the quarter turn back of the nuts, fit the split pins.

(9) Finally check that with the door fully down there is still a clearance between the top of the slave link slot and the eccentric bolt shank.

(10) Refit the main undercarriage jack lock lever bolt (*para.32*).

(11) Function-test the undercarriage (*Chap.6*).

Door hinges (*fig.12*)

37. The amount of thread of a hinge bracket attachment bolt which passes into its anchor nut is critical. It is, therefore, important that, during re-assembly of the hinge brackets, the following notes be carefully observed or, alternately, the instructions given in S.T.I.CAN.148 are complied with.

Note...

Before reassembly the hinges must be checked for excessive wear (A.P.101B-0400-6, Part 1, Chap.3).

(1) *Forward hinge* - the packing and shimming between the bracket and the door, plus the washer(s) Ref.No.28W/9419475 (each 0.048 in. thick) used under the head of a bolt, must add up in thickness to between 0.15 in. and 0.2 in. by choosing the appropriate number of washers for each bolt position.

Example:

With the packing and full shimming (0.1265 in. total) fitted, one washer only is required under each bolt head. Without packing or shimming fitted, three washers are required under each bolt head.

(2) *Aft hinge* - the packing and shimming between the bracket and the door, plus the washer(s) Ref.No.28W/9419475 (each 0.048 in. thick) used under the head of a bolt, must add up in thickness to between 0.2 in. and 0.25 in. by choosing the appropriate number of washers for each bolt position.

Example:

With packing and full shimming (0.1265 in. total) fitted, two washers are required under each bolt head. Without packing or shimming fitted, four washers are required under the head of the upper bolt and five washers under the heads of the four lower bolts.

Wheel (*fig.13*)

Removal

38.

(1) Jack and trestle the aircraft (*Sect.2, Chap.4*).

(2) Ensure that the aircraft parking brake is off (*Chap.6*).

(3) Unlock the brake piston rods by depressing the locking collar to free it from engagement with the cover plate. Screw the piston rods in tight.

(4) Remove the locking wire and unscrew and remove the locking bolt from the axle clamp.

(5) Unscrew and remove the axle clamp.

(6) Using wheel extractor Ref.No.26FZ/95292 remove the wheel from the axle.

Assembly

39. When reassembling the wheel it is

RESTRICTED

important that the wheel bearing and brake clearances are correctly adjusted. To obtain these clearances the following sequence of operations must be observed:-

(1) Ensure that the wheel bearings are lubricated with grease XG-277.

Note...

Care must be exercised to avoid shock loads being transmitted to the Maxaret unit.

(2) Slide the wheel on to the axle and, when it is fully engaged with the brake tenons, free the brakes by depressing the locking collar and unscrewing the piston rods about two turns.

(3) Whilst rotating the wheel, screw on the axle clamp until the taper bearings are fully home and the clearance is taken up. Do not overtighten the axle clamp during this operation.

(4) When the axle clamp is fully home and the clearance taken up, unscrew the axle clamp to obtain a clearance of 0.005 in. ± 0.005 in. between the clamp and the wheel.

Note...

Six locating holes for the locking

bolt are provided in the axle clamp and five in the axle, therefore only one of the axle clamp holes will coincide with a hole in the axle at any one time (fig.13). This coincidence will occur at different holes at 12 deg intervals as the axle clamp is rotated. The axle clamp is threaded 16 t.p.i., thus one complete turn of the clamp will give a clearance of 0.0625 in. A movement of 12 deg from one hole coincidence to the next would, therefore, give a clearance of 12/360 of 1/16 = 0.002 in. approximately. To obtain the minimum defined clearance the axle clamp must be unscrewed through the coincidence of three holes which will give the correct clearance of 0.006 in.

(5) Insert the locking bolt into the coinciding holes; tighten and wire-lock.

(6) Adjust the brake clearance by screwing in the piston rods until contact is made between the brake plates and friction pads (about two turns). Screw back one and a quarter turns plus the amount necessary to engage the locking device (A.P.2337, Vol.1).

(7) Function-test the operation of the brakes (Chap.6).

Brake unit (fig.13)

Removal

40.

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Ensure that all hydraulic pressure is exhausted (Chap.6).

(3) Remove the wheel (para.38).

(4) Disconnect the flexible hydraulic pipes from the brake and Maxaret units.

(5) Remove the split pins from the ten slotted nuts which secure the brake unit to the axle.

(6) Remove the brake unit.

Assembly

41.

(1) Assemble the brake unit to the stub axle and secure with the slotted nuts and new split pins.

(2) Bleed and reconnect the hydraulic pipes to the brake and Maxaret units.

(3) Refit the wheel and adjust the brake piston rods (para.39).

(4) Function-test the operation of the brakes (Chap.6).

Chapter 5B

NOSE UNDERCARRIAGE

LIST OF CONTENTS

DESCRIPTION	Para.	SERVICING	Para.	REMOVAL AND ASSEMBLY	Para.
General information	1	General information	14	Sequence-valve settings	24
Shock-absorber strut	2	Shock-absorber leakage	15	Microswitch settings	25
Shock-absorber	3	Checking and correcting shock-absorber oil pressure	16	REMOVAL AND ASSEMBLY	
Self-centring mechanism	4	Lubrication	17	General information	26
Radius rod and stay link	5	ADJUSTMENTS		Undercarriage and undercarriage doors mechanism removal	
Undercarriage jack	6	General information	18	Undercarriage	27
Up-latch mechanism	7	Radius-rod and stay-link alignment	19	Door mechanism... ..	28
Down-lock mechanism	8	Jack travel adjustments		Undercarriage and undercarriage doors mechanism assembly	
Door-operating mechanism	9	Undercarriage jack	20	General	29
Door-latching mechanism	10	Door jack	21	Door mechanism... ..	30
Principle of operation		Up-latch mechanism	22	Undercarriage	31
Raising	12	Door-latching mechanism	23	Up-latch mechanism	32
Lowering	13				

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
General view, looking aft	1	Radius rod/stay link alignment	7	Undercarriage removal and assembly (1) ...	14
General view, looking forward	2	Up-latch hook setting (1)	8	Undercarriage removal and assembly (2) ...	15
Undercarriage locking mechanism	3	Up-latch hook setting (2)	9	Hook release mechanism and door jack removal	16
Starboard door locking mechanism	4	Door forward up-latch hook setting	10	Undercarriage jack hydraulic pipes clipping	17
Door jack crosshead arrangement	5	Door aft up-latch hook setting	11		
Lubrication diagram	6	Sequence-valve setting	12		
		Microswitch setting	13		

RESTRICTED




Fig. 1. General view, looking aft

RESTRICTED

DESCRIPTION

General information (fig.1 and 2)

1. The nose undercarriage is the twin wheel, lever suspension type, fitted with a liquid spring shock-absorber and a spring-loaded self-centring device (A.P.1803E, Vol.1, Sect.6). The unit pivots about support brackets mounted on the aft face of the pressure bulkhead and, on retraction, a hydraulic jack moves it rearwards and upwards into the nose-wheel well (Chap.1). After retraction, the nose wheel is faired-off flush with the aircraft skin by two doors actuated by another hydraulic jack mounted on the aft bulkhead of the well. A mudguard, attached to the bearing bracket on the axle is provided for each wheel. A radius rod and stay link, spanned between the aircraft structure and the shock-absorber, incorporates a down-lock mechanism in its knuckle joint; the undercarriage is held locked in the retracted position by an up-latch hook situated in the roof of the wheel well. Sequence valves, interposed in the hydraulic jacks circuits, ensure correctly-timed opening and closing of the doors in relation to the undercarriage operation (Chap.6).

Shock-absorber strut

2. The strut consists of a main fitting, which houses the main pivot shaft and self-centring mechanism, a pivot fork and link fitting, a twin-stub axle beam, and a liquid-spring shock-absorber. Two bearing-brackets on the aft face of the pressure bulkhead provide a suspension and pivoting point for the strut main pivot shaft, while lugs on the rear of the strut outer sleeve form attachment points for the stay link which connects the strut to the retracting mechanism (para.5). The wheels are carried

on the stub axle beam pivoted to the lower end of the inner sleeve, with the lower end of the shock-absorber strut pin-jointed to the beam between the axle and pivot pin.

Shock-absorber

3. The shock-absorber is a liquid-spring unit housed within the strut outer sleeve and retained in the strut by a pip-pin. It consists of a cylinder, housing a piston assembly, and is described in A.P.1803E, Vol.1, Sect.6.

Self-centring mechanism

4. The spring-loaded self-centring mechanism is an integral part of the strut outer sleeve. It is housed in a dashpot at the top of the sleeve and acts as a damper to any shimmying effect which might occur during taxiing. The unit is fully castering, controlled within a range of 25deg on each side of the trailing position.

Radius rod and stay link

5. The radius rod pivots at its upper end in a block mounted between two heavy support beams on the underside of the undercarriage well roof, and is pin-jointed at its lower end to the stay link which connects it to the strut outer sleeve. Where the radius rod joins the stay link a knuckle joint is formed which folds during undercarriage retraction. Incorporated in this knuckle joint is the down-lock mechanism and a pin which engages the up-latch hook when the undercarriage is fully retracted. Two microswitches, which when operated, illuminate the undercarriage indicator lights at the pilot's station, are mounted on the knuckle joint.

Undercarriage jack

6. The jack is situated below the radius

rod, and at its body end is pivoted between the two channel stiffeners on the aft bulkhead of the undercarriage well. At its forward end the jack piston rod is attached through the down-lock lever to the knuckle joint of the radius rod. The jack is extended when the undercarriage is retracted.

Up-latch mechanism (fig.8)

7. The up-latch hook assembly is mounted between the two support beams on the underside of the wheel-well roof. The hook is retained in its normal locking position by a spring, one end of which is attached to an extension of the hook, while the other is attached to the support beam. When the undercarriage is fully retracted, the hook, under the action of its spring, engages the up-latch pin on the end of the radius rod; when the jack retracts to lower the undercarriage, the initial movement rotates the down-lock lever and a roller on the end of the lever disengages the up-latch hook from the up-latch pin to release the undercarriage. An adjustable pedestal is mounted on each side of the up-latch hook to limit the upward movement of the radius rod. The door sequence valve and trip lever is mounted just aft of the up-latch hook assembly on the port longitudinal well roof beam; the lever is operated, during undercarriage retraction, by the upper face of the radius rod.

Down-lock mechanism (fig.3 and 7)

8. The down-lock mechanism is carried in the forked end of the radius rod in which the stay link is hinged. It consists of a lever, mounted on a pivot bolt, carrying two rollers on its upper end; the lower end of the lever is connected to the end of the jack piston rod. When in the down position, the lower of the two rollers on the lever




Fig. 2. General view, looking forward

rests on the profiled end of the stay link, in which position it is locked by a spring-loaded latch pin.

Door-operating mechanism (fig. 5)

9. The two doors are hinged to the under-surface of the fuselage, one on either side of the undercarriage well, and open downward and outward. The doors are operated by a jack mounted vertically on the rear bulkhead of the undercarriage well, the upper end of the jack piston rod being connected to a crosshead yoke which is connected to the rear of both doors by actuating links; the lower end of the jack is connected to the door up-latch hook release lever (fig. 4 and 11). A trip screw on the port arm of the crosshead operates, through a lever, the undercarriage jack sequence valve when the doors are opened.

Door-latching mechanism (fig. 4)

10. The doors are secured in their closed position by two latches, one at each end of the starboard door, which hook over two up-latch bolts suitably positioned on the forward and aft walls of the undercarriage well. The port door is held in the closed position by two bevelled abutment faces (fig. 8 and 9), fitted to the edge of the starboard door, which mate with corresponding inverted abutment faces on the edge of the port door. The two door up-latch hooks are connected by an adjustable rod, and are loaded in the locked position by a latch return spring. Up stops are provided for both doors, one at the front and two at the rear of the undercarriage well; the rear stop packings are on the doors, and all three are adjustable by shimming to ensure a correct fit of the doors to the fuselage. The doors are shaped in such a manner that the forward ends close first.




Fig. 3. Undercarriage locking mechanism

RESTRICTED




Fig. 4. Starboard door locking mechanism

RESTRICTED

11. The doors are opened when the latches are operated by a hook release lever mounted at the rear end of the undercarriage well; the lever is pivoted about its centre, and its upper end carries a striker roller so

positioned that downward movement will cause it to contact the upper face of the aft latch. The lever carries the door jack lower pick-up point, and forward swing limit stops are fitted to the lever bracket to

contact the lever and ensure a positive operating point for the jack when closing the doors. Initial retraction of the jack gives an upward movement to its lower pick-up point and a forward and downward movement to the hook release lever, which causes the striker roller to contact and move the aft latch out of engagement with its latch bolt. Movement of the aft latch is transmitted by the connecting rod to the front latch which is simultaneously released; further movement of the jack opens the doors. When the doors are being closed, the final movement of the jack brings the upper edges of the latch hooks into contact with the latch bolts and, due to their bevelled shape, the latches are moved rearwards until the doors are fully closed then, under the action of the latch return spring they move forward and lock the doors.




Fig. 5. Door jack crosshead arrangement

Principle of operation

Raising

12. Upon selecting alighting gear UP, hydraulic pressure is first felt at both the undercarriage and door jacks but, since the door jack sequence valve is closed, preventing a flow of fluid from the door jack, only the undercarriage jack is operated. Initial extension of the jack piston rod overrides the spring-loaded lock lever plunger and withdraws the lower roller of the lock lever from the profiled end of the stay link (fig.3); further movement breaks the stay link/radius rod knuckle joint, raises the radius rod and retracts the undercarriage. As the undercarriage approaches the end of its movement, the up-latch bolt is engaged by the up-latch hook, and the radius rod trips the door sequence valve operating lever, permitting a flow of fluid from the door jack. Initial extension of the door jack piston rod closes the undercarriage jack

RESTRICTED




Fig.6. Lubrication diagram

RESTRICTED

KEY TO FIG. 6 (LUBRICATION DIAGRAM)

1	LINK PIVOTS	○	15	DOOR LATCH HOOKS AND CONNECTING ROD	○
2	SHOCK-ABSORBER ATTACHMENT	—■	16	STAY-LINK PIVOT	—■
3	TORQUE-LINK PIVOTS (2 NIPPLES)	—■	17	DOOR GUIDE ROLLER	○
4	PIVOT FORK BEARING	—■	18	MUDGUARD ATTACHMENT BEARINGS (2 NIPPLES)	—■
5	FORWARD UP-LATCH TAPPET RETURN SPRING AND PIVOT	○	19	WHEEL BEARINGS	—■
6	MAIN PIVOT BEARINGS (2 NIPPLES)	—■	20	ACTUATING-LINK PIVOTS	○
7	SELF-CENTRING MECHANISM	—■	21	HOOK RELEASE LEVER ROLLER	—■
8	UP-LATCH HOOK MECHANISM	○	22	SPRING HOUSING (UPPER PART ONLY)	■
9	DOOR SEQUENCE-VALVE MECHANISM	○	23	LOCK LEVER ROLLERS	■
10	RADIUS ROD PIVOT	—■	24	MICROSWITCH TAPPET AND LEAF SPRING	○
11	UNDERCARRIAGE SEQUENCE VALVE MECHANISM	○	25	JACK PISTON ROD PIVOT	—■
12	UNDERCARRIAGE JACK PIVOT	—■	26	LOCK-LEVER PIVOT	—■
13	DOOR HINGES	○	27	RADIUS ROD/STAY LINK PIVOT	—■
14	ACTUATING-LINK PIVOTS	○			

RESTRICTED

sequence valve, and continued movement of the door jack closes the doors (*para.11*).

Lowering

13. When the alighting gear is selected DOWN, hydraulic pressure is first felt at both the undercarriage and door jacks but, since the undercarriage sequence valve is closed, preventing a flow of fluid from the

undercarriage jack, only the door jack is operated. Initial retraction of the door jack piston rod operates the door latches (*para. 11*) and continued retraction opens the doors which finally operate the undercarriage jack sequence valve, allowing fluid to flow from the undercarriage jack. Initial movement of the undercarriage jack causes the lock lever to pivot and disengage the up-

latch hook, the radius rod falls and closes the door jack sequence valve and further movement of the jack lowers the undercarriage. The undercarriage is finally locked down by the engagement of the lower roller of the lock lever in the lip on the end of the stay link and the operation of the spring-loaded lock lever plunger (*fig.3*).

WARNING

The relevant safety precautions detailed on the **LETHAL WARNING** marker card must always be observed before entering the cabin or performing any operations upon the aircraft.

General information

14. The following paragraphs provide information on the routine servicing of component parts.

Shock-absorber leakage

15. External leakage from the shock-absorber is an indication of a defective sealing ring or gland washer. In these cases the unit must be considered unserviceable and a new one fitted. If leakage occurs past the bleed plug it may be caused by slackness of the plug or grit under the

ball; if cleaning and tightening proves ineffective the unit must be renewed.

Checking and correcting shock-absorber oil pressure

16. If the shock-absorber leg extension does not conform to the dimensions given in Sect.2, Chap.2 when the undercarriage is in the normal static-loaded condition and the shock-absorber shows no signs of leakage, the unit must be topped up as follows:

(1) Jack the aircraft nose (*Sect.2, Chap. 4*) to remove the load from the shock-absorber.

(2) Connect a flexible charging adapter Ref. No. 27Q/14103 to a universal lubricating gun Ref. No. 1B/4467 and prime the charging adapter using hydraulic fluid

OM-15.

(3) Remove the cap from the shock-absorber charging valve and connect the primed charging adapter and gun to the valve.

(4) Charge the shock-absorber to a pressure between 1400 and 1500 lb/in². Release the pressure in the charging adapter by slackening the adapter bleed screw. Remove the adapter and gun; refit the valve cap and lower the aircraft.

(5) Recheck the leg extension dimension (*Sect.2, Chap.2*).

Lubrication

17. Refer to fig.6 and the symbol key thereto.

General information

18. The paragraphs in this section describe the procedure to be adopted when settings have to be checked and adjustments made. The occasions arise during both servicing and assembly operations and

have for that reason been incorporated in this separate section, with relevant cross references made as necessary from other sections. After any adjustments have been made the nose undercarriage must be function-tested (*Chap.6*).

Note...

(1) Operation of the nose undercarriage **GROUND/FLIGHT selector valve to GROUND** isolates the main undercarriage units and prevents them retracting (*Chap.6*).

SERVICING

ADJUSTMENTS

RESTRICTED

(2) When raising the nose undercarriage with the door-actuating links disconnected from the doors, an assistant must hold and guide the links to prevent damage to the adjacent hydraulic piping.

Radius-rod and stay-link alignment (fig.7)

19. The radius rod and stay-link are in correct alignment when their joint pivot pin is offset 0.25in downwards from a straight line between the radius rod pin centre and the stay link pin centre. This dimension is governed by the jack length and, for that reason, can be measured only when the jack is connected and under hydraulic pressure with its overrides previously set (para.20). With hydraulic pressure released, there must be a 0.004in clearance between the upper lip of the side stay and the radius rod stop-plate (fig.7). Should adjustment be necessary, either add to, or subtract from, the shimming Ref.No. 26FZ/6146 (total pack 0.0625in in laminations of 0.002in) provided behind the stop-plate, in the following manner:

(1) Select GROUND on the GROUND/FLIGHT selector valve and partly raise the undercarriage by operating the aircraft hand pump.

(2) Remove the stop-plate by unscrewing its securing bolts and adjust the shimming Ref.No.26FZ/6146 as necessary. Refit the stop-plate.

(3) Select FLIGHT on the GROUND/FLIGHT selector and fully lower the undercarriage by operating the aircraft hand pump.

(4) Release the hydraulic pressure and check that the 0.004in clearance has

been obtained.

Jack travel adjustments

Undercarriage jack

20. The distance between the pin centres of the undercarriage jack when fully closed is 24.61in \pm 0.25in; the jack piston rod travel is 9.09in \pm 0.06in. The exact pin-centre dimension is governed by the pick-up points on the aircraft structure and the radius rod lock lever. The jack length must be checked upon renewal and after any servicing which may have affected its setting. To adjust the length:

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Disconnect the jack piston rod from the lock lever by removing the attachment bolt (para.27).

(3) Disconnect the stay link and radius rod assembly from the shock-absorber strut by removing the stay link lower pivot bolt (para.27).

Note...

The radius rod assembly must not be allowed to fall below its normal operating position whilst disconnected at its lower end, or its underside will foul and damage the rigid single-coil hydraulic pipe Ref. No.26FZ/4783 situated on the aft bulkhead immediately below the radius rod upper pivot attachment (fig.1).

(4) Unlock the nose undercarriage GROUND/FLIGHT hydraulic selector valve (Chap.6), select GROUND, and fully extend the jack by operating the aircraft hand pump.

(5) Loosen the locknut on the jack piston rod eye-end.

(6) Manually lift the radius rod assembly hard against the up-lock pedestal stops and adjust the length of the jack by screwing the piston rod eye-end either in or out, until the distance between the jack pin centres exceeds the distance between the centre of the piston rod attachment hole in the lock lever and the centre of the jack attachment bolt in the aircraft structure by 0.18in \pm 0.02in.

Note...

Do not reconnect the jack piston rod to the lock lever at this stage.

(7) Reconnect the radius rod and stay-link assembly to the shock-absorber strut in the down position. Check the radius rod and stay link for correct alignment (para.19).

(8) Select FLIGHT on the nose undercarriage GROUND/FLIGHT selector valve, and operate the aircraft hand pump to fully close the jack.

Note...

It is essential that the undercarriage jack hydraulic pipes are so positioned and secured that, during all operations of the jack, they will not foul either the undercarriage door jack crosshead or any part of the structure. The method of positioning and securing the pipes is described and illustrated in fig.17.

(9) With the radius rod assembly locked down and the jack fully closed, check that the distance between the centre of the piston rod attachment hole in the lock

lever and the centre of the jack attachment bolt in the aircraft structure exceeds the jack pin centres by 0.22 in + 0.04 in.
- 0.05

Note...

Ensure that the lock lever is correctly positioned by inserting the ground lock quick-release pip-pin (Sect.2, Chap.1); remove the pip-pin before continuing with the adjustment.

(10) Select GROUND on the nose undercarriage GROUND/FLIGHT selector valve and, using the aircraft hand pump, extend the jack until its piston rod eye-end and the holes in the lock lever coincide. Fit and lock the attachment bolt (para.31).

(11) Tighten and wire-lock the jack piston rod locknut.

(12) Reselect the GROUND/FLIGHT selector valve to FLIGHT and wire-lock. Fully close the jack. Check that the clearance between the radius rod stop-plate and the lip of the side stay is 0.004 in (fig.7). Should adjustment be necessary refer to para.19.

Door jack

21. The distance between the pin centres of the door jack when fully closed must not exceed 16.21 in ± 0.25 in; the jack piston rod travel is 9.19 in ± 0.06 in. The exact pin centres dimension is obtained by measuring from the undercarriage well roof to the door actuating link pin centres on the jack crosshead; this dimension is 6.55 in when the jack is fully extended (fig.5, dimension A). The jack closed position is governed by the setting of the crosshead

stops. On replacement of the jack or after any servicing which may have affected its setting, the jack length must be checked and, if necessary, adjusted in the following manner.

(1) Disconnect the undercarriage jack from the radius rod lock lever and the aircraft structure and remove the jack (para.27). Disconnect the door actuating links from the door (para.28).

(2) Select GROUND on the nose undercarriage GROUND/FLIGHT selector valve, and fully extend the door jack.

(3) Release the jack piston rod locknut and remove the piston rod eye-end connecting bolt from the crosshead.

(4) Adjust the jack length by turning the eye-end one half turn at a time, re-inserting the connecting bolt, but not locking it and, with a straight edge placed across the pin centres of the two door actuating link attachment bolts on the crosshead, measure a vertical dimension to the skin of the well roof. Adjust until a vertical dimension of 6.55 in is obtained (fig.5, dimension A).

(5) Tighten and wire-lock the piston rod locknut.

(6) Lock the slotted nut to the jack piston rod connecting bolt with a split pin.

(7) Reconnect the door actuating links.

(8) Adjust the crosshead stops until the doors are at their fully open position; 54.50 in ± 0.50 in measured between the outer edges of their outer skins.




Fig.7. Radius rod/stay link alignment




Fig.8. Up-latch hook setting (1)

(9) Refit the undercarriage jack to the aircraft (para.31).

Note...

Ensure that the flexible hydraulic pipe Part No.OC.101B/10 (fig.1) which runs to the top of the door jack, is positioned in its cleat on the mud shield so as to give the maximum possible clearance between its elbow union and the port wheel tyre during nose undercarriage retraction.

Up-latch mechanism (fig.8)

22. The following information covers the installation of a replacement up-latch hook

and/or bracket assembly. It will be evident that the whole procedure is not necessary for a normal check of the hook setting, but the additional information relating to the initial hook setting has been incorporated to cover cases of extreme maladjustment, when the complete procedure must be adopted. To assemble the up-latch mechanism:

- (1) Jack and trestle the aircraft (Sect.2, Chap.4).
- (2) Remove the mudguards and wheels (para.27).

(3) Disconnect the door-actuating links from the doors.

(4) Disconnect the jack piston rod from the radius rod lock lever (para.27).

Note...

The radius rod assembly must not be allowed to fall below its normal operating position whilst disconnected at its lower end or its underside will foul and damage the rigid single-coil hydraulic pipe Ref. No.26FZ/4783 situated on the aft bulkhead immediately below the radius rod upper pivot attachment (fig.1).

RESTRICTED

(5) Remove the pivot pin attaching the radius rod stay link to the undercarriage strut (para.27).

(6) Remove the cover box of the up-latch mechanism from the floor of the upper equipment compartment. Remove the hook and bracket assembly and the up-stop pedestals and discard the unserviceable item. Retain the shims and fastenings, less split pins.

(7) Assemble the hook bracket, less shims, to the well roof structure and secure with a stiffnut.

(8) Assemble the up-stop pedestals, complete with shims, and secure with stiffnuts.

Note...

The torque loading on the hook and pedestal stiffnuts must not exceed 125 lb in.

(9) Refer to fig.8 and, with a $\frac{3}{8}$ in ± 0.000 in dia pin inserted in the hook $- 0.001$ pivot bracket, set the hook and pedestals to the dimensions given in the illustration. Attach the hook and connect the hook spring.

(10) Manually raise the radius rod until the latch pin rests in the hook.

(11) Adjust the radial stop-bolt to give a clearance of 0.004 in between the end face of the radial stop-bolt and the hook flat. Tighten the radial stop-bolt locknut.

(12) With the latch-pin still resting in the hook, adjust the up-stop pedestals to give a clearance of 0.050 in ± 0.015 in between the pedestals and the radius rod stop faces.

Note...

(1) If the 0.050 in clearance cannot be attained after the removal of all the shims from beneath the up-stop pedestals, shims must be inserted beneath the hook bracket and, if necessary, further adjustment obtained by reshimming the up-stop pedestals.

(2) The two up-stop pedestals are to be adjusted to within 0.003 in of each other.

(13) Manually push the radius rod hard up against the up-stop pedestals and support it in that position.

(14) Check, and if necessary adjust, the jack override (para.20). Connect the jack to the radius rod lock lever (para.31).

(15) Select the GROUND/FLIGHT selector valve to FLIGHT and, by using the aircraft hand pump, force the radius rod against the up-stop pedestals and adjust the sequence valve (para.24).

(16) Disconnect the jack from the lock lever, lift the radius rod clear of the hook




Fig. 9. Up-latch hook setting (2)

and lower by hand to reconnect the stay link to the undercarriage strut (para.31). Check that the radius rod lock lever is engaged.

(17) Select the GROUND/FLIGHT selector valve to GROUND and fully close the jack under pressure. Check its closed override (para.20) and connect the jack to the lock lever (para.31).

(18) With the wheels or an equivalent weight fitted to the undercarriage stub axles, raise the undercarriage under hydraulic pressure.

(19) Take and record a vertical measurement from a point in the roof of the wheel well to the undercarriage stub axle (fig.9, dimension A).

(20) Place a jack or trestle beneath the strut allowing a clearance of approximately 1 in between the strut and the jack or trestle.

(21) Using the aircraft hand pump, lower the door jack until its crosshead trips the undercarriage sequence valve. An audible click will be heard when the radius rod latch-pin drops into the well of the up-latch hook. When this occurs, stop pumping immediately, leaving the undercarriage suspended by the up-latch hook.

(22) Take a second measurement from the same point in the roof, to the nose-wheel axle (fig.9, dimension A); this dimension should exceed that obtained in operation (19) by 0.20 in ± 0.050 in. If this dimensional difference is incorrect, it can be corrected by adjusting the shimming beneath the up-stop pedestals.

RESTRICTED




Fig. 10. Door forward up-latch hook setting

Note...

The 0.20 in ± 0.050 in dimension ensures that, with the radius rod hard up against the up-stop pedestals, a gap of approximately 0.030 in exists between the latch-pin and the hook.

(23) Function-test the nose undercarriage and ensure that the hook engages correctly with the latch pin. Recheck the sequence-valve setting and the jack overrides.

(24) Refit the box cover over the up-latch mechanism in the upper equipment compartment.

(25) Reconnect the door-actuating links and ensure all nuts, pins and unions are correctly locked.

Door-latching mechanism (fig.10 and 11)

23. The correct setting of the doors in the up position depends upon the critical

setting of several adjustable items, namely: the forward and aft door up-latch hooks and connecting rod, the door up-stop pads, abutment faces, and the door actuating links. Any item which is maladjusted can affect the setting of each of the other items; for this reason the following procedure must be adopted, as the sequence in which the settings are made is as important as the settings themselves. To set the nose undercarriage doors:

- (1) Jack and trestle the aircraft (Sect. 2, Chap. 4).
- (2) Remove, and mark for re-identification, both door-actuating links.
- (3) For ease of access remove the landing wheels and mudguards.
- (4) Fully retract the undercarriage.
- (5) Remove and retain the packing and shimming from the up-stop on the forward up-latch bolt attachment bracket.

- (6) Manually close the starboard door and align its trailing edge flush with the fuselage contour by adding or subtracting shims at the aft up-stop pad (fig. 11). Hold the door firmly in the closed position and obtain a 0.030 in 'out-of-wind' step at the door leading-edge by inserting a Paxalin wedge (of local manufacture) between the door inner skin and the starboard lower edge of the forward-up-latch bolt mounting bracket.

- (7) Adjust the up-latch hooks connecting rod on the starboard door so that the hooks will fully engage over the up-latch bolts. Remove the PAXALIN wedge.

- (8) Support the front edge of the door in the up position and check that the forward hook is in line with the microswitch tappet lever, and that the tappet is in line with the microswitch plunger.

- (9) Should it be necessary to align the tappet and/or the microswitch, lateral adjustment can be gained on both items

Note...

The door is designed to close at its forward end first.




Fig. 11. Door aft up-latch hook setting

by repositioning the shims fitted on the attachment bolts between the distance pieces and the brackets (fig.10).

Note...

It is permissible to fit the shims equally on each side of the distance pieces, or both at one side, depending upon the adjustment required. In cases of extreme maladjustment a similar arrangement is permissible with the hook pivot pin shims (fig.10).

(10) Check the clearance between the forward up-latch hook and the up-latch bolt; this is to be 0.30 in (fig.10). If adjustment is required, remove the locating screw from the scalloped head of the up-latch bolt (fig.4) and revolve the bolt until the correct clearance is obtained. Refit the locating screw.

Note...

To obviate any possibility of a foul occurring between the threaded portion of the locating screw and the microswitch tappet return spring, the up-latch bolt must be fitted with its head inboard facing port.

(11) Check, and if necessary, adjust the forward up-latch microswitch tappet (fig.13).

(12) With the starboard door still closed, check the clearances of the aft up-latch mechanism:

(a) The hook should be in line with the centre of the hook release lever roller to within 0.10 in.


(b) If, after renewal of a starboard door, hook, or hook release lever mechanism, it is found necessary to make adjustments

to obtain this alignment:

- (i) Remove the abutment piece and the hook assembly from the door; retain the washer (fig.11).
- (ii) Drill out the five rivets attaching the packing to the hook.
- (iii) Reassemble the packing to the hook to suit the alignment of the hook and hook release lever roller.
- (iv) Rivet the packing to the hook and reassemble the hook assembly to the door, fitting the washer removed in operation (i). Refit the abutment piece.

Note...

The washer Ref.No. 28W/9419476 may be filed to give free fore-and-aft movement of the hook, without allowing any side play (fig.11).



NOTE... TAPPET LOCKNUT MAY BE POSITIONED EITHER SIDE OF TRIP LEVER DEPENDING UPON THE AMOUNT OF ADJUSTMENT REQUIRED.

Fig. 12. Sequence-valve setting

(c) Check the clearance between the aft up-latch hook and the up-latch bolt (fig.11). If adjustment is required, remove the locating screw from the scalloped head of the up-latch bolt and revolve the bolt until the correct clearance is obtained. Refit the locating screw.

(d) When all other aft latch mechanism settings have been met, check the clearance between the hook lip and the hook release lever roller (fig.11). If adjustment is required, remove the slotted nut which secures the roller housing to the hook release lever, and add or subtract shims Part No. EA3.10.3339 as necessary to a maximum shim thickness of 0.20 in (nominal thickness 0.080 in.).


Note...

If, after adjusting the hook release lever roller, the roller attachment nut fouls the adjacent vertical stiffener when the lever is moved aft, the stiffener may be filed locally to clear (max depth 0.20 in.). Protective treatment (A.P. 101A-0600-6, Scheme 9.1.2) must be applied to all filed surfaces.

(e) Wedge the sequence valve on the bulkhead in the open position, i.e. tappet away from plunger, and remove the sequence valve lever trip screw from the port arm of the jack crosshead. THIS IS IMPORTANT.

(f) Ensure that the crosshead down-stops are correctly set (para.21) and fully close the jack. The two tails of the hook release lever should abut the lever bracket, but a maximum gap of 0.005 in is allowed at any one tail (fig.11).



(13) Lower the starboard door and



NOTE...
AFTER ANY MICROSWITCH ADJUSTMENT
AN UNDERCARRIAGE RETRACTION TEST
MUST BE MADE AND THE WARNING LIGHTS
CHECKED

DOWN MICROSWITCH ADJUSTMENT

- 1 CONNECT A 24-VOLT SUPPLY TO THE EXTERNAL SUPPLY SOCKET.
- 2 SLACKEN THE BOLTS (3).
- 3 MOVE THE ATTACHMENT PLATE (2) COMPLETE WITH MICROSWITCH (4) APT TO THE LIMIT OF ITS TRAVEL. (GREEN LIGHT OFF).
- 4 INSERT A 0.090 IN. FEELER GAUGE BETWEEN THE MICROSWITCH PLUNGER AND LOCK LEVER (1); MOVE THE MICROSWITCH (4) AND ATTACHMENT PLATE (2) FORWARD UNTIL THE PLUNGER IS JUST 'BOTTOMING' (GREEN LIGHT ON).
- 5 TIGHTEN THE BOLTS (3).
- 6 ENSURE THAT SOME PLUNGER MOVEMENT REMAINS WHEN ADJUSTMENT IS FINALISED.
- 7 RE-CHECK THE ADJUSTMENT AFTER HAVING FINALLY REFITTED THE MICROSWITCH AND TIGHTENED THE SECURING BOLTS.




NO PROVISION IS MADE FOR ADJUSTING THE UP MICROSWITCH. IF SATISFACTORY OPERATION IS NOT OBTAINED WHEN THE UP-LOCK HOOK IS CORRECTLY ADJUSTED (SECT.3, CHAP.5), THE SWITCH MUST BE REPLACED WITH ONE OF KNOWN SERVICEABILITY

UP MICROSWITCH

DOOR MICROSWITCH ADJUSTMENT

- 1 JACK THE NOSE [SECT.2, CHAP.4].
- 2 CONNECT A 24-VOLT SUPPLY TO THE EXTERNAL SUPPLY SOCKET.
- 3 DISCONNECT THE PORT DOOR ACTUATING ROD [SECT.3, CHAP.5].
- 4 RAISE THE NOSE WHEEL [SECT.3, CHAP.6]. TAKE CARE THAT DAMAGE IS NOT CAUSED BY THE DISCONNECTED ACTUATING ROD.
- 5 SLACKEN THE TAPPET LOCKNUT (6).
- 6 SCREW TAPPET (5) AWAY FROM THE MICROSWITCH (7) [RED LIGHT ON].
- 7 SCREW TAPPET (5) TOWARDS THE MICROSWITCH (7) UNTIL A DEFINITE CLICK IS HEARD AND GIVE ANOTHER COMPLETE TURN. [RED LIGHT OFF].
- 8 TIGHTEN THE LOCKNUT (6) AND ENSURE THAT SOME PLUNGER MOVEMENT STILL REMAINS.
- 9 RECONNECT THE PORT DOOR ACTUATING ROD.



DOOR MICROSWITCH

Fig. 13. Microswitch setting

raise the port door. Adjust the up-stop pad at the aft end until the door leading-edge is 0.030 in inside the fuselage contour, 'out-of-wind'. With the aft up-stop correctly set, refit the forward up-stop packing removed in operation (5) and shim to suit the 0.030 in condition.

(14) Close both doors and, with pressure applied to the starboard door, check that the doors fit flush with each other and that their leading edges are 0.030 in inside the fuselage contour 'out-of-wind'. If the doors do not fit flush with each other adjust the shims beneath the port door abutment pieces (fig.10 and 11).

Note...

The door up-latch hooks can be released when the doors are locked up by removing the small access panel from below the aft hook in the door skin, and operating the hook tail with key Ref.No.26FZ/95493.

(15) Ensure the door jack is fully extended and fit the starboard door-actuating link; adjust the link if necessary by turning the link eye-end until, with the port door closed manually, the doors fit as in operation (14). Tighten the link locknut and remove the link.

(16) Fit the port door-actuating link and adjust the link if necessary as in operation (15), until the condition described in operation (14) is obtained. Tighten the actuating link locknut and split pin the attachment bolts.

(17) Close the door jack and refit and lock the starboard door actuating link.

(18) Support the undercarriage and remove





Fig.14. Undercarriage removal and assembly (1)







Fig. 15. Undercarriage removal and assembly (2)

the wedge from the sequence valve on the bulkhead. Refit the sequence valve lever trip-screw to the port arm of the door jack crosshead.

(19) Hydraulically lower the undercarriage (Chap. 6).

(20) Refit the landing wheels and mudguards.

(21) Hydraulically raise the undercarriage and check that the doors fit correctly and that the 0.030 in 'out-of-wind' condition is maintained.

(22) Check that the door microswitch functions correctly (fig. 13).

(23) Check all skin gaps around both doors (A.P. 101B-0400-6, Part 1).

(24) Function-test the undercarriage (Chap. 6).

Sequence-valve settings (fig. 12)

24. The sequence-valve lever tappets are adjusted to a 0.15 in dimension measured from the striking face of the tappet and the body of the valve when the lever is in its fully operated position. After any adjustments to the sequence-valve setting a functional check of the undercarriage must be made (Chap. 6).

Note...

The tappet locknut may be fitted on either side of the tappet bracket depending upon the amount of adjustment required.

Microswitch settings (fig. 13)

25. Following any servicing or component replacement which may have affected the

microswitch settings, a thorough check and, if necessary, resetting must be made as detailed in fig. 13.

REMOVAL AND ASSEMBLY

General information

26. The following paragraphs detail the removal and assembly operations for the nose undercarriage and its main components. Items which do not require special instructions for removal or assembly are not included. The sequence of operations for assembling the undercarriage must be adhered to, and checks and subsequent adjustments are to be made at the stated operation.

Undercarriage and undercarriage doors mechanism removal (fig. 14, 15 and 16)

Note...

The undercarriage and doors mechanism can be removed independently of each other.

Undercarriage

27. (1) Jack and trestle the aircraft (Sect. 2, Chap. 4).

(2) Exhaust all hydraulic pressure (Chap. 6).

(3) Remove the three bolts and washers securing each mudguard to its bearing bracket and remove the mudguards.

(4) Remove the six stiffnuts and washers securing each landing wheel to its axle and remove the wheels.

(5) Disconnect the hydraulic fluid pipes from the undercarriage jack and blank off the pipe ends and jack apertures (Chap. 6).

(6) Remove the clamps and blocks from the jack body (fig. 17) and release the hydraulic fluid pipes.

(7) Remove the split pin and slotted nut from the jack piston rod pivot pin and withdraw the pivot pin (fig. 15, detail C).

(8) Remove the split pin, slotted nut and washer from the jack crosspiece pivot between the two channel members on the aft bulkhead, and withdraw the pivot pin (fig. 15, detail E).

Note...

Two plain washers Ref. No. 28W/9419467 are fitted one at each side of the jack pivot between the jack crosspiece and the vertical channel members.

(9) Remove the jack.

(10) Disconnect the electrical cables from the two microswitches on the radius rod knuckle joint (Sect. 5, Chap. 1, Group G) remove the three cable clips from the radius rod tube, and coil and stow the cables in the roof of the wheel well.

(11) Remove the split pin, slotted nut and special washer from the stay link pivot pin on the shock-absorber strut (fig. 15, detail D).

(12) Remove the locating grub screw from the head of the stay link pivot pin and, using an extractor, withdraw the pivot pin. Support the radius rod assembly.

Note...

The radius rod assembly must not be allowed to fall below its normal operating position or its underside will foul and




Fig. 16. Hook release mechanism and door jack removal

damage the single-coil-shaped rigid hydraulic pipe situated on the aft bulkhead immediately below the radius rod upper pivot attachment (fig. 1).

(13) Remove the split pin, slotted nut and special washer from the radius rod upper pivot pin (fig. 14, detail A).

Note...

The head of the pivot pin is a plain nut which is, and must remain, peened.

(14) Slacken the bearing pin retaining grub screw on the starboard shoulder of the radius rod pivot bracket casting (fig. 14, detail A) and, taking the weight of the assembly from the pivot, withdraw the pivot bolt, special washer, and bearing pin. Carefully lower and remove the radius rod/stay link assembly.

(15) Support the undercarriage and remove the split pins, slotted nuts and washers from the four bolts attaching each saddle clamp at the undercarriage main pivot (fig. 15, detail B).

Note...

The heads of the four upper attachment bolts are accessible from inside the pressure cabin.

(16) Withdraw the lower bolts and remove the saddle clamps. Remove the undercarriage.

Door mechanism

28. (1) Remove the split-pins, slotted nuts and special bolts from both ends of each door actuating link and remove the links. Tie the doors in the fully open position.

(2) Remove the four 2 B.A. bolts attaching the mud shield to the hook release lever mechanism box section. Note the number and location of any packing washers between the mud shield and box section.

(3) Disconnect and remove the flexible hydraulic pipes from the door jack. Blank off the exposed pipe ends and jack apertures.

(4) Remove the split pin, slotted nut and special bolt attaching the door jack piston rod to the crosshead.

Note...

It is necessary to remove the undercarriage jack from its aft pivot (para.27) to gain access to the door jack piston rod attachment bolt.

(5) Remove the countersunk headed screws attaching the capping strip to the fuselage skin on the lower forward face of the wheel well aft bulkhead (fig.16).

(6) Remove the split pin, slotted nut and washer from the up-latch bolt. Remove the bolt, taking note of the position of the scalloped head in relation to the locating screw (fig.16).

(7) Remove the two 1/4in bolts and spring washers attaching the bottom of each release lever bracket to the aft bulkhead (fig.16).

(8) Break the wire-locking and remove the two 2 B.A. bolts securing each release lever bracket to the vertical channel stiffeners.

(9) Remove the door jack and release lever mechanism by sliding the complete assembly upwards and out through the top of the vertical channel stiffeners.

Note...

When this operation is made with the undercarriage jack still in situ and disconnected from its aft pivot (para.27), the jack must be strapped clear from the top of the channel stiffeners.

(10) Disconnect the door jack from the hook release lever mechanism by removing the split pin, slotted nut, pivot bolt, washer and distance pieces (fig.16).

(11) Dismantle the hook release levers from their brackets by removing the split pin, slotted nut, washer, Part No.EA1.10.1407 and bolt Part No.EA1.10.3219 from each lever (fig.16).

(12) Remove the thirty-eight 2 B.A. bolts, washers and stiffnuts securing the crosshead roller guides to the aft bulkhead, and remove the guides.

(13) Withdraw the jack crosshead from the slots in the vertical channel stiffeners.

Undercarriage and undercarriage doors mechanism assembly (fig.14, 15 and 16)

General

29. Consideration has been given in the following sequence of operations, to the additional work entailed in fitting replacement components. It will be obvious which operations are not necessary when reassembling original items. Instructions for fitting new undercarriage doors are given in A.P. 101B-0400-6, Part 1. To reassemble the undercarriage and undercarriage door mechanism:

Door mechanism

30. (1) Refit the door jack crosshead between the vertical channel stiffeners on the aft bulkhead, and fit the roller guides over the crosshead rollers using the thirty-eight 2 B.A. bolts, washers and stiffnuts.

(2) Assemble each hook release lever to its bracket using the special-to-type bolt and washer, plain washer, slotted nut and split pin (fig.16).

Note...

The washer Part No.EA1.10.1407 fitted between each lever and bracket may be filed on assembly to obtain free movement of the lever. Protective treatment (A.P. 2662B, Scheme 9.1.2), must be applied to filed surfaces.

(3) Fit the door jack lower pick-up point to the hook release lever mechanism, using the pivot pin Ref.No.26FZ/169 distance pieces, washer, slotted nut and split pin (fig.16).

(4) Slide the complete jack and release lever mechanism assembly from the top to the bottom of the vertical channel members.

(5) Connect the door jack piston rod eye-end to the crosshead, using the bolt, slotted nut and split pin.

(6) Bolt the hook release lever brackets to the aft bulkhead using the four 1/4in bolts and spring washers (fig.16).

(7) Fit the two 2 B.A. bolts to secure each release lever support bracket to the vertical channel stiffeners (fig.16). Tighten and wire-lock the bolt heads together.

(8) Refit the up-latch bolt, ensuring the scalloped head is returned to its original position. Fit the washer, slotted nut and split pin (fig.16).

(9) Refit the capping strip to the lower lip of the aft bulkhead using the counter-sunk screws and stiffnuts (fig.16).

(10) Reconnect the flexible hydraulic fluid pipes to the door jack. Prime and bleed the door jack hydraulic circuit (Chap.6). Wire-lock the pipe unions.

(11) Refit the mud shield over the hook release lever mechanism box section using the four 2 B.A. screws. Replace the packing washers, if any, in their original positions.

Note...

Ensure that hydraulic fluid pipe Part No. OC.101B/10 (fig.1), which runs to the top of the door jack, is positioned in its cleat on the mud shield so as to give the maximum possible clearance between its elbow union and the port wheel tyre during undercarriage retraction.

(12) Reconnect the door-actuating links to the doors using the bolts, slotted nuts and split pins.

Note...

The preceding operations will, upon completion, necessitate a thorough check of the door-operating and latching mechanism adjustment (para.23).

Undercarriage

31. (1) For ease of access, remove the door actuating links and tie back the doors.

(2) Assemble the undercarriage to its main pivot support brackets, taking care to ensure that the pivot shaft bush is properly located by its spigot on both the port and starboard saddle clamp faces (fig.15, detail B). Fit the four bolts, washers, slotted nuts and split pins which secure the removable half of each saddle clamp.

Note...

The heads of the four upper saddle clamp bolts are accessible from inside the pressure cabin.

(3) Refit the radius rod to its upper pivot point by inserting the bearing pin. Slide the pivot pin, with a washer, through the bearing pin and secure with another washer and slotted nut and split pin (fig.14, detail A). Tighten the bearing pin locking grub screw.

Note...

The radius rod assembly must not be allowed to fall below its normal operating position or its underside will foul and damage the single-coil-shaped rigid hydraulic pipe situated on the aft bulkhead immediately below the radius rod upper pivot attachment (fig.1).

(4) Reconnect the stay link to the lugs on the undercarriage strut, using the pivot pin and washer, slotted nut and split pin. Refit and tighten the locating grub screw at the head of the pivot pin (fig.15, detail D).

(5) Reconnect the electrical cables to the two microswitches on the radius rod/stay link knuckle joint. Reclip the cables to the radius rod tube (Sect.5, Chap.1,

Group G) and ensure they will not foul when the undercarriage is retracted.

(6) Assemble the undercarriage jack crosspiece between the aft bulkhead vertical channel stiffeners, inserting the pivot pin from the port side so that its head seats into the locking plate on the outside of the port vertical channel stiffener (fig.15, detail E).

Note...

Ensure that the two washers Ref. No. 28W/9419467 are fitted one at each side of the jack pivot between the jack crosspiece and the vertical channel stiffeners.

(7) Secure the jack crosspiece pivot pin, using the washer, slotted nut and split pin (fig.15, detail E).

(8) Connect the flexible hydraulic fluid pipes to the jack and fit the blocks and clamps to the jack body (fig.17).

Note...

The hydraulic fluid pipes must be so positioned and secured in their blocks that, during the operation of the jack, they will not foul either the door jack crosshead or any other part of the structure (fig.17).

(9) Prime and bleed the jack and pipelines (Chap.6) and fully close the jack, using the aircraft hand pump.

(10) Check, and if necessary adjust, the jack overrides (para.20).

Note...

When hydraulic pressure is first applied, the door jack will move and trip the undercarriage sequence valve, allowing pressure




Fig. 17. Undercarriage jack hydraulic pipes clipping

RESTRICTED

to be transmitted to the undercarriage jack.

(11) Connect the jack piston rod to the radius rod lock lever using the pivot bolt, slotted nut and split pin (*fig.15, detail C*).

(12) Raise the undercarriage fully and adjust the door jack sequence valve (*para.24*).

Note...

When raising the undercarriage door jack with the actuating links disconnected from the doors, an assistant must hold and guide the links to prevent damage to the adjacent hydraulic fluid piping and aircraft structure.

(13) Check, and if necessary adjust, the up-stop pedestals (*para.22*).

(14) Ensure that the up-latch hook is engaging the radius rod latch pin. Adjust if necessary (*para.22*).

(15) Lower the undercarriage and fit the landing wheels and mudguards.

(16) Fit the starboard door-actuating link (*para.30*) and raise the undercarriage. Ensure that the undercarriage and undercarriage door mechanism is operating correctly.

(17) Check, and if necessary adjust, the undercarriage and undercarriage door micro-switches (*fig.13*).

(18) Fit the port door-actuating link (*para.30*) and raise the undercarriage. Check that the doors fit flush with each other and that their leading edges are 0.030 in 'out-of-wind' (*para.23*).

(19) Function-check the operation of the undercarriage (*Chap.6*).

Up-latch mechanism

32. The removal and assembly procedure for the up-latch mechanism is given in *para.22*.

RESTRICTED

Chapter 6 HYDRAULIC SYSTEM

LIST OF CONTENTS

	Para.		Para.		Para.
Introduction	1	Air brakes and flaps GROUND/FLIGHT selector	16	Faults and remedies	32
List of hydraulic components	2	Charging valves	17	REMOVAL AND ASSEMBLY	
DESCRIPTION		SERVICING		General information	33
Hydraulic fluid reservoir	3	General information	18	Reservoir	34
Power circuit	4	Topping up the reservoir	20	Main accumulator	35
Accumulators	5	Draining the reservoir	22	Wheel brakes accumulator	36
Relief valves	6	Filling the system... ..	23	Automatic cut-out valve	37
Hand pump circuit	7	Draining the system	24	Filter	38
Alighting gear circuit	8	Charging the accumulators	25	Hand pump	39
Flaps circuit	9	Filling the pressure gauge pipe lines..	26	Brake relay control valve	
Air brakes circuit	10	Pressure settings and component adjustments...	27	Removal	40
Wheel brakes circuit	12	Automatic cut-out valve setting	28	Assembly	41
Bomb doors circuit..	13	Pressure test of the system... ..	29	Engine-driven pump	
Mechanical emergency selectors...	14	Functioning tests of the services	30	Removal	42
Nose undercarriage GROUND/FLIGHT selector	15	Procedure after functioning tests	31	Assembly	43
				Priming and bleeding..	44

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
Auxiliary hand pump circuit... ..	1	Location of hydraulic components in fuselage	3	Location of hydraulic components in main planes	4
Hydraulic system diagram	2				

Introduction

1. This chapter describes and illustrates the hydraulic system, gives details of the servicing operations and recommends meth-

ods for the removal and assembly of certain components. The system provides power for the operation of the alighting gear, flaps, bomb doors, air brakes and wheel brakes.

The location of the hydraulic units in the fuselage and main planes is illustrated in fig.3 and 4 respectively and the system is illustrated diagrammatically in fig.2

RESTRICTED

List of principal components

2. The components of the system, together with their Air Publication references, are given in the following table:

Component	Description	A.P.	Sect.	Chap.	No.off per A/C	Component	Description	A.P.	Sect.	Chap.	No.off per A/C
Engine-driven pump	Lockheed Mk.9(37J/266) (post Mod.2335)	1803B	2	2	2	Non-return valve (pressurisation)	British Messier, 8557	1803T	13	10	1
Hand pump	Turner, 77C/1275	1803G	3	1	1	Non-return valve	Dowty, 524 Y	1803D	9	58	1
Accumulator	Lockheed, AIR40016	1803B	5	1	2	Pressure-relief valves:					
Brake relay control valve	Dunlop, AC61762 (post Mod.3962)	1803S	7	2	1	Flaps	Dowty, C1034Y, Mk.Q	1803D	9	11	1
Brake units, port	Dunlop, AH9780	2337	3	2	1	Reservoir	Dowty, D2568Y	1803D	9	42	1
starboard	Dunlop, AH9781	2337	3	2	1	Restrictor valves:					
Maxaret anti-skid unit port	Dunlop, AC11516	1803S	8	5	1	Flaps	Dowty, D657Y	1803D	9	21	1
starboard	Dunlop, AC11514	1803S	8	5	1	Main undercarriage doors	Dowty, 03371Y.B.O.1 (post Mod.3937) and Dowty, 06209Y.B.O.1 (post Mod.3937)	1803D	9	41	2
Gyp inflation valve	High Pressure Components Ltd. A58	4303Z	4	6	6	Selector valves:					
Automatic cut-out valve	Lockheed, AIR43634	1803B	10	2	1	Air brakes and flaps	Dowty, 408Y, Mk.BL (post Mod.3937)	1803D	7	13	2
Filter, Vokes	27B/1877(30L/1/7915) or 27B/2620(30L/1/22537)	1803P	5	1	1	Alighting gear	Dowty, 408Y, Mk.BQ (post Mod.3937)	1803D	7	13	1
Hand pump oil filter unit	Dowty, C2254Y	1803D	6	2	1	Bomb doors	Dowty, 408Y, Mk.BR (post Mod.3937)	1803D	7	13	1
Flow dividers	British Messier, 8076/52	1803T	13	1	2	Ground/flight selector valves:					
Gauge relay	Electro Hydraulics, 7391	1803F	14	1	2	Nose undercarriage	Dowty, 01183Y, Mk.B02 (post Mod.3937)	1803D	7	20	1
Jacks:						Air brakes and flaps	Dowty, 408Y, Mk.BN (post Mod.3937)	1803D	7	19	1
Air brakes	British Messier, 5232 (post Mod.3158)	1803T	15	1	2	Sequence valves:					
Bomb doors Forward	Dowty, 1.00522.001 (post Mod.3282)	1803D	10	-	1	Main undercarriage, port	Dowty, D401Y, Mk.L	1803D	9	23	1
Aft	Dowty, 1.00523.001 (post Mod.3282)	1803D	10	-	1	Main undercarriage, starboard	Dowty, D401Y, Mk.M	1803D	9	23	1
Flaps	Dowty, 07016Y.C.O.1 (post Mod.2380)	1803D	10	38	4	Main undercarriage door, port	Dowty, D401Y, Mk.K	1803D	9	23	1
Main undercarriage	Dowty, 07017Y.C.O.1 (post Mod.2380)	1803D	10	36	2	Main undercarriage door, starboard	Dowty, D401Y, Mk.J	1803D	9	23	1
Nose undercarriage	Dowty, 08214Y.C.O.1 (post Mod.2380)	1803D	10	37	1	Nose undercarriage	Dowty, D401Y, Mk.G	1803D	9	23	1
Main and nose undercarriage doors	Dowty, 08246Y.C.O.1 (post Mod.2379)	1803D	10	34	3	Nose undercarriage doors	Dowty, D401Y, Mk.H	1803D	9	23	1
Non-return valve	U.M.C.704, 1/4 in. B.S.P.	1803P	4	2	2	Thermal relief valve	Dowty, C4603Y, Mk.E	1803D	9	55	13
Non-return valve	27W/17, U.C.M.706, 3/8 in. B.S.P. (post Mod.3368)	1803P	4	2	4	Thermal relief valve	Dowty, C8697Y, Mk.A (post Mod.3749)	1803D	9	-	2
						Transfer valve	Dowty, C6790Y, Mk.A	1803D	9	67	2
						Solenoid-operated valve (air brakes)	British Messier, 6330	1803T	14	1	1
						Pressure gauge	6A/2693, Mk.14LL	1275A	15	6	4

RESTRICTED

DESCRIPTION

Hydraulic fluid reservoir

3. The reservoir is mounted just to the rear of the pressure bulkhead, against the upper starboard fuselage skin. It is oval in shape and is inclined at an angle of approximately 45 deg. The filler neck is on the side and is accessible through a Dzus fastened panel in the fuselage skin. The engine-driven pump suction pipe-line is taken from a stack pipe in the bottom of the reservoir, thus providing a reserve of fluid for the hand pump. The suction pipe for the hand pump is taken from a point slightly higher up, although, due to the reservoir being inclined, this is its lowest point. A pipe-line from the pressure bulkhead ducts cabin pressure to the reservoir, and a non-return valve in this pipe-line maintains a maximum pressure difference of $\frac{1}{2}$ lb/in². between the cabin and reservoir pressures when the cabin pressure system is in operation. A pressure relief valve, situated in a pipe-line connecting with the tank above fluid level, blows off at 12 to 17 lb/in²., re-seating itself when the pressure falls to 8 lb/in²., this blow-off line is led to atmosphere through the bottom of the fuselage.

Power circuit

4. Power is supplied by two continuously-running hydraulic pumps, one mounted on each engine accessory gearbox. The pumps draw fluid from the reservoir, through a filter located on the forward face of frame 13 bulkhead, and deliver it under pressure to the four rotary control valves and the brake relay control valve. A non-return valve is fitted in the pipe-line on the pressure side of each pump and the flexible pipes from each pump are fitted with self-sealing couplings. *(These couplings may be broken to enable hydraulic servicing trolleys to be*

connected into the circuit for ground testing purposes). An automatic cut-out valve, located in the starboard main plane leading-edge, is fitted in the pressure line and connects to the return line, providing an idling circuit and diverting the pump delivery back to the reservoir between operational demands; it is set to cut out when the accumulator pressure reaches $2700 + 50$ lb/in². and cuts in at a minimum pressure of $2200 - 0$ lb/in². A gauge mounted on the starboard instrument panel gives indication of the pressure in the power circuit.

Note...

This pressure gauge must not be used for circuit testing.

Accumulators

5. The main hydraulic accumulator is mounted inboard of rib 1 in the starboard main plane leading edge, and is connected to the power circuit by a branch pipe; it maintains a reserve of power, prevents hammering of the cut-out, and provides initial power for the movement of the jacks when a service is selected. The charging valve and pressure gauge for the main accumulator is situated on the forward diaphragm of the starboard wheel well. A second hydraulic accumulator, located on the aft face of frame 12 bulkhead, is connected to the pressure line of the wheel brakes circuit to facilitate smooth braking and maintain an independent reserve of power for application of the brakes. The brakes accumulator pressure gauge and charging valve is positioned in the bomb bay on the aft face of the forward bulkhead.

Relief valves

6. Thermal relief valves, suitably posi-

tioned in the circuits, open when, due to temperature variation, pressure in the line of a service increases to 3350 to 3500 lb/in².; these valves reseat when the pressure falls to 3100 lb/in². (*min.*). Mod.3749 introduces an additional thermal relief valve set to relieve at 3100 lb/in². which is interposed between the sequence valve and the transfer valve of each main undercarriage circuit; to avoid premature pressure relief of the system and to ensure satisfactory functioning of this valve, a modified brake relay control valve (*Mod.3962*) incorporating a pressure relief valve relieving at a pressure of 3500 ± 100 lb/in². is installed in the wheel brakes system.

Hand pump circuit

7. The hand pump, situated at the starboard side of the pilot's seat, will operate the alighting gear, bomb doors and wheel brakes after the appropriate selection has been made. A ground selector and non-return valve in the pressure line normally isolates the air brakes and flaps from the hand pump circuit, but provision is made for operating these services by the hand pump during ground servicing operations. The hand pump draws fluid from the reservoir through a filter mounted on the aft face of frame 12 bulkhead, and delivers it under pressure to the service selected. In the event of hydraulic failure due to loss of fluid in the system, sufficient fluid is retained in the reservoir (*para.3*) to operate the bomb doors and the alighting gear.

Alighting gear circuit

8. Operation of the alighting gear is controlled by two pushbuttons marked UP and DOWN, which are mounted on the sloping panel on the port side of the instrument

RESTRICTED

flying panel. Provision is made on the UP selector button for an override UP selection, this is accomplished by rotating the knobbed sleeve of the pushbutton clockwise as far as possible, and then depressing the pushbutton. Undercarriage DOWN emergency selection is made by pulling the black-and-yellow painted handle protruding above the alighting gear sloping panel (*para.14*). When a pushbutton is depressed, the selector valve, located in the roof of the bomb bay, is operated by an electrical actuator, and fluid is delivered to the jacks operating the alighting gear and alighting gear doors. Fluid already in the nose undercarriage and door jacks is returned via the selector valve and return line to the reservoir. Fluid in the main undercarriage jack down circuits, is similarly returned to the reservoir, but return flow fluid in the jack up circuits is passed through transfer valves and sequence valves to the down side of the jacks. The transfer valves, therefore, by supplementing the delivery of fluid to the down side of the jacks, assist in reducing the time required to complete the lowering. This transfer is especially effective where an emergency lowering has to be carried out as the extra fluid provided reduces the number of strokes required on the hand pump. If 'out-of-sequence' retraction occurs due to a defective valve the hydraulic lock so caused can be overcome by the relieving of the thermal relief valve fitted between the sequence valve and the transfer valve (*post Mod.3749*) (*para.6*), thus ensuring that the undercarriage can still be lowered in an emergency. Incorporated in each transfer valve is a thermal relief valve which will, under abnormal temperature or pressure changes, relieve from the 'up' to the 'down' line; the transfer valves are fully described in A.P.1803D, Vol.1, Book 3,

Sect.9. The main undercarriage units are raised and their doors closed by the retraction of the operating jacks, whilst the nose-wheel unit is raised and its doors closed by the extension of the operating jacks. Sequence valves incorporated in the circuits ensure that the door and wheel unit circuits operate in their proper sequence, and restrictor valves in these circuits give smooth operation to all movements. A GROUND/FLIGHT selector (*para.15*) is connected into the nose-wheel circuits to enable nose-wheel retraction for ground servicing.

Flaps circuit

9. The flaps are operated by a two position selector switch mounted on the alighting gear sloping panel and marked UP and DOWN. A guard on either side of the switch is provided with holes, into which the flap safety pip-pin can be inserted. The switch controls the electrically-actuated selector valve which directs fluid, under pressure, to either end of the double-ended jacks. Fluid displaced by the movement of the jacks is returned, via the selector valve and return line, to the reservoir. To ensure progressively equal movement of both the port and starboard flaps, a two-way restrictor is incorporated in the down line of the circuit.

Air brakes circuit

10. This circuit is controlled by a three position selector switch mounted on the top of the control column, and the selector valve is operated by an electric actuator. Fluid under pressure is delivered through the selector valve to the jacks operating the air brakes, and fluid displaced by the movement of the jacks is returned via the selector valve, to the reservoir. Flow dividers are incorporated in both lines of the circuit to

ensure synchronization of the two operating jacks.

11. Three positions, IN, OUT and MID, may be selected for the air brakes, these positions being indicated on the selector switch label. The first two positions are obtained by the selector valve directing the fluid to the appropriate end of the jacks, the displaced fluid returning to the reservoir. To obtain the MID position, two microswitches mounted on a bracket attached to the body of the starboard jack, an electrical relay, and a solenoid-operated valve, located in the out pressure line, are employed; the microswitches are operated by cams mounted on the piston-rod of the starboard jack. When MID position is selected from IN, the selector valve is operated as for OUT, and fluid is directed, under pressure, to the piston-rod end of the jack, causing it to retract and extend the drag channels out of the main plane. When half-travel position has been reached, the cams on the piston-rod engage the microswitches, which complete an electrical circuit and cause the solenoid-operated valve to close and the selector valve to be reversed, directing pressure fluid to the piston end of the jack. The solenoid-operated valve, being closed, prevents displacement of the fluid from the piston-rod end of the jack and so forms a hydraulic lock. Movement of the selector switch to OUT from MID reverses the selector valve and opens the solenoid-operated valve, permitting the jack to retract fully and further extend the drag channels out of the main plane. Selection of MID from OUT operates the selector valve to extend the jacks, and withdraws the drag channels to the half-travel position when, as for outward travel, completion of the electrical circuit causes the solenoid-operated valve to close

RESTRICTED

and prevent, by the hydraulic lock so formed, further movement. When IN is selected from MID, the solenoid-operated valve opens and permits the flow of displaced fluid from the jack, which extends to the outward limit, withdrawing the drag channels into the main planes. Selection of IN from OUT or vice versa, isolates the microswitch circuit and permits a normal flow of fluid through the system.

Wheel brakes circuit

12. The wheel brakes are applied by movement of the hand lever, mounted on the control column and connected by a Bowden cable to a relay control valve situated beneath the pilot's raised floor-structure. From the relay control valve, pressure, proportionate to the movement of the brake lever, is supplied to the brake units. To enable the pressure actuating each brake to be varied when taxiing or towing the aircraft, the relay valve is mechanically linked to the rudder pedals. The brake relay control valve reduces the system pressure of 2700 lb/in². to 1500 ± 150 lb/in². for braking purposes. In the event of excessive deceleration of the aircraft on landing, automatic Maxaret control units, mounted on the brake torque plates, release the pressure in the brakes and close the brake pressure supply until the wheels regain speed. If, after landing, bouncing occurs after the brakes have been applied, the brake pressure is released in a similar manner for a maximum period of 3.5 seconds. A branch pipe from the pressure pipeline is connected through a gauge relay to a pressure gauge on the pilot's starboard instrument panel, and to a charging valve mounted on the forward face of frame 1 (*post Mod.3513*) (*para.17*).

Bomb doors circuit

13. A two-position selector switch on the

pilot's console, marked 'OPEN' and 'CLOSED', operates the selector valve through the medium of an electrical actuator. Fluid under pressure is delivered through the selector valve to the two jacks operating the bomb doors, and fluid displaced by the movement of the jacks is returned, via the selector valve and return line, to the reservoir.

Mechanical emergency selectors

14. Mechanical emergency selectors are provided for operating the alighting gear and bomb door circuits in the event of an electrical fault rendering the actuators inoperative (*Sect.3, Chap.11*). The alighting gear control is situated above the pilot's alighting gear control panel, and the bomb doors control lever is mounted on the port wall of the cabin. Both controls are linked, by cable, directly to levers on their respective selectors and, when operated, mechanically move the selectors to the alighting gear DOWN and bomb doors OPEN positions, enabling the movement to be completed either by the engine-driven pumps, if the system is otherwise serviceable or, alternatively, by the hand pump.

Nose undercarriage GROUND/FLIGHT selector

15. A manually operated GROUND/FLIGHT selector valve is mounted on the forward face of frame 13 bulkhead on the port side of the battery bay; it is positioned in the up and down lines of the nose undercarriage circuit and has an independent connection to the hand pump delivery pipeline. The selector has two positions, GROUND and FLIGHT; it is normally wire-locked in the FLIGHT position. When in the GROUND position it enables the nose undercarriage unit to be retracted, by operation of the

hand pump, independently of the main undercarriage.

Air brakes and flaps GROUND/FLIGHT selector

16. To enable the air brakes and flaps to be operated by the hand pump during servicing operations, a non-return valve and manual selector, operable only when the aircraft is on the ground, are positioned in the main delivery line, to which the hand pump is connected. The selector, mounted in the roof of the bomb bay, has two positions, FLIGHT and GROUND; it is normally wire-locked in the FLIGHT position. In this position the air brakes and flaps circuits are isolated from the hand pump by a non-return valve; movement of the selector to GROUND opens a line which by-passes the non-return valve and permits the air-brakes and flaps to be operated by the hand pump after the appropriate selection has been made.

Charging valves

17. Six A.58 Gyp inflation valves are installed in the system for three different purposes; two valves, situated adjacent to each accumulator (*para.5*), are provided for charging the accumulators with air pressure; two more, one on each main undercarriage leg fairing, are provided as test points for wheel brake pressure testing, when a Turner adapter is employed (*para.30*). A further valve is installed in the main pressure gauge pipeline and is mounted on the forward face of frame 1 in the pressure cabin; this valve is used for priming the pressure gauge and its pipeline (*para.26*). The wheel brakes pressure gauge also has, on the introduction of Mod.3513, a valve installed in its pipeline to serve a similar purpose; it is situated adjacent to the main gauge valve on frame 1.

SERVICING

WARNING

The relevant safety precautions detailed on the LETHAL WARNING marker card must always be observed before entering the cabin or performing any operations upon the aircraft

Note...

1. After the removal of any component or if the system has been drained or partly drained, the engine-driven pumps must be primed (para.44) and the complete system bled (para.23).

2. During the reassembly of system components, new bonded seals, AGS. 1186, are to be fitted to all banjo connections. Care must be taken not to over-tighten banjo bolts (A.P. 1803A, Vol.1, Sect.2, Chap.1, Table 1).

General information

18. Scrupulous cleanliness is essential during all servicing operations on hydraulic mechanisms. When dismantling a component, which should be done, when possible, in a dust-free atmosphere, the parts removed should be laid out in a suitable drip tray.

Note...

Hydraulic fluid has a deleterious effect on paint, rubber, electric cables, etc., and care must be taken to avoid spilling it on such parts.

19. Because the presence of a foreign body, no matter how minute, in a component, might not only shorten the life of the equipment, but might also result in a serious failure, benches, tools and test rigs should be kept spotlessly clean. All pipe ends and unions exposed during servicing operations should be blanked off to prevent the entry of dirt. Containers used for holding fluid or for the reception of drained fluid

should be kept perfectly clean; after a container has been cleaned it should be rinsed with a small quantity of fluid which should then be discarded. Always work with clean hands, clean tools and on a clean bench.

Topping up the reservoir

20. The reservoir should be topped up with the alighting gear selected DOWN, the bomb doors OPEN and with the accumulator hydraulic pressures exhausted. The fluid in the main accumulator may be exhausted by operating either the flaps selector switch or the bomb doors selector switch until no further movement can be obtained on the flaps or bomb doors. Operate the wheel brakes to exhaust the brakes accumulator pressure. The reservoir must be topped up to the maximum possible level with fluid, OM-15; a drainpipe is provided for fluid spilt through overfilling.

21. Before topping up the reservoir, check the air pressure in the accumulators; the gauges are situated, one in the starboard undercarriage well (main) and the other on the aft face of the bomb bay forward bulkhead (brakes); the pressure should be as given in the Leading Particulars when the accumulators are exhausted of fluid pressure. If the pressure is high it is an indication that fluid is still contained in the accumulator, and if low the accumulator should be examined and, if it is undamaged and showing no signs of leakage, charged up to the correct pressure. The accumulator charging valves are adjacent to the accumulator pressure gauges.

Draining the reservoir

22. The reservoir should be drained with the alighting gear and flaps DOWN, the air brakes IN, and the bomb doors OPEN.

(1) Connect an external electrical supply (Sect.5, Chap.1).

(2) Exhaust the hydraulic pressure as detailed in para.20.

(3) Select bomb doors CLOSED to exhaust any residual pressure.

(4) Select bomb doors OPEN. THIS IS IMPORTANT.

(5) Remove the hand pump suction line banjo connection at the reservoir, and drain the reservoir at this point.

Note...

Overtightening of the banjo bolt may result in stripping the threads. A leak at this point is to be rectified by fitting washers AGS.1186C, not by increasing the torque loading on the banjo bolt.

Filling the system

23. To fill the system:-

(1) Jack and trestle the aircraft (Sect.2, Chap.4).

(2) Examine the gauze filter in the neck of the reservoir; clean it if necessary. Fill the reservoir to the maximum possible level with fluid OM-15 (para.21); a drainpipe is provided for fluid spilt through overfilling.

(3) Break the locking wire and move the air brakes and flaps, GROUND/FLIGHT selector (para.16), to GROUND.

(4) Using the hand pump, operate each hydraulic service several times in the following order: air brakes, flaps, alighting gear, and bomb doors, bleeding air through the respective jack bleed screws and topping up the reservoir until the system is full.

Draining the system

24. The bulk of the fluid can be drained

from the system by uncoupling unions or connections at the lowest point of individual pipe runs, depending upon the attitude of the aircraft. Providing the aircraft is suitably trestled or jacked with the wheels clear of the ground, draining may be facilitated by operation of the jacks using the hand pump.

Charging the accumulators

25. The main accumulator charging valve is located in the starboard undercarriage well and the wheel brakes accumulator charging valve on the aft face of the bomb bay forward bulkhead; the pressure gauges, recording the accumulator pressures, are adjacent to the charging valves. The accumulators are to be inflated to the pressures given in the Leading Particulars, with all hydraulic pressure exhausted (*para.20*).

Filling the pressure gauge pipe lines

26. The pipelines to the main and wheel brakes pressure gauges are to be filled with fluid OM-15. A Gyp Type A.58 inflation valve, located on the forward face of frame 1 starboard side, is provided to fill the main pressure gauge line, and a similar inflation valve, introduced by Mod.3513 and located adjacent to the main gauge inflation valve, provides the wheel brakes pressure gauge line with the same facility. On aircraft not embodying Mod.3513 the wheel brakes gauge line is filled at the gauge pipe union. The following items of equipment are required:

- (1) Portable hydraulic hand pump rig with a 0-3500 lb/in². pressure gauge (*Ref.No. 4G/3029*).
- (2) Charging valve adapter (*Ref.No.4G/6246*).
- (3) Gauge pipe-union adapter (*local manu-*

facture) (*for brake pressure gauge line pre Mod. 3513*).

Before commencing this operation the main and wheel brake accumulators are to be exhausted of hydraulic pressure as instructed in *para.20*. To fill the gauge pipelines with fluid:

Main pressure gauge pipeline, and wheel brakes pressure gauge pipeline (post Mod. 3513)

(1) The following operations apply to both the main and the wheel brakes pressure gauge pipelines:

(a) Remove the locking wire, and slacken the priming plug of the gauge relay: located between frames 15 and 16 on the port wall of the bomb bay for the main pressure gauge, and between frames 1 and 2 beneath the nose ramp, for the wheel brakes pressure gauge.

(b) Remove the screwed cap of the charging valve at frame 1 and attach the flexible pipe, with adapter, from the hand pump rig, to which the pressure gauge is fitted.

(c) Commence to pump slowly to fill the pipeline and continue until the oil flows from the gauge relay priming point clearly and free from air. Tighten and wire-lock the gauge relay priming plug.

(d) Slacken the pipe union at the aircraft pressure gauge. Operate the pump until clear fluid flows from the pipe union, and tighten the union.

(e) Build up a pressure of 2500 lb/in². and note that the aircraft and rig pressure gauges each register this pressure.

(f) Gradually slacken the pipe union at

the aircraft pressure gauge and allow the pressure to fall to zero. Tighten and wire-lock the pipe union.

(g) Remove the adapter from the charging valve, and replace the screwed cap.

Brake pressure gauge line (pre Mod.3513)

(2) The following operations are applicable only to aircraft not embodying Mod. 3513:

(a) Remove the pipe union from the wheel brake pressure gauge and attach the flexible pipe, with adapter, from the hand pump rig to the gauge pipeline.

(b) Remove the locking wire from the priming plug on the gauge relay located in the pipeline between frames 1 and 2.

(c) Build up a pressure of 2500 lb/in². and slacken the relay priming plug. Continue to pump until fluid flows from the priming point clearly and free from air. Tighten and wire-lock the gauge relay priming plug.

(d) Remove the adapter from the pipe union, and reconnect and wire-lock the union to the pressure gauge.

Pressure setting and component adjustments

27. Pressure settings of all pressure relief and thermal relief valves are given in Leading Particulars: the adjustment of all the hydraulic components is described in the appropriate Air Publication Vol.1, listed in *para.2*.

Automatic cut-out valve setting

28. The cut-out valve (*Lockheed AIR 43634*) is to be set to cut out at 2700 $\begin{matrix} + 50 \\ - 0 \end{matrix}$ lb/in². Final adjustment may be carried

out with the valve fitted in the aircraft but prior to installation preliminary setting and testing is necessary. Using a static test rig (Ref.No.4G/3430), with hydraulic fluid, OM-15, adjust the cut-out and cut-in pressures as follows:

Preliminary adjustment

(1) Blank off the system connection of the valve and couple the pump connection to the test rig.

(2) Build up pressure gradually with a smooth action of the hand pump and note the pressure at which fluid commences to escape from the reservoir connection; this is the cut-out pressure.

(3) Remove the blank from the system connection to allow the fluid trapped behind the non-return valve to escape, then replace the blank.

(4) Adjust the pressure setting by turning the adjusting screw clockwise to increase, or anti-clockwise to reduce the pressure. Test and adjust alternately until 2700 + 50 lb/in². is obtained.
- 0

Leakage test

(1) Disconnect the test rig from the pump connection and couple to the system connection of the valve.

(2) Apply a pressure of 2700 lb/in²., seepage from either pump or reservoir connections must not exceed 10 c.c. per minute.

(3) Disconnect the coupling from the system connection and couple to the pump connection.

(4) Apply a pressure of 2200 lb/in². seepage from the reservoir connection must not exceed 10 c.c. per minute.

(5) Disconnect the coupling from the pump connection and couple to the reservoir connection.

(6) Blank off the pump and system connections and apply a pressure of 250 lb/in²., there must be no leakage.

Final adjustments in the aircraft

(1) Install the valve and couple to the aircraft system.

(2) Trestle the aircraft (Sect.2, Chap.4) and couple a hydraulic servicing trolley fitted with a Lockheed Mk.9 hydraulic pump to the system.

(3) Fill the system (para.23) and inflate the accumulators to the correct pressure (para.25).

(4) Start the servicing trolley, and note that when the valve cuts out, the main accumulator pressure gauge registers 2700

+ 50 lb/in². If the cut-out pressure is in-
- 0 correct, turn the adjusting screw in the appropriate direction until the correct setting is obtained.

(5) Operate the flaps to discharge the accumulator and cause the valve to cut-in. Note that the cut-in pressure is at or above the minimum of 2200 lb/in². If not, the valve must be considered unserviceable.

(6) When the correct settings are obtained wire-lock the connections and repeat the test several times to ensure that the settings remain constant.

IMPORTANT

On satisfactory completion of these tests, MOD.CAN.1265 is to be painted conspicuously on the valve body. It is essential that replacement valves are adjusted and marked in accordance with the foregoing instruction before final installation.




Fig. 1. Auxiliary hand pump circuit

Pressure test of the system

29. To pressure test the hydraulic system:

Note...

The reservoir must be kept topped-up to the correct level during all bleeding operations. The aircraft hand pump must be used for operation and bleeding of the jacks and wheel brakes. The hand pump of the auxiliary rig must be used only for building up pressure.

- (1) Jack and trestle the aircraft (Sect.2, Chap.4).
- (2) Connect an external electrical supply (Sect.5, Chap.1).
- (3) Uncouple the hand pump pressure pipe at the hand pump and connect an auxiliary hand pump circuit into the pipe and the hand pump union (fig.1).
- (4) Uncouple the delivery pipe at the flap pressure relief valve, adjacent to the flap selector in the roof of the bomb bay, and blank off the pipe and the valve.
- (5) Charge the main and wheel brakes accumulators (para.25).
- (6) Move the air brakes and flaps GROUND/FLIGHT selector (para.16) to GROUND.
- (7) Fill the reservoir with hydraulic fluid OM-15.
- (8) Prime and bleed the aircraft hand pump.
- (9) With the alighting gear selected DOWN, the nose undercarriage GROUND/FLIGHT selector at FLIGHT, the bomb doors selector at OPEN, the flaps selector at DOWN, the air brakes selector at IN, and the wheel

brakes parked, use the aircraft hand pump to fill the system and jacks with fluid until pressure commences to build up.

(10) Check the lengths of the bomb door jacks (Chap.1), the air brakes and flap jacks (Chap.4), and the alighting gear jacks and sequence valve settings (Chap.5).

(11) Top up the reservoir and replace the tank cap.

IMPORTANT

The tank cap must be fitted during all the following tests; on no account must it be removed with the alighting gear UP.

(12) Without altering any system selection (9), bleed all jack pipelines and brake units at the bleed valves or suitable connections on individual jacks.

(13) Build up a preliminary test pressure of 2000 to 2500 lb/in². with the auxiliary hand pump and check the pressure lines for leaks and security. Hold this pressure for a few minutes and then release.

(14) Remove the nose undercarriage door actuating links and tie back the doors in the open position.

(15) Select alighting gear UP and, using the aircraft hand pump, retract the alighting gear as far as is possible to leave the jack bleed valves accessible. Bleed the main and nose undercarriage jacks.

(16) Using the aircraft hand pump fully retract the alighting gear, disconnecting the main undercarriage door jacks from the doors as soon as they commence to retract.

(17) Retract the main undercarriage door

jacks and extend the nose undercarriage door jack and bleed all three jacks when they have completed the 'doors-closed' stroke.

(18) Select bomb doors CLOSED, and using the aircraft hand pump, partially close the bomb doors. Bleed both bomb door jacks.

(19) Fully close the bomb doors. Ensure, by checking that there is a 0.2 in. ± 0.06 in. clearance between the metal faces of the edges of the doors, and that the jacks are fully at the end of their stroke and are not straining the bomb doors. The method of adjusting the bomb doors is given in Chap.1.

(20) Select flaps UP and, using the aircraft hand pump, partially raise the flaps and bleed the jacks. If the flaps are not assembled to the mechanism, operate the jacks to the end of their stroke before bleeding.

(21) Fully raise the flaps and ensure that they are not under any strain when bearing against the main plane trailing edges (Chap.4).

(22) Select the air brakes OUT and, using the aircraft hand pump, operate the air brake jacks to the end of their stroke and bleed the jacks.

(23) Test the brake relay control unit:

- (a) *Pre Mod.3962* – Disconnect the brake control unit and, using the auxiliary hand pump, apply a test pressure of 2900 lb/in². Retain this pressure and check the pressure drop; it must not exceed 150 lb/in². during the first fifteen minutes. Hold the pressure for a further fifteen minutes and then release. Reconnect the brake control

unit and repeat the test at a pressure of 2480 lb/in².

(b) *Post Mod.3962* — Using the auxiliary hand pump apply a test pressure of 2900 lb/in². Retain this pressure and check the pressure drop; it must not exceed 150 lb/in². during the first fifteen minutes. Hold the pressure for a further fifteen minutes and release. The brake differential unit is not to be disturbed.

(24) Lower the flaps, select air brakes IN, open the bomb doors, and lower the alighting gear, recoupling the main undercarriage door jacks before the jacks are fully extended (*Chap.5*). Reconnect the nose undercarriage doors actuating links.

(25) Repeat the pressure test (23).

(26) Disconnect the auxiliary hand pump circuit and recouple the hand pump pressure pipe to the hand pump, and the delivery pipe to the flap pressure relief valve.

(27) Move the air brakes and flaps GROUND/FLIGHT selector to FLIGHT, and wire-lock.

(28) Disconnect the external electrical supply.

Functioning test of the services

30. With the aircraft jacked and trestled (*Sect.2, Chap.4*), and using two Mk.2A, or 2B, or 2C hydraulic servicing trolleys fitted with Lockheed Mk.9 engine-driven pumps, connected to the Avery couplings in the suction and delivery lines of the aircraft engine-driven pumps, test the functioning of the services as follows:

Note...

The air brakes and flaps GROUND/FLIGHT selector in the roof of the bomb bay must be in the FLIGHT position for all power tests.

(1) Connect an external electrical supply (*Sect.5, Chap.1*).

(2) Test the power circuit using both servicing trolleys, and check the operation of the automatic cut-out valve by operating the bomb doors, air brakes and flaps. The automatic cut-out valve should cut-in at 2200 lb/in². and cut-out when the system pressure has built up to 2700 lb/in². $\begin{matrix} + 50 \\ - 0 \end{matrix}$ lb/in².

(3) *Alighting gear*

(a) Using both servicing trolleys retract and lower the alighting gear five times and check that the mechanical down locks, up locks, and door locks, function correctly (*Chap.5*). The time taken to raise and lower the alighting gear must not exceed fourteen and eight seconds respectively.

(b) Stop the servicing trolley, release all hydraulic pressure and raise the alighting gear using the aircraft hand pump.

(c) Operate the alighting gear emergency control and lower the alighting gear using the aircraft hand pump. Ensure that the nose undercarriage door hooks engage centrally and check the operation of the main doors and shoot bolts (*Chap.5*).

IMPORTANT

To prevent oscillation when lowering the alighting gear by the hand pump, station a man at each main alighting gear door with instructions to hold the doors fully

open to ensure that the sequence valves controlling the lowering of the alighting gear remain open for returning fluid.

(d) Reset the selector actuator and the emergency control (*Chap.11*), set the nose undercarriage GROUND/FLIGHT selector to GROUND and retract and lower the nose undercarriage with the aircraft hand pump. Set the selector to FLIGHT and wire-lock.

(e) Using the port servicing trolley only, retract and lower the alighting gear once.

(f) Repeat operation (e) using the starboard servicing trolley only.

(g) Using both servicing trolleys retract and lower the alighting gear three times.

(h) Check that the alighting gear indicating lights at both stations function correctly (*Sect.5, Chap.1, Group G*).

(j) On aircraft embodying Mod.3749, test each main undercarriage individually as follows:

(i) Remove the door jack attachment bolt at the piston end (*Chap.5*).

(ii) Remove the bolt which connects the door check links to the door (*Chap.5*).

(iii) Using both servicing trolleys retract the main undercarriage ensuring that the door jack piston-rod is clear of surrounding mechanisms and structure.

(iv) Fold the check links back to remove the pressure from the sequence valve plunger.

(v) With the servicing trolleys still running, select alighting gear DOWN and pump vigorously on the aircraft hand pump until the undercarriage is locked down.

(vi) Partially retract the undercarriage and reconnect the door check links and door jack (*Chap.5*).

(vii) Using both servicing trolleys retract and lower the alighting gear.

(4) Bomb doors

(a) Using both servicing trolleys close and open the bomb doors and check that the warning lamp on the pilot's console is on when the doors are open. The time for the bomb doors to close and open must not exceed six and five seconds respectively.

(b) Using each servicing trolley independently, close and open the bomb doors.

(c) Stop the servicing trolleys, release the pressure and, using the aircraft hand pump, close the bomb doors. Operate the bomb doors emergency control and open the bomb doors using the aircraft hand pump.

(d) Reset the bomb doors selector actuator and emergency control (*Chap.11*). Using both servicing trolleys, close and open the bomb doors.

(5) Flaps

(a) Using both servicing trolleys raise and lower the flaps four times. Check the operation of the flaps position indicator and check the synchronisation of the port and starboard flaps. The time taken to

either raise or lower the flaps must be between 15 and 19 seconds.

(b) Using each servicing trolley independently, raise and lower the flaps.

(6) Air brakes

(a) Using both servicing trolleys operate the air brakes OUT, MID and IN three times, checking the synchronisation of the port and starboard brakes. The time taken to either extend or retract the air brakes must be between a half and two-and-a-half seconds.

Note...

In the MID position the dimensional difference between the port and starboard drag channels must not exceed 0.50 in.

(b) Using each servicing trolley independently, operate the air brakes as in operation (a).

(7) Wheel brakes

(a) Stop the servicing trolleys and attach a Turner adapter (*Ref.No. 4G/6246*) with a pressure gauge (*Ref.No. 4G/3028*) to the wheel brake test connections in the hydraulic pipes to the brakes.

(b) Start the servicing trolleys and, with the wheel brakes off, check that the wheels are free to rotate.

(c) Apply the brakes progressively and, with the rudder bars central, check that at intermediate positions the pressures at each brake do not vary considerably from each other and that when the brakes are fully applied there is a steady pressure of 1500 ± 150 lb/in². at each brake.

- 0

Note...

For all pressures from zero to 1000 lb/in². the pressure gauge readings must be within 100 lb/in². of each other and for pressures from 1000 lb/in². to 1500 lb/in². the readings must be within 150 lb/in². of each other.

(d) Apply full port rudder and check that the pressure in the port brake remains at 1500 ± 150 lb/in². and the pressure in the starboard brake falls to zero.

(e) Apply full starboard rudder and check that the pressure in the starboard brake returns to 1500 ± 150 lb/in². and the pressure in the port brake falls to zero. Release the brakes.

(f) Repeat operation (c).

(g) Release the brake lever and check that the pressure at both brakes falls to zero.

(h) Stop the servicing trolleys and remove the Turner adapter and pressure gauge from both wheel brake test connections.

(j) Fully apply the brake lever and operate the parking lever; this should operate easily with one hand.

(8) Air brakes and flaps GROUND/FLIGHT selector

(a) Place the selector in the GROUND position and ensure that all hydraulic services can be operated by the aircraft hand pump.

(b) Move the selector back to FLIGHT and check that the air brakes and flaps

cannot be operated by the hand pump. Wire-lock the selector valve at FLIGHT.

(9) *Nose undercarriage GROUND/FLIGHT selector*

(a) Place the selector in the GROUND position and ensure only the nosewheel retracts when the hand pump is operated.

(b) Move the selector back to FLIGHT and check that both the nose and main undercarriage retracts when the hand pump is operated. Wire the selector valve at FLIGHT.

Procedure after functioning tests

31. After the functioning tests are satisfactorily completed the following operations must be carried out:

- (1) Disconnect the external electrical supply.
- (2) Disconnect the servicing trolleys and connect the aircraft engine-driven pumps at the Avery couplings.
- (3) Bleed the pumps and top-up the reservoir as instructed in para.20.
- (4) Re-seal the emergency release cables as instructed in Chap.8.

(5) Ensure that the air brakes and flaps, and the nose undercarriage, ground selectors are wire-locked in the FLIGHT position with new wire.

(6) Re-lock and seal the undercarriage and bomb door emergency release handles as instructed in Chap.11.

Faults and remedies

32. The more common hydraulic faults and their remedies are listed in the following table; faults in individual components are covered in the appropriate A.P.1803, Vol.1.

Fault	Possible Cause	Remedy
(1) Engine-driven pump and hand pump fail to operate the system	No fluid in the system Leakage in the system	Refill the system Correct the leak and refill the system
(2) Engine-driven pump drive shears	Pump dry	Change the engine-driven pump (Lockheed Mk.9 (37J/266))
	Excessive pressure due to foreign matter in system	Drain the system and replenish with clean fluid
	Hammering of the automatic cut-out	Renew the automatic cut-out (Lockheed AIR.41158)
(3) All services inoperative by engine-driven pumps but services can be operated by the hand pump	Engine-driven pump drives sheared	(See (2))
	Foreign matter in the filter By-pass valve in the automatic cut-out leaking	Remove the filter and clean it Renew the automatic cut-out (see (2))
(4) Spongy action on hand pump	Air in particular service	Bleed the affected service and test
	Faulty non-return valves	Renew the affected non-return valves (U.M.C.704)
(5) All services inoperative by hand pump	Hand pump worn or damaged	Renew the hand pump (Turner, 77C/1275)
(6) Flaps droop, or spring back from the lowered position	Jack piston-rod glands leaking	Renew the jack (Dowty, 07016Y.C.O.2)
	Non-return valve in rotary control valve leaking	Renew the rotary control valve (Dowty, 408Y, Mk.BL)
	Air in system	Bleed the system and test

(continued)

Fault	Possible Cause	Remedy
(7) Flaps return to original position after moving	Jack piston rod glands leaking Leaking rotary control valve Leaking thermal relief valve	Renew the jack (see (6)) Renew the rotary control valve (see (6)) Renew the thermal relief valve (Dowty, C4603Y, Mk.E)
(8) No movement of flaps upon selection, accumulator pressure correct	Actuator fuse blown	Renew relevant fuse (Sect.5, Chap.1)
(9) Flaps on one side move in advance of those on the other side	Foreign matter in restrictor valve and pressure relief valve Air in system	Remove the restrictor valve and pressure relief valve, and clean them Bleed the system and test
(10) Bomb doors droop	Jack piston rod glands leaking Non-return valve in rotary control valve leaking Air in system	Renew the jack (Dowty, 1,00522 or 3.001) Renew the rotary control valve (Dowty, 408Y, Mk.BR) Bleed the system and test
(11) No movement of bomb doors upon selection, with accumulator pressure correct	Actuator fuse blown	Renew relevant fuse (Sect.5, Chap.1)
(12) Alighting gear doors droop	Door jack piston rod glands leaking Non-return valve in rotary control valve leaking Air in system Incorrect setting of door jack sequence valves	Renew the affected jack (Dowty, 08246Y, C.O.2) Renew the rotary control valve (Dowty, 408Y, Mk.BQ) Bleed the system and test Reset affected sequence valve
(13) No movement of alighting gear upon selection, with accumulator pressure correct	Actuator fuse blown	Renew relevant fuse (Sect.5, Chap.1)
(14) Wheel brakes inoperative, with accumulator pressure correct	Broken Bowden cable Slack Bowden cable	Renew the Bowden cable Release the cable and adjust
(15) Wheel brakes remain on after parking brake lever is released	Tight Bowden cable Frayed Bowden cable	Release the Bowden cable and adjust Renew the Bowden cable
(16) Air brakes inoperative upon selection, with accumulator pressure correct	Actuator fuse blown	Renew relevant fuse (Sect.5, Chap.1)
(17) Air brake drag channels protrude from main plane surfaces	Jack piston rod glands leaking Non-return valve in rotary control valve leaking Air in system	Renew the jack (British Messier, 5232) Renew the rotary control valve (Dowty, 408Y, Mk.BL) Bleed the system and test

(continued)

RESTRICTED

Fault	Possible Cause	Remedy
(18) Hammering of the automatic cut-out	Air in the system Leaking non-return valve Broken secondary spring Leaking rotary control valve Restriction in pressure line	Bleed the system and test Renew the non-return valve or automatic cut-out Renew the automatic cut-out (refer to (2)) Renew the affected rotary control valve Flush the pressure line - renew if damaged
(19) Slow movement of services	Insufficient air pressure in the appropriate accumulator due to leakage at inflation point	Stop the leak, re-inflate and test
(20) Sluggish movement of a particular service with correct accumulator pressure	Air in system	Bleed the system and test

Note...
Fault (20) may be apparent only in flight, or with one engine at idling rev/min., and not when using the servicing trolleys.

REMOVAL AND ASSEMBLY

General information

33. Methods of removing certain items from the system are given in the following paragraphs. Generally, the assembly sequence is the reverse of removal, but where there are special reassembly features they are specifically mentioned.

Note...

1. After removal of any component, or if the system has been drained or partly drained, the engine-driven pumps must be primed (para.44) and the complete system bled (para.23).

2. When reassembling hydraulic pipes Pt.No.EA3.73.799 and EA3.73.803 to the transfer valve in the port wheel bay, ensure that they are not crossed. The two pipes should run parallel throughout their length.

3. During the reassembly of system components, new bonded seals, AGS.1186, are to be fitted to all banjo connections. Care must be taken not to over-

tighten banjo bolts (A.P.1803A, Vol.1, Sect.2, Chap.1, Table 1).

Reservoir

34. To remove the reservoir:-

(1) Remove the equipment bay hatch (Sect.2, Chap.4).

(2) Drain the reservoir (para.22).

(3) Disconnect all the remaining pipes from the reservoir, and blank off all exposed pipe ends and apertures.

(4) Remove the locking wire from the trunnion tension rods and unscrew the tension rods. This operation will release the straps retaining the reservoir in position. Remove the reservoir.

Note...

1. When assembling the reservoir, it is important that pieces of hard felt, 3/4 in. x 1/8 in. x 26 in. long, are attached to the reservoir with rubber-resin cement at the retaining strap position.

2. Care must be taken not to over-tighten the hand pump suction pipe banjo bolt when reassembling. Leakage at this point should be rectified by fitting washers AGS.1186C, not by increasing the torque loading on the banjo bolt.

Main accumulator

35. To remove the main accumulator:-

(1) Exhaust all hydraulic pressure from the system (para.20).

(2) Remove the inboard access panel from the upper surface of the starboard main plane leading edge (Sect.2, Chap.4).

(3) Release the air pressure by depressing the Schrader unit in the charging valve.

(4) Disconnect and blank off the air charging pipeline and the hydraulic pipeline at the accumulator.

(5) Remove the bolts on the two retaining straps and remove the accumulator.

Note...

When assembling the accumulator it is important that pieces of hard felt, 3/4 in. x 3/8 in. x 10 in. long, are attached to the accumulator with rubber-resin cement at the retaining strap positions.

Wheel brakes accumulator

36. Removal and assembly operations for this accumulator are the same as for the main accumulator (para.35) except that it is removed through the battery compartment door on the port side of the fuselage.

Automatic cut-out valve

37. To remove the automatic cut-out valve:

- (1) Exhaust the system of hydraulic pressure (para.20).
- (2) Remove the inboard access panel from the upper surface of the starboard main plane leading edge (Sect.2, Chap.4).
- (3) Disconnect and blank off the pressure pipelines and the return to reservoir pipeline.
- (4) Remove the three retaining bolts and remove the cut-out valve.

Filter

38. To remove the filter:

- (1) Exhaust the system of hydraulic pressure (para.20).
- (2) Drain the reservoir (para.22).
- (3) Disconnect and blank off the inlet and outlet pipes.
- (4) Remove the two retaining bolts attaching the filter to the channel-section on the forward face of frame 13 bulkhead.

- (5) Lift the filter out of the retaining ring and remove the filter.

Hand pump

39. To remove the hand pump:

- (1) Exhaust the system of hydraulic pressure (para.20).
- (2) Disconnect and blank off the pressure and suction pipes.
- (3) Remove the three attachment bolts in the side of the pump and remove the pump.

Brake relay control valve*Removal*

40. To remove the brake relay control valve:

- (1) Exhaust the system of hydraulic pressure (para.20).
- (2) Drain the system (para.24).
- (3) Remove the access panels from the cabin floor.
- (4) Disconnect the four pipelines at the control unit.
- (5) Disconnect the Bowden cable.
- (6) Disconnect the operating lever from the rudder lever.
- (7) Remove the bolts securing the control unit to the cabin floor, and remove the unit.

Assembly

41. Before fitting the brake relay control valve to the aircraft, blow out the pipelines:

- (1) Bolt the control valve to the cabin floor, and connect the four pipelines and the Bowden cable to their respective points on the control valve.

- (2) With the rudder bar central, connect the operating rod to the control valve and adjust the rod until the pointer on the control valve is central.

- (3) Fit Turner inflation adapters and gauges to the connections in the hydraulic pipes to the brakes (para.30(7)).

- (4) Ensure that the main hydraulic pressure is 2700 lb/in².

- (5) With the aircraft jacked and trestled (Sect.2, Chap.4), and with the rudder bar central, apply the hand brake lever and adjust the Bowden cable to give a brake pressure of 1500 ± 150 lb/in². on the Turner gauges. Release the brakes and ensure that the pressure falls to zero and that the wheels are free to turn.

- (6) Apply full port rudder and check the pressures registered on the Turner gauges; they should be:

Port — 1500 ± 150 lb/in².

Starboard — Zero, with the wheel free to turn.

- (7) Apply full starboard rudder and repeat the check in operation (6), the pressures should be:

Starboard — 1500 ± 150 lb/in².

Port — Zero, with the wheel free to turn.

- (8) Check the pressures at various brake lever settings with the rudder bar central.

For partly applied brakes at pressures up to 1000 lb/in², there should not be more than 100 lb/in² difference between port and starboard gauge readings. For partly applied brakes at pressures exceeding 1000 lb/in², there should not be more than 150 lb/in² difference between gauge readings.

Note...

The brake lever must not be snatched on, as high and incorrect readings may result.

(9) Remove the Turner inflation adapters and gauges.

Note...

Should any fluctuation in the pressures occur at the Turner gauges it is an indication that there is a leak past the relay control valve and the valve is unserviceable.

Engine-driven pump

Removal

42. (1) Exhaust the system of hydraulic pressure (para.20).

(2) Remove the appropriate access panels (Sect.2, Chap.4).

(3) Drain the hydraulic fluid from the pump.

(4) Disconnect and blank off the hydraulic

pipes to the pump, and blank off the pump apertures.

(5) Disconnect the pump drain pipe.

(6) Remove the six nuts and spring washers securing the pump to the accessory gearbox, and remove the pump.

(7) Remove the driving quill from the gearbox driveshaft, attach it to the blanking cover, and blank off the gearbox aperture.

Assembly

43. To assemble the pump to the accessory gearbox:

(1) Remove the blanking cover from the gearbox aperture, and retain the gasket.

(2) Lightly smear the pump driving quill with grease XG-277 and insert into the gearbox driveshaft.

Note...

Driving quills are supplied with the accessories gearbox.

(3) Fit the gasket to the pump seating flange on the gearbox.

(4) Prime the pump with hydraulic fluid OM-15.

(5) Offer up the pump to the gearbox, line up the splines and fit the pump over the

securing studs on the gearbox flange, ensuring that the bleed screw is at the top of the pump.

(6) Fit and tighten the six nuts and spring washers.

(7) Remove the blanks from the hydraulic pipes and pump apertures, and fit the pipes and apertures.

(8) Connect the drain pipe to the pump, and wire-lock the union.

(9) Bleed the pump (para.44).

Priming and bleeding

44. (1) Top up the reservoir with hydraulic fluid OM-15.

(2) Slacken the bleed screw on the pump.

(3) Build up a pressure of 1 to 2 lb/in² in the reservoir.

Note...

To pressurize the reservoir, a cap of local manufacture incorporating a Schrader valve and 0-5 lb/in² pressure gauge, may be used. Pressure should be built up slowly to 1 or 2 lb/in².

(4) Allow fluid to flow from the bleed vent until it flows freely and free from air.

(5) Tighten and wire-lock the bleed screw.




Fig.2. Hydraulic system diagram

RESTRICTED




Fig. 3. Location of hydraulic components in fuselage

RESTRICTED




Fig.4. Location of hydraulic components in main planes

RESTRICTED

Chapter 8

AIR CONDITIONING, VENTILATED SUIT AND DE-MISTING SYSTEMS

(Completely revised)

LIST OF CONTENTS

	Chapter
AIR CONDITIONING SYSTEM	8A
AIR VENTILATED SUIT SYSTEM (post Mod.3243 – B (I) Mk.6)	
aircraft only)	8B
DE-MISTING SYSTEM	8C

Note... A detailed list of contents will be found at the beginning of each chapter

Chapter 8A AIR CONDITIONING SYSTEM

LIST OF CONTENTS

	Para.		Para.		Para.
Introduction	1	Diffusers	22	Constant-flow valves	
List of principal components	2	Pilot's cold-air supply	23	Port main plane	39
DESCRIPTION		Cabin sealing... ..	24	Bomb/flare bay	40
General information	3	SERVICING		Mixing valve actuator	
Supply	4	Test points	25	Removal	41
Cabin temperature control	5	Pressure test of pipe lines	26	Assembly	42
Bombsight computer air supply	7	Functional test with test rig	27	Mixing valve	
Camera and gun pack heating	8	Cabin pressure tests		Removal	43
Hot-air (gate) valves	9	With test rig	28	Assembly	44
Constant-flow valves	10	With engines	29	Air coolers	
Mixing valve	11	Test after major repair	30	Primary air cooler	45
Air coolers	12	Sealing		Secondary air cooler	46
Cold-air unit	13	Structural	31	Cold-air unit	
Relief valve	14	Emergency release cables... ..	32	Removal	47
Non-return valves	15	Constant-flow valves	33	Oil priming and testing	48
Water extractor	16	Pressure controller and combined		Installation... ..	49
Pressure controller	17	valve unit	34	Pressure controller	50
Combined valve unit	18	Cold-air unit	35	Combined valve unit	
Pressure warning system	19	Mixing valve	36	Removal	51
Cabin air distribution		Temperature control valve	37	Assembly	52
General	20	REMOVAL AND ASSEMBLY		Relief valve	53
Punkah louvres	21	General information	38		

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
Air conditioning system	1	Constant-flow valve	4	Thrustair-type temperature control valve	7
Air conditioning system diagram... ..	2	Mixing valve	5	Pressure cabin sealing... ..	8
Air conditioning system - port inner		Pilot's cold-air supply... ..	6	Pressure bulkhead sealing	9
wing leading edge	3				




Fig. 1. Air conditioning system

RESTRICTED

Introduction

1. This chapter describes and illustrates the air-conditioning system and its associated bomb computer and gun pack or camera heating systems; it gives details of servicing

operations, and recommends methods for the removal and assembly of certain components. The ventilated suit and de-misting systems are described and illustrated separately in

Chapters 8B and 8C respectively. The location of the units in the air-conditioning system is illustrated in fig.1 and fig.3; the system is shown diagrammatically in fig.2.

List of principal components

2. Details of the components of the system, together with their Air Publication references, where applicable, are given in the following table:

LIST OF PRINCIPAL COMPONENTS IN THE AIR CONDITIONING SYSTEM

Ref.No.	Component	Description	A.P.	Sect.	Chap.
27UA/555	Water extractor	Godfrey, Type W.E.30, Mk.2B	4340	9	2
27KD/3	Pressure controller	Normalair, 500326	1275A	20	2
27KD/2836	Combined valve unit	Normalair, 527060 (post Mod.3955)	1275A	20	5
27KD/7	Non-return valve	Normalair, 500457	4340	6	4
27UA/492	Primary cooler	Marston, D106/8A	4340	8	1
27UA/491	Secondary cooler	Marston, D106/6A	4340	8	1
27UA/382	Cold-air unit	Godfrey, A.C.R.E.9, Mk.10E	4340	2	4
27V/4282	Hot-air (gate) valve	Teddington, FKH/A/16	4303E	2	11
5W/4002	Hot-air (gate) valve actuator	English Electric, Type 234	4343D	16	12
27KD/5	Constant-flow valve	Normalair, 502090 or NAYR/105/11205	4340	6	2
27V/4281	Mixing valve	Teddington, FKH/A/15	4303E	2	—
5W/409	Actuator, mixing valve	English Electric, Type 233	4343D	12	12
27KD/510	Constant-flow valve	Normalair, 510930	4340	6	2
6A/2133	Desynn transmitter	—	1275A	16	2
26FZ/31672	Valve, temperature control	English Electric, Pt.No. EA2.75.669	—	—	—
27G/2091	Filter (bombsight computer)	Dunlop, A.Ç.O.1268	—	—	—
27F/2119	Cock, air control (bombsight air supply)	Vickers, D253	—	—	—

RESTRICTED




Fig. 2. Air conditioning system diagram

RESTRICTED

DESCRIPTION

General information

3. Air for pressurizing and conditioning the cabin, for camera or gun pack heating (*B(1)Mk.6 aircraft*), and for operating the bombsight computer, is supplied from a tapping on both engine compressors. The cabin pressure is controlled by a pressure controller and combined valve unit, and the temperature by a two-way mixing valve. The pressure and temperature of the air for heating the camera or gun pack is not controllable by the pilot but is governed by a temperature-control valve situated in each system; the gun pack temperature-control valve is not a part of the aircraft system and is integral with the gun pack heating arrangement. The pressure controller, in conjunction with the combined valve unit, controls the cabin pressure above 10000 ft.; cabin pressure and atmospheric pressure below this height are approximately the same. The temperature of the cabin is controlled by a cabin heat control switch mounted on the pilot's starboard instrument panel. The cabin is insulated by fibre-glass blanketing affixed to the interior of the fuselage skin.

Supply (*fig.2*)

4. Hot air from both engine compressors passes through non-return valves and electrically-actuated gate valves into a common main duct which runs laterally through the main planes and fuselage. Four tee-piece tappings along the length of this duct supply various air conditioning and aircraft services. In the port inner wing equipment compartment a pipe branches from the main duct to the hot air side of the

mixing valve, and a similar branch pipe in the starboard wing is fed into the inlet side of the primary cooler. At the point where the main duct runs across the bomb/flare bay roof two more tappings are made; one runs aft to either the rear camera or gun pack (*para.8*), and a smaller diameter pipeline supplies the operating pressure for the bombsight computer (*para.7*). A test point connection is provided at each end of the main duct just after the gate valve.

Cabin temperature control

5. The temperature of the delivery to the cabin is governed by a mixing valve, electrically controlled by the cabin heat switch mounted on the pilot's starboard instrument panel. By suitable operation of this switch air is delivered hot, cooled, or cold. Movement of the switch to HOT directs hot air from the engine compressors through the mixing valve along the common delivery duct to the cabin, the air passing through a constant-flow valve, water extractor and non-return valve. By moving the switch to COLD the hot air from the engine compressors is directed through the primary cooler in the starboard main plane leading edge to the mixing valve in the port main plane leading edge, the cold side of which allows the partly-cooled air to pass to the compressor side of the cold-air unit (C.A.U.). On leaving the compressor side of the C.A.U. the air passes through the secondary cooler to the turbine stage of the C.A.U. and then, very cold, through the common delivery duct to the cabin. A relief valve, with outlet to the secondary cooler outlet duct, upon which it is mounted, is incorporated in the line to

prevent build-up of pressure in the cold-air unit. The cabin heat control switch can be operated to give any desired temperature; it has a centre OFF position and, when in use, should be held to the HOT or COLD position, whichever is desired, until the required temperature is obtained and then returned to OFF. The position of the mixing valve is registered on the cabin heat control indicator mounted adjacent to the control switch on the starboard instrument panel.

Note...

(1) *No air will be supplied to the cabin unless the gate-valve switches are set to ON.*

(2) *In the event of a fault developing in the supply from an engine, or if an engine fails or is shut off, the gate-valve switch of that engine should be set to OFF.*

6. From the constant-flow valve in the port main plane leading edge the common delivery duct passes into the fuselage and then forward to the water extractor at frame 11, and on through the non-return valve at the pressure bulkhead. In the pressure cabin, the duct branches into three smaller ducts at frame 3 to supply the pilot's, navigator's and air bomber's stations with conditioned air through punkah louvres, diffusers and fish tails (*para.20*).

Bombsight computer air supply

7. The air pressure for operating the bomb sight computer is drawn from the main hot air duct where it passes through the bomb/flare bay. The small bore pipeline runs




Fig. 3. Air conditioning system – port inner wing leading edge

RESTRICTED

forward, through an air filter mounted on the aft face of frame 12A, along the port side of the cabin to the forward station where the supply is controlled by an ON-OFF cock mounted just aft of frame B.

Camera and gun pack heating

8. From a tee-piece tapping in the main hot-air duct, the F.24 camera, or gun pack, heating pipe runs aft, through a constant flow valve, along the starboard roof of the bomb/flare bay to a flexible hose at frame 29. When air is supplied to the camera diffuser, the flexible hose connects with a pipe passing through frame 29 bulkhead to a thrust-at-type temperature control valve (*para.37*) mounted in the camera bay which governs the bay temperature. Air for gun pack heating is provided by disconnecting the camera flexible hose at frame 29 and connecting it to the heating pipe on the gun pack, the temperature of which is governed by an integral solenoid operated valve (*Sect. 7, Chap.3*). The heating pipe not in use is sealed with a suitable blanking plug, sealing ring and clamp.

Hot-air (gate) valves

9. An electrically-actuated gate-valve is mounted on the inboard face of each engine rib in the air supply duct from the engine compressors. Operation of the gate valve actuator to ON lifts a carbon slide clear of the air flow and allows air to pass into the system. The gate valves can be operated independently by two toggle switches mounted on the pilot's starboard instrument panel; their purpose is to shut off air from either engine should a fault occur or if an engine fails.

Constant-flow valves (*fig.4*)

10. Two constant-flow valves, each incorporating a removable filter, provide the

required constant flow of air from the engine compressors to the cabin and camera bay or gun pack, for a pre-determined altitude and temperature, irrespective of engine speed. Air entering the valve passes through the filter and into the open end of the support tube, and then between the flow controller and the support tube, leaving the valve at its outlet to continue along the ducting. The valves are fully described in A.P.4340, Vol.1, Sect.6, and their location is shown in *fig.1*.

Mixing valve (*fig.5*)

11. The mixing valve, installed in the port inner wing leading edge equipment compartment, consists of a light-alloy body housing two carbon slide valves each with an inlet port and both discharging through separate outlets. The halves are operated simultaneously by two crankshafts geared together, and are so arranged that when one slide is open, the other is fully closed, both valves being half-way open at the mid-position of the unit. The movement of each slide valve from open to closed is effected by 180 deg. rotation of its crankshaft. Hot air is led to one inlet port and cooled air to the other, the two air streams being entirely separate within the valve. The hot-air stream is directed to the cabin duct without any cooling, and the cooled-air stream from the primary cooler is further cooled in the cold-air unit and the secondary cooler. Mixing occurs downstream of the cold-air unit, and temperature control is effected by varying the air flow through the cooling system and the cooling system by-pass. The valve is operated by an electrical actuator controlled by the cabin heat switch mounted on the starboard instrument panel; the switch is spring-loaded to the off position, and must be held to COLD or HOT until the desired position of the mixing valve is attained.

The valve setting is indicated to the pilot by a Desynn transmitter connected to the valve by an adjustable tie-rod, and registering on the cabin heat indicator also on the starboard instrument panel.

Air coolers

12. The primary and secondary air coolers are installed in the starboard and port main planes respectively, between the fuselage and ribs 1. Air enters through the intakes in the leading edge skinning, cools the air passing through the units, and exhausts to atmosphere beneath the main planes.

Cold-air unit

13. The cold-air unit, installed in the leading edge of the port main plane, consists of a turbine driving a centrifugal compressor, both being mounted on a common shaft and operating in separate chambers. The motive power for the unit is supplied by air passing through the mixing valve from the engine compressors. The unit is inoperative when the mixing valve is in the full HOT position. The unit is fully described in A.P.4340, Vol.1, Sect.2, Mod.2316 re-routes the cold air unit oil sump breather pipe, from the generator exhaust duct, to a waste oil collector bottle mounted on the aft face of the forward wheel-well diaphragm.

Relief valve

14. A relief valve, discharging to atmosphere via the secondary cooler outlet duct, is incorporated in the line between the compressor stage of the cold-air unit, and the secondary cooler. It is mounted on top of, and vents into, the secondary cooler, operating to relieve undue pressure at the cold-air unit.

Non-return valves

15. A spring-loaded non-return valve is

incorporated in the system forward of the water extractor on the pressure bulkhead to prevent any back flow of air through the supply duct in the event of failure of the cold-air unit or a leak in the system. A non-return valve is also fitted between each gate valve and engine to prevent back flow in the event of a single engine failure.

Water extractor

16. A water extractor is installed in the supply duct on the wall of the port equipment compartment to prevent condensation. A drain from the extractor has an outlet in the port side of the fuselage. A full description of the extractor is given in A.P.4340, Vol.1, Sect.9.

Pressure controller

17. The pressure controller, mounted on




Fig. 4. Constant-flow valve

the starboard side of the pressure bulkhead, maintains, in conjunction with the combined valve unit, a cabin pressure greater than atmospheric at altitudes above 10000 ft., the difference between these two pressures being termed the differential pressure. The unit regulates the pressure in the cabin by adjusting the opening of the discharge valve in the combined valve unit, thus regulating the discharge of air from the cabin. The controller is designed to initiate cabin pressurizing at approximately 10000 ft. and to build up and maintain a maximum differential pressure of 3.5 lb/in² at 25000 ft. and above. Below 10000 ft. cabin pressure and atmospheric pressure are approximately the same. A warning horn is operated by the pressure controller in the event of a serious drop in pressure.

Combined valve unit

18. The combined valve unit, mounted on the rear face of the pressure bulkhead, regulates the cabin pressure by controlling the rate at which air is allowed to escape from the cabin. Two safety valves are incorporated in the unit and, should the cabin pressure rise to more than 4.2 lb/in², both valves will open automatically, allowing the excess pressure to vent to atmosphere. An inwards relief valve limits to a safe value the amount of negative differential pressure which may occur in certain circumstances, such as rapid aircraft descent following engine failure.

Pressure warning system

19. A warning horn, operated by the pressure controller, and mounted on the starboard side of the cabin aft of the entrance door, gives audible warning if the cabin pressure should fall to a dangerous level. A warning horn override switch is situated on the starboard instrument panel.

Cabin air distribution

General

20. From the common delivery duct running along the port wall of the pressure cabin, conditioned air is ducted through branch pipes to louvres and diffusers positioned at various points about the cabin. In addition to providing conditioned air to selected areas, the combined mass of air from the louvres and diffusers also maintains the cabin pressure at a predetermined level at all altitudes.

Punkah louvres

21. From the common delivery duct within the cabin, conditioned air is delivered to various parts of the cabin through branch pipes (*para.6*), some of which terminate in punkah louvres; these are controlled by the crew members and may be shut off when not required for use. The pilot's station has three punkah louvres which are located on the rudder pedal guard, the alighting gear control panel and the coaming tube above the entrance door. Mod.3518 introduces to B(I)Mk.6 aircraft an additional punkah louvre at the pilot's station, positioned on the coaming cross tube to starboard of the ejection seat. The navigator's station is provided with one punkah louvre mounted on the port side of the cabin above the chart table.

Diffusers

22. The pilot's and the navigator's stations are each provided with a fish-tail shaped diffuser, located forward of the respective crew member's feet, and a diffuser is fitted to the coaming tube to port of the pilot and also to the inboard edge of the navigator's instrument panel. These latter diffusers may be controlled to deliver either a jet or a diffused flow of air into the cabin by rotation of the diffuser top, they cannot be shut off. A third fish-tail diffuser directs air to the

sighting panel of the perspex nose fairing.

Pilot's cold-air supply (fig.6)

23. A supply of cold air to the pilot is provided via a small air-scoop on the front fuselage, immediately forward of the canopy, to a punkah louvre at the side of the instrument-flying panel. A simple non-return valve

in the ducting prevents air from the pressurized cabin blowing back through the system; the supply may be cut off at the punkah louvre. Any moisture that accumulates in the system is drained away through a drain hole in the fuselage side.

Cabin sealing (fig.8)

24. The entrance door, pilot's canopy,

crew escape hatch, and the joint between the plastic nose and the fuselage are sealed by rubber sealing strips and bushes. All electrical connections, controls, etc., passing through the pressure bulkhead are also sealed, typical examples of which are given in fig.9. The sealing of the joints in the cabin structure is made with Peratol and Bostik sealing compounds.

SERVICING

◀ **Note...**

(1) With the exception of SILASTIC hose joints, the standard procedure for remaking hose joints must be adopted (A.P.1464D, Vol.1, Part 2, Sect.3, Chap.8). To remake the SILASTIC hose joints, proceed as follows:-

(a) Renew the SILASTIC hose.

(b) Ensure that the gap between the ends of the pipes to be connected is between 0.10 in and 0.50 in.

(c) Fit the hose clips using clamping rings Pt.No.EEAS.66/14 beneath each clip.

(d) Fully tighten the hose clips and ensure that the gap between the ends of the clamping ring beneath each clip is between 0.05 in and 0.07 in.

(2) Whenever box type lagging is removed, care must be taken on reassembly that the jubilee clips securing the lagging are not overtightened to the extent of crushing the lagging. It is considered sat-

isfactory that the clips are tightened to the stage where they can just be moved by hand.

(3) To prevent seizure of metal-to-metal couplings molybdenum disulphide anti-seize compound ZX-28 must be applied to the threads of the unions on reassembly. ▶

Test points

25. A test point, positioned in the main hot air duct from the engine, is located in each inner main plane leading edge; either point may be used for pressure testing the pipe lines of the system. A third test point, and a pressure gauge connection is fitted on the rear face of the pressure bulkhead and is accessible from the nose undercarriage well; these are used when pressure testing the cabin.

Pressure test of pipe lines

26. To pressure test the system pipelines:

(1) Disconnect and securely blank off the following pipe connections:

(a) Mixing valve to cold-air unit at the cold-air unit inlet.

(b) Mixing valve to constant-flow valve (leading edge equipment bay) at the constant-flow valve inlet.

(c) Camera/gunpack heating pipe at inlet of constant-flow valve in bomb/flare bay.

(d) Ventilated suit tee-piece tapping in bomb/flare bay.

(e) Both engine compressor delivery pipes at the engine compressor.

(2) Ensure the bombsight computer air supply cock in the aircraft nose is in the OFF position.

(3) Connect an electrical supply to the external supply socket (Sect.2, Chap.2) and set the mixing valve midway between HOT and COLD.

(4) Open both engine gate valves.

(5) Connect a test rig incorporating a 0-100 lb/in² pressure gauge to the test point in either the port or starboard leading edge equipment bay.

RESTRICTED




Fig. 5. Mixing valve

RESTRICTED




Fig. 6. Pilot's cold-air supply

- (6) Start the test rig and raise the pressure in the system to 80 lb/in².
- (7) Stop the test rig and check the time taken for the pressure to drop to 30 lb/in². This must not be less than 10 mins.
- (8) Check all joints and pipelines for leaks using a Teepol (Ref.No.33C/1129) and water solution.
- (9) Release the pressure and remove all traces of Teepol solution.
- (10) Disconnect the test rig and refit the blank to the test point.

(11) Remove all blanks, and reconnect the pipes disconnected in operation (1). Wire-lock all pipe unions.

(12) Close the engine gate valves and return the mixing valve to the fully HOT position.

Functional test with test rig

27. To carry out a functional test of the system using a ground test rig:

- (1) Ensure that the cold-air unit is filled with oil OEP.71 to the MAX mark on the dipstick.
- (2) Disconnect the main supply pipe at the starboard engine compressor and connect a ground test rig, incorporating a 0-100 lb/in² pressure gauge, to the supply pipe.
- (3) Connect an electrical supply to the external supply socket (Sect.2, Chap.2).
- (4) Select fully HOT at the cabin heat control switch, and move the starboard engine gate valve switch to ON. Both these switches are situated on the starboard instrument panel.
- (5) Start the test rig to give a pressure of 80 lb/in² to the system, and check that air is flowing into the cabin at all distribution outlets, i.e. louvres, diffusers, bomb computer, and ventilated suit cocks.
- (6) Disconnect the mixing valve to cold-air unit pipe, and check that there is no air flow.
- (7) Re-connect the mixing valve to cold-air unit pipe.

(8) Remove the test rig, re-connect the supply pipe to the engine compressor, and connect the test rig to the delivery pipe at the port engine compressor.

(9) Select fully COLD at the cabin heat control switch, and switch the port engine gate valve switch ON and the starboard to OFF.

(10) Start the test rig and carry out the flow test (operation (5)).

(11) Visually check that the cold-air unit is running by disconnecting the pipe from the cold-air unit outlet. Re-connect the pipe.

(12) Remove the test rig, and re-connect the delivery pipe at the port engine compressor.


(13) Select fully HOT at the cabin heat control switch, and move the port engine gate valve switch to OFF.

(14) Disconnect the external electrical supply.

Cabin pressure tests

WARNING

- (1) Pressure must not exceed 3.5 lb/in² with personnel inside the cabin.
- (2) Only personnel certified by the Station or Unit Medical Officer as fit for Servicing duties inside pressure cabins, are permitted inside the pressurized portion of an aircraft during tests at ground level. Personnel with colds must have further medical approval.
- (3) At no time is the cabin pressure to exceed 4.7 lb/in².



TEST PROCEDURE

TO TEST THE VALVE OPERATION:-

- (1) FULLY IMMERSE THE THRUSTAT (2) INTO WATER AT A TEMPERATURE OF 60 ± 1 DEG. C.
- (2) CHECK THAT THE VALVE CLOSES FULLY IN NOT MORE THAN 90 SECONDS.
- (3) REMOVE THE VALVE FROM THE WATER AND CHECK THAT THE PISTON RETURNS TO THE FULLY OPEN POSITION. THE CHECK MAY BE EXPEDITED BY SUBJECTING THE VALVE TO A CURRENT OF COLD AIR, OR IMMERSING THE THRUSTAT IN COLD WATER.

NOTE...
THE THRUSTAT MUST NOT BE ALLOWED TO COME INTO CONTACT WITH A NAKED FLAME.

- (4) REFIT THE VALVE IN THE AIRCRAFT AND LOCK THE COUPLING UNIONS.

TO ADJUST THE VALVE PORT OPENING:-

- (1) REMOVE THE VALVE FROM THE AIRCRAFT BY UNSCREWING THE TWO COUPLING UNIONS (5).
- (2) UNLOCK AND REMOVE THE VALVE BASE (1) CONTAINING THE THRUSTAT (2).
- (3) SLACKEN THE ADJUSTING SCREW LOCK NUT (3).
- (4) TURN THE ADJUSTING SCREW (4) UNTIL THE VALVE PORT OPENING IS 0.30 IN.

NOTE...
IT WILL BE NECESSARY TO REFIT THE VALVE BASE AND THRUSTAT AFTER EACH ADJUSTMENT UNTIL THE CORRECT PORT OPENING IS OBTAINED.

- (5) LOCK THE ADJUSTING SCREW.
- (6) REFIT AND WIRE-LOCK THE VALVE BASE AND THRUSTAT.

Fig. 7. Thrust-at-type temperature control valve

RESTRICTED

(4) On completion of a pressure test, the cabin entrance door must not be opened until the pressure gauge reads zero and two minutes have elapsed to allow any residual pressure to escape.

Note...

During pressure tests, each control passing through the pressure bulkhead must be operated very slowly, at least three times, over its entire range.

With test rig

28. The pressure cabin should be tested in the following manner, using a Mk.1C pressure cabin testing trolley (Ref.No. 4F/1714) instructions for the operation of which are given in A.P.2306G, Vol.1. This test must always be carried out whenever a canopy, windows, etc. have been removed and replaced.

(1) Ensure that the canopy and nose demisting systems units are installed and connected up.

(2) Remove the static vent plugs.

(3) Remove the blanking cap from the pressure gauge connection on the rear face of the pressure bulkhead, accessible from the nose undercarriage well, and fit a 0 to 10 lb/in² pressure gauge to the connection.

(4) Ensure that the air supply adapter (Ref.No. 4F/1807) is fitted to the delivery hose of the ground testing trolley, and connect the hose to the ground test connection on the rear face of the pressure bulkhead; access is through the nose undercarriage well.

(5) Disconnect the pipe connecting the

combined valve unit to the pressure controller and blank off the pressure controller pipe only, using plug (Ref.No.26FZ/95270).

(6) With the entrance door and direct vision window closed, pressurize cabin and record the pressure at which the safety valve 'cracks' open. This pressure is to be 4.2 $\begin{smallmatrix} +0 \\ -0.25 \end{smallmatrix}$ lb/in², with an airflow of 5 lbs/min.

(7) Check cabin structure for any signs of permanent distortion and, using a Teepol (Ref.No.33C/1129) and water solution, make a note of any leaks.

(8) Stop the testing trolley and, with a stop watch, note the time taken for the pressure to drop from 3.5 to 1.75 lb/in². This must not be less than 70 sec.

Note...

If the time taken is less than 70 sec., rectify the leaks noted in operation (7), repeat the pressure test.

(9) Remove the delivery hose and pressure gauge from the pressure bulkhead ground test connection and refit the blanking caps.

(10) Remove the blanking plug from the pressure controller pipe and refit and wire-lock the pipe to the combined valve unit.

(11) Check the operation of the warning horn. *(As this does not function during cabin pressure tests on the ground, the electrical test should be made as detailed in Sect.5, Chap.1, Group H).*

With engines

WARNING

When the aircraft is stationary, there is no cooling air flow through the primary

◀ and secondary coolers. Prolonged ground running is therefore to be avoided, and with the engines running (maximum speed 5000 rev/min), the cold-air unit must not be operated for longer than ten minutes during any one period. It is permissible, however, to use the cold-air unit whilst taxiing. ▶

29. To pressure test the cabin with engines:

(1) Ensure that the canopy and nose demisting systems units are installed and connected up.

(2) Remove the static vent plugs.

(3) Top up oil level in cold-air unit to the MAX mark on the dipstick; oil level is critical, do not overfill.

(4) Disconnect the pipe, which connects the combined valve unit to the pressure controller, at the combined valve unit, and blank off the pipe only, using special plug (Ref.No.26FZ/95270).

(5) Before starting the engines, operate the cabin heat control switch to secure full travel of the mixing valve and note the time taken for this operation; the time of operation in each direction should be approximately three seconds. Switch the mixing valve to the COLD position.

(6) Start the engines, and with the port engine running at 5500 rev/min. and the starboard engine idling, check that air enters the cabin. Operate the cabin heat control switch and check the time taken for the mixing valve to move from one extreme of travel to the other. The maximum time for this operation in each direction is five seconds.

(7) With the starboard engine running at

RESTRICTED

5500 rev/min. and the port engine idling, repeat operation (6).

(8) Close the entrance door, and with both engines running at 5500/6000 rev/min., and using a hand pressure gauge (*boost gauge Ref.No. 6A/1279*), carry out the following test:

(a) With temperature at fully HOT check the time of pressure rise to 3.5 lb/in², this is to be within 60 secs.

(b) With temperature at fully COLD check the time of pressure rise to 3.5 lb/in², this is to be within 60 secs.

(c) At the change of the selector from HOT to COLD, check that there is a change of air temperature entering the cabin. Check that the air is entering at all louvres, diffusers and fishtails.

(d) With the port engine idling and starboard engine running at 5500 rev/min., check that the cabin pressure can be maintained for at least three minutes. Repeat test with starboard engine idling and port engine running at 5500 rev/min.

(e) Switch off the engine gate valves, and with both engines idling check the time of pressure drop from 3.5 lb/in² to 1.75 lb/in² this must not be less than 70 seconds.

(f) Check that air ceases to enter the cabin when the engine gate-valves are switched off.

(9) Ensure all pressure inside the cabin has been released, and remove the blanking plug from the pressure controller pipe and re-connect the pipe to the combined-valve unit.

(10) Close all doors and apertures, select fully HOT, and with both engines running at 5500 rev/min., check that the cabin pressure does not exceed 1.0 lb/in².

Note...

The hot and cold pressurizing are to be regarded as two independent systems. Times and pressures are to be recorded under both headings.

Test after major repair

30. Whenever replacements of, or repairs to, components affecting the pressure sealing of the cabin have been made, the cabin pressure test detailed in para.28 must be carried out.

Sealing

Structural

31. Two alternative types of sealant, Bostik and Peratol, were used for sealing the pressure cabin during manufacture, but on repair or pressure leak rectification, Bostik only should be used. Full particulars of Bostik sealing compound for repairing damaged sealing are given in A.P.1464B, Vol.1, Part 2, Sect.4, Chap.7, and details of the method of application are given in A.P.4326, Vol.6, Part 1, Chap.2.

Emergency release cables

32. The barrel on the pressure bulkhead

through which the alighting gear and bomb doors emergency release cables pass, houses seven felt washers, which are impregnated on assembly with anti-freezing oil. If either emergency control has been operated, remove the circlip on the front of the barrel and fully impregnate the sealing washers with oil, OX-14. Replace the circlip after repacking with oil.

Constant-flow valves

33. These valves are set by the manufacturers and the only servicing permitted is the removal of the filter for cleaning. This is accessible when the knurled end cap has been unscrewed and the end plate, together with its asbestos washer, removed.

Pressure controller and combined valve unit

34. Refer to A.P.1275A, Vol.1, Sect.20.

WARNING

Particular care must be taken to ensure that the gauze inlet filter of the combined valve unit is kept clean. Failure to do so may result in serious damage to the pressure cabin and the mechanism of the combined valve unit.

Cold-air unit

35. Refer to A.P.4340, Vol.1.

Mixing valve

36. Refer to A.P.4303E, Vol.1.

Temperature control valve

37. Instructions for adjusting and testing this valve are given in (*fig.7*).

REMOVAL AND ASSEMBLY

Note ...

◀ (1) With the exception of SILASTIC hose joints, the standard procedure for remaking hose joints must be adopted (A.P.1464D, Vol.1, Part 2, Sect.3, Chap.8). To remake the SILASTIC hose joints, proceed as follows:-

(a) Renew the SILASTIC hose.

(b) Ensure that the gap between the ends of the pipes to be connected is between 0.10 in and 0.50 in.

(c) Fit the hose clips using clamping rings Pt.No.EEAS.66/14 beneath each clip.

(d) Fully tighten the hose clips and ensure that the gap between the ends of the clamping ring beneath each clip is between 0.05 in and 0.07 in.

(2) Whenever box type lagging is removed, care must be taken on reassembly that the jubilee clips securing the lagging are not overtightened to the extent of crushing ► the lagging. It is considered satisfactory that the clips are tightened to the stage where they can just be moved by hand.

(3) To prevent seizure of metal-to-metal couplings molybdenum disulphide anti-seize compound ZX-28 must be applied to the threads of the unions on reassembly.

General information

38. The following paragraphs detail the recommended methods of removing certain components from the system. Generally the

assembly sequence is the reverse of the removal, but where there are special assembly features they are specifically mentioned.

Constant-flow valves*Port main plane*

39. To remove the constant-flow valve:

(1) Remove the access panels from the upper surface of the port main plane leading edge (Sect.2, Chap.4).

(2) Disconnect the clamping ring on the outlet pipe inboard of rib 2.

(3) Disconnect the supply pipe at the inlet port of the valve.

(4) Release the two Jubilee clips securing the valve to the mounting bracket and remove the valve.

Bomb/flare bay

40. To remove the constant-flow valve:

(1) Unscrew the inlet pipe adapter and disconnect the inlet pipe from the valve.

(2) Remove the six 2 B.A. bolts and washers attaching the outlet pipe to the valve.

(3) Release the two Jubilee clips attaching the valve to the mounting bracket and remove the valve.

Mixing-valve actuator*Removal*

41. To remove the mixing-valve actuator:

(1) Disconnect the electrical supply.

(2) Remove the outboard access panel from the upper surface of the port inner wing leading edge (Sect.2, Chap.4).

(3) Remove the Plessey plug from the actuator socket.

(4) Remove the four 2 B.A. nuts from the studs on the mixing valve and remove the actuator.

Assembly

42. To assemble the actuator to the mixing valve:

(1) Turn the actuator shaft to the full extent of its travel in an anti-clockwise direction, when viewed looking into the gearbox from the drive end.

(2) Turn the mixing valve drive shaft clockwise, so that the master spline on the drive shaft attains a position relative to the master slot in the actuator drive.

(3) Offer up the actuator to the mixing valve ensuring that the master spline engages with the master slot in the actuator drive shaft.

Note...

It may be necessary to operate the follower lever slightly to achieve actuator engagement.

(4) Fit and tighten the four 2 B.A. nuts, and plain and spring washers securing the actuator to the mixing valve.

(5) Test the operation of the assembly (para.29).

RESTRICTED




Fig. 8. Pressure cabin sealing

RESTRICTED

Mixing valve*Removal*

43. To remove the mixing valve:

- (1) Remove the outboard access panel from the upper surface of the port inner wing leading edge (*Sect.2, Chap.4*).
- (2) Remove the actuator (*para.41*).
- (3) Remove the split pin, steel pin and washer connecting the link arm to the Desynn transmitter.
- (4) Slacken the clamping rings at each of the following connections:
 - (a) Mixing valve to primary cooler.
 - (b) Mixing valve to engine compressors.
 - (c) Mixing valve to cold-air unit.
 - (d) Mixing valve to constant-flow valve.
- (5) Remove the six 2 B.A. nuts and bolts attaching the mixing valve to the mounting bracket on the forward face of the undercarriage well diaphragm, and remove the valve.
- (6) Securely blank off all pipe ends and valve apertures.

Assembly (fig.5)

44. To assemble the mixing valve:

- (1) Remove all blanking caps.
- (2) Fit the valve to the mounting bracket on the forward face of the undercarriage well diaphragm, and fit and tighten the six 2 B.A. nuts, bolts, plain and spring washers.

(3) Fit and tighten the clamping rings connecting the pipes to the valve at the following ports:

- (a) Valve to primary cooler.
- (b) Valve to engine compressors.
- (c) Valve to cold-air unit.
- (d) Valve to constant-flow valve.

(4) Fit the actuator (*para.42*).

(5) Set the mixing valve follower lever at its mid-position (*i.e. 30 deg. from either end of full travel*).

(6) Set the adjustable Desynn transmitter lever at its mid-position (*i.e. 30 deg. from either end of full travel*).

Note...

The lever should initially be set at 2.0 in. from the centre of the shaft to the connecting pin centre.

(7) Connect the two levers without disturbing the setting, by fitting the adjusting tie-rod. If adjustment is necessary to fit the tie-rod, ensure that both the mixing valve follower lever and the Desynn transmitter, operating lever have full 60 deg. travel, *i.e. 30 deg. either side of the mid-position after adjustment has been made.*

(8) Fit the steel pins, washers and split pins, and lock all adjustment points.

(9) Test the operation of the assembly (*para.29*).

Air coolers*Primary air-cooler*

45. To remove the primary air-cooler:

(1) Remove the inboard access panel from the upper surface of the starboard main plane leading edge (*Sect.2, Chap.4*).

(2) Disconnect the supply pipes at the inlet and outlet ports of the cooler.

(3) Disconnect and remove the clamping rings at the inlet and outlet ducts of the cooler.

(4) Remove the bolt attaching the cooler to the top support bracket and remove the air cooler, by lifting clear of the two bottom locating brackets.

(5) Blank off pipe ends and component apertures.

Secondary air-cooler

46. To remove the secondary air cooler:

(1) Remove the inboard access panel from upper surface of the port main plane leading edge (*Sect.2, Chap.4*).

(2) Disconnect the relief valve pipe at the junction on the compressor to cooler pipe.

(3) Disconnect the relief valve to outlet duct clamp.

(4) Disconnect the supply pipes at the inlet and outlet ports of the cooler.

(5) Disconnect and remove the clamping rings at the inlet and outlet ducts of the cooler.

(6) Remove the bolt attaching the cooler to the top support bracket, and remove the cooler by lifting clear of the bottom support bracket.




Fig. 9. Pressure bulkhead sealing

RESTRICTED

(7) Blank off pipe ends and component apertures.

Cold-air unit

Removal

47. To remove the cold-air unit:

(1) Remove the inboard access panel from the upper surface of the port main plane leading edge (Sect.2, Chap.4).

(2) Remove the clamping rings at each of the following connections to the unit:

- (a) Unit to mixing valve.
- (b) Unit to cabin delivery duct.
- (c) Unit compressor to secondary cooler.
- (d) Unit turbine to secondary cooler.

(3) Disconnect the oil breather pipe from the unit.

(4) Remove the 16 bolts, light alloy and double spring washers securing the unit to the mounting brackets and remove the unit.

(5) Securely blank off all pipe ends and unit apertures.

Oil priming and testing

48. To oil prime the cold-air unit, and test for oil leaks before installation:

(1) Stand the unit on a bench with the rotor shaft horizontal, and the vent plug uppermost.

(2) Ensure that the dipstick is secure, then remove the breather and its washer from the top of the centre casing.

(3) Slowly pour approximately 85 c.c. of

oil OEP-71 through the tapped hole in the centre casing from which the breather has been removed. Spin the turbine wheel in the normal direction of rotation.

Note...

Ensure that both the oil and oil container used are scrupulously clean.

(4) Allow the unit to stand for one hour with the rotor shaft horizontal, then examine the oil-level dipstick and filler assembly banjo connection. If oil leakage has occurred, remake the banjo connection and repeat this test.

(5) After ascertaining that no oil leakage has occurred, drain the oil from the centre casing.

(6) Refit the breather, using a new joint washer, to the top of the centre casing. Wire-lock the banjo bolt and the breather.

Installation

49. To install the cold-air unit:

(1) Remove all blanking caps.

(2) Position the unit in the aircraft and fit and tighten the 16 bolts, light alloy washers (Part No. SP.16/C), and double spring washers (Part No. AGS.586/C).

(3) Make the connections between the unit and the following ducts:

- (a) Unit to mixing valve.
- (b) Unit to cabin delivery duct.
- (c) Unit compressor to secondary cooler.
- (d) Unit turbine to secondary cooler.

(4) Ensure that each split clamp is tightened to give an equal gap on each side, between the halves of the clamp.

(5) Reconnect the oil breather pipe to the unit and wire-lock.

(6) After installation, remove the filler cap, and fill the unit with oil OEP-71 to the MAX mark on the dipstick.

(7) Refit the oil level dipstick.

Note...

(1) Owing to the speed at which the cold-air unit operates, gyroscopic forces are high, and the alignment of the unit in the aircraft is critical. It is essential that if the unit be removed or replaced, the packings, if any, are replaced exactly as found on the original installation, and the unit is securely fitted.

(2) When fitting a replacement unit it is essential that new banjo bolts and washers are fitted, or internal leakage of oil may ensue.

Pressure controller

50. To remove the pressure controller:

(1) Disconnect the pipe to the combined valve unit at the base of the unit.

(2) Disconnect the static pipe at the base of the unit.

(3) Disconnect electrical cables from the unit (Sect.5, Chap.1).

(4) Remove the nuts and washers from the two bolts securing the unit to the aircraft structure.

(5) Blank off pipe ends and unit apertures.

Combined valve unit

Removal

51. To remove the combined valve unit:

- (1) Remove the inlet grid of the unit on the forward face of the pressure bulkhead by turning it anti-clockwise and lifting it clear of the three special to-type bolts.
- (2) Disconnect the pipe to the pressure controller at the banjo union, and remove the union by unscrewing the bolt.
- (3) Remove the three special to-type bolts, and the eight $\frac{1}{4}$ in. B.S.F. bolts and washers securing the unit, and remove from the rear face of the pressure bulkhead.

Assembly

52. To assemble the combined valve unit:

- (1) Remove the inlet grid from the valve unit by rotating it anti-clockwise, and lifting it clear of the three special bolts.

- (2) Remove the three special to-type bolts and the banjo connection bolt containing the metering orifice, noting their respective positions.

- (3) Offer up the combined valve unit to the rear face of the pressure bulkhead, ensuring that the rubber sealing ring is fitted between the bulkhead and the valve unit, and that the metering orifice housing is in the 7 o'clock position when viewed from the cabin.

- (4) Secure the unit to the bulkhead by fitting the three special to-type bolts, eight $\frac{1}{4}$ in. B.S.F. bolts, and the metering orifice banjo bolt, fitting both plain and spring washers. Ensure that the three bolts are in their correct positions as noted in op.(2), and that the two washers are in their correct positions on the banjo bolt.

- (5) Connect the pipe from the pressure controller to the banjo union and wire-lock

the union. Check that all bolts are tight. Refit the inlet grid to the three unit-securing bolts, by rotating the grid frame clockwise to the fullest extent of the keyhole slots.

- (6) Test the pressure controller (*A.P. 1275A, Vol.1, Sect.20, Chap.2*).

- (7) Pressure test the cabin (*para.28*).

Relief valve

53. To remove the relief valve:

- (1) Remove the inboard access panel from the upper surface of the port main plane leading edge (*Sect.2, Chap.4*).

- (2) Remove the clamp from the forward end of the valve, and the Jubilee clip from the rear.

- (3) Remove the two bolts securing the valve to the secondary cooler and remove the valve.

Chapter 8B AIR VENTILATED SUIT SYSTEM (post Mod.3243 – B (I) Mk.6 aircraft only)

LIST OF CONTENTS

	<i>Para.</i>		<i>Para.</i>		<i>Para.</i>
<i>Introduction</i>	1	<i>Non-return valves</i>	9	<i>During engine runs</i>	16
<i>List of principal components</i>	2	<i>Control valves</i>	10	REMOVAL AND ASSEMBLY	
DESCRIPTION					
<i>General information</i>	3	<i>Ground cooling air supply</i>		<i>General information</i>	17
<i>Cabin distribution</i>	4	<i>External air supply</i>	11	<i>Water extractor and vent pipe</i>	18
<i>Water extractor, Type W.E.5, Mk.9</i>	6	<i>Without external air supply</i>	12	<i>External breakaway charging connection</i> ...	19
<i>Pressure-reducing valve</i>	7	SERVICING			
<i>Pressure-relief valve</i>	8	◀ <i>Test set</i>	13 ▶	<i>Pressure reducing valve</i>	20
		<i>System leakage test</i>	14	<i>Pressure relief valve</i>	21
		<i>System flow tests</i>			
		<i>With external air supply</i>	15		

LIST OF ILLUSTRATIONS

	<i>Fig.</i>
<i>Air ventilated suit system</i>	1
<i>Air ventilated suit system diagram</i>	2
<i>Air ventilated suit system with test equipment</i>	3
◀ <i>Test set (Mod.4047)</i>	4 ▶

Introduction

1. This chapter describes and illustrates the air ventilated suit system which provides conditioned air to the special crew suits at a constant flow at all cabin pressures and aircraft altitudes. Details are given of certain servicing operations and methods recommended for the removal and assembly of particular components. The location of the system components is illustrated in fig.1, and the system is shown diagrammatically in fig.2; equipment required for testing the system and the manner in which it should be attached is illustrated in fig.3.

List of principal components

2. Details of the system components are given in the following table:

LIST OF PRINCIPAL COMPONENTS IN VENTILATED SUIT SYSTEM

Ref.No.	Description	Part No.
27KD/989	Control valve	Normalair Ltd. 513390
27KD/969	Breakaway charging connection	Normalair Ltd. 512070
27UA/1217	Water extractor, W.E.5, Mk.9	Godfrey, 119173
—	Non-return valve	Flight Refuelling Ltd. 9811125/H
—	Reducing valve, 3/4 in. Relief valve	Hymatic Ltd. PAS.148.074 Hymatic Ltd. RAV.158.002




Fig. 1. Air ventilated suit system

RESTRICTED

DESCRIPTION

General information

3. The supply of air for the ventilated suit system is taken from the pipeline in the air conditioning system which runs between the primary air cooler and the mixing valve (*Chap.8A*), the tee-piece tapping being made on the starboard side of the bomb/flare bay. To provide additional cooling, the pipe is run aft from the tee-piece to a point midway between frames 28 and 29 where it crosses the roof of the bomb/flare bay and then runs forward, along the port side of the fuselage, to a Type W.E.5, Mk.9 water extractor mounted on the forward face, and in the centre of, frame 13 bulkhead. The pipe from the water extractor continues to a pressure reducing valve mounted on the lower section of the battery bay starboard wall, and then on, through a pressure relief valve and two non-return valves, to the pressure cabin. At a tee-piece tapping in the pipeline between the two non-return valves, a branch pipe connects to an external break-away charging valve situated on the starboard side of the fuselage flush with the outer skin between frames 12 and 13 just above the main longeron.

Cabin distribution

4. The ventilated suit supply pipeline enters the pressure cabin through the starboard side of the pressure bulkhead; it follows the contour of the fuselage almost to floor level, then runs inboard to a four-way union mounted on the bulkhead between the air bomber's and navigator's ejection seats. The three branch pipes from the four-way union distribute the supply of air equally to each crew member.

5. Mounted immediately above the four-way union is a bracket which supports the navigator's and air bomber's control valves. Two of the branch pipes from the four-way union are connected to these control valves, whilst the other one runs forward, as a flexible hose, along the edge of the navigator's raised floor to the pilot's control valve mounted on the forward face of the electrical control panel. From each control valve, a length of kinkproof hose, incorporating a quick-release socket, is clipped to the relevant ejection seat and terminates in another quick-release socket which connects with the hose from the crew members ventilated suit.

Water extractor, Type W.E.5, Mk.9

6. This unit, mounted on the forward face of frame 13 bulkhead, ensures that the air taken from the air conditioning system is free from moisture when delivered to the ventilated suits. The moisture is separated from the air and drained to atmosphere through a drain pipe. The unit is fully described in A.P.4340, Vol.1.

Pressure-reducing valve

7. This valve, situated at frame 12 on the starboard side of the battery bay, reduces the system air pressure to 12 lb/in². The air pressure issuing from this valve is such that the air flow through the ventilated suits will be maintained at all cabin pressures and aircraft altitudes.

Pressure-relief valve

8. The relief valve is positioned in the pipe run adjacent to the pressure-reducing

valve. It relieves excess pressure in the system when all crew control valves are closed, or in the event of failure of the pressure-reducing valve. The valve relieves pressures in excess of 8 lb/in².

Non-return valves

9. A non-return valve is fitted between the tee-piece tapping for the external charging valve and the pressure relief valve. This valve ensures that there will be no back flow to the air conditioning system when cooling air is being supplied through the external charging valve. A second non-return valve is fitted in the pipe run aft of the pressure bulkhead to ensure that cabin pressure is not lost when the suits are not in use and the control valves are left open.

Control valves

10. There are three control valves, one adjacent to each crew members' ejection seat. Each valve can be operated individually and controls the supply of air only to the ventilated suit in the same circuit as the valve. Each valve exit incorporates a quick-release socket into which snaps a length of kinkproof hose.

Ground cooling air supply*External air supply*

11. A breakaway charging connection is installed on the starboard side of the fuselage between frames 12 and 13. When the aircraft is stationary the connection provides for a ground supply unit to be attached so that an air supply can be fed direct to the crew stations. The connection is automatically sealed when the ground supply is

FRAME NUMBERS :




Fig.2. Air ventilated suit system diagram

RESTRICTED

disconnected. Cooling air to the system may be supplied by:

(1) An approved ground testing trolley similar to that shown in A.P.4306A, Sect. 5, Item 39 (Ref.No. 4F/2195).

(2) One or more 15000 litre air bottles charged to 3500 lb/in². with dry air. The air to be fed through a suitable arrangement of reducing valves to reduce the

◀ pressure to 8lb/in². ▶

Note...

The flexible hose connecting the external air supply to the aircraft must be fitted with a Normalair connector (Part No. 512080).

Without external air supply

12. After the external supply has been

◀ disconnected, cooling air may be supplied to the ventilated suits by operating the air conditioning system hot-air valve switches (Chap.8A). If COLD is selected on the cabin heat control switch the selection must not exceed a period of five minutes whilst the aircraft is stationary and the engine rev/min. must not exceed 5000 continuously. When taxiing, the cooling effect attains its maximum efficiency with one or both engines running at 5000 rev/min. ▶

SERVICING

◀ **Test set (fig.4)**

13. Mod. G.E.4047 introduces a wooden carrying case test set (Ref.No.26FZ/95619) containing equipment for testing the air ventilated suit system. The contents of the case consists of two test gauges, one 0-200 lb/in² and one 0-30lb/in²., two test gauge adapters, and a stowage bag containing three blanking plug assemblies and three test orifices. Fig.3 shows the correct application of the equipment when the system is being tested.

System leakage test

14. Prepare and test the ventilated suit system for leaks in the following manner:

Note...

The test equipment required for the following test is contained in the test set (Ref. No.26FZ/95619) introduced by Mod.4047 (para.13).

(1) Disconnect the system from the air conditioning system duct at the tee-piece tapping in the bomb/flare bay aft of frame 20 (fig.1).

(2) Connect the test gauge adapter (Pt. No.EA3.88.5069), together with the 0-30 lb/in² test gauge, to the ventilated suit system supply pipe.

(3) Connect a source of clean dry air, capable of supplying 10lb/in² pressure, into the test adapter.

(4) Blank off the water extractor drain using blanking plug assembly (Pt.No. EA3.88.5061).

(5) Remove the reducing valve vent filter and blank off the vent using blanking plug assembly (Pt.No.EA3.88.5059).

(6) Blank off the relief valve inlet using blanking plug assembly (Pt.No.EA3.88.5063).

(7) Close all crew control valves.

(8) Carefully pressurize the system to 8 lb/in² and turn off the air supply.

Note...

Care must be taken to restrict the supply

pressure to 8lb/in²., as a high pressure will result in damage to the 0-30lb/in test gauge.

(9) Check the system for leaks using a Teepol (Ref.No.33C/1129) and water solution.

(10) Hold the 8lb/in² test pressure for 15 minutes; the maximum permissible pressure drop in this time is 5 lb/in².

(11) Remove the blanking plug assemblies from the water extractor drain, the relief valve inlet and the reducing valve vent; refit the reducing valve vent filter.

(12) Remove the test gauge and adapter, and recouple the ventilated suit system to the air conditioning system duct in the bomb/flare bay.

(13) Replace all test equipment in the test set carrying case (fig.4).

**System flow tests
IMPORTANT**

On completion of these tests ensure that ▶




Fig.3. Air ventilated suit system with test equipment

◀ (Mod.4047 incorporated) ▶

RESTRICTED

◀ the test orifices have been removed from the control valves.

Note...

The test equipment required for the following tests is contained in the test set (Ref. No.26FZ/95619) (Mod.4047) described in para.13.

With external air supply

15. To flow test the ventilated suit system with an external air supply:

(1) Disconnect the system from the air conditioning system duct at the tee-piece tapping in the bomb/flare bay aft of frame 20 (fig.1).

(2) Connect the test gauge adapter assembly (Pt.No.EA3.88.5069), together with the 0-200lb/in² test gauge, to the ventilated suit system supply pipe.

(3) Connect a source of clean dry air, capable of supplying 90 lb/in² pressure, to the test adapter.

(4) Blank off the water extractor drain using blanking plug assembly (Pt.No. EA3.88.5061).

(5) Connect the test gauge adapter assembly (Pt.No.EA3.88.5077) together with the 0-30lb/in² test gauge, to the pilot's control valve.

(6) Close all control valves.

(7) Open air supply to register 90 lb/in² pressure on the 0-200 lb/in² test gauge.

(8) Check all joints and pipelines in the system up to the pressure reducing valve for leaks.

(9) Open the pilot's control valve and the test equipment control valve.

(10) Check that under full flow conditions and with the pressure reducing valve datum pressure outlet suddenly blanked off the pressure on the 0-30lb/in² test gauge does not rise above 8 lb/in².

(11) Remove the test gauge adapter and test gauge from the system supply pipe in the bomb/flare bay. Recouple the system to the air conditioning system.

- | | |
|---|---|
| 1 | BLANKING PLUG ASSEMBLY (PT. No. EA3-88-5063) FOR BLANKING PRESSURE RELIEF VALVE. |
| 2 | BLANKING PLUG ASSEMBLY (PT. No. EA3-88-5059) FOR BLANKING PRESSURE REDUCING VALVE DATUM OUTLET. |
| 3 | BLANKING PLUG ASSEMBLY (PT. No. EA3-88-5061) FOR BLANKING WATER EXTRACTOR DRAIN PIPE. |
| 4 | TEST ORIFICE (PT. No. EA3-88-5057) 3-OFF. |

(12) Remove the blanking plug assembly from the water extractor drain.

During engine runs

Note...

The air conditioning system must not be selected COLD during these tests.

16. To flow test the ventilated suit system with the engines running:

Note...

Do not blank off the water extractor drain. ▶




Fig.4. Test set (Mod.4047)

◀ (New illustration) ▶

RESTRICTED

◀ (1) Ensure the air bomber's control valve is closed.

(2) Fit a test orifice (*Pt.No.EA3.88.5057*) into the navigator's control valve, and ensure the test equipment (*para.15(5)*) is correctly assembled at the pilot's control valve.

(3) Open the navigator's, the pilot's and the test equipment control valves and check that the pressure registered on the 0-30 lb/in² test gauge does not fall below the following:

(a) 2.0lb/in² with engines running at 5500 rev/min.

(b) 2.5lb/in² with engines running at 7400 rev/min.

(4) Close the navigator's control valve and check that the pressure at the test gauge does not rise above 5.5 lb/in².

(5) With the test equipment at the navigators position, and the test orifice at the pilot's valve, repeat operations (3) and (4).

(6) With the test equipment at the air bomber's position and with the navigator's control valve closed, repeat operations (3) and (4).

(7) Remove the test equipment and test orifice and close all control valves. Replace the test equipment back in the test set carrying case (*fig.4*).

Note...

The results of the preceding tests should be the same with or without the cabin pressurized. ▶

REMOVAL AND ASSEMBLY

General information

17. In the following paragraphs only the removal sequence is detailed as the assembly is generally the reverse of the removal sequence.

Water extractor and vent pipe

18. The procedure for the removal of the water extractor and vent pipe is as follows:

(1) Disconnect the feed and outlet pipes by slackening off their respective outer sleeves. Retain the inner nipples.

(2) Disconnect the vent pipe by slackening off the union attaching the pipe to the vent connection in the fuselage skin.

(3) Release the body of the extractor by removing the two bolts securing the retaining strap to the bracket.

(4) Remove the two clips attaching the vent pipe to the bulkhead.

(5) Blank off the exposed pipe ends.

External breakaway charging connection

19. To remove the charging connection:

(1) Disconnect the pipe from the body of the connection and from the T-union in the supply pipe. Retain the inner nipple.

(2) Remove the four 2 B.A. screws adjacent to the connection aperture in the fuselage skin.

(3) Remove the charging connection from the aircraft. Retain the packing from between the fuselage skin and the connection.

Pressure reducing valve

20. To remove the pressure reducing valve:

(1) Disconnect the two pressure pipes from the valve body by releasing their respective outer sleeves. Retain the inner nipples.

(2) Remove the two 2 B.A. bolts securing the saddle clamp to the aircraft structure. Retain the saddle clamp.

(3) Blank off the exposed pipe ends.

Pressure relief valve

21. To remove the pressure relief valve:

(1) Disconnect the two pipes by releasing their respective outer sleeves. Retain the inner nipples.

(2) Remove the two 2 B.A. bolts and washers securing the saddle clamp to the aircraft structure. Retain the saddle clamp.

(3) Blank off the exposed pipe ends.

Chapter 8C DE-MISTING SYSTEM

LIST OF CONTENTS

	<i>Para.</i>		<i>Para.</i>		<i>Para.</i>
<i>Introduction</i>	1	<i>Inner surface de-misting</i>	6	<i>System leakage rate</i>	9
<i>List of principal components</i>	2	SERVICING		<i>Testing the static air-drier</i>	10
DESCRIPTION		<i>Charging the air-drier tubes</i>		REMOVAL AND ASSEMBLY	
<i>General information</i>	3	<i>Pilot's canopy static air-drier... ..</i>	7	<i>Filter</i>	12
<i>Closed circuit de-misting</i>	4	<i>Blower circuit and observation window</i>		<i>Blower motor</i>	14
<i>Static air-drier tubes</i>	5	<i>air-driers... ..</i>	8		

LIST OF ILLUSTRATIONS

	<i>Fig.</i>
<i>De-misting system... ..</i>	1
<i>Static air-drier test rig</i>	2

Introduction

1. The purpose of the de-misting system is to prevent the formation of condensation within the interspaces of the transparent fairings. This chapter describes and illustrates the system, gives details of servicing operations, and recommends methods for the removal and assembly of certain components. The location of the de-misting units is illustrated in fig.1.

List of principal components

2. Details of the de-misting system components are given in the following table:

LIST OF PRINCIPAL COMPONENTS IN DE-MISTING SYSTEMS

Ref.No.	Description	System
5UD/3310	Blower unit	Canopy
26FZ/2146	Closed circuit air-drier	Canopy
26FZ/1815	Filter	Canopy
26FZ/2841	Static air-drier	Canopy
26FZ/1374	Closed circuit air-drier	Nose




Fig. 1. De-misting system

RESTRICTED

DESCRIPTION

General (fig.1)

3. The pilot's canopy, the transparent nose fairing, the observation window and the navigator's window are all provided with dry-air de-misting. Three air driers are utilised, one of which is connected in a system providing for an initial circulation of air through the pilot's canopy; this air-drier is also connected to the navigator's window, but since there is no feed back to this window, its role in this respect is purely static. Of the two remaining driers, one is connected to the pilot's canopy, in addition to that in the circulatory system, and the other is connected to the nose fairing and nose observation window, the role of these two tubes is static.

Closed circuit de-misting

4. The air-drier tube for the circulatory system is connected to the inner sheet of the canopy, on the port side, by a rubber tube with a slip-on connection. It is part of a system forming a closed circuit which

ensures that the air initially contained in the canopy cavity is extracted, dried and returned to the canopy. This is accomplished by a small electrically driven blower, which draws air from the canopy, through the air-drier tube and returns it through a filter and slip-on rubber tube to a connection on the inner sheet of the canopy, at the centre front. The navigator's window is connected to the suction side of the system but there is no feed back when the blower is running. The drier tube is mounted on the canopy coaming and is charged with silica gel. The blower is mounted on a bracket at the front of the navigator's table and is controlled by the canopy de-misting switch on the pilot's take-off panel; the filter is mounted in the roof of the nose on fuselage frame 1.

Static air-drier tubes

5. The static air-drier tube connected to the canopy is fitted with inlet and outlet valves and its drying medium is silica gel.

It is mounted on the canopy coaming cross-tube and connected to the inner sheet of the canopy on the starboard side. The air-drier tube for the nose fairing is not fitted with valves, and it is mounted just aft of the nose fairing, the drying medium in this tube is also silica gel. Both tubes are connected to their respective windows by rubber tubes, that at the canopy being a slip-on connection permitting the joint to be broken when the canopy is jettisoned; at all other points the connections are wired.

Inner surface de-misting

6. To prevent misting of the nose fairing and canopy inner surfaces, conditioned air is ducted from the cabin air system and delivered to these surfaces through diffusers (Chap.8A). The canopy diffuser has a control valve located on the frame to port of the alighting gear control panel; the diffuser for the nose fairing is not controllable but delivers conditioned air to the inner surface simultaneously with the cabin air supply.

SERVICING

Charging the air-drier tubes

Pilot's canopy static air-drier

7. The drier tube is fitted with a window through which the contents may be inspected; the contents should be changed, when they turn pink. To re-charge:

(1) Remove the blanking cap from the stowage on the canopy coaming, adjacent to the air-drier.

(2) Remove the air-drier connection tube at the canopy and seal the canopy connec-

tion by fitting the blanking cap.

(3) Release the mounting clips and remove the air-drier from the aircraft.

(4) Slacken the Jubilee clips securing the

RESTRICTED

hose connecting the container to the valve body and withdraw the container.

(5) Empty the container and re-fill it with silical-gel (Ref.No. 33C/790).

(6) Refit the valve to the container and tighten the Jubilee clips around the connecting hose.

(7) Refit the air-drier into the aircraft and tighten the securing clips.

(8) Remove the blanking cap from the canopy connection and connect the air-drier to the canopy by sliding the rubber tube on to the connection on the canopy; this connection is not wired.

(9) Refit the blanking cap on its stowage.

Blower circuit and observation window air-driers

8. These air-driers are each fitted with a tell-tale compartment incorporating a window through which the contents may be inspected. The tell-tale compartment and the main compartments are filled with silica gel. The contents of both the tell-tale and main compartments should be changed when the crystals visible through the inspection window, become pink coloured. To re-charge:

(1) Pinch the rubber connecting tube with a clip to prevent air entering the cavity in the canopy or window, and in the case of the canopy air-drier, pinch also the tubes to the blower and navigator's window.

(2) Remove the wire securing the rubber tubes to the air-drier and remove the tubes from the air-drier.

(3) Release the air-drier mounting clips and remove the air-drier from the aircraft.

(4) Remove the end cap, filter and sealing ring from the air-drier (the end cap is secured by wing nuts) and empty the main and tell-tale compartments.

(5) Fill the tell-tale and main compartment with silica gel (Ref.No. 33C/790).

(6) Refit the filter, sealing ring and end cap to the air-drier body.

(7) Replace the air-drier into the aircraft and tighten the securing clips.

(8) Fit the rubber tubes to the air-drier and wire them securely.

(9) Remove the clips from the rubber connection tubes.

Note...

When re-filling the air-driers a minimum amount of time should be taken in packing the crystals, as moisture from the air is absorbed by the crystals, so reducing the efficiency and life span of the component.

System leakage rate

9. With all system components assembled and connected together, a pressure drop from $\frac{1}{2}$ lb/in². to $\frac{1}{4}$ lb/in². must not take less than 50 seconds.

Note...

The air supply used for this test must be clean and free from moisture.

Testing the static air-drier

10. The following equipment is required for testing the pilot's canopy static air-drier:

(1) A test rig capable of applying an air pressure of 2 lb/in². and a suction of 0.6 lb/in².




Fig. 2. Static air-drier test rig

(2) A 12 in. mercury U-tube.

11. Before testing the air-drier, it must be removed from the aircraft (para.7, operation (1) to (3)), then proceed as follows:

(1) Connect the air pressure pipe from the test rig to the canopy end (A) of the drier with the mercury tube interposed (fig.2). Blank off the aperture (B) at the opposite end of the drier.

(2) Apply a pressure of 2 lb/in². and check that the complete assembly is airtight.

(3) Release the pressure and remove the

blank from the end of the drier.

(4) Apply pressure and check that the outlet valve opens at 0.6 lb/in². but that it is airtight below 0.3 lb/in².

(5) Remove the pressure pipe and connect the suction pipe in its place.

(6) Apply suction and check that the inlet valve opens at 0.6 lb/in². but that it

is airtight at 0.3 lb/in².

(7) Disconnect the test rig and refit the drier tube into the aircraft.

REMOVAL AND ASSEMBLY

Filter

12. To remove the element from the filter:

- (1) Pinch the rubber tube at the inlet connection to the canopy.
- (2) Disconnect the rubber hose from the base of the filter.
- (3) Release the filter base from the outer case by slackening the wing nut.
- (4) Remove the filter element.

13. Before assembly, the ends of the filter

element should be lightly greased with lanolin.

Blower motor

14. To remove the blower motor:

- (1) Pinch the rubber tube at the inlet connection to the canopy.
- (2) Disconnect the electrical cable at the motor.
- (3) Remove the four 6 B.A. bolts attaching the outlet connection to the blower and remove the outlet connection.

(4) Remove the 2 B.A. stiffnuts from the two studs holding the inlet connection and remove the inlet connection.

(5) Remove the 2 B.A. stiffnuts from the four bolts securing the attachment clip.

(6) Remove the attachment clip and the motor.

15. Before assembling the inlet and outlet connections to the blower, apply rubber-resin cement (*Ref.No. 33C/1173*) to their faces.

Chapter 10 OXYGEN SYSTEM

(Completely revised)

LIST OF CONTENTS

	Para.		Para.		Para.
Introduction	1	Air bomber's bombing station supply... ..	9	Emergency oxygen control lever... ..	15
List of principal components	2	Emergency oxygen... ..	10	Lubrication	16
DESCRIPTION					
General information	3	SERVICING			
Pilot's supply	6	General information	11	Oxygen cylinders	17
Navigator's supply... ..	7	Charging the cylinders... ..	12	Oxygen regulators	
Air bomber's supply	8	System leakage test	13	Removal	18
		System functional test	14	Assembly	19
				REMOVAL AND ASSEMBLY	

TABLE

	Table
List of principal components	1

LIST OF ILLUSTRATIONS

	Fig.
Oxygen system	1

WARNING

Oxygen and oil or grease unite explosively. When handling any equipment used in high pressure oxygen systems, keep all oil and grease from contact with the equipment. Failure to do this may result in loss of life and equipment.

Introduction

1. This chapter contains a description

together with the servicing procedure and the method of removal and assembly of certain components of the oxygen system. The electrical services associated with the oxygen regulators are described in Sect.5, Chap.1, Group W, and brief details of the regulators and pressure gauges are given in Sect.5, Chap.2, Group D. A full description of the system components, the procedure for

servicing them, and the method of charging the cylinders is given in A.P.1275A or G, Vol.1.

List of principal components

2. A list of the principal components used in the system is given in Table 1.




Fig. 1. Oxygen system

RESTRICTED

TABLE 1
List of principal components

Ref.No.	Description	No. off per A/C
6D/9429900	Oxygen cylinder, 2250 litres	2
6D/9429896	Oxygen cylinder, 750 litres	5
6D/1616	Pressure reducing valve, Mk.1	2
or		
6D/2344	Pressure reducing valve, Mk.1A	2
6D/2313	Valve, Mk.10A, charging or stop	3
6D/1650	Flanged connector	3
6D/2237	Oxygen contents gauge, Mk.4	2
6D/427	Non-return valve, Mk.1	4
6D/1652	Quick-release socket, Mk.9	3
6D/1817	Quick-release socket, Mk.10A	1
6D/2294	Oxygen regulator, Mk.17E	4
or		
6D/2671	Oxygen regulator, Mk.17F	4
6D/574	Filter unit	1
6D/575	Connection, 2-way	5
6D/603	Connection, 3-way, Mk.3A	9
6D/1797	Clip plate	3
6D/1698	Aerolex clip, Type D	3
6D/1580	Flexible tubing, 6 ft long	1
6D/1579	Flexible tubing, 4 ft long	3
6D/1497	Union blank, Mk.3	5
6D/2429	Emergency oxygen set, Mk.3E/SC	1
6D/2678	Emergency oxygen set, Mk.7J	3

DESCRIPTION

General

3. Oxygen is carried in seven cylinders, two 2250 litres and five 750 litres, mounted in the compartment aft of the pressure bulkhead. Each cylinder is fitted with a five-way connection incorporating two non-return valves. In order to reduce vulnerability and as a safeguard against total loss of oxygen

in the event of fracture of the supply lines the cylinders are grouped into two banks, isolated from each other and the high-pressure system is duplicated. A charging valve, with a filter in the charging line, is connected to all the cylinders enabling them to be charged in situ. The charging valve is located on the aft face of frame 12.

4. High pressure supply lines, one to each bank of cylinders, pass forward through the pressure bulkhead on the port and starboard sides, respectively, to Mk.10A stop valves located, one on the port wall of the navigator's station, and one on the forward face of the pressure bulkhead on the starboard side. From the stop valves the high pressure supply lines pass along the walls of the pressure cabin to a point forward of the pilot's instrument panels, where the port supply line passes across the cabin to join the starboard line. The supply lines are joined by a three-way connector housing a non-return valve in each of the connections to the supply lines, the third being connected to a pipe leading to a Mk.1 pressure-reducing valve, and housing a filter in the pipe-line connection. Two pressure gauges, located above the entrance door, are connected into the supply lines, to register the pressure in each bank of oxygen cylinders. From the pressure reducing valve, which reduces the pressure to 400 lb/in², an intermediate-pressure supply line is connected to the pilot's Mk.17E or 17F pressure regulator mounted on the port wall of the cabin above the console and, through a three-way connection in the pipeline, to a Mk.17E or 17F pressure regulator on the starboard side of the air bomber's forward station in the nose of the aircraft.

5. A pipeline passing across the cabin at the navigator's and air bomber's normal stations, joins the two supply lines on the port and starboard walls, respectively. At the navigator's position, a three-way connector, housing two non-return valves and a filter, joins a pipeline to a Mk.1 reducing valve which, through intermediate pressure branch pipelines, supplies the navigator's and air bombers Mk.17E or 17F pressure regulators, mounted on the canopy coaming

RESTRICTED

cross-tube and on the starboard wall of the cabin respectively.

Pilot's supply

6. From the pilot's pressure-regulator a low pressure pipe, terminating in a flanged connector, takes the supply to an attachment point on the starboard side of the ejection seat. The flexible tube from the pilot's face mask connects to a break point on the connector so that it will disengage when the seat is ejected.

Navigator's supply

7. From the navigator's pressure-regulator the supply is conveyed by a low-pressure pipe terminating in a quick-release socket. The navigator's face mask is connected to the socket and will disengage when the seat is ejected.

Air bomber's supply

8. From the air bomber's pressure regulator the supply is conveyed by a low-pressure line to a flanged connector and a quick-release socket. The air bomber's face mask is connected to the socket and will disengage when the seat is ejected.

Air bomber's bombing station supply

9. From the pressure regulator on the starboard side of the air bomber's bombing station a low-pressure line connects to a flexible tube, terminating in a quick-release socket. The tube passes aft and is stowed in a clip on the starboard side of the air bomber's normal station. The arrangement of this and the normal supply enables the

air bomber to change over when preparing to move to his forward station, by disengaging the face mask flexible tube at the quick-release connection and connecting it to the alternative supply tube, which is of sufficient length to enable him to move freely to his forward station.

Emergency oxygen

10. An emergency oxygen cylinder is mounted on the starboard side of the Mk.2CA.1 and 2CA.2 ejection seats; these may be used in the event of failure of the main supply as instructed in Sect.1, Chap.3. An emergency oxygen cylinder is also fitted at the air bomber's bombing station to supply the air bomber when at that station.

SERVICING

WARNING

Oxygen and oil or grease unite explosively. When handling any equipment used in high pressure oxygen systems, keep all oil and grease from contact with the equipment. Failure to do this may result in loss of life and equipment.

General information

11. The servicing necessary to maintain the system in an efficient working condition consists of keeping the installation free from oil, grease and moisture, checking that the cylinders are always fully charged, and testing for leaks at all joints. An examination of the system should also be made for

signs of damage, and to ensure that components are securely mounted. Check that the flexible tubes are fitted securely and, at the pilot's station, check that the flexible tube is fully down to the flange at the ejector seat break-point. The standard serviceability and operational test of the components are fully described in A.P.1275A or G, Vol.1.

Charging the cylinders

12. Scrupulous cleanliness of all connections must be observed during charging operations. To charge the cylinders:



(1) Remove the blanking cap from the oxygen charging valve on the aft face of frame 12 bulkhead.

(2) Connect a high pressure oxygen supply from an oxygen charging trolley and charge the cylinders to 1800lb/in² in accordance with A.P.1464G, Vol.1, Sect.5, Chap.38.

Note...

Charge the cylinders to 2000lb/in²; on cooling, the pressure will be approximately 1800lb/in².

(3) When charging is completed, disconnect the charging trolley and replace the

blanking cap on the charging valve. ▶◀

System leakage test

13. To test the system for leaks:

- (1) Switch all four oxygen regulators ON/OFF valves to OFF.
- (2) Ensure there is between 1700lb/in² and 1800lb/in² pressure in the oxygen cylinders.
- (3) Check that the stop valves on the pressure bulkhead are OPEN.
- (4) Check all pipelines (3/16in. copper and 5/16in. L.A. piping) and components from the charging valve to the regulators for leaks, using a solution of water and Teepol (Ref.No.33C/1129) to A.P.1275G, Vol.2, Leaflet A4.

Note...

If a leak is found it is generally caused by dirt on the nipple or branch mating face; this is remedied by cleaning and degreasing the faulty fitting. If the leak persists, the fitting should be renewed.

- (5) On completion of the tests all traces of the Teepol solution must be removed.
- (6) Return the regulators ON/OFF valves to ON and wire-lock.

System functional test

14. To test the functioning of the system and system components:

- (1) Ensure there is between 1700lb/in²

and 1800lb/in² pressure in the oxygen cylinders.

- (2) Close both stop valves on the pressure bulkhead.
- (3) Exhaust the cabin side of the system by depressing the valve in the free end of the pilot's flexible hose connection and operating the regulator MASK TEST switch.
- (4) Open the stop valve on the port side of the pressure bulkhead. Pressure should read rapidly on rear contents gauge.

Note...

The forward contents gauge will record slowly due to leak past non-return valve in the starboard supply line.

- (5) Close the stop valve on the port side of the pressure bulkhead.
- (6) Exhaust cabin side of system as at operation (3).

(7) Open the stop valve on the starboard side of the pressure bulkhead. Pressure should read rapidly on the forward contents gauge.

Note...

The rear contents gauge will record slowly due to leak past the non-return valve in the port supply line.

- (8) Open the stop valve on the port side of the pressure bulkhead.
- (9) Ensure that the flexible hose is down to the flange at the ejection seat break-point.

Make the following checks at all four

oxygen regulators.

(10) *Pressure reducing valve check*—Check that each regulator pressure gauge reads between 200lb/in² and 400lb/in².

Note...

If the pressure at the regulator is greater or less, the pressure reducing valve is suspect and should be tested as detailed in A.P.1275G, Vol.1, Sect.2, Chap.10.

(11) *Regulator internal leakage check*—Switch the regulator ON/OFF valve to OFF and check the pressure drop on the regulator gauge. This must not exceed 25lb/in² in 60 seconds. Switch the regulator ON.

(12) *Low pressure pipe check*—Set air inlet shutter to NORMAL, insert rubber stopper in mask socket connection, switch emergency toggle to left or right and turn off the regulator ON/OFF valve. Check time taken for the regulator pressure to drop to zero; this must not be less than 60 seconds.

(13) *Air inlet shutter check*—Switch the air inlet shutter on the oxygen regulator to 100% OXYGEN and, with the regulator ON/OFF valve OFF, suck gently through face mask. There should be a considerable resistance to suction. Whilst still sucking move air inlet shutter to NORMAL; there should be no resistance to suction.

(14) Using a face mask make the following checks:

- (a) Breathing normally with the regulator switch ON and the air inlet shutter at NORMAL, check that with each inhalation the blinker indicator on the regulator face operates.

(b) Deflect the EMERGENCY toggle switch to the left and to the right and check that there is a continuous flow of oxygen. With the toggle switch in the central position, push the toggle switch downwards and verify that there is a continuous flow of oxygen at a much increased pressure. Insert a rubber stopper in the mask socket connection and with the toggle switch in each position (*i.e. left, right and centre*), check that the flow

ceases and the blinker indicator returns to normal.

(15) On satisfactory completion of these tests wire-lock the stop valves on the pressure bulkhead in the fully OPEN position. Wire-lock the regulators' ON/OFF valves ON.

Emergency oxygen control lever

15. The pull off load for the emergency

oxygen control lever must not exceed 30 lb.

Lubrication

16. Refer to the WARNING preceding para. 11. The authorized lubricant for use on the screw threads of the oxygen equipment is graphited lubricating fluid (ZX-24). No other lubricant may be used. Instructions for lubrication will be found in A.P. 275G, Vol. 1, Sect. 1, Chap. 3.

REMOVAL AND ASSEMBLY

Oxygen cylinders

17. To remove an oxygen cylinder:

- (1) Remove the appropriate access panel (*Sect. 2, Chap. 4*).
- (2) Remove the locking wire from the high-pressure stop valve in the supply line from the appropriate bank of cylinders, and fully close the valve.
- (3) Unscrew the stop valve forward union, slowly open the stop valve, and allow the oxygen to escape.
- (4) Disconnect the cylinder pipelines and blank off the exposed pipe-ends.
- (5) Release the two cylinder retaining straps by unscrewing the two turnbuckles.

(6) Remove the cylinder from the compartment.

Oxygen regulator

Removal

18. (1) Disconnect all electrical supplies.
- (2) Disconnect the electrical plug from its socket.
 - (3) Uncouple, remove and blank off the oxygen supply and delivery pipes.
 - (4) Remove the four 2BA securing screws and remove the regulator.

Assembly

19. (1) Position the regulator in its bracket and secure with the four 2BA screws.

(2) Re-connect the oxygen supply and delivery pipes.

(3) Re-connect the electrical plug and socket.

(4) Functionally test the regulator and system (*para. 14*).

(5) Re-connect the electrical supplies.

(6) Functionally test the regulator and system (*A.P. 1275G, Vol. 1*).

(7) Carry out the electrical test (*Sect. 5, Chap. 1, Group W*).

Chapter II EMERGENCY EQUIPMENT

LIST OF CONTENTS

DESCRIPTION	Para.		Para.		Para.
General information	1	Alighting-gear emergency raising control	16	Cocking the snatch unit... ..	26
Canopy and hatch	2	Bomb/flare-doors emergency opening control	17	Cocking the hatch-jettisoning mechanism boxes	27
Ejection seats	3	Entrance-door jettisoning mechanism... ..	19	Resetting the alighting-gear and bomb/flare-doors emergency controls	28
Combined time-release and breech unit.	4	Fire protection system	22		
Control column snatch unit		Aircraft-destroyer stowage	23		
◀ (post Mod. 4435)	5 ▶				
Hatch-jettisoning single-lever ejection (post Mod. 3776)	9				
Hatch-jettisoning mechanism boxes	10				
Secondary firing cable	13				
Alighting-gear emergency lowering control	14				

REMOVAL AND ASSEMBLY	
Ejection seats	29
Snatch unit	
Removal	30
Assembly	31
Elevator control tube severance unit	
Removal	33
Assembly	34

SERVICING	
Ejection seats	24
Combined time-release and breech unit	25

LIST OF ILLUSTRATIONS

	Fig.		Fig.
Control column snatch unit	1	Entrance-door jettisoning mechanism... ..	4
Hatch-jettisoning mechanism	2	Elevator control tube severance unit assembly	5
Alighting-gear and bomb/flare doors emergency selectors	3	Pilot's ejection seat removal (post Mod. 3518 or 4051)... ..	6

WARNING

The relevant safety precautions detailed on the LETHAL WARNING marker card must always be observed before entering the cabin or performing any operations upon the aircraft.

DESCRIPTION

General information

1. The emergency equipment comprises; Martin Baker ejection seats, with 'single-lever' facilities (post Mod. 4051 and 3776), for the pilot and crew;

provision for emergency lowering and raising of the alighting gear; fire detection and extinguishing systems; an aircraft destructor and provisions for jettisoning the entrance door, canopy, and crew hatch. Operating instructions are given in Sect. 1, Chap. 3.

Canopy and hatch

2. The pilot's canopy and the crew's escape hatch are attached to the fuselage by bolts containing detonators; both are jettisonable by operation of the associated jettison switches.

Ejection seats

3. The Type and Mark No. (Sect. 1, Chap. 1 & 2), are dependent upon the modification state of the aircraft. The seats are described in A.P. 109B-0101-1.

Combined time-release and breech unit

4. This unit provides the power to operate the snatch unit and incorporates a time-delay mechanism which withdraws the sear from the seat ejection-gun approximately one second after the snatch-unit gun has been fired. The snatch-unit gun and the time-delay

RESTRICTED





FIG. 1. CONTROL COLUMN SNATCH UNIT

◀ MOD. 4435 EMBODIED ▶

RESTRICTED

the snatch unit and incorporates a time-delay mechanism which withdraws the sear from the seat ejection-gun approximately one second after the snatch-unit gun has been fired. The snatch-unit gun and the time-delay mechanism are contained in separate compartments within a casing bolted to the rear of the guide rail. At the base of the snatch-unit gun is a threaded union which, together with a soft metal washer, forms a gas-tight connection with a pipe which communicates with the chamber of the piston valve assembly on the top of the snatch unit. For a description of the combined time-release and breech unit Pt.No.MBSJ/159 refer to A.P.109A-0001-1.

Control column snatch unit (fig.1)

5. This unit is fitted within the pilot's console on the port side of the cockpit and is connected to the elevator control-lever. Its purpose is to move the control column forward and hold it against the instrument panel to provide an unobstructed exit for the pilot in his ejection seat when abandoning the aircraft. An explosive severance-unit, fitted around the elevator control tube aft of the control lever and fired prior to the operation of the snatch unit, severs the elevator control tube which nullifies the effect the movement of the control column, due to the action of that snatch unit, would otherwise have upon the flying attitude of the aircraft.

6. The unit consists of a tubular casing supported at the rear end by a bracket and attached at the forward end to the aircraft structure by a collar secured to a mounting bracket by a retaining pin and split pin. The tubular casing houses a hollow piston which, when the unit is cocked, holds the mainspring under compression against the closed

rear end of the casing. The piston is retained in the cocked position by a sear, the roller of which projects through the wall of the tubular casing; the sear is spring-loaded in its cocked position by the sear return spring. A snatch-rod passes through the rear-end casing, inside the mainspring and through the drilled head of the hollow piston, to terminate in a shouldered end-fitting carry-a rubber cushion. The other end of the rod is screwed into a slotted attachment fitting and locked by a locknut; the length of the snatch rod can be adjusted at this point. The end of the slotted attachment fitting is drilled and bushed to fit on to a shouldered stud fitted to the elevator control-lever; the bush is radiused at one end and it is essential that this end faces the shouldered stud. The slot allows free movement of the snatch-rod, and the rod, which is of sufficient length to allow full fore-and-aft movement of the control column moves freely within the piston.

7. The snatch unit and the elevator-control-tube severance-unit detonator-switch (which is mounted on a bracket secured to the snatch unit) of post Mod.4051 aircraft are controlled by the ejection seat face-screen, or seat-pan, firing handle. When either handle is operated a cartridge is fired in the combined time-release and breech unit (para.4) from which the resultant gas pressure is directed through a pipe to a valve piston assembly mounted on the top of the snatch unit. The valve piston engages a boss on a bell-crank lever which is pivoted, at its centre, on the snatch unit and is interlinked at its lower end to the sear; its upper end is forked to engage the toggle of the detonator switch. The gas pressure forces the piston against the bell-crank lever which rotates on its axis. The lower

end of the lever withdraws the sear and the forked end operates the toggle of the detonator switch, the charge in the severance-unit being exploded before the snatch unit operates. Operation of the firing handle also trips the time release of the combined time-release and breech unit which withdraws the ejection gun sear, after a delay of one second, to initiate seat ejection.

8. The action of releasing the sear frees the hollow piston which, under the force of the mainspring, is propelled along the interior of the casing and contacts the end fitting of the snatch rod; further extension of the spring moves the snatch rod forward and, through the elevator control-lever, rotates the elevator torque-shaft and moves the control column forward against the instrument panel.

Hatch jettisoning single-lever ejection (post Mod.3776)

9. The single-lever ejection system for the crew member comprises Type 2.CA2, Mk.2 ejection seats and two hatch-jettisoning mechanisms which are secured to the rear face of the pressure bulkhead. The ejection guns of these seats have breech-type time-delayed firing units fitted with a restrictor and safety-catch (A.P.109A-0001-1), the latter being connected to the hatch by a secondary firing cable. The seat-firing cable is bifurcated, one leg being connected to the ejection gun sear and the other to the sear of the hatch-jettisoning mechanism.

Hatch-jettisoning mechanism boxes (fig.2)

10. These units are mounted on the aft face of the pressure bulkhead and are positioned behind each crew ejection seat; their purpose is to initiate automatic jettisoning of the hatch prior to ejection of either crew

RESTRICTED

COCKING OF HATCH JETTISONING MECHANISM

- 1 INSERT COCKING LEVER INTO COCKING LINK APERTURE.
 - 2 MOVE COCKING LEVER TO STARBOARD AND ENGAGE ON LOCKING PEG.
 - 3 HOOK FIRING CABLE ON SEAR: INSERT SEAR INTO PLUNGER SLOT TO A DEPTH OF APPROXIMATELY $2\frac{1}{2}$ IN. FROM BULKHEAD FACE.
- NOTE...
WHEN REFITTING SEAR, OPEN-END OF HOOK MUST BE TO δ ARBOARD.
- 4 SLIDE COCKING LEVER TO STARBOARD AND LIFT OFF PEG, COCKING LEVER SHOULD MOVE TO PORT APPROXIMATELY $\frac{1}{4}$ IN.
 - 5 RETURN COCKING LEVER TO STOWAGE BOX. CHECK TENSION ON FIRING CABLE TO ENSURE SEAR IS LOCKED IN MECHANISM.




Fig. 2. Hatch-jettisoning mechanism

RESTRICTED

mechanism are contained in separate compartments within a casing bolted to the rear of the guide rail. At the base of the snatch-unit gun is a threaded union which, together with a soft metal washer, forms a gas-tight connection with a pipe which communicates with the chamber of the piston valve assembly on the top of the snatch unit. For a description of the combined time-release and breech unit Pt.No.MBSJ/159 refer to A.P. 109A-0001-1.

Control column snatch unit

◀ (post Mod. 4435) (fig. 1) ▶

5. This unit is fitted within the pilot's console on the port side of the cockpit and is connected to the elevator control-lever. Its purpose is to move the control column forward and hold it against the instrument panel to provide an unobstructed exit for the pilot in his ejection seat when abandoning the aircraft. An explosive severance-unit, fitted around the elevator control tube aft of the control lever and fired prior to the operation of the snatch unit, severs the elevator control tube which nullifies the effect that movement of the control column, due to the action of the snatch unit, would otherwise have upon the flying attitude of the aircraft.

6. The unit consists of a tubular casing supported at the rear end by a bracket and attached at the forward end to the aircraft structure by a collar secured to a mounting bracket by a retaining pin and split pin. The tubular casing houses a hollow piston which, when the unit is cocked, holds the mainspring under compression against the closed rear end of the casing. The piston is retained in the cocked position by a sear, the roller of which projects through the wall of the tubular casing; the sear is spring-loaded in

its cocked position by the sear return spring. A snatch-rod passes through the rear-end casing, inside the mainspring and through the drilled head of the hollow piston, to terminate in a shouldered end-fitting carrying a rubber cushion. The other end of the rod is screwed into a slotted attachment fitting and locked by a locknut; the length of the snatch rod can be adjusted at this point. The end of the slotted attachment fitting is drilled and bushed to fit on to a shouldered stud fitted to the elevator control-lever; the bush is radiused at one end and it is essential that this end faces the shouldered stud. The slot allows free movement of the snatch-rod, and the rod, which is of sufficient length to allow full fore-and-aft movement of the control column, moves freely within the piston.

7. The snatch unit and the elevator-control-tube severance-unit detonator switch (which is mounted on a bracket secured to the snatch unit) are controlled by the ejection seat face-screen, or seat-pan, firing handle. When either handle is operated a cartridge is fired in the combined time-release and breech unit (para. 4) from which the resultant gas pressure is directed through a pipe to a valve piston assembly mounted on the top of the snatch unit. The valve piston engages a boss at the interconnection of the sear operating lever and the microswitch operating lever. The sear operating lever is pivoted at its centre on the snatch unit and is interlinked at its lower end to the sear; the microswitch operating lever, which is pivoted on the mounting plate, has an adjustable tappet at its switch end and a stop face at the other end, which bears against the breech casing of the valve piston assembly. The gas pressure forces the piston against the boss and rotates both levers, the sear operating

lever withdraws the sear and the microswitch operating lever operates the microswitch, the severance unit being exploded before the snatch unit operates. Operation of the firing handle also trips the release of the combined time-release and breech unit which withdraws the ejection gun sear, after a delay of one second, to initiate seat ejection.

8. The action of releasing the sear frees the hollow piston which, under the force of the mainspring, is propelled along the interior of the casing and contacts the end fitting of the snatch rod; further extension of the spring moves the snatch rod forward and, through the elevator control-lever, rotates the elevator torque-shaft and moves the control column forward against the instrument panel.

Hatch jettisoning single-lever ejection (post Mod. 3776)

9. The single-lever ejection system for the crew members comprises Type 2 CA 2, Mk. 2 ejection seats and two hatch-jettisoning mechanisms which are secured to the rear face of the pressure bulkhead. The ejection guns of these seats have breech-type time-delayed firing units fitted with a restrictor and safety-catch (A.P. 109A-0001-1), the latter being connected to the hatch by a secondary firing cable. The seat-firing cable is bifurcated, one leg being connected to the ejection gun sear and the other to the sear of the hatch-jettisoning mechanism.

Hatch-jettisoning mechanism boxes (fig. 2)

10. These units are mounted on the aft face of the pressure bulkhead and are positioned behind each crew ejection seat; their purpose is to initiate automatic jettisoning of the hatch prior to ejection of either crew

RESTRICTED

COCKING OF HATCH JETTISONING MECHANISM

- 1 INSERT COCKING LEVER INTO COCKING LINK APERTURE.
- 2 MOVE COCKING LEVER TO STARBOARD AND ENGAGE ON LOCKING PEG.
- 3 HOOK FIRING CABLE ON SEAR: INSERT SEAR INTO PLUNGER SLOT TO A DEPTH OF APPROXIMATELY $2\frac{1}{2}$ IN. FROM BULKHEAD FACE.

NOTE...
WHEN REFITTING SEAR, OPEN-END OF HOOK MUST BE TO STARBOARD.

- 4 SLIDE COCKING LEVER TO STARBOARD AND LIFT OFF PEG. COCKING LEVER SHOULD MOVE TO PORT APPROXIMATELY $\frac{1}{4}$ IN.
- 5 RETURN COCKING LEVER TO STOWAGE BOX. CHECK TENSION ON FIRING CABLE TO ENSURE SEAR IS LOCKED IN MECHANISM.




Fig. 2. Hatch-jettisoning mechanism

RESTRICTED

on the shaft of the door-jettisoning handle. The horizontal shaft is carried in three bearings, one at either end and one, a double bearing, in the centre; the centre bearing, in addition to locating the wormwheel, also forms the bearing for the shaft of the jettisoning handle. Stop pins, fitted to the forward end bearing, are contacted by a stop on the horizontal shaft to register the position of the hinge-pin cups on the ends of the horizontal shaft. Similar cups are freely pivoted in the front and rear bearing housings, the space between the two cups in each housing accommodating the door hinge brackets.

20. The door carries two hinge brackets on its upper frame, each bracket having a freely-rotating hinge-pin which extends outward on either side. The hinge-pins are accommodated in the hinge-pin cups which, in the safe condition, are rotated so that their slots are facing inboard, thereby forming sockets in which the hinge-pins are retained. The position of the hinge pins relative to the cups is adjusted during initial assembly by guide bolts which project through the inboard face of the bearings and bear on the inner face of the door hinge brackets.

21. When the door is assembled to the fuselage and the mechanism is in the safe condition, the slots of the hinge-pin cups are facing inboard and the door is retained in the door aperture; in this condition the jettisoning handle has been rotated in a counter-clockwise direction. To jettison the door, the handle is rotated in a clockwise direc-

tion, thereby revolving the horizontal shaft and hinge-pin cups until their slots face outboard and permit the door to fall away from the aircraft. To facilitate ground servicing the door may be removed by this means.

Fire protection system

22. Refer to Sect. 4, Chap. 5.

Aircraft destructor stowage

23. This is attached to the inner surface of the starboard equipment bay door.

SERVICING

WARNING

The relevant safety precautions detailed on the LETHAL WARNING marker card must always be observed before entering the cabin or performing any operations upon the aircraft.

Ejection seats

24. Refer to A.P. 109B-0101-1.

Combined time-release and breech unit

25. Refer to A.P. 109A-0001-1.

Cocking the snatch unit

26. Refer to fig. 1.

Cocking the hatch-jettisoning mechanism boxes

27. Refer to fig. 2.

Resetting the alighting-gear and bomb/flare doors emergency controls

28. Both procedures are similar. In the case of the alighting-gear control,

press in the ends of the spring lock in the shaft and push the handle into its housing; in that of the bomb/flare doors control, move the leaf-spring outboard and return the handle to the up position. After resetting the controls, lock the handles in position with 20 s.w.g. aluminium wire joined at the ends by a lead seal, and check that the levers on the respective selectors have been returned to the off position and that they are bearing on their stops. Repack the sealing washers where the cables pass through the pressure bulkhead (Sect. 3, Chap. 8).

REMOVAL AND ASSEMBLY

Ejection seats

29. Refer to fig. 6 and A.P. 109B-0101-5.

Snatch unit

Removal

30.

(1) Disconnect all normal, emergency and ground electrical supplies.

(2) Remove the time-release and breech unit cartridge (A.P. 109A-0001-1).

(3) Remove the elevator severance unit detonator (para. 33(1-4)).

(4) Remove the forward inboard side panel from the pilot's console.

(5) Disconnect the microswitch electrical leads at the six-way terminal block.

(6) Remove the locking wire and dis-

connect the gas pipe from the valve piston chamber.

(7) Remove the stiffnut and washer and disconnect the snatch rod from the elevator control lever.

(8) Remove the split pin from the tubular casing forward retaining pin and withdraw the retaining pin from the mounting bracket.

Assembly

31. This is the reverse of the removal procedure but the following points should be noted:-

(1) The microswitch clearance is to be as shown in fig.1.

(2) After assembly make electrical checks (Sect.5, Chap.1, Group W).

(3) The snatch unit may be tested as detailed in the relevant Servicing Procedure detailed in A.P.101B-0406-5A3.▶




Fig.5. Elevator control tube severance unit assembly

32. Upon completion of the instructions detailed in the previous paragraph, and whenever the elevator control circuit is readjusted or the snatch unit is test fired and reset:-

(1) Move the control column aft until the elevator bulkhead stop is contacted, at the same time closely observing the sear return spring and the sear operating lever on the snatch unit for movement.

(2) Movement indicates that the snatch rod is fouling the sear which may result in premature operation of the snatch unit. Where movement is found, check, and if necessary adjust, the setting of the elevator bulkhead stops (Chap.4).

(3) Check, by applying hand pressure to the snatch-unit rod, that, with the control




Fig. 6. Pilot's ejection seat removal (post Mod. 3518 or 4051)

on the bulkhead stop, it is capable of 1/16in to 1/8in free travel between contacting the end of the slot in its attachment fitting at the elevators control lever, and contacting the sear. If necessary adjust the length of the snatch rod (*para.6*).

Elevator control tube severance unit (*fig.5*)

Removal

33. (1) Disconnect the normal, emergency and ground supplies.

(2) Remove the centre access panel from the inboard side of the pilot's console.

(3) Disconnect the terminal leads from the terminal block mounted on the elevator control tube.

(4) Unscrew the detonator-securing nut from the housing in the top half of the severance unit and remove the detonator.

WARNING

Before handling detonators, refer to the **LETHAL WARNING** marker card at the beginning of this book.

(5) Check that a red line has been painted on the control tube, on either side of the severance unit and terminal block clamp assembly. If the lines are missing or indistinct paint accordingly.

(6) Supporting the lower half of the severance unit, remove the nuts from the bolts securing the two halves and remove the bolts.

(7) Remove the severance unit from the control tube.

Assembly

34. This is the reverse of the removal procedure, but the following points are to be noted:

(1) Ensure that the severance unit and terminal block clamp assembly are correctly positioned and secured i.e., cannot rotate between the two red lines on the control tube (*para.33(5)*). The lower half of the terminal block clamp should bear against the lower spoke nipple securing the attachment at the forward end of the control tube,

and the cut-away in the upper half of the clamp should overlap the upper rear nipple (*fig.5*). The severance unit must be assembled to bear against the rear face of the terminal block, ensure vertical alignment.

(2) When tightening the bolts securing the two halves of the severance unit, pull the nuts up evenly, in turn, until the tube is gripped firmly by the unit and the rubber inserts between the two halves are compressed.

(3) Ensure that the detonator rests on the explosive charge before tightening the detonator-securing nut. For information upon assembly of the detonator refer to A.P.1661F, Vol.1, Sect.6.

35. After refitting the access panel removed in *para.33(2)* move the control column through its full travel fore-and-aft and ensure that the severance unit does not foul the access panel or the surrounding structure.

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

