

Chapter 6 HYDRAULIC SYSTEMS

LIST OF CONTENTS

DESCRIPTION	Para.		Para.		Para.
General information	1	Flaps	29	Services system	
Power supplies	3	Autostabilizer actuators	30	Filling and bleeding the reservoir	53
Hand pump	4	Tail-plane and rudder feel system	31	Priming and bleeding the engine-	
Reservoirs	5	Canopy	32	driven pumps and hand pump	54
Reservoir air supply		Two-missile pack... ..	33	Bleeding the pressure lines	55
Main	8	Pressure gauge	34	Bleeding the service lines	56
Auxiliary... ..	9	Controls systems		Bleeding the return lines	57
Heat exchangers	10	Ailerons	35	Bleeding the autostabilizer	
Off-load circuit	11	Tail plane... ..	36	actuators after renewal or	
Relief valves	12	Rudder	37	malfunction	58
Pressure switches... ..	13	Braking parachute doors	38	Controls systems	
Pressure regulator	14	Alighting gear emergency lowering	39	Filling and bleeding the reservoirs	59
Protection unit	15			Priming and bleeding the engine-	
Accumulators - system location, access				driven pumps	60
and nitrogen inflation pressures	16			Bleeding the pressure lines... ..	61
Accumulator gauges	17			Bleeding the return lines	62
Services system				Bleeding after replacement of the	
Alighting gear				pressure filters	63
General information	18			Bleeding systems of laid-up aircraft	
Main undercarriage				At commencement of lay-up	64
UP selection	19			During any seven concurrent days	
DOWN selection	20			of a lay-up	65
Nose undercarriage				Before first engine run	
Shimmy damping	21			following lay-up	66
UP selection	22			During first engine run	
DOWN selection	23			following lay-up	67
Emergency lowering	24			Bleeding jacks before installation	68
Wheel brakes	25			Filters - tail-plane p.f.c.u	69
Air brakes				Filter elements Ref.No. 26DK/12140 -	
General information	26			renewing	70
OUT selection	27			Scavenging No.1 and No.2 controls	
IN selection	28			systems	71
				No.1 controls	
				Pressure pipelines	72

continued...

RESTRICTED

LIST OF CONTENTS - continued

	Para.		Para.		Para.
Return pipelines	73	Accumulator capacity test	89	Tests after fitting a replacement	
Suction pipelines	74	Canopy	90	controls system engine-driven pump	
No. 2 controls		Pressure gauge	91	(F Mk.1 post Mod.1814 and all	
Pressure pipelines	75	Services operating times	92	F Mk.1A)... ..	106
Return pipelines	76	No.1 and No.2 controls systems		Braking parachute release	
Suction pipelines	77	Rudder	93	mechanism	107
Functioning tests		Pressure test... ..	94		
Precautions	78	Operational test	95		
Services system		Tail plane	96		
Preparation	79	Operational test	97		
Alighting gear		Accumulator capacity test... ..	98		
Nose-wheel centring... ..	80	Motor test	99		
Operation and correct locking	81	Ailerons	100		
Rates of operation	82	Pressure test... ..	101		
Sinking... ..	83	Operational test	102		
Emergency retraction	84	Accumulator capacity test... ..	103		
Emergency lowering	85	P.f.c.u. leakage check	104		
Flaps	86	Tests after fitting a replacement			
Air brakes	87	controls system engine-driven pump			
Wheel brakes	88	(F Mk.1, pre Mod.1814)	105		

REMOVAL AND ASSEMBLY

General information	108
Reservoirs	
Services and No.1 controls	
systems	109
No.2 controls system... ..	110
Auxiliary	
Removal	111
Installation	112
Reservoir bladder	
Removal	113
Installation	114
Testing	115

LIST OF TABLES

	Table		Table
Torque loading of stainless steel pipe		Services operating times in seconds	3
assemblies... ..	1	Tools and equipment	4
◀ Torque loading of bonded seals	1A ▶	Major components - frames 1-25A	5
Accumulators - system location,		Major components - frames 25B-50	6
access and nitrogen inflation		Major components - frames 50-63	7
pressures	2	Major components - main planes	8

LIST OF ILLUSTRATIONS

	Fig.		Fig.		Fig.
Power supplies	1	Services system - autostabilizers		Location of major components -	
Fluid reservoir	2	and feel units	5	frames 25B-50	9
Services and No.1 controls systems -		Services system - two-missile pack... ..	6	Location of major components -	
alighting gear	3	No.1 and No.2 controls systems	7	frames 50-63	10
Services system - flaps, wheel brakes,		Location of major components -		Location of major components -	
air brakes and canopy	4	frames 1-25A	8	main planes... ..	11

DESCRIPTION

General information

1. Three independent systems operate the flying controls and services. These systems, and the components for which they provide pressure, are:-

(1) *Services system*
(two engine-driven pumps)

Alighting gear
Wheel brakes
Air brakes
Flaps
Nose-wheel centring
Autostabilizer actuators
Feel units
Canopy
Two-missile pack

(2) *No.1 controls system*
(one engine-driven pump)

Aileron p.f.c.u. (outboard)
Tail-plane p.f.c.u. (port motor)
Rudder p.f.c.u. (forward piston)
Alighting gear emergency lowering
Braking-parachute doors

(3) *No.2 controls system*
(one engine-driven pump)

Aileron p.f.c.u. (inboard)
Tail-plane p.f.c.u. (stbd. motor)
Rudder p.f.c.u. (aft piston)

2. Mod. Lightning 18 is embodied in all Mk.1A aircraft. This provides for the substitution of all tungum pipelines of the system - with the exception of those along the starboard leading edge in the compass detector field - by stainless steel pipes. Colour

identification markings and direction-of-flow indicators are also introduced by this modification.

Power supplies (fig.1)

3. Power for the three systems is supplied by four engine-driven pumps, mounted in pairs on the external wheel-case of each engine; the forward pumps jointly power the services system and the aft pumps the No.1 and No.2 controls systems respectively. The pumps are the two-stage type, the first stage consisting of a pair of meshing gears, and the second stage, seven pistons in radially-disposed cylinders, operated by an eccentric driving ring; when maximum line pressure is attained the pumps commence to off-load the fluid to the reservoirs via the by-pass circuit. Each pump embodies a magnetic filter element located in the by-pass chamber of the gear housing. To maintain the minimum pressure of 2700 lb/in² required when the two-missile pack alternator motor is running, a pressure regulator and a non-return valve (para.14) are interposed between the services No.1 and No.2 pump delivery lines.

Hand pump

4. A hand pump, located behind access panel 75P, is provided for ground operation of the services system. The pump handle is detachable, and is stowed in the port wheel well. The pump handle attachment is accessible behind panel 79P.

Reservoirs (fig.2)

5. Four (three main and one auxiliary)

reservoirs are in the fuselage:-

Services system: one reservoir, between frames 50 and 51, port.

No.1 controls system: two reservoirs (one auxiliary) between frames 46 and 47, and frames 50 and 51, port.

No.2 controls system: one reservoir, between frames 51 and 52, starboard.

6. The three main reservoirs are identical, each comprising a cylindrical metal body containing a bladder in which fluid is stored. A junction head, fitted to the base of each reservoir, is drilled and tapped to provide connections for delivery fluid to the pump, return fluid from the pump and system, reservoir fluid drain, and compressed air. Fluid is drawn through holes in a tube positioned centrally in the bladder, and passes, through a hollow bolt forming the suction connection to the pump. Return fluid from the pump or system enters the reservoir through a banjo connection and passes around the outside of the hollow bolt and through cross drillings in the junction head, to enter the bladder through a filter.

7. Protection against over-pressurizing is provided by a relief valve set to discharge at 35±1 lb/in². The services reservoir relief valve also functions to relieve excess fluid when an emergency lowering of the alighting gear is made. The reservoir drain connection on the junction head is fitted with a pipe which is taken to the top

RESTRICTED




FIG.1. POWER SUPPLIES

RESTRICTED

of the reservoir, and blanked with a cone cap. The purpose of the auxiliary reservoir fitted between the No.1 controls main reservoir and the engine-driven pump is to increase the capacity of the system to provide for alighting gear emergency lowering. This reservoir is similar in construction to the main reservoirs, the junction head containing fluid and air connections.

Reservoir air supply (fig.1)

Main

8. The main reservoirs are supplied with air at 16-18 lb/in² from the engine compressors. A non-return valve in the system retains the pressure and isolates the reservoirs from the rest of the auxiliary air system. Air enters each reservoir at the junction head connection and passes into the space between the bladder and the cylinder walls. As the bladder becomes fully charged with fluid, it is expanded against the cylinder walls, and the surrounding air is expelled through a relief valve, set at 22 lb/in². As fluid is withdrawn by the pumps, the bladder collapses, and the fluid volume is replaced by air on the outside of the bladder. An air-charging and release valve, serving the reservoirs, is located behind access panel 63P.

Auxiliary

9. The auxiliary reservoir has an atmospheric head which allows ingress of air at atmospheric pressure and spillage of air (fluid in the case of bladder failure) at pressure in excess of normal main reservoir pressure. The

reservoir bladder is thus maintained in a stable condition of inflation and its life correspondingly prolonged.

Heat exchangers (fig.1)

10. Off-load fluid from each pump is cooled by circulation through a heat exchanger in the pump by-pass line. The heat exchangers are connected to the main-plane integral fuel tanks delivery pipes, the fuel being the cooling medium. Each exchanger is divided into two heat-transfer compartments, respectively cooling by-pass fluid from a controls or services pump.

Off-load circuit (fig.1)

11. In each of the three systems, fluid is drawn from the associated reservoir, or reservoirs, by the pumps, which commence to off-load at about 2650 lb/in². When fully off-loaded at 3000 lb/in², delivery ceases and the fluid is returned to the reservoir via a heat exchanger, a non-return valve and a filter.

Relief valves

12. Relief valves safeguard the alighting-gear circuit in the event of a pressure rise in excess of 3600 lb/in². The valves are located as follows:-

- (1) One pressure relief valve in each main and nose undercarriage up line.
- (2) One thermal relief valve in No.1 controls pressure line to the emergency selector.
- (3) One thermal relief valve embodied in the protection unit.

Pressure switches


13. A pressure switch, set to close at 1750 lb/in², is provided in the pressure line of both No.1 and No.2 controls systems. The switches are each in circuit with an associated power failure warning on the auxiliary warnings indicator panel. In the event of pressure failure of both systems, an additional warning on the standard warning system indicator unit, together with the attention lamp, becomes illuminated. The No.1 controls pressure switch is located in the front fuselage between frames 22 and 23 port side, and is accessible behind panel 26P; the No.2 controls pressure switch is fitted on the aft face of frame 55, rear fuselage star-board side, and is accessible behind panel 72S.

Pressure regulator

14. The pressure regulator, interposed between the two services system pumps, works in conjunction with a non-return valve in a by-pass line to isolate the two pumps unless the following conditions prevail:-

- (1) No.1 pump pressure exceeds 2700 lb/in² (required to run the alternator motor in the two-missile pack) and the pressure is greater than that being delivered by No.2 pump.
- (2) No.2 pump pressure is greater than that of No.1 pump.
- (3) When condition (1) is current the pressure closes the non-return valve and displaces the spring-loaded piston in the regulator which opens a port and

RESTRICTED



★ ITEMS MARKED THUS ARE FITTED DURING ASSEMBLY OF THE RESERVOIR TO THE AIRCRAFT

FIG.2. FLUID RESERVOIR

RESTRICTED

allows the pressure to augment that of No. 2 pump. When condition (2) arises the pressure opens the non-return valve and assists No. 1 pump.

Protection unit

15. The protection unit ensures that, in a case of services pressure failure, the alighting gear can be lowered by using No. 1 controls system pressure via the emergency selector. In normal conditions this pressure retains a piston in the upper position, allowing free flow of services pressure to the normal alighting-gear selector. When the emergency system is used the emergency selector redirects No. 1 controls system pressure to the opposite side of the piston which moves down and closes a valve to isolate the services pressure line, and opens another valve to connect the normal selector, irrespective of its setting, to return. The services system is protected from pressure fluctuations by an integral non-return valve at the inlet connection, and a relief-valve which vents fluid to return if the normal working pressure is exceeded.

Accumulators - system location, access and nitrogen inflation pressures (Table 2)

16. Eight accumulators in the controls and services systems hold, under nitrogen pressure, a reserve volume of fluid which minimizes fluctuations of pressure when heavy fluid demands are being made; they also provide power for a limited number of operations of the flying controls and certain components if hydraulic failure occurs. To extend

this period for the flying controls, braking parachute and alighting gear emergency lowering, the accumulators serving them are provided with separate nitrogen bottles. An accumulator provided for the nose-wheel shimmy damper is charged with hydraulic fluid only. Table 2 gives a list of the accumulators, the components they serve, access and charging pressures.

Accumulator gauges

17. Miniature gauges, fitted in the fuselage skin, provide an indication of hydraulic pressure in the accumulators. With the exception of the feel unit damping accumulator the gauge dials are calibrated 0-4 and the readings must be multiplied by 1000 to give the true reading in pounds per square inch. The dial of the feel unit damping accumulator gauge is calibrated 0-2 and the reading must be multiplied by 100 to give the true reading. For details of gauge positions and types, refer to Tables 5, 6 and 7 and their associated illustrations.

SERVICES SYSTEM

Alighting gear

General information

18. Two push switches in the cockpit, marked UP and DOWN respectively, control operation of the alighting gear. Pressing a switch to either of the two marked positions, UP or DOWN, energizes one of two solenoids integral with the alighting-gear selector which, according to the selection made, operates valves to direct fluid to the appropriate ends of

the jacks, and opens the opposite lines to return. A pitot-operated pressure switch, connected into the alighting gear up electrical circuit, renders the up switch inoperative below an actual or simulated air speed of 150 ± 5 knots. For details of the electrical circuit, refer to Sect. 6, Chap. 5. Emergency lowering of the alighting gear is controlled by a lever, to port of the pilot's seat, connected by cable to an emergency selector (*Chap. 11*). A protection unit, installed between the pumps and the selector unit, ensures that, when the emergency lowering system (*para. 24*) is used, all up lines in the alighting-gear circuits are connected to return irrespective of the setting of the normal selector.

Main undercarriage (*fig. 3*)

19. UP selection.- When an UP selection is made, the pumps deliver fluid to each undercarriage down-lock jack, to the undercarriage jack via the open sequence valve, and to the closed wheel-well door sequence valve; the latter valve ensures that the door retraction jack up line is vented to suction return, thus preventing door movement until the strut is retracted. The undercarriage down-lock (in the radius rod) is released hydraulically and the main jack functions to raise the undercarriage which, on its final movement, contacts the trip mechanism on the door sequence valve to open the valve. With the sequence valve open, fluid is directed to the door jack and to the door up-lock jack; the internal locking mechanism in the door jack is released and the jack operates to close the door. Finally, when the




FIG. 3. SERVICES AND NO.1 CONTROLS SYSTEMS—ALIGHTING GEAR

trip pin on the door strikes the toggle lock in the master door-lock mechanism (Chap. 5), the up-latch jack retracts, operating the door latch hooks to lock the door.

20. *DOWN selection.*- A DOWN selection causes pressure to be directed to the door up-lock jacks, door jacks, and undercarriage jacks. On each undercarriage, the door up-lock jack operates to disengage the door latching mechanism, then the door jack extends to open the door which, when fully open, is locked by an internal mechanism in the jack. The final opening of the door causes contact to be made with the trip mechanism of the undercarriage sequence valve which opens to permit fluid transfer between the undercarriage jack and the reservoir via the up line. The undercarriage jack then retracts to lower the undercarriage which, when fully down, is locked by the spring-loaded down-lock jack in the radius rod.

Nose undercarriage (fig. 3)

21. *Shimmy damping.*- The nose undercarriage is equipped with a hydraulic shimmy damper and centring unit. The unit receives pressure from the nose undercarriage shimmy damper accumulator which, in turn, can be pressurized from the services system. The accumulator has a main and a secondary piston, the former being influenced by hydraulic pressure and the latter by the accumulator spring and by a mechanical connection with hydraulic pressure when alighting gear UP is selected. The shimmy damper is pressurized for castering and shimmy damping on touchdown, by

the basic spring pressure of 60-70 lb/in² exerted by the accumulator spring.

22. *UP selection.*- When an UP selection is made, fluid is directed to the undercarriage down-lock jack, the by-pass valve and the undercarriage jack. The lock-jack extends to disengage the lock, and the undercarriage jack retracts to raise the undercarriage. The up line pressure to the by-pass valve operates the valve to cut off the services suction return line from one side of the nose undercarriage shimmy-damper accumulator main piston, and to connect services pressure in its place. The main piston is directly connected, on its opposite side, with services pressure but, the effective piston area on this side being the lesser of the two, the resultant differential force causes a movement of the main piston towards the secondary piston. Mechanical contact of the main piston extensions with the secondary piston increases the shimmy-damping pressure of 60-70 lb/in², exerted by the accumulator spring, to 685 lb/in², thus ensuring that the wheel is centred and locked. The undercarriage is finally locked in the up position by the locking plunger housed in the strut (Chap. 5).

23. *DOWN selection.*- When a DOWN selection is made, pressure fluid is directed to the by-pass valve and to the up-lock jack, and to the undercarriage jack via the shuttle valve. The by-pass valve functions to cut off services pressure from the valve to the nose undercarriage shimmy-damper accumulator, and to by-pass the supply line

to services suction return. The direct services pressure to the accumulator then moves the main piston extensions out of contact with the secondary piston. The up-lock jack operates to disengage the locking mechanism, and the undercarriage jack extends to lower the undercarriage, which is finally locked mechanically. A one-way restrictor in the up-line, between the jack and the by-pass valve, limits the rate of return flow, to prevent the strut lowering too quickly; the pipeline upstream of the restrictor is protected by a 3600 lb/in² relief valve. For the operation of the undercarriage doors, linkage and mechanical locks, refer to Chap. 5.

Emergency lowering (fig. 3)

24. The emergency selector directs No. 1 controls pressure to:-

- (1) Close a valve in the protection unit to isolate services pressure from the normal selector.
- (2) Open a valve in the protection unit to connect the normal selector input to return, so ensuring that all up circuits in the system are connected to return irrespective of the setting of the normal selector.
- (3) Apply pressure to the by-pass valve to move the shuttle to the nose undercarriage down position.
- (4) Simultaneously apply pressure to:-
 - (a) The emergency side of the relay valves.

RESTRICTED




FIG. 4. SERVICES SYSTEM - FLAPS, WHEEL BRAKES, AIR BRAKES AND CANOPY

A2290-2

RESTRICTED

(b) The emergency side of the shuttle valves on the main and nose undercarriage jacks.

(c) The emergency side of the shuttle valves on the main undercarriage door jacks and door up-lock jacks, and the nose undercarriage up-lock jack.

The door up-lock jacks and the door jack shuttle valves of each main undercarriage are displaced, and the door unlocked and opened, by emergency pressure which also opens a port in the relay valve, allowing return fluid to by-pass the closed sequence valve. Fluid entering the undercarriage jack via the shuttle valve lowers the undercarriage. Return fluid is passed to the services system reservoir through the up-line via the normal selector unit and the protection unit. In the nose undercarriage, emergency pressure operates the up-lock jack and the undercarriage jack after displacing the shuttle valves. Shimmy damping is effected normally by the pressure imparted by the nose undercarriage shimmy-damper accumulator spring.

Wheel brakes (fig. 4)

25. The wheel brakes are applied by means of a lever on the control column handle, which tensions a cable connected, to the brake control unit which transmits hydraulic pressure to the brakes up to 1500 lb/in², the pressure applied being proportional to the degree of displacement of the control lever and, for steering purposes, the rudder pedals to which the unit is connected

by a lost motion linkage. Pressure is supplied from the wheel-brakes and services system accumulators; non-return valves in the line on the pump side of the accumulators isolate them to maintain a reserve of pressure. From the brake control unit, pressure is transmitted to each brake via a Maxaret anti-skid unit; when pressure is released, the fluid is connected to return through the open Maxaret return valve. A Maxaret unit is mounted on each undercarriage leg; should excessive deceleration occur and wheel locking be imminent, the units release brake pressure and allow the wheels to revolve; the cycle then recommences, ensuring that maximum tyre adhesion is maintained. An indicator registering brake pressure available, from 0 to 4000 lb/in², is mounted on the starboard console and is operated electrically by a pressure transmitter. Between the transmitter and the accumulator is a pressure relay valve, which seals off the system in the event of leakage or failure in the single line to the pressure transmitter.

Air brakes (fig. 4)

General information

26. The air brakes take the form of two forward-opening doors fitted one on each side of the fuselage, just forward of the fin. They are each operated by a jack, through a selector unit, and controlled by a switch mounted on the No. 2 engine throttle lever. The switch has three positions - IN, OUT, and centre off - and is spring-loaded to the centre off position. Operation of the switch energizes one of two solenoids in the

electro-hydraulic selector unit, causing a slide valve to be displaced to connect the appropriate ends of the jacks to pump supply, and the opposite ends to return. A Mach pressure switch in the electrical circuit to the selector prevents the air brakes opening or, if they are already open, closes them at a predetermined Mach number. A mechanical linkage from each brake is connected to control levers on the synchronizing valve unit. When IN or OUT selections are made, the levers will move equally if the jacks are synchronized. If, however, one brake tends to lead, the action of the control lever will cause the relevant metering valve in the synchronizing valve unit to be throttled until synchronization is effected.




OUT selection

27. When air brakes OUT is selected, fluid from the services pump is directed by the selector, via a synchronizing valve unit, to the lock jacks and the brake jacks. The locks disengage, and the brake jacks extend and pivot to open the brakes. Return fluid from the brake jacks and lock jacks is passed via the selector to the reservoir.

IN selection

28. When air brakes IN is selected, fluid from the pumps is directed by the selector to the brake jacks, which retract to close the brakes. When fully closed, the brakes are locked mechanically (Chap. 4F). Return fluid from the jacks passes through the synchronizing valve and the selector valve to the reservoir.

RESTRICTED



NUMBERS REFER TO MAJOR COMPONENT TABLES:-
0.99 SERIES, FR. 1-25A
100 SERIES, FR. 25B-50
200 SERIES, FR. 50-63
300 SERIES, MAIN PLANKS

FIG.5. SERVICES SYSTEM - AUTOSTABILIZERS AND FEEL UNITS

A22961

RESTRICTED

Flaps (fig.4)

29. The two-position flap selector on the port coaming panel is in circuit with an electro-hydraulic selector unit. Pressure fluid is supplied by the services pumps and directed by the selector to the up or down connections of the four jacks; return fluid is directed via the selector to the reservoir. To prevent abrupt trim changes, restrictors are fitted in the up and down lines to each jack. Internal mechanical locks in each jack give positive locking in the up position, and a transmitter, linked to each flap, is in circuit with a twin-dial position indicator, fitted on the port instrument panel. A switch, operated by pitot pressure, ensures that the flaps are automatically raised at air speeds above 250 knots.

Autostabilizer actuators (fig.5)

30. Operating pressure for the aileron, rudder and tail-plane autostabilizer actuators (Chap.4C, 4D and 4E respectively) is provided by the autostabilizer actuator accumulator (access panel 66S). Each actuator has a filter in its pressure line; a non-return valve, on the pump side of the accumulator, isolates accumulator pressure from all services except autostabilization and feel simulation.

Tail-plane and rudder feel system (fig.5)

31. A simulated-feel system provides artificial tail-plane and rudder feel, and prevents excessive control surface movement at high air speeds. Operating pressure is supplied by the autostabi-

lizer actuator accumulator. The system is based on a feel simulator control unit (A.P.4604Z, Sect.1, Chap.8) and two hydraulic feel units. Interaction between the feel units, due to rapid operation of the controls, is absorbed by the feel unit damping accumulator. An electro-hydraulic feel selector is operated by a two-position switch in the cockpit and, when feel ON is selected, a slide in the selector operates to direct metered pressure from the feel simulator to the feel unit damping accumulator and the two feel units; when the switch is set to OFF, the slide in the selector moves to connect the feel units and the accumulator to return, so cancelling hydraulic feel. A by-pass valve, fitted between the selector and the rudder feel unit, is subjected to alighting gear up and down pressures on opposing sides. When alighting gear DOWN (normal or emergency) selection is made, the by-pass valve connects the rudder feel unit to return, so cancelling rudder hydraulic feel, which is

re-introduced when alighting gear UP is selected.

Canopy (fig.4)

32. The canopy is opened and closed by a jack which is in circuit with the services system accumulator and is controlled through an electro-hydraulic selector by either of two switches. The location of the switches and a description of the mechanical locks will be found in Chapter 1A. Both switches have three positions - OPEN, CLOSE, and centre off - and are spring-loaded to the latter position. An OPEN selection of either switch operates the selector to direct pressure fluid through a two-way restrictor to the jack, which extends to open the canopy; return fluid passes through a two-way restrictor and the selector to the reservoir. Movement of the canopy may be arrested at any point between the closed and fully-open position by releasing the spring-loaded switch; the selector thereupon returns to neutral, locking the canopy hydraulically in the selected position. The canopy is closed by making the appropriate selection with either switch. Two indicator lamps above the F2B compass, illuminate when the canopy is not closed and locked, and a warning buzzer sounds whilst the canopy is moving.

Two-missile pack (fig.6)

33. The two-missile pack electrical supply is provided by an alternator driven by a hydraulic motor, both of which are installed in the pack. The motor is connected through a control valve and self-sealing couplings to the services system, and controlled by a




Fig.6. Services system -
two-missile pack D2276-1

RESTRICTED




FIG. 7. NO. 1 & NO. 2 CONTROLS SYSTEMS

RESTRICTED

solenoid-operated selector valve in circuit with the G.W. ARM switch/indicator in the cockpit.

Pressure gauge (fig.1)

34. A pressure gauge, operated by a pressure transmitter and indicating services system line pressure, is fitted above the standard warning panel. Selection of any service which has a heavy fluid demand will cause the gauge to fall rapidly and then gradually recuperate. In hydraulic pressure failure the gauge pointer falls to, and remains in, the red sector; electrical failure causes it to fall to the white sector.

CONTROLS SYSTEMS

Ailerons (fig.7)

35. Each aileron is moved by two p.f.c.u., power for the outboard control unit being supplied by No.1 controls system and for the inboard unit by No.2 controls system; effective aileron control is obtainable from either system should the other fail. Power for high rates of operation and for emergency use is augmented by the ailerons, No.1 and No.2 controls systems accumulators. The accumulator charging connections for both systems are situated behind access panel 27P. The control units are described in Chap.4C, and A.P.105D-0405-16AC.

Tail plane (fig.7)

36. The tail plane is moved by a p.f.c.u. which comprises a pair of screwjacks powered by two hydraulic

motors; an associated valve mechanism controls the direction of rotation (Chap.4E). Fluid for the port motor is supplied by the No.1 controls system, and that for the starboard motor by the No.2 controls system. The tail plane and rudder No.1 and No.2 controls systems accumulators assist the normal power supplies for high rates of operation and emergency use. Charging connections for the accumulators are accessible behind access panels 72S and 76P.

Rudder (fig.7)

37. The rudder is operated by a dual-piston p.f.c.u. (Chap.4D). Fluid is supplied to the forward and aft pistons by No.1 and No.2 controls systems respectively, each system employing its associated relay valve on the p.f.c.u. Both valves are directly operated by the pilot's controls through the common input linkage. The accumulators mentioned in para.36 also serve both rudder circuits.

Braking parachute doors (fig.7)

38. The braking parachute is streamed by pulling a control handle in the cockpit (Chap.13). The handle is connected, through a cable-and-pulley system, to the lever of the parachute selector which directs fluid from the No.1 controls system to the parachute doors jack. The jack is connected by cables to the doors (Chap.13) in such a manner that retraction causes the compartment doors to open. When the selector is positioned normally, both sides of the jack piston are connected to return, permitting the jack ram to be reset manually.

Alighting gear emergency lowering

39. No.1 controls system is used for alighting gear emergency lowering. The emergency system is described in para.24.

SERVICING

WARNING

The relevant safety precautions detailed on the LETHAL WARNING marker card must always be observed before entering the cockpit or performing any operations upon the aircraft.

Note...

1. If, at any time, it is necessary to remove ten or more pipes from the controls systems, the scavenging instructions (para.71-77) must be carried out in full.
2. Bonding is to be restored to its previous state following breakdown of systems.
3. AGS.2111 outer sleeves must be fitted in such a manner that, when fully tightened, a flat of the sleeve is opposite any point of foul to enable clearance to be maintained.
4. Whenever servicing trolleys are being used to operate hydraulic systems, air pressure at 16-18 lb/in² must be applied to the associated reservoirs.
5. To operate the feel selector when required, the services system must be pressurized to a minimum of 1000 lb/in².

General information

40. Scrupulous cleanliness is essential during all servicing operations on hydraulic mechanisms. The presence of a foreign body, however minute, in a component may not only shorten the life of the equipment, but may result in serious failure. Benches, tools, test rigs, and fluid containers must, therefore, be kept spotlessly clean. All pipe ends and unions exposed during servicing operations must be blanked immediately to prevent the ingress of foreign matter. Hydraulic fluid has a deleterious effect on paint, rubber, cable insulation, etc., and care must be taken to avoid spilling it on such materials.

Tools and equipment

41. For tools and equipment used in servicing, and removal and assembly operations, refer to Table 4.

Techniques*Torque loading of pipe connections*

42. The torque-loading figures given in Table 1 are for stainless steel pipes fitted with steel or aluminium AGS. flared end-fittings. All torque-loading figures are applicable after initial finger tightening. During finger-tightening, care must be taken to ensure that the flare is in correct alignment with, and held firmly against, the cone of its mating coupling. Lubricate union threads with clean system fluid. The angular movements given in the Table correspond approximately with the specified torque loading applicable and may be used where couplings are inaccessible for the use of torque spanners.

Note...

If the sealing faces of the flared end of the pipe and its mating coupling do not seat fully after finger tightening they must be dismantled and rectified, or new parts fitted. After assembly all connections must be inspected with the system pressurized.

Screwed connections

43. Spanner torque must not be transmitted, inadvertently or otherwise, to the mating fitting or the assembly of a screwed connection: reaction in the form of a spanner held on the mating coupling must be provided during slackening or tightening.

◀ *Renewing bonded seals*

43A. When renewing bonded seals, the threads and contact faces of the associated unions, together with the seals and P.T.F.E. locating rings, are to be soaked in system fluid. The unions are to be torque loaded to the appropriate figure quoted in Table 1A. ▶

P.T.F.E. hoses - fitting and handling

44. If P.T.F.E. hoses are incorrectly fitted, mishandled, or subjected to strains, they will inevitably fail. To avoid failures the following precautions must be observed:-

(1) Hoses removed during servicing operations must be stored in a manner that allows them to retain the shape they take up in the aircraft.

(2) When installing a hose, secure the nuts at each end finger-tight only to allow the hose to adopt a natural lie without any twisting. Complete the

installation by holding each end of the hose in turn, firmly by hand, to avoid twisting, and tighten the adjacent union nut.

(3) Spanners must not be applied to the hexagonal sections of the hose sleeve or ferrule. Use hand pressure only to avoid twisting.

(4) Ensure that hoses are not kinked or distorted by overtightening clips or bending through a small radius.

(5) The following pressures must not be exceeded when pressure-testing individual P.T.F.E. hoses:-

Suction and return low-pressure hoses	500 lb/in ²
High-pressure hoses	4500 lb/in ²

Servicing trolley connection

45. When connecting a servicing trolley to the services system connections at access panel 45P the following technique must be used to avoid damage to the services suction hose:-

(1) Disconnect the services suction hose at the servicing connection.

(2) Depress the hose lower elbow with the left hand and whilst so doing guide the free end of the hose with the right hand to a position below, and slightly inboard of, the servicing connection, and adjacent to the forward face of frame 31.

(3) With the hose retained in this position connect the servicing trolley hose.

(4) Removal is the reverse of the above procedure.

Services No.2 pump suction hose (post Mod. 2529)

46. Services No.2 pump suction hose must be fitted in accordance with the following instructions:-

(1) Check that the services No.2 pressure hose elbow-connection at frame 48 is set parallel to the fuselage skin.

(2) Check that the suction hose banjo connection on the pump is angled approximately 5 deg inboard from vertical.

(3) Connect the suction hose to the T-piece at frame 47.

(4) Hold the suction hose so that the bottom portion curves slightly outboard with the elbow pointing into the corner formed by frame 48 and the fuselage skin, and outboard of the services-pressure rigid pipe on the face of frame 48. With the hose held in this position connect it to the banjo connection at the pump. This procedure will ensure adequate clearance between the hose and the reheat fuel pipe.

(5) Check that the services No.2 pressure and the by-pass hoses are outboard of the suction hose.

(6) Lock all connections and fill and bleed the system (para.52-54).

Accumulators

General information

47. Accumulator pressures listed in Table 2 are based on the assumption that the temperature of the nitrogen inside the accumulator is the same as that of the external air. Therefore, checks must not be made after flight or

engine runs until sufficient time has elapsed for the nitrogen to cool. A table of accumulator pressures is displayed on a data plate attached to the inner surface of each main undercarriage door.

Checking nitrogen pressure

48. To check the nitrogen pressure:-

(1) Release the hydraulic pressure in the accumulators as follows:-

(a) Operate the aileron and tail-plane controls, at a rate not exceeding one stroke between limit stops in five seconds, until control surface movement ceases.

(b) Apply light fingertip pressure to deflect the control column aft and switch feel ON and OFF; slight pulsations will be felt on the control column with each switch movement. Continue switching until the pulsations cease.

(c) Ensure that feel is selected OFF. (Refer to Note (5) after para.39).

(d) Alternately apply and release the wheel brakes until the brake pressure gauge in the cockpit registers zero.

(2) Fit an inflation adapter and pressure gauge to the accumulator being checked.

(3) With the air release valve on the adapter closed, and the inflation point blanking cap tight, turn the pressure gauge until a reading is obtained. Refer to Table 2 for the correct pressure

relative to the surrounding air temperature of the accumulator being checked.

(4) If the reading is in excess of that given in the table, residual hydraulic pressure is indicated and must be released. If the reading is appreciably less than that specified, inspect the accumulator for any defect causing loss.

◀ Note...

With maximum hydraulic pressure in the systems the tail plane and rudder, No.1 and No.2 controls systems accumulators may, when cold, indicate 2700 lb/in² system pressure caused by the piston abutting the end-fitting. This is a design feature and correct system pressure will be indicated as the temperature of the nitrogen rises. ▶

(5) The accumulator is charged by removing the blanking cap and connecting the nitrogen rig line to the supply point on the inflation adapter.

Note...

When discharging, or after charging accumulators with nitrogen, an oil mist may be released from the charging valve; this is normal and does not necessarily mean that fluid is leaking past the accumulator piston. All accumulators are purposely charged with a small volume of hydraulic fluid on the nitrogen side of the piston (60 to 70 cc for medium-sized accumulators) to provide lubrication for the piston seals. If an excessive amount of oil is emitted this should, of course, be investigated. On no account must oil be removed from or

introduced into the nitrogen side of the accumulator unless instructed by the accumulator manufacturers.

Charging the nose undercarriage shimmy-damper accumulator

49. The accumulator is mounted behind the nose-undercarriage pivot pin at the port side, and its remote bleed screw and the charging point are on the nose undercarriage starboard beam and the shock-absorber strut respectively.

To charge the accumulator:-

(1) Remove the blanking cap from the charging point and fit an adapter.

(2) Connect a lubricating gun and adapter to the charging point.

(3) Centralize the wheel, and add oil OM-15 at a pressure not exceeding 300 lb/in², until the mark on the accumulator plunger rises above the pointer on the accumulator casing.

(4) Open the bleed screw and bleed off fluid until the plunger marking is level with the pointer.

(5) Disconnect the charging equipment, replace the blanking cap and wire-lock both cap and bleed screw.

Capacity checks

50. The accumulator capacity checks are given in the paragraphs detailing functioning tests of the various systems. As the same accumulators serve both the rudder and tail plane systems, the capacity checks given for the tail plane cover both systems.

Reservoir draining

51. To drain a services or controls system reservoir:-

(1) Operate the associated system to discharge pressure.

(2) Connect an overflow pipe to the reservoir drain (No.1 controls and services system, access panel 69P; No.2 controls system, access panel 66S). Place a receptacle to collect the fluid.

(3) Apply air pressure of 16-18 lb/in² at the air charging valve, access panel 63P.

PRIMING AND BLEEDING

General information

52. The instructions in the following paragraphs, if followed systematically, will result in a complete system relatively free from air. If a part of the system is subsequently broken down and reconnected, discretion will be necessary in determining the extent of bleeding required, but, in general, the instructions dealing with the section where breakdown has occurred, and subsequent instructions relating to the affected service, should be carried out. In cases where only part of the system is being primed or bled, certain obvious additions to the sequence of operations given may be necessary for preparation, and to restore the system to normal after completion. As the flying controls are operated by two independent systems, it is recommended that the reservoir, pump, and pressure lines of one system be completely bled before commencing to bleed the other system. Before commencing priming and bleeding operations, all accumulators must be fully charged with

nitrogen (*para.48*). Bleed points must not be re-tightened until a continuous flow of clear fluid is obtained. Servicing trolleys should be connected to the ground connections of the appropriate system Sect.2, Chap.4, Table 3.

Services system

Filling and bleeding the reservoir

53. Fill and bleed the reservoir, using fluid OM-15 and a fluid dispenser.

Note...

Only one hydraulic servicing trolley may be used when lowering the alighting gear.

(1) With the external electrical supply connected, select:-

Alighting gear	DOWN
Flaps	UP
Air brakes	IN
(refer to note after (4))	
Canopy	OPEN

(2) Release pressure from the system accumulators by alternately applying and releasing the wheel brakes, and by alternately selecting feel ON and OFF.

(3) Remove the blanking cap from the services reservoir filling self-sealing half-coupling (access panel 63P), and connect the bayonet-type half-coupling of the dispenser. Fit a drainpipe at the reservoir drain. Vent the air-release valve to atmosphere. Fill until clear fluid flows from the relief valve drainpipe. Any air in the reservoir will be bled off before clear fluid commences to flow.

(4) Check the nitrogen pressure in the

wheel brakes, autostabilizer actuator and feel unit damping accumulators (Table 2).

Note...

1. If any work has been done or is in progress on the air brakes or synchronizing mechanism, which necessitates subsequent adjustment of these components, then the jacks must not be moved unless the following precautions are observed:-

- (a) Disconnect the synchronizing mechanism from the doors by removing the pins connecting the linkage to each door bracket.
- (b) Disconnect the jack ram from each door. Secure the doors open so that movement of the jack rams will not foul the doors.
- (c) Support the jacks in such a manner that the jack rams can extend and retract without obstruction and without distortion of the swivel couplings.
- (d) Insert, from above, a setting pin through the synchronizing unit shaft. It is important that the setting pin is used only when the synchronizing mechanism is disconnected from the doors.
- (e) To satisfy (1), select air brakes IN, and move the jack rams by using the aircraft hand pump only.

2. After bleeding a jack it is necessary to exercise the jack a number of times and then repeat the bleeding.

Priming and bleeding the engine-driven pumps and hand pump

54. To prime the pumps:-

(1) Maintain pressure in the reservoir with the filling rig, and bleed at the services No.1 and No.2 ground servicing trolley connections on the aircraft or at the engine-driven pump bleed connections.

(2) Bleed at the pressure connection of the aircraft hand pump, assisting the flow, if necessary, by slowly operating the hand pump.

Bleeding the pressure lines

55. To bleed the pressure lines:-

(1) Jack and trestle the aircraft with all wheels clear of the ground (Sect. 2, Chap. 4).

(2) Maintain reservoir pressure with the ground filling rig, and slowly operate the aircraft hand pump. Bleed in turn at the pressure connections of the following components:-

Air brakes selector
Autostabilizer actuator accumulator
Tail-plane autostabilizer
Feel simulator
Rudder autostabilizer
Services No. 1 and No. 2 engine-driven pumps (or servicing trolley connections)
Flaps selector
Alighting-gear selector
Canopy selector
Two-missile pack selector
(when fitted)

Services system accumulator
Wheel brakes accumulator
Aileron autostabilizers
Feel selector
Pressure gauge transmitter

Bleeding the service lines

56. To bleed the service lines:-

(1) *Air brakes*

(a) Disconnect the air brake jacks from the doors (Chap. 4F), and select air brakes OUT. Ensure that the synchronizing unit is centralized and maintaining pressure in the reservoir with the ground filling rig, operate the aircraft hand pump slowly and bleed in turn at the bleed screw at the jack out line connections, and at the out line connections of the air brake door-lock jacks.

(b) Select air brakes IN, and repeat the bleeding operations at the in line bleed screws.

(2) *Flaps*

(a) Disconnect the jacks from the flaps (Chap. 4F), and select flaps DOWN. Maintain reservoir pressure with the ground filling rig, operate the aircraft hand pump slowly, and bleed in turn at the jack end of the swivel-coupling connections to the port and starboard, inboard and outboard jack down lines.

(b) Select flaps UP, and repeat the bleeding operations at the up line connections.

(3) *Alighting-gear emergency*

(a) Bleed No.1 controls system (para. 59-62).

(b) With the undercarriage down and with the emergency selector in the NORMAL position, maintain pressure in No.1 controls reservoir with the ground filling rig. Operate the hand pump on the No.1 controls servicing trolley slowly, and bleed at the second connection from the indicator-rod end of the protection unit.

(c) Select alighting-gear emergency DOWN and, maintaining reservoir pressure with the ground filling rig, operate the hand pump on the servicing trolley slowly, and bleed in turn at the emergency connections of the following components:-

Protection unit (connection adjacent to indicator rod)

Nose undercarriage jack shuttle valve

Nose undercarriage up-lock jack shuttle valve

Main undercarriage door jack shuttle valves

Main undercarriage door-lock jack shuttle valves

Main undercarriage jack shuttle valves

Main undercarriage relay valves

Shimmy damper by-pass valve

Rudder feel by-pass valve

(d) Reset the emergency system (para. 84).

(e) Pressurize No.1 controls system, using the servicing trolley, until the protection unit indicator rod is fully extended.

(4) *Main and nose undercarriages*

(a) Ensure that the protection unit is in the normal position with the indicator rod fully extended. With the selector and alighting gear in the DOWN position, maintain pressure in the services reservoir with the ground filling rig. Operate the aircraft hand pump slowly and bleed in turn at the normal down connection of the following components:-

Nose undercarriage up-lock jack at the down and emergency pipe connections aft of frame 14

Nose undercarriage jack shuttle valve

Main undercarriage door jack shuttle valves

Main undercarriage door-lock jack shuttle valves

Main undercarriage jack shuttle valves

Shimmy damper by-pass valve

Rudder feel by-pass valve

(b) With the aircraft fully jacked and trestled, apply pitot pressure equivalent to 150+5 knots.

(c) Select alighting gear UP, and

depress and secure the plungers of the sequence valves operated by the main undercarriage legs when in the up position. Maintain pressure in the reservoir with the ground filling rig, operate the aircraft hand pump slowly, and bleed in turn at the following components:-

Nose undercarriage down-lock jack

Nose undercarriage jack (up connection)

Main undercarriage jacks (up connections)

Main undercarriage door jacks (up connections), or nearest accessible connections in up lines

Main undercarriage door-lock jacks (up connections)

Main undercarriage down-lock jacks

Rudder feel by-pass valve (up connection)

Shimmy damper by-pass valve (up connections)

Nose undercarriage shimmy damper accumulator (two side connections)

(d) Release the undercarriage door sequence valve plungers.

(5) *Canopy*

(a) Maintaining reservoir pressure with the ground filling rig, select canopy OPEN, operate the aircraft hand pump slowly, and bleed at the

open connection to the jack (or the nearest accessible connection).

(b) Select canopy CLOSED and repeat, using the opposite jack connection.

(6) *Two-missile pack*

Remove the panel giving access to the alternator. Maintain reservoir pressure with the ground filling rig, and bleed at the return connection on the alternator.

(7) *Shimmy damper and centring circuit*

(a) With the nose undercarriage in the down position, connect a priming rig to the filling point on the starboard side of the nose undercarriage leg. Prime and bleed at the shimmy damper and centring jack uppermost bleed screws at each end of the jack, and at the bleed nipple aft of the nose-wheel pivot on the starboard nose-wheel beam.

(b) Centralize the nose wheel, and operate the aircraft hand pump slowly to over-fill the accumulator, but do not allow the pressure to exceed 300 lb/in². Slacken the accumulator bleed nipple, and bleed until the level indicators on the top of the accumulator are in line.

(8) *Wheel brakes*

(a) Maintain reservoir pressure with the ground filling rig, and set the parking brake ON. Operate the aircraft hand pump slowly, and

bleed in turn at the bleed nipples on the port and starboard main undercarriage brake assemblies.

(b) Maintain reservoir pressure and bleed at the return connection on the brake differential unit or the nearest accessible connection in the return line, and at the port and starboard Maxaret units.

(9) *Feel system*

(a) With the aircraft fully jacked and trestled, and with pitot pressure equivalent to 150 ± 5 knots applied, maintain reservoir pressure with the ground filling rig. Select alighting gear UP, and operate the aircraft hand pump to increase the system pressure to 300 lb/in²; the alighting gear should partially retract. Select feel ON, operate the aircraft hand pump slowly, and bleed in turn at the pressure connection of the feel unit damping accumulator, and at the bleed nipples of the rudder and tail-plane feel units.

(b) Stop pumping with the hand pump, and bleed in turn at the return connections of the following components whilst still maintaining pressure in the reservoir:-

Tail-plane and rudder feel units
Feel selector
Feel simulator
Rudder feel by-pass valve

(10) *Autostabilizers*

Maintain reservoir pressure with the

ground filling rig, and bleed at the return connections of the port and starboard aileron and the tail-plane and rudder autostabilizers.

(11) *Wheel brakes accumulator gauge relay*

Fit a clamp between the two grooves at the base of the relay and, maintaining reservoir pressure with the ground filling rig, bleed at the pressure transmitter connection. Remove the clamp from the relay.

Note...

To avoid distorting the cylinder, care must be taken not to overtighten the clamp.

Bleeding the return lines

57. The following operations involve the functioning of the aircraft services to expel air from the return lines. Before the operations are commenced, reference must be made to the services system functioning tests (para. 78-92). After completing the instructions given in para. 53-56 bleed the services system return lines:-

(1) With the aircraft fully jacked and trestled, and with pitot pressure equivalent to 150 ± 5 knots applied, connect an external air supply of 16-18 lb/in² to the services reservoir.

(2) Using the aircraft hand pump, function each of the services at least three times in each direction; air in the return lines will be returned to the reservoir, and should be bled off

RESTRICTED

as instructed in para.53. This operation may result in excess fluid being discharged from the reservoir overflow during the actual movement of the service.

(3) When each service has been functioned and all air bled from the reservoir, refill and bleed the reservoir as instructed in para.53.

(4) With a servicing trolley connected to each services ground pressure connection and an external air supply of 16-18 lb/in² applied to the reservoir, start the servicing trolleys and run for approximately one minute without operating any of the services. Stop the trolleys.

(5) Discharge the accumulators as instructed in para.53. Release air pressure and re-bleed the reservoir using the ground filling rig.

(6) Apply reservoir airpressure, start one servicing trolley, and operate the following services at least three times, in turn:-

Alighting gear

Air brakes

Flaps

Canopy

(7) Stop the trolley, discharge the accumulators, release the reservoir air pressure, and re-bleed the reservoir, using the ground filling rig.

(8) Repeat (6) and (7) until no further air can be bled from the reservoir.

(9) Disconnect the ground servicing trolleys from the ground pressure connections, and reconnect the services engine-driven pumps into the system.

(10) Maintaining reservoir hydraulic pressure with the ground filling rig bleed at the pump bleed connections or the nearest accessible connections.

Bleeding the autostabilizer actuators after renewal or malfunction

58. Minute quantities of air in the autostabilizer actuators can result in an oscillatory malfunction at the rate of approximately 1 c/s. This can be corrected by, repeating twice, the operations detailed in para.66 (5), (6), (7) and (8) and then carrying out operation (13). In the renewal case, the autostabilizer actuator should be bled on the aircraft, in addition to bench servicing, as a precautionary measure.

Controls systems

Filling and bleeding the reservoirs

59. Fill and bleed the reservoirs using fluid OM-15 and a fluid dispenser.

(1) Release the pressure in the ailerons, No.1 and No.2 controls systems and tail-plane and rudder, No.1 and No.2 controls systems accumulators by operating the tail plane and aileron controls. The rate of operation must not exceed one stroke between stops in 5 sec.

(2) In the No.1 controls system, ensure that the alighting gear emergency lowering control is set to normal, and

the brake parachute door jack normal, i.e. PULL TO STRFAM control handle in, and parachute compartment doors closed.

(3) Remove the blanking caps from the self-sealing half-couplings of No.1 and No.2 controls reservoir filling connections, and fit an overflow pipe to each drain. Connect the bayonet-type half-couplings of the dispenser to each connection in turn, and fill until clear fluid flows from the overflow pipes. The filling connections for No.1 and No.2 controls systems reservoirs are located beneath access panels 63P and 60S, respectively.

(4) Check the nitrogen inflation pressure in the ailerons, No.1 and No.2 controls systems and tail plane and rudder, No.1 and No.2 controls systems accumulators (Table 2).

Priming and bleeding the engine-driven pumps

60. Maintain pressure in the controls reservoir of the system to be bled and bleed at the servicing trolley connection.

Bleeding the pressure lines

61. To bleed the pressure lines:-

(1) Maintain pressure in the reservoir of the system to be bled, using the ground filling rig, and slowly operate the hand pump on the servicing trolley connected to the system. On No.1 controls system, bleed in turn at the pressure connections of the following components:-

Pressure switch

RESTRICTED

Ailerons, No.1 controls system accumulator

Aileron p.f.c.u. (outboard)

Emergency alighting gear selector

Tail plane and rudder, No.1 controls system accumulator

Tail-plane p.f.c.u. (port motor)

Braking parachute selector

Rudder p.f.c.u. (No.1 controls connection)

(2) Similarly, for No.2 controls system maintaining reservoir pressure with the ground filling rig connected to No.2 controls reservoir, slowly operate the hand pump of the servicing trolley connected to the system, and bleed at the pressure connections of the following components:-

Ailerons, No.2 controls system accumulator

Aileron p.f.c.u. (inboard)

Pressure switch

Rudder p.f.c.u. (No.2 controls connection)

Tail plane and rudder, No.2 controls system accumulator

Tail-plane p.f.c.u. (starboard motor)

Bleeding the return lines

62. The following operations involve the functioning of the aircraft controls to expel air from the return lines. Before the operations are commenced, reference must be made to the controls system functioning tests (Chap.4C, 4D,

and 4E) and para.93-103 of this chapter. To bleed the return lines:-

(1) Connect an external air supply of 16-18 lb/in² to the reservoir of the system to be bled, and start the servicing trolley connected to the system.

(2) For No.1 controls system, operate the following controls over full stroke several times:-

Ailerons

Tail plane

Rudder

Braking parachute

Do not operate emergency alighting gear selector.

(3) Stop the servicing trolley and exhaust accumulator pressure by operating the aileron and tail-plane controls. Rate of operation is not to exceed one stroke between stops in 5 sec.

(4) Release the reservoir air pressure and bleed the reservoir, using the ground filling rig.

(5) Repeat (1) to (4) until no further air can be bled from the reservoir.

(6) For No.2 controls system, repeat (1) to (5) using the appropriate reservoir and ground servicing trolley connections, with the exception of the operation of the braking parachute in (2).

(7) Disconnect the servicing trolleys,

and reconnect No.1 and No.2 controls system engine-driven pumps.

(8) Maintaining hydraulic pressure in the appropriate reservoir, using the ground filling rig, bleed at the pump bleed connections or the nearest accessible connections.

Bleeding after replacement of the pressure filters

63. After periodical removal and replacement of the pressure filter elements, the filters and adjacent pipelines are to be filled and bled by the following method. During these operations the reservoirs are to be maintained in a topped-up condition.

(1) Fill and bleed the services and controls systems reservoirs (para.53 and 59).

(2) Connect servicing trolleys with the pipelines primed and bled, to services No.1 and No.1 controls ground test connections.

(3) To fill and bleed services No.1 pressure filter:-

(a) Slacken the union of the protection unit non-return valve (access panel 26P) and operate the hand pump of the servicing trolley slowly until air-free fluid flows from the slackened union.

(b) Repeat (a) using the aircraft hand pump. When clear fluid flows, tighten the union and cease pumping. Wire-lock the union.

(4) To fill and bleed No.1 controls pressure filter:-

(a) Slacken the union on the upstream side of the tail-plane port motor non-return valve (access panel 26P) and operate the servicing trolley hand pump slowly until clear fluid flows from the union. Tighten the union and cease pumping.

(b) Slacken the union at No.1 controls pressure switch (access panel 26P) and operate the servicing trolley hand pump slowly until air-free fluid flows from the union. Tighten the union and cease pumping.

(c) Wire-lock the non-return valve and pressure switch unions.

(5) To fill and bleed services No.2 pressure filter:-

(a) Disconnect the servicing trolley from services No.1 ground test connection and replace the self-sealing coupling on the trolley pipeline with a stud coupling. Connect the pipeline to services No.2 ground test connection.

(b) Slacken the union at the top of services No.2 pressure filter (access panel 58S) and operate the hand pump of the servicing trolley slowly until clear fluid flows from the union. Tighten the union, cease pumping and wire-lock the union.

(c) Detach the servicing trolley

and replace the stud coupling with the self-sealing coupling. Bleed the pipeline and attach it to services No.1 ground test connection.

(6) To fill and bleed No.2 controls pressure filter:-

(a) Connect a servicing trolley to No.2 controls ground test connection.

(b) Slacken the union on the top of No.2 controls pressure filter (access panel 60S) and operate the servicing trolley hand pump slowly until clear fluid flows from the union. Tighten the union and cease pumping. Wire-lock the union.

(7) With a servicing trolley connected to services No.1 ground test connection function the flaps several times using the trolley hand pump. Replenish the services reservoir and repeat the functioning and replenishing until the fluid flowing from the reservoir overflow pipe is clear and free from air.

(8) Function the air brakes several times using the trolley hand pump. Replenish the services reservoir and repeat the functioning and replenishing until the fluid flowing from the reservoir overflow pipe is clear and free from air.

(9) Repeat (7) and (8) with the servicing trolley connected to services No.2 ground test connection.

(10) With servicing trolleys connected to No.1 and No.2 controls ground test connections, function the tail plane, using the trolley hand pump on each system in turn. Replenish No.1 and No.2 controls reservoirs and continue functioning and replenishing until clear fluid flows from each reservoir overflow pipe.

(11) Finally, repeat (7) to (10) and ensure that the reservoir fluid is free from air. Replenish the reservoirs, disconnect the servicing trolleys and replace the access panels.

Bleeding systems of laid-up aircraft

At commencement of lay-up

64. In an aircraft is to be laid up for a period exceeding seven days, and the systems are to be made unserviceable by the nature of the lay-up, the nitrogen pressure must be discharged from all accumulators in the services and controls systems at the commencement of the lay-up (*para.53 and 59*).

During any seven concurrent days of a lay-up

65. If the instructions in para.64 have not been carried out the following operation must be carried out within any seven concurrent days from the start of the lay-up:-

Exercise all accumulators in the services and controls systems by moving the accumulator pistons up and down the bores by fully hydraulically charging and discharging each accumulator for a minimum of three times.

Servicing trolleys will be required for the controls systems.

This procedure will dispense with the need to carry out the instructions in para. 66.

Before first engine run following lay-up 66. If an aircraft has been laid up for a period in excess of ten days without exercising the accumulators the following operations must be carried out, before the first engine run:-

Note...

The accumulator pressures should be noted before and after carrying out the following operations and any deviation from normal investigated (refer to Table 2 for correct pressures).

(1) Connect servicing trolleys to the No. 1 and No. 2 controls systems.

(2) Fill and bleed the reservoirs (para. 53 and 59).

(3) Maintain pressure with the hand pump and bleed at the services No. 2 engine-driven pump and the hand pump until a flow of clear oil is obtained.

(4) Bleed the wheel brake assemblies and Maxaret units (para. 56 (8)).

(5) Using the aircraft system hand pump, maintain the system pressure at 2000 lb/in². Apply pitot pressure of 300 knots. Connect an autopilot test

set to the test connections in the main equipment bay.

(6) Select YAW on the test set and allow the autostabilizer actuator to stroke and centralize before releasing the switch. After releasing the switch, allow the actuator to stroke and centralize in the opposite sense, and then repeat the operations until the autostabilizer actuator accumulator is exhausted.

(7) Repeat (5) and (6) with the test set switched to the ROLL channel.

(8) Repeat (5) and (6) with the test set switched to the PITCH channel.

(9) Pressurize the system to 2000 lb/in² and apply pitot pressure of 300 knots. Select feel ON and OFF repeatedly until the autostabilizer actuator accumulator is exhausted. Do not discharge the wheel brakes accumulator.

(10) Repeat (2) and (3).

(11) Repeat (5), (6), (7), (8) and (9).

(12) Repeat (2) and (3).

(13) Discharge the wheel brakes accumulator by repeated application of the brakes.

(14) Repeat (2) and (3).

(15) Operate all the flying controls a minimum of three times over their full range of movement.

(16) Fill and bleed the controls reservoirs (para. 59).

(17) If necessary repeat (15) and (16) until a flow of clear oil is obtained.

During first engine run following lay-up 67. To ensure that the systems are free from air, as many units as possible must be exercised during the first engine run after a lay-up. In particular, the controls systems must be operated to produce large oil flows. After the engine run is completed the reservoirs must be topped up (para. 53 and 59).

Bleeding jacks before installation

68. Before installing a jack into the aircraft system, the following procedure must be adopted to assist in the subsequent bleeding of the system:-

(1) Set up the jack on a test bench and, using a hand-pump rig, fill the jack with fluid by connecting the pipe unions to each jack connection in turn. The connections to the jack should be made whilst slowly pumping so that air in the connecting pipelines is expelled; the union should be tightened only when clear fluid is flowing freely from the joint.

(2) Stroke the jack over its full travel three times, (e.g. extend-close-extend) with the relief connection uppermost and slackened to allow the escape of trapped air.

(3) When all air is finally expelled disconnect the jack from the hand-pump

RESTRICTED

rig, and fit pressure blanks pending the fitment of the jack into the aircraft system.

(4) Before installing the jack, the pressure and service lines and the reservoir should be bled as described in the foregoing paragraphs.

(5) After installing the jack, but before connecting the jack to the mechanism, select the opposite position and, maintaining pressure in the reservoir with the ground filling rig, operate the aircraft hand pump slowly and bleed at the selected connection until clear fluid is flowing. Do not stroke the jack.

(6) When clear fluid is flowing, tighten the connection and stroke the jack to its opposite position.

(7) Reverse the selection and bleed in a similar manner at the opposite connection. Do not stroke the jack until bleeding is completed and the connection finally tightened.

(8) Select and stroke the jack to the required position for attachment to the mechanism.

Filters - tail-plane p.f.c.u.

69. Servicing of the filters (A.P.105D-0405-16AC) in the tail-plane p.f.c.u. is required only if any of the following conditions arise:-

(1) Sluggishness of control response to application of normal hydraulic pressure.

(2) Noisy operation of the p.f.c.u.

(3) Contamination of either controls systems.

(4) After major breakdown of either controls systems.

After refitting the filters carry out functioning tests, using both controls systems, and bleed the systems if necessary.

Filter elements Ref.No. 26DK/12140 - renewing

70. When it is necessary to renew a pressure filter element, the element and casing must be assembled as follows:-

(1) Before fitting a new element, ensure that threads on filter casing and base housing are clean.

(2) Screw casing into base housing until its flange bottoms on top of base housing, screwing action must be smooth and easy.

(3) Remove casing and fit a new seal in base housing.

(4) With base on bench, insert new element, ensuring that locating lugs on bottom of element are directly above locating recesses in base.

(5) Place element casing over element and, using a drift or other similar implement inserted through hole in casing top plate, push on centre of element to compress spring until locating lugs engage in recesses. Check

engagement visually through radially disposed holes in base.

(6) Carefully screw down element casing until finger-tight and all end float of filter element has been eliminated.

(7) Wire-lock casing to base.

Note...

With the element installed and the casing sufficiently tightened it is not necessary for the flange on the casing to bottom on the top face of the base housing.

Scavenging No.1 and No.2 controls systems

71. The following instructions cover the whole of the No.1 and No.2 controls systems. Where contamination is suspected in a particular section of either system it will be obvious which pipe or pipes should be disconnected to scavenge the affected area. If any doubt exists regarding the cleanliness of a system the whole of the scavenging instructions must be carried out.

Note...

1. If the highest standard of cleanliness is not observed throughout the scavenging sequence, the whole operation may be rendered abortive; and the system left in a worse condition than before scavenging took place.

2. When a system or part of a system has been scavenged the appropriate bleeding instructions and functioning tests must be carried out.

RESTRICTED

No. 1 controls*Pressure pipelines*

72. To scavenge the pressure pipelines:-

(1) Uncouple the flexible pressure pipe at the No. 1 controls pump and connect it to the scavenging rig (Table 4).

(2) Disconnect the following pipes and fit extra lengths of pipes and blanking caps:-

(a) Pressure connection of the pressure switch (aft face of frame 22, access panel 26P).

(b) Single connection at the protection unit supplied by the alighting gear emergency selector (aft face of frame 23, port).

(c) The pressure side of the thermal relief valve, alighting gear emergency pressure supply (between frames 23-25, port).

(d) Pressure connection at the ailerons, No. 1 controls system accumulator (fwd. face of frame 23, port).

(e) Pressure connection at the tail plane and rudder, No. 1 controls system accumulator (fwd. face of frame 56, port).

(f) Pressure connection at port tail-plane motor (access panel 93P).

(g) Pressure side of braking parachute door jack (frames 57-59, stbd.).

(h) Flexible pipe at forward pressure connection on rudder p.f.c.u. (access panel 86S).

(j) Flexible pipe at pressure connection to port outboard aileron p.f.c.u. (access panel 132B).

(k) Flexible pipe at pressure connection to starboard outboard aileron p.f.c.u. (access panel 132B).

(l) Flexible pipe at port undercarriage jack shuttle-valve emergency connection (port undercarriage bay).

(m) Emergency connection at port undercarriage door jack shuttle-valve (port undercarriage bay).

(n) Emergency connection at relay valve (port undercarriage bay).

(o) Emergency connection at port undercarriage door-lock jack shuttle-valve (port undercarriage bay).

(p) Flexible pipe at starboard undercarriage jack shuttle-valve emergency connection (starboard undercarriage bay).

(q) Emergency connection at starboard undercarriage door jack shuttle valve (starboard undercarriage bay).

(r) Emergency connection at relay valve (starboard undercarriage bay).

(s) Emergency connection at starboard undercarriage door lock-jack shuttle-valve (starboard undercarriage bay).

(t) Emergency connection at nose undercarriage jack shuttle-valve (frames 13-14, stbd.).

(u) Emergency connection at nose undercarriage up-lock jack shuttle-valve (frames 13-14, stbd.).

(v) Emergency connection at by-pass valve (frames 15-16, port).

(w) Emergency connection at feel by-pass valve (fwd. face, frame 57, stbd.).

(3) Disconnect the pipes at the pressure filter and connect them together using extra pipes and connectors (aft face, frame 23, port).

(4) Disconnect the emergency pipes at the 180 deg banjo bolt on the protection unit and connect them together using extra pipe and connectors (aft face, frame 23, port).

(5) Check that the alighting gear emergency selector is in the unoperated position.

(6) Set the braking-parachute selector to the stream position.

(7) Remove the blank from each pipe in turn in the sequence given in (2) (a) to (k) inclusive and, using the scavenging rig, thoroughly flush out

RESTRICTED

each pipe run. Refit the blanks immediately after each operation.

(8) Operate the alighting gear emergency-selector to the emergency position; remove the blank from each pipe in turn in the sequence given in (2) (1) to (w) inclusive and, using the scavenging rig, thoroughly flush out each pipe run. Refit the blanks immediately after each operation.

(9) From each pipe in turn, remove the extra pipe or blank and restore the system to normal.

(10) Reset the alighting gear emergency selector to normal (*Chap. 11*).

Return pipelines

73. To scavenge the return pipelines:-

(1) Disconnect the return pipe at No.1 controls reservoir and connect the pipe to the scavenging rig.

(2) Disconnect the following pipes at their respective connections and fit extra lengths of pipe and blanking caps:-

(a) The return connection at the port tail-plane p. f. c. u. (access panel 93P).

(b) The return connection at the braking-parachute door selector.

(c) The return connection of the braking parachute door-jack (access panel 78S).

(d) The flexible pipe at the by-

pass return from the engine-driven pump.

(e) The reservoir oil filling line at bayonet coupling (access panel 63P).

(f) The return connection of the thermal relief valve, alighting gear emergency pressure supply (frames 23-25, port).

(g) The flexible pipe at the return connection of the port outboard aileron p. f. c. u. (access panel 132B).

(h) The flexible pipe at the return connection of the starboard outboard aileron p. f. c. u. (access panel 132B).

(3) Disconnect the pipes at the non-return valve in the No.1 controls by-pass return line from the heat-exchanger, and connect the pipes together. Use an extra pipe and couplings (frame 39, port).

(4) Disconnect the three pipes at the No.1 controls by-pass filter and connect them together using extra pipes and couplings (frame 42, port).

(5) Remove the blank from each pipe in turn in the sequence given in (2) (a) to (f) inclusive and, using the scavenging rig, thoroughly flush out each pipe run. Refit the blanks immediately after each operation.

(6) From each pipe in turn, remove the extra pipe or blank and restore the system to normal.

Suction pipelines

74. To scavenge the suction pipelines:-

(1) Disconnect the suction pipe at No.1 controls reservoir and connect it to the scavenging rig (frames 50-51, port).

(2) By-pass the auxiliary reservoir by disconnecting the pipes and connecting them together with extra pipes and couplings (frames 46-47, port).

(3) Disconnect the following pipes and fit extra lengths of pipe and blanking caps:-

(a) The valve return connection at the port tail-plane motor (access panel 93P).

(b) The flexible pipe at the return connection of the rudder p. f. c. u. (access panel 86S).

(c) The flexible pipe to the engine-driven pump.

(4) Remove the blank from each pipe in turn in the sequence given in (3) (a) to (c) and, using the scavenging rig, thoroughly flush out each pipe run. Refit the blanks immediately after each operation.

(5) From each pipe in turn, remove the extra pipe or blank and restore the system to normal.

No. 2 controls

Pressure pipelines

75. To scavenge the pressure pipelines:-

(1) Uncouple the flexible pressure

pipe at the No.2 controls pump and connect it to the scavenging rig.

(2) Disconnect the following pipes and fit extra lengths of pipe and blanking caps:-

(a) Pressure connection of the pressure switch (aft face, frame 55, access panel 72S).

(b) Pressure connection at the tail plane and rudder, No.2 controls system accumulator (frames 55-56, stbd.).

(c) Pressure connection at starboard tail-plane p.f.c.u. (access panel 93P).

(d) Flexible pipe at aft pressure connection on rudder p.f.c.u. (access panel 86S).

(e) Pressure connection at the ailerons, No.2 controls system accumulator (frames 22-23, port).

(f) Flexible pipe at pressure connection to starboard inboard aileron p.f.c.u. (access panel 132A).

(g) Flexible pipe at pressure connection to port inboard aileron p.f.c.u. (access panel 132A).

(3) Disconnect the pipes at the pressure filter and connect them together using extra pipes and connectors (fwd. face of frame 49, stbd.).

(4) Remove the blanks from each pipe

in turn in the sequence given in (2) (a) to (g) and, using the scavenging rig, thoroughly flush out each pipe run. Refit the blanks immediately after each operation.

(5) From each pipe in turn, remove the extra pipe or blank and restore the system to normal.

Return pipelines

76. To scavenge the return pipelines:-

(1) Disconnect the return pipe at No.2 controls reservoir and connect the pipe to the scavenging rig.

(2) Disconnect the following pipes at their respective connections and fit extra lengths of pipe and blanking caps:-

(a) The return connection at the starboard tail-plane p.f.c.u. (access panel 93P).

(b) The reservoir oil filling line at the bayonet coupling (access panel 60S).

(c) The flexible pipe at the by-pass return from the engine-driven pump.

(d) The flexible pipe at the return connection of the starboard inboard aileron p.f.c.u. (access panel 132A).

(e) The flexible pipe at the return connection of the port inboard aileron p.f.c.u. (access panel 132A).

(3) Disconnect the pipes at the non-return valve in the No.2 controls by-pass return line from the heat-exchanger, and connect the pipes together. Use an extra pipe and couplings (frames 46-47, port).

(4) Disconnect the three pipes at the No.2 controls by-pass filter and connect them together using extra pipes and couplings (forward face, frame 47, stbd.).

(5) Remove the blank from each pipe in turn in the sequence given in (2) (a) to (e) and, using the scavenging rig, thoroughly flush out each pipe run. Refit the blanks immediately after each operation.

(6) From each pipe in turn, remove the extra pipe or blank and restore the system to normal.

Suction pipelines

77. To scavenge the suction pipelines:-

(1) Disconnect the suction pipe at No.2 controls reservoir, and connect it to the scavenging rig.

(2) Disconnect the following pipes and fit extra lengths of pipe and blanking caps:-

(a) The valve return connection at the starboard tail-plane p.f.c.u. (access panel 93P).

(b) The flexible pipe at the return connection of the rudder p.f.c.u. (access panel 86S).

(c) The flexible pipe to the engine-driven pump.

(3) Remove the blank from each pipe in turn in the sequence given in (2) (a) to (c) and, using the scavenging rig, thoroughly flush out each pipe run. Refit the blanks immediately after each operation.

(4) From each pipe in turn, remove the extra pipe or blank and restore the system to normal.

FUNCTIONING TESTS

Precautions

78. Under certain conditions it is possible for the alighting gear selector to be selected DOWN electrically and UP hydraulically, with the ensuing danger of initial hydraulic pressure causing the unlocking of one, or more, of the down locks. To prevent these conditions arising the following procedure must be adopted before lowering the aircraft off jacks:-

(1) D.C. power ON.

(2) Alighting gear selected DOWN.

(3) Apply 2000 lb/in² minimum, services hydraulic pressure.

(4) Ensure alighting gear locks engage and position indicator shows three green lights.

(5) Fit alighting gear ground locks.

Alighting gear ground locks must be

fitted at all times during servicing unless functioning checks are being carried out.

Services system

Preparation

79. To prepare the aircraft for functioning tests:-

(1) Jack and trestle the aircraft with the wheels clear of the ground (Sect. 2, Chap. 4).

(2) Replenish the fluid in the reservoirs (para. 53 and 59) and connect an external air supply of 16-18 lb/in² to the reservoir air release valve (access panel 63P).

(3) When carrying out alighting gear retraction or flap functioning tests with pitot pressure applied, the flying controls must be set to neutral and feel OFF must be selected to obviate feel unit reaction; therefore:-

(a) Connect servicing trolleys, one to each controls system ground connection coupling.

(b) Start both trolleys and set the flying controls to neutral; do not lock the controls. Stop the trolleys.

(c) Select feel OFF. (Refer to Note (5) after para. 39).

Alighting gear

Note....

1. During functioning tests of the alighting gear or air brakes, it is essential that the upper engine hatch is fitted.

2. When lowering the alighting gear during functioning tests, do not use power from more than one servicing trolley.

3. If the nose wheel is castered to the extent that the auto-disconnect operates it must be centralized manually, to re-engage the mechanism, before any further retractions are carried out.

80. Nose-wheel centring.- To fulfil this test:-

(1) Build up the services system pressure to 3000 lb/in² to charge the services system accumulator. Stop the trolley.

(2) With the alighting gear in the down position, pivot the nose wheel over one way. Select alighting gear UP and, using the hand pump, commence to retract the alighting gear, the nose wheel should centre during the initial stages of retraction. Repeat the operation, pivoting the nose wheel in the opposite direction.

Note...

1. For this test the nose wheel must not be castered more than 30 deg in either direction to avoid automatic disconnection from the centring device. Should this occur inadvertently then the nose wheel must be centred to re-engage before any attempt at retraction is made.

2. The services system accumulator must be hydraulically charged for each repetition of this test.

81. *Operation and correct locking.*- With the servicing trolley running and with pitot pressure in excess of 150 ± 5 knots applied, retract and lower the alighting gear five times, checking the following:-

(1) That the main undercarriage door-locks and the nose undercarriage up-lock engage in the up position.

(2) That the main and nose undercarriage down-locks engage in the down position.

(3) That the mechanical lock indicator on the underside of each main undercarriage door jack is indicating full engagement of the jack internal lock in the down position. (The lock is engaged when the tab and the scribed lines are aligned.)

(4) That the alighting gear position indicators in the cockpit give correct indications. These are:-

No lights	Locked UP
Red light(s)	Associated undercarriage not locked
Three green lights	Locked DOWN

82. *Rates of operation.*- To fulfil this test:-

With a servicing trolley connected to one of the services system ground connections, and with pitot pressure in excess of 150 ± 5 knots applied, raise and lower the alighting gear and check the rates of operation (Table 3).

83. *Sinking.*- To fulfil this test:-

(1) With the alighting gear down, and the servicing trolley connected to services No.1 ground connection, start the trolley and stop when the alighting gear is approximately 15 degrees from the fully up position.

(2) Continue to retract the alighting gear, using the hand pump, until the main undercarriages are about to contact the sequence valves. (The sequence valves must not be operated.)

(3) Cease pumping and observe the alighting gear for sinking; it should maintain the near fully-retracted position.

84. *Emergency retraction.*- To fulfil this test:-

(1) Connect a servicing trolley to the services No.1 ground connection couplings.

(2) Connect a pitot pressure rig to the pressure head. Apply pressure progressively and check that the alighting gear up push-switch is inoperative below a rig A.S.I. reading of 150 ± 5 knots.

(3) Start the servicing trolley and, with a pitot pressure rig A.S.I. reading of less than 150 knots (the pressure switch operates at 150 ± 5 knots), select emergency UP on the selector, by turning the collar of the UP push-switch clockwise to its full extent and then depressing the switch. Check that the emergency override functions correctly. Reset the UP push-switch lock by depressing the

DOWN push-switch and inserting a resetting tool in the small hole in the UP push-switch and pressing until the collar can be returned to its full extent in a counter-clockwise direction.

85. *Emergency lowering.*- To fulfil this test:-

(1) Start the servicing trolley connected to the services system and select air brakes OUT and flaps DOWN.

(2) Retract the alighting gear, stop the trolley and release pitot pressure. Do not select alighting gear DOWN until the emergency lowering tests have been completed.

(3) Connect a servicing trolley to No.1 controls system ground connection and start the trolley.

(4) Using a spring balance, operate the emergency lowering lever in the cockpit and check that the force required does not exceed 15 lb. Check that the alighting gear is lowered and locked correctly. Stop the trolley and select alighting gear DOWN using normal selector.

(5) Reset the emergency selector lever and the control handle in the cockpit to the unoperated position (Chap.11). The emergency selector is behind access panel 26P.

(6) Check that the visual indicator rod on the protection unit has returned to its normal position, i.e. that the rod is visible (the protection unit

should be reset automatically by pressure from the tail plane and rudder, No. 1 controls system accumulator).

(7) Start the servicing trolley connected to the services system and build up pressure to 3000 lb/in² to reset the alighting-gear shuttle valves to normal.

(8) Disconnect the external air supply from the reservoir air-release valve and release the reservoir air pressure. Remove the blanking cone from the reservoir drain (access panel 69P) and fit a suitable length of pipe to the drain.

(9) Reconnect the external air supply and, using air pressure, remove a full half-gallon of fluid from the services reservoir. Release the air pressure, and refit the blanking cone to the drain.

(10) Start the servicing trolley connected to the services system and select flaps UP and air brakes IN.

(11) Release pressure from all services accumulators, and refill the services system reservoir (para. 53).

(12) Release hydraulic pressure from the ailerons, No. 1 and No. 2 controls systems and the tail plane and rudder, No. 1 and No. 2 controls systems accumulators and refill the No. 1 controls reservoir (para. 59). Reconnect the external air supply to the reservoir air-release valve, and pressurize to 16-18 lb/in².

(13) With the servicing trolley connec-

ted to the services system, retract and lower the alighting gear twice.

(14) Repeat operation (13) with a trolley connected to the other services connection.

Note...

1. *It is important that, after any emergency lowering of the alighting gear, (5) to (14) are carried out; (13) and (14) at least twice.*

2. *Should the strand of tell-tale wire on the emergency lever in the cockpit be found broken i.e. the lever partially moved, (5) to (7) inclusive must be carried out.*

3. *Using the emergency system, the time taken to lower the alighting gear must agree with the time given in Table 3.*

Flaps

86. To test the functioning of the flaps:-

(1) With servicing trolleys connected to both services system ground connections, start the trolleys and lower and raise the flaps. Check the flap position indicators, and the flap jack mechanical locks. Check that the operating times agree with those shown in Table 3.

(2) With the flaps in the down position, apply pitot pressure equivalent to 250 knots air speed; the flaps should return to the up position regardless of the DOWN selection.

(3) Release pitot pressure; the flaps should revert to the down position.

(4) Repeat the tests using one servicing trolley only.

Air brakes

87. Adjustment, synchronizing checks, and functioning tests of the air brakes are described in Chap. 4F.

Wheel brakes

88. To fulfil this test:-

(1) Attach an inflation adapter and pressure gauge to the test connection in each brake pipeline at the main undercarriages.

(2) With the rudder pedals in neutral, release the parking brake, and check the gauge readings; these should not be greater than the air pressure in the reservoirs.

(3) With the rudder pedals in neutral, apply the brakes. Check that the gauge reading at each test point is $1500 \begin{smallmatrix} +150 \\ -50 \end{smallmatrix}$ lb/in².

(4) Apply half port rudder. Check that the pressure at the starboard test point falls to zero or to the air pressure in the reservoirs, and that the port remains at $1500 \begin{smallmatrix} +150 \\ -50 \end{smallmatrix}$ lb/in².

(5) Apply half starboard rudder. Check that the pressure at the port test point falls to zero or to the air pressure in the reservoirs, and that the starboard remains at $1500 \begin{smallmatrix} +150 \\ -50 \end{smallmatrix}$ lb/in².

(6) With wheel brakes OFF and rudder pedals in neutral, check that the gauge readings do not exceed the air pressure

in the reservoirs. Spin the wheels and, allowing for the retarding effect of the Maxaret unit, check that the brakes are not binding.

Note...

With the rudder pedals in neutral, any difference between the two gauge readings must not exceed:-

(a) 100 lb/in² for all pressures between 0 and 1000 lb/in².

(b) 150 lb/in² for all pressures between 1000 and 1500 lb/in².

(7) Remove the inflation adapters, and refit the blanks to the test points.

Accumulator capacity test

89. Fully charge the wheel brakes accumulator using the hand pump, and discharge the services system accumulator by selecting canopy OPEN and CLOSED repeatedly. With the rudder pedals in neutral, apply and release the brakes at a rate not to exceed one operation in 5 seconds and with the brakes in the OFF position for 3 sec between each application. A minimum of 10 cycles should be obtained before the accumulator pressure is discharged.

Canopy

90. To test the functioning of the canopy system:-

(1) Connect a servicing trolley to the services No.1 ground connections.

Note...

During the following tests, check that the canopy mechanical locks and the

indicator lamps function correctly and that the audible warning sounds during canopy movement.

(2) Open and close the canopy twice, using the cockpit controls.

(3) Repeat (2) using the external controls.

(4) Stop the servicing trolley and open and close the canopy by means of the services system accumulator pressure.

(5) Open the canopy, and with both control switches in the neutral position, check that it remains open, i.e. observe it for creep.

Pressure gauge

91. To check for correct functioning of the services system pressure gauge in the cockpit:-

(1) Connect electrical and hydraulic ground servicing trolleys.

(2) With the instrument master switch OFF check that the pressure gauge pointer is in the white sector of the dial.

(3) With the instrument master switch ON and no pressure in the services system check that the pressure gauge pointer is in the red sector of the dial.

(4) With the servicing trolley running and instrument master switch ON, check that a pressure of approximately 3000 lb/in² is indicated on the gauge.

(5) Operate air brakes or alighting gear (if the aircraft is on jacks) and check that the gauge pointer falls rapidly, and then gradually rises to approximately 3000 lb/in² when air brakes or alighting gear come to rest.

(6) Repeat (5) three times.

(7) Stop the servicing trolley and release pressure in the services system (para.53). Check that the gauge pointer drops to the red sector on the dial.

(8) Switch the instrument master switch OFF and check that the gauge pointer falls to the white sector on the dial.

(9) Remove the servicing trolleys and return the system to normal.

Services operating times

92. The services operating times are shown in Table 3. The times quoted are for ground test conditions and do not correspond to operating times in conditions of flight.

(1) *Internal locks*

In the case of alighting gear and flaps, both of which have internal locks, it may be found that the times have been exceeded when locking is completed. The time for internal locking after jack movement has ceased must not exceed 3 sec.

(2) *Flap asymmetry*

Flap asymmetry, port to starboard, must not exceed ½ sec.

No. 1 and No. 2 controls systems*Rudder*

93. The following functioning tests of the rudder must always be carried out after a replacement rudder control unit has been fitted, subsequent to the rigging instructions (*Chap. 4D*) being effected.

94. *Pressure test:-*

(1) Select feel OFF. The services system must be pressurized to a minimum of 1000 lb/in² to ensure that the feel selector operates.

(2) Set the rudder to neutral and remove the pin connecting the control unit input lever to the control system. Do not disturb the setting of the turn-barrel adjuster.

(3) Start the hydraulic servicing trolley connected to No. 1 controls system. Move the control unit input lever to apply port rudder until the control unit is fully extended. Keeping the relay valve open, check for leakage of the control unit and the hydraulic connections.

(4) Repeat (3) with the control unit fully retracted and the rudder to starboard.

(5) Repeat (3) and (4) with the trolley connected to No. 2 controls system.

(6) Stop the trolley. Reconnect the control unit input lever to the turn-barrel adjuster.

95. *Operational test.-*

(1) Select feel OFF. The services system must be pressurized to a minimum of 1000 lb/in² to ensure that the feel selector operates.

(2) Start the servicing trolley connected to a controls system.

(3) Displace the rudder pedals and check the control unit functioning and rudder sense.

(4) Operate the rudder pedals at the rate of 2 strokes per second for 6 seconds.

(5) Repeat (3) and (4) with the servicing trolley connected to the other controls system.

Tail plane

96. The following functioning tests of the tail plane must always be carried out after a replacement tail-plane control unit has been fitted, subsequent to the rigging instructions (*Chap. 4E*) being effected.

97. *Operational test.-*

(1) Select feel OFF. The services system must be pressurized to a minimum of 1000 lb/in² to ensure that the feel selector operates.

(2) Release all pressure from the tail plane and rudder, No. 1 controls system accumulator.

(3) Start the servicing trolley connected to No. 2 controls system.

(4) Move the control column, and check the motor functioning and tail-plane sense.

(5) Operate the control column at the rate of 1½ strokes per second for 3 seconds.

(6) Repeat the test with the tail plane and rudder, No. 2 controls system accumulator exhausted and the servicing trolley connected to No. 1 controls system.

98. *Accumulator capacity test.-*

(1) Select feel OFF. The services system must be pressurized to a minimum of 1000 lb/in² to ensure that the feel selector operates.

(2) Release all pressure from the tail plane and rudder, No. 1 controls system accumulator.

(3) With the servicing trolley connected to No. 2 controls system, start the trolley and, with the control column stationary, allow the system to build up to maximum pressure. Stop the trolley.

(4) Operate the control column to extremes (rate not to exceed 1 stroke between stops in 5 seconds). There should be a minimum of 3½ strokes before the accumulator pressure is exhausted.

(5) Repeat (2), (3) and (4) with the tail plane and rudder, No. 2 controls system accumulator exhausted, and the servicing trolley connected to No. 1 controls system.

(6) If the requirements of this test fail to be met refer to para. 104.

99. *Motor test.*- If contamination of system fluid is found, or suspected, the following check must be carried out after ensuring that the tail plane and rudder, No.1 and No.2 controls systems accumulators are fully charged:-

(1) With an operator stationed at each tail-plane trailing edge, move the control column, tail-plane sense, at a rate of approximately one stroke per 2 seconds until the accumulators are discharged.

(2) Whilst carrying out (1) check quietness and smoothness of tail-plane movement visually, by ear and by touch. The normal low-level gear noise is acceptable. A succession of harsh metallic knocks accompanied by tail-plane vibration indicates motor failure and must be more fully investigated.

Ailerons

100. The following functioning tests of the ailerons must always be carried out after a replacement aileron control unit has been fitted, subsequent to the rigging instructions (*Chap. 4C*) being effected.

101. *Pressure test.*- Before installation the p.f.c.u. must be primed, bled and checked for external leakage as described in A.P. 105D-0405-16AC.

102. *Operational test.*-

(1) Release ailerons, No.1 and No.2 controls system accumulators and line

pressure from the controls systems by operating the control column until all pressure is exhausted.

(2) Connect a servicing trolley to No.2 controls system. Start the trolley.

(3) Check the ailerons for control unit functioning and aileron sense when the control column handle is displaced. Operate the control column at the rate of 2 strokes per second for 6 seconds.

(4) Repeat (3) with ailerons, No.2 controls system accumulator and line pressure exhausted and with a servicing trolley connected to No.1 controls system.

103. *Accumulator capacity test:*-

(1) Release accumulator and line pressure in No.1 controls system, connect a servicing trolley to No.2 controls system.

(2) Start the trolley, and with the control column handle at neutral, build up maximum pressure. Stop the trolley.

(3) Operate the control column; there should be a minimum of 5 full strokes before the accumulator pressure is exhausted.

(4) Repeat (1) to (3) with no accumulator or line pressure in the No.2 controls system, and with the servicing trolley connected to No.1 controls system.

(5) If the requirements of this test fail to be met refer to para. 104.

P.f.c.u. leakage check

104. To check the p.f.c.u. for excessive leakage:-

(1) Connect a ground servicing trolley to the No.1 controls hydraulic system and pressurize the system to 3000 lb/in².

(2) Centralize the control column and rudder bar.

(3) Stop the servicing trolley.

(4) Ensure no movement of the controls for a period of 60 seconds.

(5) Operate the control column, tail-plane sense, at a rate of one full stroke in five seconds. Check that two full strokes are obtained before the accumulator is exhausted.

(6) Repeat (5) operating control column aileron sense. Check that 3½ strokes are obtained.

(7) Repeat (1)-(6) with servicing trolley connected to No.2 controls hydraulic system.

(8) If the correct number of strokes is not achieved, check the return leakage of the p.f.c.u. in the affected system, the values of which must not exceed:-

Aileron	300 cc per minute
Rudder	200 cc per minute
Tail plane	600 cc per minute

(9) If the return leakages are within these values, the source of the leakage

must be found by checking non-return valves, selectors, etc., in the affected system.

Tests after fitting a replacement controls system engine-driven pump (F Mk.1 pre Mod.1814)

105. The following tests are to be carried out during engine runs before flight after a replacement controls system pump has been fitted:-

(1) With No.2 engine running at 98 per cent rev/min move the control column continuously over full travel to operate the tail plane until No.2 controls system hydraulic pressure warning lamp is illuminated.

(2) Continue to operate the column to maintain the warning lamp flickering ON and OFF, and count the number of strokes required over a period of fifteen seconds to keep the lamp flickering. This should be between 16 and 18.

(3) Run No.1 engine at 98 per cent rev/min with No.2 engine at not less than 55 per cent rev/min.

(4) Repeat (1) and (2), observing No.1 controls system warning lamp. Ignore No.2 controls system warning lamp during this test.

Note...

If, during either test, it is not possible to obtain a warning light, repeat the test at 50 per cent rev/min. The number of strokes obtained in this case should be between 8 and 10 in the 15-second period.

Tests after fitting a replacement controls system engine-driven pump (F Mk.1 post Mod.1814 and all F Mk.1A)
106. The following tests are to be carried out, during engine runs before flight, after a replacement controls system pump has been fitted:-

(1) Run No.2 engine at 98 per cent rev/min. Check that the tail plane and rudder, No.2 controls system accumulator is hydraulically charged and that feel is selected OFF before carrying out (2) and (3).

(2) Operate the control column (tail-plane sense) over its full travel at a rate of 1 stroke per second for a minimum of 45 seconds.

(3) Check that the system functions correctly.

(4) Run No.1 engine at 98 per cent rev/min with No.2 engine idling (55 per cent rev/min). Check that the tail plane and rudder, No.1 controls system accumulator is hydraulically charged and that feel is selected OFF before carrying out (5).

(5) Repeat (2) and (3).

Braking parachute release mechanism
107.

(1) Remove the braking parachute (*Chap. 13*) if fitted.

(2) Connect a servicing trolley to No.1 controls system. Start the trolley.

(3) Using a spring balance, operate

the parachute control handle in the cockpit, and check that the force required does not exceed 30 lb, and that the parachute doors and operating mechanism function correctly.

(4) Return the control handle and doors to the unoperated condition (*Chap.13*).

(5) Repeat (1) to (4) twice and stop the servicing trolley.

(6) Exhaust the pressure from No.1 controls system by operating the control column at a rate not exceeding 1 stroke between stops in 5 seconds.

REMOVAL AND ASSEMBLY

Note...

Bonding is to be restored to its previous state following breakdown of systems.

General information

108. The recommended method of removal of certain system components from the aircraft is given in the following paragraphs. Installation of a component is normally the reverse of the removal procedure; any special assembly notes are given at the end of the paragraph concerned. After assembly of a component, the relevant priming, bleeding and functioning tests, given in the previous paragraphs, must be completed.

Reservoirs

Services and No.1 controls systems

109. The reservoirs of these systems are protected on the inner side by a heat shield, to the lower horizontal portion

of which the reservoir bases are secured. Connections to the heads and bases of the reservoirs are accessible with access panels 69P and 71P removed. The removal instructions given below apply equally to either reservoir. To remove a services or No.1 controls system reservoir:-

(1) Remove access panels 63P, 69P, and 71P.

(2) Release the air pressure from the reservoirs at the release valve (63P).

(3) Unscrew and remove the ¼ in. B.S.P. cone cap from the drain connection of the reservoir to be removed and, with a two-gallon container beneath the drain, fit a suitable pipe extension.

Note...

To retain the fluid in a usable condition the container should be totally enclosed except for an air vent, the pipe extension being connected to the inlet by a short length of rubber tubing.

(4) With an external air supply of 16-18 lb/in² connected to the charging valve (access panel 63P), drain the reservoir into the container. Release the air pressure, remove the drainpipe extension and replace the cone cap.

(5) Disconnect the electrical cables from each of the j.p.t. amplifiers above the reservoirs, remove the two 2 B.A. bolts securing each amplifier tray and remove the amplifiers from the aircraft.

(6) On both reservoirs unscrew and remove the 3/8 in. B.S.P. banjo bolt securing the fluid relief valve and uncouple the first pipe union downstream of the valve. Remove the valve and pipe assemblies and fit blanks to the exposed pipe ends.

(7) Remove the two 2 B.A. bolts securing the drainpipe bracket to the frame of access panel 69P.

(8) From the base of the appropriate reservoir (71P) disconnect the following pipelines:-

Suction (services)	7/8 in. B.S.P. banjo assembly
Return (No.1 controls)	¾ in. B.S.P. banjo assembly
Return	½ in. B.S.P. banjo assembly
Pressure (air)	¼ in. B.S.P. pipe union
Drain	¼ in. B.S.P. pipe union

(9) Unscrew and remove the air release valve from the base of the reservoir.

(10) Remove the two ¼ in. B.S.P. shouldered bolts securing the reservoir base to the heat shield.

(11) Remove the two 2 B.A. bolts securing the collar, fitted around the reservoir neck, to the aircraft structure.

(12) Raise the reservoir and remove it

from the aircraft through access panel 69P.

Note...

◀ *When assembling the reservoir, the bonded seals, removed in the dismantling operations, must be renewed (para.43A) and all nuts and connections must be wire-locked.*

No.2 controls system

110. Connections to the head and base of this reservoir are accessible with panels 64S and 66S removed. Removal of the reservoir from the aircraft necessitates the prior removal of No.1 engine intermediate and reheat jet pipes (Sect. 4, Chap.1); access is then gained by removal of a panel, secured by quick-release fasteners, in the heat shield protecting the reservoir. To remove the reservoir:-

(1) Remove access panels 64S and 66S.

(2) Refer to para.109 and perform operations (2) to (4) and (6) to (11) for this reservoir.

(3) Within the fuselage, unfasten the quick-release fasteners securing the removable panel in the heat shield protecting the reservoir, and remove the panel.

(4) Remove the reservoir through the access aperture.

Note...

When assembling the reservoir, the bonded seals, removed in the dismant-

RESTRICTED

ling operations, must be renewed and all nuts and connections must be wire-locked.

Auxiliary

Removal

111. To remove the auxiliary reservoir:-

(1) Remove the No.1 engine jet pipes (Sect.4, Chap.1).

(2) Drain the No.1 controls main reservoir (para.51).

(3) Slacken the union of the inlet pipe at the base of the auxiliary reservoir and empty the reservoir.

(4) Disconnect the banjo connections at the inlet and outlet pipes, and the atmospheric head connection at the base of the reservoir.

(5) Unscrew and remove the slotnut and washer securing the reservoir to the top support plate.

(6) Remove the four 2 B.A. bolts from the flanged half-plate and remove it from the top support plate.

(7) Remove the nine 2 B.A. bolts securing the bottom support plate to the structure.

(8) Remove the reservoir from the aircraft. Remove the three 2 B.A. bolts securing the bottom support plate to the reservoir. Fit blanks to all pipe ends and reservoir connections.

Installation

112. Installation of the reservoir is the reverse of removal. After installation the main and auxiliary reservoirs must be filled and bled as detailed in para.59.

Reservoir bladder

Removal

113. To remove a reservoir bladder:-

(1) Remove the reservoir from the aircraft (refer to para.109, 110 or 111 as appropriate).

(2) Remove the banjo bolt, banjo and washers from the junction head, and the outer slotnut from the stackpipe guide (the latter operation is not required on main reservoirs).

(3) Fit the reservoir in a clamping cradle, and unscrew the outer sleeve.

(4) Remove the reservoir from the cradle and remove the outer sleeve from the cylinder.

(5) Remove the slotnut (main reservoirs, locknut) and lockwasher from the stackpipe guide.

(6) Remove the junction head, bladder, stackpipe and guide from the cylinder.

(7) Unscrew and remove the retaining nut and sealing bush from the junction head.

(8) Separate the bladder from the junction head and remove the junction

head, spring cap (main reservoirs, and filter) and stackpipe.

(9) Separate the bladder from the stackpipe guide.

Installation

114. To install a new bladder into a reservoir:-

(1) Fit new sealing rings to the junction head and sealing bush.

(2) Insert the stackpipe guide into the small orifice of the bladder.

(3) Insert the stackpipe through the large orifice of the bladder and into the stackpipe guide.

(4) Assemble the spring cap (main reservoirs, filter) to the junction head, and fit the assembly to the stackpipe.

(5) Carefully pull the larger orifice of the bladder over the junction head and check that the bladder rim fits snugly in the groove in the junction head.

(6) Fit the sealing bush over the junction head and screw on the retaining nut. Torque load to 350 lb in.

(7) Carefully insert the assembly into the cylinder, ensuring that the grooves in the stackpipe guide are positioned at 90 deg to the flats on the cylinder. Guide the stackpipe-guide through the small orifice of the cylinder. If the stackpipe guide is in its correct

RESTRICTED

position the lockwasher will fit over the guide and engage freely with the flats on the cylinder. If the washer does not so engage remove the whole assembly from the cylinder, rotate the required amount and re-insert. This procedure must be repeated as necessary until the lockwasher falls freely into position. On no account must the stackpipe guide be rotated in the cylinder or the bladder twisted to obtain the correct position.

Note...

Force must not be used on the junction head to locate the stackpipe guide in the cylinder, as this may damage the spring cap.

- (8) Fit the slotnut on the stackpipe guide and torque load to 50-60 lb in.
- (9) Fit the outer sleeve on the cylinder, but do not tighten.
- (10) Position and secure the reservoir in a clamping cradle, ensuring that the pegs locate in the junction head.

(11) Using a soft-lead pencil, draw a creep mark on the cylinder and the cradle.

(12) Fully tighten the outer sleeve, using a maximum torque loading of 250 lb in. Check for any signs of creeping. If creeping has taken place the assembly must be dismantled to enable (7) and subsequent operations to be carried out again.

(13) When (12) has been successfully completed, remove the reservoir from the cradle; wire-lock the outer sleeve

to the retaining nut, and the stackpipe guide slotnut to the cylinder.

Note...

Screw threads are to be lubricated with grease ZX-24.

Testing

115. After assembly, test the reservoir as follows:-

- (1) Apply air pressure not exceeding 5 lb/in², to the oil side of the bladder and check for leaks.
- (2) Apply air pressure not exceeding 5 lb/in², to the air side of the bladder and check for leaks.
- (3) Fill the bladder with hydraulic fluid and maintain a maximum hydraulic pressure of 56 lb/in² absolute. No leakage is permissible.

Note...

The period of time between the assembling of the reservoir and fitting it in the aircraft hydraulic system must

be kept to a minimum. If the reservoir is not to be installed in the aircraft immediately following assembly it must be stored with the bladder filled with hydraulic fluid and all connections blanked off.

TABLE 1**Torque loading of stainless steel pipe assemblies**

Outside diameter of pipe (in.)	Torque (lb in) $\pm 10\%$	Angular movement
3/16	40	} 2 spanner flats
1/4	100	
3/8	135	
1/2	175	} 1/2 spanner flats
5/8	195	
3/4	230	
7/8	280	
1	330	
1 1/4	455	
1 1/2	780	

TABLE 1A**Torque loading of bonded seals**

Section/Ref.No.	Type	Size (B. S. P.)	Torque required (lbf in.)
28F/9428452	AGS.1186A	1/8 in.	100 ± 5
28F/9428453	AGS.1186B	1/4 in.	170 ± 10
28F/9429527	AGS.1186BB	19 T.P.I., 0.6 in. o.d.	260 ± 12
28F/9429532	AGS.1186C	3/8 in.	360 ± 15
28F/9428454	AGS.1186CC	14 T.P.I., 0.75 in. o.d.	475 ± 20
28F/9428455	AGS.1186D	1/2 in.	615 ± 25
28F/9434374	AGS.1186E	5/8 in.	660 ± 30
28F/9428456	AGS.1186F	3/4 in.	700 ± 35
		All sizes over 3/4 in.	700 ± 35

RESTRICTED

TABLE 2

Accumulators - system location, access and nitrogen inflation pressures

COMPONENT	ACCUMULATOR TITLE	SYSTEM	ACCESS PANEL	PRESSURE LIMITS	PRESSURE lb/in ² RELATED TO AMBIENT TEMPERATURE					
					-26°C (-14.8°F)	-10°C (14°F)	0°C (32°F)	15°C (59°F)	30°C (86°F)	50°C (122°F)
Wheel brakes	Wheel brakes (refer to fig.4,item 3)	SERVICES	27S	+50 - 0	1455	1550	1610	1700	1790	1905
Wheel brakes Canopy Nose-wheel centring	Services system (refer to fig.4,item 2)		27S	+50 - 0	1285	1370	1420	1500	1580	1680
Shimmy damping	Nose undercarriage shimmy damper (refer to fig.3,item 4)		Nose-wheel leg	-	Charged with oil OM-15 only					
Autostabilizers Feel units Feel selector Feel simulator	Autostabilizer actuator (refer to fig.5,item 201)		66S	+50 - 0	1285	1370	1420	1500	1580	1680
Feel unit damping	Feel unit damping (refer to fig.5,item 202)		76S	+ 0 - 5	100	105	110	115	122	130
Aileron p.f.c.u. (outboard)	Ailerons, No.1 controls system (refer to fig.7,item 1)		27P	+50 - 0	1285	1370	1420	1500	1580	1680
Tail-plane p.f.c.u. (port motor) Rudder p.f.c.u. (forward piston) Braking parachute doors Ailighting gear emergency lowering	Tail plane and rudder, No.1 controls system (refer to fig.7,item 203)		76P	+50 - 0	1285	1370	1420	1500	1580	1680
Aileron p.f.c.u. (inboard)	Ailerons No.2 controls system (refer to fig.7,item 1)		27P	+50 - 0	1285	1370	1420	1500	1580	1680
Tail plane (starboard motor) Rudder p.f.c.u. (aft piston)	Tail plane and rudder, No.2 controls system (refer to fig.7,item 203)		72S	+50 - 0	1285	1370	1420	1500	1580	1680

TABLE 3

Services operating times in seconds

Service	One pump 3750 rev/min		Two pumps 3750 rev/min	
	Up, in or close	Down, out or open	Up, in or close	Down, out or open
Alighting gear	7.5 max.	18.0 max.	-	-
Alighting gear emergency	-	22.0 max.	-	-
Flaps	4.0 min. 6.0 max.	5.0 min. 7.0 max.	4.0 min. 6.0 max.	5.0 min. 7.0 max.
50 deg travel Air brakes -	4.5 max.	6.0 max.	3.5 max.	4.0 max.
70 deg travel	5.0 max.	7.0 max.	4.0 max.	4.5 max.
Canopy	3.0 min. 5.0 max.	3.0 min. 5.0 max.	3.0 min. 5.0 max.	3.0 min. 5.0 max.

TABLE 4
Tools and equipment

REF.NO.	DESCRIPTION	APPLICATION/REMARKS
26DK/95171	Spanner, box	Micronic filters
26DK/95072	Spanner, reservoir	Outer sleeve tensioning
26DK/95175	Spanner, special	Hydraulic reservoir
26DK/95176	Spanner, socket, special	
26DK/95177	Cradle, clamping	
26DK/95316	Spanner, special	
26DK/95340	Spanner, hydraulic union	
26DK/95341	Spanner, hydraulic union	Sequence valve
26DK/95342	Spanner, hydraulic	5/8 in. dia. Avery couplings
26DK/95575	Spanner, key	1/2 in. dia. Avery couplings
26DK/	Spanner, banjo bolt	3/8 in. dia. Avery couplings
26DK/	Wrench, peg spanner	Aux. hydraulic reservoir
26DK/	Spanner, peg, slotnut	
26DK/95769	Tool, end cover, withdrawing	
1L/233	Wrench, crowfoot, 5/16 in. B.S.F. x 1/4 in. S.D.	Tecalemit, pressure filter
1L/234	Wrench, crowfoot, 3/8 in. B.S.F. x 3/8 in. S.D.	Torque loading hydraulic pipe unions
1L/332	Adapter, 3/8 in. S.S. x 1/4 in. S.P.	
37J/3432	Extractor magnetic element	
26DK/95191	Dispenser, hydraulic fluid, Juniper	Hydraulic pumps
26DK/95039	Adapter, use with 26DK/95191	
26DK/95144	Pipe, overflow	Priming hydraulic reservoirs
26DK/95368	Pipe, overflow	
26DK/95220	Adapter, nose-wheel shimmy damper	Hydraulic system, Mk.1 only
26DK/95304	Adapter, nitrogen charging	Hydraulic system, Mk.1A only
26DK/95781	Rig, setting	Accumulator charging
4F/3603	Trolley, Mk 3	Accumulators
4F/3761 or	Trolley	Hydraulic pump connections
4F/4527 or		Hydraulic servicing
4F/5147 or		Electrical servicing
4F/3786 or		
4F/4258		
4G/3029	Gauge pressure	Wheel brake servicing
4G/6734	Trolley	Accumulators, nitrogen charging

TABLE 5
Major components - frames 1-25A

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P. REFERENCE			
				A.P.	SECT.	CHAP. APP.	
Accumulators							
1	No.1 and No.2 controls ailerons	Dowty Roto1 { 8785 8603 8603 8794	2	1803	T	8	7
2	Services system				T	8	6
3	Wheel brakes				T	8	6
4	Nose undercarriage shimmy damper				T	8	9
Control unit							
8	Brakes { pre Mod.2150 post Mod.2150	Dunlop { ACM 12734 AC 60692	1	1803	S	7	2 3
Filters							
10	Pressure { pre Mod.1865 No.1 controls and services No.1 post Mod.1865 No.1 controls and services No.1 post Mod.2169 No.1 controls	EB2.73.4495 EB2.73.4485 EB2.73.6655	2 2	101B-1001-1A			
Jacks							
13	Canopy { pre Mod.2290 post Mod.2290	Electro hydraulics { 6098 6149/1	1	1803	F	9	
14	Nose undercarriage { pre Mod.1591 post Mod.1591	J5080 1.01003.001			T	15	39
15	Nose undercarriage up-lock	J5203			U	11	5
16	Nose undercarriage down-lock	J5204			T	15	35
17	Shimmy damper	J5204 4561			T	15	35
					T	5	3
19	Nitrogen bottles Ailerons, No.1 and No.2 controls systems	8786	2		T	8	11
Pressure gauges							
24	Accumulators (4000 lb)	Appleby and Ireland AI-440-EE	4	112G-0400-1	4-2		
25	Brakes (4000 lb) { Mk.1 Mk.1A	Sangamo Weston { S63-4-657 or 721 S63-4-721					
26	Services system, post Mod.1802 (Mk.1): Mod.1809 (Mk.1A)	Appleby and Ireland AI-756	1275A		16	29	
Pressure transmitters							
30	Brakes { Mk.1 Mk.1A either	Sangamo Weston { S122-4-31 S122-4-55	112G-0400-1				
31	Services system gauge, post Mod.1802 (Mk.1): Mod.1809 (Mk.1A)	Appleby and Ireland AI-757	1	1275A	15		
Pressure and protection							
35	Pressure switch	Thermal controls TP 298	1275A		11		
36	Pressure relay valve { Mk.1 Mk.1A	Dunlop { ACM 18798 or 15698 ACM 18798	105B-0715-1				
37	Protection unit { pre Mod.4056 post Mod.4056	6097 1.02507.001	1	1803	T	13	48
Restrictors							
41	Canopy, two-way	H5024/25 or 1.00379.001	2		T	13	
42	Nose undercarriage, one-way	H5048/8	1		U	9	32
					T	13	56

continued...

TABLE 5 Major components - frames 1-25A - continued

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P. REFERENCE					
				A.P.	SECT.	CHAP. APP.			
Selectors									
46	Alighting gear	Dowty Roto1	1	1803	T	14	8		
47	Alighting gear emergency				U	8	24		
					T	14	8		
48	Canopy				U	8	24		
					T	11	12		
50	Two-missile pack	D	8	51					
51	By-pass valve	U	7						
					T	14	3	1	
					T	13	54		
Valves									
Inflation									
56	Accumulator charging	High Pressure Components	4	4303Z	4	6	1		
57	Shimmy damping							A58 or A57/2	4
								A58	4
		A58 or A57/2	1						
		A58	1						
Non-return									
60	Services pressure, 1/4 in. B.S.P.	H2006	2		T	13			
63	Controls, No.1 pressure and services return, 3/8 in. B.S.P.	8395	4	5	T	13	22		
								pre Mod.2416	
		post Mod.2416							
Relief									
70	U/c up line	H5051/36 H5052			T	13			
71	Thermal, u/c emergency				T	13	53		
Shuttle									
75	Nose u/c jack	Dowty Roto1		1803	T	13	52		
76	Nose u/c up-lock jack				8423	T	13	52	
Swivel couplings									
80	Nose undercarriage UP	CB521Y CB520Y CB478Y Mk. A 11825Y-A01 CB652Y 12086Y-A01	1		D	11	28		
81	Nose undercarriage DOWN				D	11	28		
82	Nose undercarriage EMERGENCY				D	11	28		
83	Shimmy damping				D	11	31		
					D	11	30		
					D	11	30		
					D	11	30		
					D	11	30		
Flexible pipes									
84	Shimmy damping bleed	Dunlop DC100B/15.4							
Couplings									
86	Armament connections	Lockheed Avery	2		AVA58D				
87	Blanking caps				AVA1150D				
		AVA58D							
		AVX3393							
		AVA64D							



FIG.8. LOCATION OF MAJOR COMPONENTS - FRAMES 1-25A

RESTRICTED



FIG.9. LOCATION OF MAJOR COMPONENTS - FRAMES 25B-50

A2132-3

RESTRICTED

TABLE 6
Major components - frames 25B-50

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P. REFERENCE		
				A.P.	SECT.	CHAP. APP.
	Autostabilizers					
101	Tail plane	Type 214 Mk.1 (Ref.No.6T/614)	1	4685	4	3
	Control units					
105	Feel unit, tail plane	EB2.45.2509	1	101B-1001-1A		
	Couplings					
109	Ground servicing, oil filling, $\frac{1}{2}$ in. B.S.P.	Lockheed Avery { AVA551B AVA1151D	3			
110	Ground servicing, air, $\frac{1}{2}$ in. B.S.P.		1			
111	At hydraulic pumps	Lockheed Avery	12			
	Filters					
115	Services return	EB2.73.4477	2	101B-1001-1A		
116	Services pressure { pre Mod.1865 post Mod.1865	EB2.73.4495				
117	No.2 controls pressure { pre Mod.1865 post Mod.1865	EB2.73.4485				
118	No.1 controls return	EB2.73.4495				
119	No.2 controls return	EB2.73.4485				
		EB2.73.4478				
	Heat exchangers					
123	Services and No.1 controls	Marston Excelsior				
124	Services and No.2 controls	Marston Excelsior				
	Pressure regulators					
128	Services pressure { Mk.1 Mk.1A	Dowty Roto1 { 11650YA02 or 11651A02 11651YA02			S 9 117	
	Pumps					
132	No.1 controls	Integral { Type 220 Mk.37 (Ref.No.37J/1232) Type 180 Mk.50 (Ref.No.37J/7008) or 180 Mk.65 (Ref.No.37J/	1	1803	J 2 10	
133	No.2 controls				J 2 10	
134	Services No.1				J 2 10	5
135	Services No.2					
	Reservoirs					
139	No.1 controls auxiliary { Mk.1 post Mod.1803 Mk.1A post Mod.1823	EF3.73.223		101B-1001-1A		
	Selectors					
143	Flaps	Dowty Roto1 { C7435Y Mk.B or 1.00135.002 H2015	1	1803	D 8 51 1	
	Valves				U 8	
146	Auxiliary reservoir atmospheric head (post Mod.2048)				T 13	
	Relief					
149	Auxiliary reservoir atmospheric head (post Mod.2048)	1.01344.001 included in EF2.73.2627		1803	U 9 39	
	Vent					
152	Auxiliary reservoir atmospheric head (post Mod.2048)	EF2.73.2625		101B-1001-1A		

TABLE 7
Major components - frames 50-63

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P. REFERENCE						
				A.P.	SECT.	CHAP.	APP.			
Accumulators										
201	Autostabilizer actuator	Dowty Roto1 { 8603 8795 A1032 8795 A1032 A1019	1	1803	T	8	6			
202	Feel unit damping { Mk.1 { pre Mod.403 post Mod.403 Mk.1A { pre Mod.373 post Mod.373				T	2	10	1		
					T	8	10	3		
203	Tail plane and rudder, No.1 and No.2 controls systems	T	8	10	1					
Autostabilizers										
207	Rudder	Type 214 Mk.3 Ref.No.6T/613	1	4685	4	3	3			
Control units		Hobson { Type 205 Mk.1 or 2 Type 205 Mk.2						4604Z	1	8
211	Feel simulator, tail plane and rudder { Mk.1 Mk.1A									
212	Feel unit, rudder									
Filters										
216	Services pressure, feel system	Lockheed Purolator { MFHA.15100 MFHA.15100	1	1803	B	6	14			
217	Services pressure, tail-plane autostabilizers									
Jacks										
222	Air brake, port	Dowty Roto1 { J.5033 J.5033 J.5040 or J.5061 J.5081 or J.5061 J.5168 J.5168 5189 1.03034.001	1	1803	T	15	40			
223	Air brake, stbd. { pre Mod.1525									
222	Air brake, port									
223	Air brake, stbd. { post Mod.1525									
224	Air brake lock jack, port									
225	Air brake lock jack, stbd.									
226	Brake parachute pre Mod.4208 post Mod.4208	105B-0907-16C	1803 T 15 38	105B-0952-16C						
Nitrogen bottles										
230	Tail plane and rudder, No.1 and No.2 controls systems	Dowty Roto1 8607	2	1803	T	8	12			
P.f.c.u.										
234	Tail plane	Hobson { Type 150 S and T Type 337 Mk.3	1	105D-0405-16AC						
235	Rudder									
Pressure gauges										
239	Tail plane and rudder, No.1 and No.2 controls systems accumulators	Appleby and Ireland { AI-440-EE 0-4000 lb AI-440-EE 0-4000 lb AI-441- 0-200 lb	2	112G-0400-1	4-2					
240	Autostabilizer actuator accumulator									
241	Feel unit damping accumulator									
Pressure switches										
245	Controls No.2, tail-plane motor	Thermal controls TP.298	1	1275	11					
Pumps										
249	Hydraulic, hand { Mk.1 Mk.1A	EB1.73.1735 EB3.73.125	1	101B-1001-1A						

continued...

TABLE 7 Major components - frames 50-63 - continued

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P.	A.P. REFERENCE SECT.	CHAP.	APP.		
Reservoirs									
253	No.1 controls	EB2.73.4453	}	101B-1001-1A					
254	No.2 controls								
255	Services								
Swivel couplings									
260	Rudder feel unit, pressure	C.8477Y	}	1	D	11	26		
261	Air brake, stbd. IN	C.8361Y			D	11	25		
262	Air brake, port IN	C.8360Y			D	11	25		
263	Air brake, stbd. OUT								
264	Air brake, port OUT								
Selectors									
	Air brakes, Mk.1	Dowty Roto1	}	1803					
270	Air brakes Mk.1A pre Mod.2039	0.7480.Y.A02 or 1.00132.002			D	8	53		
	Air brakes Mk.1A post Mod.2039	0.7480.Y.A02 or 1.00132.002			U	8	53	2	
271	Braking parachute { pre Mod.4065 post Mod.4065	0.7480.Y.A03 or 1.00132.003			T	11	11		
272	Feel units { pre Mod.4065 post Mod.4345	C.5011			U	10			
		1.02464.001 1.02835.001			D	8	54	1	
		0.7481.Y.A03 or 1.00133.002							
Valves									
Inflation									
277	Accumulator charging { Mk.1 Mk.1A	High Pressure Components { A58 or A57/2 or 4 A58	4	4303Z	4	6	1		
By-pass									
281	Rudder feel	8521	1		T	13	54		
Non-return									
285	Services pressure, 1/2 in. B.S.P. { Mk.1 Mk.1A	H.2005 or 2006	2		}	1803			
286	No.1 controls return	H.2006	2						
287	No.2 controls return	H.2008	1						
288	Services pressure, 1/2 in. B.S.P.	H.2008	1	T			13		
289	Services return	H.2008	2						
290	No.2 controls pressure, 3/8 in. B.S.P.	H.2007	2						
291	Air supply, engine to reservoirs	H.2009	1				10	3	
Pressure relief									
293	Air supply to reservoirs { pre Mod.2238 post Mod.2238	8429	3				T	13	49
294	Hydraulic from reservoirs	1.01345.001	3		U	9	39		
		8466	3		T	13	50		
Synchronizing									
296	Air brakes	8439	1		T	12	10		


TABLE 8
Major components - main planes

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P. REFERENCE			APP.					
				A.P.	SECT.	CHAP.						
Autostabilizers												
301	Aileron, port	Type 214, Mk.2 Ref.No.6T/601	}	4685	4	3						
302	Aileron, stbd.	Type 214, Mk.4 Ref.No.6T/617										
Brakes												
306	Port wheel	Refer to Leading Particulars						1	2337	3		
307	Maxaret unit, port	Dunlop AC13936							1803S	8		
308	Starboard wheel	Refer to Leading Particulars							2337	3		
309	Maxaret unit, stbd.	Dunlop AC13942		1803S	8							
Filters												
313	Refer to item 345											
314	Aileron autostabilizer, P and S	Lockheed Purolator N.F.H.A.15100	1 each	1803B								
Jacks												
318	Main undercarriage, port	pre Mod.4112	}	1	105B-0925-16C							
		post Mod.4112										
		post Mod.4220										
		post Mod.4375										
319	Main undercarriage, stbd.	pre Mod.4112										
		post Mod.4112										
		post Mod.4220										
		post Mod.4375										
		Dowty Roto1	1.03003.009									
			1.03003.011									
			1.03003.012									
			1.03003.013									
			1.03004.009									
			1.03004.011									
			1.03004.012									
			1.03004.013									
320	Main undercarriage door, P and S	J.5373	1 each	1803 T	15	41						
321	Main undercarriage door lock, P and S	5243	1 each	105B-0907-16C								
322	Main undercarriage down-lock, P and S	5260	1 each									
323	Flap, outboard, port	J.1027	1	1803	T	15	}					
324	Flap, outboard, stbd.	J.1027	1									
325	Flap, inboard, port	J.1027	1									
326	Flap, inboard, stbd.	J.1027	1									
											36	
P.f.c.u.												
330	Aileron, P and S	Hobson Type 203 Mk.3	2 each	4604G	2	1						
Restrictors												
332	One-way, flaps UP, P and S	Dowty Roto1 { H5044 H5045		1803T	[13 13	56 59	1 1					
333	Two-way, flaps DOWN, P and S											
Valves												
Inflation												
334	Wheel brake pressure, P and S { Mk.1 Mk.1A	High Pressure Components { A58 or 57/2 or 4 A58	1 each	4303Z	4	6	1					
Relief												
337	Undercarriage up, P and S	H5051/36			T	13	4	5				
Shuttle												
340	Undercarriage jack, P and S	Dowty Roto1 { 8420 8423 8423		1803	T	13	}					
341	Undercarriage door jack, P and S											
342	Undercarriage door-lock jack, P and S											
					T	13	51					
					T	13	52					
					T	13	52					

continued...

TABLE 8 Major components - main planes - continued

ITEM NO.	COMPONENT	TYPE OR PART NO.	QTY.	A.P. REFERENCE			APP.			
				A.P.	SECT.	CHAP.				
Sequence										
345	Main undercarriage c/w filter 8198, P and S pre Mod.1958	Dowty Roto1	1 each	T	12	3	2			
	Main undercarriage c/w filter 8198, P and S post Mod.1958			U	10	5				
346	Undercarriage doors			8049	T	12		2 & 11		
				1.00322.002	U	10		6		
	P and S, Mk.1			8387, 8397 or H4006	T	12		2 & 11		
				1.00321.001	U	10		6		
	P and S, Mk.1A			8397 or H4006	T	12		2 & 11		
				1.00321.001	U	10		6		
Relay										
349	Main undercarriage, P and S			Electro Hydraulics 6960		F		8	15	
Swivel couplings										
352	Undercarriage door jack, UP, P and S	Dowty Roto1	1	1803	D	11	28			
353	Undercarriage door jack, DOWN, P and S				C8779Y Mk.A	D	11	28		
354	Undercarriage door jack, EMERGENCY, P and S				C8784Y Mk.A	D	11	28		
355	Flap, O/B jack, UP, port				C8784Y Mk.A	D	11	28		
356	Flap, O/B jack, UP, starboard				C8781Y Mk.A	D	11	28		
357	Flap, O/B jack, DOWN, port				C8781Y Mk.A	D	11	28		
358	Flap, O/B jack, DOWN, starboard				C8782Y Mk.A	D	11	28		
359	Flap, I/B jack, UP, port				C8782Y Mk.A	U				
360	Flap, I/B jack, UP, starboard				1.00434.001	U				
361	Flap, I/B jack, DOWN, port				1.00434.002	D	11	28		
362	Flap, I/B jack, DOWN, starboard				C8783Y Mk.A	D	11	28		
363	Wheel brake, port				C8783Y Mk.A	U				
364	Wheel brake, starboard				1.00632.003	U				
					1.00632.004	U				
Flexible pipes										
370	Undercarriage jack, UP, P and S	Dunlop DC-202-B-14-2	1 each							
371	Undercarriage jack, DOWN, P and S	Palmer Aero FP406/369								
372	Undercarriage jack, EMERGENCY, P and S	Dunlop DC-202-B-16-8								
373	Undercarriage, down-lock jack, P and S	Dunlop DC-201-B-17-2								
		Palmer Aero FP404/360								
374	Maxaret return, P and S	FP404/1032								
		DC-300-B/40 or DC-400-A/40								
375	Maxaret return, P and S	DC-400-C-36								
		DC-300-D-36 or DC-400-C-36								
376	Wheel-brake pressure, P and S	Dunlop DC-400-A-40								
377	Aileron jacks, I/B and O/B return P and S	DC-101-C-34								
378	Aileron jacks, I/B and O/B pressure P and S	AHO 34589								
		AHO 30869								



PLAN VIEW OF PORT MAIN PLANE;
STARBOARD MAIN PLANE SIMILAR

FIG. 11. LOCATION OF MAJOR COMPONENTS—MAIN PLANES



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.



LIGHTNING MK. 1
COVER PITOT HEAD
EB2-88-5111