

Chapter 8A AIR SYSTEMS - GENERAL INFORMATION, MAIN AIR SUPPLY AND AUXILIARY POWER SUPPLIES SYSTEMS

(completely revised)

LIST OF CONTENTS

DESCRIPTION	Para.	SERVICING	Para.	Para.
				<i>Accessory drive unit</i>
<i>General information</i>	1	<i>Lubrication</i>	9	<i>Removal...</i> 13
<i>Main air supply</i>	2	<i>Main air supply duct</i>		<i>Assembly</i> 14
<i>Accessory drive unit</i>	4	<i>Checks and adjustments</i>	10	<i>D.C. generator</i>
<i>Accessory drive unit shut-down valve</i>	6	<i>Torque-loading Conoseal couplings</i>	11	<i>Removal...</i> 15
<i>Reheat nozzle control</i>	7			<i>Assembly</i> 16
<i>Reheat pipe cooling</i>	8	REMOVAL AND ASSEMBLY		<i>A.C. generator</i>
		<i>Equipment required</i>	12	<i>Removal...</i> 17
				<i>Assembly</i> 18

LIST OF TABLES

	Table
<i>Torque-loading Conoseal couplings</i>	1
<i>Tools and equipment</i>	2
<i>Major components - frames 1-25A</i>	3
<i>Major components - frames 25B-57</i>	4

LIST OF ILLUSTRATIONS

	Fig.		Fig.
<i>Layout of systems</i>	1	<i>Main air supply - frames 48 to 55</i>	
<i>Air systems diagram - front fuselage</i>	2	<i>(Mks. 1 and 1A A/C)</i>	8
<i>Air systems diagram - rear fuselage...</i>	3	<i>Reheat services</i>	9
<i>Main air supply - frames 25B to 39</i>		<i>Accessory drive unit installation</i>	10
<i>(Mk. 1 A/C)</i>	4	<i>Accessory drive unit -</i>	
<i>Main air supply - frames 25B to 39</i>		<i>removal and assembly</i>	11
<i>(Mk. 1A A/C)</i>	5	<i>A.C. generator - removal</i>	
<i>Main air supply - frames 39 to 48</i>		<i>and assembly</i>	12
<i>(Mk. 1 A/C)</i>	6	<i>Location of major components -</i>	
<i>Main air supply - frames 39 to 48</i>		<i>frames 1-25A</i>	13
<i>(Mk. 1A A/C)</i>	7	<i>Location of major components -</i>	
		<i>frames 25B-57</i>	14

DESCRIPTION

General information

1. This chapter contains information about the main air system, the accessory drive unit and reheat jet pipe services. A list of major components is provided in Tables 3 and 4.

Main air supply (fig.4 to 8)

2. The air employed for the main supply, with the exception of some cooling air, is derived from two interconnected 15th-stage compressor tapplings, one

from each engine, and passes through non-return valves to the main air duct.

3. The main air duct, which comprises several interconnected lengths of stainless steel ducting, runs along the starboard side of the rear fuselage, approximately parallel with the horizontal datum line, from frame 25 to frame 55. Thermal expansion is provided for by the inclusion of sliding and bellows-type expansion couplings, and Conoseal-type clamp couplings. Refrasil-type lagging secured to the duct by

hose clips reduces the heat transfer. An accessory drive unit turbine shut-down valve is inserted in the duct at frame 53. The duct is divided, at its forward end, into two pipes which supply the cabin air system (Chap.8B) and the canopy seal, gun purging, de-misting, anti-icing and rain dispersal systems (Chap.8C) respectively. The aft end of the duct traverses the fuselage at frame 55 to terminate on the volute casing of the accessory drive unit. Intermediate tapplings direct air to operate the reheat nozzles (para.7) and




Fig.1. Layout of systems

to assist the induction of reheat pipe cooling air (*para. 8*).

Accessory drive unit (*fig. 10*)

4. The accessory drive unit, located in the port side of the fuselage between frames 53 and 55, comprises a constant speed air turbine, gearbox, governor, control switch, shut-off valve, over-speed cut-out switch, cooling fan, and various ducts. The turbine is operated by air from the engine compressors and it drives, through the gearbox, the fan and the a.c. and d.c. generators. For further information on the accessory drive unit refer to A.P. 2240A, Book 15, Vol. 1 and 6.

5. Air supplied to the turbine via a shut-down valve (*para. 6*), passes through the turbine and is then discharged into the fuselage. Ram air from the fin intake is ducted to the fan casing where it is distributed to various ducts for cooling gearbox oil, the a.c. generator and the d.c. generator. The exhaust air then passes through the auxiliary air heat exchanger into the fuselage.

Accessory drive unit shut-down valve (*fig. 9*)

6. The valve is an electro-mechanically-operated butterfly type, incorporating a manual reset lever (access panel 47S), and is interposed in the main air duct between frames 53 and 54 on the starboard side of the fuselage. It is a safety device which automatically shuts off the main air supply to the air turbine (*para. 4*) should overspeeding of the turbine occur, and is electrically controlled by an over-speed cut-out

switch incorporated in the turbine. Once overspeeding has occurred and the valve has operated, it can only be reset manually on the ground. For a detailed description and the resetting procedure refer to A.P. 2240A, Vol. 1, Book 15, Sect. 3, Chap. 6.

Note...

The embodiment of Mod. 2184 deletes the regulating facilities from the valve; the air inlet is left open to atmosphere.

Reheat nozzle control (*fig. 9*)

7. Reheat nozzle area is varied by an air-motor-driven screwjack. The air supply is drawn from the main air duct through a tapping upstream of the accessory drive unit shut-down valve (*para. 6*). At frame 57, the air supply is routed through two pipes, one pipe continuing along the starboard side and the other crossing the fuselage and continuing along the port side; both terminate at their respective motors on No. 1 and No. 2 reheat pipes. A small tapping from each branch pipe directs compressed air to the associated air motor control unit. For detailed information of the reheat system refer to Sect. 4, Chap. 1 and to A.P. 102C-1520-1, Sect. 1, Chap. 5.

Reheat pipe cooling (*fig. 9*)

8. The reheat pipes are cooled by air passed between their inner and outer skins. The air is introduced from outside through four intakes in the fuselage skin (*Chap. 8D*); in flight, this is effected by ram pressure. To maintain the cooling air flow during ground run-

ning when no ram pressure exists, each duct from the intakes incorporates an injector nozzle through which compressed air flows to induce the flow of cooling air. The compressed air is directed to the nozzles from two tappings at frame 55 in the air motor supply pipe.

SERVICING

WARNING

The relevant safety precautions detailed on the LETHAL WARNING marker card must always be observed before entering the cockpit or performing any operations upon the aircraft.

Lubrication

9. After breakdown of pipe joints and components:-

- (1) Ensure good ventilation.
- (2) Thoroughly clean with trichloroethane, Ref. No. 33D/2201949, the surfaces to be lubricated.
- (3)
 - (a) *Screw threads*
Using a soft brush, apply grease ZX-24. Allow 30 minutes to elapse before assembly.
 - (b) *Sliding joints*
Using a soft clean cloth, apply Molybdenum powder No. 3 (C.S. 2819) to the sliding surfaces of the joints to be treated. Move the joint repeatedly to bed-in both surfaces. Remove surplus powder before assembly. If a new component is being fitted, treat sliding surfaces with Molybdenum disulphide (A.P. 101B-1000-6, Part 1, Chap. 1),

substituting Molybdenum powder No. 3 for Molybdenum paste 300 in the final operation.

Main air supply duct

Checks and adjustments

10. On completion of any servicing operation involving the breakdown of the main air supply duct, the relevant dimensions shown in fig. 4 to 8 inclusive must be checked and, where necessary, adjustments made to achieve them.

Torque-loading Conoseal couplings

11. The torque-loading figures given in Table 1 are applicable when tightening clamp bolts incorporated on all Conoseal-type couplings.

REMOVAL AND ASSEMBLY

Equipment required

12. The special-to-type tools and equipment required during removal and assembly operations are listed in Table 2.

Accessory drive unit

Removal (fig. 10 and 11)

13. To remove the accessory drive unit:-

(1) Ensure that the necessary precautions in Sect. 4, Chap. 1, are being observed.

(2) Remove the intermediate and reheat pipes (Sect. 4, Chap. 1).

(3) Fit the rear fuselage walkway (Sect. 2, Chap. 4).

(4) Remove the flexible pipe between the turbine air inlet cross-over pipe and frame 55.

(5) Remove the cross-over pipe by releasing the two clamps, and screwing down on the large nut at the starboard end to release the flexible metal gaskets at the flanged joints.

(6) Remove the cooling air duct by disconnecting at:-

(a) the joint on frame 53, starboard side

(b) the cooling fan inlet

(c) the downstream end of the 2½ in. non-return valve

(d) the compartment cooling air pipe.

(7) Remove the section of compartment cooling air pipe extending forward to frame 53 by releasing the joint at frame 53 and the intermediate clipping.

(8) Remove the accessory drive unit cooling manifold by disconnecting at:-

(a) The cooling fan outlet

(b) The a.c. generator

(c) The d.c. generator

(d) The oil cooler inlet

(9) Disconnect the fibreglass pipe at the oil cooler outlet and release the clip at frame 55.

(10) Remove the breather pipe between the turbine adapter casing and the fuselage skin (detail A).

(11) Disconnect the turbine exhaust duct, and slide it aft.

(12) Disconnect the cables from the a.c. and d.c. generator terminal blocks (access panel 77P).

(13) Disconnect the cables from the turbine underspeed/overspeed switch and the stall-warning switch.

(14) Release the d.c. generator mounting clamp, withdraw the generator and remove it from the aircraft.

(15) Release the a.c. generator mounting clamp, withdraw the a.c. generator (weight about 60 lb) and remove it from the aircraft.

(16) Remove completely the aft, and the forward inboard, tie-rods connecting the gearbox with the fuselage. Disconnect the forward outboard tie-rod at the gearbox and swivel it upwards about its remaining bolt.

(17) Attach the hoist to the slinging point at frame 54.

(18) Attach the lifting hook of the hoist to the lifting eye on the air turbine casing, and take the weight of the unit.

(19) Mount the accessory drive unit handling cradle on the jet-pipe rails and move it forward to frame 54.

(20) With two assistants, one to operate the hoist and the other to assist in handling, withdraw the mounting bolts, bottom bolt first, from the gearbox. Lift the drive unit to clear the jet pipe rail, whilst applying restraint to




FIG. 3. AIR SYSTEMS DIAGRAM-REAR FUSELAGE

prevent damage to the gearbox or fuselage components.

(21) Remove the pin and roller assembly from its stowage on the handling cradle and insert it through the bottom attachment bolt hole in the drive unit.

(22) Rotate the accessory drive unit until the turbine casing faces to starboard, and lower it carefully until the rollers contact the aft end of the cradle rails. Move the rollers forward, whilst still lowering the unit, until the upper mounting hole is aligned with the holes in the cradle locating brackets. Fit the locating pin and disconnect the hoist.

(23) Roll the cradle aft, and lift it away from the aircraft.

Assembly

14. To install the accessory drive unit:-

(1) Ensure that the necessary precautions (Sect. 4, Chap. 1) are being observed.

(2) Mount the accessory drive unit in the handling cradle (para. 13 (21) and (22)).

(3) Lift the cradle and drive unit on to the jet-pipe rails and move them forward to a convenient point near frame 54.

(4) Attach the hoist to the slinging point at frame 54 and to the drive unit lifting eye.

(5) Take the weight of the drive unit

on the hoist, and withdraw the cradle locating pin.

(6) With two assistants, one to operate the hoist and the other to assist in handling, lift the drive unit out of the cradle until the lower jet-pipe rail is cleared. Remove the cradle. Remove the pin and roller assembly from the drive unit and stow in the cradle.

(7) Manoeuvre the drive unit into position between frames 53 and 55, rotating it so that the gearbox is facing forward; lower the unit slowly until the top mounting bolt can be inserted.

(8) Locate and fit the bottom bolt (eye-end forward) and align the eye-end of the bolt with the tie-rod. Bolt in position and lock with a new split pin. Refit nuts on both mounting bolts and secure with new split pins.

(9) Fit the tie-rods.

(10) Assemble the breather pipe and wire-lock the unions.

(11) Refit the a.c. generator and d.c. generator, in that order, after first:-

(a) Immersing the drive quills in gearbox oil and ensuring an unbroken film of oil on the splines (the quills are fitted wet).

(b) Lubricating the a.c. generator drive shaft with gearbox oil.

(c) Lubricating the d.c. generator drive shaft with grease XG-2.

(d) Lubricating the clamp-ring adapter flanges and screw threads with grease XG-278.

Note...

Ensure that the white lines on the clamp ring and adapter flange are aligned in each case. Tighten the clamp ring nuts with a torque wrench, tightening each at least three times to a loading of:-

A.C. generator	100 lb in.
D.C. generator	60 lb in.

(12) Connect the electrical cables to the a.c. and d.c. generator terminal blocks and the overspeed/underspeed, and stall-warning switches.

(13) Fit the accessory drive cooling ducts, ensuring correct locking and bonding at all joints.

Note...

The pipe clamp latches at each end of the 2½ in. non-return valve must be vertically disposed and facing forward.

(14) Fit the turbine exhaust duct.

(15) Fit the air turbine inlet cross-over pipe:-

(a) Insert the metal gaskets and position the pipe, bellows to port, between the turbine and the fuselage pipe.

(b) Unscrew the large union nut to bring the faces of the flanged joints together.

(c) Fit the clamps and, after

RESTRICTED




FIG. 4. MAIN AIR SUPPLY-FRAMES 25B TO 39 (MK.1 A/C)

1-8542-1

RESTRICTED




FIG. 5. MAIN AIR SUPPLY-FRAMES 25B TO 39 (MK. IA A/C)

RESTRICTED




FIG. 6. MAIN AIR SUPPLY - FRAMES 39 TO 48 (MK. I A/C)

1-8543-1

RESTRICTED

NOTE...
ALL DETAILS ARE LOOKING
OUTBOARD TO STARBOARD
UNLESS OTHERWISE STATED






FIG. 7. MAIN AIR SUPPLY - FRAMES 39 TO 48 (MK. IA A/C)

RESTRICTED







FIG. 8. MAIN AIR SUPPLY-FRAMES 48 TO 55 (MKS. I AND IA A/C)

RESTRICTED





FIG. 9. REHEAT SERVICES

RESTRICTED



NUMBERED OPERATIONS REFER TO REMOVAL SEQUENCE

FIG.10. ACCESSORY DRIVE UNIT INSTALLATION

1-8546-1

RESTRICTED







FIG.II. ACCESSORY DRIVE UNIT-REMOVAL AND ASSEMBLY

ensuring correct setting of the flexible pipe adapter, tighten them.

(d) Tighten the large union nut until the inboard face of the fuselage pipe contacts the pipe support bracket.

(e) Connect the flexible pipe.

(16) Refer to A.P.2240A, Vol.1 and 6, (Book 15), Sect.4, Chap.1 and ensure that the turbine nozzle is in the open condition.

(17) Remove the handling equipment and assemble the jet pipes (Sect.4, Chap.1).

D.C. generator

Removal

15. To remove the d.c. generator:-

- (1) Remove access panel 77P.
- (2) Disconnect the electrical cables from the generator terminal block.
- (3) Detach the cooling pipe from the generator by unfastening the quick-release clamp.
- (4) Support the generator and remove the securing clamp.
- (5) Move the generator forward approximately 2 in. to free the drive from the accessory drive unit gearbox and remove it from the fuselage.

Assembly

16. To assemble the d.c. generator re-




Fig.12. A.C. generator - removal and assembly

verse the removal procedure (*para. 15*) first lubricating the quill, drive shaft adapter flange and clamp-ring, using grease XG-287. The white lines on the clamp-ring and adapter flange should first be aligned and the clamp-ring nut tightened at least three times to a torque load of 60 lb in.

A.C. generator

Removal (*fig. 12*)

17. To remove the a.c. generator:-

- (1) Remove the d.c. generator (*para. 15*).
- (2) Remove the outboard tie-rod from the accessory drive unit gearbox, through the access aperture.
- (3) Disconnect the a.c. generator cooling duct.
- (4) Disconnect and stow the electrical cables from the terminal blocks on the a.c. generator casing.
- (5) Attach the handling arm to the access panel landing (*detail A*).
- (6) Assemble the hoisting equipment and attach it to the handling arm.
- (7) Fit the cradle to the handling arm (identification plate outboard) and, with the handling arm fully lowered,

insert the cradle through the access aperture.

(8) Raise the cradle to support the a.c. generator, positioning it as in *detail A*.

(9) Remove the a.c. generator clamp-ring.

(10) Swing the handling arm and a.c. generator forward to disengage the drive from the gearbox and unwind the hoist to align the a.c. generator with the access aperture.

(11) Swivel the a.c. generator through 90 deg and manoeuvre it through the access aperture.

(12) Lift the a.c. generator (weight approx. 60 lb) from the handling arm.

Assembly

18. To assemble the a.c. generator:-

(1) Lubricate the drive quill and drive shaft (*para. 14 (11)*) and insert the quill.

(2) Mount the a.c. generator in the handling arm cradle and manoeuvre it through the skin aperture, drive-end first.

(3) Rotate the a.c. generator through

90 deg and hoist it into alignment with the drive unit gearbox flange.

(4) Insert the drive and fit the attachment clamp-ring (after first lubricating the clamp-ring and adapter flange with grease XG-278). Ensure that the white lines on the clamp-ring and adapter flange are aligned, and tighten the clamp-ring nut at least three times to a torque loading of 100 lb in.

(5) Dismantle the hoisting equipment.

(6) Connect the a.c. generator cooling duct.

(7) Connect the electrical cables.

(8) Fit the d.c. generator (*para. 16*).

(9) Replace the gearbox tie-rod and the access panel.

TABLE 1

Torque-loading Conoseal couplings

Bolt size (UNF)	Max. torque-loading (lb in)
¼	85
10	35

TABLE 2
Tools and equipment

Ref. No.	Part No.	Item	Purpose
Accessory drive unit			
4GC/5699	-	Hoist, a/c heavy component, 2½ cwt	Removal and installation
4GC/6673	-	Jib No. 4	} Used with hoist
4GC/5743	-	Handle, winch, 9-inch	
4GC/5427	-	Extension tube, 24-inch	
4GC/5700	-	Top sheath (Type No. 1 hook) 2½ cwt	
4GC/5429	-	Hook, cable winch	
26DK/95137	EB2. 88. 4939	Cradle, gearbox	Drive unit handling
26DK/95055	EB2. 88. 3943	Walkway, fuselage rear end	Access to drive unit
A. C. generator			
4GC/5699	-	Hoist, a/c heavy component, 2½ cwt	Removal and installation
4GC/5743	-	Handle, winch, 9-inch	} Used with hoist
4GC/5443	-	Extension tube 36-inch	
4GC/5700	-	Top sheath (Type No. 1 hook) 2½ cwt	
26DK/95209	EB2. 88. 3151	Arm, handling, a. c. generator assembly	
26DK/95296	EB2. 88. 4215	Cradle, a. c. generator assembly	Removal and installation

TABLE 3

Major components - frames 1-25A

Item No.	Component	Type or Part No.	Qty.	A. P. Reference		
				A. P.	Sect.	Chap. App.
<i>Note... Certain item numbers have been omitted to allow for any additional components that may be introduced in the future</i>						
Air blowers, Mk. 2						
1	Canopy de-misting, interspaces	E. E. AEC. 6001. 102	1			
Air driers						
2	Canopy de-misting, interspaces	EB2. 76. 393	2	101B-1001-1A		
3	Radar-head pressurization	(Mk. 1 pre Mod. 2144) EB2. 75. 6293	1			
		(Mk. 1 post Mod. 2144) EB2. 75. 6491	1			
		(Mk. 1A . pre Mod. 2144) EB3. 75. 873	1			
		(Mk. 1A post Mod. 2144) EB3. 75. 1135	1			
Ductstats						
5	Cockpit pressurization, inlet	Teddington FHG/A/35	1	107B-0216-1		
6	Cockpit pressurization, outlet	Teddington FHG/A/35	1			
Filters						
9	Canopy seal inflation	Dunlop ACM 18302	2	4303B	2	7
10	Radar-head pressurization	Hymatic LF 7/4	1	4303C	2	5 2
Flamestat						
12	Anti-icing	(Mk. 1A post Mod. 104) Teddington FHO/A/583	1	1275A	24	6
Ground connections						
14	A.V.S. cooling air	EB2. 75. 4937	1	101B-1001-1A		
15	A.V.S. anti-g and radar-head pressurization (post Mod. 1588)	EB2. 75. 6405	1			
16	Canopy seal inflation	EB2. 75. 2571	1			
17	Cockpit pressurization	Normalair 505560	1	4340	13	1 8
18	Radar head cooling air	Normalair 504300	1	4340	13	2
Heat exchangers						
21	A.V.S. and anti-g system	Marston Excelsior D934/1A	1	4340	8	1 35
22	Pre-cooler	Marston Excelsior D158/10A	1	4340	8	1 34
23	Radar head	Marston Excelsior D603/1A	1	4340	8	
24	Water boiler	Marston Excelsior D695/2A	1	4340	8	4

continued...

RESTRICTED

TABLE 3 Major components - frames 1-25A - continued

Item No.	Component	Type or Part No.	Qty.	A.P. Reference			
				A. P.	Sect.	Chap.	App.
Valves							
<i>Non-return</i>							
27	A.V.S. and anti-g supply	Flight Refuelling B9811155E	3	4511	12		2
28	A.V.S./anti-g/radar head gd. connection	Flight Refuelling B9811155E	1				
29	Canopy de-misting	(Mk. 1) Saunders 706/AA/11B	1	4340	6		3
		(Mk. 1A) Saunders 706/AA/06B	1				
30	Canopy seal inflation	Hymatic NAR 131/002	2	4303C	4		
31	Cockpit pressurization (flap type)	Normalair 504390	1	107B-1021-16			
32	Cockpit pressurization (insert type)	Normalair 513930	1	107B-			
33	Radar head ground pressurization	Flight Refuelling B9811000/C	1	4340	6		
34	Water header-tank inlet (irreversible type)	(pre Mod. 2082) Flight Refuelling B9811240/C	1	106D-1000A-1			
		(post Mod. 2082) Flight Refuelling B9811245/C	1				
35	Windscreen de-misting	Normalair 506420	1	4340	6		4
<i>Pressure reducing</i>							
38	A.V.S. supply	Hymatic PS60/31	1	4303C	4	34	6
39	Canopy de-misting	Hymatic PS48/40	1	4303C	4	21	9
40	Canopy seal inflation	Hymatic PS29/18	1	4303C	4	15	13
41	Cockpit pressurization	(pre Mod. 2358) EB2. 75. 6183	1	101B-1001-1A			
		(post Mod. 2358) EB2. 75. 6503	1				
42	Radar-head pressurization	Hymatic PAS/160/043	1	4303C	4	34	12
<i>Pressure relief</i>							
46	Cockpit pressurization	EB2. 75. 2693	1	101B-1001-1A			
47	Radar-head pressurization	Hymatic RAV 150/005	1	4303C	4	39	2
48	Water header-tank outlet	(pre Mod. 2132) EB2. 75. 2301	1	101B-1001-1A			
		(post Mod. 2132) EB2. 75. 6476	1				
<i>Stop valves</i>							
51	Anti-g	(Mk. 1) Hymatic SV35/1	1	4303C	6		10
		(MK. 1A) Hymatic SV35/1 Mk. 2	1				
52	Anti-icing	(Mk. 1A post Mod. 104)					
	Butterfly valve	Teddington FMP/A/145	1	4303E	2	5	8
	Solenoid valve	Teddington FGB/A/16	1	4303E	2	8	2
	Filter and body	Teddington FGB/SA/462	1				

continued...

TABLE 3 Major components - frames 1-25A - continued

Item No.	Component	Type or Part No.	Qty.	A. P. Reference			
				A. P.	Sect.	Chap.	App.
Valves							
<i>Stop valves - continued</i>							
53	Canopy de-misting	Normalair 505980	1	4340	5	1	4
54	Canopy seal inflation	Hymatic SV 19/2	1	4340C	6	6	4
55	Rain dispersal	(Mk. 1A post Mod. 104)					
	Butterfly valve	Teddington FMP/A/170	1	4303E	2	5	13
	Solenoid valve	Teddington FGB/A/16	1	4303E	2	8	2
	Filter and body	Teddington FGB/SA/462	1				
56	Windscreen de-misting	Normalair 505980	1	4340	5	1	4
Miscellaneous valves							
59	Anti-g	Hymatic AG 9/1 or VAG 109/006	1	4303C	4	38	1
60	A.V.S. flow control	Hymatic FC 2/5	1	4303C	6	9	1
61	Cockpit temperature regulation	(pre Mod. 2359)					
		(post Mod. 2359)					
		Teddington FOZ/A/7	1	4303E	2	14	
		Teddington FOZ/A/5019	1	4303E			
62	Cooling air temperature control	EB2. 75. 1503	1	10 1B-1001-1A			
63	Combined valve unit	Normalair 518030	1	1275A	20	6	6
64	Pressure controller	Normalair 517500	1	1275A	20	32	4
65	Spill valve	EB2. 75. 3871	1				
66	Gun purging	(pre Mod. 4047)					
		(post Mod. 4047)					
		EB2. 75. 6223	1				
		EB2. 75. 7565	1				
67	Emergency air	EB2. 75. 1689	1				
Water system							
68	Drain valve	(pre Mod. 2227)					
		(post Mod. 2227)					
		EB2. 75. 4127	1				
		EB2. 77. 6507	1				
69	Float valve	EB2. 75. 3511	1				
70	Replenishing valve	(Mk. 1)					
		(Mk. 1A)					
		Lockheed AVA 551D or AUX 227	1				
		Lockheed AVA 1485	1				
Miscellaneous components							
75	Canopy seal inflation storage bottle	(post Mod. 123)					
		Hymatic RES 4 Mk. 1	1	4303C	3	5	
76	Cold-air unit	De Havilland RU45/03	1	4340	2	14	
77	Canopy seal inflation pressure gauge	(post Mod. 123)					
		Smiths EU/13/LN/K006	1	1275A	15	24	
78	Anti-icing pressure switch	(Mk. 1A)					
		Teddington FRJ/A/6	1	112G-1107-1			
79	Gun purging pressure switch	Thermal controls TP 5563	1				
80	Water extractor	Godfrey WE 30 Mk. 1A	1	4340	9	2	
81	Water header tank	EB2. 75. 5271	1				
82	Water trap - A.V.S. and anti-g system	EB2. 75. 4211	1				
83	Radar head pressurization bursting disc	EF3. 75. 3639	1				
84	Restrictor nipple - canopy de-misting	EB2. 75. 1661	1				

TABLE 4

Major components - frames 25B-57

Item No.	Component	Type or Part No.	Qty.	A. P. Reference			
				A. P.	Sect.	Chap.	App.
<i>Note... Certain item numbers have been omitted to allow for any additional components that may be introduced in the future</i>							
Air driven accessories							
88	Accessory drive unit	Rotol ADE 326	1	2240A			
Filters							
90	Accessory drive unit cooling	EB2. 55. 435	1	4303C	2	5	1
91	Auxiliary air supply	Hymatic LF/1	1				
Ground connections							
93	Air turbine shut-off valve testing	EB2. 75. 5941	2	101B-1001-1A			
94	Reheat nozzle valves supply	EB2. 75. 4111	1				
Heat exchanger							
96	Auxiliary air supply	Marston Excelsior D555/2A	1	4340	8	1	36
Valves							
<i>Non-return</i>							
98	Accessory drive unit cooling	Flight Refuelling B9807100/7	1	106D-1000A-1			
99	Auxiliary air supply	Saunders 706AA/11B	2	107B-0905-16AD			
<i>Main air supply</i>							
100	No. 1 engine	(Mk. 1) EB2. 75. 1615	1	101B-1001-1A			
		(Mk. 1A) EB2. 75. 255	1				
101	No. 2 engine	(Mk. 1) EB2. 75. 1615	1				
		(Mk. 1A) EB3. 75. 243	1				
102	Reheat nozzle supply	Normalair 512200	1	107B-0905-16AD			
<i>Pressure reducing</i>							
103	Auxiliary air supply	Hymatic PS48/42	1	4303C	4	21	6
<i>Pressure relief</i>							
104	Auxiliary air supply	Hymatic RB28/9 or RV37/23	1	4303C	4	28	2
<i>Stop valves</i>							
106	Accessory drive unit shut-down	(pre Mod. 2216) ATPR 2/1 or 2/2	1	2240A Bk. 15	3	6	
		(post Mod. 2216) Rotol 6. 1301/000	1				
107	Cockpit pressurization	Teddington FMP/A/5027	1	4303E	2	5	12
<i>Miscellaneous valves</i>							
108	Constant-flow	EB2. 75. 4523	1	101B-1001-1A			
109	Cooling air temperature control	EB2. 75. 1503	1				
Miscellaneous components							
110	Water trap	EB2. 55. 607	1				




FIG.14. LOCATION OF MAJOR COMPONENTS - FRAMES 25B-57

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

