

ADMIRALTY
AIR MINISTRY

Appendix 2

ROTAX, TYPE A0200 GROUP *Series A1-50*

LIST OF CONTENTS

	Para.		Para.
Introduction	1	Rear cover assembly... ..	11
Description	2	Functioning	12
Motor and brake	3	Servicing	
Intermediate housing	6	Brushes	14
Ram housing	7	Lubrication	17
Switch and terminal block housing	10	Final check	18

LIST OF ILLUSTRATIONS

	Fig.
Typical actuator, A0200 group	1
Sectional view of typical actuator	2
Typical circuit diagram	3




Fig. 1. Typical actuator, A0200 group

RESTRICTED

ELECTRICAL MANUAL, GENERAL
This is A.L. No. 28 to A.P.4343, Vol. 1

Sect. 17, Chap. 2. List of Appendices: delete "(to be issued later)" after the title of Appendix 2, and write "(A.L. 28)" in the outer margin against the deletion. Insert this Appendix 2 to follow the List of Appendices, and record the incorporation of this A.L. in the Amendment Record Sheet.

RESTRICTED




Fig. 2. Sectional view of typical actuator

Introduction

1. Rotax linear actuators of the A0200 group follow the general design described in this Appendix; a typical actuator, the A0209, is illustrated in fig. 1 and 2, and its circuit diagram is given in fig. 3. Specific details of individual actuators will be found in A.P.4343D, Vol. 1, Sect. 14.

DESCRIPTION

2. In these actuators the motor is parallel to and above the ram.

Motor and brake

3. The 24-volt motor used in these actuators is of 2-pole, split-series field design. External electrical connection to the motor is made through a plug mounted on the outside of the switch and terminal cover, and internal connection via a terminal block mounted on the intermediate housing.

4. The motor is secured to the ram housing, in a position parallel to and above the ram, by a centralizing spigot and two bolts. Access to the brush gear is gained by removing the spring-clipped motor end cover.

5. Mounted at the commutator end of the motor is an electro-magnetic brake, the coil of which is connected in series with the armature of the motor. When energized, the coil attracts a central spring-loaded plunger clear of the brake plate upon which it normally bears, so permitting the brake plate to revolve with the armature. De-energizing of the coil will allow the spring to force the plunger against the brake plate, thus, in effect, locking the armature.

Intermediate housing

6. This housing comprises a plate carrying three gears which, with a pinion at the driving end of the armature shaft, form a four-stage spur gear train, with a reduction ratio of 33:64:1. The housing is located at the end of the ram housing by a number of pins, and is secured by the two motor bolts.

Ram housing

7. The ram housing contains a screw and ram assembly, at the outer end of which is fitted a shackle with self-aligning bearing. In the outer surface of the ram, near its inner end, are two pairs of hemispherical holes. Each pair is in line with a slot that extends along the full length of the housing. Four

steel balls operating in these holes and slots prevent the twisting effect of the screw shaft being imparted to the ram during operation.

8. A projection at the extreme inner end of the ram engages with stop plates on the switch-operating rod when the ram reaches the extended or retracted position. The rod and stop plates are accommodated beneath a cover plate, secured to the underside of the ram housing by 10 rd/hd. screws. No adjustment should be made to the stop plates as they govern the length of travel of the ram and are preset by the manufacturers.

9. A gear is machined on the inner end of the screw shaft, the shaft being supported in the housing base by a ball bearing.

Switch and terminal block housing

10. On the opposite side of the intermediate housing to that on which the gears are mounted is assembled a terminal block and a double-acting cam and toggle-operated switch. The switch and terminal block cover is fixed to the intermediate housing by two bolts and locating pins, and, when assembled, forms a deep recess to accommodate the terminal block and switch.

Rear cover assembly

11. Six long, rd/hd. screws that pass through the rear cover, switch cover, and intermediate housing into the ram housing secure the rear cover, attached to the outside of which is a coupling shackle.

Functioning

12. Assuming that the ram is in the extended position, the EXTEND field of the motor will be open-circuited, but a circuit through the RETRACT field will, when the external selector switch is moved to the appropriate position, be completed. The solenoid of the brake assembly is also energized, and the brake lifted clear of the armature plate, permitting free rotation of the armature, which transmits its drive through the gearbox components to retract the ram.

13. As retraction of the ram commences, the projection on the inner end of the ram moves out of contact with the stop plates on the switch operating rod. The rod is then returned, by action of the spring, to its previous position. Both limit switches are now made. Thus, if the ram is stopped in any position between the extremities of its travel,

RESTRICTED




Fig. 3. Typical circuit diagram

it may consequently be moved either towards the extended or retracted position, as desired, by selecting the appropriate position on the external control switch.

SERVICING

Brushes

14. Servicing of the electric motor is normally restricted to brush inspection. Brushes should be renewed before they are unduly worn; check that the brushes are a free fit in their boxes, and that they are bedded satisfactorily. Check for correct brush spring tension.

15. When inspecting the brushes, spring off the retaining clip which secures the end cover of the motor, and remove the cover to gain access to the brushes.

16. When re-fitting the cover, examine the sealing ring and gasket; if they are frayed or damaged they must be renewed. The cover

must be locked in position with the retaining clip, and all other reasonable precautions be taken to prevent the ingress of moisture.

Lubrication

17. The actuators are lubricated during manufacture, and should need no further attention between the appropriate servicing periods.

Final check

18. Ensure that all external nuts, screws and locking devices are secure. Examine the coupling shackles for security and see that the electrical connections are tight and free from corrosion.

Note . . .

No attempt must be made to interfere with the limit switches. They are set to give the correct ram travel, within pre-determined limits. If the settings are altered they cannot be re-obtained while the actuator is installed in the aircraft.

RESTRICTED



This file was downloaded from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms, and more aircraft documents.

