

CHAPTER 1

ELECTRICAL SERVICING

LIST OF CONTENTS

	PARA.
Introduction	1
Power supply	2

INSTALLATION DETAILS

Fuses	3
Table of fuses	4
Junction boxes	5
Terminal blocks	6
Bulkhead plugs	7

INTERPRETATION OF DIAGRAMS

Location	8
Schematic	9
Routing charts	10
Method of reading	11

SERVICING NOTES

General	12
Table of lamps	13
Ground-flight switch	14
Starter and booster coils (SA)	15
Fire extinguisher (FA)	16
Fuel pressure warning lamp (PA)	17
Undercarriage position indicator (U)	18
Navigation lamps (N)	19
Identification lamps (J)	20
Landing lamp (LL)	21
Fuel contents gauges (S)	22
Cabin pressure warning (PW)	23
Bonding	24
Access to components	25

LIST OF ILLUSTRATIONS

	FIG.
Location diagram	1
Schematic diagram of electrical services	2, 2A
Generator (GA)	3
Starter and boost coils (SA)	3

Fire extinguisher	(FA)	}	4
Oil thermometer	(OA)		
Metering oil pressure	(TA)	}	5
Wing tank jettison	(TJ)		
Navigation lamps	(N)	}	6
Undercarriage position indicator	(U)		
Undercarriage lever lock	(UL)		
Interior lamps	(T)	}	7
Booster pump	(BP)		
Identification lamps	(J)	}	8
Landing lamp	(LL)		
Heated pressure head	(P)	}	9
Cabin pressure warning	(PW)		
Fuel contents gauges	(S)	}	10
Flap position indicator	(F)		
Camera gun	(CG)	}	11
Gun firing	(GF)		
I.F.F. supply and demolition	(Q, QS)	}	12
R.I. compass	(RI)		
T.R.1464 supply	(QG)	}	11
Engine speed indicator	(RA)		
Pyrometer	(PA)	}	12
Fuel pressure warning lamp	(GS)		
Gyro gun sight	(GS)		
Bonding diagram			12

Introduction

1. This section contains diagrams giving the location of the various electrical components and wiring of the various services; notes on the servicing of equipment, and access to components. For detailed information on standard items of equipment, reference should be made to the list of specialist publications at the beginning of this book.

Power supply

2. Power is supplied by a generator, type HX, 24-volt, 1500-watt, mounted on the starboard side behind the firewall, which charges two 12-volt, 40-amp. hr. accumulators connected in series. To prevent interference

R E S T R I C T E D

with the radio equipment a suppressor is included in the circuit. A voltage regulator, type A, maintains a constant voltage irrespective of engine speed or load current. A cut-out, type D2, prevents reverse feed from the accumulator when the generator voltage falls below the accumulator voltage. A warning lamp mounted on the top instrument panel indicates when the generator is not charging the accumulators, either because the generator has failed or the main fuse has broken.

INSTALLATION DETAILS

Fuses

3. The general service fuses are located on J.B.1 and J.B.2. Their numbers, service and rating are shown on the fusebox covers.

Table of fuses

4.	Circuit	Circuit code size	Fuse (amps)	Fuse No.
Generator	GA	5	32
			5	33
			10	34
			60	35
Starter and booster coils	SA	5	31	
Identification lamps	J	10	5
			5	17
Landing lamp	LL	20	28
			10	3
Heated pressure head	P	10	3
I.F.F. supply and demolition	QS-Q	20	18, 25
			10	10
Camera gun	CG	10	10
Gun firing valves	GF	10	14
			25	26
T.R.1464 supply	QG	40	29
			5	6
Interior lamps	T	5	6
				7
Cabin pressure warning	PW		15	15
R.I. compass supply	RI		5	2
Navigation lamps	N	5	4
Fire extinguisher	FA	5	8
				16
Undercarriage indicator	U		5	22
Undercarriage lever lock	UL		5	23
Fuel contents gauges	S	5	20
Fuel pressure warning lamp	PA	5	9

Circuit	Circuit code size	Fuse (amps)	Fuse No.
Flap indicator	F	5 21
Gyro gun-sight	GS	10 24 1
Oil thermometer	OA	5 11
Metering oil pressure	TA	5 19
Wing tank jettison	TJ	5 12
Booster pump	BP	10 13

Junction boxes

5. The junction boxes are prefixed by the letters JB., and are referenced numerically, i.e., JB.1, etc. They are referenced on the routing charts and their positions in the aircraft shown on the location diagram. Multi-pole plugs on the junction boxes are each denoted by a label showing its number preceded by a letter, i.e., C1 on JB.1 and C10 on JB.2. The internal wiring of all junction boxes and conduits between junction boxes is carried out in V.I.R. cable.

Terminal blocks

6. Terminal blocks are provided at convenient points throughout the installation. They are not numbered themselves, and the numbers shown on the routing charts are arbitrary, and used purely to correlate them with the location and other diagrams.

Bulkhead plugs

7. The plugs are double-ended and are used to take wiring through metal panels as at fire-walls and bulkheads.

INTERPRETATION OF DIAGRAMS

Location

8. This diagram shows the position of the electrical components, the lay-out of the instrument panel and the junction boxes. The location diagram will be found of assistance if referred to when reading a routing chart.

Schematic

9. The purpose of this diagram is to give the theoretical representation of a circuit.

R E S T R I C T E D

Routing chart

10. The various electrical circuits are drawn in the form of routing charts, which have vertical columns, each representing either a junction box, a pin reference, or an equipment panel, as indicated at the head of each column. The extreme left-hand column gives the circuit name and code letter. Where one routing chart bears more than one circuit, each circuit is separated by a heavy horizontal line.

Method of reading

11. As an example of the manner in which the routing chart is used, reference should be made to the flap indicator circuit, *fig. 8*. Commencing at fuse No. 21, in junction box JB.1, a quintocel 4 cable, coded F+, is connected to the transmitter. The cable is then taken from the transmitter through cable coded F1, F2, F3, and enters JB.2 by the conduit C10 at X, Y and Z, leaving by the conduit at C5A at T, U and V and passing through bulkhead 2 by conduit C5 at T, U and V to JB.1. The cable continues from JB.1 through conduit C2 at T, U and V to the indicator in the instrument panel. The negative wire is connected from the transmitter to JB.1 through conduit C10 at T.

SERVICING NOTES

General

12. The information given in the following paragraphs covers the procedure for certain inspections, tests and adjustments with respect to the electrical equipment in the aircraft, but does not cover all the operations that may be necessary during the servicing of the various circuits. The servicing of other items of equipment fitted in the aircraft is covered in specialist publications, a list of which is given in the front of this publication.

Table of lamps

13. Lamp	Stores Ref.	Voltage	Wattage
Navigation :			
Port	5C/887	24	20
Starboard....	5C/889	24	20
Tail	5C/498	24	10
Identification			
(downward)	5C/557	24	80
Landing	5C/1515	24	240

Lamp	Stores Ref.	Voltage	Wattage
Floodlamps :			
Right-hand	5C/2278	24	2·8
Left-hand	5C/2278	24	2·8
Compartment	5C/2278	24	2·8
Ultra-violet	5C/1952	2·5	0·75
Fire warning	5C/1069	24	3
Undercarriage			
warning	5C/1069	24	3
Fuel pressure warning	5C/1553	6	0·24
Generator power			
failure warning	5C/1553	6	0·24

Ground/flight switch

14. This switch is situated on the port side aft of the throttle box and enables the services to be tested with external accumulators. The switch must be placed in the FLIGHT position before take-off. The prime function of the Ground/Flight switch is for ground testing and starting from an external supply.

Starter and booster coils (SA)

15. It is important to maintain the solenoid switch-covers in good condition and the terminal lugs spaced adequately to avoid the possibility of a short circuit between the terminals, as this may cause unexpected operation of the starter motor.

Note . . . The aircraft accumulators must not be used for ground tests or ground starting.

Fire extinguishers (FA)

16. A flame switch is mounted on each engine bearer behind the firewall and one on each diaphragm at the trailing edge of rib one. The container should be disconnected during any tests to this circuit. To disconnect the container from the circuit, the 2-pole plug should be pulled from the socket at the bottom of the container.

Fuel pressure warning lamp (PA)

17. The warning lamp is mounted on the top instrument panel, and gives a red light when the engine fuel pressure drops below 1½ lb. per sq. in. The switch unit can be adjusted on a test rig by removing the C-spring and lifting the cover off by the eye, when a small 4 B.A. nut will be revealed. Use a box spanner to slacken the nut and a fine screwdriver to turn the adjusting screw; turning the screw in a CLOCKWISE direction will REDUCE the operating pressure.

Undercarriage position indicator (U)

18. In the event of trouble in this circuit, check the micro switch connections; renew a micro switch if the plungers or contacts have become corroded. The only servicing required for the indicator will be the replacement of the filament lamps. This can be effected by removing the two screws on the bezel of the instrument, and unscrewing the bezel from the body to gain access to the lamps.

Navigation lamps (N)

19. The lamps are mounted on the port and starboard wing tips and are easily accessible through the access panel on the undersurface of the main plane. The tail lamp is withdrawn by releasing the screws securing the lamp to the port tail boom so that the screws securing the lamp housing to the mounting are revealed. Release these screws and withdraw lamp and holder from the mounting.

Identification lamps (J)

20. These are positioned on underside of the rear cone engine fairing. To remove the filament lamps remove the nuts securing the glass holder.

Landing lamp (LL)

21. Adjustments can be carried out by slackening the screws holding the lamp panel to the main plane. For further information on adjustments reference should be made to A.P.1095A, Vol. 1.

Fuel contents gauges (S)

22. When a fuel tank has been changed ensure that the wire secured to the float arm has been removed.

Cabin pressure warning (PW)

23. This warning lamp system is fitted to give visual indication when the cabin pressure is less than $1\frac{1}{2}$ lb. per sq. in. above atmospheric pressure. The Westland valve is mounted in the nose, and the lamp on the right-hand dashboard. This circuit only applies to later aircraft.

Bonding

24. Fig. 12 shows the aircraft bonding. Pipes, metal-braided cables, fuel and oil tanks are bonded together and to the main structure.

When refitting bonding clips, ensure that the surfaces to be bonded are free from oil, rust or grease. Tests from ailerons, elevators, flaps, rudders and control systems to the main airframe need not be made as the hinged joints are considered to be effective links and do not require additional bonding.

Access to components

25. The position of the main components can be ascertained from the location diagram, fig. 1. The table given below gives components to which access is not obvious.

<i>Components</i>	<i>Access</i>
GENERATOR CONTROLS	
Accumulators	From under fuselage through gun access door.
Generator	Port side of engine.
Suppressor	Rear spar of starboard main plane. Put flaps to DOWN position.
External supply socket (test)	On port side of fuselage, under main plane.

ENGINE STARTING

Boost coils	On port and starboard side of engine at top of firewall.
External supply socket (start)	On starboard side of fuselage, under main plane.

UNDERCARRIAGE INDICATOR AND FLAP INDICATOR

Flap transmitter	On rear starboard underside of main plane. Put flaps to DOWN position.
Throttle switch	In cockpit—switch is located at throttle lever in the engine control box.
UP limit switches	Two in the port and starboard wheelwell. Two on the underside of the mudguard in the nose.
Leg lock switches	One each on port and starboard leg knuckle. One on the nose wheel hinge casting.
Warning lamp	On left-hand instrument panel in cockpit.

R E S T R I C T E D

FIRE EXTINGUISHER

- Extinguisher container Rear spar of port main plane. Put flaps to DOWN position.
- Flame switches One on each engine bearer, and one on each diaphragm at the trailing edge of rib one.

FUEL PRESSURE WARNING LAMP

- Resistance unit In the cockpit, on JB.1

LANDING LAMP

- Lamp Lower surface of port wing, outboard of tail boom : access by removal of lamp panel.

- Selector switch In the cockpit, on JB.1

IDENTIFICATION LAMPS

- Lamps, downward Rear cone engine fairing access to lamps by removal of screws on lamp panel.

NAVIGATION LAMPS

- Port and starboard lamps From port and starboard outer plane wing tips through panel under main plane.
- Tail lamp Remove the fairing from port tail boom.

Section 1: Introduction

Section 2: Methodology

Section 3: Results

Section 4: Discussion

Section 5: Conclusion

Section 6: References

Section 7: Appendix A


Section 8: Appendix B

Section 9: Appendix C



Section 10: Appendix D

Section 11: Appendix E


Section 12: Appendix F




JUNCTION BOX 2 (LID REMOVED)




JUNCTION BOX I
VIEW ON TOP PLATE





F FLAP INDICATOR

P HEATED PRESSURE HEAD




SEE FIG. 8

SEE FIG. 6


S FUEL CONTENTS GAUGES

T INTERIOR LAMPS



SEE FIG. 4

FA FIRE EXTINGUISHER




SEE FIG. 3

SEE FIG. 3

GA GENERATOR

SA STARTER & BOOSTER COIL




SEE FIG. 5

SEE FIG. 5

U U/C INDICATOR

UL U/C LEVER LOCK



SEE FIG. 5


SEE FIG. 7

SEE FIG. 7

N NAVIGATION LAMPS

J IDENTIFICATION LAMPS

LL LANDING LAMP



SEE FIG. 10


SEE FIG. 10

SEE FIG. 10

QG TR.1464 SUPPLY

QS L.F.F. SUPPLY & DEMOLITION

R1 COM



SEE FIG. 11


SEE FIG. 7

SEE FIG. 6

PA FUEL PRESSURE WARNING LAMP

PW CABIN PRESS. WARNING

B P BOOSTER P



SEE FIG. 9

SEE FIG. 9

CG CAMERA GUN

GF GUN


FIG 2A

SCHEMATIC



SEE FIG. 4

OIL THERMOMETER




SEE FIG. 11

GS GYRO GUNSIGHT

FIG. 10

COMPASS SUPPLY



COMP






FIG. 9

FIRING VALVES



SEE FIG. 11

PYROMETER




SEE FIG. 10

RA ENGINE SPEED INDICATOR


DIAGRAM OF ELECTRICAL SERVICES.

PANELS

EQUIPMENT



STARTER PANEL





CIRCUITS: GA - SA


FIG. 3

JUNCTION BOXES &

CCT REF.	EQUIPMENT	DASHBOARD	CON. PIN REF.	J. B. 1	CON. PIN REF. 2	CON. PIN REF.	J. B. 2
----------	-----------	-----------	---------------	---------	-----------------	---------------	---------



C NAVIGATION LAMPS Z
 C U/C POSITION INDICATOR
 C I/F VFR LOCK
 C I/F VFR LOCK
 C I/F VFR LOCK






ON BOXES & PANELS

J.B.2

CON
PIN
REF

EQUIPMENT




Handwritten: 91-031/92

WIRING CHART, CIRCUITS: FA - OA - TJ

FIG. 4

RESTRICTED

EQUIPMENT



JUNCTION BOXES & PANEL




FIG. 5

ROUTING CHART. CIRCUIT

RESTRICTED






FIG. 6

ROUTIN




EQUIPMENT



AP1

EQUIPMENT

BREAK AT TAIL
PIPE FAIRING



EE NAV. LAMP
CIRCUIT FIG. 5.

NOTE:-ALL JUNCTION BOX & INTER-JUNCTION BOX CONDUIT
WIRING UNIRUBBER/4, UNLESS OTHERWISE STATED.

JUNCTION BOXES & PANELS


CCT REF	EQUIPMENT	DASHBOARD	JUNCTION BOXES & PANELS					
			CON PIN REF	J.B.1	CON PIN REF 2	CON PIN REF	J.B.2	CON PIN REF
IDENTIFICATION LAMPS								
LANDING LAMP								
HEATED PRESS H ^o								
CABIN PRESS. WARNING	WESTLAND VALVE							

FIG. 7

REF.	EQUIPMENT	DASHBOARD	CON. PIN REF.	J. B. I.	CON. PIN REF.	BLKD. 2	CON. PIN REF.
------	-----------	-----------	---------------	----------	---------------	---------	---------------

S



FUEL CONTENTS GAUGES



INDICATOR (STARBOARD)

NOTE:- ALL JUNCTION BOX & INTER-JUNCTION BOX CONDUIT WIRING UNIRUBBER/4 UNLESS OTHERWISE STATED.


U/4	C2-J	S21	C5-P	C5A-P
U/4	C2-K	S22	C5-Q	C5A-Q
U/4	C2-L	S23	C5-R	C5A-R
			C5-S	C5A-S



CENTRE

INDICATORS

U/4	C2-F	S11	C6-M	
U/4	C2-G	S12	C6-J	
U/4	C2-H	S13	C6-K	
			C6-L	




PORT

U/4	C2-L	S1	C5-L	C5A-L
U/4	C2-D	S2	C5-M	C5A-M
U/4	C2-E	S3	C5-N	C5A-N

F

FLAP POSITION INDICATOR



INDICATOR

U/4	C2-T	F1	C5-T	C5A-T
U/4	C2-U	F2	C5-U	C5A-U
U/4	C2-V	F3	C5-V	C5A-V
			C5-W	C5A-W





FIG. 8

ROUTING CHA

CON.
PIN
REF.

EQUIPMENT



RT. CIRCUITS: S-F

RESTRICTED

FIG. 8


CT.6 CHAP.1

& PANELS

J.B.2

CON.
PIN
REF.

EQUIPMENT



CIRCUITS: CG-GF

FIG. 9

RESTRICTED

JUNCTION BOXES





FIG. 9

ROUTING CHART



REST

AP4099A
JUNCTION



BLK. NO.	CON. PIN REF.	J. B. 2	CON. PIN REF.	EQUIPMENT
2				

NOTE: ALL JUNCTION BOX & INTER-JUNCTION BOX CONDUIT WIRING UNIRUBBER/4, UNLESS OTHERWISE STATED.





CIRCUITS: Q - QS - RI - QG - RA


FIG. 10

CON.
PIN
REF.

EQUIPMENT



CONTROL UNIT, TYPE 'B' MK. 6 LINKS STOWED (CLASS 3)





UNITS: PYROMETER - PA - GS

TESTED


FIG. II

JUNCTION BOXES & PAN







DETAIL OF FIXING AT BULKHEAD N°1



VIEW ON BULKHEAD N°2 LOOKING AFT.



REAR FACE BULKHEAD N°3



BONDING OF CANOPY OPERATING GEAR





FIG. 12

BONDING DIAGRAM

FIG. 12





This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.