Chapter 98

DIMMER SWITCH, FAIREY, TYPE FES 75

LIST OF CONTENTS

				LOI.			3					
				Pa	ıra.						Pa	ara.
Introduction	•••	•••	•••	• • • •	1	Servicin	ıg					11
Description	• • •	• • •	•••	•••	2	Testing						12
Electrical conne	ections	• • •		• • •	7		••••		•••		•••	
Installation			•••	• • •	9	Insulati	on resi	stance i	est	•••	• • •	13
			LIST	г ов	ш	ISTRATI	ONS					
LIST OF ILLUSTRATIONS Fig. Fig.												
Circuit diagram				1	1	T	1	11 6			1	Fig.
		s of sv			2	Internal	assem	ibly of s	switch	•••	•••	3
Plan and elevation views of switch 2 LEADING PARTICULARS												
D:		EEC		(DII)	GIA	KIICUL	CAF	- 0				
Dimme Nomin	r switch al opera	l, FES ting v	15 oltane	•••	•••		•••	Ref.	No. 5C	W/6535 28V d.c.		
Power	dissipate	ed .								o Fig. 1		
Resisto	rs, 3 W	att	2.7							-		
0.	hms 4·7		No. off (1)						Services			
	33		(3)						Z11977 Z11328			
	47		(1)			•••	•••		Z11328			
	68		(1)	•••	•••	•••	•••	•••	.Z11329			
	100 150		(1) (3)		•••	•••	•••		Z11329 Z11330			
Weight	of unit								211330	0·31 <i>lb</i> .		
			7									
Å	پېښې	1	‡	PDIM	, P,		ρ.,	. 0		o c	BRIGH	т
28V+VE	1 0-		OFF VVV	•-\/\	/ /~~ /\	/VV-4-/VV\	√ - √\	^	- √ √√	+W-	7	
		_					J.		^^^	3.4		
									33			
<u> </u>			<u></u> -^ΛΛΛ									
			150	_	_							
ò			 ^-					11 P	•			
•			150					0,	0			
o				Ş				0				
В								AO	\bigcirc B			
Ō							TER	MINAL AR	RANGEMEN	IT		
		NOTE	:- FOR LOAD:	S OF 3	- 6 WATT	. 192 20	7 MUCT	. DE 1188				
LIGHTING			FOR LOAD					BE LINK				
2-24WATTS			FOR LOAD					BE LINK				
İ			FUR LUAD	3 UF 18	C4 WALLS	1 & 2 , 3 &	D M021	DE LINK	EU			

Fig. 1. Circuit diagram

RESTRICTED

Introduction

1. The dimmer switch FES 75 is used to control the intensity of illumination in the cockpit and crew stations of the aircraft.

DESCRIPTION

- 2. A two-gang, 9-position switch is wired as shown in figure 1 to provide step control of lighting intensity on four ranges of loads as determined by the positions of the terminal links.
- 3. When issued for use in aircraft, a switch may be identified by suffix mark numbers and letters, the mark number will indicate the aircraft installation it will be used on, whilst the suffix letter will determine the switch loading as indicated by the arrangement of the links at the terminal block.
- 4. Referring to figure 2, the suffix mark number is determined by the angular position of the datum hole relative to the "off" position. To select a switch for any particular aircraft it may be necessary to alter the suffix mark number and letter; this is achieved by repositioning the front plate to the mark number required and re-arranging the links at the terminal block to suit the required suffix letter.
- 5. To reposition the front plate (fig. 2), remove the finger knob, loosen the centre retaining nut and rotate the front plate so that the locating lug of the wafer switch protrudes through the same number reference hole as the mark number required. The mark number, together with their corresponding degrees of angular difference is as follows:—

Suffix Mark No. Angular difference (deg. C)


1	C
2	45
3	90
4	135

6. The suffix letter determines the arrangement of the links at the terminal block and hence the load adjustment required for any particular aircraft as follows:—

Suffix	Li	Load			
letter	posi	tions	(Watts)		
A	1–2	2-3	2 to 6		
В	2-B		6 to 11		
C	3-B		11 to 18		
D	1-2	3-B	18 to 24		

Electrical connections

7. Referring to figure 3, the resistors, ten in number, are equally spaced radially around a centre spindle which, when rotated by the control knob, connects with the contacts located between each resistor.



TERMINAL BLOCK

Fig. 2. Plan and elevation views of switch

- **8.** The internal electrical connections as shown in figure 3 are as follows:—
 - (1) D = dummy clip
 - (2) S = short clip
 - (3) L = long clip
 - (4) SD = dummy clip via short clip

The connection marked SD should be soldered on dummy clips and not the short clips. The soldered connections of the resistors must be made towards the centre of the switch.

INSTALLATION

- 9. To facilitate the installation of the switch control in various positions, four holes in the facia plate are provided to enable the position of the switch plate to be varied in relation to the control knob to suit different aircraft installations.
- 10. When issued for use in aircraft, a switch may be identified to indicate both its

installation and the fitting of the terminal block links for any particular aircraft, e.g. Mk. No. followed by the suffix number and letter.

SERVICING

11. At the periods prescribed in the relevant Servicing Schedule, the switch should be examined for security of electrical connections, mounting fittings, deterioration of cables and signs of corrosion.

TESTING

12. The switch should be tested for correct operation when controlling its relevant internal lighting circuit.

Insulation resistance test

13. Using a 250 V d.c. insulation resistance tester, Type C, or equivalent, measure the insulation resistance between all live parts and the frame; the reading should be not less than 5 megohms.




Fig. 3. Internal assembly of switch

RESTRICTED