

ARMATURE DROP TESTER



Ref. No. ... 5G/549

Associated publication A.P.4343S, Vol. 1, Sect. 13, Chap. 12

BRIEF DESCRIPTION

The armature drop tester is used to locate faults in armature coils by measuring the voltage drop between adjacent segments of the commutator whilst a current is flowing through an armature winding. The tester is used in conjunction with an external 12-volt battery which is connected to the armature winding through contacts on a V-shaped commutator rest via a switch and one of two rheostats. The latter provide the required adjustment to the supply voltage for motor and generator armatures respectively.

Two insulated prods, mounted on a pivoted spring-loaded lever, and connected to a millivoltmeter, make contact with two adjacent commutator segments when the protruding end of the lever is depressed.

RESTRICTED