

### **NOTE TO READERS**

Pren cable is now obsolete, replacement is to be by the Nyvin equivalent. Where tag ends are used the "twistgrip" type are to be used *not* single grip type which can lead to core fracture.

This file was downloaded  
from the RTFM Library.  
Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

