

RESTRICTED  
 CANBERRA A/C - AP 101B-0400-3D  
 SECTION ONE  
 APPLICABILITY CHART

| REFERENCE NUMBER | PART NUMBER | DESCRIPTION | DENOM OF QTY | COMPONENT<br>SERVICING BAYS |                  |                  |   |   |    | APPLICABILITY |    |     |     |     |     |      |
|------------------|-------------|-------------|--------------|-----------------------------|------------------|------------------|---|---|----|---------------|----|-----|-----|-----|-----|------|
|                  |             |             |              | TO SUPPORT 7AE              | TO SUPPORT 10 AE | TO SUPPORT 14 AE |   |   |    |               |    |     |     |     |     |      |
| 1                | 2           | 3           | 4            | 5                           | 6                | 7                | 8 | 9 | 10 | B2            | T4 | PR7 | PR9 | E15 | T17 | TT18 |
|                  |             |             |              |                             |                  |                  |   |   |    | 11            | 12 | 13  | 14  | 15  | 16  | 17   |

RESTRICTED

AP101B-0400-30

SECTION 1

CHAPTER 1

SCALES OF MECHANICAL, ELECTRICAL AND INSTRUMENT AIRCRAFT SERVICING TRS





RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                  | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|--------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 5CW</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 5907    |   | SWITCH Torque      | Each |   | 1 |   |   |   |    | X  | X  | X  |    | X  |    |    |
| 6165    |   | SWITCH Mag Relay   | Each |   | 1 |   |   |   |    |    |    |    | X  | X  |    |    |
| 6185    |   | SWITCH Mag Relay   | Each | 1 | 1 | 2 |   |   |    |    |    | X  | X  | X  | X  | X  |
| 9064    |   | SOLENOID           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 9065    |   | SOLENOID           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1057583 |   | SWITCH Mag Relay   | Each | 2 | 1 | 3 |   |   |    |    |    | X  | X  |    | X  | X  |
| 1096752 |   | CONTACTOR Relay    | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1984725 |   | CONTACTOR 80 Amp   | Each |   |   | 3 |   |   |    |    |    |    |    |    | X  |    |
| 4400158 |   | RELAY T100B        | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4400250 |   | SWITCH - Tail Trim | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4400251 |   | RELAY              | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 5CW</u> (Contd) |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4402866 |   | SWITCH Time                | Each | 2 | 1 | 2 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4402868 |   | SWITCH Cartridge Selector  | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4405089 |   | SWITCH Magnetic            | Each |   | 1 |   |   |   |    |    |    | X  | X  | X  |    |    |
| 4405478 |   | SWITCH Magnetic            | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  | X  |
| 4405591 |   | SWITCH Magnetic            | Each | 1 | 1 |   |   |   |    |    |    | X  | X  | X  |    | X  |
| 4408100 |   | SWITCH Toggle              | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  | X  |
| 4408105 |   | SWITCH Toggle              | Each | 1 |   | 2 |   |   |    |    | X  |    |    |    |    |    |
| 4664472 |   | SWITCH Push Button U/C     | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 6362390 |   | SWITCH Push                | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 9003770 |   | SWITCH Mag Start           | Each | 2 | 1 |   |   |   |    |    |    | X  | X  | X  |    | X  |
| 9321711 |   | SWITCH Push                | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 9332574 |   | RELAY 2 Pole               | Each |   | 1 | 2 |   |   |    |    |    | X  |    |    | X  |    |
| 9499154 |   | SWITCH Mag Relay           | Each |   | 1 |   |   |   |    | X  |    |    | X  |    |    |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2          | 3                        | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|------------|--------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |            | <u>SECTION 5CY</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4376067 | LEA300B/4  | CIRCUIT Breaker          | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4376109 | LEA400B6/8 | CIRCUIT Breaker          | Each |   | 1 |   |   |   |    | X  | X  | X  | X  | X  |    |    |
| 4376491 | D No 1B    | CIRCUIT Breaker          | Each | 2 | 2 | 2 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4376492 | D 2B       | CIRCUIT Breaker          | Each |   | 1 |   |   |   |    | X  |    | X  | X  | X  |    |    |
| 4375508 |            | CUT-OUT-Type A Mk 2      | Each | 2 | 2 | 3 |   |   |    | X  | X  |    | X  | X  | X  | X  |
|         |            | <u>SECTION 5CZ</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1044017 |            | FLASHER Unit             | Each | 1 | 1 | 1 |   |   |    |    |    | X  | X  |    | X  | X  |
| 4335599 |            | BOX Relay                | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4335643 |            | BOX Relay                | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4335751 |            | AMPLIFIER Unit           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |            | <u>SECTION 5D</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4340987 |            | PANEL Bomb Aimers        | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |
| 4341025 |            | BOMB - Control Unit Mk 2 | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                    | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|----------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 5J</u>    |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1115903 |   | BATTERY - Type K     | Each | 3 | 3 |   |   |   |    |    |    | X  | X  |    |    | X  |
| 6368902 |   | BATTERY              | Each |   | 4 |   |   |   |    |    |    |    | X  |    |    |    |
| 9499955 |   | BATTERY Alkaline     | Each |   | 3 |   |   |   |    |    |    | X  | X  |    |    |    |
|         |   | <u>SECTION 5Q</u>    |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4347724 |   | VOLTMETER 0-35       | Each |   | 1 |   |   |   |    | X  | X  |    | X  | X  |    |    |
| 4348348 |   | VOLTMETER            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4348349 |   | METER Frequency      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4348457 |   | METER Frequency      | Each | 1 |   |   | 1 |   |    |    |    |    |    |    | X  |    |
|         |   | <u>SECTION 5UA</u>   |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4357528 |   | GENERATOR - Type 514 | Each |   | 3 |   |   |   |    |    |    |    | X  |    |    |    |
| 4357530 |   | GENERATOR - Type 519 | Each |   | 2 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4357574 |   | ALTERNATOR - 30 KVA  | Each | 2 |   |   | 3 |   |    |    |    |    |    |    | X  |    |
| 4360453 |   | GENERATOR - E.D.     | Each | 2 | 2 |   | 3 |   |    | X  | X  |    |    |    | X  | X  |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2       | 3                  | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---------|--------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |         | <u>SECTION 5UB</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4935    |         | INVERTER T 100 B   | Each |   | 1 |   |   |   |    | X  |    |    |    |    |    |    |
| 4938    |         | INVERTER T 100 A   | Each | 2 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 1055250 |         | TRANSFORMER TC1    | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 1069622 |         | INVERTER Static    | Each | 1 | 1 |   |   |   |    |    | X  |    |    |    |    |    |
| 1084608 |         | TRANSFORMER        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1959028 |         | INVERTER Ecko E208 | Each |   | 3 | 3 |   |   |    | X  |    | X  | X  |    |    |    |
| 4342258 |         | INVERTER TRC8A     | Each |   | 1 |   |   |   |    | X  |    |    |    |    |    |    |
| 4342262 |         | INVERTER T200      | Each |   | 1 |   |   |   |    | X  | X  | X  |    | X  |    |    |
| 4342693 |         | INVERTER T103A     | Each | 1 | 1 |   |   |   |    |    |    | X  | X  | X  |    | X  |
| 4342748 | RD 6528 | TRANSFORMER        | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4342763 | P 6601  | TRANSFORMER        | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  |    |
| 4342895 |         | INVERTER T201B-5   | Each |   | 2 |   |   |   |    | X  | X  | X  | X  | X  |    |    |
| 4343314 |         | TRANSFORMER        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4357502 |         | INVERTER T112      | Each |   | 2 |   |   |   |    |    |    |    |    | X  |    |    |
| 4357509 |         | INVERTER T117      | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |
| 4357518 |         | INVERTER           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4357520 |         | INVERTER RT 108A   | Each |   | 1 |   |   |   |    |    |    |    |    |    |    | X  |

| 1       | 2 | 3                           | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|-----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 5UC</u>          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1098486 |   | SEQUENCE Unit               | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  | X  |
| 1983716 |   | PANEL Control               | Each | 2 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4375793 |   | FREQUENCY Control Unit      | Each | 2 |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 4379035 |   | REGULATOR Volt T23          | Each | 2 | 2 | 3 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4379038 |   | REGULATOR Volt T30          | Each | 2 | 2 | 2 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4379154 |   | PANEL Control T15           | Each | 1 | 1 |   |   |   |    |    |    | X  | X  | X  |    | X  |
| 4379155 |   | PANEL Control T24           | Each |   | 1 |   |   |   |    |    |    | X  | X  | X  |    |    |
| 4379169 |   | REGULATOR Voltage T1555A    | Each |   | 1 |   |   |   |    | X  | X  | X  |    | X  |    |    |
| 4379190 |   | REGULATOR Elect T2B         | Each |   | 1 |   |   |   |    | X  |    | X  | X  | X  |    |    |
| 4379290 |   | REGULATOR Volt              | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4379340 |   | REGULATOR Volt T114         | Each |   | 2 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4395825 |   | CONTROLLER W/S Temp         | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4396009 |   | CONTROL and Protection Unit | Each | 2 |   | 3 |   |   |    |    |    |    |    |    | X  |    |
| 6369631 |   | PANEL Control T12           | Each | 2 | 2 | 2 |   |   |    |    | X  | X  | X  | X  | X  | X  |
| 6423525 |   | REGULATOR Volt T22B         | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 9723101 |   | PHASE Sequence Unit         | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                        | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|--------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 5UD</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 3310    |   | BLOWER Air T21           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 5738    |   | BLOWER Air T48           | Each |   | 1 |   |   |   |    | X  |    |    | X  |    |    |    |
| 1095866 |   | BLOWER Motor             | Each |   |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 1171846 |   | BLOWER Heater Axial Flow | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4387982 |   | SERVOMOTOR LKQ 604       | Each |   | 1 |   |   |   |    |    | X  |    |    | X  |    |    |
| 4387984 |   | MOTOR Elect KLQ502       | Each |   | 1 |   |   |   |    | X  |    | X  | X  | X  |    |    |
| 4388048 |   | BLOWER Air T710          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |   | <u>SECTION 5UE</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4412535 |   | PUMP Fuel Mk 3           | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4412539 |   | PUMP Fuel                | Each |   | 2 |   |   |   |    |    |    | X  | X  |    |    |    |
| 4412611 |   | PUMP Fuel                | Each | 1 | 2 | 2 |   |   |    |    |    |    |    | X  | X  |    |
| 6206979 |   | PUMP Fuel Mk 4           | Each | 2 | 2 | 3 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
|         |   | <u>SECTION 5V</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 795     |   | FAN 28V                  | Each | 1 | 1 | 1 |   |   |    |    |    |    |    | X  | X  | X  |

| 1       | 2 | 3                 | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|-------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 5W</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4698    |   | ACTUATOR          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 7098    |   | ACTUATOR          | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 8517    |   | ACTUATOR          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1036707 |   | ACTUATOR          | Each |   | 1 | 1 |   |   |    |    |    |    | X  |    |    |    |
| 4489232 |   | ADAPTOR           | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  | X  |
| 4511906 |   | ACTUATOR          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4511908 |   | ACTUATOR T234-1   | Each | 1 | 2 | 2 |   |   |    |    | X  | X  | X  | X  | X  | X  |
| 4511929 |   | ACTUATOR          | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4511979 |   | ACTUATOR          | Each |   |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 4520708 |   | ACTUATOR          | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4520712 |   | ACTUATOR          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4520727 |   | ACTUATOR          | Each | 1 | 1 | 2 |   |   |    |    |    | X  |    |    | X  | X  |
| 4520730 |   | ACTUATOR          | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4520732 |   | ACTUATOR          | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4520733 |   | ACTUATOR          | Each | 1 | 1 | 2 |   |   |    | X  |    |    |    |    | X  | X  |
| 4511895 |   | ACTUATOR          | Each | 2 | 2 |   |   |   |    | X  | X  | X  | X  | X  |    | X  |
| 4511909 |   | ACTUATOR          | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4520728 |   | ACTUATOR          | Each |   | 1 | 1 |   |   |    | X  |    |    |    |    | X  |    |
| 4520729 |   | ACTUATOR          | Each |   | 1 |   |   |   |    |    | X  | X  |    | X  |    |    |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                      | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6A</u>      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 3119    |   | INDICATOR Zero Reader  | Each | 1 | 1 |   |   |   |    |    | X  | X  | X  |    |    | X  |
| 3366    |   | CHANNEL Pitch/Roll     | Each |   | 1 |   |   |   |    |    | X  | X  | X  | X  |    |    |
| 3953    |   | INDICATOR T/S          | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4424    |   | BOX Junction - TB      | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 5957    |   | CONTROL Unit T605      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1037475 |   | INDICATOR - TAT        | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 1037854 |   | ALTIMETER Cabin Mk 21  | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 1042370 |   | ACCELEROMETER Mk 3     | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 1054258 |   | TACHOMETER Eng Speed   | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 1146374 |   | ALTIMETER HE Mk 30A    | Each | 1 | 2 | 2 |   |   |    | X  | X  |    | X  | X  | X  | X  |
| 1178082 |   | TOTAL HEAD Thermometer | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4332846 |   | SWITCH Diff            | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4333178 |   | CLOCK                  | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4333288 |   | INDICATOR              | Each |   | 1 |   |   |   |    |    |    | X  | X  |    |    |    |
| 4337796 |   | HORIZON Gyro           | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4338332 |   | BOX Junction           | Each |   | 1 |   |   |   |    |    |    |    | X  | X  |    |    |
| 4664238 |   | METER Fatigue T13      | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    |    | X  |

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                         | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|---------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6A</u> (Contd) |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4327991 |   | FATIGUE Meter Mk 16B      | Each |   | 1 |   |   |   |    |    |    | X  | X  | X  |    |    |
| 4333074 |   | GAUGE Oil Press           | Each | 1 | 1 | 2 |   |   |    | X  |    | X  |    | X  | X  | X  |
| 4333083 |   | CONNECTOR                 | Each |   | 1 |   |   |   |    |    |    | X  | X  | X  |    |    |
| 4333096 |   | AMPLIFIER - FAA           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4333106 |   | BULB                      | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                                     | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|---------------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6A (Contd)</u>             |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4333174 |   | INDICATOR Post'n Flap                 | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4333214 |   | COMPUTER - Flight                     | Each |   | 1 |   |   |   |    |    | X  |    | X  |    |    |    |
| 4333225 |   | INDICATOR - Position Aileron:<br>Trim | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4333226 |   | INDICATOR - Position Rudder<br>Trim   | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4333280 |   | GENERATOR Mk 8C                       | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4333348 |   | ACCELEROMETER                         | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |
| 4333387 |   | INDICATOR Type A                      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4333473 |   | GAUGE - Fuel Contents                 | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4333474 |   | GAUGE - Fuel Contents                 | Each |   | 1 |   |   |   |    |    |    | X  | X  |    |    |    |
| 4333477 |   | GAUGE - Fuel Contents                 | Each |   | 1 |   |   |   |    |    |    | X  | X  |    |    |    |
| 4333778 |   | PANEL Control                         | Each | 1 | 1 |   |   |   |    |    | X  |    |    |    |    | X  |
| 4337742 |   | INDICATOR Air Speed                   | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4337745 |   | POTENTIOMETER                         | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |

| 1       | 2 | 3                         | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|---------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6A (Contd)</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4337773 |   | GENERATOR Mk 3            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4337780 |   | ACCELEROMETER Mk 2A       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4337782 |   | AMPLIFIER Mk 22           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4337986 |   | AMPLIFIER Mk 1A           | Each | 1 | 1 | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4337996 |   | INDICATOR AT/AB           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4338060 |   | INDICATOR Post'n T/Trim   | Each | 1 |   | 1 |   |   |    | X  |    |    |    |    | X  | X  |
| 4338176 |   | HORIZON Gyro 4A           | Each | 1 | 1 |   |   |   |    |    | X  | X  | X  | X  |    |    |
| 4338244 |   | MACHMETER Mk 2A           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4338246 |   | TRANSMITTER T709          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4338247 |   | COMPUTER T810             | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4338248 |   | INDICATOR - RATE          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4338249 |   | INDICATOR - R + T         | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4338320 |   | GYRO Unit                 | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  |    | X  | X  |    |
| 4338811 |   | VIBRATOR Unit             | Each | 1 |   | 2 |   |   |    |    |    |    | X  |    | X  | X  |
| 4339125 |   | GAUGE Fuel Cont:          | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4339155 |   | INDICATOR Rate of Climb   | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4339168 |   | ALTIMETER Mk 22D          | Each | 1 | 1 | 2 |   |   |    |    |    | X  |    | X  | X  | X  |
| 4339679 |   | FLIGHT Computer B         | Each |   | 1 |   |   |   |    |    |    |    |    |    |    | X  |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2              | 3                               | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|----------------|---------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |                | <u>SECTION 6A (Contd)</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4670625 |                | MACHMETER Mk 2                  | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4676147 |                | GENERATOR Tacho                 | Each | 1 | 1 | 2 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4676148 |                | TACHOMETER Eng Speed            | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4695406 |                | ACCELEROMETER Mk 2              | Each | 1 | 1 |   |   |   |    | X  | X  |    |    | X  |    | X  |
| 6201976 |                | ALTIMETER Encoding Mk 29B       | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 6203321 |                | PRESSURE Error Correctn Unit    | Each | 1 | 1 | 1 |   |   |    | X  | X  |    | X  | X  | X  | X  |
| 6203323 |                | CORRECTION Module               | Each | 1 | 1 | 1 |   |   |    | X  | X  |    | X  | X  | X  | X  |
| 6426683 |                | POWER Unit                      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6426686 |                | REMOTE Pilot Indicator          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6556084 |                | GAUGE Press T.10069             | Each | 2 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 7101865 |                | TRANSMITTER                     | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
|         |                | <u>SECTION 6B</u>               |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| NIV     | SCSHQ125582 AO | JUNCTION Box (RAF)Wyton Pattern | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 408     |                | Panel Control Type A            | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4680    |                | BODY Assy (Mother Board)        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1048857 |                | COMPASS T E2B                   | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4343585 |                | INDICATOR - Air Mileage         | Each | 1 | 1 |   |   |   |    | X  |    | X  |    | X  |    | X  |
| 4343591 |                | REPEATER Unit                   | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4343605 |                | COMPASS T. E2A                  | Each |   | 1 |   |   |   |    |    |    | X  |    |    |    |    |
| 4343636 |                | AIR Mileage Unit                | Each | 1 | 1 |   |   |   |    | X  | X  | X  |    | X  |    | X  |
| 4343640 |                | GYRO Compass - Mk 48            | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4343641 |                | AMPLIFIER Type B                | Each | 1 | 1 |   |   |   |    | X  | X  | X  | X  | X  |    | X  |
| 4343645 |                | AMPLIFIER GP 1                  | Each | 1 | 1 | 2 |   |   |    |    |    | X  | X  |    | X  |    |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6B (Contd)</u>  |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4343814 |   | DETECTOR Unit              | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4351990 |   | REMOTE Correction Unit     | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4352094 |   | INDICATOR - Master Compass | Each | 1 | 1 | 2 |   |   |    |    |    | X  | X  |    | X  | X  |
| 6285831 |   | PEC No 2                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6341552 |   | INDICATOR - Master T "B"   | Each |   | 1 |   |   |   |    | X  | X  | X  |    | X  |    |    |
| 6361962 |   | PANEL Control              | Each | 1 | 1 |   |   |   |    | X  | X  | X  |    | X  |    | X  |
| 6349771 |   | INDICATOR GP Mk 4A         | Each |   | 1 |   |   |   |    | X  |    | X  |    | X  |    |    |
| 6349772 |   | INDICATOR GP Mk 4          | Each | 1 | 1 | 1 |   |   |    | X  |    | X  |    | X  |    |    |
| 6349775 |   | INDICATOR Air Post'n       | Each | 1 | 1 |   |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 6391580 |   | PEC No 1                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6462891 |   | PEC No 10                  | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6462894 |   | PEC No 11                  | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6462895 |   | PEC No 12                  | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6462896 |   | FRONT Panel Assy           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463210 |   | PEC No 3                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463211 |   | PEC No 4                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463215 |   | PEC No 7                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463216 |   | PEC No 8                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463222 |   | PEC No 5                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463223 |   | PEC No 6                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6463224 |   | PEC No 9                   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6498559 |   | POWER Unit                 | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |
|         |   | <u>SECTION 6BC</u>         |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 6506983 |   | MACH Transducer            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |

LDS 305492/1(10)

RESTRICTED

SHEET NO 18

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2           | 3                           | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|-------------|-----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |             | <u>SECTION 6D</u>           |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 2244070 |             | VALVE Reducing              | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 2242918 |             | REGULATOR Oxygen 21B        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1039710 |             | REGULATOR Oxygen 17F        | Each | 1 | 1 | 3 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 2243028 |             | OXYGEN Set - Emerg          | Each | 1 | 1 | 1 |   |   |    | X  |    | X  |    |    | X  | X  |
| 2248252 |             | REGULATOR Oxygen            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |             | <u>SECTION 6G</u>           |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 6508389 | 243606-0100 | ELECTRONIC Reference Unit   | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6508390 | 265902-0100 | CONTROL Unit                | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6481928 | 243606-0206 | GEAR Box                    | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510648 | 243506-0100 | GYRO Reference Unit         | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510649 | 243606-0226 | POWER Supply Board          | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510650 | 243606-0227 | START Up and Static Logic   | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510651 | 243606-0228 | START Memory and BITE       | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510652 | 243606-0229 | AZIMUTH Step Motor Logic    | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510654 | 243606-0232 | PITCH Demod/Servo Amps      | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510655 | 243606-0233 | ROLL Demod/Servo Amps       | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510656 | 243606-0235 | LEVELLING Computation       | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510657 | 243606-0238 | DOPPLER Interface           | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6512923 | 253606-0230 | AZIMUTH VCO and ORTH: Amp   | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6512924 | 243606-0237 | BUFFER Amps/Rev Main Switch | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |

| 1       | 2           | 3                              | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|-------------|--------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |             | <u>SECTION 6G (Contd)</u>      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 6456507 | 243606-0244 | BRACKET                        | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6456508 | 265902-0200 | INDICATING & Setting Mech Assy | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6456509 | 265902-0215 | FRONT Panel Assy               | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6458344 | 243606-0246 | CHASSIS                        | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6474897 | 265902-0400 | ELECTRONICS Module             | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 6510658 | 243606-0234 | HEADING Servo                  | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
|         |             | <u>SECTION 6S</u>              |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4551392 |             | GYRO - Auto Stabiliser         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4551429 |             | PHASE Advance Unit "F"         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4551430 |             | MONITOR Unit "F"               | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4551431 |             | SERVOMETER "E"                 | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4551635 |             | AMPLIFIER Unit "J"             | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6340962 |             | RELAY SLAVE Unit "A"           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                       | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|-------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6TB</u>      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1666    |   | "G" Switch              | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1667    |   | SWITCH Altitude         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4537606 |   | DETECTOR/Amplifier Unit | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545183 |   | AMPLIFIER Unit "A"      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545187 |   | CONTROLLER Pilots "A"   | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545188 |   | HEADING Selector        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545189 |   | INDICATOR R.T. "A"      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545233 |   | COUPLING Unit "B"       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545259 |   | BOX Junction            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545436 |   | SWITCH Unit             | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545440 |   | "G" Switch              | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6519352 |   | ROLL Damper Actuator    | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 6TB (Contd)</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4545257 |   | CUT-OUT Roll Error         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4545426 |   | GYRO Unit                  | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6402609 |   | SERVOMETER Type "B"        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6402613 |   | SERVOMETER Type "D"        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |   | <u>SECTION 7B</u>          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 9632737 |   | SELECTOR RP Cont Unit      | Each |   |   | 1 |   |   |    |    |    |    | X  |    | X  |    |
| 9632739 |   | DISTRIBUTOR - No 2 Mk 1    | Each |   |   | 1 |   |   |    |    |    |    | X  |    | X  |    |
|         |   | <u>SECTION 9</u>           |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4656188 |   | AMPLIFIER T4 Bomb Sight    | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |
|         |   | <u>SECTION 9A</u>          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1097452 |   | WINCH Control Panel        | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1103960 |   | PUMP - Lubricating Oil     | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1145381 |   | PROGRAMME Circuit Assy     | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |



| 1       | 2 | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 9A (Contd)</u>  |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1145383 |   | DISCRIMINATOR Assy DFS     | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1175834 |   | SPRING Unit Assy           | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1937784 |   | INDICATOR - Footage Assy   | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1938350 |   | SOLENOID                   | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1938360 |   | BOX - Resistor Assy        | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1145198 |   | BOX - Spring Assy          | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1981897 |   | JACK Assy (Variable Drive) | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1982139 |   | DRIVE and Gearbox - Fwd    | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1995594 |   | VARIDRIVE Servo Amp        | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1995609 |   | MAGNETIC Sensing Coil      | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 2206220 |   | CG Launcher - Complete     | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 2206975 |   | METER - Footage Indicator  | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 6200896 |   | CABLE Runaway Computer     | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 6200897 |   | CONTROL Box TAV Assy       | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 6200898 |   | DC Regulator Assy          | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
|         |   | <u>SECTION 10F</u>         |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 0119139 |   | SWITCH - Mag Relay         | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 9321487 |   | RELAY Magnetic             | Each |   |   | 2 |   |   |    |    |    |    |    |    | X  |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1         | 2 | 3                              | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|-----------|---|--------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|           |   | <u>SECTION 15A</u>             |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4177500   |   | PARACHUTE Assy Type Back Mk 42 | Each | 2 | 3 | 3 |   |   |    |    |    |    | X  |    |    |    |
| 4177511   |   | PARACHUTE Assy Type Back Mk 45 | Each | 2 | 3 | 3 |   |   |    |    |    |    | X  |    |    |    |
| * 4177654 |   | PARACHUTE Assy Type Seat Mk 18 | Each | 4 | 5 | 5 |   |   |    |    |    | X  |    |    |    |    |
| * 4177654 |   | PARACHUTE Assy Type Seat Mk 18 | Each | 6 | 7 | 8 |   |   |    | X  | X  |    |    | X  | X  | X  |

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                           | 4    | 5 | 6  | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|-----------------------------|------|---|----|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 26FZ</u>         |      |   |    |   |   |   |    |    |    |    |    |    |    |    |
| 5638    |   | VALVE Non Return GRP        | Each | 1 |    | 1 |   |   |    |    |    |    |    |    | X  |    |
| 13311   |   | JACK Camera Door Top Fwd    | Each |   | 1  |   |   |   |    |    |    |    | X  |    |    |    |
| 13312   |   | JACK Camera Door Btm Fwd    | Each |   | 1  |   |   |   |    |    |    |    | X  |    |    |    |
| 30290   |   | SELECTOR U/C Emergency      | Each |   | 1  |   |   |   |    |    |    |    | X  |    |    |    |
| 30306   |   | VALVE Transfer Emergency    | Each |   | 1  |   |   |   |    |    |    |    | X  |    |    |    |
| 30327   |   | VALVE Shutter Emergency     | Each |   | 1  |   |   |   |    |    |    |    | X  |    |    |    |
| 43049   |   | LOGIC Unit BBS              | Each | 1 |    | 1 |   |   |    |    |    |    |    |    | X  |    |
| 1439214 |   | STRUT Elevator - Brake Comp | Each |   | 1  |   |   |   |    |    |    |    | X  |    |    |    |
|         |   | <u>SECTION 27A</u>          |      |   |    |   |   |   |    |    |    |    |    |    |    |    |
| 1450713 |   | MAIN Wheel                  | Each |   | 3  |   |   |   |    |    |    | X  | X  | X  |    |    |
| 4560291 |   | NOSEWHEEL                   | Each | 1 | 2  | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4560430 |   | MAINWHEEL                   | Each | 2 | 2  | 2 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4560809 |   | COVER Outer Mainwheel       | Each |   | 12 |   |   |   |    |    |    | X  | X  | X  |    |    |
| 6478423 |   | COVER Outer Main Wheel      | Each | 2 | 4  | 4 |   |   |    | X  | X  |    |    |    | X  | X  |
| 7166215 |   | COVER-Outer Mainwheel       | Each | 2 | 2  | 4 |   |   |    | X  | X  | X  | X  | X  | X  | X  |

## Section 1

| 1         | 2 | 3                                      | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|-----------|---|----------------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|           |   | <u>SECTION 27C</u>                     |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| * 1508972 |   | PERSON SURVIVAL Pack ZM Mk 1           | Each | 2 | 3 | 3 |   |   |    |    | X  |    |    |    |    |    |
| * 1508972 |   | PERSON SURVIVAL Pack ZM Mk 1           | Each | 4 | 5 | 5 |   |   |    |    |    | X  |    |    |    |    |
| * 1508972 |   | PERSON SURVIVAL Pack ZM Mk 1           | Each | 6 | 7 | 8 |   |   |    | X  |    |    |    | X  | X  | X  |
| 4486163   |   | PERSONAL SURVIVAL Pack Type YA<br>Mk 1 | Each | 4 | 5 | 5 |   |   |    |    | X  |    |    |    |    |    |
| 6250285   |   | PERSONAL SURVIVAL Pack Type ZL<br>Mk 1 | Each | 2 | 3 | 3 |   |   |    |    |    |    | X  |    |    |    |
| 6250288   |   | PERSONAL SURVIVAL Pack Type ZG<br>Mk 1 | Each | 2 | 3 | 3 |   |   |    |    |    |    | X  |    |    |    |
|           |   | <u>SECTION 27F</u>                     |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1456246   |   | RAM Air Turbine                        | Each | 2 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4526771   |   | VALVE Non Return                       | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4526777   |   | VALVE Non Return                       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|           |   | <u>SECTION 27FR</u>                    |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4692555   |   | VALVE Non Return                       | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
|           |   | <u>SECTION 27FS</u>                    |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4524532   |   | FUEL COCK                              | Each | 1 | 1 | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4524596   |   | FUEL COCK                              | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
|           |   | *Note Different Scales for T4 and PR7  |      |   |   |   |   |   |    |    |    |    |    |    |    |    |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                        | 4    | 5 | 6 | 7  | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|--------------------------|------|---|---|----|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 27G</u>       |      |   |   |    |   |   |    |    |    |    |    |    |    |    |
| 7159907 |   | VALVE Brake Control Mk 3 | Each |   | 1 |    |   |   |    |    |    |    | X  |    |    |    |
| 4617714 |   | MAXARET Unit             | Each |   | 2 |    |   |   |    |    |    | X  | X  | X  |    |    |
| 4617715 |   | MAXARET Unit             | Each |   | 2 |    |   |   |    |    |    | X  | X  | X  |    |    |
| 4617745 |   | VALVE Brake Control Mk 3 | Each |   | 1 |    |   |   |    |    |    | X  |    | X  |    |    |
| 4618165 |   | VALVE Brake Control      | Each | 1 | 1 | 1  |   |   |    | X  | X  |    |    |    | X  | X  |
| 4618240 |   | BRAKE Unit (Port)        | Each |   | 4 |    |   |   |    | X  | X  |    |    |    | X  | X  |
| 4618241 |   | BRAKE Unit (Stbd)        | Each | 1 | 2 | 2  |   |   |    | X  | X  |    |    |    | X  | X  |
| 4618243 |   | BRAKE Unit (Port)        | Each |   | 2 |    |   |   |    |    |    | X  | X  | X  |    |    |
| 4618244 |   | BRAKE Unit (Stbd)        | Each |   | 2 |    |   |   |    |    |    | X  | X  | X  |    |    |
| 4618425 |   | PLATE Friction           | Sets |   | 8 |    |   |   |    |    |    | X  | X  | X  |    |    |
| 4618426 |   | PLATE Friction           | Sets | 4 | 8 | 10 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4618483 |   | PLATE Backing and B*Pads | Each |   | 4 |    |   |   |    |    |    | X  | X  | X  |    |    |
| 4618525 |   | PLATE Backing and B*Pads | Each | 2 | 4 | 4  |   |   |    | X  | X  |    |    |    | X  | X  |
| 4618530 |   | PLATE Carrier and B*Pads | Each | 2 | 4 | 4  |   |   |    | X  | X  |    |    |    | X  | X  |
| 4618890 |   | PLATE Carrier Assy       | Each |   | 4 |    |   |   |    |    |    | X  | X  | X  |    |    |
|         |   | <u>SECTION 27J</u>       |      |   |   |    |   |   |    |    |    |    |    |    |    |    |
| 4542842 |   | HANDLE Control Assy      | Each |   | 1 |    |   |   |    |    |    |    |    | X  |    |    |
| 4542959 |   | HANDLE Control Port Assy | Each |   | 1 |    |   |   |    |    |    |    | X  |    |    |    |
| 4542964 |   | HANDLE Control Stbd Assy | Each |   | 1 |    |   |   |    |    |    |    | X  |    |    |    |

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1                  | 2 | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|--------------------|---|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|                    |   | <u>SECTION 27KD</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4631280            |   | CONSTANT Press Controller  | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4631281            |   | MASTER Valve Unit          | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4631292            |   | VALVE United Combined      | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4631299            |   | VALVE Press Control        | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4631306            |   | VALVE Constant Flow        | Each | 1 | 1 | 1 |   |   |    | X  |    | X  |    |    | X  | X  |
| 4631313            |   | VALVE Constant Flow        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4631325            |   | VALVE Non Return           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|                    |   | <u>SECTION 27KF</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1482732            |   | FILTER Assy                | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1482751            |   | FILTER Assy                | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1482932            |   | VALVE Servo Elect Hyd Assy | Each | 2 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4542582            |   | JACK and Valve Group       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|                    |   | <u>SECTION 27KH</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4628412 OR 6146516 |   | PFCU Type 101/3            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4628468            |   | PFCU Type 207/2            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                             | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|-------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 27M</u>            |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1449838 |   | ACCUMULATOR                   | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1449843 |   | JACK Launcher                 | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1449870 |   | VALVE E H Selector            | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1449884 |   | VALVE E H                     | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1449893 |   | VALVE Solenoid Sel/P.R.       | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 1500045 |   | VALVE Press Release           | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4600790 |   | VALVE Cut Out                 | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4600791 |   | VALVE Cut Out                 | Each |   | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  |    |
| 9153489 |   | ACCUMULATOR - Hyd             | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
|         |   | <u>SECTION 27N</u>            |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4526592 |   | FIRE Decting Unit (Resetting) | Each |   | 2 | 4 |   |   |    | X  | X  | X  |    | X  | X  |    |
|         |   | <u>SECTION 27Q</u>            |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1446363 |   | VALVE Non Return              | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 1491292 |   | VALVE Press Relief            | Each | 1 | 1 | 1 |   |   |    |    |    |    | X  |    |    |    |
| 4143142 |   | VALVE Press Relief Res:       | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4143168 |   | RESTRICTOR One Way            | Each |   | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  |    |
| 4143176 |   | VALVE Restrictor              | Each |   | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  |    |
| 4143237 |   | VALVE Restrictor              | Each |   | 1 | 2 |   |   |    |    |    |    | X  |    | X  |    |
| 4143362 |   | FILTER Oil                    | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |

| 1       | 2 | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 27Q (CONTD)</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4140000 |   | VALVE Non Return           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4170000 |   | RESTRICTOR One Way         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |   | <u>SECTION 27QM</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1446725 |   | JACK Airbrake              | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 1490316 |   | NOSE U/C Unit              | Each |   | 1 |   |   |   |    |    | X  | X  | X  | X  |    |    |
| 4113203 |   | VALVE - Transfer           | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  | X  |
| 4143123 |   | VALVE - Press              | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4143161 |   | VALVE - Restrictor         | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143183 |   | VALVE - Sequence           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143189 |   | VALVE - Sequence           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143190 |   | VALVE - Sequence           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143192 |   | VALVE - Sequence           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143196 |   | VALVE - Sequence           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143197 |   | VALVE - Thermal            | Each | 1 | 2 | 3 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143227 |   | VALVE - Transfer           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143258 |   | VALVE - Rotary             | Each |   | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143260 |   | VALVE - Control            | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143267 |   | VALVE - Rotary             | Each |   | 1 | 2 |   |   |    |    |    |    | X  |    | X  |    |
| 4143270 |   | VALVE - Rotary             | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                         | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|---------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | SECTION 27QM (Contd)      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4143276 |   | VALVE - Control           | Each |   | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143279 |   | VALVE - Rotary            | Each |   | 1 | 1 |   |   |    |    |    |    | X  |    | X  |    |
| 4143282 |   | VALVE - Rotary            | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143301 |   | VALVE - Sequence          | Each |   | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  |    |
| 4143314 |   | SELECTOR Group            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143346 |   | SELECTOR - Unit           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143355 |   | ACCUMULATOR Unit          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143333 |   | VALVE Selector            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143442 |   | RESERVOIR - Hyd           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143452 |   | JACK - Bomb Door Front    | Each | 1 | 1 |   |   |   |    | X  | X  | X  | X  | X  |    | X  |
| 4143473 |   | JACK - Bomb Door Rear     | Each | 1 | 1 |   |   |   |    | X  | X  | X  | X  | X  |    | X  |
| 4143500 |   | JACK Camera Door Rear     | Each |   | 1 |   |   |   |    |    |    | X  | X  |    |    |    |
| 4143518 |   | JACK Camera Door Group    | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4143561 |   | JACK Flap Group           | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143591 |   | JACK Nosewheel Door       | Each | 1 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143616 |   | JACK Main U/C Group       | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143637 |   | JACK Nose-wheel           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4143680 |   | JACK Feel unit            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4170002 |   | VALVE NR Press            | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4170015 |   | VALVE - Solenoid Operated | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  | X  |
| 4170079 |   | ACCUMULATOR               | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4204873 |   | JACK Shutter Operating    | Each | 1 |   | 2 |   |   |    |    |    |    |    |    | X  |    |
| 4674311 |   | VALVE Thermal             | Each | 1 | 2 | 2 |   |   |    |    |    |    | X  |    | X  | X  |
| 4618530 |   | VALVE - Control           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |

| 1                 | 2 | 3                        | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|-------------------|---|--------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|                   |   | <u>SECTION 27UA</u>      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4611964           |   | HEAT Exchanger (Sec)     | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4611965           |   | HEAT Exchanger (Air)     | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 4611972           |   | WATER Extractor          | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4612374           |   | VALVE Non Return         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4612829           |   | COLD Air Unit            | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 6341307           |   | COLD Air Unit            | Each |   | 1 |   |   |   |    | X  | X  | X  | X  | X  |    |    |
|                   |   | <u>SECTION 27V</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4604667           |   | VALVE Hot Air 2 inch     | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4604668           |   | VALVE Hot Air Half-Inch  | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4604884           |   | VALVE                    | Each |   |   | 2 |   |   |    |    |    |    |    |    | X  |    |
|                   |   | <u>SECTION 27VA</u>      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4625488           |   | VALVE Press Reducing     | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4625959           |   | CYLINDER - Master - Stbd | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4626068           |   | UNIVALVE Assy            | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6457372           |   | CYLINDER - Master - Port | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|                   |   | <u>SECTION 27VB</u>      |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1456211           |   | VALVE Start              | Each | 1 |   |   |   |   |    |    |    |    |    |    |    | X  |
| 4496849           |   | VALVE Non Return         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| LDS 247984/1(114) |   |                          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2 | 3                           | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|-----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 27VB (Contd)</u> |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4497144 |   | VALVE Press Reducing        | Each |   | 1 |   |   |   |    |    |    |    |    | X  |    |    |
| 4497275 |   | VALVE Reducing              | Each |   |   | 1 |   |   |    |    |    |    |    |    | X  |    |
| 4497298 |   | VALVE Reducing              | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4497380 |   | VALVE Press Reducing        | Each |   |   | 1 |   |   |    |    |    |    |    |    | X  |    |
| 4497443 |   | VALVE Press Relief          | Each |   |   | 1 |   |   |    |    |    |    |    |    | X  |    |
| 4497485 |   | VALVE Press                 | Each |   |   | 1 |   |   |    |    |    |    |    |    | X  |    |
| 4497534 |   | VALVE Relief                | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 6594280 |   | VALVE Reducing              | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |   | <u>SECTION 27W</u>          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4619629 |   | VALVE Non Return            | Each |   | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  |    |
| 4619630 |   | VALVE Non Return            | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4619632 |   | VALVE Non Return            | Each | 1 | 1 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
|         |   | <u>SECTION 27Y</u>          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 6326208 |   | RELAY - Hyd Press Gauge     | Each | 1 | 1 | 1 |   |   |    | X  |    | X  | X  |    | X  | X  |
|         |   | <u>SECTION 27Z</u>          |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4420704 |   | HAND Pump - "Duplex"        | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  | X  | X  | X  | X  |

| 1       | 2  | 3                         | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|----|---------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |    | <u>SECTION 36LL</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 5492    |    | FUEL Pump                 | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 7733    |    | FUEL Pump Lower           | Each | 1 |   | 1 |   |   |    |    |    |    |    |    | X  | X  |
| 6106548 |    | FUEL Pump                 | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 6477256 |    | FUEL Pump Lower           | Each | 1 | 1 |   |   |   |    |    |    |    |    |    | X  |    |
| 6477257 |    | FUEL Pump Upper           | Each | 1 | 1 |   |   |   |    |    |    |    |    |    | X  |    |
|         |    | <u>SECTION 36VV</u>       |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 22946   |    | ACU Metering Block        | Each | 1 | 1 |   |   |   |    |    |    |    |    |    | X  |    |
| 6104782 |    | RAM Operating             | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    | X  | X  |
|         |    | <u>SECTION 37A</u>        |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4387626 |    | HIGH Energy Ignition Unit | Each | 2 | 2 | 2 |   |   |    | X  | X  | X  | X  | X  | X  | X  |
| 4387755 | or |                           |      |   |   |   |   |   |    |    |    |    |    |    |    |    |

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

| 1       | 2           | 3                          | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|-------------|----------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |             | <u>SECTION 37F</u>         |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4380011 | CK 12938    | STARTER IPN                | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 6082313 | 700/1/12170 | CONTROL Unit Mk 8A         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4380018 | 7CZ 75700   | IGNITION Unit Mk 8         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4380026 | CK 11901    | MOTOR Cradle Assy          | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4380036 | CK 18434    | PUMP Blower and Motor Unit | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4380037 | CK 18433    | HP Switch/Solenoid Valve   | Each |   | 2 |   |   |   |    |    |    |    | X  |    |    |    |
| 4381282 | C137362     | TURBO Starter              | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4382141 | GP 11010A   | TURBO Starter              | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    | X  | X  |
| 6119543 | 750/4/01158 | HE/HF Igniter Plug         | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |             | <u>SECTION 37J</u>         |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 1228    |             | VALVE Non Return           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 1622913 |             | PUMP - Hydraulic           | Each | 1 | 1 | 1 |   |   |    | X  | X  | X  |    | X  | X  | X  |
| 4602595 |             | PUMP - Hydraulic           | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
|         |             | <u>SECTION 37L</u>         |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 335     |             | DRIVE Gearbox GD9/80       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 356     |             | DRIVE Gearbox GD9/50       | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 357     |             | DRIVE Gearbox GD9/49       | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 359     |             | DRIVE Gearbox GD9/48       | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    | X  | X  |
| 360     |             | DRIVE Gearbox GD9/47       | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    | X  | X  |
| 19596   |             | MICRO Switch               | Each |   |   | 2 |   |   |    |    |    |    |    |    | X  |    |



| 1       | 2 | 3                            | 4    | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---------|---|------------------------------|------|---|---|---|---|---|----|----|----|----|----|----|----|----|
|         |   | <u>SECTION 37L</u>           |      |   |   |   |   |   |    |    |    |    |    |    |    |    |
| 4521642 |   | GEARBOX Rotol PTG 3/3        | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4521643 |   | GEARBOX Rotol PTG 3/4        | Each | 1 | 1 | 1 |   |   |    | X  | X  |    |    |    | X  | X  |
| 4521647 |   | GEARBOX Rotol PTG 3/25       | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4521648 |   | GEARBOX Rotol PTG 3/26       | Each |   | 1 |   |   |   |    |    |    | X  |    | X  |    |    |
| 4521653 |   | GEARBOX Rotol PTG 3/52       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4521654 |   | GEARBOX Rotol PTG 3/53       | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4521678 |   | GEARBOX Drive GD 9/81        | Each |   | 1 |   |   |   |    |    |    |    | X  |    |    |    |
| 4521692 |   | GEARBOX Self Changing SCG/D9 | Each | 1 | 1 |   |   |   |    |    |    |    |    |    | X  |    |
| 4521706 |   | GEARBOX Turbo                | Each | 2 |   | 2 |   |   |    |    |    |    |    |    | X  |    |

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

**TELEBRIEF  
CONNECTIONS**

**E**