

RESTRICTED

AP101B-0400-3D

SECTION 1

CONTENTS

CHAPTER 1 - Scales of Mechanical, Electrical and Instrument Aircraft Servicing Turn Round Spares.

CHAPTER 2 - Scales of Airborne Radio Installation Turn Round Spares.

CHAPTER 3 - Scales of Air Camera Aircraft Servicing Spares (TRS).

RESTRICTED
 CANBERRA A/C - AP 101B-0400-3D
 SECTION ONE
 APPLICABILITY CHART

REFERENCE NUMBER	PART NUMBER	DESCRIPTION	DENOM OF QTY	COMPONENT SERVICING BAYS						APPLICABILITY						
				TO SUPPORT 7AE	TO SUPPORT 10 AE	TO SUPPORT 14 AE										
1	2	3	4	5	6	7	8	9	10	B2	T4	PR7	PR9	E15	T17	TT18
										11	12	13	14	15	16	17

RESTRICTED

AP101B-0400-30

SECTION 1

CHAPTER 1

SCALES OF MECHANICAL, ELECTRICAL AND INSTRUMENT AIRCRAFT SERVICING TRS

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5CW</u>														
5907		SWITCH Torque	Each		1					X	X	X		X		
6165		SWITCH Mag Relay	Each		1								X	X		
6185		SWITCH Mag Relay	Each	1	1	2						X	X	X	X	X
9064		SOLENOID	Each		1								X			
9065		SOLENOID	Each		1								X			
1057583		SWITCH Mag Relay	Each	2	1	3						X	X		X	X
1096752		CONTACTOR Relay	Each	1												X
1984725		CONTACTOR 80 Amp	Each			3									X	
4400158		RELAY T100B	Each	1	1	2				X	X	X		X	X	X
4400250		SWITCH - Tail Trim	Each	1	1	1				X	X	X		X	X	X
4400251		RELAY	Each		1									X		

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5CW</u> (Contd)														
4402866		SWITCH Time	Each	2	1	2				X	X	X		X	X	X
4402868		SWITCH Cartridge Selector	Each		1							X		X		
4405089		SWITCH Magnetic	Each		1							X	X	X		
4405478		SWITCH Magnetic	Each	1		2									X	X
4405591		SWITCH Magnetic	Each	1	1							X	X	X		X
4408100		SWITCH Toggle	Each	1		2									X	X
4408105		SWITCH Toggle	Each	1		2					X					
4664472		SWITCH Push Button U/C	Each	1	1	2				X	X	X	X	X	X	X
6362390		SWITCH Push	Each		1								X			
9003770		SWITCH Mag Start	Each	2	1							X	X	X		X
9321711		SWITCH Push	Each		1								X			
9332574		RELAY 2 Pole	Each		1	2						X			X	
9499154		SWITCH Mag Relay	Each		1					X			X			

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5CY</u>														
4376067	LEA300B/4	CIRCUIT Breaker	Each		1							X		X		
4376109	LEA400B6/8	CIRCUIT Breaker	Each		1					X	X	X	X	X		
4376491	D No 1B	CIRCUIT Breaker	Each	2	2	2				X	X	X		X	X	X
4376492	D 2B	CIRCUIT Breaker	Each		1					X		X	X	X		
4375508		CUT-OUT-Type A Mk 2	Each	2	2	3				X	X		X	X	X	X
		<u>SECTION 5CZ</u>														
1044017		FLASHER Unit	Each	1	1	1						X	X		X	X
4335599		BOX Relay	Each		1								X			
4335643		BOX Relay	Each		1								X			
4335751		AMPLIFIER Unit	Each		1								X			
		<u>SECTION 5D</u>														
4340987		PANEL Bomb Aimers	Each		1									X		
4341025		BOMB - Control Unit Mk 2	Each		1									X		

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5J</u>														
1115903		BATTERY - Type K	Each	3	3							X	X			X
6368902		BATTERY	Each		4								X			
9499955		BATTERY Alkaline	Each		3							X	X			
		<u>SECTION 5Q</u>														
4347724		VOLTMETER 0-35	Each		1					X	X		X	X		
4348348		VOLTMETER	Each		1								X			
4348349		METER Frequency	Each		1								X			
4348457		METER Frequency	Each	1			1								X	
		<u>SECTION 5UA</u>														
4357528		GENERATOR - Type 514	Each		3								X			
4357530		GENERATOR - Type 519	Each		2							X		X		
4357574		ALTERNATOR - 30 KVA	Each	2			3								X	
4360453		GENERATOR - E.D.	Each	2	2	3				X	X				X	X

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5UB</u>														
4935		INVERTER T 100 B	Each		1					X						
4938		INVERTER T 100 A	Each	2	2	2				X	X	X	X	X	X	X
1055250		TRANSFORMER TC1	Each	1		2									X	
1069622		INVERTER Static	Each	1	1						X					
1084608		TRANSFORMER	Each		1								X			
1959028		INVERTER Ecko E208	Each		3	3				X		X	X			
4342258		INVERTER TRC8A	Each		1					X						
4342262		INVERTER T200	Each		1					X	X	X		X		
4342693		INVERTER T103A	Each	1	1							X	X	X		X
4342748	RD 6528	TRANSFORMER	Each	1		1									X	X
4342763	P 6601	TRANSFORMER	Each	1		1									X	
4342895		INVERTER T201B-5	Each		2					X	X	X	X	X		
4343314		TRANSFORMER	Each		1								X			
4357502		INVERTER T112	Each		2									X		
4357509		INVERTER T117	Each		1									X		
4357518		INVERTER	Each		1								X			
4357520		INVERTER RT 108A	Each		1											X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5UC</u>														
1098486		SEQUENCE Unit	Each	1		2									X	X
1983716		PANEL Control	Each	2												X
4375793		FREQUENCY Control Unit	Each	2		2									X	
4379035		REGULATOR Volt T23	Each	2	2	3				X	X				X	X
4379038		REGULATOR Volt T30	Each	2	2	2				X	X				X	X
4379154		PANEL Control T15	Each	1	1							X	X	X		X
4379155		PANEL Control T24	Each		1							X	X	X		
4379169		REGULATOR Voltage T1555A	Each		1					X	X	X		X		
4379190		REGULATOR Elect T2B	Each		1					X		X	X	X		
4379290		REGULATOR Volt	Each		2								X			
4379340		REGULATOR Volt T114	Each		2							X		X		
4395825		CONTROLLER W/S Temp	Each	1		1									X	X
4396009		CONTROL and Protection Unit	Each	2		3									X	
6369631		PANEL Control T12	Each	2	2	2					X	X	X	X	X	X
6423525		REGULATOR Volt T22B	Each		1							X		X		
9723101		PHASE Sequence Unit	Each	1		2									X	

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5UD</u>														
3310		BLOWER Air T21	Each	1	1	1				X	X	X		X	X	X
5738		BLOWER Air T48	Each		1					X			X			
1095866		BLOWER Motor	Each			2									X	
1171846		BLOWER Heater Axial Flow	Each		2								X			
4387982		SERVOMOTOR LKQ 604	Each		1						X			X		
4387984		MOTOR Elect KLQ502	Each		1					X		X	X	X		
4388048		BLOWER Air T710	Each		1								X			
		<u>SECTION 5UE</u>														
4412535		PUMP Fuel Mk 3	Each		2								X			
4412539		PUMP Fuel	Each		2							X	X			
4412611		PUMP Fuel	Each	1	2	2								X	X	
6206979		PUMP Fuel Mk 4	Each	2	2	3				X	X	X	X	X	X	X
		<u>SECTION 5V</u>														
795		FAN 28V	Each	1	1	1								X	X	X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5W</u>														
4698		ACTUATOR	Each		1								X			
7098		ACTUATOR	Each	1		2									X	
8517		ACTUATOR	Each		1								X			
1036707		ACTUATOR	Each		1	1							X			
4489232		ADAPTOR	Each	1		2									X	X
4511906		ACTUATOR	Each		1								X			
4511908		ACTUATOR T234-1	Each	1	2	2					X	X	X	X	X	X
4511929		ACTUATOR	Each	1	1	2				X	X	X	X	X	X	X
4511979		ACTUATOR	Each			2									X	
4520708		ACTUATOR	Each		2								X			
4520712		ACTUATOR	Each		1								X			
4520727		ACTUATOR	Each	1	1	2						X			X	X
4520730		ACTUATOR	Each	1	1	1				X	X	X		X	X	X
4520732		ACTUATOR	Each		2								X			
4520733		ACTUATOR	Each	1	1	2				X					X	X
4511895		ACTUATOR	Each	2	2					X	X	X	X	X		X
4511909		ACTUATOR	Each	1	1	2				X	X	X	X	X	X	X
4520728		ACTUATOR	Each		1	1				X					X	
4520729		ACTUATOR	Each		1						X	X		X		

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A</u>														
3119		INDICATOR Zero Reader	Each	1	1						X	X	X			X
3366		CHANNEL Pitch/Roll	Each		1						X	X	X	X		
3953		INDICATOR T/S	Each	1	2	2				X	X	X	X	X	X	X
4424		BOX Junction - TB	Each	1												X
5957		CONTROL Unit T605	Each		1								X			
1037475		INDICATOR - TAT	Each	1	1	1				X	X	X		X	X	X
1037854		ALTIMETER Cabin Mk 21	Each	1	1	1				X	X	X	X	X	X	X
1042370		ACCELEROMETER Mk 3	Each	1		2									X	
1054258		TACHOMETER Eng Speed	Each		2								X			
1146374		ALTIMETER HE Mk 30A	Each	1	2	2				X	X		X	X	X	X
1178082		TOTAL HEAD Thermometer	Each		1								X			
4332846		SWITCH Diff	Each	1	2	2				X	X	X	X	X	X	X
4333178		CLOCK	Each	1												X
4333288		INDICATOR	Each		1							X	X			
4337796		HORIZON Gyro	Each	1												X
4338332		BOX Junction	Each		1								X	X		
4664238		METER Fatigue T13	Each	1	1	1				X	X					X

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A</u> (Contd)														
4327991		FATIGUE Meter Mk 16B	Each		1							X	X	X		
4333074		GAUGE Oil Press	Each	1	1	2				X		X		X	X	X
4333083		CONNECTOR	Each		1							X	X	X		
4333096		AMPLIFIER - FAA	Each	1	1	1				X	X	X	X	X	X	X
4333106		BULB	Each	1		2									X	

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A (Contd)</u>														
4333174		INDICATOR Post'n Flap	Each	1												X
4333214		COMPUTER - Flight	Each		1						X		X			
4333225		INDICATOR - Position Aileron: Trim	Each	1		1									X	X
4333226		INDICATOR - Position Rudder Trim	Each	1		1									X	X
4333280		GENERATOR Mk 8C	Each		1							X		X		
4333348		ACCELEROMETER	Each		1									X		
4333387		INDICATOR Type A	Each		1								X			
4333473		GAUGE - Fuel Contents	Each	1												X
4333474		GAUGE - Fuel Contents	Each		1							X	X			
4333477		GAUGE - Fuel Contents	Each		1							X	X			
4333778		PANEL Control	Each	1	1						X					X
4337742		INDICATOR Air Speed	Each	1	2	2				X	X	X	X	X	X	X
4337745		POTENTIOMETER	Each		2								X			

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A (Contd)</u>														
4337773		GENERATOR Mk 3	Each		1								X			
4337780		ACCELEROMETER Mk 2A	Each		1								X			
4337782		AMPLIFIER Mk 22	Each		1								X			
4337986		AMPLIFIER Mk 1A	Each	1	1	1									X	X
4337996		INDICATOR AT/AB	Each		1								X			
4338060		INDICATOR Post'n T/Trim	Each	1		1				X					X	X
4338176		HORIZON Gyro 4A	Each	1	1						X	X	X	X		
4338244		MACHMETER Mk 2A	Each		1								X			
4338246		TRANSMITTER T709	Each		1								X			
4338247		COMPUTER T810	Each		1								X			
4338248		INDICATOR - RATE	Each		1								X			
4338249		INDICATOR - R + T	Each		2								X			
4338320		GYRO Unit	Each	1	1	2				X	X	X		X	X	
4338811		VIBRATOR Unit	Each	1		2							X		X	X
4339125		GAUGE Fuel Cont:	Each	1												X
4339155		INDICATOR Rate of Climb	Each	1	1	2				X	X	X	X	X	X	X
4339168		ALTIMETER Mk 22D	Each	1	1	2						X		X	X	X
4339679		FLIGHT Computer B	Each		1											X

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A (Contd)</u>														
4670625		MACHMETER Mk 2	Each	1	1	2				X	X	X		X	X	X
4676147		GENERATOR Tacho	Each	1	1	2				X	X				X	X
4676148		TACHOMETER Eng Speed	Each	1	1	2				X	X	X		X	X	X
4695406		ACCELEROMETER Mk 2	Each	1	1					X	X			X		X
6201976		ALTIMETER Encoding Mk 29B	Each	1	2	2				X	X	X	X	X	X	X
6203321		PRESSURE Error Correctn Unit	Each	1	1	1				X	X		X	X	X	X
6203323		CORRECTION Module	Each	1	1	1				X	X		X	X	X	X
6426683		POWER Unit	Each		1								X			
6426686		REMOTE Pilot Indicator	Each		1								X			
6556084		GAUGE Press T.10069	Each	2	2	2				X	X	X	X	X	X	X
7101865		TRANSMITTER	Each	1		1									X	X
		<u>SECTION 6B</u>														
NIV	SCSHQ125582 AO	JUNCTION Box (RAF)Wyton Pattern	Each		1								X			
408		Panel Control Type A	Each	1	1	2				X	X	X	X	X	X	X
4680		BODY Assy (Mother Board)	Each		1								X			
1048857		COMPASS T E2B	Each	1	1	1				X	X	X	X	X	X	X
4343585		INDICATOR - Air Mileage	Each	1	1					X		X		X		X
4343591		REPEATER Unit	Each	1												X
4343605		COMPASS T. E2A	Each		1							X				
4343636		AIR Mileage Unit	Each	1	1					X	X	X		X		X
4343640		GYRO Compass - Mk 48	Each	1	1	2				X	X	X	X	X	X	X
4343641		AMPLIFIER Type B	Each	1	1					X	X	X	X	X		X
4343645		AMPLIFIER GP 1	Each	1	1	2						X	X		X	

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6B (Contd)</u>														
4343814		DETECTOR Unit	Each	1	1	1				X	X	X	X	X	X	X
4351990		REMOTE Correction Unit	Each		1								X			
4352094		INDICATOR - Master Compass	Each	1	1	2						X	X		X	X
6285831		PEC No 2	Each		1								X			
6341552		INDICATOR - Master T "B"	Each		1					X	X	X		X		
6361962		PANEL Control	Each	1	1					X	X	X		X		X
6349771		INDICATOR GP Mk 4A	Each		1					X		X		X		
6349772		INDICATOR GP Mk 4	Each	1	1	1				X		X		X		
6349775		INDICATOR Air Post'n	Each	1	1					X	X	X	X	X	X	X
6391580		PEC No 1	Each		1								X			
6462891		PEC No 10	Each		1								X			
6462894		PEC No 11	Each		1								X			
6462895		PEC No 12	Each		1								X			
6462896		FRONT Panel Assy	Each		1								X			
6463210		PEC No 3	Each		1								X			
6463211		PEC No 4	Each		1								X			
6463215		PEC No 7	Each		1								X			
6463216		PEC No 8	Each		1								X			
6463222		PEC No 5	Each		1								X			
6463223		PEC No 6	Each		1								X			
6463224		PEC No 9	Each		1								X			
6498559		POWER Unit	Each		1									X		
		<u>SECTION 6BC</u>														
6506983		MACH Transducer	Each		1								X			

LDS 305492/1(10)

RESTRICTED

SHEET NO 18

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6D</u>														
2244070		VALVE Reducing	Each	1	2	2				X	X	X	X	X	X	X
2242918		REGULATOR Oxygen 21B	Each		1								X			
1039710		REGULATOR Oxygen 17F	Each	1	1	3				X	X	X		X	X	X
2243028		OXYGEN Set - Emerg	Each	1	1	1				X		X			X	X
2248252		REGULATOR Oxygen	Each		1								X			
		<u>SECTION 6G</u>														
6508389	243606-0100	ELECTRONIC Reference Unit	Each		2								X			
6508390	265902-0100	CONTROL Unit	Each		2								X			
6481928	243606-0206	GEAR Box	Each		2								X			
6510648	243506-0100	GYRO Reference Unit	Each		2								X			
6510649	243606-0226	POWER Supply Board	Each		2								X			
6510650	243606-0227	START Up and Static Logic	Each		2								X			
6510651	243606-0228	START Memory and BITE	Each		2								X			
6510652	243606-0229	AZIMUTH Step Motor Logic	Each		2								X			
6510654	243606-0232	PITCH Demod/Servo Amps	Each		2								X			
6510655	243606-0233	ROLL Demod/Servo Amps	Each		2								X			
6510656	243606-0235	LEVELLING Computation	Each		2								X			
6510657	243606-0238	DOPPLER Interface	Each		2								X			
6512923	253606-0230	AZIMUTH VCO and ORTH: Amp	Each		2								X			
6512924	243606-0237	BUFFER Amps/Rev Main Switch	Each		2								X			

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6G (Contd)</u>														
6456507	243606-0244	BRACKET	Each		2								X			
6456508	265902-0200	INDICATING & Setting Mech Assy	Each		2								X			
6456509	265902-0215	FRONT Panel Assy	Each		2								X			
6458344	243606-0246	CHASSIS	Each		2								X			
6474897	265902-0400	ELECTRONICS Module	Each		2								X			
6510658	243606-0234	HEADING Servo	Each		2								X			
		<u>SECTION 6S</u>														
4551392		GYRO - Auto Stabiliser	Each		1								X			
4551429		PHASE Advance Unit "F"	Each		1								X			
4551430		MONITOR Unit "F"	Each		1								X			
4551431		SERVOMETER "E"	Each		1								X			
4551635		AMPLIFIER Unit "J"	Each		1								X			
6340962		RELAY SLAVE Unit "A"	Each		1								X			

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6TB</u>														
1666		"G" Switch	Each		1								X			
1667		SWITCH Altitude	Each		1								X			
4537606		DETECTOR/Amplifier Unit	Each		1								X			
4545183		AMPLIFIER Unit "A"	Each		1								X			
4545187		CONTROLLER Pilots "A"	Each		1								X			
4545188		HEADING Selector	Each		1								X			
4545189		INDICATOR R.T. "A"	Each		1								X			
4545233		COUPLING Unit "B"	Each		1								X			
4545259		BOX Junction	Each		1								X			
4545436		SWITCH Unit	Each		1								X			
4545440		"G" Switch	Each		1								X			
6519352		ROLL Damper Actuator	Each		1								X			



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6TB (Contd)</u>														
4545257		CUT-OUT Roll Error	Each		1								X			
4545426		GYRO Unit	Each		1								X			
6402609		SERVOMETER Type "B"	Each		1								X			
6402613		SERVOMETER Type "D"	Each		1								X			
		<u>SECTION 7B</u>														
9632737		SELECTOR RP Cont Unit	Each			1							X		X	
9632739		DISTRIBUTOR - No 2 Mk 1	Each			1							X		X	
		<u>SECTION 9</u>														
4656188		AMPLIFIER T4 Bomb Sight	Each		1									X		
		<u>SECTION 9A</u>														
1097452		WINCH Control Panel	Each	1												X
1103960		PUMP - Lubricating Oil	Each	1												X
1145381		PROGRAMME Circuit Assy	Each	1												X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 9A (Contd)</u>														
1145383		DISCRIMINATOR Assy DFS	Each	1												X
1175834		SPRING Unit Assy	Each	1												X
1937784		INDICATOR - Footage Assy	Each	1												X
1938350		SOLENOID	Each	1												X
1938360		BOX - Resistor Assy	Each	1												X
1145198		BOX - Spring Assy	Each	1												X
1981897		JACK Assy (Variable Drive)	Each	1												X
1982139		DRIVE and Gearbox - Fwd	Each	1												X
1995594		VARIDRIVE Servo Amp	Each	1												X
1995609		MAGNETIC Sensing Coil	Each	1												X
2206220		CG Launcher - Complete	Each	1												X
2206975		METER - Footage Indicator	Each	1												X
6200896		CABLE Runaway Computer	Each	1												X
6200897		CONTROL Box TAV Assy	Each	1												X
6200898		DC Regulator Assy	Each	1												X
		<u>SECTION 10F</u>														
0119139		SWITCH - Mag Relay	Each	1		2									X	
9321487		RELAY Magnetic	Each			2									X	

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 15A</u>														
4177500		PARACHUTE Assy Type Back Mk 42	Each	2	3	3							X			
4177511		PARACHUTE Assy Type Back Mk 45	Each	2	3	3							X			
* 4177654		PARACHUTE Assy Type Seat Mk 18	Each	4	5	5						X				
* 4177654		PARACHUTE Assy Type Seat Mk 18	Each	6	7	8				X	X			X	X	X

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 26FZ</u>														
5638		VALVE Non Return GRP	Each	1		1									X	
13311		JACK Camera Door Top Fwd	Each		1								X			
13312		JACK Camera Door Btm Fwd	Each		1								X			
30290		SELECTOR U/C Emergency	Each		1								X			
30306		VALVE Transfer Emergency	Each		1								X			
30327		VALVE Shutter Emergency	Each		1								X			
43049		LOGIC Unit BBS	Each	1		1									X	
1439214		STRUT Elevator - Brake Comp	Each		1								X			
		<u>SECTION 27A</u>														
1450713		MAIN Wheel	Each		3							X	X	X		
4560291		NOSEWHEEL	Each	1	2	2				X	X	X	X	X	X	X
4560430		MAINWHEEL	Each	2	2	2				X	X				X	X
4560809		COVER Outer Mainwheel	Each		12							X	X	X		
6478423		COVER Outer Main Wheel	Each	2	4	4				X	X				X	X
7166215		COVER-Outer Mainwheel	Each	2	2	4				X	X	X	X	X	X	X

Section 1

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27C</u>														
* 1508972		PERSON SURVIVAL Pack ZM Mk 1	Each	2	3	3					X					
* 1508972		PERSON SURVIVAL Pack ZM Mk 1	Each	4	5	5						X				
* 1508972		PERSON SURVIVAL Pack ZM Mk 1	Each	6	7	8				X				X	X	X
4486163		PERSONAL SURVIVAL Pack Type YA Mk 1	Each	4	5	5					X					
6250285		PERSONAL SURVIVAL Pack Type ZL Mk 1	Each	2	3	3							X			
6250288		PERSONAL SURVIVAL Pack Type ZG Mk 1	Each	2	3	3							X			
		<u>SECTION 27F</u>														
1456246		RAM Air Turbine	Each	2												X
4526771		VALVE Non Return	Each	1	1	2				X	X	X	X	X	X	X
4526777		VALVE Non Return	Each		1								X			
		<u>SECTION 27FR</u>														
4692555		VALVE Non Return	Each	1		1									X	X
		<u>SECTION 27FS</u>														
4524532		FUEL COCK	Each	1	1	1									X	X
4524596		FUEL COCK	Each	1												X
		*Note Different Scales for T4 and PR7														



RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27G</u>														
7159907		VALVE Brake Control Mk 3	Each		1								X			
4617714		MAXARET Unit	Each		2							X	X	X		
4617715		MAXARET Unit	Each		2							X	X	X		
4617745		VALVE Brake Control Mk 3	Each		1							X		X		
4618165		VALVE Brake Control	Each	1	1	1				X	X				X	X
4618240		BRAKE Unit (Port)	Each		4					X	X				X	X
4618241		BRAKE Unit (Stbd)	Each	1	2	2				X	X				X	X
4618243		BRAKE Unit (Port)	Each		2							X	X	X		
4618244		BRAKE Unit (Stbd)	Each		2							X	X	X		
4618425		PLATE Friction	Sets		8							X	X	X		
4618426		PLATE Friction	Sets	4	8	10				X	X				X	X
4618483		PLATE Backing and B*Pads	Each		4							X	X	X		
4618525		PLATE Backing and B*Pads	Each	2	4	4				X	X				X	X
4618530		PLATE Carrier and B*Pads	Each	2	4	4				X	X				X	X
4618890		PLATE Carrier Assy	Each		4							X	X	X		
		<u>SECTION 27J</u>														
4542842		HANDLE Control Assy	Each		1									X		
4542959		HANDLE Control Port Assy	Each		1								X			
4542964		HANDLE Control Stbd Assy	Each		1								X			

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27KD</u>														
4631280		CONSTANT Press Controller	Each		1								X			
4631281		MASTER Valve Unit	Each	1	1	1				X	X	X		X	X	X
4631292		VALVE United Combined	Each		1								X			
4631299		VALVE Press Control	Each	1	1	1				X	X	X	X	X	X	X
4631306		VALVE Constant Flow	Each	1	1	1				X		X			X	X
4631313		VALVE Constant Flow	Each		1								X			
4631325		VALVE Non Return	Each		1								X			
		<u>SECTION 27KF</u>														
1482732		FILTER Assy	Each	1												X
1482751		FILTER Assy	Each	1												X
1482932		VALVE Servo Elect Hyd Assy	Each	2												X
4542582		JACK and Valve Group	Each		1								X			
		<u>SECTION 27KH</u>														
4628412 OR 6146516		PFCU Type 101/3	Each		1								X			
4628468		PFCU Type 207/2	Each		1								X			

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27M</u>														
1449838		ACCUMULATOR	Each	1												X
1449843		JACK Launcher	Each	1												X
1449870		VALVE E H Selector	Each	1												X
1449884		VALVE E H	Each	1												X
1449893		VALVE Solenoid Sel/P.R.	Each	1												X
1500045		VALVE Press Release	Each	1												X
4600790		VALVE Cut Out	Each	1	1	1				X	X	X		X	X	X
4600791		VALVE Cut Out	Each		1	1				X	X	X		X	X	
9153489		ACCUMULATOR - Hyd	Each	1	1	1				X	X	X		X	X	X
		<u>SECTION 27N</u>														
4526592		FIRE Decting Unit (Resetting)	Each		2	4				X	X	X		X	X	
		<u>SECTION 27Q</u>														
1446363		VALVE Non Return	Each		1								X			
1491292		VALVE Press Relief	Each	1	1	1							X			
4143142		VALVE Press Relief Res:	Each	1	1	1				X	X	X		X	X	X
4143168		RESTRICTOR One Way	Each		1	2				X	X	X	X	X	X	
4143176		VALVE Restrictor	Each		1	1				X	X	X	X	X	X	
4143237		VALVE Restrictor	Each		1	2							X		X	
4143362		FILTER Oil	Each	1		1									X	X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27Q (CONTD)</u>														
4140000		VALVE Non Return	Each	1	1	1				X	X	X	X	X	X	X
4170000		RESTRICTOR One Way	Each		1								X			
		<u>SECTION 27QM</u>														
1446725		JACK Airbrake	Each	1	2	2				X	X	X	X	X	X	X
1490316		NOSE U/C Unit	Each		1						X	X	X	X		
4113203		VALVE - Transfer	Each	1		2									X	X
4143123		VALVE - Press	Each	1	1	1				X	X	X		X	X	X
4143161		VALVE - Restrictor	Each	1	1	2				X	X	X	X	X	X	X
4143183		VALVE - Sequence	Each	1	1	1				X	X	X	X	X	X	X
4143189		VALVE - Sequence	Each	1	1	1				X	X	X	X	X	X	X
4143190		VALVE - Sequence	Each	1	1	1				X	X	X	X	X	X	X
4143192		VALVE - Sequence	Each	1	1	1				X	X	X	X	X	X	X
4143196		VALVE - Sequence	Each	1	1	1				X	X	X	X	X	X	X
4143197		VALVE - Thermal	Each	1	2	3				X	X	X	X	X	X	X
4143227		VALVE - Transfer	Each		1								X			
4143258		VALVE - Rotary	Each		1	1				X	X	X	X	X	X	X
4143260		VALVE - Control	Each	1	1	1				X	X	X	X	X	X	X
4143267		VALVE - Rotary	Each		1	2							X		X	
4143270		VALVE - Rotary	Each	1	1	1				X	X	X	X	X	X	X

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		SECTION 27QM (Contd)														
4143276		VALVE - Control	Each		1	1				X	X	X	X	X	X	X
4143279		VALVE - Rotary	Each		1	1							X		X	
4143282		VALVE - Rotary	Each	1	1	1				X	X	X	X	X	X	X
4143301		VALVE - Sequence	Each		1	1				X	X	X	X	X	X	
4143314		SELECTOR Group	Each		1								X			
4143346		SELECTOR - Unit	Each		1								X			
4143355		ACCUMULATOR Unit	Each		1								X			
4143333		VALVE Selector	Each		1								X			
4143442		RESERVOIR - Hyd	Each		1								X			
4143452		JACK - Bomb Door Front	Each	1	1					X	X	X	X	X		X
4143473		JACK - Bomb Door Rear	Each	1	1					X	X	X	X	X		X
4143500		JACK Camera Door Rear	Each		1							X	X			
4143518		JACK Camera Door Group	Each		1								X			
4143561		JACK Flap Group	Each	1	1	2				X	X	X	X	X	X	X
4143591		JACK Nosewheel Door	Each	1	2	2				X	X	X	X	X	X	X
4143616		JACK Main U/C Group	Each	1	1	1				X	X	X	X	X	X	X
4143637		JACK Nose-wheel	Each	1	1	1				X	X	X	X	X	X	X
4143680		JACK Feel unit	Each		1								X			
4170002		VALVE NR Press	Each	1	1	1				X	X	X	X	X	X	X
4170015		VALVE - Solenoid Operated	Each	1		2									X	X
4170079		ACCUMULATOR	Each		1								X			
4204873		JACK Shutter Operating	Each	1		2									X	
4674311		VALVE Thermal	Each	1	2	2							X		X	X
4618530		VALVE - Control	Each	1	1	1				X	X	X	X	X	X	X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27UA</u>														
4611964		HEAT Exchanger (Sec)	Each	1		1									X	X
4611965		HEAT Exchanger (Air)	Each	1		1									X	X
4611972		WATER Extractor	Each	1	1	1				X	X	X		X	X	X
4612374		VALVE Non Return	Each		1								X			
4612829		COLD Air Unit	Each	1		1									X	X
6341307		COLD Air Unit	Each		1					X	X	X	X	X		
		<u>SECTION 27V</u>														
4604667		VALVE Hot Air 2 inch	Each	1	1	1				X	X	X		X	X	X
4604668		VALVE Hot Air Half-Inch	Each	1	1	1				X	X	X		X	X	X
4604884		VALVE	Each			2									X	
		<u>SECTION 27VA</u>														
4625488		VALVE Press Reducing	Each		1								X			
4625959		CYLINDER - Master - Stbd	Each		1								X			
4626068		UNIVALVE Assy	Each		1								X			
6457372		CYLINDER - Master - Port	Each		1								X			
		<u>SECTION 27VB</u>														
1456211		VALVE Start	Each	1												X
4496849		VALVE Non Return	Each		1								X			
LDS 247984/1(114)																

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27VB (Contd)</u>														
4497144		VALVE Press Reducing	Each		1									X		
4497275		VALVE Reducing	Each			1									X	
4497298		VALVE Reducing	Each		1								X			
4497380		VALVE Press Reducing	Each			1									X	
4497443		VALVE Press Relief	Each			1									X	
4497485		VALVE Press	Each			1									X	
4497534		VALVE Relief	Each	1		1									X	X
6594280		VALVE Reducing	Each		1								X			
		<u>SECTION 27W</u>														
4619629		VALVE Non Return	Each		1	1				X	X	X	X	X	X	
4619630		VALVE Non Return	Each	1	1	1				X	X	X	X	X	X	X
4619632		VALVE Non Return	Each	1	1	2				X	X	X	X	X	X	X
		<u>SECTION 27Y</u>														
6326208		RELAY - Hyd Press Gauge	Each	1	1	1				X		X	X		X	X
		<u>SECTION 27Z</u>														
4420704		HAND Pump - "Duplex"	Each	1	1	1				X	X	X	X	X	X	X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 36LL</u>														
5492		FUEL Pump	Each		1								X			
7733		FUEL Pump Lower	Each	1		1									X	X
6106548		FUEL Pump	Each		1							X		X		
6477256		FUEL Pump Lower	Each	1	1										X	
6477257		FUEL Pump Upper	Each	1	1										X	
		<u>SECTION 36VV</u>														
22946		ACU Metering Block	Each	1	1										X	
6104782		RAM Operating	Each	1	1	1				X	X				X	X
		<u>SECTION 37A</u>														
4387626		HIGH Energy Ignition Unit	Each	2	2	2				X	X	X	X	X	X	X
4387755	or															

RESTRICTED

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 37F</u>														
4380011	CK 12938	STARTER IPN	Each		1								X			
6082313	700/1/12170	CONTROL Unit Mk 8A	Each		1								X			
4380018	7CZ 75700	IGNITION Unit Mk 8	Each		1								X			
4380026	CK 11901	MOTOR Cradle Assy	Each		1								X			
4380036	CK 18434	PUMP Blower and Motor Unit	Each		2								X			
4380037	CK 18433	HP Switch/Solenoid Valve	Each		2								X			
4381282	C137362	TURBO Starter	Each		1							X		X		
4382141	GP 11010A	TURBO Starter	Each	1	1	1				X	X				X	X
6119543	750/4/01158	HE/HF Igniter Plug	Each		1								X			
		<u>SECTION 37J</u>														
1228		VALVE Non Return	Each	1	1	1				X	X	X		X	X	X
1622913		PUMP - Hydraulic	Each	1	1	1				X	X	X		X	X	X
4602595		PUMP - Hydraulic	Each		1								X			
		<u>SECTION 37L</u>														
335		DRIVE Gearbox GD9/80	Each		1								X			
356		DRIVE Gearbox GD9/50	Each		1							X		X		
357		DRIVE Gearbox GD9/49	Each		1							X		X		
359		DRIVE Gearbox GD9/48	Each	1	1	1				X	X				X	X
360		DRIVE Gearbox GD9/47	Each	1	1	1				X	X				X	X
19596		MICRO Switch	Each			2									X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 37L</u>														
4521642		GEARBOX Rotol PTG 3/3	Each	1	1	1				X	X				X	X
4521643		GEARBOX Rotol PTG 3/4	Each	1	1	1				X	X				X	X
4521647		GEARBOX Rotol PTG 3/25	Each		1							X		X		
4521648		GEARBOX Rotol PTG 3/26	Each		1							X		X		
4521653		GEARBOX Rotol PTG 3/52	Each		1								X			
4521654		GEARBOX Rotol PTG 3/53	Each		1								X			
4521678		GEARBOX Drive GD 9/81	Each		1								X			
4521692		GEARBOX Self Changing SCG/D9	Each	1	1										X	
4521706		GEARBOX Turbo	Each	2		2									X	

RESTRICTED

AP101B-0400-3D

SECTION 1

CHAPTER 2

SCALES OF AIRBORNE RADIO INSTALLATION TRS

RESTRICTED
CANBERRA A/C
APPLICABILITY CHART

SECTION REFERENCE	PART NUMBER	DESCRIPTION	D OF Q	22AE	25AE	14AE	RAF WYTON				Applicability					
											B2	T4	PR7	PR9	E15	T17
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

RESTRICTED

AP 101B-0400-30

SECTION 1

CHAPTER 2

SEE SHEET NO 4 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
	<u>ARI 18011 MILITARY ILS</u>															
10D 17815	154-LRU-71	JUNCTION Box	Each		1					X	X	X	X	X		
10D 6352825	3-LRU-86FF	RECEIVER R1965	Each		2					X	X	X	X	X		
10D 6352827	3-LRU-86EE	RECEIVER R1964	Each		3					X	X	X	X	X		
10L 4704227	1-LRU-82E	CONTROL Unit	Each		1					X	X	X	X	X		
10Q 4049193	RC7003-46A	INDICATOR	Each		2					X	X	X	X	X		
	<u>ARI 23057 UHF ST/BY</u>															
10D 6523788		TRANSCEIVER	Each			2							X			
10P 9700362	C17/01	FILTER Radio	Each			1							X			
	<u>ARI 23090 - COLLINS 618</u>															
10B/2222687	Z5017	AERIAL MAST	Each			1				X	X	X	X	X	X	X
	<u>ARI 23117/23118 - AD160/260 VHF/ILS/VOR</u>															
10AD 6392409	D1530G001784	INTERCONNECTION BOX	Each	1	1	1				X					X	X
10B 9570378	140-LRU-99A/1	ANTENNA	Each	1	1	1				X					X	X
10D 6384405	W104058EDB	RX GILDESLOPE 6404ME	Each	1	2	1				X					X	X
10D 9702193	W104057	RX MARKER 6403M	Each	1	2	1				X					X	X
10D 9702194	W104056	NAV ANALYSER	Each	1	2	2				X					X	X
10D 9704801	W1040504	TRANSMITTER 6400MA	Each	2	2	2				X					X	X
10D 9704803	W104055	RX (VHF) 640 1M	Each	1	2	2				X					X	X
10L 9702196	A30-2534-01	CONTROLLER 7430M	Each	1	1	1				X					X	X
10Q 1054264	PW21/RNA/CP1	INDICATOR	Each	1	1	1				X					X	X
10Q 9514214	RL 7003-184B	INDICATOR	Each	1	1	1				X					X	X
	<u>ARI 23134 IFF/SSR</u>															
10AE/1071521	66009	SWITCH UNIT AERIAL	Each			1				X	X	X	X	X	X	X
10D/9563378	D/GA 81441	TRANSPONDER 1520	Each			4				X	X	X	X	X	X	X
10L/9563379	D/GA 81450	CONTROL Unit 1503	Each			2				X	X	X	X	X	X	X

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
110F/0688089	<u>ARI 23165-X BAND JAMMER</u> R30-90-8450	SWITCH	Each	1		2				X	X			X	X	
	<u>ARI 23172-RAD ALT 7B</u>															
10AF/4277232	RL7003-92B	INDICATOR HEIGHT	Each				1						X		X	
10AJ/1037400	395-LRU-115C	MOUNTING	Each				1						X		X	
10AJ/1037401	1133900/1	MOUNTING	Each				1						X		X	
10B/1042252	48-LRU-3A	HORN	Each				1						X		X	
10B/1046007	112-LRU-169A	DUPLEXOR	Each				1						X		X	
10D/4277188	154-LRU-127C	JUNCTION BOX	Each				1						X		X	
10D/4277189	154-LRU-129C	JUNCTION BOX	Each				2						X		X	
10D/6460986	30-LRU-17D	TX/RX RADAR	Each				1						X		X	
10L/1037449	1-LRU-262B	CONTROL UNIT	Each				1						X		X	
10Q/1941563	WTB-134654	IND LIGHT ASSY	Each				1						X		X	
10U/9542618	416-LRU-10D	COMPUTER	Each				1						X		X	
	<u>ARI 23219 RAD ALT AN/PN 171</u>															
110AJ 5841-00-0639358	1987638-1	MOUNTING TRAY	Each			1						X				
110D 5841-00-0508338	HG 905001	TX/RX RADAR	Each			2						X				
110Q 5841-00-9331802	JG 206D1	INDICATOR	Each			1						X				
	<u>ARI 23288 AD 120 VHF(AM)</u>															
10D 5821-99-6395428	AA1201-2	TX/RX	Each			3						X				
10L 5821-99-6392496	AA1202-2	CONTROL UNIT	Each			1						X				

RESTRICTED

AP 101B-0400-3C/3D

SECTION 1

CHAPTER 3

AIR CAMERAS

PR7 CANBERRA TURN ROUND SPARES AIR CAMERAS (SHEET NO 40)
PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS (SHEET NO 44)

RESTRICTED

PR7 CANBERRA A/C
APPLICABILITY CHART

SECTION ONE
AP 101B-0400-3D
CHAPTER THREE

SECTION REFERENCE	PART NUMBER	DESCRIPTION		12 AE												
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

RESTRICTED

AP 101B-0400-3D

SECTION 1 CHAPTER 3

SEE SHEET NO 40 FOR COLUMN HEADINGS

PR7 CANBERRA TURN ROUND SPARES AIR CAMERAS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
<u>F95 MK 2</u> <u>SECTION 14A</u>																
4291203		Camera F95 Mk 2		3												
1013846		Magazine Mk 2/Mk 2A		2												
1013847		Indicator Assy		2												
1013929		Indicator		2												
1017031		Motor		1												
1093652		Lens 12"		2												
1930339		Cable Assy		1												
1931472,		Lens 4"		2												
4290336		Control		1												
<u>F49 MK 2</u>																
1062922		Gear Assy		1												
1142222		Switch		1												
1142348		Box Drive Assy		1												
1985642		Magazine 250 ft		2												
4290884		Adaptor		1												
6177504		Camera F49 Mk 2		3												

PR7 CAMERA TURN ROUND SPARES AIR CAMERAS

LDS 303297/1(9)

RESTRICTED

AL 30

SHEET NO 41

PR7 CANBERRA TURN ROUND SPARES AIR CAMERAS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
SECTION 14A (Contd)																
<u>F49 MK 3</u>																
6177507		Camera F49 Mk 3		3												
<u>CAMERA F52 MK 3</u>																
1099047		Camera F52 36" Assy		3												
4290096		Camera F52 20" Assy		1												
4695801		Lens and Cone Unit 36" F6.3		4												
1099048		Gearbox		2												
4290127		Motor		2												
4290950		Cover		1												
4693878		Lens		1												
4695813		Lens 48"		1												
4290202		Mounting		1												
4290203		Adaptor		1												

PR7 CAMERA TURN ROUND SPARES AIR CAMERAS

LDS 303297/1(10) 10256 244 12/83 T9500

RESTRICTED

AP 101B-0400-3D
SECTION 1 CHAPTER 3

PR7 CANBERRA TURN ROUND SPARES AIR CAMERAS

SEE SHEET NO 40 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

PR7 CANBERRA TURN ROUND SPARES AIR CAMERAS
LDS 247984/1(125)

RESTRICTED

AL 28

SHEET NO 43



RESTRICTED

AP 101B-0400-30

SECTION 1

CHAPTER 3

PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS

APPLICABILITY CHART

SECTION REFERENCE	PART NUMBER	DESCRIPTION		10 AE												
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

RESTRICTED

AP 101B-0400-3D

SECTION 1 CHAPTER 3

SEE SHEET NO 45 FOR COLUMN HEADINGS

PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
<u>CAMERA F95 MK 2</u>																
<u>SECTION 14A</u>																
4291203		Camera		4												
1013846		Magazine Mk 2/2A		4												
1013847		Indicator Assy		2												
1013929		Indicator		1												
1015865		Motor Gear		1												
1017031		Motor		1												
1930339		Cable Assy		1												
1931472		Lens Unit 4"		2												
1992163		Clutch Assy		1												
6258347		Lens Assy 12"		1												
6473084		Control Exposure		1												
<u>CAMERA F49 MK 2</u>																
7133		Camera Mk 2D6)														
7183		Camera Mk 2B6)		3												
6177504		Camera		2												
1142348		Box Drive		1												
1062977		Control Unit		1												
1098963		Plate Pressure		1												
1106025		Mounting Type 133		2												
1106026		Adaptor Type 133		1												

PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS
LDS 247984/1(127)

RESTRICTED

AL 28

SHEET NO 46

PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS

10AE

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
<u>CAMERA F49 MK 2 (CONTD)</u>																
4290884		Adaptor 6"		1												
4290885		Adaptor 12"		1												
4290900		Isolator		1												
4290974		Mounting		1												
<u>CAMERA F49 MK 3</u>																
6177507		Camera		2												
1989699		Shutter Assy		2												
1985642		Magazine		2												
<u>CAMERA F49 MK 4</u>																
6177505		Camera		1												
1062903		Control Unit		3												
1062904		Magazine 200 ft		3												
1142222		Switch		1												
1063028		Pad Pressure		1												
1106165		Transmitter		1												
1106166		Indicator		1												
1142155		Diode Assy		1												
PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS				10AE												

LDS 247984/1(128)

RESTRICTED

SHEET NO 47

10AE

SEE SHEET NO 45 FOR COLUMN HEADINGS

PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS

[illegible]

PR9 CANBERRA TURN ROUND SPARES AIR CAMERAS
LDS 247984/1(129)

RESTRICTED

AL 28

SHEET NO 48

