AL 5

MASTER SERVICING LIST CANBERFA 2,3,4,6,7,15,17,18,19 & 22

AP101B-0400-5A1 Section 1 (2nd Ed)

	List of Cha	pters			Sheet No.	No. of Sheets
Chapter 1 - Airframe	•••	•••	•••		1 - 55	55
Chapter 2 - Weapons	•••		•••		1 - 5	5
Chapter 3 - Electrical	•••			•••	1 - 11	11
Chapter 4 - Propulsion			•••	•••	1 - 12	13 inc 3A
Chapter 5 - Not Allocated						
Chapter 6 - Nav Inst	•••	•••		•••	1	1
Chapter 7 - Air Radar		•••			1 - 3	3
Chapter 8 - Air Comms		•••		•••	1 - 5	5
Chapter 9 - Photo					1 - 2	2
Chapter 10 - NBS	•••			•••	Ni).	
Chapter 11 - Not Allocated						
Chapter 12 - ECM		•••		***	1 - 3	3
Chapter 13 - Survival Equipment	(SE)			•••	1 ~ 2	2
Chapter 14 - General Engineering	; ··· ···				Nil	
Chapter 15 - NDT				•••	1 - 5	5

AL 5

MASTER SERVICING LIST CANBERRA 2,3,4,6,7,15,17,18,19 & 22

AP101B-0400-5A1 (2nd Ed)

Modification Standard

This Servicing Schedule has been written to the following Modification Standard:

1. The servicing implications of the following modifications have been included in the Pre and/or Post Mod state and are so annotated:

MOD No.	SCHEDULE IDENT No.	MOD No.	SCHEDULE IDENT No.	MOD No.	SCHEDULE IDENT No.	MOD No.	SCHEDULE IDENT No.
5	013424,25,32,34,35	3535	010292	4933	010648,150614	AVON 5315	042201
272	010680	3816	034504 031101	4960	010648,150614	# 5430	042201
720	011804	3850	043903 043914	5015	010612,13,18-20 32,33,35,36	" 112	042303
736	043917	40/15	010802	5027	010610,150613	DOWTY 3106	011810
1165	012103	4270	011711,17 151701-04	5051	151706	5045	040610
1461	034505	4335	031103	5320	042207	5,046	010314 150303
1478	043915	4356	011804	5415	042207	5063	010314 150303
14 8 0	043916	4357	011804	EE/ACT/ 2348	031001-2		
2316	013433	4427	010569	ELECT/ C426	034503		
2380	011304,05	4704	010663,011745	AV ON 169	042201		
25 45	010611,150612	4781	010685	" 525	042201		
3156	150603,04,05 150607-09	4783	010503	" 826	0/+2201		
3487	011832	4930	010926,27,32,33,38, 39,44,52	" 1009	0/+2201		

2. The servicing implications of the following modifications have been included by amendment action between revisions as in the Pre and/or Post Mod state and are so annotated:

MOD No.	SCHEDULE IDENT No.	MOD No.	SCHEDULE IDENT No.	MOD No.	SCHEDULE IDENT No.	MOD No.	SCHEDULE 1DENT No.
							·
			<u>-</u>				·
		-					***
		 					
							
							
							
				,			
) <u> </u>						:	
				 			

SMS/77/210/8A

AP101B-0400-5A1 (2nd Ed)

MASTER SERVICING LIST CANBERRA 2,3,4,6,7,15,17,18,19 & 22

Groups Occupied During Servicing

01	Aircraft General	36	Ventilated Suit System	69	VOR Installation (If Fitted)
02	Nose Fuselage (See 14)	37	Waveguide Pressurization System	70	HF Installation (If Fitted)
03	Centre Fuselage	38		21	Radio Compass Installation (If Fitted)
04	Rear Fuselage	-	Cooling Shutter Operating System	72	Decca Navigation Installation (If Fitted)
05	Tail Unit	39	Aircraft Fuel and Pressurization	73	VHF Installation (If Fitted)
06	Mainplanes (See 15)		System	74	VHF/UHF Installation (If Fitted)
07	Furnishings	40	Fire Protection System	75	UHF Installation (If Fitted)
08	Emergency Equipment	41	Explosion Suppression	76	Standby UHF Installation (If Fitted)
09	Flying Control Operating System	42	Jet Pipe Temperature Control and	77	ILS Installation (If Fitted)
10	Trim Operating System	_	Indicating System	78 78	Radio Altimeter Installation (If Fitted)
11	Variable Incidence Tailplane	43		79	IFF Mk 10 Installation (If Fitted)
	Operating System	-	Distribution	ģó.	Tacan Installation (If Fitted)
12	Airbrake Operating System	44	Turbo-alternator and Supplies	81	Radio Altimeter Mk 6A Installation
	Flap Operating System	45	Internal and External Lighting	8 <u>2</u>	DME Installation (If Fitted)
14	Nose Fuselage (Continued)	-	System	83	IFF/SSR Installation (If Fitted)
15	Mainplanes (Continued)	46	Radio Power Supplies	84	Doppler Navigation Installation (If Fitted)
16		47	Oxygen System	85	Blue Shadow Installation
17	Main Undercarriages	48		86	Blue Parrot Installation
18	Nose Undercarriage		Instruments	87	Towed Target Installation (If Fitted)
19	Undercarriage Operating System	49	Flight Instruments and Supplies	8 8	Rushton Targets Mk 2 Types A and C
20	Undercarriage Emergency Operating	50	Zero Reader Installation	89	Ejection Seats
	System	51	Compass Installation	90	ARI26051 Installation (If Fitted)
21	Wheel Brake System	52	Navigation Instruments	91	Bomb/Flare Gear System
22	Basic Engines		Installation	92	ARI18165 Installation (If Fitted)
23	Jet Pipes	53		93	ARI18207 Installation
24	Engine Oil System	54		94	ARI23165 Installation
25	Engine Fuel System	55 56		95	ARI23166 Installation
26	Engine Starting and Ignition System	56		96	ARI23167 Installation
27	Engine Control System	57		97	Photographic Installation
28	Engine Anti-icing System	58		98	Gravity Window System
29	Ancillary Drives	59		99	Discharger No.4 Mk 1 System
3 0	Hydraulic Power System	60			
31	· • • • •	61			
	System	62			
32	Bomb/Flare Bay Door Emergency	63			
	Operating System	64			
33	Camera Door Operating System	65 66			
3-	Air Conditioning and				
75	Pressurization System	67			
27	Demisting System	68			