

PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip M.R. L.M.	Plate No.
		1 2 3 4 5 6				
	EA3.80.7001	EQUIPMENT IN PRESSURE CABIN, ASSEMBLY (MOD 4937) (PRE—MOD 5204)	—	—	—	
	EA3.80.8001	EQUIPMENT IN PRESSURE CABIN, ASSEMBLY (MOD 5204)	—	—	—	
	EA3.80.7015	Spares for:— ACCELEROMETER, INSTALLATION	—	—	—	GA1/1
6A/4695406	—	Spares for:— ACCELEROMETER, MK.2	1	—	A	GA1/2
28S/1012358	A43/B32	Attaching parts for Ref. 6A/4695406:— Screw, 4BA	3	—	C	GA1/3
	—	BRACKET, mounting (Existing bracket EA3.80.6465 modified) (C/Mod Con/0516/STC—Mod 5180)	1	L59	—	GA1/4
28M/4342710	AGS2001B4	Attaching parts for bracket:— Nut, 4BA	6	—	C	GA1/5
28S/9150582	A43/B16	Screw, 4BA	6	—	C	GA1/6
28W/1010006	SP22B	Washer, 4BA	6	—	C	GA1/7
45842	EA3.80.6469	BRACKET, L.H. coaming tube	1	BS267	—	GA1/8
45843	EA3.80.6471	BRACKET, R.H. coaming tube	1	BS267	—	GA1/9
	EA3.83.95	BALLAST, UNDER BOMB AIMER'S RAMP, ASSEMBLY (MOD 5204)	—	—	—	GA2/1
		Spares for:—				
32203	EA3.84.23	BLOCK, ballast, 18 ³ / ₄ lbs S.O.O.	1	—	B	GA2/2
	or					
46393	EA3.84.27	BLOCK, wood, S.O.O.	1	—	—	
12997	EA3.84.25	BLOCK, ballast, 49 ¹ / ₂ lbs S.O.O.	3	—	B	GA2/3
	or					
	EA3.84.29	BLOCK, wood, S.O.O.	3	—	—	
32202	EA3.84.21	BLOCK, ballast, 106 ¹ / ₂ lbs S.O.O.	1	—	B	
	or					
	EA3.83.113	BLOCK, hardwood, 19" x 7" x 2"	1	—	—	GA2/4
		Attaching parts for EA3.84.113:—				
28D/1013176	AS.1242/10E	Bolt, 1/4" BSF	1	—	C	GA2/5
28D/1212828	AS.1242/11E	Bolt, 1/4" BSF	1	—	C	GA2/6
28D/1212831	AS.1242/14E	Bolt, 1/4" BSF	7	—	C	GA2/7
28M/1011475	A27/EP	Nut, 1/4" BSF	6	—	C	GA2/8
28W/9418921	SP13E	Washer	6	—	C	GA2/9
13044	EA3.83.97	BOX, ballast	1	—	B	GA2/10
		Attaching parts for EA3.83.97:—				
28D/1008151	A25/4E	Bolt, 1/4" BSF	1	—	C	GA2/11
28D/1011245	A25/10E	Bolt, 1/4" BSF	4	—	C	GA2/12
28M/9480017	AGS2001E1/66	Nut, 1/4" BSF	5	—	C	GA2/13
26763	EA3.83.105	Packing	1	—	C	GA2/14
26762	EA3.83.107	Packing	2	—	C	GA2/15
26761	EA3.83.109	Plate, washer	1	S514	C	GA2/16
24855	EA3.83.111	Plate, washer	2	S514	C	GA2/17
28W/9418921	SP13E	Washer	1	—	C	GA2/18

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off						Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
			1	2	3	4	5	6			
32204	EA3.83.99	STRAP, ballast box Attaching parts for EA3.83.99:—	1						—	B	GA2/19
28D/1011240	A25/5E	Bolt, 1/4" BSF	1						—	C	GA2/20
28M/9480017	AGS2001E1/66	Nut, 1/4" BSF	1						—	C	GA2/21
26760	EA3.83.101	STRAP, support Attaching parts per pair EA3.83.101:—	2						—	C	GA2/22
28D/1011238	A25/3E	Bolt, 1/4" BSF	1						—	C	GA2/23
28M/9480017	AGS2001E1/66	Nut, 1/4" BSF	1						—	C	GA2/24
28W/9418921	SP13E	Washer	1						—	C	GA2/25
	EA3.80.6541	BRACKET, PLUG BREAK, PILOT'S ALTIMETER INSTALLATION (MOD 4859) Spares for:—	—						—	—	
45825	EA3.80.6543	BRACKET, 18 SWG	1						L72	LM	
	EA3.80.2619	COMPASS, E2A ASSEMBLY (PRE—MOD 5204)	—						—	—	
	EA3.80.8043	COMPASS, E2B, ASSEMBLY (MOD 5204) Spares for:—	—						—	—	GA15/1
4626	EA3.80.2623	BRACKET, mounting, assembly	1						—	C	GA15/2
6B/4343605	—	COMPASS, type E2A (Pre—Mod 5076)	1						—	A	
6B/1048857	—	COMPASS, type E2B (Mod 5076)	1						—	A	GA15/3
		Attaching parts for Ref. 6B/4343605 or 6B/1048857:—									
28S/1012356	A43/B12	Screw, 4BA	2						—	C	GA15/4
8631	EA3.80.2621	FLAP, assembly (Pre—Mod 4724)	1						—	C	
8633	EA3.80.1949	PIN, hinge (Pre—Mod 4724)	1						—	C	
8632	EA3.80.2627	SPRING (Pre—Mod 4724)	1						—	C	
8630	EA3.80.2633	TUBE, distance (Pre—Mod 4724)	2						—	C	
	EA3.80.7009	CONSOLE, PILOT'S, ASSEMBLY (MOD 4937) (PRE—MOD 5204)	—						—	—	
	EA3.80.8009	CONSOLE, PILOT'S ASSEMBLY (MOD 5204) Spares for:—	—						—	—	GA15/5
	EA3.80.7011	PANEL, PILOT'S CONSOLE, EQUIPMENT AND WIRING (MOD 4937) (PRE—MOD 5204)	—						—	—	
	EA3.80.8011	PANEL, PILOT'S CONSOLE, EQUIPMENT AND WIRING (MOD 5204) Spares for:—	—						—	—	GA15/6
5CW/4400995	EA3.81.2083	BRACKET, switch, bomb doors Attaching parts for EA3.81.2083:—	1						—	C	GA15/7
28S/9419435	A31/B12	Screw, 4BA	4						—	C	GA15/8
29C/1007776	AGS2034/B	Washer, shakeproof	4						—	C	GA15/9

AP101B-0402-3A

Page GA.3

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
41036-1SS5	. . .	CONSOLE, PILOT'S, ASSEMBLY (SRIM 3577)	—	—	
		Spares for:			
703-1-00416		BLOCK, fuse	2	—	GA15/10
		Attaching parts for 703-1-00416:			
A32/B8		Screw, 4BA	2	—	GA15/11
SP47B		Washer	2	—	GA15/12
41035		CONSOLE, SUB-ASSEMBLY (SRIM 3577)	1	—	GA16/1
		Spares for:			
13659		PANEL, access	1	—	GA16/2
		Attaching parts for 13659:			
AS1246½B		Bolt, 4BA	4	—	GA16/3
21970		PANEL, ACCESS, SUB-ASSEMBLY	1	—	GA16/4
		Spares for:			
13946		HOLDER, spare fuse	1	—	GA16/5
		Attaching parts for 21970:			
213		Stud	2	—	GA16/6
214		Washer	2	—	GA16/7
R WIS.10112-C-1		FUSE, 5 amp	7	—	GA16/8
R AS10		FUSE, 10 amp	8	—	GA16/9
R AS20		FUSE, 20 amp	2	—	GA16/10
Z1788		GROMMET	4	—	GA16/11
R 10H2073169		HOLDER, fuse	1	—	GA16/12
R H2702 RED		LAMP, bomb doors	1	—	GA16/13
EEAS71/2		LINK, 3-way	1	—	
EEAS71/3		LINK, 4-way	1	—	
508-1-06394		PLUG, 4-way	1	—	GA15/13
508-1-06399		PLUG, 9-way	2	—	GA15/14
508-1-06413		PLUG, 26-way	2	—	GA15/15
R H2704		SCREEN, night, bomb door lamp	1	—	GA16/14
AS10512A-2		SWITCH, canopy demist, vent valve, pressure head and windscreen	4	—	GA16/15
R AS10	. . .	FUSE, 10A, anti-collision lights (C/Mod/Con/0267/FC-Mod.5180)	1	—	GA16/16
EA3.81.2077	. . .	KNOB, switch, bomb doors	1	—	GA15/16
		Attaching parts for EA3.81.2077:			
A31/B28	. . .	Screw, 4BA	1	—	GA15/17
31936-ISS3	. . .	PANEL, SWITCH, SUB-ASSEMBLY (SRIM 3577)	1	—	GA16/17
		Spares for:			
13950		GLOVE, aileron trim switch	1	L85	GA16/18
13947		GLOVE, rudder trim switch (Pre Mod.3428)	1	—	
13951A		GLOVE, inboard rudder trim switch (Mod.3428)	1	L85	GA16/19
13951B		GLOVE, outboard rudder trim switch (Mod.3428)	1	L85	GA16/20
		Attaching part for glove:			
A55A2		Screw, grub, 6BA	1	—	GA16/21

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
22106		PANEL, switch, engraved	1	L72	GA16/22
AS10512C-1		SWITCH, external lights master	1	—	GA16/23
AS10512A-1		SWITCH, aileron and rudder trim	QR	—	
AS10512A-2		SWITCH, navigation, taxiing and anti-collision lights	3	—	GA16/25
AS10512E-1		SWITCH, landing and identification lights	3	—	GA16/26
D0523		SWITCH, push, type B, morse	1	—	GA16/27
—		PRESS TO TEST FOR CANOPY AND HATCH DETONATOR CIRCUIT (SEM/CAN/016/STC-Mod.5180)	—	—	
		Spares for:			
WB1110S1B		BLOCK, terminal	1	—	GA16/28
WB1110/1B		COVER, terminal block	1	—	GA16/29
10H0590107		FUSE, 250 mA	2	—	GA16/30
FU8		HOLDER, fuse	2	—	GA16/31
C500/C/7		LAMP, warning	2	—	GA16/32
WB1114/28		PILLAR, terminal block	2	—	GA16/33
EA3.81.5851		SWITCH ASSEMBLY, BOMB DOORS	1	—	GA15/18
		Spares for:			
A33A6		SCREW, 6BA	2	—	GA15/19
5CW1047697		SWITCH	1	—	GA15/20
EA3.81.2073		TOGGLE	1	—	GA15/21
2061		UNIT, control, type 7681/A	1	—	GA16/34
		Attaching parts for EA3.80.7011 or EA3.80.8011:			
AS1248/1C		Bolt, 2BA	17	—	GA16/35
EA3.80.669		STRUCTURE, PILOT'S CONSOLE, ASSEMBLY	—	—	GA17/1
		Spares for:			
EA3.80.2575		FAIRING, CONTROL, ASSEMBLY	1	—	GA17/2
		Spares for:			
EA3.80.2579		COVER, detachable	1	—	GA17/3
		Attaching parts for EA3.80.2579:			
AS1248/1/2C		Bolt, 2BA	5	—	GA17/4
AS1248/1C		Bolt, 2BA	3	—	GA17/5
EB7.80.365		PANEL, removable, forward (Pre Mod.5061)	1	L72	GA17/6
EA3.80.6641		PANEL, ASSEMBLY, FORWARD, ACCESS FOR EMERGENCY BATTERY (MOD.5061)	1	—	
		Spares for:			
DZUS					
A4-30		FASTENER	1	—	
EA3.80.6649		FLAP, 18 SWG	1	L72	
DZUS					
GA4-250		GROMMET	1	—	
EA3.80.6651		HINGE (Make from AS1878 Ref.28N/9511950)	1	—	

AP101B-0402-3A

Page GA.5

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
BULGIN				
T102	... TERMINAL, red	1	—	
T102	... TERMINAL, black	1	—	
	Attaching parts for T102:			
A31C24	... Screw, 2BA	1	—	
EA3.80.2755	... PANEL, removable centre	1	—	GA17/7
EA3.80.1177	... PANEL, removable, rear intermediate	1	—	GA17/8
EA3.80.2849	... PANEL, removable, rear	1	—	GA17/9
	Attaching parts for Panels, removable:			
AS1248/1C	... Bolt, 2BA	QR	—	GA17/10
A25/1E	... Bolt, 1/4" BSF	QR	—	GA17/11
EA3.80.1727	... CONTAINER, URINE, ASSEMBLY	—	—	GA2/26
	Spares for:			
E20002	... CLIP, spring	1	—	GA2/27
HX11761	... CONTAINER, Mk.2	1	—	GA2/28
E20001	... FUNNEL	1	—	GA2/29
EB7.80.327	... CURTAIN, BLACKOUT, ASSEMBLY (MOD.1413)	—	—	
	(MOD.4937) (PRE MOD.5204)			
	Spares for:			
EB7.80.331	... CURTAIN, main	1	—	
EA3.80.1753	... CURTAIN, navigator's window	1	—	
CARR				
No.759	... FASTENER	3	—	
AGS2001C1/66	... NUT, 2BA	4	—	
AGS2002C1	... NUT, 2BA	2	—	
EB6.80.139	... PLATE, black-out, starboard	1	—	
EB6.80.183	... PLATE, black-out, port	1	—	
EEAS132/12	... STRAP, securing	2	—	
CARR				
No.882	... STUD, hex. base	6	—	
EEAS27/16ER	... WASHER, special	2	—	
EA3.80.8071	... CURTAIN, BLACKOUT, ASSEMBLY (MOD.5204)	—	—	GA3/1
	Spares for:			
EH6.80.381	... BLACKOUT, NAVIGATOR'S WINDOW, ASSEMBLY	—	—	
	(MOD.5204)			
	Spares for:			
EH6.80.383	... CURTAIN, navigator's window	1	—	GA3/2
EA3.80.8069	... CURTAIN, MAIN, ASSEMBLY	1	—	GA3/3
	Spares for:			
CARR				
GJ4.00671.00.000	... BUTTON, dome	3	—	GA3/4
EA3.80.8067	... CURTAIN, main	1	—	GA3/5
CARR				
GJ1.00708.00.000A	... PLATE, clinch	8	—	GA3/6
GJ1.00608.00.000	... SOCKET, fastener	8	—	GA3/7
GJ4.00548.00.000	... SOCKET	3	—	GA3/8

EQUIPMENT AIRCRAFT
PRESSURE CABIN AIRCRAFT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA3.80.6689	.	.	.	CURTAIN, UPPER, ASSEMBLY			1	—	GA3/9
				Spares for:					
CARR	.	.	.	BUTTON, dome			8	—	GA3/10
GJ4.00671.00.000	.	.	.	CURTAIN, upper			1	—	GA3/11
EA3.80.8081	.	.	.						
CARR	.	.	.	SOCKET			8	—	GA3/12
GJ4.00548.00.000	.	.	.	NUT, 2BA			6	—	GA3/13
AGS2001C1/66	.	.	.	NUT, 2BA			2	—	GA3/14
AGS2002C1	.	.	.	PLATE, BLACKOUT, ASSEMBLY, PORT			1	—	GA3/15
EA3.80.6389	.	.	.	Spares for:					
EB6.80.177	.	.	.	BRACKET			1	—	GA3/16
EA3.80.6391	.	.	.	PLATE, assembly			1	L72	GA3/17
EA3.80.6395	.	.	.	PLATE			1	L72	GA3/18
				Attaching parts for EA3.80.6395:					
A25/1B	.	.	.	Bolt, 4BA			4	—	GA3/19
SP13B	.	.	.	Washer			4	—	GA3/20
EEAS132/12	.	.	.	STRAP			2	—	GA3/21
CARR	.	.	.						
GJ1.00882.00.000	.	.	.	STUD			8	—	GA3/22
GJ4.00759.00.000	.	.	.	STUD			11	—	GA3/23
EEAS27/16ER	.	.	.	WASHER			2	—	GA3/24
EA3.85.15	.	.	.	DESTRUCTOR, MOUNTING, ASSEMBLY			—	—	GA14/1
				Spares for:					
EA3.85.17	.	.	.	BRACKET, MOUNTING, ASSEMBLY			1	—	GA14/2
				Spares for:					
EA3.85.25	.	.	.	BAND, wire			1	—	GA14/3
EA3.85.27	.	.	.	BAND, wire			1	—	GA14/4
EA3.80.7005	.	.	.	EQUIPMENT IN NAVIGATOR'S COMPARTMENT,			—	—	
				ASSEMBLY (MOD.4937) (PRE MOD.5204)					
EA3.80.8005	.	.	.	EQUIPMENT IN NAVIGATOR'S COMPARTMENT,			—	—	GA5/1
				ASSEMBLY (MOD.5204)					
				Spares for:					
EA3.80.2919	.	.	.	ATTACHMENT OF NAVIGATOR'S TABLE			—	—	GA5/2
				TO PILOT'S SEAT RAIL					
				Spares for:					
EA3.80.2921	.	.	.	BRACKET, assembly			1	—	GA5/3
				Attaching parts for EA3.80.2921:					
A25/1C	.	.	.	Bolt, 2BA			4	—	GA5/4
A25/3C	.	.	.	Bolt, 2BA			4	—	GA5/5
SP10C	.	.	.	Washer			4	—	GA5/6
SP13C	.	.	.	Washer			4	—	GA5/7

AP101B-0402-3A

Page GA.7

EQUIPMENT AIRCRAFT

PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5	6			
—	.	.	.	.	.	BOX, JUNCTION, MICROPHONE (FIG 3 and 4, SEM/CAN/015/STC—MOD 5180) Spares for:—	1	—	GA5/8
R SP93B8	.	.	.	.	.	GROMMET	2	—	
PO4A4X2-12/0	.	.	.	.	.	PLUG, fixed, size 2, 12-way	2	—	GA5/10
R KT95291/5	.	.	.	.	.	POST, terminal	2	—	
N314567-1	.	.	.	.	.	SOCKET, base	4	—	GA5/12
SO4A4X1-4/1	.	.	.	.	.	SOCKET, fixed size, 4-way	1	—	GA5/13
SO4AX2-12/0	.	.	.	.	.	SOCKET, fixed, size 2, 12-way	2	—	GA5/14
N324362	.	.	.	.	.	SWITCH, magnetic relay	4	—	GA5/15
HC302	.	.	.	.	.	TAG, RT	5	—	
EA3.80.2067	.	.	.	.	.	BRACKET, platform (For Aircraft WJ640) (Pre—Mod 5204)	1	—	
EA3.80.2069	.	.	.	.	.	BRACKET, platform (For Aircraft WJ640) (Pre—Mod 5204) Attaching parts for EA3.80.2067 and EA3.80.2069:—	1	—	
A25/1C	.	.	.	.	.	Bolt, 2BA	4	—	
AGS2001C1/66	.	.	.	.	.	Nut, 2BA	4	—	
SP15C	.	.	.	.	.	Washer	4	—	
EA3.80.8041	.	.	.	.	.	BURCOSTAT, PORT WALL, INSTALLATION (MOD 5204) Spares for:—	—	—	GA6/1
SP93B6	.	.	.	.	.	GROMMET, (C/Mod/Con/0539) (Mod 5180)	1	—	GA6/2
22977	.	.	.	.	.	PLATE, mounting (SRIM 3867 or 3868) Attaching parts for 22977:—	1	—	GA6/3
A25/1C	.	.	.	.	.	Bolt, 2BA	7	—	GA6/4
SP15C	.	.	.	.	.	Washer	7	—	GA6/5
L100CB	.	.	.	.	.	RHEOSTAT (C/Mod/Con/0539) (Mod 5180) Attaching parts for L100/CB:—	1	—	GA6/6
A25/1/2C	.	.	.	.	.	Bolt, 2BA	3	—	GA6/7
SP47C	.	.	.	.	.	Washer	3	—	GA6/8
AS10512C-1	.	.	.	.	.	SWITCH (C/Mod/Con/0539) (Mod 5180)	1	—	GA6/9
Z10129	.	.	.	.	.	DRIVE, flexible, repeater unit	1	—	GA5/16
	.	.	.	.	.	EXTINGUISHER, FIRE, NAVIGATOR'S (C/MOD/0426/STC—MOD 5180) Spares for:—	—	—	
11B180	.	.	.	.	.	BRACKET, mounting	1	—	GA5/17
34H	.	.	.	.	.	EXTINGUISHER, fire, 34H	1	—	GA5/18
EA3.80.1203	.	.	.	.	.	PLATE, base	1	—	GA5/19

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA3.80.7025	. . .	PANEL, NAVIGATOR'S INSTRUMENT INSTALLATION Spares for:—	—	—	GA7/1
31076	. . .	CLAMP, panel top attachment (SRIM 3577) (Mod 4937) Attaching parts for 31076:—	2	—	GA7/2
A25/1/2C	. . .	Bolt, 2BA	2	—	GA7/3
AGS2001C1/66	. . .	Nut, 2BA	2	—	GA7/4
SP15C	. . .	Washer	2	—	GA7/5
AGS2097B6C	. . .	LEAD, bonding	1	—	GA7/6
AGS2097C3C	. . .	LEAD, bonding	1	—	GA7/7
14/511	. . .	MOUNT, resilient, 14 lb, lower Attaching parts for 14/511:—	3	—	GA7/8
A25/1C	. . .	Bolt, 2BA	4	—	GA7/9
AGS2001C1/66	. . .	Nut, 2BA	4	—	GA7/10
SP15C	. . .	Washer, forward bolts	2	—	GA7/11
SP18C	. . .	Washer, aft bolts	2	—	GA7/12
EA3.80.7027	. . .	PANEL, INSTRUMENT, ASSEMBLY Spares for:—	—	—	GA8/1
KOLLSMAN L83261-04-010	. . .	ALTIMETER, Mk. 30A Attaching parts for L83261-04-010:—	1	—	GA8/2
KOLLSMAN L84380-00-100	. . .	Plate, mooring	1	—	GA8/3
A219B36	. . .	Screw, 6UNC	4	—	GA8/4
703-2-00244	. . .	BLOCK, terminal, 10-way	1	—	GA8/5
—	. . .	CLIP	9	—	GA8/6
X16929	. . .	CONTROL, transponder	1	—	GA8/7
TYPE 9273	. . .	CONTROL, unit, type 9273	1	—	GA8/8
TYPE 7681A	. . .	CONTROL, unit, type 7681/A	1	—	GA8/9
640-1-12638	. . .	CONTROL, unit, type C1607/7 (Pre Mod 5409)	1	—	GA8/10
703-1-00265	. . .	COVER, terminal block	1	—	GA8/11
A259	. . .	FILAMENT	2	—	GA8/12
L1338	. . .	FILAMENT	9	—	GA8/13
SP40	. . .	GROMMET	4	—	GA8/14
AGS1696/6	. . .	GROMMET	3	—	GA8/15
SIS2465	. . .	HOLDER, correction card	1	—	GA8/16
SIS1128	. . .	HOLDER, ejection drill card (C/Mod/Con/0328/STC—Mod 5180)	1	—	GA8/17
TYPE 9M	. . .	INDICATOR, airspeed Mk. 9HP Attaching parts for TYPE 9M	1	—	GA8/18
AS1246/10C	. . .	Bolt, 2BA	2	—	GA8/19
AS1246/11C	. . .	Bolt, 2BA	2	—	GA8/20

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

	Part Number	Description						No. Off	Matl. Spec.	Plate No.
		1	2	3	4	5	6			
R	6A2769	.	.	.	.	.	INDICATOR, air temperature	1	—	
R	or 6A1037475	.	.	.	.	.	INDICATOR, air temperature, type 'B' Attaching parts for 6A/2769 or 6A/1037475:	1	—	GA8/21
	AS1246/2B	.	.	.	.	.	Bolt, 4BA	2	—	GA8/22
	AS1246/5B	.	.	.	.	.	Bolt, 4BA	2	—	GA8/23
	6B4343585	.	.	.	.	.	INDICATOR, air mileage Attaching parts for 6B/4343585:	1	—	GA8/24
	AS1246/3C	.	.	.	.	.	Bolt, 2BA	3	—	GA8/25
	AGS2001C1/66	.	.	.	.	.	Nut, 2BA	3	—	GA8/26
	SP15C	.	.	.	.	.	Washer	3	—	GA8/27
	6B6349775	.	.	.	.	.	INDICATOR, air position, Mk.1A	1	—	GA8/28
R	or 6B458	.	.	.	.	.	INDICATOR, air position, Mk.1B	1	—	
R	6B1996	.	.	.	.	.	INDICATOR, master, type 'A'	1	—	GA8/29
	or 6B6341552	.	.	.	.	.	INDICATOR, master, type 'B' Attaching parts for 6B/1996 or 6B/6341552:	1	—	
	AS1246/5C	.	.	.	.	.	Bolt, 2BA	3	—	GA8/30
R	WT/D143473	.	.	.	.	.	INDICATOR, electrical, type 9547, tacan	1	—	GA8/31
	10Q4698518	.	.	.	.	.	INDICATOR, relative bearing, type 1630 Attaching parts for WT/D143473 and 10Q4698518	1	—	GA8/32
	AS1246/5B	.	.	.	.	.	Bolt, 4BA	2	—	GA8/33
	AS1246/8B	.	.	.	.	.	Bolt, 4BA	2	—	GA8/34
R	C5165Y	.	.	.	.	.	INDICATOR, electro magnetic, oxygen	1	—	GA8/35
	01-0460 RED	.	.	.	.	.	LAMP, bridge	2	—	GA8/36
	5CX1042173	.	.	.	.	.	LAMP, bridge	1	—	GA8/37
	01-0483 RED	.	.	.	.	.	LAMP, bridge	1	—	GA8/38
	80/10/0678	.	.	.	.	.	LAMP, pillar, red	2	—	GA8/39
R	01-0497 RED	.	.	.	.	.	LAMP, pillar	1	—	GA8/40
R	C1102/E/18	.	.	.	.	.	LAMP, warning	1	—	GA8/41
	703-2-00252	.	.	.	.	.	LINK, 3-way	2	—	
	703-2-00253	.	.	.	.	.	LINK, 4-way	1	—	
	EA3.80.7029	.	.	.	.	.	PANEL, INSTRUMENT, SUB-ASSEMBLY Spares for:	1	—	GA7/13
	14/531	.	.	.	.	.	MOUNT, resilient, 14 lb, upper Attaching parts for 14/531:	2	—	GA7/14
	AS1246/1B	.	.	.	.	.	Bolt, 4BA	4	—	GA7/15
	AGS2001B1	.	.	.	.	.	Nut, 4BA	4	—	GA7/16
	SP15B	.	.	.	.	.	Washer	4	—	GA7/17
	PRC3½	.	.	.	.	.	RECEPTACLE, for control unit attachment	12	—	GA7/18
	13668	.	.	.	.	.	SCREW, wing (SRIM 3577) (Mod 4937)	1	—	GA7/19

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
21533	PANEL, shorting link, used when control unit type TI607/7 fitted (SRIM 3577) (Mod 4937) (Pre—Mod 5409)	1	—	
703-2-00267	PLUG, fixing	2	—	GA8/42
EA3.80.6593	PLATE, altimeter adapter	1	L73	GA8/43
AS1242/1C	Attaching parts for EA3.80.6593: Bolt, 2BA	4	—	GA8/44
EA3.80.6595	PLATE, blanking	1	L72	GA8/45
AS1248/1B	Attaching parts for EA3.80.6595: Bolt, 4BA	4	—	GA8/46
AGS2001B1	Nut, 4BA	4	—	GA8/47
AS10512A-7	SWITCH, transmit	1	—	GA8/48
909E1448-13	VOLTMETER, 0-40V	1	—	GA8/49
A33A16	Attaching parts for 5Q/4347793: Screw, 6BA	4	—	GA8/50
A25/8E	Attaching parts for EA3.80.7027: Bolt, 1/4" BSF	5	—	GA7/20
AGS2001E1/77	Nut, 1/4" BSF	3	—	GA7/21
10AC1053243	Washer, check	3	—	GA7/22
13611	STOP, hinged table (SRIM 3577) (Mod.4937)	1	—	GA7/23
A25/1B	Attaching parts for 13611: Bolt, 4BA	2	—	GA7/24
AGS2001B1	Nut, 4BA	2	—	GA7/25
SP15B	Washer	2	—	GA7/26
EA3.80.7033	PANEL, NAVIGATOR'S AUXILIARY, INSTALLATION	—	—	GA6/10
AS2633	Spares for: BLOCK, terminal, 2-way	1	—	GA6/11
AS2635	BLOCK, terminal, 5-way	3	—	GA6/12
AGS2001B1	Attaching parts for AS2633 and AS2635: Nut, 4BA	2	—	GA6/13
A33B16	Screw, 4BA	2	—	GA6/14
SP13B	Washer	2	—	GA6/15
AS3180/12B	CLIP, 4BA	1	—	GA6/16
AS3180/20B	CLIP, 4BA	1	—	GA6/17
AGS2001B1	Attaching parts for AS3180/12B and AS3180/20B: Nut, 4BA	1	—	GA6/18
A33B16	Screw, 4BA	1	—	GA6/19
SP13B	Washer	1	—	GA6/20
10J4306022	CONTROLLER, loop, type 1342	1	—	GA6/21

R

AP101B-0402-3A

Page GA.11

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description					No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5 6			
13944	.	.	.	COVER, plate, used when voice range filter is not fitted (SRIM 3577) (Mod 4937)		1	—	
AS1248/1/2C	.	.	.	Attaching parts for 13944:— Bolt, 2BA		2	—	
AS2601	.	.	.	COVER, 2 way terminal block		1	—	GA6/22
AS2603	.	.	.	COVER, 5 way terminal block		3	—	GA6/23
10P/4698455	.	.	.	FILTER, voice range (SRIM 1785) (Mod 5204)		1	—	GA6/24
178536	.	.	.	PANEL, auxiliary (SRIM 3577) (Mod 4937) Attaching parts for 178536:—		1	—	GA6/25
A31/C16	.	.	.	Screw, 2BA		9	—	GA6/26
SP13C	.	.	.	Washer		9	—	GA6/27
10L/4306006	.	.	.	RECEIVER, controller, type 1274		1	—	GA6/28
10H/9402799	.	.	.	SOCKET, terminal		17	—	GA6/29
AS10512A-2	.	.	.	SWITCH, radio compass and ILS (S.O.O. ILS SWITCH NOT REQUIRED FOR AIRCRAFT WJ637 AND WJ731) (MOD 5263)		2	—	GA6/30
EA3.80.1	.	.	.	PEDESTAL ASSEMBLY, FOR NAVIGATOR'S TABLE Spares for:—		1	—	GA9/1
EA3.80.457	.	.	.	HINGE, connecting rod		1	—	GA9/2
EA3.80.43	.	.	.	STOP, rubber		2	—	GA9/3
EA3.80.2043	.	.	.	PEDESTAL, support assembly, for equipment platform under navigator's table (For Aircraft WJ640) (Pre—Mod 5204)		1	—	
EA3.80.2011	.	.	.	PLATFORM, support assembly, for equipment under navigator's table (For Aircraft WJ640) (Pre—Mod 5204)		1	—	
EA3.80.573	.	.	.	RAIL, support assembly		1	—	GA9/4
—	.	.	.	REPEATER, unit for API		1	—	GA5/20
EA3.80.785	.	.	.	STOWAGE, navigator's valise Spares for:—		1	—	GA13/6
EA3.80.1203	.	.	.	PLATE, base Attaching parts for EA3.80.1203:—		1	—	GA13/7
AS1248/1/2B	.	.	.	Screw, 4BA		6	—	GA13/8
EA3.80.775	.	.	.	STRAP, assembly		1	—	GA13/9
40926	.	.	.	SWITCHES, DIMMER, NAVIGATOR'S LIGHTING, INSTALLATION (SRIM 3577) (MOD 4937) (PRE—MOD 5204)		—	—	
41693	.	.	.	SWITCHES, DIMMER, ON PORT WALL, NAVIGATOR'S LIGHTING, INSTALLATION (SRIM 3867 or 3868) (MOD 5204) Spares for:—		—	—	GA6/31
K114/5	.	.	.	KNOB, switch		2	—	GA6/32
01-0010	.	.	.	SWITCH, dimmer, CU lights		1	—	GA6/33
01-0016	.	.	.	SWITCH, dimmer, instrument lights		1	—	GA6/34

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

AP101B-0402-3A

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
41108		TABLE, NAVIGATOR'S INSTALLATION (SRIM 3577) (MOD 4937) (PRE-MOD 5204) (For Aircraft WJ640) Spares for:—	—	—	
13988		LINK, connecting	1	L72	
41098		PEDESTAL, TABLE, SUB-ASSEMBLY Spares for:—	—	—	
13994		ATTACHMENT, link, forward	1	—	
13993B		SPACER, link, forward attachment	1	—	
13993C		SPACER, link, forward attachment	1	—	
41109		TOP, TABLE, ASSEMBLY Spares for:—	—	—	
14010		SPACER, for hinge brackets	4	—	
EA3.80.181		SPRING	1	—	
41110		TOP, TABLE, AFT, SUB-ASSEMBLY Spares for:—	1	—	
14045		ATTACHMENT, link	1	—	
13989		BRACKET, link	1	—	
14026		BRACKET, hinge	2	—	
14028		BRACKET, spring	1	—	
13992		PLATE, spring attachment	1	—	
13993A		SPACER, link	1	—	
13996		SPACER, spring	1	—	
13990		SPIGOT	1	—	
41100		TOP, TABLE, CENTRE, SUB-ASSEMBLY Spares for:—	1	—	
14032		BRACKET, hinge	4	—	
41101		TOP, TABLE, FORWARD, SUB-ASSEMBLY Spares for:—	1	—	
14026		BRACKET, hinge	2	—	
14028		BRACKET, spring	1	—	
13992		PLATE, spring attachment	1	—	
13996		SPACER, spring	1	—	
EA3.80.7019		TABLE, NAVIGATOR'S INSTALLATION Spares for:—	—	—	GA9/5
EA3.80.575		TABLE, NAVIGATOR'S ASSEMBLY Spares for:—	1	—	GA9/6
EA3.80.183		LINK, connecting	1	—	GA9/7
EA3.80.187		PLATE, spring connection	2	—	GA9/8
EA3.80.181		SPRING	1	—	GA9/9
EA3.80.519		TOP, centre portion, assembly	1	—	GA9/10
EA3.80.579		TOP, front portion, assembly	1	—	GA9/11
EA3.80.581		TOP, rear portion, assembly	1	—	GA9/12
EA3.80.629		TRAY, mounting assembly, repeater unit and Tacan coupling unit	1	—	GA9/13

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.80.899	EXTINGUISHER, FIRE, ASSEMBLY	—	—	GA4/1
	Spares for:			
EA3.80.1211	BRACKET, assembly	1	—	GA4/2
EA3.80.1213	BRACKET, assembly	1	—	GA4/3
11B180	BRACKET, extinguisher, fire	1	—	GA4/4
	Attaching parts for 11B180:			
AS1248/7C	Bolt, mush, head 2BA	2	—	GA4/5
AGS2001C1/66	Nut, stiff, 2BA	2	—	GA4/6
AS2810/8/05	Tube, distance	2	—	GA4/7
SP15C	Washer, 2BA	2	—	GA4/8
34H	EXTINGUISHER, fire	1	—	GA4/9
15420	FAIRLEAD (SRIM 3868-Mod.5204)	1	—	GA9/14
EA3.80.1989	HANDLE, EMERGENCY HYDRAULIC PUMP	1	—	GA14/5
	Spares for:			
ROMAC				
B80	HANDGRIP	1	—	GA14/6
or				
B79	HANDGRIP	1	—	
or				
FLEET RUBBERS				
1001	HANDGRIP	1	—	
or				
AUTOMOTIVE				
PRODUCTS				
UMC529	HANDGRIP	1	—	
—	HOLDER, FREQUENCY CARD ON PILOT'S			
	STARBOARD BLAST SHIELD, INSTALLATION			
	(C/MOD/CAN/0563/STC) (MOD.5180)			
	Spares for:			
SIS1564	BLOCK, terminal type B, 2-way	1	—	
VITALITY 736	FILAMENT	3	—	
—	HOLDER, assembly (C/Mod/Con/0563STC,	1	—	
	Fig.1, 2 and 3) (Mod.5180)			
01-0497	LAMP, pillar	3	—	
6A1046812	HOLDER, escape drill cards	1	—	
	(C/Mod/Con/0328/STC) (Mod.5180)			
EA3.83.175	LOCK, FLAP SWITCH, ASSEMBLY	1	—	GA14/7
	Spares for:			
AVDEL				
A415	PIN, quick release	1	—	GA14/8
EA3.83.299	LOCK, undercarriage switch	1	—	GA14/9
EA3.80.901	MOUNTING, FIRE AXE, ASSEMBLY	—	—	GA4/10
	Spares for:			
27N4670513	AXE, fire	1	—	GA4/11
AS2294/8	CLIP, spring	1	—	GA4/12
NEWAY				
TYPE 7/7	FASTENER	1	—	GA4/13
EA3.80.1829	PLATE, doubling	1	L72	GA4/14
EA3.80.1831	STRAP, 1/8" thick	1	Leather	GA4/15

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.80.1833	. MOUNTING, FIRST AID CONTAINER, ASSEMBLY	—	—	GA14/10
EA1.80.881	. Spares for: . CONTAINER, first aid box	1	—	GA14/11
AS1248/4C	. Attaching parts for EA1.80.881:	2	—	GA14/12
AGS2001C1/66	. Bolt, 2BA	2	—	GA14/13
EA3.80.1923	. Nut, 2BA	1	—	GA14/14
SP15C	. Pad, packing	4	—	GA14/15
	. Washer, 2BA			
EA3.80.1835	. COVER	1	—	GA14/16
ODDIE 212	. Attaching parts for EA3.80.1835:	2	—	GA14/17
ODDIE 213/2	. Clip	2	—	GA14/18
ODDIE 214	. Stud	2	—	GA14/19
	. Washer			
EA3.80.7003	. PANELS, PILOT'S INSTRUMENT, ASSEMBLY (MOD.4937) (PRE MOD.5204)	—	—	
EA3.80.8003	. PANELS, PILOT'S INSTRUMENT, ASSEMBLY (MOD.5204)	—	—	GA15/22
32000	. Spares for: . BRACKET, upper AV mounting (SRIM.3577) (Mod.4937)	1	—	GA15/23
31999	. BRACKET, upper AV mounting (SRIM.3577) (Mod.4937)	1	—	GA15/24
A25/1B	. Attaching parts for 32000 and 31999:	4	—	GA15/25
AGS2001B1	. Bolt, 4BA	4	—	GA15/26
SP13B	. Nut, 4BA	8	—	GA15/27
	. Washer			
22201	. BRACKET, on flying panel upper AV mount (SRIM.3577) (Mod.4937)	2	—	GA19/1
22202	. BRACKET, on flying panel lower AV mount (SRIM.3577) (Mod.4937)	2	—	GA19/2
14124	. BRACKET, snub	1	—	GA15/28
A25/1B	. Attaching parts for 14124:—	2	—	GA15/29
AGS2001B1	. Bolt, 4BA	2	—	GA15/30
SP13B	. Nut, 4BA	2	—	GA15/31
	. Washer			
14125	. BRACKET, snub	2	—	GA15/32
14126	. BRACKET, snub	1	—	GA15/33
EA3.80.331	. CHANNEL	1	—	GA15/34
14123	. FITTING, support assembly (SRIM.3577) (Mod.4937)	2	—	GA17/12
AS1248/1C	. Attaching parts for 14123:—	2	—	GA17/13
AGS2001C1/66	. Bolt, 2BA	2	—	GA17/14
SP13C	. Nut, 2BA	2	—	GA17/15
	. Washer			
EA1.81.401	. LEAD, bonding	1	—	GA17/16
AGS2097C4C	. LEAD, bonding	1	—	GA17/17
27H4605579	. MOUNTING, AV; 4 lbs engine panel	6	—	GA17/18
AGS2001B1	. Attaching parts for 27H/4605579:	4	—	GA17/19
A32B14	. Nut, 4BA	4	—	GA17/20
	. Screw, 4BA			

AP101B-0402-3A

Page GA.15

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description					No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5 6			
R IN13154G963GA 27H4605574	.	.	.	.	MOUNT, AV, 10 lbs flying panel MOUNT, AV, 12 lbs flying panel Attaching parts for IN13154G963GA and 27H4605574:	5 3	— —	GA17/21 GA17/22
A25/18	.	.	.	.	Bolt, 4BA	AR	—	GA17/23
A25/28	.	.	.	.	Bolt, 4BA	AR	—	GA17/24
AGS2001B1	.	.	.	.	Nut, 4BA	AR	—	GA17/25
R 14130	.	.	.	.	Spacer (SRIM.3577) (Mod.4937)	AR	—	GA17/26
SP13B	.	.	.	.	Washer	AR	—	GA17/27
EA3.80.6117	.	.	.	.	PANEL, ENGINE INSTRUMENT, ASSEMBLY Spares for:	1	—	GA18/1
EA3.80.6115	.	.	.	.	BRACKET, mounting, assembly Attaching parts for EA3.80.6115:	1	—	GA18/2
A25½A	.	.	.	.	Bolt, 6BA	4	—	GA18/3
AGS2001A1	.	.	.	.	Nut, 6BA	4	—	GA18/4
SP15A	.	.	.	.	Washer	4	—	GA18/5
R Uninyvin 14	.	.	.	.	CABLE, Uninyvin 14	AR	BSG 177	
R Uninyvin 20	.	.	.	.	CABLE, Uninyvin 20	AR	BSG 177	
R Uninyvin 16	.	.	.	.	CABLE, Uninyvin 16	AR	BSG 177	
HV3711	.	.	.	.	CAP, Helvin, dolly	6	—	
5L9951110	.	.	.	.	FILAMENT, 6V, 0.24W	2	—	GA18/6
EA3.81.5787	.	.	.	.	GUARD, assembly	6	—	GA18/7
SMITH	.	.	.	.				
AG26	.	.	.	.	INDICATOR, gauge, fuel contents (Mod.1271)	1	—	GA18/8
AG27	.	.	.	.	INDICATOR, gauge, fuel contents (Mod.1271)	1	—	GA18/9
AG25	.	.	.	.	INDICATOR, gauge, fuel contents (Pre Mod.3391)	1	—	GA18/10
AG144	.	.	.	.	INDICATOR, gauge, fuel contents (Mod.3391)	1	—	
1ACR	.	.	.	.	INDICATOR, gauge, oil pressure	2	—	GA18/11
SIS3596	.	.	.	.	INDICATOR, engine speed (Mod.322)	2	—	GA18/12
A44B24	.	.	.	.	Attaching parts for indicators: Screw, 4BA	AR	—	GA18/13
EA3.80.6121	.	.	.	.	LABEL	1	L72	GA18/14
R H2702 RED	.	.	.	.	LAMP, warning, type H2702, fuel pressure	2	—	GA18/15
R H2702 RED	.	.	.	.	LAMP, warning, type H2702, generator fail (B/Com/Mod Con/15) (Mod.5180)	2	—	GA18/16
AGS1658/0	.	.	.	.	NUT, gland	2	—	GA18/17
508-1-06407	.	.	.	.	PLUG, assembly	2	—	GA18/18
508-1-06399	.	.	.	.	PLUG, assembly, 9 pin, size B	2	—	GA18/19
508-1-06405	.	.	.	.	PLUG, assembly, 12 pin, size C	2	—	GA18/20
EA3.81.2311	.	.	.	.	REFLECTOR, fuel tank gauge	1	DTD339	GA18/21
EA3.81.2399	.	.	.	.	REFLECTOR, fuel tank gauge	1	DTD339	GA18/22
EA3.81.2315	.	.	.	.	SCREEN, fuel tank gauge reflector	1	L72	GA18/23
AGS1651/3	.	.	.	.	SLEEVE	2	—	
508-2-11232-002	.	.	.	.	SLEEVE, cable	38	—	
R XD776	.	.	.	.	SWITCH, toggle Attaching parts for XD776	6	—	GA18/24
A44B20	.	.	.	.	Screw, 4BA	2	—	GA18/25
EEAS28/2EP	.	.	.	.	Washer	2	L16	GA18/26
SIS3652	.	.	.	.	THERMOMETER, exhaust gas, type B Attaching parts for SIS3652:	1	—	GA18/27
AGS2001C4	.	.	.	.	Nut	4	—	GA18/28
A44C14	.	.	.	.	Screw	4	—	GA18/29

Page GA.16		EQUIPMENT AIRCRAFT		AP101B-0402-3A	
PRESSURE CABIN EQUIPMENT					
Part Number	Description	No. Off	Matl. Spec.	Plate No.	
	1 2 3 4 5 6				
EEAS28/2EP	. . . WASHER, special Attaching parts for EA3.80.6117:	12	L16	GA18/31	
A25/9B	. . . Bolt, 4BA	3	—	GA17/28	
AGS2001B1	. . . Nut, 4BA	3	—	GA17/29	
EA3.80.1789	. . . Washer, 1" o/d	12	L72	GA17/30	
SP13B	. . . Washer	6	—	GA17/31	
EA3.80.7007	. . . PANEL, FLYING' ASSEMBLY Spares for:	—	—	GA19/3	
KOLLSMAN L82621-04-010	. . . ALTIMETER, Mk.29B (Mod.4859) Attaching parts for L82621-04-010:	1	—	GA20/1	
KOLLSMAN L84380-00-100	. . . Plate, mooring	1	—	GA20/2	
A219B36	. . . Screw, 6UNC	4	—	GA20/3	
WB1110S2B	. . . BLOCK, terminal (Mod.3922) Attaching parts for WB1110S2B:	1	—	GA19/4	
AGS2001B1	. . . Nut, 4BA	2	—	GA19/5	
EB6.81.5349	. . . Pillar, fixing	2	—	GA19/6	
SP13B	. . . Washer	2	—	GA19/7	
6B4343640	. . . COMPASS, Gyro Unit, Type A Attaching parts for Ref.6B4343640	1	—	GA20/4	
A44C24	. . . Screw, 2BA	4	—	GA20/5	
WB1110B2	. . . COVER, terminal block	1	—	GA19/8	
VITALITY 736	. . . FILAMENT, lamp, 28V, 1.1W	4	—	GA20/6	
THORN. L1114	. . . FILAMENT, lamp, 28V, 3.5W	1	—	GA20/7	
HV3033	. . . GROMMET	1	—	GA20/8	
SP93B4	. . . GROMMET	2	—	GA20/9	
MRI-1AP-274	. . . HOLDER, compass deviation card	1	—	GA20/10	
6A1046811	. . . HOLDER, frequency card	1	—	GA20/11	
6A4338320	. . . HORIZON, artificial Attaching parts for Ref.6A4338320	1	—	GA19/9	
A44C20	. . . Screw, 2BA	4	—	GA19/10	
SMITH					
430FL	. . . INDICATOR, aileron trim	1	—	GA19/11	
218FL	. . . INDICATOR, flap position	1	—	GA19/12	
431FL	. . . INDICATOR, rudder trim	1	—	GA19/13	
813FL	. . . INDICATOR, tail trim Attaching parts for indicators:	1	—	GA19/14	
A44B24	. . . Screw, 4BA	4	—	GA19/15	
6A4337742	. . . INDICATOR, air speed, Mk.9M Attaching parts for Ref.6A/4337742:	1	—	GA20/12	
AGS2001C4	. . . Nut, 2BA	4	—	GA20/13	
A44C20	. . . Screw, 2BA	4	—	GA20/14	
AS2809/5/070	. . . Tube, distance	4	L62	GA20/15	
5CZ4340430	. . . INDICATOR, electro-magnetic, 24 volt, type A2	1	—	GA20/16	
5CZ1031243	. . . INDICATOR, electro-magnetic, 24 volt, type C1	1	—	GA20/17	
10Q4280389	. . . INDICATOR, electrical type 9547, Tacan Attaching parts for 10Q/4280389:	1	—	GA20/18	
A32B20	. . . Screw, 4BA	4	—	GA20/19	

AP101B-0402-3A

Page GA.17

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
27-RC-PC	.	.	.	INDICATOR, rate of climb, Mk.3P (Pre Mod.5228)			1	—	GA20/20
KRA1001K	.	.	.	INDICATOR, rate of climb, Mk.3Q (Mod.5228)			1	—	
A44B28 BARBER & COLMAN 1906	.	.	.	Attaching parts for Ref. 27-RC-PC or KRA1001K			4	—	GA20/21
	.	.	.	Screw, 4BA					
	.	.	.	Washer, shakeproof			4	—	GA20/22
10Q4698518	.	.	.	INDICATOR, relative bearing, type 1630			1	—	GA20/35
A44B28	.	.	.	Attaching parts for 10Q4698518			4	—	GA20/36
	.	.	.	Screw, 4BA					
RL7003-46A	.	.	.	INDICATOR, ILS, type 7			1	—	GA19/18
A44B20	.	.	.	Attaching parts for RL7003-46A			4	—	GA19/19
	.	.	.	Screw, 4BA					
ID95ISSUE2	.	.	.	INDICATOR, turn and slip, Mk.3			1	—	GA20/23
A44B20	.	.	.	Attaching parts for ID95ISSUE2			2	—	GA20/24
A44B28	.	.	.	Screw, 4BA			2	—	GA20/25
BARBER & COLMAN 1906	.	.	.	Washer, shakeproof			4	—	GA20/26
80/10/1192	.	.	.	LAMP, bridge, type C			1	—	GA20/27
80/10/0678	.	.	.	LAMP, pillar			2	—	GA20/28
H2705	.	.	.	LAMP, warning amber, ILS marker			1	—	GA20/29
M1684	.	.	.	MACHMETER, Mk.2			1	—	GA20/30
A44B28	.	.	.	Attaching parts for M1684			4	—	GA20/31
	.	.	.	Screw, 4BA					
EA3.80.6639	.	.	.	PANEL, SUB-ASSEMBLY (MOD.4859)			1	—	GA19/20
EA3.80.6557	.	.	.	Spares for:			1	L73	GA19/21
AS10512L-1	.	.	.	PLATE, adaptor, 10 SWG			1	—	GA20/32
	.	.	.	PLATE, adaptor, switch					
	.	.	.	(Alt. R60/58-Mod.5097)			1	—	GA20/33
EA3.81.6247	.	.	.	PLATE, switch (Alt. R60/58-Mod.5097)			1	—	GA20/34
AS10512M-1	.	.	.	SHROUD, terminal (Alt. R60/58-Mod.5097)			1	—	
AS10512B-3	.	.	.	SWITCH (Alt. R60/58-Mod.5097)			1	—	
A25/14E	.	.	.	Attaching parts for EA3.80.7007:			4	—	GA17/32
AGS2001E1/77	.	.	.	Bolt, 1/4" BSF			4	—	GA17/33
WT33047	.	.	.	Nut, 1/4" BSF			12	—	GA17/34
	.	.	.	Washer, check					
EA3.80.2933	.	.	.	PANEL, FIXED, INSTRUMENT, STARBOARD			—	—	
	.	.	.	INSTALLATION (MOD.4937)					
	.	.	.	(PRE-MOD.5204)					
EA3.80.8023	.	.	.	PANEL, FIXED, INSTRUMENT, STARBOARD,			—	—	GA21/1
	.	.	.	INSTALLATION (MOD.5204)					
	.	.	.	Spares for:					
EA3.80.7013	.	.	.	PANEL, FIXED, INSTRUMENT, STARBOARD,			1	—	
	.	.	.	ASSEMBLY (MOD.4937)					
	.	.	.	(PRE-MOD.5204)					
EA3.80.8013	.	.	.	PANEL, FIXED, INSTRUMENT, STARBOARD			1	—	GA21/2
	.	.	.	ASSEMBLY (MOD.5204)					
	.	.	.	(PRE-MOD.5)					
EA3.80.8015	.	.	.	PANEL, FIXED, INSTRUMENT, STARBOARD,			1	—	
	.	.	.	ASSEMBLY (MOD.5204) (Mod.5)					
	.	.	.	For Aircraft WH667 only					
	.	.	.	Spares for:					
6A4333072	.	.	.	ALTIMETER, Mk.18			1	—	GA21/3
A44B24	.	.	.	Attaching parts for 6A/4333072:			4	—	GA21/4
AGS2037B	.	.	.	Screw, 4BA			4	—	GA21/5
	.	.	.	Washer, shakeproof					

EQUIPMENT AIRCRAFT

PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
703-1-00238	.	.	.	.	.	BLOCK, terminal, 5-way Attaching parts for 703-1-00238:	1	—	GA21/6
A32B24	.	.	.	.	.	Screw, 4BA	2	—	GA21/7
14067	.	.	.	.	.	Spacer threaded (SRIM.3577) (Mod.4937)	2	—	GA21/8
AGS2037B	.	.	.	.	.	Washer, shakeproof	2	—	GA21/9
630/1/37854/010	.	.	.	.	.	CONTROLLER, V/UHF (Service supply) (Mod 5409)	1	—	
703-1-00264	.	.	.	.	.	COVER, terminal block	1	—	GA21/10
L1034	.	.	.	.	.	FILAMENT (Sem/Can/039/STC) (Mod.5180)	2	—	GA21/11
10069 N & Z	.	.	.	.	.	GAUGE, pressure	2	—	GA21/12
or									
SIS3592	.	.	.	.	.	GAUGE, pressure, Mk.14LL Attaching parts for SIS3592 and 10069 N & Z:			
GE21552	.	.	.	.	.	Plate, adapter	1	—	GA21/13
A44B24	.	.	.	.	.	Screw, 4BA	4	—	GA21/14
AGS2037B	.	.	.	.	.	Washer, shakeproof	4	—	GA21/15
KGA0463	.	.	.	.	.	GAUGE, pressure, oxygen	2	—	GA21/16
289FL	.	.	.	.	.	INDICATOR, air mixer valve Attaching parts for KGA0463 and 289FL:	1	—	GA21/17
A44B24	.	.	.	.	.	Screw, 4BA	4	—	GA21/18
AGS2037B	.	.	.	.	.	Washer, shakeproof	4	—	GA21/19
IN14343-2	.	.	.	.	.	LABEL, hydraulic, pressure gauge	2	—	GA21/20
EA3.81.6235	.	.	.	.	.	LABEL, engine air to cabin (Alt. R60/58-Mod.5097)	1	—	GA21/21
40925/36	.	.	.	.	.	LABEL, muting, CU nav and lower aerial (SRIM.3577) (Mod.4937) (Pre Mod.5204)	1	—	
40925/34	.	.	.	.	.	LABEL, PTR175 (SRIM.3577) (Mod.4937) (Pre Mod.5204)	1	—	
22111	.	.	.	.	.	LABEL, mute, CU pilot and upper aerial (SRIM.3577) (Mod.4937) (Pre Mod.5204)	1	—	
R 5CX5361 X	.	.	.	.	.	LAMP, pillar (C/Mod/Con/0473/STC) (Mod.5180)	2	—	
R 703-2-00251	.	.	.	.	.	LINK, 2-way	1	—	
EA3.80.6169	.	.	.	.	.	PANEL, SUB-ASSEMBLY (PRE MOD.5204) Spares for:	1	—	
EB6.80.5645	.	.	.	.	.	BRACKET, assembly, control unit	1	—	
EB6.80.695	.	.	.	.	.	DOOR, assembly, switch Attaching parts for EB6.80.695:	1	—	
A32A12	.	.	.	.	.	Screw, 6BA	2	—	
41181	.	.	.	.	.	PANEL, sub-assembly (SRIM.3676) (Mod.5204)	1	—	GA21/24
—	.	.	.	.	.	PANEL, sub-assembly, fire switches (SEM/Con/039/STC) (Mod.5180) Attaching parts for panel:	1	L72	
R A32B12	.	.	.	.	.	Screw, 4BA	4	—	
AS10512L-2	.	.	.	.	.	PLATE, adapter, cabin pressure switch (Mod.4939) (Pre Mod.5204)	1	—	
15417	.	.	.	.	.	PLATE, switch, cabin pressure (SRIM.3867) (Mod.5204)	1	—	GA21/26
AS10512L-1	.	.	.	.	.	PLATE, adaptor (Alt. R60/58-Mod.5097)	3	—	GA21/27
13615	.	.	.	.	.	PLATE, switch, PTR175 (SRIM.3577) (Mod.4937) (Pre Mod.5204)	1	—	
AS10512M-1	.	.	.	.	.	SHROUD, terminal (Alt. R60/58-Mod.5097)	3	—	
EL37711	.	.	.	.	.	SWITCH, push, fire (SEM/Con/039/STC) (Mod.5180)	2	—	GA21/28
C5162Y Mk.3	.	.	.	.	.	SWITCH, push, fire warning and test (SEM/Con/039/STC) (Mod.5180)	1	—	GA21/29
AS10512C-4	.	.	.	.	.	SWITCH, DP, cabin pressure on/off test (Mod.4939)	1	—	GA21/30

AP101B-0402-3A

Page GA.19

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
AS10512A-2	.	.	.	.	SWITCH, engine air to cabin (Alt. R60/58-Mod.5097) (Mod.5)		2	—	
AS10512A-2	.	.	.	.	SWITCH, PTR 175, control unit and aerial (SRIM.3577) (Mod.4937)		2	—	GA21/31
AS10512A-7	.	.	.	.	SWITCH, PTR 175, muting (SRIM.3577) (Mod.4937)		1	—	GA21/32
AS10512A-1	.	.	.	.	SWITCH, cabin air hot/cold (Alt. R60/58-Mod.5097)		1	—	GA21/33
R 10L9455739	.	.	.	.	UNIT, control, T1607/4 (Pre Mod 5409)		1	—	GA21/34
5CW11817	.	.	.	.	WINDOW, F1 (SEM/Con/039/STC) (Mod.5180)		1	—	GA21/35
5CW11818	.	.	.	.	WINDOW, F2 (SEM/Con/039/STC) (Mod.5180)		1	—	GA21/36
EA3.81.8137	.	.	.	.	WIRING, STARBOARD, INSTRUMENT PANEL (MOD.5204) (Pre Mod.5)		—	—	
EA3.81.8139	.	.	.	.	WIRING, STARBOARD INSTRUMENT PANEL (MOD.5204) (MOD.5)		—	—	
Minyvin 16	.	.	.	.	CABLE, Minyvin 16		AR	BSG195	
Minyvin 20	.	.	.	.	CABLE, Minyvin 20		AR	BSG195	
508-1-06406	.	.	.	.	PLUG, 14 way		2	—	
EEAS146/16	.	.	.	.	SLEEVE, 1/4" long		AR	—	
EEAS146/16	.	.	.	.	SLEEVE, 3/4" long		AR	—	
EEAS146/20	.	.	.	.	SLEEVE, 1/4" long		AR	—	
EEAS146/20	.	.	.	.	SLEEVE, 3/4" long		AR	—	
508-2-11232-002	.	.	.	.	SLEEVE, inner		23	—	
508-2-11231-002	.	.	.	.	SLEEVE, inner		4	—	
HC294	.	.	.	.	TAG, RT		4	—	
HC294D	.	.	.	.	TAG, RT		3	—	
HC295	.	.	.	.	TAG, RT		2	—	
HC296	.	.	.	.	TAG, RT		2	—	
HC304	.	.	.	.	TAG, RT		2	—	
HC306B	.	.	.	.	TAG, RT		2	—	
HC490	.	.	.	.	TAG, QR		7	—	
HC1187RH	.	.	.	.	TAG, cranked		3	—	
AS1248/1C	.	.	.	.	Attaching parts for fixed panel: Bolt, 2BA		9	—	GA21/37
EA3.04.11001	.	.	.	.	PANEL, FIXED, INSTRUMENT, STARBOARD INSTALLATION (EA3.04.9533) (MOD.2523-S.O.O.)		—	—	
6A4333072	.	.	.	.	Spares for: ALTIMETER, cabin		1	—	
R S1S6118	.	.	.	.	Attaching parts for 6A/4333072: Adaptor		1	—	
A44B24	.	.	.	.	Screw, 4BA		4	—	
SIS1564	.	.	.	.	BLOCK, terminal, 2 way		2	—	
AGS2001A1	.	.	.	.	Attaching parts for SIS1564: Nut, 6BA		1	—	
A45A20	.	.	.	.	Screw, 6BA		1	—	
Unipren 6	.	.	.	.	CABLE, Unipren 6		AR	BSG177	
Unipren 12	.	.	.	.	CABLE, Unipren 12		AR	BS2E21	
EA3.04.1887	.	.	.	.	CABLE, assembly, N64, from starboard fixed panel to pressure bulkhead		1	—	
EA3.04.10749	.	.	.	.	CABLE, assembly, N65 from starboard fixed panel to electrical control panel		1	—	
AS491/15	.	.	.	.	CLIP, cable		2	—	
AGS2001B1	.	.	.	.	Attaching parts for AS491/15: Nut, 4BA		1	—	
A44B20	.	.	.	.	Screw, 4BA		1	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
AGS1765/2	. . .	COVER, spring, assembly	2	—	
ZA2401-1	. . .	FILAMENT, lamp, 28V, 3.5W	3	—	
A44B10	. . .	GUARD, locking	1	—	
EEAS28/2HP	. . .	Attaching parts for ZA2401-1:			
	. . .	Screw, 4BA	2	—	
	. . .	Washer	2	—	
505FL	. . .	INDICATOR, air valve	1	—	
A44B24	. . .	Attaching parts for 505FL:			
	. . .	Screw, 4BA	4	—	
H2702 RED	. . .	LAMP, warning, red	3	—	
EA3.04.10999	. . .	PANEL, starboard, fixed	1	—	
EA3.83.827	. . .	PIPE, assembly (Pre Mod.887)	1	—	
EA3.73.981	. . .	PIPE, assembly (Mod.887)	1	—	
EA3.04.11031	. . .	PLATE, blanking, assembly (Pre Mod.887)	1	—	
	. . .	Attaching parts for EA3.04.11031:			
AGS2001B1	. . .	Nut, 4BA	4	—	
A441B14	. . .	Screw, 4BA	4	—	
SP15B	. . .	Washer	4	—	
508-1-06406	. . .	PLUG, size C	2	—	
508-2-11231-002	. . .	SLEEVE, cable	2	—	
508-2-11232-002	. . .	SLEEVE, cable	22	—	
DO523	. . .	SWITCH, button, push	2	—	
5CW1042625	. . .	SWITCH, toggle	1	—	
XD778	. . .	SWITCH, toggle	1	—	
D5404	. . .	SWITCH, toggle	1	—	
	. . .	Attaching parts for D5404, XD778: and 5CW/1042625:			
A44B10	. . .	Screw, 4BA	2	—	
EEAS28/2HP	. . .	Washer	2	—	
5K4266	. .	SNUB, pilot's instrument panel (SRIM.3577)	4	—	GA15/35
EA3.80.383	. .	STAY, tubular	1	—	GA19/22
EA2.80.17	. .	PANEL, UNDERCARRIAGE INSTRUMENT, ASSEMBLY	1	—	GA22/1
	. .	Spares for:			
EA3.81.2081	. .	BRACKET, assembly	1	—	GA22/2
	. .	Attaching parts for EA3.81.2081:			
A31B12	. .	Screw, 4BA	4	—	GA22/3
AGS2035B	. .	Washer, shakeproof	4	—	GA22/4
DOWTY C2524Y	. .	BUTTON, push undercarriage	1	—	GA22/6
	. .	Attaching parts for C2524Y:			
A40B14	. .	Screw, 4BA	2	—	GA22/7
Uninyvin 16	. .	CABLE, Uninyvin 16	AR	BSG177	
Uninyvin 20	. .	CABLE, Uninyvin 20	AR	BSG177	
THORN. L1114	. .	FILAMENT, lamp, 28V, 3.5W	9	—	GA22/8
5CX4330226	. .	INDICATOR, undercarriage	1	—	GA22/9
	. .	Attaching parts for Ref.5CX4330226			
A40B14	. .	Screw, 4BA	4	—	GA22/10

AP101B-0402-3A		EQUIPMENT AIRCRAFT		Page GA.21	
PRESSURE CABIN EQUIPMENT					
Part Number	Description		No. Off	Matl. Spec.	Plate No.
	1	2 3 4 5 6			
THERMOTANK					
DAR2	.	LOUVRE, punkah	1	—	GA22/14
		Attaching parts for DAR2:—			
AS2922/4B	.	Bolt, 4BA	3	—	GA22/15
AGS2001B1	.	Nut, 4BA	3	—	GA22/16
SP14B	.	Washer	3	—	GA22/17
EA1.81.321	.	PANEL, removable	1	—	GA22/18
508-1-06406	.	PLUG, assembly, size C	1	—	GA22/19
508-2-11232-002	.	SLEEVE, cable, 4-7 amp	9	—	
508-2-11231-002	.	SLEEVE, cable 7-19 amp	2	—	
EA3.81.2071	.	SWITCH, FLAP SELECTOR, ASSEMBLY (PRE—MOD 4005)	1	—	
EA3.81.5851	.	SWITCH, FLAP SELECTOR, ASSEMBLY (MOD 4005)	1	—	GA22/20
		Spares for:—			
A33A6	.	SCREW, 6BA	2	—	GA22/21
5CW/6435	.	SWITCH (Pre—Mod 4005)	1	—	
XD789	.	SWITCH (Mod 4005)	1	—	GA22/22
EA3.81.2073	.	TOGGLE	1	—	GA22/23
EA3.80.2853	.	SWITCH, MASTER, UNDERCARRIAGE AND SWITCH FLAP ASSEMBLY (MOD 2392)	—	—	GA22/24
		Spares for:—			
AS10512L-2	.	ADAPTER, plate (Alt. R60/58—Mod 5097)	1	—	
EA2.80.271	.	BRACKET, switch mounting, assembly Attaching parts for EA2.80.271:—	1	—	GA22/26
A25/1B	.	Bolt, 4BA	3	—	GA22/5
AGS2001B1	.	Nut, 4BA	3	—	GA22/11
UNINYVIN16	.	CABLE, Uninyvin 16	AR	—	
ZA2402-2	.	GUARD, switch (Pre—Mod 5097) Attaching parts for ZA2402-2	1	—	
A32B6	.	Screw, 4BA	4	—	
EH7.80.49	.	GUARD, switch (Alt. R60/58—Mod 5097)	1	—	GA22/12
AS10512M-2	.	SHROUD, terminal (Alt. R60/58—Mod 5097)	1	—	
EEAS146/16	.	SLEEVE, 3/4" long	2	—	
5CW/6435	.	SWITCH, D.P. changeover (Pre—Mod 3849)	1	—	
XD789	.	SWITCH, D.P. changeover (Mod 3849) (Pre—Mod 5097)	1	—	
AS10512D-2	.	SWITCH, D.P. (Alt. R60/58—Mod 5097)	1	—	GA22/13
EB6.80.1017	.	PERISCOPE, STOWAGE AND ELECTRICAL WIRING, ASSEMBLY (MOD 2132— S.O.O.) (EA3.00.1)	—	—	
		Spares for:—			
EA3.81.3009	.	BOX, junction, No. 14	1	—	
EA3.82.217	.	BRACKET, MOUNTING, P.F.C. TRANSFORMER, INSTALLATION	1	—	
		Spares for:—			
EA3.82.215	.	BRACKET, assembly Attaching parts for EA3.82.215:—	1	—	
A25/1C	.	Bolt, 2BA	5	—	
AGS2001C1/66	.	Nut, 2BA	5	—	
SP13C	.	Washer, 2BA	5	—	

PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EB6.81.2899	.	.	.	.	.	CABLE, assembly, 14Q, from J.B.14 to pressure bulkhead	1	—	
AS3180/15B	.	.	.	.	.	CLIP, cable	1	—	
AS3180/4B	.	.	.	.	.	CLIP, cable	6	—	
	.	.	.	.	.	Attaching parts for AS3180/4B:—			
AGS2001B1	.	.	.	.	.	Nut, 4BA	1	—	
A31B16	.	.	.	.	.	Screw, 4BA	1	—	
Z49431	.	.	.	.	.	GROMMET	1	—	
EB7.80.901	.	.	.	.	.	MOUNTING, PERISCOPE, ASSEMBLY	1	—	
	.	.	.	.	.	Spares for:—			
R 6B3469	.	.	.	.	.	PERISCOPE, mounting, Mk. 1F	1	—	
	.	.	.	.	.	Attaching parts for 6B/3469:—			
AS2920/8E	.	.	.	.	.	Bolt, 1/4"	8	—	
EA3.81.3013	.	.	.	.	.	PANEL, ELECTRICAL CONTROL, ASSEMBLY (PRE—MOD 76)	1	—	
EA3.81.3011	.	.	.	.	.	PANEL, ELECTRICAL CONTROL, ASSEMBLY (MOD 76) (PRE—MOD 310)	1	—	
EA3.81.3015	.	.	.	.	.	PANEL, ELECTRICAL CONTROL, ASSEMBLY (MOD 76) (MOD 310)	1	—	
	.	.	.	.	.	Spares for:—			
EA1.81.410	.	.	.	.	.	BAR, TERMINAL, ASSEMBLY	2	—	
	.	.	.	.	.	Spares for:—			
EA1.81.411	.	.	.	.	.	BAR, terminal, c/w studs	1	—	
EA1.81.410A	.	.	.	.	.	BASE, 5/16" thick	1	LFS	
EA1.81.410B	.	.	.	.	.	COVER, plate, 1/8" thick	1	LFS	
BULGIN T5	.	.	.	.	.	HEAD, terminal moulded, 4BA	2	—	
R UNINYVIN 20	.	.	.	.	.	CABLE, Uninyvin 20	AR	—	
R UNINYVIN 16	.	.	.	.	.	CABLE, Uninyvin 16	AR	—	
R UNINYVIN 12	.	.	.	.	.	CABLE, Uninyvin 12	AR	—	
R UNINYVIN 8	.	.	.	.	.	CABLE, Uninyvin 8	AR	—	
EA3.81.121	.	.	.	.	.	COVER, terminal block access	1	—	
9225	.	.	.	.	.	GROMMET, Helsyn No. 1	2	—	
EA3.81.167	.	.	.	.	.	LABEL, 'Fuel pumps and cocks circuit breakers port and starboard'	1	—	
EA3.81.1573	.	.	.	.	.	LABEL, 'Control—1600~'	1	—	
EA3.81.189	.	.	.	.	.	LABEL, 'Inverters No. 2, No. 3 and No. 4'	1	—	
EA3.81.1449	.	.	.	.	.	LABEL, 'Pump cock, pump cock No. 1 tank'	1	—	
EA3.81.1447	.	.	.	.	.	LABEL, 'Pump cock, pump cock No. 2 tank'	1	—	
EA3.81.1445	.	.	.	.	.	LABEL, 'Pump cock, pump cock No. 3 tank'	1	—	
EA3.81.1945	.	.	.	.	.	LANYARD, fuse panel check	2	—	
703-2-00251	.	.	.	.	.	LINK, 2 way	2	—	
703-2-00252	.	.	.	.	.	LINK, 3 way	1	—	
703-2-00253	.	.	.	.	.	LINK, 4 way	3	—	
703-2-00260	.	.	.	.	.	LINK, transverse	8	—	
EEAS71/3	.	.	.	.	.	LINK, 4 way	14	—	
EA3.83.285	.	.	.	.	.	LOCK, SAFETY, BOMB DOOR RELEASE AND STOWAGE, ASSEMBLY	1	—	
	.	.	.	.	.	Spares for:—			
R EA3.83.151	.	.	.	.	.	PIN, SAFETY, ASSEMBLY	1	—	
	.	.	.	.	.	Spares for:—			
AVIATION DEVELOPMENTS	.	.	.	.	.				
A415	.	.	.	.	.	PIN, 'pip'	1	—	
R Z2889-2	.	.	.	.	.	LUG, terminal	3	—	
EA3.81.1427	.	.	.	.	.	PANEL, SWITCH, C/W EQUIPMENT, ASSEMBLY	1	—	
	.	.	.	.	.	Spares for:—			
EA3.81.1211	.	.	.	.	.	GUARD, switch, accumulator isolator	1	—	
EA3.81.1213	.	.	.	.	.	GUARD, switch, No. 1 generator	1	—	
EA3.81.1215	.	.	.	.	.	GUARD, switch, No. 2 generator	1	—	

AP101B-0402-3A

Page GA.23

EQUIPMENT AIRCRAFT

PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA3.81.109	.	.	.	.	PANEL, FUSE, C/W EQUIPMENT, ASSEMBLY (PRE-MOD 310)		1	—	
EA3.81.2579	.	.	.	.	PANEL, FUSE, C/W EQUIPMENT, ASSEMBLY (MOD 310)		1	—	
					Spares for:—				
703-1-00416	.	.	.	.	BLOCK, fuse		16	—	
703-2-00244	.	.	.	.	BLOCK, terminal, 10 way		3	—	
G6A	.	.	.	.	GROMMET, Helsyn		6	—	
Z1841	.	.	.	.	GROMMET, Helsyn		4	—	
EA3.81.197	.	.	.	.	LABEL, 'Fuel pump ammeter test'		1	—	
EA3.81.199	.	.	.	.	LABEL, 'Ammeter'		1	—	
EA3.81.1457	.	.	.	.	LABEL, 'No. 1 gen. volts'		1	L72	
EA3.81.1453	.	.	.	.	LABEL, 'No. 1 gen. amps'		1	L72	
EA3.81.1455	.	.	.	.	LABEL, 'No. 2 gen. volts'		1	L72	
EA3.81.1451	.	.	.	.	LABEL, 'No. 2 gen. amps'		1	L72	
EA3.81.111	.	.	.	.	PANEL, fuse		1	—	
EA3.81.119	.	.	.	.	PANEL, circuit breaker		1	—	
508-1-06406	.	.	.	.	PLUG, size C		3	—	
508-1-06410	.	.	.	.	PLUG, size D		1	—	
508-1-06399	.	.	.	.	PLUG, size B		6	—	
508-1-06405	.	.	.	.	PLUG, size C		2	—	
508-1-06413	.	.	.	.	PLUG, size D		8	—	
E&I 7562	.	.	.	.	PLUG, type K, 3 pin		2	—	
508-2-11231-002	.	.	.	.	SLEEVE, cable		15	—	
508-2-11232-002	.	.	.	.	SLEEVE, cable		157	—	
EEAS146A	.	.	.	.	SLEEVE, $\frac{3}{4}$ " long		3	—	
EEAS146A1	.	.	.	.	SLEEVE, $\frac{3}{4}$ " long		9	—	
EEAS146C	.	.	.	.	SLEEVE, $\frac{3}{8}$ " long		1	—	
508-1-40041-320	.	.	.	.	SOCKET, fixed, Mk. 4		1	—	
508-1-40056-320	.	.	.	.	SOCKET, fixed, Mk. 4		1	—	
CARR									
No. 882	.	.	.	.	STUD, hex. base		2	—	
HC490	.	.	.	.	TAG, quick release, terminal		172	—	
HC500	.	.	.	.	TAG, quick release, terminal		61	—	
HC510	.	.	.	.	TAG, quick release, terminal		91	—	
ROSS COURTNEY									
350	.	.	.	.	TAG		11	—	
703-2-00315-020	.	.	.	.	TAG, quick release terminal, 6 amp		5	—	
EEAS142	.	.	.	.	TERMINAL, earth		2	—	
703-2-00339-020	.	.	.	.	THIMBLE, quick release, 6 amp		5	—	
EEAS43/1	.	.	.	.	WASHER, special		1	—	
EEAS43/3	.	.	.	.	WASHER, special		1	—	
EEAS146C	.	.	.	.	SLEEVE, $\frac{3}{4}$ " long		1	—	
EB6.80.943	.	.	.	.	STOWAGE, PERISCOPE, ASSEMBLY		1	—	
					Spares for:—				
EB6.80.947	.	.	.	.	BRACKET, tube support, lower		1	—	
EB6.80.949	.	.	.	.	BRACKET, tube support, upper		1	—	
EB6.80.1019	.	.	.	.	BRACKET, assembly		1	—	
					Attaching parts for EB6.80.947, EB6.80.949 and EB6.80.1019:—				
A25/1B	.	.	.	.	Bolt, 4BA		6	—	
A27BP	.	.	.	.	Nut, 4BA		6	—	
SP47B	.	.	.	.	Washer, spring		6	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
HV3254	. . .	STRAP, Helvin	AR	—	
HV.3255	. . .	STUD, Helvin	12	—	
EB6.80.945	. . .	TUBE, ASSEMBLY	1	—	
		Spares for:—			
EB6.80.985	. . .	HANDLE	1	—	
EB6.80.979	. . .	LOCK	1	—	
EB6.80.983	. . .	NUT	1	—	
SP29E8	. . .	PIN, taper	1	—	
EB6.80.981	. . .	SPRING	1	—	
EB6.80.977	. . .	TUBE	1	—	
EEAS28/42AR	. . .	WASHER, packing	AR	—	
		Attaching parts for EB6.80.945:—			
A25/16B	. . .	Bolt, 4BA	2	—	
A27BP	. . .	Nut, 4BA	2	—	
SP47B	. . .	Washer, spring	2	—	
EA3.83.151	. . .	PIN, SAFETY, BOMB DOOR LOCK, ASSEMBLY	1	—	GA14/20
		Spares for:—			
AVIATION DEVELOPMENTS					
A415	. . .	PIN, quick release	1	—	GA14/21
EA2.10.707	. . .	RAMP ASSEMBLY, BOMB AIMER'S	1	—	
		Spares for:—			
EA2.10.709	. . .	SPIGOT, assembly	2	—	
EA3.80.1231	. . .	SEAT, MAP READER'S, ASSEMBLY	1	—	GA10/1
		Spares for:—			
EA3.80.1289	. . .	CABLE, BOWDEN, ASSEMBLY	1	—	GA10/2
		Spares for:—			
EA3.80.1293	. . .	BRACKET	1	L72	GA10/3
P19/52A	. . .	CABLE, 'Bowdenite' non-fray, inner	AR	—	GA10/4
B52	. . .	CONDUIT, outer	AR	—	GA10/5
PN980	. . .	FERRULE, plain	2	—	GA10/6
PN3341A	. . .	NIPPLE, spherical	2	—	GA10/7
PN1159	. . .	STOP, plain adjusting	1	—	GA10/8
EA3.80.1291	. . .	WASHER, tapped, radiused	1	S11	GA10/9
EEAS112/6	. . .	CLIP, pipe 1/4" single	4	L16	GA10/10
EA3.80.1237	. . .	LOCK, BOTTOM, ASSEMBLY	1	—	GA10/11
		Spares for:—			
EA3.80.1249	. . .	BRACKET, bottom half	1	140	GA10/12
EA3.80.1250	. . .	BRACKET, bottom half	1	L40	GA10/13
		Attaching parts for EA3.80.1249 and 1250:—			
EA3.80.1255	. . .	Bolt, special	2	S11	GA10/14
A27CP	. . .	Nut, plain 2BA	2	—	GA10/15
SP47C	. . .	Washer, spring 2BA	2	—	GA10/16
EA3.80.1251	. . .	CATCH, bottom	1	DTD124	GA10/17
		Attaching parts for EA3.80.1251:—			
A25/2C	. . .	Bolt, 2BA	1	—	GA10/18
A27CS	. . .	Nut, slotted 2BA	1	—	GA10/19
SP90C7	. . .	Pin, split	1	—	GA10/20
EA3.80.1253	. . .	SPRING	1	Spring Steel	GA10/21
EA3.80.1285	. . .	SADDLE, special	1	DTD124	GA10/22
		Attaching parts for EA3.80.1285:—			
A25/4B	. . .	Bolt, 4BA	1	—	GA10/23
AGS2001B1	. . .	Nut, stiff, 4BA	1	—	GA10/24

AP101B-0402-3A

Page GA.25

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EEAS28/6GR	. . . WASHER, special Attaching parts for EA3.80.1237:	4	L72	GA10/25
A25/2C	. . . Bolt, 2BA	6	—	GA10/26
AGS2001C1/66	. . . Nut, stiff, 2BA	6	—	GA10/27
SP15C	. . . Washer, 2BA	6	—	GA10/28
EA3.80.1231A	. . . PAD, 2" x 1" (Make from 32C/4659939) or two of 32C/4659938)	1	—	GA10/29
EA3.80.1233	. . . SEAT, assembly	1	—	GA10/30
EA3.80.1957	. . . STOWAGE, MAP READER'S SEAT, ASSEMBLY Spares for:	1	—	GA10/31
—	. . . BLOCK, mounting, terry clip (Make from 5F/9400958) (C/Mod/Con/0475/ STC) (Mod.5180)	1	—	
80X2	. . . CLIP, terry ¾" (C/Mod/Con/0475/STC) (Mod.5180)	1	—	
EA3.80.1961	. . . PLATE, front (Pre Mod.5180)	1	L72	GA10/32
EA3.80.1963	. . . PLATE, reinforcing (Pre Mod.5180)	1	L72	GA10/33
EA3.80.1959	. . . STRAP Attaching parts for EA3.80.1957:	1	—	GA10/34
AS1242/4C	. . . Bolt, 2BA	1	—	GA10/35
AGS2001C1/66	. . . Nut, stiff, 2BA	1	—	GA10/36
EA3.80.1235	. . . SUPPORT, MAP READER'S SEAT, ASSEMBLY Spares for:	1	—	GA10/37
EA3.80.1261	. . . ROLLER, GUIDE, ASSEMBLY Spares for:	1	—	GA10/38
EA3.80.1259	. . . BOLT, special	1	S11	GA10/39
EA3.80.1257	. . . ROLLER	1	L40	GA10/40
AS2811/6/020	. . . WASHER, distance Attaching parts for EA3.80.1261:	1	T4	GA10/41
A27EP	. . . Nut, ¾" BSF	1	—	GA10/42
SP47E	. . . Washer, spring ¾"	1	—	GA10/43
AS2811/6/025	. . . WASHER, distance	1	T4	GA10/44
EA3.80.6475	. . . SEATING, PRESSURE CABIN, ASSEMBLY Spares for:	—	—	GA23/1
EA1.80.867	. . . BRACKET, top, pilot's seat rail attachment Attaching parts for EA1.80.867:	2	—	GA23/2
A25/5C	. . . Bolt, 2BA	2	—	GA23/3
A27CP	. . . Nut, 2BA	2	—	GA23/4
EA3.80.1569	. . . Packing, fillet	2	—	GA23/5
EA2.80.5135	. . . BRACKET, pipe clamp, assembly Attaching parts for EA2.80.5135:	1	—	GA23/6
A25/1C	. . . Bolt, 2BA	2	—	GA23/7
SP13C	. . . Washer, 2BA	2	—	GA23/8
MARTIN BAKER MBCJ2587	. . . BREECH-UNIT, and time release (Mod.5244) Attaching parts for MBCJ2587:	1	—	GA23/9
AS1242/13E	. . . Bolt, ¾" BSF, csk. head	2	—	GA23/10
AS1242/17E	. . . Bolt, ¾" BSF, csk. head	1	—	GA23/11
AGS2001E1/77	. . . Nut, ¾" BSF	3	—	GA23/12
SP13E	. . . Washer, ¾" BSF	6	—	GA23/13

R

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
B/MBCJ/1110	. . CARTRIDGE, No.3, Mk.1	1	—	GA23/14
12K9629465	. . CARTRIDGE, set No.13, Mk.1	3	—	GA23/15
EG5.80.177	. . CLAMP, pipe, assembly	1	—	GA23/16
	Attaching parts for EG5.80.177:			
A25/10B	. . Bolt, 4BA	2	—	GA23/17
AGS2001B1	. . Nut, 4BA	2	—	GA23/18
SP13B	. . Washer, 4BA	2	—	GA23/19
AS4525/8C	. . CLIP, support	4	—	GA23/20
	Attaching parts for AS4525/8C:			
A25/1C	. . Bolt, 2BA	1	—	GA23/21
AGS2001C1/66	. . Nut, 2BA	1	—	GA23/22
EEAS239/1A	. . Washer, 'D'	1	L72	GA23/23
R MARTIN BAKER				
C76HC/MB	. . COUPLING, hermeto	2	—	GA27/1
MARTIN BAKER				
MBEU34678	. . GUN, ejection, type 12, Mk.1, navigator and passenger	2	—	GA23/24
MARTIN BAKER				
MBEU34679	. . GUN, ejection, type 10, Mk.1 pilot's	1	—	GA23/25
EA3.80.2869	. . LINE, LEG RESTRAINT AND BRACKETS, NAVIGATOR'S AND BOMB AIMER'S ASSEMBLY	—	—	GA24/1
	Spares for:			
EA3.80.2887	. . BRACKET, SHEAR PIN, NAVIGATOR AND BOMB AIMER, INSTALLATION	—	—	GA24/2
	Spares for:			
EA3.80.2859	. . BRACKET, SHEAR PIN, BOMB AIMER'S ASSEMBLY	—	—	GA24/3
	Spares for:			
R MARTIN BAKER				
A/MBEU3666	. . BRACKET, floor	2	—	GA24/4
	Attaching parts for A/MBEU3666:			
A25/3C	. . Bolt, 2BA	4	—	GA24/5
EA3.80.2889	. . BRACKET, SHEAR PIN, NAVIGATOR'S ASSEMBLY	—	—	GA24/6
	Spares for:			
MARTIN BAKER				
A/MBEU3666	. . BRACKET, floor	2	—	GA24/7
	Attaching parts for A/MBEU3666:			
A25/7C	. . Bolt, 2BA	4	—	GA24/8
AGS2001C1/66	. . Nut, 2BA	4	—	GA24/9
SP13C	. . Washer, 2BA	4	—	GA24/10
AS2809/4/060	. . TUBE, distance	2	—	GA24/11
MARTIN BAKER				
B/MBEU17353	. . LINE, leg restraint	4	—	GA24/12
MARTIN BAKER				
MBEU8921	. . PIN, QR	4	—	GA24/13
EA2.80.5143	. . LINE, LEG RESTRAINT AND BRACKETS, PILOT'S, ASSEMBLY	—	—	GA24/14
	Spares for:			
EG5.80.157	. . BRACKETS, LEG RESTRAINT, ASSEMBLY	—	—	GA24/15
	Spares for:			
MARTIN BAKER				
A/MBEU3666	. . BRACKET, floor	2	—	GA24/16
	Attaching parts for A/MBEU3666:			
A25/9C	. . Bolt, 2BA	4	—	GA24/17

AP101B-0402-3A

Page GA.27

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
MARTIN BAKER B/MBEU17353	.	.	.	.	LINE, leg restraint		2	—	GA24/18
MARTIN BAKER MBEU8921	.	.	.	.	PIN, QR		2	—	GA24/19
EA3.80.6405	.	.	.	.	MECHANISM, SINGLE LEVER, EJECTION, INSTALLATION		—	—	
					Spares for:				
R EA3.80.6411	.	.	.	.	BOLT, special		3	S95	GA25/1
					Attaching parts for EA3.80.6411:				
AGS2001C1/66	.	.	.	.	Nut, stiff, 2BA		1	—	GA25/1A
SP16C	.	.	.	.	Washer, thick, 2BA		1	—	GA25/1B
EA3.80.6409	.	.	.	.	BOX, sealing		1	S510	GA25/2
R EA3.80.6609	.	.	.	.	CABLE, assembly, secondary firing, port side (Pre Mod.5353)		1	—	
					Attaching parts for EA3.80.6609:				
SP121G	.	.	.	.	Collar		1	—	
SP4Z/B4	.	.	.	.	Pin, shackle		1	—	
SP113G5	.	.	.	.	Pin, shear		1	—	
SP90C3	.	.	.	.	Pin, split		1	—	
SP90E7	.	.	.	.	Pin, split		1	—	
SP13C	.	.	.	.	Washer		1	—	
R EA3.80.6695	.	.	.	.	CABLE, secondary firing, port rear seat (Mod.5353)				
					Spares for:				
R MARTIN BAKER MBEU.56016	.	.	.	.	PIN, assembly		1	—	
					Attaching parts for MBEU.56016:				
R SP121/G	.	.	.	.	Collar		1	—	
R SP113/G5	.	.	.	.	Pin, shear		1	—	
R SP90/E7	.	.	.	.	Pin, split		1	—	
					Attaching parts for EA3.80.6695:				
R SP4Z/B4	.	.	.	.	Pin, shackle		1	—	
R SP90/C3	.	.	.	.	Pin, split		1	—	
R SP13/C	.	.	.	.	Washer, 2BA, plain		1	—	
EA3.80.6691	.	.	.	.	CABLE, assembly, secondary firing, starboard side (Mod.5266)		1	—	GA25/3
					Attaching parts for EA3.80.6691:				
SP121B	.	.	.	.	Collar		1	—	GA25/4
SP113B5½	.	.	.	.	Pin, shear		1	—	GA25/5
SP90C5	.	.	.	.	Pin, split		1	—	GA25/6
EA3.80.6425	.	.	.	.	CONDUIT, convoluted, assembly		1	—	GA25/7
					Attaching parts for EA3.80.6425:				
A25/2B	.	.	.	.	Bolt, 4BA		8	—	GA25/7A
AGS2001B1	.	.	.	.	Nut, stiff, 4BA		8	—	GA25/7B
SP15B	.	.	.	.	Washer, 4BA		8	—	GA25/7C
EA3.80.6427	.	.	.	.	CONDUIT, convoluted, assembly		1	—	GA25/8
EA3.80.6407	.	.	.	.	COVER, assembly		2	S515	GA25/9
					Attaching parts for EA3.80.6407:				
A25/2C	.	.	.	.	Bolt, 2BA		10	—	GA25/10
SP15C	.	.	.	.	Washer, 2BA		10	—	GA25/11
EA3.80.6417	.	.	.	.	LEVER, cocking, assembly		2	—	GA25/12
EA3.80.6413	.	.	.	.	LINK, cocking, assembly		1	—	GA25/13
					Attaching parts for EA3.80.6413:				
SP90E3	.	.	.	.	Pin, split		3	—	GA25/13A
SP10E	.	.	.	.	Washer		3	—	GA25/13B

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.81.6531	MECHANISM, SINGLE LEVER, EJECTION, PORT, ASSEMBLY Spares for:	1	—	GA26/1
EA3.81.6553	ARM, cam follower, assembly	1	S61	GA26/2
EA3.81.6043	BODY	1	—	GA26/2A
A25/26C	BOLT, 2BA	3	—	GA26/3
A25/10B	BOLT, 4BA	2	—	GA26/4
AS1242/26C	BOLT, 2BA, csk. head	2	—	GA26/5
AS1242/10B	BOLT, 4BA, csk. head	1	—	GA26/6
EA3.81.6061	BLOCK, guide	1	L64	GA26/7
EA3.81.6063	BLOCK, guide	1	L64	GA26/8
EA3.81.6527	MASK, assembly	1	L16	GA26/9
AGS2002C1	NUT, 2BA	5	—	GA26/10
A27BT	NUT, 4BA	3	—	GA26/11
EA3.81.6067	PIN, locating	2	S1	GA26/12
EA3.81.6069	PIN, cocking	1	S1	GA26/13
SP4Z/A2	PIN, shackle	1	—	GA26/15
SP90C4	PIN, split	2	—	GA26/16
EA3.81.6039	PLATE, back	1	—	GA26/16A
EA3.81.6065	PLATE, mounting assembly	1	—	GA26/16B
EA3.81.6087	PLATE, sealing	1	L72	GA26/17
EA3.81.6551	PLUNGER, cam	1	L64	GA26/18
DOWTY				
1077Z136	RING, retaining micro switch	2	—	GA26/33
EA3.81.6051	ROLLER	1	S61	GA26/19
4104/4/3/16	SCREW, self tapping mush. head	2	—	GA26/19A
EA3.80.6485	SEAR	1	—	GA26/20
EA3.81.6085	SEAL	1	Neoprene	GA26/21
DOWTY				
1077Z138	SHROUD, micro switch cable entry	2	—	GA26/34
EA3.81.6529	SPINDLE, adjusting	1	S1	GA26/22
EA3.81.6041	SPRING	1	DTD5A	GA26/23
EA3.81.6053	SPRING, compression	1	DTD5A	GA26/24
DOWTY				
DN1241Z	SWITCH, microseal	2	—	GA26/25
AS2811/5/235	TUBE, distance	3	—	GA26/26
SP13C	WASHER, 2BA	5	—	GA26/27
SP13B	WASHER, 4BA	3	—	GA26/28
SP13E	WASHER, 1/4"	1	—	GA26/29
EA3.81.6523	MECHANISM, SINGLE LEVER EJECTION STARBOARD, ASSEMBLY Spares for:	1	—	GA26/30
EA3.81.6553	ARM, cam follower, assembly	1	S61	GA26/2
EA3.81.6043	BODY	1	—	GA26/2A
A25/26C	BOLT, 2BA	3	—	GA26/3
A25/10B	BOLT, 4BA	2	—	GA26/4
AS1242/26C	BOLT, 2BA, csk. head	2	—	GA26/5
AS1242/10B	BOLT, 4BA, csk. head	1	—	GA26/6
EA3.81.6061	BLOCK, guide	1	L64	GA26/7
EA3.81.6063	BLOCK, guide	1	L64	GA26/8
EA3.81.6527	MASK, assembly	1	L64	GA26/9
AGS2002C1	NUT, 2BA	4	—	GA26/10
A27BT	NUT, 4BA	3	—	GA26/11
SP90C4	PIN, split	2	—	GA26/16
EA3.81.6067	PIN, locating	2	S1	GA26/12

AP101B-0402-3A

Page GA.29

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA3.81.6069	.	.	.	.	PIN, cocking		1	S1	GA26/13
SP4Z/A2	.	.	.	.	PIN, shackle		1	—	GA26/15
EA3.81.6039	.	.	.	.	PLATE, back		1	—	GA26/16A
EA3.81.6329	.	.	.	.	PLATE, mounting assembly		1	—	GA26/16C
EA3.81.6087	.	.	.	.	PLATE, sealing		1	L72	GA26/17
EA3.81.6551	.	.	.	.	PLUNGER, cam		1	L64	GA26/18
DOWTY									
1077Z136	.	.	.	.	RING, retaining micro switch		2	—	GA26/33
EA3.81.6051	.	.	.	.	ROLLER		1	S61	GA26/19
4104/4/3/16	.	.	.	.	SCREW, self tapping mush, head		2	—	GA26/19A
EA3.81.6085	.	.	.	.	SEAL		1	Neoprene	GA26/21
EA3.80.6485	.	.	.	.	SEAR		1	—	GA26/20
DOWTY									
1077Z138	.	.	.	.	SHROUD, micro switch cable entry		2	—	GA26/34
EA3.81.6529	.	.	.	.	SPINDLE, adjusting		1	S1	GA26/22
EA3.81.6041	.	.	.	.	SPRING		1	DTD5A	GA26/23
EA3.81.6053	.	.	.	.	SPRING, compression		1	DTD5A	GA26/24
DOWTY									
DN1241Z	.	.	.	.	SWITCH, microseal		2	—	GA26/25
AS2811.5.235	.	.	.	.	TUBE, distance		3	—	GA26/26
SP13C	.	.	.	.	WASHER, 2BA		5	—	GA26/27
SP13B	.	.	.	.	WASHER, 4BA		3	—	GA26/28
SP13E	.	.	.	.	WASHER, 1/4" BSF		1	—	GA26/29
A27CT	.	.	.	.	NUT, thin 2BA		4	—	GA25/14A
EA3.80.6463	.	.	.	.	PACKING		1	L72	GA25/14
EA3.80.6415	.	.	.	.	PLATE, peg		1	S510	GA25/15
					Attaching parts for EA3.80.6415:				
A27CT	.	.	.	.	Nut, 2BA		3	—	GA25/16
EEAS1/2C	.	.	.	.	Screw, 2BA, csk. head		3	S96	GA25/17
SP10C	.	.	.	.	Washer, 2BA		3	—	GA25/18
EEAS1/2C	.	.	.	.	SCREW, 2BA, csk. head		4	S96	GA25/19
EEAS1/3C	.	.	.	.	SCREW, 2BA, csk. head		5	S96	GA25/20
EA3.80.6421	.	.	.	.	SEAL, for cover and mechanism		1	Neoprene	GA25/21
EA3.80.6429	.	.	.	.	SEAL, for conduit		1	Neoprene	GA25/22
EA3.80.6419	.	.	.	.	STOWAGE, COCKING LEVER, ASSEMBLY		1	—	GA25/23
					Spares for:				
AS1877/20	.	.	.	.	HINGE		1	—	GA25/24
EA3.80.6451	.	.	.	.	LID		1	L72	GA25/25
EA3.80.6453	.	.	.	.	SPRING		1	DTD187	GA25/26
					Attaching parts for EA3.80.6419:				
AS1248/1C	.	.	.	.	Bolt, 2BA, mush. head		2	—	GA25/27
AGS2001C1/66	.	.	.	.	Nut, 2BA		2	—	GA25/28
SP15C	.	.	.	.	Washer, 2BA		2	—	GA25/29
EA3.80.6431	.	.	.	.	WASHER, packing		2	L72	GA25/30
SP10C	.	.	.	.	WASHER, 2BA		4	—	GA25/30A
MR1/RFD/400	.	.	.	.	PACK, personal survival, M, Mk.2 (Pre Mod.5204)		3	—	GA27/2
MR1/RFD/460	.	.	.	.	PACK, personal survival, 2M, Mk.1 (Mod.5204)		3	—	
15A4177659	.	.	.	.	PARACHUTE, Mk.19 (Pre Mod.5204)		3	—	GA27/3
MR1 IRV646	.	.	.	.	PARACHUTE, S, Mk.18 (Mod.5204)		3	—	
MARTIN BAKER									
MBCJ1765	.	.	.	.	PIPE, assembly		1	—	GA27/4
MARTIN BAKER									
MBCJ1766	.	.	.	.	PIPE, assembly		1	—	GA27/5

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	MARTIN BAKER MBCJ1684	. . PIPE, assembly (Pre Mod.4868)	1	—	GA27/6
	MBCJ2211/1	. . PIPE, assembly (SRIM.3479) (Mod.4868) For Aircraft WJ637 and WJ731	1	—	
	MARTIN BAKER MBEU1902EE	. . RAIL, guide, pilot's Attaching parts for MBEU1902EE:	1	—	GA27/7
	A25/5G	. . Bolt, 5/16" BSF	2	—	GA27/8
	A25/5J	. . Bolt, 3/8"	2	—	GA27/9
	AGS2001G1	. . Nut, 5/16" BSF	2	—	GA27/10
	AGS2001J1	. . Nut, stiff, 3/8" BSF	1	—	GA27/10A
	SP15J	. . Washer, 3/8"	2	—	GA27/12
	MARTIN BAKER MBEU1963EE	. . RAIL, guide, navigator's Attaching parts for MBEU1963EE:	1	—	GA27/13
	A25/5C	. . Bolt, 2BA	1	—	GA27/13A
R	A25/6E	. . Bolt, 1/4" BSF	12	—	GA27/14
	A25/7E	. . Bolt, 1/4" BSF	10	—	GA27/15
	A25/8E	. . Bolt, 1/4" BSF	1	—	GA27/16
	A25/7G	. . Bolt, 5/16" BSF	4	—	GA27/17
	A25/8G	. . Bolt, 5/16" BSF	1	—	GA27/18
	A25/10G	. . Bolt, 5/16" BSF	2	—	GA27/19
	A25/5L	. . Bolt, 7/16"	5	—	GA27/20
	AS1242/6E	. . Bolt, 1/4" BSF, csk. head	1	—	GA27/21
	A27CP	. . Nut, 2BA	1	—	GA27/21A
	AGS2001E1/77	. . Nut, 1/4" BSF	24	—	GA27/22
	AGS2001G1	. . Nut, 5/16" BSF	7	—	GA27/23
	AGS2001L1	. . Nut, 7/16" BSF	5	—	GA27/24
	EA3.80.1569	. . Packing, fillet	1	L72	GA27/24A
	EA3.80.477	. . Packing, fillet	2	L72	GA27/25
	EA3.80.479	. . Packing, fillet	5	L72	GA27/26
	EA3.80.481	. . Packing, fillet	20	L72	GA27/27
	EA3.80.1725	. . Packing	1	DTD683	GA27/28
	EA3.10.2197	. . Packing	1	DTD683	GA27/29
	EA3.10.571	. . Shim, laminated	1	Attewell	GA27/30
	SP15E	. . Washer, 1/4" BSF	20	—	GA27/31
	SP15G	. . Washer, 5/16" BSF	2	—	GA27/32
	SP15L	. . Washer, 7/16" BSF	5	—	GA27/33
	SP16E	. . Washer, 1/4" BSF	4	—	GA27/34
	SP16G	. . Washer, 5/16"	4	—	GA27/35
	MARTIN BAKER MBEU1964EE	. . RAIL, guide, bomb aimer's Attaching parts for MBEU1964EE:	1	—	GA27/36
	A25/5C	. . Bolt, 2BA	1	—	GA27/36A
	A25/4E	. . Bolt, 1/4" BSF	9	—	GA27/37
	A25/5E	. . Bolt, 1/4" BSF	8	—	GA27/38
	A25/6E	. . Bolt, 1/4" BSF	6	—	GA27/39
	A25/9G	. . Bolt, 5/16" BSF	2	—	GA27/40
	A25/5L	. . Bolt, 7/16" BSF	5	—	GA27/41
	AS1242/5E	. . Bolt, 1/4" BSF, csk. head	1	—	GA27/42
	A27CP	. . Nut, 2BA	1	—	GA27/42A
	AGS2001E1/77	. . Nut, 1/4" BSF	24	—	GA27/43
	AGS2001G1	. . Nut, 5/16" BSF	2	—	GA27/44

AP101B-0402-3A

Page GA.31

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
AGS2001L1	. . Nut, 7/16" BSF	5	—	GA27/45
EA3.80.1569	. . Packing, fillet	1	L72	GA27/45A
EA3.80.477	. . Packing, fillet	2	L72	GA27/46
EA3.10.2197	. . Packing	1	L72	GA27/47
EA3.10.571	. . Shim, laminated	1	Attewell	GA27/48
SP15E	. . Washer, 1/4" BSF	20	—	GA27/49
SP15G	. . Washer, 5/16" BSF	2	—	GA27/50
SP15L	. . Washer, 7/16" BSF	5	—	GA27/51
SP16E	. . Washer, 1/4" BSF	4	—	GA27/52
27L1445204	. . SEAT, ejection, type 2CA1, Mk.2	1	—	GA27/53
27L1445205	. . SEAT, ejection, type 2CA2, Mk.4	2	—	GA27/54
EA3.80.1225	. STOWAGE, ASBESTOS GLOVES, ASSEMBLY Spares for:	1	—	GA12/1
NEWAY				
7/7-101	. . FASTENER, snap	1	—	GA12/2
EA3.80.1795	. . STRAP, 2 1/2" wide	1	Blue Webbing	GA12/3
EA3.80.6175	. STOWAGE, BLOCK, PILOT'S EJECTION SEAT SAFETY PINS, ASSEMBLY (MOD.4442) Spares for:	—	—	GA1/10
EA3.80.6547	. . BLOCK, stowage (Mod.4925) Attaching parts for EA3.80.6547:	1	—	GA1/11
AS1242/6C	. . Bolt, 2BA	2	—	GA1/12
EA3.80.6173	. . CLIP	1	—	GA1/13
EA3.80.6669	. STOWAGE, BLOCKS REAR CREW EJECTION SEAT SAFETY PINS, ASSEMBLY (MOD.5103) Spares for:	—	—	GA1/14
EA3.80.6667	. . BLOCK, stowage (Make from EA3.80.6547 Ref.6101183) Attaching parts for EA3.80.6667:	2	—	GA1/15
AS1246/6C	. . Bolt, 2BA	2	—	GA1/16
AGS2001C1/66	. . Nut, 2BA	2	—	GA1/17
SP15C	. . Washer	2	—	GA1/18
EA3.80.2893	. STOWAGE, FIRST AID, INSTALLATION (MOD.3228-S.O.O.) Spares for:	—	—	
EA3.80.2913	. . BRACKET, mounting assembly	1	—	
EA3.80.2899	. . CONTAINER, first aid stowage, assembly Attaching parts for EA3.80.2899:	1	—	
AS1248/4C	. . Bolt, 2BA	2	—	
SP13C	. . Washer	2	—	
EA3.80.6643	. STOWAGE, MAP, PILOT'S INSTALLATION (MOD.5061) Spares for:	—	—	GA13/1
EA3.80.6655	. . STOWAGE, map, pilot's (Make from AS432, Ref. No.25158) Attaching parts for EA3.80.6655:	1	—	GA13/2
AS1248/2C	. . Bolt, 2BA	2	—	GA13/3
AGS2002C1	. . Nut, 2BA	2	—	GA13/4
SP124D	. . Washer	6	—	GA13/5
EA3.83.1	. STOWAGE, PILOT'S PERSONAL EQUIPMENT (PRE Mod.76) Spares for:	—	—	
EA3.83.133	. . STOWAGE	1	—	
—	. STOWAGE, bag, key, flap and bomb door selector safety pins, on crew entrance door (C/Mod/Con/015-Mod.5180)	1	—	GA14/22

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA1.80.899	STOWAGE, HANDLE, EMERGENCY U/C HAND PUMP (MOD.4937) Spares for:	—	—	GA13/10
TERRY No.257-7-8	CLIP	2	—	GA13/11
EA1.80.967	STRAP, BACK, OCCASIONAL SEAT, ASSEMBLY Spares for:	1	—	GA11/1
EA1.80.987	LUG Attaching parts for EA1.80.987:	1	—	GA11/2
A25/3C	Bolt, 2BA	4	—	GA11/3
AGS2001C1/66	Nut, 2BA	4	—	GA11/4
EA1.80.985	Washer, radiused	2	—	GA11/5
EA3.80.2665	STRAP, BACK, ASSEMBLY Spares for:	1	—	GA11/6
AS2394	COLLAR	1	—	GA11/7
EA1.80.971	EYE-BOLT	1	L72	GA11/8
EA1.80.973	PLATE, strap	1	L72	GA11/9
EA1.80.975	PLATE, strap	1	L72	GA11/10
AS2385	TRUNNION, 5/16" BSF	1	—	GA11/11
EA3.80.2681	WEBBING, 40" long x 6½" wide (Proof-load) Attaching parts for EA3.80.2665:	1	—	GA11/12
AVDEL A405	PIN, 'pip'	1	HTS	GA11/13
EA2.83.6081	SUNBLIND, PILOT'S, INSTALLATION (Pre Mod.5408) Spares for:	—	—	
EA3.83.195	BEARING, support, bottom	2	LFS26	GA12/4
EA3.83.197	BEARING, support, top Attaching parts for EA3.83.195 and 197:	2	LFS26	GA12/5
AS1242/13C	Bolt, 2BA	2	—	GA12/6
AGS2002C1	Nut, 2BA	2	—	GA12/7
SP13C	Washer, 2BA	2	—	GA12/8
EB7.83.5359	PLATE, stop, assembly Attaching parts for EG5.83.47:	1	—	GA12/9
A25/4C	Bolt, 2BA	6	—	GA12/10
AGS2002C1	Nut, 2BA	6	—	GA12/11
SP13C	Washer, 2BA	6	—	GA12/12
EA3.82.205	SPRING, compression	1	DTD215	GA12/13
EA2.83.6067	SUNBLIND, PILOT'S, ASSEMBLY Spares for:	1	—	GA12/14
EG5.83.51	BRACKET, stop, port	1	—	GA12/15
EG5.83.53	BRACKET, stop, starboard	1	—	GA12/16
EB7.83.7375	COVER, sunblind	1	—	GA12/17
EA2.83.6079	FRAME, flexible	1	—	GA12/18
EA2.83.6075	FRAME, INNER, ASSEMBLY Spares for:	1	—	GA12/19
EA2.83.6071	FRAME, inner member	1	L65	GA12/20
EA2.83.6073	FRAME, wire	1	DTD215	GA12/21
EG5.83.33	SOCKET, frame, port	1	—	GA12/22
EG5.83.35	SOCKET, frame, starboard	1	—	GA12/23

AP101B-0402-3A

Page GA.33

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG5.83.63	.	HANDLE, control	1	—	GA12/24
EG5.83.45	.	LEVER, assembly, compression spring	1	—	GA12/25
EG5.83.41	.	SHAFT, inner	1	—	GA12/26
EA2.83.6077	.	SOCKET, outer frame, port	1	—	GA12/27
EG5.83.39	.	SOCKET, outer frame, starboard	1	—	GA12/28
EA2.83.6069	.	STAY, outer, port	1	L65	GA12/29
EB7.83.5357	.	STAY, outer, starboard	1	L65	GA12/30
EA3.83.211	.	STIFFENER, 3.7" x 7/16" x 1/16" thick	2	Wovellon	GA12/31
EA3.83.213	.	STIFFENER, 2.8" x 7/16" x 1/16" thick	2	Wovellon	GA12/32
EA3.83.215	.	STIFFENER, 2.6" x 7/16" x 1/16" thick	2	Wovellon	GA12/33
EG5.83.43	.	TUBE, bearing	1	—	GA12/34
EA3.83.201	.	TUBE, spring, housing	1	—	GA12/35
EA3.83.203	.	TUBE, spring, housing	1	—	GA12/36
		Attaching parts for EA3.83.201 and 203:			
AGS899/1	.	Collar	1	—	GA12/37
SP4Y/A4	.	Pin, shackle	1	—	GA12/38
SP90C4	.	Pin, split	1	—	GA12/39
31709	.	SWITCH, FUEL TANK JETTISON, REPOSITIONED (SRIM.3577) (MOD.4937)	—	—	
		Spares for:			
AGS1765/2	.	COVER, spring	1	—	
DO523	.	SWITCH, push	1	—	
5K4329557	.	TRANSFER	1	—	
EA3.80.7021	.	WALL, STARBOARD, INSTALLATION (MOD.4937) (PRE MOD.5204)	—	—	
EA3.80.8021	.	WALL, STARBOARD, INSTALLATION (MOD.5204)	—	—	GA28/1
		Spares for:			
6B4343641	.	AMPLIFIER, type B, G4B compass	1	—	GA28/2
EA3.80.1035	.	BRACKET, mounting assembly, warning horn	1	—	GA28/3
—	.	BRACKET, assembly, inverter mounting, type 100B (Appendix D and E, C/Mod/Con/43) (Mod.4937)	1	—	
EA3.80.929	.	FLOOR, assembly, second navigator	1	—	GA28/4
6A1046812	.	HOLDER, escape drill card (C/Mod/Con/0328/STC) (Mod.5180)	1	—	
EA3.80.7023	.	MOUNTING PLATE FOR BURCOSTAT AND BLANKING PLATES, INSTALLATION (MOD.4937) (PRE MOD.5204)	—	—	
EA3.80.8039	.	MOUNTING BRACKET FOR BURCOSTAT AND BLANKING PLATE, INSTALLATION (MOD.5204)	—	—	GA28/5
		Spares for:			
22943	.	BRACKET, mounting, for burcostat, 18 SWG (SRIM.3867 or 3868) (Mod.5204)	1	L72	GA28/6
		Attaching parts for 22943:			
AS1248/3C	.	Bolt, 2BA	10	—	GA28/7
31907	.	PANEL, blanking (SRIM.3577) (Mod.4937)	1	L72	GA28/8
		Attaching parts for 31907:			
AS1248/3C	.	Bolt, 2BA	6	—	GA28/9
—	.	PLATE, mounting for burcostat (C/Mod/0539/STC, Fig.9) (Mod.5180) (Pre Mod.5204)	1	—	
		Attaching parts for plate:			
AS1248/3C	.	Bolt, 2BA	9	—	

R
R

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mtl. Spec.	Plate No.
	1 2 3 4 5 6			
31932	TRAY (SRIM.3577) (Mod.4937) Attaching parts for 31932:	1	L72	GA28/10
AS1242/6B	Bolt, 4BA	4	—	GA28/11
AGS2001B1	Nut, 4BA	4	—	GA28/12
WT33047/C7	Washer, check	8	—	GA28/13
EA3.81.6395	SWITCH, NAVIGATOR'S HATCH, DETONATOR, ASSEMBLY	1	—	GA28/14
EA3.81.6519	Spares for: FLAP, SPRING, ASSEMBLY, L.H. SWITCH	1	—	GA28/15
EA3.81.6513	Spares for: FLAP (5CW5514, modified)	1	—	GA28/16
EA4.81.1663	FLAP, support	1	—	GA28/17
EA4.81.1659	PIN	1	—	GA28/18
EA4.81.1661	SPRING	1	—	GA28/19
EA3.81.6517	FLAP, assembly, for R.H. switch	1	—	GA28/20
EA6.81.369	PIN, hinge, for R.H. switch flap	1	DTD683	GA28/21
EA1.81.929	SPRING, torsion, for R.H. switch flap	1	—	GA28/22
EA3.81.6497	SWITCH, unit, sub-assembly	1	—	GA28/23
DOWTY				
AS10512C-1	SWITCH, D.P.	2	—	GA28/24
DP1002A	WASHER, locking	8	—	GA28/25
EA3.81.6515	Attaching parts for EA3.81.6395:	1	—	GA28/26
A32A17	Packing	4	—	GA28/27
SP13A	Screw, 6BA	4	—	GA28/28
	Washer	4	—	
15390/014	TRAY, mounting, G4B, amplifier	1	—	GA28/29
AS1248/1E	Attaching parts for 15390/014:	4	—	GA28/30
SP13E	Bolt, 1/2" BSF	4	—	GA28/31
	Washer	4	—	
EA3.80.2007	EQUIPMENT IN PRESSURE CABIN, ASSEMBLY (PRE MOD.4937)	—	—	
EA3.80.6473	Spares for: ACCELEROMETER INSTALLATION (MOD.4158)	—	—	
6A4695406	Spares for: ACCELEROMETER, Mk.2	1	—	
A43B32	Attaching parts for Ref.6A/4695406:	3	—	
	Screw, 4BA	3	—	
EA3.80.6465	BRACKET, mounting	1	L59	
AGS2001B4	Attaching parts for EA3.80.6465:	6	—	
A43B16	Nut, 4BA	6	—	
SP22B	Screw, 4BA	6	—	
	Washer	6	—	
EA3.80.6469	BRACKET, L.H., coaming tube	1	BS267	
EA3.80.6471	BRACKET, R.H., coaming tube	1	BS267	
EA3.83.95	BALLAST, UNDER BOMB AIMER'S RAMP, ASSEMBLY	—	—	
	For spares breakdown see Page GA.1			

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
—	. BALLAST, ADDITIONAL, UNDER CHEST PLATFORM (EA3.84.5635) (MOD.3723-S.O.O.) Spares for:	—	—	
EA3.84.5659	. . . TRAY, BALLAST, ASSEMBLY Spares for:	—	—	
EB6.97.507	. . . BRACKET	1	—	
EB6.10.319	. . . SPIGOT	1	S92	
EB6.10.320	. . . SPIGOT Attaching parts for EB6.10.319 and EB6.10.320:	1	S92	
AS1242/1C	. . . Bolt, 2BA	2	—	
AS1242/7C	. . . Bolt, 2BA	1	—	
AGS2001C1/66	. . . Nut, 2BA	3	—	
EA3.84.5661	. . . TRAY, ballast, engraved	1	—	
EA3.84.5645	. . . WEIGHT, ballast	1	—	
EA3.84.5647	. . . WEIGHT, ballast	2	—	
EA3.84.5649	. . . WEIGHT, ballast Attaching parts for EA3.84.5645, EA3.84.5647 and EA3.84.5649:	1	—	
A59/32E	. . . Bolt, 1/4" BSF	3	—	
A59/38E	. . . Bolt, 1/4" BSF	3	—	
EA3.84.5665	. . . Strap	2	S510	
SP13E	. . . Washer	6	—	
SP16E	. . . Washer	4	—	
EA3.80.1839	. BRACKET, support, accumulator	1	—	
EA3.80.875	. CONSOLE, PILOT'S ASSEMBLY Spares for:	—	—	
EA3.81.1563	. . . PANEL, PILOT'S CONSOLE, EQUIPMENT AND WIRING ASSEMBLY Spares for:	1	—	
5CW4400976	. . . BAR, switch coupling	1	—	
EA2.81.359	. . . BRACKET, plug Attaching parts for EA2.81.359:	1	—	
AGS2001B1	. . . Nut, 4BA	6	—	
A32B12	. . . Screw, 4BA	6	—	
EA3.81.2083	. . . BRACKET, switch, bomb doors Attaching parts for EA3.81.2083:	1	—	
AGS2001A1	. . . Nut, 6BA	2	—	
A32A16	. . . Screw, 6BA	2	—	
EA3.81.1379	. . . BLOCK, fuse assembly (Make from Ref.5X/4491411)	1	—	
EA3.81.1381	. . . BLOCK, fuse, assembly	1	—	
EA3.81.6547	. . . CABLE, assembly, N49D, from jettison switch unit to snatch unit terminal block	1	—	
EA2.81.5907	. . . CABLE, assembly, earth rudder trim switch (Mod 4229)	1	—	
R Uninyvin 12	. . . CABLE, Uninyvin 12	AR	BSG177	
R Uninyvin 16	. . . CABLE, Uninyvin 16	AR	BSG177	
R Uninyvin 20	. . . CABLE, Uninyvin 20	AR	BSG177	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
AGS1600A	.	.	.	.	CABLE, end, eye		5	—	
HV3711	.	.	.	.	CAP, dolly		7	—	
EA1.81.542	.	.	.	.	CARRIER, spare fuse		1	—	
	.	.	.	.	Attaching parts for EA1.81.542:				
AGS2001A1	.	.	.	.	Nut, 6BA		2	—	
A32A16	.	.	.	.	Screw, 6BA		2	—	
EA3.04.15147	.	.	.	.	COVER, assembly (Mod.3796-S.O.O.)		1	—	
EA3.81.375	.	.	.	.	COVER, fuse, compartment		1	—	
	.	.	.	.	Attaching parts for EA3.81.375:				
ODDIE	.	.	.	.					
213	.	.	.	.	Stud		2	—	
214	.	.	.	.	Washer		2	—	
EA3.81.377	.	.	.	.	COVER, SPRING, BOMB JETTISON SWITCH (PRE MOD.5081)		1	—	
	.	.	.	.	Spares for:				
EA3.81.383	.	.	.	.	SPRING, tension		1	DTD215	
5K9573173	.	.	.	.	COVER, spring, fuel tank jettison switch		1	—	
THORN. L1114	.	.	.	.	FILAMENT, 2V, 3.5W		1	—	
AS5	.	.	.	.	FUSE, type S, 5 amp		6	—	
TDA-62-10A	.	.	.	.	FUSE, type S, 10 amp		8	—	
AS20	.	.	.	.	FUSE, type S, 20 amp		2	—	
Z1719	.	.	.	.	GROMMET		4	—	
Z1840	.	.	.	.	GROMMET		1	—	
HV2420A	.	.	.	.	GROMMET, dummy		2	—	
EA3.81.787	.	.	.	.	KNOB, switch, aileron trim		1	DTD683	
	.	.	.	.	Attaching parts for EA3.81.787:				
EA3.81.1089	.	.	.	.	Screw, grub		1	S1	
or	.	.	.	.					
A55A4	.	.	.	.	Screw, grub		1	—	
EA3.81.2077	.	.	.	.	KNOB, switch, bomb doors		1	—	
	.	.	.	.	Attaching parts for EA3.81.2077:				
A31B28	.	.	.	.	Screw, 4BA		1	—	
H2702 RED	.	.	.	.	LAMP, warning, red		1	—	
EEAS71/3	.	.	.	.	LINK, connecting		2	—	
EA3.80.673	.	.	.	.	PANEL, console, bare		1	—	
EA3.04.15143	.	.	.	.	PANEL, mounting, assembly (Mod.3796-S.O.O.)		1	—	
	.	.	.	.	Attaching parts for EA3.04.15143:				
AS1248/1B	.	.	.	.	Bolt, 4BA		6	—	
508-1-06394	.	.	.	.	PLUG, 4 way		2	—	
508-1-06399	.	.	.	.	PLUG, 9 way		1	—	
508-1-06413	.	.	.	.	PLUG, 26 way		2	—	
508-2-11232-002	.	.	.	.	SLEEVE		21	—	
EEAS146/6	.	.	.	.	SLEEVE		10	—	
EEAS146/16	.	.	.	.	SLEEVE		70	—	
HV3254	.	.	.	.	STRAP (Mod.4229)		AR	—	
NY3255	.	.	.	.	STUD (Mod.4229)		12	—	
XD779	.	.	.	.	SWITCH		1	—	
	.	.	.	.	Attaching parts for XD779:				
A32B12	.	.	.	.	Screw, 4BA		2	—	
EEAS28/2HP	.	.	.	.	Washer, packing		2	L16	

AP101B-0402-3A

Page GA.37

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA3.81.2071	.	.	.	.	.	SWITCH, BOMB DOORS (PRE MOD.3728)	1	—	
EA3.81.5851	.	.	.	.	.	SWITCH, BOMB DOORS (MOD.3728)	1	—	
						For spares breakdown see Page GA.4			
						Attaching parts for EA3.81.2071 or EA3.81.5851:			
A31B12	.	.	.	.	.	Screw, 4BA	4	—	
AGS2035B	.	.	.	.	.	Washer, shakeproof	4	—	
EEAS28/2FP	.	.	.	.	.	Washer, spring	4	L16	
R D2710	.	.	.	.	.	SWITCH	1	—	
R XD777	.	.	.	.	.	SWITCH (Mod.4003)	1	—	
						Attaching parts for D2710 and XD777:			
A32B8	.	.	.	.	.	Screw, 4BA	2	—	
SP47B	.	.	.	.	.	Washer	2	—	
EA3.81.6375	.	.	.	.	.	SWITCH, ASSEMBLY, RUDDER TRIM (MOD.4229)	1	—	
						Spares for:			
EA4.81.6801	.	.	.	.	.	KNOB, switch	2	—	
C.W.C.									
EQUIPMENT	.	.	.	.	.	SWITCH, special (XD787 with modified dolly XD827)	1	—	
THOS. HADDON & STOKES									
DP1003	.	.	.	.	.	WASHER, crinkle, 4BA	6	—	
						Attaching parts for EA3.81.6375:			
A32B10	.	.	.	.	.	Screw, 4BA	4	—	
AGS2035B	.	.	.	.	.	Washer	4	—	
SIS3629	.	.	.	.	.	SWITCH	8	—	
						Attaching parts for SIS3629:			
AGS2001A1	.	.	.	.	.	Nut, 6BA	2	—	
A32A16	.	.	.	.	.	Screw, 6BA	2	—	
R SIS3630	.	.	.	.	.	SWITCH	1	—	
D0523	.	.	.	.	.	SWITCH	2	—	
						Attaching parts for SIS3630 and D0523:			
AGS2001A1	.	.	.	.	.	Nut, 6BA	4	—	
A32A16	.	.	.	.	.	Screw, 6BA	4	—	
R D10001 TYPE 8B No.1	.	.	.	.	.	SWITCH	3	—	
						Attaching parts for D10001 TYPE 8B No1			
A32B8	.	.	.	.	.	Screw, 4BA	4	—	
SP47B	.	.	.	.	.	Washer	4	—	
R HC1187RH	.	.	.	.	.	TAG (Mod.4229)	1	—	
HC490	.	.	.	.	.	TAG	3	—	
HC500	.	.	.	.	.	TAG	4	—	
HC510	.	.	.	.	.	TAG	5	—	
R WTD140835	.	.	.	.	.	UNIT, control type 7681 (Mod.3796-S.O.O.)	1	—	
						Attaching parts for WTD140835			
AS1246/1B	.	.	.	.	.	Bolt, 4BA	4	—	
SP15B	.	.	.	.	.	Washer	4	—	
						Attaching parts for EA3.81.1563:			
AS1248/1C	.	.	.	.	.	Bolt, 2BA	17	—	

PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1	2	3	4	5
EA3.81.3083	PANEL, PILOT'S CONSOLE EQUIPMENT AND WIRING ASSEMBLY (MOD.3352-S.O.O. WITH MOD.3428-S.O.O.) Spares for this assembly are identical with those for assembly Part No. EA3.81.1563 on Page GA40, except for the following additions: Add:	1	—	
Uniteril 20	CABLE, Uniteril 20	AR	BSG189	
TD.A62-5A	FUSE, 5 amp	1	—	
10H2071389	HOLDER, fuse	1	—	
508-2-11232-002	SLEEVE	1	—	
EEAS146/20	SLEEVE	6	—	
XD778	SWITCH	1	—	
	Attaching parts for XD778:			
A32B12	Screw, 4BA	2	—	
AGS2035B	Washer	2	—	
HC294	TAG	3	—	
HC490	TAG	1	—	
EA3.80.669	STRUCTURE, PILOT'S CONSOLE ASSEMBLY For spares breakdown see Page GA.4	—	—	
41008	CONSOLE, NAVIGATOR'S, ASSEMBLY (SRIM.3479) (MOD.4868-S.O.O.) For Aircraft WJ637 and WJ731 Spares for:	—	—	
40980	TABLE, NAVIGATOR'S, ASSEMBLY Spares for:	—	—	
22020	CATCH, SUB-ASSEMBLY FOR RAISED POSITION OF FOLDING TABLE Spares for:	1	—	
1A11668	SPRING, compression	1	—	
40979	TABLE, FOLDING SUB-ASSEMBLY Spares for:	1	—	
13780	PIN, table rest	1	—	
EA3.80.2057	CONTAINER, URINE, ASSEMBLY Spares for:	1	—	
HX11761	CONTAINER, Mk.2	1	—	
E20001	FUNNEL	1	—	
EB7.80.327	CURTAIN, BLACK-OUT, ASSEMBLY (MOD.1413) For spares breakdown see Page GA.5	—	—	
EA3.85.15	DESTRUCTOR, MOUNTING, ASSEMBLY For spares breakdown see Page GA.6	1	—	
EA3.80.2009	EQUIPMENT IN NAVIGATOR'S COMPARTMENT, ASSEMBLY Spares for:	—	—	
EB7.80.723	BRACKET, FILTER MOUNTING, INSTALLATION (PRE MOD.861) Spares for:	—	—	
EB7.80.725	BRACKET, mounting, assembly Attaching parts for EB7.80.725:	1	—	
A25/1B	Bolt, 4BA	4	—	
EB7.80.815	BRACKET, FILTER MOUNTING, INSTALLATION (MOD.861) Spares for:	—	—	
EB7.80.817	BRACKET, mounting Attaching parts for EB7.80.817:	1	—	
A25/1B	Bolt, 4BA	4	—	

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EB7.80.807	. . . BRACKET, support	1	—	
A25/1B	. . . Attaching parts for EB7.80.807: Bolt, 4BA	2	—	
EB7.80.811	. . . BRACKET, support	1	—	
A25/1B	. . . Attaching parts for EB7.80.811: Bolt, 4BA	2	—	
EA3.80.2025	. . . EQUIPMENT FORWARD OF TABLE	1	—	
EEAS143/8	. . . Spares for: CLIP, 'P'	1	—	
A25/1B	. . . Attaching parts for EEAS143/8: Bolt, 4BA	1	—	
AGS2001B1	. . . Nut, 4BA	1	—	
SP15B	. . . Washer	1	—	
Z10129	. . . DRIVE, flexible, for A.P.I. repeater unit	1	—	
EEAS132/7	. . . STRAP, cable	2	—	
AS1248/2B	. . . Attaching parts for EEAS132/7: Bolt, 4BA	2	—	
AGS2001B1	. . . Nut, 4BA	2	—	
EEAS73	. . . Plate, clamp	2	—	
SP15B	. . . Washer	2	—	
IN8501	. . . UNIT, repeater, for A.P.I.	1	—	
A25/1C	. . . Attaching parts for IN8501: Bolt, 2BA	3	—	
AGS2001C1/66	. . . Nut, 2BA	3	—	
EA3.80.49	. . . FRAME, receiver, assembly	1	—	
AGS2001E1/77	. . . Attaching parts for EA3.80.49: Nut, 1/4" BSF	4	—	
EA3.80.133	. . . Washer, special	4	—	
EA3.80.2017	. . . INDICATOR, GEE-H AND CONTROL CABLE, ASSEMBLY (PRE MOD.4868)	1	—	
EA3.80.2461	. . . Spares for: BOLT, special	2	—	
EA3.80.2463	. . . CLAMP, toggle assembly	2	—	
A. WELLS CO. H.D.F.M.35	. . . MOUNTING, Equiflex	4	—	
AGS2001J1	. . . Attaching parts for H.D.F.M. 35: Nut, 3/8" BSF	2	—	
SP15J	. . . Washer	2	—	
EA3.80.107	. . . NUT, knurled	2	—	
159/3	. . . MOUNTING, for drive unit, assembly (Pre Mod.4868)	1	—	
A25/10E	. . . Attaching parts for 159/3: Bolt, 1/4" BSF	4	—	
AGS2001E1/77	. . . Nut, 1/4" BSF	4	—	
EA3.80.1323	. . . Washer, special	4	—	
375B2	. . . MOUNTING, for Gee-H transmitter unit, assembly (Pre Mod.1282)	1	—	
A25/1E	. . . Attaching parts for 375/B2: Bolt, 1/4" BSF	16	—	
AGS2001E1/77	. . . Nut, 1/4" BSF	16	—	
EA3.80.411	. . . Washer, special	4	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.80.2023	. . . MOUNTING, A.M.U. CONTROLLER, ASSEMBLY (PRE MOD.4868) Spares for:	1	—	
6B6361962	. . . CONTROL, A.M.U. Mk.4 Attaching parts for Ref.6B/6361962:	1	—	
AS1248/4B	. . . Bolt, 4BA	4	—	
EA3.80.2685	. . . MOUNTING, R.F. UNIT, INSTALLATION Spares for:	1	—	
EA3.80.2709	. . . BRACKET, assembly (Pre Mod.4868) Attaching parts for EA3.80.2709:	4	—	
A25/1C	. . . Bolt, 2BA	4	—	
SP13C	. . . Washer	4	—	
EA3.80.2687	. . . MOUNTING, assembly (Pre Mod.4868)	1	—	
EA3.80.6637	. . . PANEL, NAVIGATOR'S INSTRUMENT, ASSEMBLY (MOD.4859) (Ref. Dwg. EB6.80.5937 and EA3.80.6623) Spares for:	—	—	
KOLLSMAN L83261-04-010	. . . ALTIMETER, Mk.30A (Mod.4859) Attaching parts for L83261-04-010:	1	—	
KOLLSMAN L84380-00-100	. . . Plate, mooring (Mod.4859)	1	—	
A219B36	. . . Screw, 6UNC	4	—	
EA3.80.551	. . . BRACKET, attachment of panel to frame 5 Attaching parts for EA3.80.551:	1	—	
A25/7E	. . . Bolt, 1/4" BSF	1	—	
AGS2001E3	. . . Nut, 1/4" BSF	1	—	
EA3.80.2325	. . . CLIP, assembly	1	—	
EA3.80.2327	. . . CLIP, assembly Attaching parts for EA3.80.2325 and EA3.80.2327:	1	—	
A25/10C	. . . Bolt, 2BA	2	—	
AGS2001C1/66	. . . Nut, 2BA	2	—	
SP13C	. . . Washer	2	—	
6B6341552	. . . COMPASS, indicator, gyro-magnetic, G4B Attaching parts for Ref.6B/6341552:	1	—	
AGS2001C3	. . . Nut, 2BA	3	—	
A40C32	. . . Screw, 2BA	3	—	
5L9959118	. . . FILAMENT (Mod.4859)	2	—	
MRI-1AP-274	. . . HOLDER, deviation card, Mk.4	1	—	
6B6349775	. . . INDICATOR, air position, Mk.1B Attaching parts for Ref.6B/6349775	1	—	
AS4565/9E	. . . Bolt, 1/4" BSF	2	—	
AS4565/31E	. . . Bolt, 1/4" BSF	1	—	
AGS2001E3	. . . Nut, 1/4" BSF	3	—	
SP15E	. . . Washer	3	—	
6A4337742	. . . INDICATOR, air speed, Mk.9HP Attaching parts for Ref.6A/4337742	1	—	
AS4565/1C	. . . Bolt, 2BA	2	—	
AGS2001C3	. . . Nut, 2BA	2	—	

AP101B-0402-3A

Page GA.41

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
5CZ1031243	 INDICATOR, electro-magnetic	1	—	
10QB4698523	 INDICATOR, unit type 208	1	—	
	 Attaching parts for Ref. 10QB4698523:			
A40B12	 Screw, 4BA	2	—	
80/10/0678	 LAMP, pillar, red (Mod.4859)	2	—	
EA3.80.6599	 PANEL, NAVIGATOR'S INSTRUMENT, SUB- ASSEMBLY (MOD.4859) (Ref. Dwg. EA3.80.2301) Spares for:	1	—	
EA3.80.2333	 BRACKET, mounting, for altimeter	1	—	
EA3.80.2305	 BRACKET, mounting, for A.P.I. Attaching parts for EA3.80.2305:	1	—	
AS1246/1C	 Bolt, 2BA	7	—	
AGS2001C1/66	 Nut, 2BA	7	—	
SP15C	 Washer	7	—	
EA3.80.533	 BRACKET, attachment	1	—	
EA3.80.2309	 BRACKET, mounting, for cathode ray tube	1	—	
EA3.80.2313	 BRACKET, mounting, for G4B compass	1	—	
WELLS & CO.				
M.D.S.M.10	 MOUNTING, Equiflex	4	—	
CARR 882	 STUD	2	—	
EA3.80.6559	 PLATE, adaptor, altimeter, 10SWG (Mod.4859) (For aircraft embodying SRIM.3479)	1	L73	
EA3.80.6593	 PLATE, adaptor, altimeter, 10SWG (Mod.4859) (For aircraft embodying SRIMS.3577 and 3676) Attaching parts for EA3.80.6593:	1	L73	
AS1242/1C	 Bolt, 2BA	4	—	
EA3.80.6595	 PLATE, blanking, 18 SWG (Mod.4859) (For aircraft embodying SRIMS.3577 and 3676) Attaching parts for EA3.80.6595:	1	L72	
AS1248/1B	 Bolt, 4BA	4	—	
AGS2001B1	 Nut, 4BA	4	—	
6A1037475	 THERMOMETER, air temperature, S63/112, Form 4 Attaching parts for Ref.6A/1037475	1	—	
A44B16	 Screw, 4BA Attaching parts for EA3.80.6637:	2	—	
A25/7E	 Bolt, 1/4" BSF	1	—	
A25/9E	 Bolt, 1/4" BSF	1	—	
A25/10E	 Bolt, 1/4" BSF	1	—	
A25/11E	 Bolt, 1/4" BSF	1	—	
AGS2001E3	 Nut, 1/4" BSF	1	—	
AGS2002E1-66	 Nut, 1/4" BSF	3	—	
EA3.80.2331	 Piece, distance	4	—	
SP16E	 Washer	1	—	
EA3.80.2013	 TABLE, NAVIGATOR'S, ASSEMBLY (PRE MOD.4868) Spares for:	1	—	
EA3.80.2119	 EYE-BOLT	1	—	
EA3.80.2173	 TABLE, folding, section Attaching parts for EA3.80.2173:	1	—	
EA3.80.2133	 Bolt, pivot	2	—	
AGS2001C1/66	 Nut, 2BA	2	—	
AS2808/5/012	 Piece, distance	2	T35	
EEAS28/36CU	 Washer	2	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EB7.80.685	.	.	.	TRAY, MOUNTING, TRANSMITTER, GEE-H, ASSEMBLY (MOD.1282)			1	—	
				Spares for:					
WELLS & CO. H.D.P.M.15	.	.	.	MOUNTING, Equiflex			4	—	
EB7.80.705	.	.	.	NUT, knurled			2	—	
				Attaching parts for EB7.80.685:					
A25/12J	.	.	.	Bolt			4	—	
A27JP	.	.	.	Nut, 3/8" BSF			4	—	
SP13J	.	.	.	Washer			4	—	
EA3.80.647	.	.	.	WASHER, special			1	—	
EA3.80.651	.	.	.	WASHER, special			2	—	
EEAS28/2CP	.	.	.	WASHER			2	L16	
EA3.80.2741	.	.	.	EQUIPMENT, BOMB AIMER'S, ASSEMBLY			—	—	
				Spares for:					
EA3.80.1035	.	.	.	BRACKET, mounting, assembly			1	—	
EA3.80.929	.	.	.	FLOOR, assembly, bomb aimer's			1	—	
EA3.10.2799	.	.	.	RAMP, for strobe unit			1	—	
EA3.81.6395	.	.	.	SWITCH, HATCH, DETONATOR, ASSEMBLY (MOD.3960)			1	—	
				For spares breakdown see Page GA.37					
EA3.82.9	.	.	.	TRAY, mounting, strobe unit			1	—	
EEAS28/2CP	.	.	.	WASHER, special			1	L16	
EA3.80.2619	.	.	.	E2A, COMPASS, ASSEMBLY			1	—	
				For spares breakdown see Page GA.2					
EA3.80.899	.	.	.	EXTINGUISHER, FIRE, STARBOARD SIDE, ASSEMBLY			—	—	
				For spares breakdown see Page GA.13					
EA3.83.179	.	.	.	FLAP, SWITCH AND UNDERCARRIAGE SWITCH, LOCK, STOWAGE, ASSEMBLY (MOD.1724)			1	—	
				Spares for:					
EA3.83.173	.	.	.	BAG, stowage, for flap switch locking pin (Pre Mod.5081)			1	—	
EA3.83.295	.	.	.	BAG, stowage, for undercarriage switch locking pin			1	—	
EA3.83.175	.	.	.	LOCK, FLAP SWITCH, ASSEMBLY			1	—	
				Spares for:					
AVIATION DEVELOPMENTS A415	.	.	.	PIN, 'pip', quick release			1	—	
EA3.83.299	.	.	.	LOCK, undercarriage switch			1	—	
EA3.80.1989	.	.	.	HANDLE, EMERGENCY HYDRAULIC PUMP, ASSEMBLY			1	—	
				For spares breakdown see Page GA.13					
EA3.80.901	.	.	.	MOUNTING, FIRE-AXE, ASSEMBLY			1	—	
				For spares breakdown see Page GA.13					
EA3.80.1833	.	.	.	MOUNTING, FIRST AID CONTAINER, ASSEMBLY			1	—	
				For spares breakdown see Page GA.14					
EA3.80.317	.	.	.	PANELS, INSTRUMENT, ASSEMBLY			—	—	
				Spares for:					
27H/4605579	.	.	.	MOUNTING, anti-vibration, rubber, 4 lbs (light duty)			6	—	
27H/4605574	.	.	.	MOUNTING, anti-vibration, rubber, 12lbs (medium duty)			6	—	

AP101B-0402-3A		EQUIPMENT AIRCRAFT		Page GA.43	
PRESSURE CABIN EQUIPMENT					
Part Number	Description	No. Off	Matl. Spec.	Plate No.	
	1 2 3 4 5 6				
EA3.80.6635	. . . PANEL, FLYING, ASSEMBLY (MOD 4859) (EA3.80.6155 and EA3.80.2931) Spares for:—	—	—		
KOLLSMAN L82621-04-010	. . . ALTIMETER, Mk. 29B (Mod 4859) Attaching parts for L82621-04-010:—	1	—		
KOLLSMAN L84380-00-100	. . . Plate, mooring	1	—		
A219B36	. . . Screw, 6UNC	4	—		
WB1110S2B	. . . BLOCK, terminal (Mod 3922)	1	—		
EA3.80.361	. . . BRACKET, shock absorber Attaching parts for EA3.80.361:—	1	L72		
A25/1B	. . . Bolt, 4BA	4	—		
AGS2001B4	. . . Nut, 4BA	4	—		
SP15B	. . . Washer	4	—		
EA3.80.357	. . . BRACKET, shock absorber	1	L72		
EA3.80.359	. . . BRACKET, shock absorber Attaching parts for EA3.80.357 and EA3.80.359:—	1	L72		
A25/1B	. . . Bolt, 4BA	6	—		
AGS2001B4	. . . Nut, 4BA	6	—		
SP15B	. . . Washer	6	—		
SIS2802 or	. . . CLOCK, Mk. 4	1	—		
4B or	. . . CLOCK, Mk. 4B	1	—		
SMITH CHX2104	. . . CLOCK, Mk. 5 Attaching parts for CHX2104	1	—		
A44B24	. . . Screw, 4BA	4	—		
16382-0	. . . COMPASS, Gyro Unit Attaching parts for 16382-0	1	—		
A44C24	. . . Screw, 2BA	4	—		
WB1110/2	. . . COVER, terminal block (Mod 3922)	1	—		
A259	. . . FILAMENT, for bridge lamp	2	—		
SP93C6	. . . GROMMET	2	—		
ZA2401-1	. . . GUARD, switch	1	—		
18846-0	. . . HORIZON, artificial	1	—		
SMITH 430FL	. . . INDICATOR, aileron trim	1	—		
9M	. . . INDICATOR, air speed, Mk. 9M Attaching parts for 9M:—	1	—		
AGS2001C4	. . . Nut, 4BA	4	—		
A44C40	. . . Screw, 2BA	4	—		
AS2809/5/070	. . . Tube, distance	4	L62		
DN1245Z-MK1	. . . INDICATOR, electro-magnetic, 24 volt, type A2	1	—		
DN1245 MK14	. . . INDICATOR, electro-magnetic, 24 volt, type C1	1	—		
SMITH 218FL	. . . INDICATOR, flap position	1	—		
KRA1001K or	. . . INDICATOR, rate of climb, Mk. 3Q	1	—		
KAB2004	. . . INDICATOR, rate of climb, Mk. 3P	1	—		

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
SMITH				
431FL	. . . INDICATOR, rudder trim	1	—	
EA3.90.26/1	. . . INDICATOR, special, pilot's (GEE-H)	1	—	
SMITH				
813FL	. . . INDICATOR, tail trim	1	—	
2A	. . . INDICATOR, turn and slip, Mk. 2A	1	—	
80/10/1192	. . . LAMP, bridge, type C (Mod 3922)	1	—	
	Attaching parts for 80/10/1192:—			
A114/4B	. . . Bolt, 6-32 UNC	2	—	
or				
A44B36	. . . Screw, 4BA	2	—	
MI684	. . . MACHMETER, Mk. 2	1	—	
EA3.80.6639	. . . PANEL, SUB-ASSEMBLY (MOD 4859)	1	—	
	Spares for:—			
EA3.80.6557	. . . PLATE, adaptor, 10 SWG	1	L73	
EB6.81.5349	. . . PILLAR, fixing, terminal block (Mod 3922)	2	—	
XD778	. . . SWITCH, type D5406	1	—	
EA3.80.329	. . . PANEL, FIXED, STARBOARD, ASSEMBLY (WITHOUT MOD 5, MOD 3905 AND MOD 4135)	—	—	
	Spares for:—			
6A/4333072	. . . ALTIMETER, cabin, Mk. 18	1	—	
	Attaching parts for Ref. 6A/4333072:—			
A44B20	. . . Screw, 4BA	4	—	
AGS2035B	. . . Washer	4	—	
1240	. . . BLOCK, terminal, type B, 2 way	2	—	
	Attaching parts for 1240:—			
AGS2002A4	. . . Nut, 6BA	2	—	
A45A32	. . . Screw, 6BA	2	—	
UNINYVIN				
20 YELLOW	. . . CABLE, Uninyvin 20	AR	—	
AGS1765-2	. . . COVER, push button, switch	2	—	
L1034	. . . FILAMENT, lamp, 28 volt, 3.5 watt	2	—	
6A/2237916	. . . GAUGE, hydraulic pressure, Mk. 14LL	2	—	
	Attaching parts for Ref. 6A/2237916:—			
A44B20	. . . Screw, 4BA	4	—	
AGS2035B	. . . Washer	4	—	
ZA2401-1	. . . GUARD, locking	1	—	
DN1320Z2	. . . GROMMET (Mod 4939)	1	—	
SMITH				
289FL	. . . INDICATOR, air mixer valve	1	—	
	Attaching parts for 289FL:—			
A44B20	. . . Screw, 4BA	4	—	
AGS2035B	. . . Washer	4	—	
EA3.81.437	. . . LABEL, 'cold and hot'	1	L72	
H2702	. . . LAMP, type H2702, red	2	—	
EA3.80.323	. . . PANEL, fixed (Pre-Mod 292)	1	L72	
EA3.80.1919	. . . PANEL, fixed (Mod 292)	1	L72	
AS10512L2	. . . PLATE, adaptor (Mod 4939)	1	—	
508-1-06399	. . . PLUG, size B, 9-way	1	—	
508-1-06406	. . . PLUG, size C, 14-way	1	—	
ROTAX				
N64799/2	. . . SWITCH, toggle D5403	1	—	
	Attaching parts for N64799/2:—			
A32B12	. . . Screw, 4BA	4	—	
AGS2035B	. . . Washer	4	—	

AP101B-0402-3A		EQUIPMENT AIRCRAFT				Page GA.45	
		PRESSURE CABIN EQUIPMENT					
	Part Number	Description				No. Off	Matl. Spec.
		1	2	3	4	5	6
R	D0523	. . .	SWITCH, push button, type B			2	—
R	A44B12	. . .	Attaching parts for D0523:			4	—
	AGS2035B	. . .	Screw, 4BA			4	—
		. . .	Washer				—
R	XD779	. . .	SWITCH, S.P. (Pre Mod.4939)			1	—
	A32A12	. . .	Attaching parts for XD779:			2	—
	AGS2035A	. . .	Screw, 6BA			2	—
		. . .	Washer				—
	DN1320ZIC-4	. . .	SWITCH, toggle D.P. (Mod.4939)			1	—
	AS10512.M2	. . .	TERMINAL, shroud (Mod.4939)			1	—
	EA3.80.6157	. . .	PANEL, FIXED, STARBOARD, INSTRUMENT, ASSEMBLY (MOD.4135 WITH MOD.5-S.O.O. AND MOD.3905-S.O.O.)			1	—
		. . .	Spares for:				
	6A/4333072	. . .	ALTIMETER, Mk.18			1	—
		. . .	Attaching parts for Ref.6A/4333072:				
	A44B24	. . .	Screw, 4BA			4	—
	AGS2037B	. . .	Washer, shakeproof			4	—
	703-1-00238	. . .	BLOCK, terminal, 5 way			1	—
		. . .	Attaching parts for 703-1-00238:				
	A44B32	. . .	Screw, 4BA			2	—
	EB6.80.615	. . .	Spacer, threaded			2	—
	AGS2037B	. . .	Washer, shakeproof			2	—
R	Unifersil 20	. . .	CABLE, Unifersil 20			AR	BSG189
	HV3711	. . .	CAP, Helvin			1	—
	508-1-07776-003	. . .	CLAMP, cable			1	—
	32A/0119481	. . .	CORD, nylon covered			AR	—
R	AGS1765/2	. . .	COVER, spring, fire button switch			2	—
R	THORN. L1114	. . .	FILAMENT (Pre Mod.5180)			2	—
	5L/9951284	. . .	FILAMENT (SEM/Can/039/STC) (Mod.5180)			2	—
	EA4.81.1687	. . .	FLAP, spring, assembly			1	—
	508-2-07705-200	. . .	GASKET, outlet			1	—
	508-2-07719-200	. . .	GASKET, union			1	—
R	10069 N & Z	. . .	GAUGE, pressure			2	—
	or						
R	SIS 3592	. . .	GAUGE, pressure, Mk.14LL				
		. . .	Attaching parts for SIS3592:				
	AGS2002C4	. . .	Nut, 2BA (Pre Mod.292)			4	—
	6A2710	. . .	Plate, mask			1	—
	A44B24	. . .	Screw, 4BA (Post Mod.292)			4	—
	A44C40	. . .	Screw, 2BA (Pre Mod.292)			4	—
	AS2811/5/065	. . .	Tube, distance (Pre Mod.292)			4	L62
	AGS2037B	. . .	Washer, shakeproof			4	—
	6D/2244063	. . .	GAUGE, pressure, oxygen			2	—
		. . .	Attaching parts for Ref.6D/2244063:				
	A44B24	. . .	Screw, 4BA			4	—
	AGS2037B	. . .	Washer, shakeproof			4	—
R	DN1320Z2	. . .	GROMMET (Mod.4939)			1	—
	6A/4333073	. . .	INDICATOR, air mixer valve			1	—
		. . .	Attaching parts for Ref.6A/4333073				
	A44B24	. . .	Screw, 4BA			4	—
	AGS2037B	. . .	Washer, shakeproof			4	—