

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
AIRCRAFT General Arrangement	EA3.00.1	A.1
CONTROLS ENGINE Engine Controls in Centre Fuselage Engine Controls in Nose Fuselage Engine Controls in Wing, Port Engine Controls in Wing, Starboard	EA1.47.125 EA1.47.5 EA3.47.21	CA.1 CB.1 CC.1 CD.1
CONTROLS FLYING Aileron Controls in Wing, Port Aileron Controls in Wing, Starboard Flap Operating Mechanism, Port Flap Operating Mechanism, Starboard Flying Controls in Centre Fuselage Flying Controls in Cockpit Flying Controls in Rear Fuselage	EA1.45.13 EA1.45.14 EA1.20.701 EA1.20.700 EA3.45.379 EA3.45.3 EA3.45.385	DD.1 DE.1 DF.1 DG.1 DB.1 DA.1 DC.1
ELECTRICAL INSTALLATION Electrical Equipment in Centre Fuselage Electrical Equipment in Front Fuselage (Pre-Mod. 4937) (Pre-Mod.5204) Electrical Equipment in Front Fuselage (Mod. 4937 - S.O.O.) ... Electrical Equipment in Front Fuselage (Mod. 5204 - S.O.O.) ... Electrical Equipment in Rear Fuselage Electrical Equipment in Wing, Port Electrical Equipment in Wing, Starboard	EA3.81.7 EA3.81.5 EA3.81.7005 EA3.81.8005 EA1.81.8 EA3.81.9 EA3.81.10	EA.1 EB.1 EB.1 EB.1 EC.1 ED.1 ED.1
EQUIPMENT GROUND Ground Equipment Transportation Equipment	EA1.88.2	FA.1 FA.7
EQUIPMENT AIRCRAFT Equipment in Pressure Cabin (Mod. 4937) (Pre-Mod. 5204) ... Equipment in Pressure Cabin (Mod. 5204) Equipment in Rear Fuselage	EA3.80.7001 EA3.80.8001 EA3.83.115	GA.1 GA.1 GB.1

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
FUSELAGE Centre Fuselage Centre Fuselage Structure Front Fuselage Rear Fuselage	EA3.00.43 EA1.11.1 EA3.00.5 EA1.00.45	KA.1 KA.3 KB.1 KC.1
MAINPLANES Aileron, Port (Mod.875) Aileron, Starboard (Mod.875) Undercarriage Door, Port Undercarriage Door, Starboard Wing, Port Wing, Starboard Wing Structure, Port Wing Structure, Starboard Wing Tip, Port Wing Tip, Starboard	EA3.24.1 EA3.24.2 EA1.20.10733 EA1.20.10734 EA3.00.11 EA3.00.12 EA3.20.1 EA3.20.2 EA1.00.67 EA1.00.68	LB.1 LB.1 LC.1 LC.1 LA.1 LA.1 LE.1 LE.1 LD.1 LD.1
MISCELLANEOUS ATTACHMENTS Centre Fuselage to Front Fuselage Centre Fuselage to Rear Fuselage Controls to Elevator and Rudder Fin to Fuselage Rear Fairing to Fuselage Rudder to Fin and Fuselage Tailplane to Rear Fuselage Tailplane Sealing Plates Wing to Fuselage, Port Wing to Fuselage, Starboard	EA1.00.23 EA1.00.25 EA1.00.63 EA1.00.55 EA1.00.59 EA1.00.57 EA1.00.53 EA1.00.21 EA1.00.22	N.1 N.1 N.1 N.1 N.2 N.2 N.2 N.2 N.3 N.3
POWER INSTALLATION Engine Cowling, Port Engine Cowling, Starboard Engine Mountings and Attachments, Port Engine Mountings and Attachments, Starboard RA3 Engine Installation, Port RA3 Engine Installation, Starboard	EA1.50.395 EA1.50.396 EA1.51.1 EA1.51.2 EA1.00.103 EA1.00.104	PA.1 PB.1 PC.1 PD.1 PE.1 PF.1

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
RADAR INSTALLATION		
Green Satin and GPI Mk. 4, ARI 5851 (Mod 4868 - S.O.O.) . .	41083	QD.1
I.F.F. Mk. 10 (Mod. 1435) (Pre-Mod. 4868) (Pre-Mod. 4937) . .	EB6.90.211	QA.1
I.F.F./SSR 1520, ARI 23134/3 Corsor (Mod. 4868 - S.O.O.) . .	41002	QA.5
I.F.F./SSR 1520, ARI 23134/3 (Mod. 4937)	EA3.82.7013	QA.5
(Pre-Mod. 5204)		
I.F.F./SSR 1520, ARI 23134/3 (Mod. 5204)	EA3.82.8013	QA.5
Rebecca, ARI 5610 (Pre-Mod. 4868) (Pre-Mod. 4937)	EA3.90.5	QC.1
Tacan, ARI 18107/18 (Mod. 4868 - S.O.O.)	40852	QB.1
(Mod. 4924 - S.O.O.)		
Tacan, ARI 18107/18 (Mod. 4937) (Pre-Mod 5204)	EA3.82.7009	QB.1
Tacan, ARI 18107/18 (Mod. 5204)	EA3.82.8009	QB.1
RADIO INSTALLATION		
I.L.S., ARI 18011 (Mod. 4937) (Pre-Mod. 5204)	EA3.82.7007	RC.10
I.L.S., ARI 18011 (Mod. 5204)	EA3.82.8007	RC.10
Intercomm, ARI 18099 (Mod. 4868 - S.O.O.)	31807	RD.11
Intercomm, ARI 18089 (Mod. 4937) (Pre-Mod 5204)	EA3.82.7003	RD.7
Intercomm, ARI 18089 (Mod. 5204)	EA3.82.8003	RD.7
PTR 175 and Standby U.H.F., ARI 23143 and 23159	41087	RC.5
(Mod. 4868 - S.O.O.)		
PTR 175 and Standby U.H.F., ARI 23143 (Mod 4937)	EA3.82.7005	RC.1
(Pre-Mod. 5204)		
PTR 175 and Standby U.H.F., ARI 23143 (Mod 5204)	EA3.82.8005	RC.1
Radio and Intercomm (Pre-Mod. 4868) (Pre-Mod. 4937)	EA3.82.1	RD.1
Radio and Intercomm (Mod. 3905 - S.O.O.) (Pre-Mod. 4868)	EA3.82.267	RD.1
(Pre-Mod 4937)		
Radio Compass, ARI 23022 (Mod. 1190 - S.O.O.) (Mod. 1191	EA3.82.463	RA.5
- S.O.O.) (Pre-Mod. 4868) (Pre-Mod. 4937)		
Radio Compass, ARI 23023, AD 7092D (Mod. 4937)	EA3.82.7011	RA.1
(Pre-Mod. 5204)		
Radio Compass, ARI 23023, AD 7092D (Mod 5204)	EA3.82.8011	RA.1
Single I.L.S. Twin V.O.R., AD 260, ARI 23118 (Mod. 4868 -	41001	RC.13
S.O.O.)		
U.H.F., ARI 18124/1 (Mod 3905 - S.O.O.) (Pre-Mod. 4868)	EA3.82.227	RC.7
(Pre-Mod. 4937)		

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
SERVICES Air Ventilated Suit in Centre Fuselage (Mod.2717 - S.O.O.) ... Air Ventilated Suit, Mk.2 in Front Fuselage (Mod.2717-S.O.O) ... Cabin Pressure System in Centre Fuselage (Pre Mod.2523) ... Cabin Pressure System in Centre Fuselage (Mod.2523-S.O.O) ... Cabin Pressure System in Front Fuselage (Pre Mod.2523) Cabin Pressure System in Front Fuselage (Mod.2535-S.O.O.) .. Cabin Pressure System in Wing, Port (Pre Mod.2523) Cabin Pressure System in Wing, Port (Mod.2523-S.O.O.) ... Cabin Pressure System in Wing, Starboard (Pre Mod.2523) ... Cabin Pressure System in Wing, Starboard (Mod.2523-S.O.O.) .. C.A.U. System in Bomb Bay (Mod.2523-S.O.O.) Cold Air Supply to Pilot Demisting System Equipment in Inner Wing Leading Edge, Port Equipment in Inner Wing Leading Edge, Port Equipment in Inner Wing Leading Edge, Starboard Equipment in Inner Wing Leading Edge, Starboard Fire Protection System Fuel and Air Delivery Pipes in Wing Tip, Port Fuel and Air Delivery Pipes in Wing Tip, Starboard Fuel System in Centre Fuselage Fuel System in Wing, Port Fuel System in Wing, Starboard Fuel Transfer and Venting from 300 Gallon Tank (Mod.3757 - S.O.O.) Fuel Venting, Frames 30 to 40 Hydraulic equipment in Centre Fuselage (Pre-Mod.2523 - S.O.O.) Hydraulic equipment in Centre Fuselage (Mod.2523-S.O.O.) .. Hydraulic equipment in Front Fuselage Hydraulic equipment in Port Wing Hydraulic equipment in Starboard Wing Oxygen Cylinder Installation Oxygen System Oxygen System - Bomb Aimer Oxygen System - Navigator Oxygen System - Pilot Pitot and Static System in Centre Fuselage Pitot and Static System in Front Fuselage (Pre-Mod.4937) (Pre-Mod.5204) Pitot and Static System in Front Fuselage (Mod.4937-S.O.O.) .. Pitot and Static System in Front Fuselage (Mod.5204-S.O.O.) .. Pitot and Static System in Wing, Port		
	EA3.75.577	SB.39
	EA3.75.575	SB.35
	EA3.75.5	SB.13
	EA3.04.9559	SB.13
	EA3.75.141	SB.1
	EA3.04.9535	SB.1
	EA3.75.7	SB.21
	EA3.04.9547	SB.21
	EA3.75.8	SB.16
	EA3.04.10941	SB.16
	EA3.04.10943	SB.31
	EA3.74.21	SB.33
	EA3.76.215	SD.1
	EA3.00.65	SE.1
	EA3.00.67	SE.3
	EA3.00.66	SE.2
	EA3.00.68	SE.7
	EA1.60.1	SF.1
	EA1.57.257	SG.36
	EA1.57.258	SG.36
	EA3.57.67	SG.1
	EA1.57.727	SG.23
	EA1.57.728	SG.23
	EA3.56.453	SG.38
	EB7.57.293	SG.37
	EA3.73.215	SH.1
	EA3.04.10971	SH.1
	EA3.73.205	SH.24
	EA3.73.539	SH.41
	EA3.73.540	SH.54
	EB6.71.11	SJ.6
	EA3.71.519	SJ.1
	EA3.71.427	SJ.1
	EA3.71.523	SJ.3
	EA3.71.469	SJ.8
	EA3.80.657	SK.1
	EA3.80.2411	SK.2
	EA3.80.7017	SK.2
	EA3.80.8017	SK.2
	EA3.80.659	SK.7

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
TAIL UNIT Rudder and Tab (Pre-Mod. 4478) Rudder and Tab (Mod. 4478) (Pre-Mod. 5043) Rudder and Tab (Mod. 5043) Tailplane and Elevators Tailplane and Elevators	EA3.33.1 EA3.00.1069 EA3.00.5397 EA1.00.19 EA3.00.5473	TA.1 TA.1 TA.1 TB.1 TB.1
TANKS Jettisonable Wing Tip Fuel Tank, 250 Gallon, Port (Pre-Mod. 2395) Jettisonable Wing Tip Fuel Tank, 250 Gallon, Port (Mod. 2395) Jettisonable Wing Tip Fuel Tank, 250 Gallon, Starboard (Pre-Mod. 2395) Jettisonable Wing Tip Fuel Tank, 250 Gallon, Starboard (Mod. 2395) Ventral Fuel Tank, 300 Gallon, Aft Position (Mod. 432 - S.O.O.) Ventral Fuel Tank, 300 Gallon, Forward Position (Mod. 3757 - S.O.O.)	EA3.00.505 EB6.00.347 EA3.00.506 EB6.00.348 EA3.56.453 EA3.57.5041	UA.1 UA.1 UA.1 UA.1 UB.1 UB.3
UNDERCARRIAGE Main Undercarriage Port Main Undercarriage, Starboard Nosewheel	EA1.40.1 EA1.40.2 EA9.40.1	WA.1 WB.1 WC.1

R

