

AP101B-0402-3A

Page EB.1

ELECTRICAL

ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.81.5	ELECTRICAL EQUIPMENT IN FRONT FUSELAGE, ASSEMBLY (PRE MOD.4937) (PRE MOD.5204)	—	—	
EA3.81.7005	ELECTRICAL EQUIPMENT IN FRONT FUSELAGE, ASSEMBLY (MOD.4937 — S.O.O.) (PRE MOD.5204)	—	—	
EA3.81.8005	ELECTRICAL EQUIPMENT IN FRONT FUSELAGE, ASSEMBLY (MOD.5204)	—	—	
EA3.81.6263	Spares for: BOX, DISTRIBUTION, No.1 ASSEMBLY (Used on aircraft not embodying Mod.272) (Alt.R60/118)	1	—	
EA3.81.7159	BOX, DISTRIBUTION, No.1, ASSEMBLY (PRE MOD.4937) (PRE MOD.5204)	1	—	
EA3.81.6671	BOX, DISTRIBUTION, No.1, ASSEMBLY (MOD.4937 — S.O.O.) (PRE MOD.5204)	1	—	
EA3.81.8147	BOX, DISTRIBUTION, No.1, ASSEMBLY (MOD.5204) Spares for:	1	—	EB1/1
EA3.81.1383	BLOCK, fuse, 4 way (Pre Mod.4937) (Pre Mod.5204)	1	—	
EA3.81.7265	BLOCK, fuse, 4 way (Mod.4937 — S.O.O.) (Mod.5204)	1	—	EB1/2
EA3.81.1385	BLOCK, fuse, 4 way (Pre Mod.4937) (Pre Mod.5204)	1	—	
EA3.81.7269	BLOCK, fuse, 4 way (Mod.4937 — S.O.O.) (Mod.5204) Attaching parts for EA3.81.1383, EA3.81.7265, EA3.81.1385 and EA3.81.7269:	1	—	EB1/3
A31B8	Screw, 4BA	2	—	EB1/4
SP47B	Washer, spring, 4BA	2	—	EB1/5
AS2651	BLOCK, terminal, 2 way	1	—	EB1/6
703-1-00249	BLOCK, terminal, 20 way Attaching parts for 703-1-00249:	10	—	EB1/7
A31B24	Screw, cheese head, 4BA	2	—	EB1/8
EA3.81.2917	BOX, shell	1	—	EB1/9
EA3.81.225	BRACKET, fuse block mounting Attaching parts for EA3.81.225:	1	—	EB1/10
A31B16	Screw, 4BA	2	—	EB1/11
EA3.81.801/1	CABLE, ASSEMBLY, F18	1	—	
EA3.81.802/2	CABLE, ASSEMBLY, F25	1	—	
EA3.81.2409/2	CABLE, ASSEMBLY, F26	1	—	
EA3.81.804/2	CABLE, ASSEMBLY, F27	1	—	
EA3.81.805/2	CABLE, ASSEMBLY, F28	1	—	
EA3.81.806/2	CABLE, ASSEMBLY, F29	1	—	
EA3.81.807/2	CABLE, ASSEMBLY, F64 (PRE MOD.5204)	1	—	
EA3.81.6145	CABLE, ASSEMBLY, F64 (MOD.5204)	1	—	
EA3.81.808/2	CABLE, ASSEMBLY, F66	1	—	
EA3.81.809/2	CABLE, ASSEMBLY, F72 (PRE MOD.5204)	1	—	
EA3.81.8171	CABLE, ASSEMBLY, F72 (MOD.5204)	1	—	
508-1-08442-003	CAP, blanking (Pre Mod.4937) (Pre Mod.5204)	2	—	EB1/12
Z115331	CAPACITOR, 0.25 μ F	2	—	EB1/13
Z115333	CAPACITOR	3	—	EB1/14
EA2.81.795	CARRIER, fuse spare Attaching parts for EA2.81.795:	1	—	EB1/15
A27AP	Nut, 6BA	2	—	EB1/16
A31A12	Screw, cheese head, 6BA	2	—	EB1/17