

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R EA3.00.5	NOSE, FUSELAGE, ASSEMBLY (Pre-Mod 5344)	1	—	
R EA3.00.5799	NOSE, FUSELAGE, ASSEMBLY (Spares condition based on EA3.00.5 to LTF standard) (Mod 5344) Spares for:—	1	—	
EA3.74.83	. BLAST, COOLING FOR INVERTER, TYPE 201, ASSEMBLY Spares for:—	—	—	KB1/1
SP144/028	. . CLIP, hose	2	—	KB1/2
EA3.74.77	. . NUT, special	1	L40	KB1/3
EA3.74.71	. . PIPE, to inverter	1	L54	KB1/4
EA3.74.79	. . PIPE, assembly	1	L54	KB1/5
EA3.74.81	. . SLEEVE, pipe, connecting	1	L54	KB1/6
EEAS20/2DU	. . TAB, locking	1	L72	KB1/7
EA3.74.73	. . WASHER, special	1	Langite	KB1/8
	. . WIRE, locking	QR	—	KB1/9
EA3.74.105	. BLAST, COOLING FOR INVERTER, TYPE 200, ASSEMBLY	—	—	KB1/10
SP144/028	. . CLIP, hose	2	—	KB1/11
EA3.74.103	. . PIPE, assembly	1	—	KB1/12
EA3.74.107	. . SLEEVE, pipe, connecting (Make from 32C/1275038)	1	BSF67 Type 1	KB1/13
EEAS20/2DU	. . TAB, locking	1	L72	KB1/14
EA3.74.99	. . WASHER, special	1	Felt	KB1/15
	. . WIRE, locking	QR	—	KB1/16
EA3.75.141	. CABIN, PRESSURE SYSTEM (See Sect. SB)	—	—	
EA3.74.21	. COLD AIR SUPPLY TO PILOT (See Sect. SB)	—	—	
EA3.45.3	. CONTROLS, FLYING IN COCKPIT (See Sect. DA)	—	—	
EA1.47.5	. CONTROL, ENGINE (See Sect. CB)	—	—	
EA3.76.215	. DE-MISTING SYSTEM (MOD 76) (See Sect. SD)	—	—	
EA3.81.5	. ELECTRICAL EQUIPMENT (See Sect. EB)	—	—	

FUSELAGE
FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA3.10.1	.	FRONT FUSELAGE ASSEMBLY	1	—	
EA3.10.6387	.	Spares for:- ALTERATIONS TO NAVIGATORS HATCH LONGERONS AND FORWARD AND AFT MEMBERS (Alt R60/88) Spares for:-	—	—	
EA3.10.6417	.	ANGLE, L.H.	1	—	KB14/1
EA3.10.6418	.	ANGLE, R.H.	1	—	KB14/2
EA3.10.6419	.	ANGLE, L.H.	1	—	KB14/3
EA3.10.6420	.	ANGLE, R.H.	1	—	KB14/4
EA3.10.6421	.	ANGLE, L.H.	1	—	KB14/5
EA3.10.6422	.	ANGLE, R.H.	1	—	KB14/6
EA3.10.6427	.	ANGLE, L.H.	3	—	KB14/7
EA3.10.6428	.	ANGLE, R.H.	3	—	KB14/8
EA3.10.6429	.	ANGLE, L.H.	1	—	KB14/9
EA3.10.6430	.	ANGLE, R.H.	1	—	KB14/10
EA3.10.65	.	ANGLE, L.H.	1	—	KB14/11
EA3.10.66	.	ANGLE, R.H.	1	—	KB14/12
R EA3.10.6395	.	ARCH, forward member (Pre-Mod 5344)	1	—	
R EA3.00.5737	.	ARCH, forward member (Spares for EA3.10.6395) (Mod 5344)	1	—	KB14/13
R EA3.10.6399	.	ARCH, aft member (Pre-Mod 5344)	1	—	
R EA3.00.5735	.	ARCH, aft member (Spares for EA3.10.6399) (Mod 5344)	1	—	KB14/14
EA3.10.561	.	ARM, steady	23	—	KB14/15
EA3.10.173	.	CLEAT	2	—	KB14/16
EA3.10.171	.	CLEAT	2	—	KB14/17
EA3.10.6415	.	DIAPHRAGM, L.H.	1	—	KB14/18
EA3.10.6416	.	DIAPHRAGM, R.H.	1	—	KB14/19
EA3.10.6501	.	DIAPHRAGM, L.H.	1	—	KB14/20
EA3.10.6502	.	DIAPHRAGM, R.H.	1	—	KB14/21
EA3.10.6503	.	DIAPHRAGM, L.H.	1	—	KB14/22
EA3.10.6504	.	DIAPHRAGM, R.H.	1	—	KB14/23
EA3.10.6505	.	DOUBLING, L.H.	1	—	KB14/24
EA3.10.6506	.	DOUBLING, R.H.	1	—	KB14/25
R EA3.10.6389	.	FRAME, bolt, navigator's hatch (Pre-Mod 5344)	1	—	
R EA3.00.5783	.	FRAME, bolt assembly (Spares for EA3.10.6389) (Mod 5344) Spares for:-	1	—	KB14/26
EA3.10.6391	.	BLOCK, corner	2	—	KB14/27
EA3.10.6393	.	BLOCK, corner	2	—	KB14/28
EA3.10.1981	.	BLOCK	30	—	KB14/29
EA3.10.161	.	FRAME, bolt, forward	1	—	KB14/30
EA3.10.163	.	FRAME, bolt, aft	1	—	KB14/31
EA3.10.165	.	FRAME, bolt, L.H.	1	—	KB14/32
EA3.10.166	.	FRAME, bolt, R.H.	1	—	KB14/33
AGS2008/E/1	.	NUT, anchor, 1/4" BSF thin	68	—	KB14/34
EA1.10.1029	.	Bolt, explosive	34	—	KB14/35
EA3.10.6407	.	Bush	21	—	KB14/36
EA3.10.6511	.	Bush	2	—	KB14/37
AGS2002/L/3	.	Nut, stiff, 7/16" BSF	34	—	KB14/38
EA3.10.6411	.	Tube, distance	2	—	KB14/39
EA3.10.6413	.	Tube, distance	21	—	KB14/40

AP101B-0402-3A

FUSELAGE
FRONT FUSELAGE

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	EA3.10.6401	. . . FITTING, forward, L.H.	1	—	KB15/1
R	EA3.10.6403	. . . FITTING, aft, L.H.	1	—	KB15/2
		Attaching parts for EA3.10.6401 and EA3.10.6403:			
R	A59/7E	. . . Bolt, 1/4" BSF	3	—	KB15/3
R	A59/5E	. . . Bolt, 1/4" BSF	4	—	KB15/4
R	A59/3E	. . . Bolt, 1/4" BSF	4	—	KB15/5
R	A25/3C	. . . Bolt, 2BA	5	—	KB15/6
R	A27/CP	. . . Nut, 2BA, plain	5	—	KB15/7
R	A27/EP	. . . Nut, 1/4" BSF, plain	11	—	KB15/8
R	SP124/E	. . . Washer, thin	4	—	KB15/9
R	SP125/E	. . . Washer, thick	4	—	KB15/10
R	SP125/C	. . . Washer, thick	5	—	KB15/11
R	EA3.10.6402	. . . FITTING, forward, R.H.	1	—	KB15/12
R	EA3.10.6404	. . . FITTING, aft, R.H.	1	—	KB15/13
		Attaching parts for EA3.10.6402 and EA3.10.6404:			
R	A59/7E	. . . Bolt, 1/4" BSF	3	—	KB15/14
R	A59/5E	. . . Bolt, 1/4" BSF	4	—	KB15/15
R	A59/3E	. . . Bolt, 1/4" BSF	4	—	KB15/16
R	A25/3C	. . . Bolt, 2BA	5	—	KB15/17
R	A27/CP	. . . Nut, 2BA, plain	5	—	KB15/18
R	A27/EP	. . . Nut, 1/4" BSF, plain	11	—	KB15/19
R	SP124/E	. . . Washer, thin	4	—	KB15/20
R	SP125/E	. . . Washer, thick	4	—	KB15/21
R	SP125/C	. . . Washer, thick	5	—	KB15/22
R	EA3.10.6513	. . . GUSSET, L.H.	1	—	KB15/23
R	EA3.10.6514	. . . GUSSET, R.H.	1	—	KB15/24
R	EA3.10.6433	. . . LONGERON, escape hatch, L.H.	1	—	KB15/25
R	EA3.10.6435	. . . LONGERON, escape hatch, R.H.	1	—	KB15/26
R	EA3.10.45	. . . LONGERON, member, L.H.	1	—	KB15/27
R	EA3.10.46	. . . LONGERON, member, R.H.	1	—	KB15/28
R	EA3.10.6497	. . . PACKING	1	—	KB15/29
R	EA3.10.6499	. . . PACKING	1	—	KB15/30
R	EA3.10.6481	. . . PANEL, skin, L.H.	1	—	KB15/31
R	EA3.10.6482	. . . PANEL, skin, R.H.	1	—	KB15/32
R	EA3.10.515	. . . PANEL, skin	1	—	KB15/33
R	EA3.10.1097	. . . PANEL, skin	1	—	KB15/34
R	EA3.10.503	. . . PANEL, skin	1	—	KB15/35
R	EA3.10.1099	. . . PANEL, skin	1	—	KB15/36
R	EA3.10.519	. . . PANEL, skin	1	—	KB15/37
R	EA3.10.6431	. . . PLATE, tie	1	—	KB15/38
R	EA3.10.6432	. . . PLATE, tie	1	—	KB15/39
R	EA3.10.6515	. . . REINFORCING, L.H.	1	—	KB15/41
R	EA3.10.6516	. . . REINFORCING, R.H.	1	—	KB15/42
R	EA3.10.549	. . . SEAL, pressure	1	—	KB14/41
R	EA3.10.6489	. . . SHIM	2	—	KB15/44
R	EA3.10.6491	. . . SHIM	2	—	KB15/45
R	EA3.10.6493	. . . SHIM	2	—	KB15/46
R	EA3.10.6495	. . . SHIM	2	—	KB15/47
R	EA3.10.6397	. . . STIFFENER, hatch frame	1	—	KB15/48
R	EA3.10.6483	. . . STRAP, butt	2	—	KB15/49
R	EA3.10.6485	. . . STRAP, butt	2	—	KB15/50
R	EA3.10.6487	. . . STRAP, butt	2	—	KB15/51
R	EA3.10.471	. . . WEDGE, packing	10	—	KB15/52

FUSELAGE
FRONT FUSELAGE

AP101B-0402-3A

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA3.10.391	.	ARM, steady, L.H. for escape hatch explosive bolt	1	—	
EA3.10.392	.	ARM, steady, R.H. for escape hatch explosive bolt	1	—	
EA3.10.561	.	ARM, steady, for escape hatch explosive bolt	24	—	
	.	Attaching parts for EA3.10.391, EA3.10.392 or EA3.10.561:			
A61/2C	.	Bolt, 2BA	2	—	
AGS2001C3	.	Nut, 2BA	2	—	
EA3.10.651	.	Shim	QR	—	
EA3.10.2551	.	ARM, steady, L.H. for escape hatch explosive bolt	1	L72	KB5/47
EA3.10.2552	.	ARM, steady, R.H. for escape hatch explosive bolt	1	L72	KB5/48
	.	Attaching parts for EA3.10.2551 or EA3.10.2552:			
A61/3C	.	Bolt, 2BA	2	—	
AGS2001C3	.	Nut, 2BA	2	—	
EA3.10.2549	.	Shim	4	—	
EA3.10.2583	.	ARM, steady, for escape hatch explosive bolt	3	—	
EA3.10.2584	.	ARM, steady, for escape hatch explosive bolt	3	—	
	.	Attaching parts for EA3.10.2583 or EA3.10.2584:			
A61/3C	.	Bolt, 2BA	2	—	
AGS2001C3	.	Nut, 2BA	2	—	
EA3.10.651	.	Shim	QR	—	
EA1.10.1029	.	BOLT, special, explosive, navigator's escape hatch	34	—	KB5/49
EA3.10.6477	.	BOLT, special, securing navigator's escape hatch (Alt. R60/44 — Mod.5097)	66	—	
EA3.10.6165	.	BRACKET, BUTT-CONNECTOR INSTALLATION (MOD.3706 — S.O.O.)	—	—	
	.	Spares for:			
EA3.10.6177	.	BRACKET (Pre. Alt. R60/44)	1	L72	
EA3.10.6131	.	STRIP, sealing (Make from 30B/9611220) (Pre. Alt. R60/44)	1	L72	
EA3.10.2581	.	BRACKET, hinge, port	1	—	KB6/9A
EA3.10.2582	.	BRACKET, hinge, starboard	1	—	KB6/10A
	.	Attaching parts for EA3.10.2581 or EA3.10.2582:			
AS1242/4C	.	Bolt, 2BA	2	—	KB6/9B
AS1242/5C	.	Bolt, 2BA (Alternative to AS1242/4C)	2	—	
AS1242/6C	.	Bolt, 2BA	2	—	KB6/9C
AS1242/7C	.	Bolt, 2BA (Alternative to AS1242/6C)	2	—	
AGS2001C1/66	.	Nut, 2BA	4	—	KB6/9D
SP13C	.	Washer	4	—	KB6/9E
EA1.20.1033	.	Washer, special	4	—	KB6/9F

AP101B-0402-3A

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.10.983	. . BUSH, rubber, for canopy bolt	16	—	KB11/16
EA1.10.1163	. . BUSH, navigator's escape hatch explosive bolt	21	L40	KB5/50
EA1.10.1165	. . BUSH, navigator's escape hatch explosive bolt forward corners only	13	L40	KB5/51
EA3.10.3021	. . CAP, sealing, for escape hatch pivot	2	L40	KB5/52
EA3.10.3019	. . COLLAR, sealing, for escape hatch pivot	2	L65	KB5/53
EA1.10.501	. . DOOR, ACCESS, EQUIPMENT, ASSEMBLY (Supplied to Part No.EA3.00.113 for spares purposes) For Alterations and modifications to door and equipment see Sect. RA (SRIM.1785) (Mod.4937 — S.O.O.) Spares for:	1	—	KB2/1
EA1.10.511	. . . LINK, connecting	2	—	KB2/2
AS2866P	. . . LOCK, L.H. FLUSH TYPE, ASSEMBLY Spares for:	1	—	KB2/3
AS5382	 BOLT, pivot	1	—	KB2/4
AS2558	 BUTTON, pressure, seal	1	—	KB2/5
AS2528	 BUTTON, push outer	1	—	KB2/5A
AS2552	 HANDLE, single handle lock	1	—	KB2/6
FGS50	 KEY	1	—	
FFE4				
AS2532	 PLATE, catch	1	—	KB2/7
AS2530	 PLATE, centre, push button	1	—	KB2/6A
AS2559	 SEAL, handle	1	—	KB2/8
AS5381	 SEAL, push button	1	—	KB2/9
AS2534	 SPRING, for catch	1	—	KB2/10
AS2556	 STUD, spring	1	—	KB2/11
A33B12	Attaching parts for AS2866P: . . . Screw, 4BA	11	—	KB2/13
EA1.10.2423	. . . PANEL, removable	1	—	KB2/14
EA1.10.2421	. . . RING, packing	1	L72	KB2/12
EA1.10.549	. . . ROD, door lock	2	L64	KB2/15
EA1.10.2425	. . . STRIP, sealing, ½" wide (Make from EEAS141/1 Ref.12713)			
EA1.10.1189	. . DOOR, access, hydraulic reservoir	1	L72	KB11/19

FUSELAGE
FRONT FUSELAGE

AP101B-0402-3A

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.00.117	. . . DOOR, main entrance (For A/C WD. 929-931, 933-938, 941-942 and WP.514, supplied with trim allowance) (For non-interchangeable A/C only)	1	—	
EA3.10.1401	. . . DOOR, MAIN ENTRANCE, ASSEMBLY Spares for:	1	—	KB3/1
EA1.10.1145	. . . BOLT, assembly, door, aft	1	—	KB3/2
EA1.10.1143	. . . BOLT, assembly, door forward	1	—	KB3/3
SP4Y/B6	. . . Pin	1	—	KB3/4
EA3.10.2313	. . . FAIRING, handle, internal Attaching parts for EA3.10.2313:	1	—	KB3/5
AS1248/2C	. . . Bolt, 2BA	13	—	KB3/6
EA1.10.1785	. . . HANDLE, door, internal Attaching parts for EA1.10.1785:	1	—	KB3/7
AS1248/2C	. . . Bolt, 2BA	1	—	KB3/8
SP47C	. . . Washer	1	—	KB3/9
SP13C	. . . Washer	1	—	KB3/10
EA3.10.1407	. . . HINGE, ENTRANCE DOOR, ASSEMBLY Spares for:	2	—	KB3/1A
SKEFCO CBS3	. . . BEARING	2	—	KB3/1B
EA3.10.1403	. . . HINGE	1	—	KB3/1C
EA3.10.1405	. . . PIN	1	—	KB3/1D
EA1.10.1733	. . . HOUSING, door, bolt aft Attaching parts for EA1.10.1733:	1	—	KB3/11
A25/2B	. . . Bolt, 4BA	16	—	KB3/12
A27BP	. . . Nut, 4BA	16	—	KB3/13
SP47B	. . . Washer	16	—	KB3/14
EA1.10.1735	. . . HOUSING, door, bolt forward Attaching parts for EA1.10.1735:	1	—	KB3/15
A25/1B	. . . Bolt, 4BA	10	—	KB3/16
A25/2B	. . . Bolt, 4BA	14	—	KB3/17
A27BP	. . . Nut, 4BA	14	—	KB3/18
SP47B	. . . Washer	24	—	KB3/19
EA1.10.1337	. . . LEVER, cranked, aft	1	—	KB3/20
EA1.10.813	. . . LEVER, cranked, forward Attaching parts for EA1.10.1337 and EA1.10.813:	1	—	KB3/21
A25/6C	. . . Bolt, 2BA	1	—	KB3/22
EA1.10.1149	. . . Tube, distance	1	—	KB3/23
EA1.10.821	. . . LINK, coupling, crank lever to door handle Attaching parts for EA1.10.821:	1	—	KB3/24
SP4Y/B4	. . . Pin	2	—	KB3/25
SP13C	. . . Washer	2	—	KB3/26

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AS2864P	. . . LOCK, FLUSH FITTING DOOR, ASSEMBLY Spares for:	1	—	KB3/27
AS5382	 BOLT, pivot	1	—	KB3/28
AS2558	 BUTTON, pressure seal	1	—	KB3/29
AS2528	 BUTTON, push inner	1	—	KB3/29A
AS2549	 HANDLE, outer, double handle lock	1	—	KB3/30
FGS50	 KEY	1	—	
or				
FFE4				
AS2532	 PLATE, catch	1	—	KB3/31
AS2530	 PLATE, centre, push button	1	—	KB3/31A
AS2569	 SEAL, handle	1	—	KB3/32
AS5381	 SEAL, push button	1	—	KB3/33
AS2534	 SPRING, for catch	1	—	KB3/34
AS2556	 STUD, spring	1	—	KB3/35
	Attaching parts for AS2864P:			
AS1248/1B	. . . Bolt, 4BA	4	—	KB3/36
A33B20	. . . Screw, 4BA	11	—	KB3/37
EA1.10.1995	. . . PANEL, access Attaching parts for EA1.10.1995:	1	L72	KB3/38
AS1242/2C	. . . Bolt, 2BA	14	—	KB3/39
AS1248/2C	. . . Bolt, 2BA	30	—	KB3/40
EA3.10.1447	. . . PANEL, dished back Attaching parts for EA3.10.1447:	1	—	KB3/41
AS1248/2C	. . . Bolt, 2BA	1	—	KB3/42
EA1.10.2657	. . . Gasket	1	—	KB3/43
EA1.10.1319	. . . PLATE (bracket), swivel door stop Attaching parts for EA1.10.1319:	1	L72	KB3/44
A27EP	. . . Nut, 1/4" BSF	1	—	KB3/45
SP13E	. . . Washer	1	—	KB3/46
EA1.10.1651	. . . SEAL, door, outer (Make from 32C/652)	1	—	KB3/47
EA3.10.2813	. . . STRAP, support strut, stowage	1	—	KB3/48
EA3.10.1459	. . . TUBE, stay, door prop	1	—	KB3/49
EA1.10.939	. . DOOR, NOSE, UNDERCARRIAGE, PORT, ASSEMBLY (Supplied to Part No.EA3.00.149 for spares purposes) Spares for:	1	—	KB4/1
EA1.10.957	. . . BLOCK, catch Attaching parts for EA1.10.957:	2	—	KB4/2
EA1.10.961	. . . Bolt, special	4	—	KB4/3
EA1.10.963	. . . Shim	1	—	KB4/4
SP47C	. . . Washer	4	—	KB4/5
EA1.10.1367	. . . BRACKET, door, pick-up Attaching parts for EA1.10.1367:	1	—	KB4/6
EA1.10.2707	. . . Bolt, special (Make from A25/3C)	8	—	KB4/7
EA1.10.1369	. . . Shim	1	—	KB4/8

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA1.10.1271	. . . HINGE (Make from AS1880, Ref.28N/9486785)	1	—	KB4/9
EA1.10.1413	. . . HINGE, assembly	1	—	KB4/10
EA1.10.955	. . . PAD	1	Rubber	KB4/11
EA1.10.2467	Attaching parts for EA1.10.955:			
or	. . . Angle	1	—	KB4/12
EA3.10.6377	. . . Angle	1	L72	
EA3.10.3485	. . . Packing	1	—	KB4/13
or				
EA3.10.6383	. . . Packing	1	L72	
A33C32	. . . Screw, 2BA	2	—	KB4/14
EA1.10.949	. . . Shim	1	Light alloy	KB4/15
or				
EA3.10.6381	. . . Shim	1	BACM64	
EEAS6C	. . . Washer	2	—	KB4/16
EA1.10.2655	. . . PAD, stop	1	—	KB4/17
EA1.10.2065	. . . SPUR	1	—	KB4/18
EA3.10.2811	. . . STRIP, sealing (Make from Ref.4756) (Pre Mod.5282)	1	Synthetic Rubber	KB4/19
EA3.10.6583	. . . STRIP, sealing (Make from EEAS844) (26FZ/6147755) (Mod.5282)	1		
AGS2001A1	Attaching parts for EA3.10.2811 and EA3.10.6583			
A33A12	. . . Nut, 6BA	16	—	KB4/20
EA1.10.2513	. . . Strip, securing	1	—	KB4/22
EA1.10.2515	. . . Strip, securing	1	—	KB4/23
EA1.10.940	. . DOOR, NOSE UNDERCARRIAGE, STARBOARD, ASSEMBLY (Supplied to Part No.EA3.00.150 for spares purposes) Spares for:	1	—	KB4/24
EA3.10.3129	. . . BLOCK, door catch	2	—	KB4/25
EA1.10.983	Attaching parts for EA3.10.3129:			
SP47C	. . . Bolt, special	4	—	KB4/26
	. . . Washer, spring	4	—	KB4/27
EA1.10.1367	. . . BRACKET, door, pick-up	1	—	KB4/28
EA1.10.2707	Attaching parts for EA1.10.1367:			
EA1.10.1369	. . . Bolt, special (Make from A25/3C)	8	—	KB4/29
EA1.10.2071	. . . Shim	1	—	KB4/30
	. . . BRACKET, roller	1	—	KB4/31
A25/3C	Attaching parts for EA1.10.2071:			
A27CP	. . . Bolt, 2BA	2	—	KB4/32
EA1.10.2077	. . . Nut, 2BA	2	—	KB4/33
	. . . Washer, special	2	—	KB4/34
EA3.10.3085	. . . BRACKET, spring seating	1	L65	KB4/35
A25/3C	Attaching parts for EA3.10.3085:			
AGS2002C1/66	. . . Bolt, 2BA	2	—	KB4/36
SP16C	. . . Nut, 2BA	2	—	KB4/37
	. . . Washer	2	—	KB4/38
EA1.10.1272	. . . HINGE (Make from AS1880, Ref.28N/9486785)	1	—	KB4/39
EA1.10.1414	. . . HINGE, assembly	1	—	KB4/40

AP101B-0402-3A

FUSELAGE
FRONT FUSELAGE

Page KB.7

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.10.3193	. . . HOOK, door latch, forward Attaching parts for EA3.10.3193:	1	—	KB4/41
EA1.10.971	. . . Pin, pivot	1	—	KB4/42
EA1.45.989	. . . Shim	1	—	KB4/43
EEAS28/23CU	. . . Washer	2	—	KB4/44
EA3.10.3239	. . . HOOK, door latch aft (Mod.1465) Attaching parts for EA3.10.3239:	1	S11	KB4/45
EA3.10.3375	. . . Packing (Mod.1465)	5	L72	KB4/46
EA1.10.971	. . . Pin, pivot	1	—	KB4/47
SP15G	. . . Washer	1	—	KB4/48
EA1.10.955	. . . PAD Attaching parts for EA1.10.955:	1	Rubber	KB4/49
EA1.10.2467	. . . Angle	1	—	KB4/50
EA3.10.6378	. . . Angle	1	L72	
EA3.10.3485	. . . Packing	2	—	KB4/51
EA3.10.6383	. . . Packing	1	L72	
A33C32	. . . Screw, 2BA	2	—	KB4/52
EA1.10.949	. . . Shim	1	Light alloy	KB4/53
EA3.10.6381	. . . Shim	1	BACM64	
EEAS6C	. . . Washer	2	—	KB4/54
EA1.10.1725	. . . PLATE, cover Attaching parts for EA1.10.1725:	1	—	KB4/55
A33B12	. . . Screw, 4BA	2	—	KB4/56
EA3.10.3211	. . . ROD, CONNECTING NOSE UNDERCARRIAGE DOOR HOOKS, ASSEMBLY Spares for:	1	—	KB4/57
EA3.10.3083	 COLLAR, spring, adjusting	1	L65	KB4/58
EA3.10.3207	 FORK-END	1	S96	KB4/59
EA3.10.3213	 FORK-END	1	S96	KB4/60
A27CP	 NUT, 2BA	2	—	KB4/61
A27CPL	 NUT, 2BA	1	—	KB4/62
EA3.10.3209	 ROD	1	S96	KB4/63
EA3.20.2271	 SPRING	1	DTD239A	KB4/64
AGS899/1	. . . Collar	2	—	KB4/65
SP4Y/A7	. . . Pin, shackle	2	—	KB4/66
SP90C4	. . . Pin, split	2	—	KB4/67
EA1.10.2075	. . . ROLLER Attaching parts for EA1.10.2075:	1	—	KB4/68
EA1.10.2073	. . . Pin	1	—	KB4/69
EA3.10.2811	. . . STRIP, sealing (Make from Ref.4756) (Pre Mod.5282)	1	Synthetic Rubber	KB4/70
EA3.10.6583	. . . STRIP, sealing (Make from EEAS844) (26FZ/6147755) (Mod.5282) Attaching parts for EA3.10.2811 and EA3.10.6583:			
AGS2001A1	. . . Nut, 6BA	16	—	KB4/71
A33A12	. . . Screw, 6BA	16	—	KB4/72
EA1.10.2145	. . . Strip, securing	1	—	KB4/73
EA1.10.2515	. . . Strip, securing	1	—	KB4/74

FUSELAGE
FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA1.10.1229	. . .	GUARD, block, pressure cabin door seal	1	—	KB3/53
EA1.10.1153	. . .	HANDLE, main door jettison	1	L72	KB3/50
EA3.00.5325	. . .	HATCH, ESCAPE, NAVIGATOR'S (MOD.4094) (EA3.10.6301) (Pre-Mod 5344) (Supplied for spares purposes with trim allowance) Spares for:	1	—	KB5/1
SIS1564	. . .	BLOCK, terminal, 2 way, type B Attaching parts for SIS1564:	1	—	KB5/2
A33A20	. . .	Screw, 6BA	2	—	KB5/3
EA3.81.5849	. . .	CABLE, ASSEMBLY, N417 Attaching parts for EA3.81.5849:	1	—	KB5/4
A33B6	. . .	Screw, 4BA	4	—	KB5/4A
EA3.10.6109	. . .	CHANNEL, butt connector Attaching parts for EA3.10.6109:	1	—	KB5/5
A25/2C	. . .	Bolt, 2BA	4	—	KB5/6
AGS2001C1/66	. . .	Nut, 2BA	4	—	KB5/7
SP16C	. . .	Washer	4	—	KB5/8
MARTIN BAKER MBEU320EE	. . .	CLIP, stowage, safety harness Attaching parts for MBEU320EE:	4	—	KB5/9
A25/5B	. . .	Bolt, 4BA	4	—	KB5/10
AGS2001B1	. . .	Nut, 4BA	4	—	KB5/11
EA3.10.2277	. . .	Packing	1	—	KB5/12
EA3.10.2281	. . .	Packing	2	—	KB5/13
SP15B	. . .	Washer	4	—	KB5/14
MARTIN BAKER MBEU321EE	. . .	CLIP, stowage, parachute harness Attaching parts for MBEU321EE:	4	—	KB5/15
A25/5B	. . .	Bolt, 4BA	4	—	KB5/16
AGS2001B1	. . .	Nut, 4BA	4	—	KB5/17
EA3.10.6135	. . .	Packing	QR	—	KB5/18
EA3.10.2275	. . .	Packing	QR	—	KB5/19
EA3.10.2279	. . .	Packing	QR	—	KB5/20
SP15B	. . .	Washer	4	—	KB5/21
EA6.10.2683	. . .	CURTAIN	1	—	KB5/22
EA3.80.6659	. . .	EYE-BOLT, starboard side (Mod.5093)	1	S94	KB5/23
EB7.10.5093	. . .	FORK-END, port side Attaching parts for EA3.80.6659 or EB7.10.5093:	1	—	KB5/23A
AGS2001C1/66	. . .	Nut, 2BA	1	—	KB5/24
SP15C	. . .	Washer	1	—	KB5/25

AP101B-0402-3A

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.10.6111	. . . HOLDER, spigot	1	—	KB5/26
A25/4E	. . . Attaching parts for EA3.10.6111:—	2	—	KB5/27
SP16E	. . . Bolt, 1/4" BSF	2	—	KB5/28
	. . . Washer			
R EA3.10.6315	. . . MEMBER, forward, escape hatch, assembly	1	—	KB17/1
	Spares for:—			
R EA3.10.129	 ANGLE	1	—	KB17/2
R EA6.10.1517	 ANGLE	1	—	KB17/3
R EA6.10.1518	 ANGLE	1	—	KB17/4
R EA3.10.123	 BRACKET, stringer (AS4766)	5	—	KB17/5
R EA3.10.124	 BRACKET, stringer (AS4766)	3	—	KB17/6
R EA3.10.127	 BRACKET, stringer	4	—	KB17/7
R EA3.10.6181	 BRACKET, stringer	1	—	KB17/8
R EA3.10.6182	 BRACKET, stringer	1	—	KB17/9
R EA3.10.6317	 FRAME, hatch	1	—	KB17/10
EA3.10.3765	. . . PLATE, blanking	1	—	KB5/29
EA3.10.6275	. . . PLATE, window securing	2	L72	KB5/30
	Attaching parts for EA3.10.6275:—			
EEAS1/1C	. . . Bolt, 2BA	46	—	KB5/31
EEAS1/2C	. . . Bolt, 2BA	2	—	KB5/32
AGS2001C1/66	. . . Nut, 2BA	48	—	KB5/33
SP15C	. . . Washer	48	—	KB5/34
EA3.10.6137	. . . RING, packing	1	—	KB5/35
EA3.10.6121	. . . RING, packing	1	—	KB5/36
EA3.10.6247	. . . RING, packing	1	—	KB5/36A
EA3.20.311	. . . SEAL, aft	1	S/H35	KB5/37
EA3.10.313	. . . SEAL, forward	1	S/H35	KB5/38
EA3.10.309	. . . SEAL, side	2	S/H35	KB5/39
EA3.10.6099	. . . SPIGOT, screwed	2	—	KB5/40
	Attaching parts for EA3.10.6099:—			
A27/JT	. . . Nut, 3/8" BSF	1	—	KB5/41
EA3.10.305	. . . WINDOW, perspex	2	—	KB5/42
	Attaching parts for EA3.10.305:—			
EEAS1/6C	. . . Bolt, 2BA	20	—	KB5/43
AGS2001C1/66	. . . Nut, 2BA	20	—	KB5/44
EA3.10.307	. . . Seal, rubber	2	—	KB5/45
SP15C	. . . Washer	40	—	KB5/46
EA3.10.3481	. . . HOOD COUPE TO FUSELAGE, ASSEMBLY (MOD.519)	—	—	KB6/1
	Spares for:—			
EA3.10.2221	. . . BOLT, special, explosive hood fixing	30	L65	KB6/2
EA3.10.2085	. . . BOLT, special, explosive hood fixing	2	L65	KB6/3
EA1.10.1035	. . . BUSH, coaming tube explosive bolt	31	L40	KB6/4
EA1.10.1167	. . . BUSH, coaming, explosive bolt entry	2	L40	KB6/5
EA1.10.1169	. . . BUSH, coaming, tube explosive bolt entry	30	L40	KB6/6
EA1.10.1435	. . . BUSH, coaming, tube explosive bolt	1	L40	KB6/7
—	. . . COAMING TUBE REPAIR FOR EXPLOSIVE BOLTS	—	—	
	(EA3.03.35, ASD.319.RS and ASD.617.RS)			
	Spares for (per set):—			
EA3.03.47	 BUSH (First Repair)	2	—	
EA3.03.129	 BUSH (Second Repair)	2	—	
EA3.03.297	 BUSH (Third Repair)	2	—	
EA3.03.45	 BUSH, locking (First Repair)	30	—	
EA3.03.127	 BUSH, locking (Second Repair)	30	—	
EA3.03.295	 BUSH, locking (Third Repair)	30	—	
EA3.03.41	 BUSH, tapped (First Repair)	31	—	
EA3.03.125	 BUSH, tapped (Second Repair)	31	—	
EA3.03.291	 BUSH, tapped (Third Repair)	31	—	
EA3.03.43	 BUSH, tapped (First Repair)	1	—	
EA3.03.201	 BUSH, tapped (Second Repair)	1	—	
EA3.03.293	 BUSH, tapped (Third Repair)	1	—	
EA3.03.37	 TUBE, distance	31	—	
EA3.03.39	 TUBE, distance	1	—	

FUSELAGE
FRONT FUSELAGE

AP101B-0402-3A

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R —	. . . HATCH, NAVIGATOR'S ASSEMBLY Comprising:—						—	—	
R EA3.00.5713	. . . HATCH, NAVIGATOR'S (Spares for EA3.10.6301 modified to EA3.10.6461 (Alt. R60/44) (Mod 5344)						1	—	KB16/1
R EA3.00.5793	. . . KIT, LOOSE EQUIPMENT FOR NAVIGATOR'S HATCH (LOOSE EQUIPMENT KIT IS ESSENTIAL REQUIREMENT WITH HATCH) (Mod 5344) Comprising:—								
R TYPE B No. 1	 BLOCK, terminal						1	—	KB16/2
R EEAS1/1C	 BOLT						10	—	KB16/3
R AS1246/1B	 BOLT						6	—	KB16/4
R A25/1B	 BOLT						3	—	KB16/5
R EA3.10.6477	 BOLT, special						68	—	KB16/6
R EA3.81.5849	 CABLE, assembly						1	—	KB16/7
R AS3180/4B	 CLIP, 'P'						3	—	KB16/8
R EA6.10.2683	 CURTAIN						2	—	KB16/9
R EA6.10.2589	 FAIRING, canopy						1	—	KB16/10
R EB7.10.5093	 FORK-END						1	—	KB16/11
R AGS2007C1	 NUT, anchor						10	—	KB16/12
R AGS2001C1	 NUT, stiff						2	—	KB16/13
R AGS2001B1	 NUT, stiff						6	—	KB16/14
R EA3.80.1787	 PLATE						2	L72 x 20 SWG	KB16/15
R AS2230-303	 RIVET						20		KB16/16
R A33A20	 SCREW, hook						8		KB16/17
R EEAS1/2E	 SCREW						2		KB16/18
R A33B6	 SCREW						2		KB16/19
R EA3.10.309	 SCREW						4		KB16/20
R EA3.10.311	 SEAL, rubber (Make from 26FZ/208-EEAS74)						2		KB16/21
R EA3.10.313	 SEAL, rubber (Make from 26FZ/208-EEAS74)						1		KB16/22
R SP15C	 SEAL, rubber (Make from 26FZ/208-EEAS74)						1		KB16/23
R SP15B	 WASHER						2		KB16/24
R	 WASHER						3	—	KB16/25
R	 WIRE, 8" long (For installation details of the above refer to drawings EA3.10.6301 and EA3.10.6461)						4	—	KB16/26

FUSELAGE
FRONT FUSELAGE

[illegible]

FUSELAGE

FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.00.507	. . . HOOD, COUPE, C/W EDGE MEMBER, ASSEMBLY (MOD.519) (For A/C WD.929, 931, 933-938 and WP.514, supplied undrilled, fitment by C.W.P.) (For non-interchangeable A/C only)	1	—	
EA3.00.509	. . . HOOD, COUPE, C/W EDGE MEMBER, ASSEMBLY (EA3.15.125) (MOD.519) Spares for:	1	—	KB6/8
EA3.10.3479	 BRACKET, hinge	1	—	KB6/9
EA3.10.3480	 BRACKET, hinge	1	—	KB6/10
EA6.10.2587	 FAIRING, canopy, forward section	1	—	KB6/11
EA3.15.115	 HOOD, ASSEMBLY Spares for:	1	—	KB6/12
EA1.15.9	 BRACKET, fastener	1	L40	KB6/13
EA1.15.13	 BRACKET, hinge	1	L40	KB6/14
EA3.15.109	 BUSH, rubber	24	—	KB6/15
EA3.15.95	 BUSH, rubber for attachment screws	148	—	KB6/16
EA1.81.689/1	 CABLE, ASSEMBLY, N57A, heated windscreen to coupe break	1	—	KB6/17
R TYPE R No. 3	 PLUG, 2 WAY FLAT TYPE R	1	—	KB6/18
R TYPE R No. 2	 SOCKET 2 WAY FLAT TYPE R	1	—	KB6/19
EA1.15.19	 EYE-BOLT, 2BA	1	DTD126A	KB6/20
EA3.15.129	 LANDING, door, 12 SWG	1	L72	KB6/21
EA1.15.17	 NUT, knurled, 2BA	1	L40	KB6/22
EA3.15.133	 RING, sealing	1	L72	KB6/23
EA3.15.107	 RING, packing	1	DTD838	KB6/24
EA3.15.135	 SEALING, rubber, 1/32" thick	1	S/H30	KB6/25
EA3.15.87	 SEALING, rubber, between edge member and hood, 1/16" x 1 1/4" x 216" long (Make from Ref.32C/4382898)	1	Natural	KB6/26
EA1.15.23	 SPRING, 20 SWG	1	Spring Steel	KB6/27
EA3.15.131	 WASHER, sealing, moulded rubber	1	S/H30	KB6/28

AP101B-0402-3A

FUSELAGE
FRONT FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA3.15.105	.	.	.	.	.	WINDOW, DIRECT VISION, ASSEMBLY (MOD.519) (PRE MOD.4333)	1	—	
EA3.15.139	.	.	.	.	.	WINDOW, DIRECT VISION, ASSEMBLY (MOD.4333) Spares for:	1	—	KB6/29
EA1.15.161	.	.	.	.	.	BRACKET, fastener	1	L40	KB6/30
EA1.15.163	.	.	.	.	.	BRACKET, hinge, c/w bushes	1	L40	KB6/31
EA1.15.173	.	.	.	.	.	PACKING, bracket, fastener	1	—	KB6/32
EA1.15.175	.	.	.	.	.	PACKING, bracket, hinge	1	—	KB6/33
EA3.15.69	.	.	.	.	.	PANEL, c/w elements (Pre Mod.4333)	1	Toughened Glass	
EA3.15.137	.	.	.	.	.	PANEL, c/w elements (Mod.4333)	1	—	KB6/34
EA1.15.151	.	.	.	.	.	PLATE, 16 SWG	1	L73	KB6/35
EA1.15.145	.	.	.	.	.	RING, rubber, insulator	1	S/H40	KB6/36
EA1.15.147	.	.	.	.	.	RING, rubber, sealing	1	S/H40	KB6/37
EA3.15.127	.	.	.	.	.	RING	1	LFS26	KB6/38
EA1.15.155	.	.	.	.	.	RING, sealing	1	Rubber	KB6/39
AH018822/15	.	.	.	.	.	RING, sealing	1	—	
EA1.15.157	.	.	.	.	.	RING, clamping, 20 SWG	1	L72	KB6/40
EA3.15.111	.	.	.	.	.	TERMINAL	4	BSS369	KB6/41
EA3.10.2223	.	.	.	.	.	MEMBER, edge, coupe loud	1	—	KB6/42
EA3.10.3451	.	.	.	.	.	PLATE, attachment, port	1	L72	KB6/43
EA3.10.3453	.	.	.	.	.	PLATE, attachment, starboard	1	L72	KB6/44
EA3.10.3455	.	.	.	.	.	PLATE, attachment, rear	1	L72	KB6/45
EA3.10.3457	.	.	.	.	.	PLATE, attachment, front	1	—	KB6/46
EA3.10.3061	.	.	.	.	.	SHIM, hinge bracket	4	—	KB6/47
EA3.10.3063	.	.	.	.	.	SHIM, hinge bracket	4	—	KB6/48
EA6.10.2679	.	.	.	.	.	STRIP, rubber, for canopy, forward fairing (Make from Ref.32C/4382968)	QR	Linatex	KB6/49
EA3.10.2249	.	.	.	.	.	SEAL, rubber strip, coaming tube to canopy 1/8" x 1 1/4" (Make from Ref.32C/4382961)	QR	Linatex	KB6/50
EA3.10.2251	.	.	.	.	.	SEAL, rubber strip coaming tube to canopy 1/16" x 1 1/4" (Make from Ref.32C/4282898)	QR	Linatex	KB6/51
EA3.10.2245	.	.	.	.	.	TUBE, COAMING, COUPE, ASSEMBLY Spares for:	1	—	KB6/52
EA3.16.5025	.	.	.	.	.	BRACKET, TOP ATTACHMENT GUIDE RAIL, ASSEMBLY (MOD.4151) Spares for:	2	—	KB6/53
EA3.16.5027	.	.	.	.	.	EYE-BOLT Attaching parts for EA3.16.5027: Nut, 1/4" BSF	1	S96	KB6/54
A27EP	.	.	.	.	.	Washer, saddle	1	—	KB6/55
EA1.10.847	.	.	.	.	.	Washer, saddle	1	—	KB6/56
EA1.10.849	.	.	.	.	.	Washer, saddle	1	—	KB6/57
EA1.10.1657	.	.	.	.	.	CLIP, special, top half air drier mounting	4	DTD214	KB6/58
EA1.10.1659	.	.	.	.	.	CLIP, special, bottom half air drier mounting	4	DTD214	KB6/59
EA1.10.1501	.	.	.	.	.	CROSS-TUBE, canopy coaming	1	—	KB6/60
EA1.10.1663	.	.	.	.	.	NUT, special, knurled finger	8	L40	KB6/61
EA3.10.2773	.	.	.	.	.	PLATE, blast	1	L72	KB6/62
EA1.10.847	.	.	.	.	.	WASHER, saddle, special, pilot's seat, rear fixing	2	L40	KB6/63

FUSELAGE
FRONT FUSELAGE

AP101B-0402-3A

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.00.285	. . . KEEL UNIT, ASSEMBLY (REPAIR) (EA3.10.17) Spares for:	—	—	KB7/1
EA3.11.655	. . . BOLT, special (Make from A25/4E)	4	—	KB7/2
EA3.00.947	. . . BRACKET, support (EA3.10.79) (Alt. R60/314)	1	—	
EA3.00.948	. . . BRACKET, support (EA3.10.80) (Alt. R60/314)	1	—	
EA3.10.885	. . . DOOR, probe, access Attaching parts for EA3.10.885:	1	—	KB7/3
AS1248/1C	. . . Bolt, 2BA	12	—	KB7/4
—	. . . SKINNING, PRESSURE CABIN KEEL UNIT ASSEMBLY (EA3.10.11) Spares for:	—	—	KB7/5
R —	 DELETION OF K AERIAL (EA3.10.6615) (MOD.5223) Spares for:	—	—	
R EA3.10.6535	 CLEAT	1	L73 x 18 SWG	
R EA3.10.6519	 PANEL, skin, starboard	1	L72 x 20 SWG	
R EA3.10.6521	 PANEL, skin, port	1	L72 x 20 SWG	
R EA3.10.6533	 STRAP, butt, 10.5" approx.	1	L73 x 18 SWG	
R EA3.10.6527	 STRINGER, port, outboard (Make from EEDX68, Ref.26FZ/4475, 19" long approx.)	1	EEDX68	
R EA3.10.6525	 STRINGER, port, inboard, (Make from EEDX68, Ref.26FZ/4475, 28" long approx.)	1	EEDX68	
R EA3.10.6523	 STRINGER, centre (Make from EEDX68, Ref.26FZ/4475, 28" long approx.)	1	EEDX68	
R EA3.10.6531	 STRINGER, starboard, outboard, (Make from EEDX68, Ref.26FZ/4475, 19" long approx.)	1	EEDX68	
R EA3.10.6529	 STRINGER, starboard, inboard, (Make from EEDX68, Ref.26FZ/4475, 28" long approx.)	1	EEDX68	
R EA3.10.2373	 PANEL, skin, starboard (Pre Mod.5223)	1	—	
R EA3.10.2371	 PANEL, skin, port (Pre Mod.5223)	1	—	
R EA1.10.829	 PLUG, drain, assembly Consisting of:	1	—	KB7/6
EA1.10.827	 HOUSING	1	L40	KB7/7
SP90E6	 PIN, split (Pre Alt. R60/48)	1	—	KB7/8
ANGUS				
OR.12	 RING, sealing	1	—	KB7/9
EA1.10.825	 SCREW, special	1	L40	KB7/10

AP101B-0402-3A

Page KB.13

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.10.9	 STRUCTURE, MAIN FLOOR PRESSURE CABIN KEEL UNIT, ASSEMBLY	—	—	KB7/11
EA3.10.2383	 Spares for: BOLT, special, bracket mounting	4	S11	KB7/12
EA1.10.217 or EA1.10.219 EA1.10.218 or EA1.10.220 EA1.10.2685	 BRACKET MOUNTING, NOSEWHEEL PIVOT SHAFT, ASSEMBLY, L.H.	1	—	KB7/13
	 BRACKET MOUNTING, NOSEWHEEL PIVOT SHAFT, ASSEMBLY, R.H.	1	—	KB7/24
	 Spares for: CAP	1	—	KB7/14
A26/15J	 Attaching parts for EA1.10.2685: Bolt	2	—	KB7/15
A27JS	 Nut	2	—	KB7/16
SP90C7	 Pin, split	2	—	KB7/17
EA3.10.2793	 Washer	2	L65	KB7/18
SP21	 NIPPLE	1	—	KB7/19
EA1.10.217A	 SPIGOT	1	S96	KB7/20
A25/4E	 Attaching parts for EA1.10.217 or EA1.10.218: Bolt, 1/4" BSF	10	—	KB7/21
A25/6E	 Bolt, 1/4" BSF	2	—	KB7/22
EA3.10.2383	 Bolt, special	2	S11	KB7/23
EA3.10.37	 BULKHEAD, PRESSURE, ASSEMBLY	—	—	KB7/25
EA9.10.5091	 Spares for: BRACKET, FORWARD LATCH ASSEMBLY (MOD.2183)	1	—	KB7/26
EA3.10.1739	 Spares for: BLOCK	1	—	KB7/27
A25/25E	 Attaching parts for EA3.10.1739: Bolt, 1/4" BSF	2	—	KB7/28
A27ET	 Nut, 1/4" BSF	2	—	KB7/29
AS2811/6/135	 Tube, distance	2	L62	KB7/30
EA1.10.1429	 PLATE	1	—	KB7/31
A45C16	 Attaching parts for EA1.10.1429: Screw, 2BA	2	—	KB7/32
EA1.10.1431	 Shim	QR	—	KB7/33
EA9.10.5093	 PLATE, side	1	—	KB7/26A
EA9.10.5095	 PLATE, side	1	—	KB7/26B
EB6.80.5949	 BRACKET, TRIP ROD, BOMB AIMER'S SEAT, INSTALLATION (MOD.4058)	—	—	
EB6.80.5947	 BRACKET, TRIP ROD, NAVIGATOR'S SEAT (MOD.4058)	—	—	
EB6.80.5951	 Spares for: BRACKET	1	L65	
EB6.80.5955	 BRACKET	3	L65	
EA3.10.6335	 BRACKET, torque switch (Mod.3960)	1	—	
NORMLAIR 504600	 CONNECTOR, ground pressurising (Mod.632)	1	—	KB7/34
EEAS69/2	 GASKET, sealing	2	—	KB7/34B
EA1.81.943	 STUD, mounting, assembly	8	—	KB7/35
EA3.81.1165	 STUD, mounting, assembly	2	—	KB7/36
EA1.10.231	 BUSH	1	DTD127	KB7/37