

CANBERRA B Mk. 6

Page 873

RADAR FRONT FUSELAGE

Ref. No.	Part No.	Description						No off	Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.90.127	RADAR, FRONT FUSELAGE, GROUP (MOD. 1435)									
		Spares for:—									
34446	E.A3.90.315	CABLE, ASSEMBLY, IF.I, FROM CODER CONTROL UNIT TO PRESSURE BULKHEAD, GROUP (MOD. 2372)						1			
		Consisting of:—									
5E/9100030	†	Cable, miniature, 12A						QR		C	
33C/	†	Compound						QR		C	
10H/0970111	Z.62237	Gasket, union						1		C	
10H/0970059	Z.60668	Outlet, gasket						1		C	
10H/0970065	CZ.49182	Outlet, straight						1		C	
10H/0560360	CZ.49458	Plug						1		C	
10H/0970091	Z.62231	Ring, sealing						1		C	
10H/0970099	Z.54092	Ring, thrust						1		C	
5K/9107065	EEAS.146/A	Sleeve, 1" long						24		C	
5K/9107068	EEAS.146/E	Sleeve, 1" long						4		C	
	HELLERMANN										
5K/	No. 3	Sleeve, rubber, 1" long						1			
98E/8850/	CA.3106ES/	Socket						1		B	
351550	20/275										
	E.A3.90.325	CABLE, ASSEMBLY, IF.I, FROM CONTROL UNIT AND I.P. SWITCH TO PRESSURE BULKHEAD, GROUP (MOD. 2544)						1			
		Consisting of:—									
5E/3080	†	Cable, Septopren 6						QR		C	
5E/4183	†	Cable, Uninyvin 20						QR		C	
10H/0970292	CZ.69733	Clamp, cable						1		C	
10H/0970108	Z.62235	Gasket, union						1		C	
10H/0970111	Z.62237	Gasket, union						1		C	
10H/0970069	CZ.49181	Outlet, angle						1		C	
10H/0970058	Z.60667	Outlet, gasket						1		C	
10H/0970059	Z.60668	Outlet, gasket						1		C	
10H/0970065	CZ.49182	Outlet, straight						1		C	
10H/0970088	Z.62229	Ring, sealing						1		C	
10H/0970091	Z.62231	Ring, sealing						1		C	
10H/0970096	Z.49037	Ring, thrust						1		C	
10H/0970099	Z.54092	Ring, thrust						1		C	
5K/9107065	EEAS.146/A	Sleeve, 1" long						14		C	
5K/9107069	EEAS.146/E	Sleeve, 1" long						2		C	
10H/0560120	CZ.49017	Socket, free						1		C	
10H/0560180	CZ.49126	Socket, free						1		C	
5K/9107065	HV.3254	Strapping						QR		C	
5K/9107065	HV.3255	Stud						9		C	
	E.A3.90.329	CABLE, ASSEMBLY, EARTH, FROM DETONATOR EARTH TERMINAL, F.8 to I.P. SWITCH, GROUP (MOD. 2544)						1			
		Consisting of:—									
5E/4183	†	Cable, Uninyvin 20						QR		C	
5X/9400382	†	Lug, 4 BA						1		C	
5K/9107065	EEAS.146/A	Sleeve, 1" long						2		C	

RADAR FRONT FUSELAGE

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.B6.90.205	PANEL, CONTROL, INSTALLATION	—	—	—	
		Spares for:—				
	E.B6.90.133	PANEL, CONTROL, ASSEMBLY	1	—	—	
		Spares for:—				
	E.B6.90.213	CABLE, ASSEMBLY, I.F.7, FROM TERMINAL BLOCK F7 (PORT SIDE) TO I.F.F. MASTER SWITCH, GROUP	1	—	—	
		Consisting of:—				
5E/4185	†	Cable, Uninyvin 16	QR	—	C	
5K/9107066	EEAS.146/A1	Sleeve, ½" long	4	—	C	
5K/9107067	EEAS.146/C	Sleeve, ½" long	2	—	C	
5X/9400063	Z.19925	Tag, quick release	2	—	C	
5X/9400064	Z.19980	Thimble, quick release	2	—	C	
	E.B6.90.135	Panel, assembly	1	—	—	
10L/16192	S.I.S.6426	Unit, control, type 927	1	—	A	
10F/	N.S.F. Z.510583	Switch	1	—	—	
—	—	INSTALLATION OF A.R.I.5610 (REBECCA) (E.B6.90.5)	—	—	—	
		Spares for:—				
37549	E.B6.90.243	Cover, switch aerial (Mod. 1444)	1	—	C	
	E.A3.90.129	INSTALLATION OF T.X. PROBE AERIAL	—	—	—	
		Spares for:—				
5X/1878	Z.1841	Grommet	1	—	C	
10H/18411	†	Holder, probe	1	—	C	
28S/9710019	A55/A2	Screw, grub	2	—	C	
28S/9419435	A31/B12	Screw, 4 BA	4	—	C	
4536	E.A3.90.127	Tube, probe, assembly	1	—	C	
	E.B6.90.227	AERIAL CAVITY RE-CONVERSION (REBECCA) (NOT REQUIRED WHEN FLIGHT COM- PUTOR IS INSTALLED) (MOD. 1447)	—	—	—	
		Spares for:—				
26456	E.B6.90.235	Angle (Made from EEJ.98/20G, Ref. 26FZ/20648)	1	—	C/MR	
26453	E.B6.90.229	Angle, forward (Made from EEJ.98/20G, Ref. 26FZ/20648)	1	—	C/MR	
26457	E.B6.90.237	Diaphragm, centre	1	L.72	C/MR	
26455	E.B6.90.233	Plate, blanking, rear	1	L.72	C/MR	
26454	E.B6.90.231	Plate, front	1	L.72	C/MR	
26458	E.B6.90.239	Plate, top	1	L.72	C/MR	
	E.B6.90.281	Plug, stowage	1	L.64	—	

CANBERRA B. Mk. 6

Page 875

RADAR CENTRE FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M	
		1 2 3 4 5 6				
	E.B6.90.129	RADAR, CENTRE FUSELAGE, GROUP (MOD. 1435)	—	—	—	
	E.B6.90.157	Spares for:— AERIAL, UPPER, INSTALLATION	1	—	—	R.1
		Spares for:—				
10B/20275	†	Aerial, OMNI, type 100B	1	—	A	R.1
26569	E.B6.90.175	Block, packing	1	L.65	C	R.1
	E.B6.90.173	Mounting, assembly	1	—	—	R.1
26573	E.B6.90.167	Seal, aerial, $\frac{1}{8}$ " Linatex	1	DTD. 900-4195	C	R.1
26572	E.B6.90.165	Seal, skin, $\frac{3}{4}$ " Linatex	1	DTD. 900-4195	C	R.1
1438562	E.A3.90.313	CABLE, ASSEMBLY, I.F.10, FROM PRESSURE BULK- HEAD TO CODER, GROUP (MOD. 2372)	1	—	B	
		Consisting of:—				
5E/9100030	†	Cable, miniature, 12A	QR	—	C	
10H/18035	M.S.3057/12	Clamp	1	—	C	
10H/0970111	Z.62237	Gasket, union	1	—	C	
10H/0970059	Z.60668	Outlet, gasket	1	—	C	
10H/0970065	CZ.49182	Outlet, straight	1	—	C	
10H/20958	M.S.3108A/20/27P	Plug	1	—	B	
10H/0970091	Z.62231	Ring, sealing	1	—	C	
10H/0970099	Z.54092	Ring, thrust	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, $\frac{1}{2}$ " long	24	—	C	
5K/9107069	EEAS.146/E	Sleeve, $\frac{1}{2}$ " long	4	—	C	
10H/0560180	CZ.49126	Socket	1	—	C	
39997	E.A3.90.327	CABLE, ASSEMBLY, I.F.1A, FROM RECEIVER TRANSMITTER TO PRESSURE BULK- HEAD (MOD. 2544)	1	—	B	
		Consisting of:—				
5E/3080	†	Cable, Septopren 6	QR	—	C	
10H/18032	M.S.3057/10	Clamp, cable	1	—	C	
10H/0970111	Z.62237	Gasket, union	1	—	C	
10H/0970059	Z.60668	Outlet, gasket	1	—	C	
10H/0970065	CZ.49182	Outlet, straight	1	—	C	
10H/20957	M.S.3108/18/1P	Plug	1	—	B	
10H/0560360	CZ.49458	Plug, free	1	—	C	
10H/0970091	Z.62231	Ring, sealing	1	—	C	
10H/0970099	Z.54092	Ring, thrust	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, $\frac{1}{2}$ " long	14	—	C	
5K/9107069	EEAS.146/F	Sleeve, $\frac{1}{2}$ " long	3	—	C	
	E.B6.90.207	FAIRLEAD, INSTALLATION, GROUP	1	—	—	
		Spares for:—				
26565	E.B6.90.209	Fairlead, half	2	—	C	

Restricted

[illegible]

CANBERRA B Mk. 6

Page 877

RADAR REAR FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. C.M.	Plate No.
		1 2 3 4 5 6				
	E.B6.90.131	RADAR, REAR FUSELAGE, GROUP (MOD. 1435) ...	—	—	—	
		Spares for:—				
	E.B6.90.159	AERIAL, LOWER, INSTALLATION ...	1	—	—	R.1
		Spares for:—				
10B/20275	†	Aerial, OMNI, type 100B ...	1	—	A	R.1
26571	E.B6.90.163	Block, packing ...	1	L65	C	R.1
26570	E.B6.90.161	Mounting, assembly ...	1	—	—	R.1
26573	E.B6.90.167	Seal, aerial, $\frac{1}{8}$ " Linatex ...	1	DTD. 900-4195	C	R.1
26572	E.B6.90.165	Seal, skin, $\frac{3}{4}$ " Linatex ...	1	DTD. 900-4195	C	R.1
	E.B6.90.215	CABLE, ASSEMBLY, IF.8, FROM ALTITUDE SWITCH TO IFF, J.B., GROUP (PRE-MOD. 2593)	1	—	—	
		Spares for:—				
SE/3079	†	Cable, Quinpren 6 ...	QR	—	C	
33H/56	†	Cement, Bostik ...	QR	—	C	
32B/498	†	Cord, waxed coreless ...	QR	4F35	C	
5K/87	AGS.1658/0	Nut, cable, gland ...	1	—	C	
10H/0970058	Z.60667	Outlet, gasket ...	1	—	C	
10H/0970069	CZ.49181	Outlet, angle ...	1	—	C	
10H/0970088	Z.62229	Ring, sealing ...	1	—	C	
10H/0970096	Z.49037	Ring, thrust ...	1	—	C	
5K/9107066	EEAS.146/A1	Sleeve, $\frac{1}{2}$ " long ...	8	—	C	
5K/9107068	EEAS.146/D1	Sleeve, 1" long ...	2	—	C	
5K/34	AGS.1688/2	Sleeve, slotted ...	1	—	C	
10H/0560120	CZ.49017	Socket, free, Mk. 4 ...	1	—	C	
5X/9450396	†	Tag, quick release, terminal ...	4	—	C	
10H/0970108	Z.62235	Union, gasket ...	1	—	C	
26562	E.B6.90.217	CABLE, ASSEMBLY, IF.2, FROM IFF TRANSMITTER RECEIVER UNIT AT 82/APX-6 TO IFF, J.B., GROUP	1	—	—	
		Spares for:—				
SE/3079	†	Cable, Quinpren 6 ...	QR	—	C	
33H/56	†	Cement, Bostik ...	QR	—	C	
08E-8850						
100910	AN.3057/6	Clamp, cable ...	1	—	C	
5K/87	AGS.1658/0	Nut, cable, gland ...	1	—	C	
5935-99-940-						
3077	AH.3108/14S/55	Socket ...	1	—	B	
5K/9107065	EEAS.146/A	Sleeve, $\frac{1}{2}$ " long ...	5	—	C	
5K/9107066	EEAS.146/A1	Sleeve, $\frac{1}{2}$ " long ...	5	—	C	
5K/9107068	EEAS.146/D1	Sleeve, 1" long ...	2	—	C	
5K/34	AGS.1688/2	Sleeve, slotted ...	1	—	C	
5X/9450396	†	Tag, quick release, terminal ...	5	—	C	
32B/498	†	Thread, waxed linen ...	QR	—	C	
	E.B6.90.219	CABLE, ASSEMBLY, IF.3, FROM AERIAL SWITCH UNIT TO IFF, J.B., GROUP	1	—	—	
		Spares for:—				
SE/4183	†	Cable, Uninyvin 20 ...	QR	—	C	
33H/56	†	Cement, Bostik ...	QR	—	C	
10H/0970108	Z.62235	Gasket, union ...	1	—	C	
5K/87	AGS.1658/0	Nut, cable, gland ...	1	—	C	
10H/0970069	CZ.49181	Outlet, angle ...	1	—	C	

RADAR
REAR FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No
10H/0970039	Z 60667	O-ring, gasket ...	1	—	C	
10H/0970102	Z 49040	Ring, compression ...	1	—	C	
10H/0970096	Z 49037	Ring, thrust ...	1	—	C	
10H/0970114	Z 62240	Sleeve, cable ...	1	—	C	
5K/9107063	EEAS.146/A	Sleeve, 1" long ...	3	—	C	
5K/9107066	EEAS.146/A	Sleeve, 1" long ...	3	—	C	
5K/9107068	EEAS.146/D	Sleeve, 1" long ...	2	—	C	
5K/33	AGS 1688/1	Sleeve, slotted, type I ...	1	—	C	
10H/0560100	CZ.49015	Socket, free, Mk. 4, 3-way ...	1	—	C	
5K/9450396		Tag, quick release, terminal ...	3	—	C	
32B/498	†	Thread, waxed linen ...	QR	—	C	
36691	E.A3.90.311	CABLE, ASSEMBLY, IF.9, FROM CODER TO TRANSMITTER RECEIVER, GROUP (MOD. 2372)	1	—	—	
		Spares for:—				
12 5100311		Cable, miniature, 12F ...	QR	—	C	
10H/16032	MS.3057/10	Clamp ...	1	—	C	
10H/16035	MS.3057/12	Clamp ...	1	—	C	
10H/1700194	Z.50780	Clip, holding ...	2	—	C	
10H/17160	16/4/0040	Cord, flexible, braided ...	QR	—	C	
10H/120928	MS.1108A/20/27P	Ring ...	1	—	B	
5K/9107063	EEAS.146/A	Sleeve, 1" long ...	18	—	C	
5K/9107070	EEAS.146/H	Sleeve, 1" long ...	4	—	C	
10H/13495	MS.106B/18/1	Socket ...	1	—	B	
5K/7012	MC.312	Tag, ring, tongue ...	2	—	C	
	E.B6.90.187	ARMED, AERIAL INSTALLATION, GROUP	1	—	—	
		Spares for:—				
26566	E.B6.90.197	Bracket, attachment ...	4	S.3	C	
26567	E.B6.90.189	Guard, aerial, assembly ...	1	—	C	
	E.B6.90.99	MOUNTING FOR IFF, J.B. AND SWITCH UNIT, GROUP	1	—	—	
		Spares for:—				
	E.B6.90.151	BOX, IFF JUNCTION, ASSEMBLY (PRE-MOD. 2593)	1	—	—	
		Spares for:—				
	E.B6.90.303	Box, junction ...	1	—	—	
26584	E.B6.90.199	COVER, ASSEMBLY	1	—	B	
		Spares for:—				
33H/56	†	Cover, Rostik ...	QR	—	C	
SCW/4860	Z.A.2404	Guard, switch ...	1	—	B	
32368	E.A9.81.4357	Screw ...	4	—	C	
32C/614	†	Strip, rubber, synthetic, 0"14 dia. ...	QR	DTD.552	C	
SCW/5624	†	Switch ...	1	—	B	
1066	EEAS.28/2CU	Washer, 4 BA ...	8	DTD.124	C	
1108	EEAS.42	Washer, leather, 0"05 thick ...	4	—	C	
	E.B6.90.1097	BOX, IFF JUNCTION, ASSEMBLY (MOD. 2593)	1	—	—	
		Spares for this assembly are identical with those for assembly Part No. E.B6.90.151				

CANBERRA B Mk. 6

Page 879

RADAR REAR FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
10F/17424	S.I.S.6425	Switch, unit, aerial type 2160 (Pre Mod. 3221) ...						1	—	B	
10F/19511	†	Switch, unit, aerial type T.6850 (Mod. 3221) ...						1	—	B	
	E.B6.90.51	TRAY STRUCTURE, INSTALLATION, GROUP ...						—	—	—	
		Spares for:—									
	E.B6.90.719	MOUNTING, SUB-ASSEMBLY (MOD. 3244) ...						1	—	—	
		Spares for:—									
	E.B6.90.111	Angle ...						2	—	—	
5K/3410	AS.3360/C3E	Bonding, 3 flex, 2BA, 1/4" BSF ends ...						2	—	C	
10AJ/162	S.I.S.5674	Mounting, A.V. ...						4	—	B	
32662	E.B6.90.721	Nut, retaining, assembly ...						2	—	C	
10A/17930	S.I.S.5669	Washer, check ...						4	—	C	
10AJ/646	†	Mounting ...						1	—	B	
32555	E.A3.90.309	Piece, packing ...						4	LFS.23-26	C	
	TEDDINGTON										
5CW/	TYPE P.A.D.	Switch, altitude (Pre Mod. 2593) ...						1	—	—	

CANBERRA B Mk. 6

Page 881

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description	No off	Matl. Spec	Cl. of Equip		Plate No.
					M R	L M	
		1 2 3 4 5 6					
	E.B6.82.5	RADIO AND INTER-COMM IN FRONT FUSELAGE, ASSEMBLY	—	—	—	—	
		Spares for:—					
	E.B6.82.13	INSTALLATION OF V.H.F. SUPPRESSED AERIALS	—	—	—	—	
		Spares for:—					
4506	E.A4.82.99	Bracket, connector, 12 SWG	2	BSS.265		B	
2491	E.A6.82.69	Strip, connecting, c/w plug 10H/9113	2	—		B	
8527	E.A6.82.73	Washer, special	2	BSS.265		C	
	E.A3.82.143	INSTALLATION OF V.H.F. RELAY PANEL	—	—	—	—	
		Spares for:—					
8524	E.A3.82.145	PANEL, GROUP	1	—		B	
		Spares for:—					
	E.A1.82.117	Bracket, push button	1	L.72		—	
5E/3098	†	Cable, Duprenmet 6	QR	—		C	
5E/3038	†	Cable, Unipren 6	QR	—		C	
5E/3042	†	Cable, Unipren 24	QR	—		C	
	E.A1.82.121	Label, "Terminal identification"	1	L.72		—	
	E.A3.82.147	Label, "Terminal mic/tel identification"	1	L.72		—	
5K/9107065	EEAS.146/A	Sleeve, 3/4" long	32	—		C	
5K/9107068	EEAS.146/D	Sleeve, 1" long	2	—		C	
5X/6240	E.A1.81.429	Terminal, earth	1	—		C	
	E.B6.82.173	I.L.S., GROUP (MOD. 1444)	—	—	—	—	
		Spares for:—					
	E.B6.82.159	BOX ATTENUATOR, INSTALLATION	—	—	—	—	
		Spares for:—					
	E.B6.82.161	BOX, ATTENUATOR, GROUP	1	—		—	
		Spares for:—					
	E.B6.82.169	Case	1	L.59		—	
	E.B6.82.163	Piece, distance	4	L.65		—	
32C/	E.B6.82.167	Seal, 1/8" Linatex	1	—		—	
5071	E.A6.10.2181	Packing, cork	4	—		C	
4202	E.A3.81.1165	Stud, mounting	4	—		C	
	E.B6.82.187	CABLE, ASSEMBLY, R.T.1, FROM ATTENUATOR BOX TO PRESSURE BULKHEAD AND JB.154, I/C RELAY PANEL, GROUP	1	—	—	—	
		Consisting of:—					
5E/3038	†	Cable, Unipren 6	QR	—		C	
5E/3098	†	Cable, Duprenmet 6	QR	—		C	
5E/3040	†	Cable, Uniprenmet 6	QR	—		C	
5E/3042	†	Cement, Bostik	QR	—		C	
10H/	CZ.69733	Clamp, cable	1	—		—	
5X/2040	†	Coupling, unit	1	—		C	
10H/0970068	Z.60667	Gasket, outlet	1	—		C	
10H/	†	Gasket, union	1	—		C	
10H/0970069	CZ.49181	Outlet	1	—		C	
10H/0970096	Z.49037	Ring, thrust	1	—		C	
5K/2609	AGS.1651/12	Sleeve, type 1	1	—		C	
5K/9107066	EEAS.146/A1	Sleeve, 1/2" long	28	—		C	
5K/9107067	EEAS.146/C	Sleeve, 3/4" long	2	—		C	
5K/9107068	EEAS.146/D	Sleeve, 1" long	1	—		C	
5K/9107069	EEAS.146/G	Sleeve, 1 1/2" long	2	—		C	

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
10H/3162	†	Socket, type W.492	1	—	B	
10H/0560120	CZ.49017	Socket	1	—	C	
32B/498	†	Thread, waxed linen No. 18	QR	—	C	
28W/9419480	SP.15/P	Washer	1	—	C	
5E/3141	†	Wire, tinned copper, 32 SWG	QR	—	C	
	E.B6.82.189	CABLE, ASSEMBLY, R.T.1A, FROM ATTENUATOR BOX TO VOLUME CONTROL, GROUP	1	—	—	
		Consisting of:—				
5E/3038	†	Cable, Unipren 6	QR	—	C	
10H/	CZ.69733	Clamp, cable	1	—	—	
5K/27	AGS.1651/4	Ferrule, cut	1	—	C	
10H/0970058	Z.60667	Gasket, outlet	1	—	C	
10H/	—	Gasket, union	1	—	C	
5K/87	AGS.1658/1	Nut, gland	1	—	C	
10H/0970069	CZ.49181	Outlet, angle	1	—	C	
10H/0549290	—	Plug, Mk. 4, 4 way	1	—	C	
10H/0970088	Z.62229	Ring, sealing	1	—	C	
10H/0970096	Z.49037	Ring, thrust	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, 1/2" long	8	—	C	
5K/9107068	EEAS.146/D	Sleeve, 1/2" long	3	—	C	
32A/	—	Twine	QR	—	C	
	E.B6.82.191	CABLE, ASSEMBLY, R.T.2, FROM PRESSURE BULKHEAD TO V.H.F. RELAY PANEL AND I.L.S., JB.157, GROUP	1	—	—	
		Consisting of:—				
5E/3038	†	Cable, Unipren 6	QR	—	C	
5E/3090	†	Cable, Uniprenmet 6	QR	—	C	
33C/1138	†	Cement, Bostik	QR	—	C	
5K/2845	†	Coupling, unit	1	—	C	
10H/0970058	Z.60667	Gasket, outlet	1	—	C	
10H/0970108	Z.62235	Gasket, union, rubber	1	—	C	
10H/0970062	CZ.49180	Outlet, straight	1	—	C	
10H/0970102	Z.49040	Ring, compression	1	—	C	
10H/0970096	Z.49037	Ring, thrust	1	—	C	
10H/0970114	Z.62240	Sleeve, cable, rubber	1	—	C	
5K/2609	AGS.1651/12	Sleeve, circular, type 1	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, 1/2" long	24	—	C	
5K/9107067	EEAS.146/C	Sleeve, 1/2" long	4	—	C	
5K/9107068	EEAS.146/D	Sleeve, 1/2" long	2	—	C	
5K/9107070	EEAS.146/G	Sleeve, 1" long	2	—	C	
10H/0560100	CZ.49015	Socket, free, Mk. 4, 3 way	1	—	C	
10H/3162	†	Socket, type W.492	1	—	C	
5F/2279	HELLERMAN HV.3254	Strap	QR	—	C	
5F/2280	HELLERMAN HV.3255	Stud	48	—	C	
32B/498	†	Thread, waxed linen No. 18	QR	—	C	
5F/	†	Wire, tinned copper	QR	—	C	
	E.B6.82.193	CONTROL, TYPE 705, INSTALLATION	—	—	—	
		Spared for:—				
28104	E.B6.82.195	Bracket, assembly	1	—	C	
32B/	5K.5028	Wire, control, type 705	1	—	A	

CANBERRA B Mk. 6

Page 883

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A3.82.139	PANEL, RELAY AND I/C AMPLIFIER	—	—	—	
		Spares for:—				
8535	E.A3.82.149	Panel, inter-comm	1	—	B	
	E.B6.82.17	V.H.F. AND I/C WIRING, ASSEMBLY	—	—	—	
		Consisting of:—				
	E.B7.82.29	CABLE, ASSEMBLY, EARTH, BOMB AIMER'S AND NAVIGATOR'S TEL/MIC TERMINAL BOARD, GROUP	1	—	—	
		Consisting of:—				
5E/3040	†	Cable, Unipren 12	QR	—	C	
5X/6504	†	Lug, 4 BA	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, ½" long	2	—	C	
5X/9400064	Z.19980	Thimble, quick release	1	—	C	
	E.A1.82.41/1	CABLE, ASSEMBLY, V.H.F. RELAY PANEL EARTH CONNECTION, GROUP	1	—	—	
		Consisting of:—				
5E/3042	†	Cable, Unipren 24	QR	—	C	
5X/6509	70009	Lug, 2 BA	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, ½" long	1	—	C	
5K/	†	Sleeve, ½" long	1	—	—	
	E.A7.82.47	CABLE, ASSEMBLY, TAKE-OFF PANEL, EARTH CONNECTION, GROUP	1	—	—	
		Consisting of:—				
5E/3040	†	Cable, Unipren 12	QR	—	C	
5X/6504	†	Lug, 4 BA	2	—	C	
5K/9107066	EEAS.146/B	Sleeve, ½" long	2	—	C	
	E.A3.82.65/1	CABLE, ASSEMBLY, RT23, FROM I/C RELAY PANEL TO CONTROL COLUMN TERMINAL BOARD, GROUP	1	—	—	
		Consisting of:—				
5E/3038	†	Cable, Unipren 6	QR	—	C	
5K/	†	Sleeve, ½" long	6	—	—	
8358	E.A3.82.59/1	CABLE, ASSEMBLY, RT20, FROM TERMINAL BOARD TO MIC/TEL AT PILOT'S SEAT, GROUP	1	—	B	
		Consisting of:—				
5E/3038	†	Cable, Unipren 6	QR	—	C	
5E/3098	†	Cable, Duprenmet 6	QR	—	C	
5K/9107065	EEAS.146/A	Sleeve, ½" long	4	—	C	
5K/9107066	EEAS.146/A1	Sleeve, ½" long	4	—	C	
5K/9107067	EEAS.146/C	Sleeve, 1" long	1	—	C	
5K/9107068	EEAS.146/D	Sleeve, 1" long	1	—	C	
5K/9107068	EEAS.146/D1	Sleeve, 1" long	3	—	C	
10HA/2206	†	Socket, type 359	3	—	A	
5K/	ROSS	Tag, P.O.29	4	—	C	
	COURTNEY					
32B/498	†	Thread, waxed linen No. 18	QR	—	C	
5E/3141	†	Wire, tinned copper, 32 SWG	QR	—	C	

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description						No. off	Matl. Spec	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A3.82.129	CABLE, ASSEMBLY, RT21, FROM TERMINAL BOARD TO MIC/TEL AT NAVIGATOR'S SEAT, GROUP						1	—	—	
		Spares for this group are identical with those for group Part No. E.A3.82.59/1 on page 883.									
	E.A3.82.113	CABLE, ASSEMBLY, TEL/MIC SOCKET, GROUP						1	—	—	
		Consisting of:—									
10A/13766	†	Bracket	...	...	...	...	...	2	—	C	
5E/9100014	†	Cable, miniature, 4B	...	...	...	...	...	QR	—	C	
32A/94	†	Cord, braided, waxed	...	...	...	...	...	QR	—	C	
5K/	†	Sleeve, ½" long	...	...	...	...	...	6	—	—	
10H/18574	†	Socket, tel/mic	...	...	...	...	...	1	—	A	
32B/498	†	Thread, waxed linen No. 18	...	...	...	...	...	QR	—	C	
	E.A3.82.131	CABLE, ASSEMBLY, RT22, FROM TERMINAL BOARD TO MIC/TEL AT BOMB AIMER'S SEAT, GROUP						1	—	—	
		Spares for this group are identical with those for group Part No. E.A3.82.59/1 on page 883.									
	E.A3.82.169	CABLE, ASSEMBLY, RT1, FROM CONNECTION AT PRESSURE BULKHEAD TO I/C RELAY PANEL, GROUP (PRE MOD. 1444)						1	—	—	
		Consisting of:—									
5E/3038	†	Cable, Unipren 6	...	...	...	...	...	QR	—	C	
5E/3098	†	Cable, Duprenmet 6	...	...	...	...	...	QR	—	C	
33C/1138	†	Cement, Bostik	...	...	...	...	...	QR	—	C	
5K/2845	†	Coupling, unit	...	...	...	...	...	1	—	C	
5K/9107065	EEAS.146/A	Sleeve, ½" long	...	...	...	...	...	20	—	C	
5K/9107067	EEAS.146/C	Sleeve, ½" long	...	...	...	...	...	3	—	C	
5K/9107068	EEAS.146/D	Sleeve, ½" long	...	...	...	...	...	2	—	C	
5K/9107069	EEAS.146/G	Sleeve, 1" long	...	...	...	...	...	2	—	C	
5K/2609	AGS.1651/12	Sleeve, type 1, circular	...	...	...	...	...	1	—	C	
10H/3162	†	Socket, type W.492	...	...	...	...	...	1	—	A	
5F/2279	HELLERMAN HV.3254	Strapping	...	...	...	...	...	QR	—	C	
5F/2280	HELLERMAN HV.3255	Stud	...	...	...	...	...	18	—	C	
32B/498	†	Thread, waxed linen No. 18	...	...	...	...	...	QR	—	C	
28W/9419480	SP.15/P	Washer	...	...	...	...	...	1	—	C	
5E/3141	†	Wire, tinned copper, 32 SWG	...	...	...	...	...	QR	—	C	
	E.A3.82.171	CABLE, ASSEMBLY, RT2, FROM CONNECTION AT PRESSURE BULKHEAD TO V.H.F. RELAY PANEL, GROUP (PRE MOD. 1444)						1	—	—	
		Spares for this group are identical with those for group Part No. E.A3.82.169									

CANBERRA B Mk. 6

Page 885

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
	E.A3.82.173	CABLE ASSEMBLY, RT3, FROM I/C RELAY PANEL TO PILOT'S V.H.F. CONTROL PANEL GROUP	1	—	—	—	
		Consisting of:—					
SE/3038		Cable, Unscreened 6	QR	—	—	C	
SK/9107065	EEAS.146/A	Sleeve, 1/2" long	8	—	—	C	
SK/9107067	EEAS.146/C	Sleeve, 1/2" long	4	—	—	C	
SK/9107069	EEAS.146/G	Sleeve, 1/2" long	2	—	—	C	
	HELLERMAN						
5F/2279	HV.3254	Strapping	QR	—	—	C	
	HELLERMAN						
5F/2280	HV.3255	Stud	QR	—	—	C	
	E.B6.82.21	CABLE ASSEMBLY, RT4, FROM I/C RELAY PANEL TO BOMB AIMER'S AND NAVIGATOR'S TEL/MIC TERMINAL BOARD, GROUP	1	—	—	—	
		Consisting of:—					
SE/3038		Cable, Unscreened 6	QR	—	—	C	
SE/3039		Cable, Dicrosmet 6	QR	—	—	C	
SK/9107065	EEAS.146/A	Sleeve, 1/2" long	8	—	—	C	
SK/9107067	EEAS.146/C	Sleeve, 1/2" long	2	—	—	C	
SK/9107068	EEAS.146/D	Sleeve, 1/2" long	2	—	—	C	
SK/9107069	EEAS.146/F	Sleeve, 1/2" long	2	—	—	C	
	HELLERMAN						
5F/2279	HV.3254	Strapping	QR	—	—	C	
	HELLERMAN						
5F/2280	HV.3255	Stud	40	—	—	C	
SE/3141		Wire, tinned copper, 32 SWG	QR	—	—	C	
	E.A3.82.177	CABLE ASSEMBLY, RT5, FROM I/C RELAY PANEL TO PILOT'S SEAT TERMINAL BOARD, GROUP	1	—	—	—	
		Seams for this group are identical with those for group Part No. E.B6.82.21 on page 885					
	E.A3.82.179	CABLE ASSEMBLY, RT6, FROM I/C RELAY PANEL TO BOMB AIMER'S PRONE POSITION, GROUP	1	—	—	—	
		Consisting of:—					
SE/3038		Cable, Dicrosmet 6	QR	—	—	C	
SK/9107065	EEAS.146/A	Sleeve, 1/2" long	4	—	—	C	
SK/9107068	EEAS.146/D	Sleeve, 1/2" long	2	—	—	C	
SE/3141		Wire, tinned copper, 32 SWG	QR	—	—	C	
	E.A3.82.181	CABLE ASSEMBLY, RT7, BETWEEN PILOT'S SEAT TERMINAL BOARD AND BOMB AIMER'S PRONE POSITION TERMINAL BOARD, GROUP	1	—	—	—	
		Consisting of:—					
SE/3038		Cable, Unscreened 6	QR	—	—	C	
SK/9107065	EEAS.146/A	Sleeve, 1/2" long	4	—	—	C	
SK/9107067	EEAS.146/C	Sleeve, 1/2" long	2	—	—	C	

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
										M.R. L.M.	
		1	2	3	4	5	6				
5258	EEAS.143/6H GIRDLESTONE PUMPS Ltd.	Clip, pipe, single bonding						13	L.72	C	
10B/16799	A.751/A GIRDLESTONE PUMPS Ltd.	Stub, matching V.H.F. aerial, 11"88 long						1	—	B	
10B/16800	A.751/B	Stub, matching V.H.F. aerial, 13"88 long						1	—	B	

279
Pages 881 to 890 not issued
HL-18 887

CANBERRA B Mk. 6

Page 891

RADIO AND INTER-COMM.

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip. M.R. L.M.	Plate No.
		1 2 3 4 5 6				
	E.B6.82.7	RADIO AND INTER-COMM IN CENTRE FUSELAGE, ASSEMBLY	—	—	—	
	E.A3.82.15	Spares for:— INSTALLATION OF I/C CONNECTOR	—	—	—	
	E.A3.82.133	Spares for:— CABLE, ASSEMBLY, GROUND I/C, FROM TER- MINAL BLOCKS ON V.H.F. PANEL TO TERMINAL BLOCK ON FRAME 19, GROUP	1	—	—	
		Consisting of:—				
5E/3038	†	Cable, Unipren 6	QR	—	C	
5E/3098	†	Cable, Duprenmet 6	QR	—	C	
5K/9107065	EEAS.146/A	Sleeve, 1/2" long	8	—	C	
5K/9107066	EEAS.146/B	Sleeve, 3/4" long	4	—	C	
5K/9107068	EEAS.146/D	Sleeve, 1" long	2	—	C	
328/498	†	Thread, waxed linen No. 18	QR	—	C	
5E/3141	†	Wire, tinned copper, 32 SWG	QR	—	C	
	E.A3.82.17	Plate, doubling	1	L.72	—	
7724	EEAS.28/2EPH	Washer, special (Mod. 1280)	10	—	C	
17517	EEAS.28/2ER	Washer, special	15	—	C	

CANBERRA B Mk. 6

Page 893

RADIO AND INTER-COMM. PORT WING

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.B6.82.181	I.L.S. IN WING, PORT, GROUP (MOD. 1444)	—	—	—	
		Spares for:—				
108/16708	†	Aerial, localiser assembly, type 239 ...	1	—	A	
	E.A4.82.287	ENGINE BREAK, OUTER, INSTALLATION	—	—	—	
		Spares for:—				
23864	E.A9.82.171	Bracket, assembly ...	1	—	C	
	E.A4.82.2899	ENGINE BREAK, INNER, INSTALLATION	—	—	—	
		Spares for:—				
23864	E.A9.82.171	Bracket, assembly ...	1	—	C	


CANBERRA B Mk. 6

Page 895

RADIO AND INTER-COMM. STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.B6.82.182	I.L.S. IN WING, STARBOARD, GROUP (MOD. 1444)	—	—	—	
		Spares for:—				
10B/16707	†	Aerial, glide path, assembly, type 238 ...	1	—	A	
10B/16706	†	Aerial, marker, assembly, type 237 ...	1	—	A	
	E.A4.82.288	ENGINE BREAK, OUTER, INSTALLATION	—	—	—	
		Spares for:—				
23864	E.A9.82.171	Breaker, assembly ...	1	—	C	
	E.A4.82.290	ENGINE BREAK, INNER, INSTALLATION	—	—	—	
		Spares for:—				
23864	E.A9.82.171	Breaker, assembly ...	1	—	C	

Plate R.1



I.F.F. AERIAL INSTALLATION

RESTRICTED