

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EB7.81.7	ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE ASSEMBLY						—	—	
EA2.81.811	. EQUIPMENT WIRING AND ELECTRICAL BETWEEN FRAMES 12-13						—	—	
EA3.81.1829	. . BAG, stowage						4	—	EA1/1
AS1249/1/2B	. . Bolt, 4BA						3	—	EA1/2
AGS2001B1	. . Nut, stiff, 4BA						3	—	EA1/3
EA2.81.161	. . BOX, JUNCTION NO. 4 ASSEMBLY						1	—	EA1/4
703-1-00249	. . . BLOCK, terminal, 20 way						2	—	EA1/5
A31B24	. . . Screw, 4BA						2	—	EA1/6
EA1.81.583	. . . BOX, junction, 40 way						1	—	EA1/7
UNIPREN 6	. . . CABLE, unipren 6						QR	—	
EA1.81.597G	. . . COVER, ASSEMBLY						1	—	EA1/8
32C/4382997	 RUBBER, synthetic						QR	—	
EEAS117/1	 SCREW, round head 4BA						6	—	EA1/9
EEAS28/2CU	 WASHER, 4BA						12	DTD124A	EA1/10
EEAS42	 WASHER, leather						6	—	EA1/11
508-4-11290-004	 GASKET						2	—	EA1/12
508-4-11290-005	 GASKET						2	—	EA1/13
Z22634	 GROMMET						5	—	EA1/14
703-2-00252	 LINK, connecting, 3 way						1	—	EA1/15
703-2-00254	 LINK, connecting, 5 way						1	—	EA1/16
EA1.81.461	 PLATE, blanking						1	—	EA1/17
EA1.81.463	 PLATE, blanking						2	—	EA1/18
A27AP	 Nut, plain, 6BA						4	—	EA1/19
A32A32	 Screw, round head 6BA						4	—	EA1/20
SP47A	 Washer, spring						4	—	EA1/21
508-1-06413	 PLUG, size 'D' (Pre-Mod 3381)						1	—	EA1/22
2CZ111229	 PLUG, size 'D' (Mod 3381)						1	—	
508-2-11232-002	 SLEEVE						16	—	
SIEGRIST OREL	 SLEEVE, 3/4" long, yellow						16	—	
SL2/3	 SLEEVE, 3/8" long, yellow						24	—	
SL3/3	 TAG, Q.R.						16	—	
703-2-00315-020	 THIMBLE						16	—	
703-2-00339-020	 Attaching parts for EA2.81.161:—								
AGS2002C1	. . . Nut, stiff, 2BA						2	—	EA1/23
A32C24	. . . Screw, 2BA						2	—	EA1/24
No. 10R	. . . Screw, self tapping 1/4" long, type 4101						2	—	EA1/25
EB7.81.5669	. . . CHANNEL						1	—	EA1A/1
EB7.81.5673	. . . CHANNEL						5	—	EA1A/2
EB7.81.5781	. . . CLEAT						6	—	EA1A/3
AS3180/3B	. . . CLIP, cable						8	—	EA1A/4
AS3180/4B	. . . CLIP, cable						9	—	EA1A/5
AS3180/5B	. . . CLIP, cable						1	—	EA1A/6
AS3180/16B	. . . CLIP, cable						2	—	EA1A/7
A25/1B	. . . Bolt, 4BA						1	—	EA1A/8
AGS2001B1	. . . Nut, stiff, 4BA						1	—	EA1A/9
A32B16	. . . Screw, round head, 4BA						1	—	EA1A/10
SP13B	. . . Washer, 4BA						1	—	EA1A/11

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R AS3180/7B	. . CLIP, cable	5	—	EA1A/12
R AS3180/8B	. . CLIP, cable	7	—	EA1A/13
R AS3180/14B	. . CLIP, cable	2	—	EA1A/14
	Attaching parts for Cable Clips:—			
R A25/1B	. . Bolt, 4BA	1	—	EA1A/15
R AGS2001B1	. . Nut, stiff, 4BA	1	—	EA1A/16
R SP15B	. . Washer, 4BA	1	—	EA1A/17
R AS3180/6B	. . CLIP, cable	2	—	EA1A/18
R AS3180/9B	. . CLIP, cable	1	—	EA1A/19
	Attaching parts for AS3180/6B and AS3180/9B:—			
R A25/1B	. . Bolt, 4BA	1	—	EA1A/20
R AGS2001B1	. . Nut, stiff, 4BA	1	—	EA1A/21
R SP15B	. . Washer, 4BA	1	—	EA1A/22
R AS3180/10B	. . CLIP, cable	1	—	EA1A/23
R AS491/12B	. . CLIP, cable	2	—	EA1A/24
R AS491/18	. . CLIP, cable	1	—	EA1A/25
R AS491/27	. . CLIP, cable	1	—	EA1A/26
R AS491/34	. . CLIP, cable	1	—	EA1A/27
R AS3180/6B	. . CLIP (Mod 4354—S.O.O.)	1	—	†
R AS3180/10B	. . CLIP (Mod 4354—S.O.O.)	1	—	†
	Attaching parts for AS3180/6B and AS3180/10B:—			
R A25/1B	. . Bolt (As required)	1	—	†
R AGS2001B1	. . Nut (As required)	1	—	†
R EEAS237/6A	. . Washer, 'D' (As required)	1	—	†
R EEAS238/1A	. . Washer, 'D' (As required)	1	—	†
R EA2.81.177	. . FAIRLEAD	2	—	EA1A/28
R EA2.81.179	. . FAIRLEAD	2	—	EA1A/29
	Attaching parts for EA2.81.177 and EA2.81.179:—			
R A32C20	. . Screw, round head 2BA	6	—	EA1A/30
R AGS2002C1	. . Nut, stiff	6	—	EA1A/31
R EB7.81.2577	. . FAIRLEAD (Mod 1038)	1	—	EA1A/32
	Attaching parts for EB7.81.2577:—			
R A32B20	. . Screw, round head 4BA	4	—	EA1A/33
R AGS2001B1	. . Nut, stiff, 4BA	4	—	EA1A/34
R EB6.80.5685	. . FAIRLEAD, half (Mod 4127)	2	—	EA1A/35
	Attaching parts for EB6.80.5685:—			
R A25/3B	. . Bolt	4	—	EA1A/36
R SP15B	. . Washer	4	—	EA1A/37
R EB7.80.5121	. . FAIRLEAD, half	2	—	EA1A/38
	Attaching parts for EB7.80.5121:—			
R A25/3B	. . Bolt, 4BA	2	—	EA1A/39
R SP15B	. . Washer, 4BA	2	—	EA1A/40
R 5L/9953271	. . FILAMENT, 28v, 7 watt	2	—	EA1A/41
R 5CX/4330002	. . LAMP, cockpit, Mk. 1A	2	—	EA1A/42
	Attaching parts for 5CX/4330002:—			
R A32B16	. . Screw, round head	3	—	EA1A/43
R EA2.81.439	. . PANEL, mounting lamp (Pre—Mod 891)	1	—	EA1A/44
R EA2.81.1067	. . PANEL, mounting lamp (Mod 891)	1	—	
R EA2.81.613	. . PLATE, mounting stowage bag	2	—	EA1/26

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R EEAS132/7	.	.	STRAP, cable c/w buckle, 7" long				2	—	EA1A/45
R AS1249/1B	.	.	Attaching parts for EEAS132/7:—						
R AGS2001B1	.	.	Bolt, mush. head 4BA				1	—	EA1A/46
R EEAS28/18DR	.	.	Nut, stiff, 4BA				1	—	EA1A/47
	.	.	Washer, 4BA				1	—	EA1A/48
R EEAS132/9	.	.	STRAP, cable c/w buckle, 9" long				3	—	EA1A/49
R EEAS132/12	.	.	STRAP, cable c/w buckle, 12" long				4	—	EA1A/50
HELLERMANN									
HV3254	.	.	STRAP, 3" wide				QR	—	
NY3255	.	.	STUD				25	—	
R EA2.81.563	.	.	TUBE, support, cable looms				1	—	EA1A/51
R EA2.81.671	.	.	TUBE, support, cable looms				1	—	EA1A/52
	.	.	Attaching parts for EA2.81.563 and EA2.81.671:—						
R A25/4C	.	.	Bolt, 2BA				2	—	EA1A/53
R AGS2001C1/66	.	.	Nut, stiff, 2BA				2	—	EA1A/54
R AS2809/4/403	.	.	TUBE, distance, cable looms support				4	—	EA1A/55
R 5F2335	.	.	TUBE, PVC				QR	—	†
R 5F4349856	.	.	TUBE, PVC				QR	—	†
EB7.81.1479	.	.	EQUIPMENT WIRING AND ELECTRICAL				—	—	
	.	.	BETWEEN FRAMES 13-21						
	.	.	Spares for:—						
EA2.81.849	.	.	BRACKET, strap support				10	—	EA2/1
	.	.	Attaching parts for EA2.81.849:—						
A25/1C	.	.	Bolt, 2BA				2	—	EA2/2
A27CP	.	.	Nut, plain, 2BA				2	—	EA2/3
SP47C	.	.	Washer, 2BA				2	—	EA2/4
EA2.73.53	.	.	CLIP, half for brackets				9	—	EA2/5
AS3180/16B	.	.	CLIP, cable				7	—	EA2/6
	.	.	Attaching parts for AS3180/16B:—						
A25/1B	.	.	Bolt, 4BA				1	—	EA2/7
AGS2001B1	.	.	Nut, stiff, 4BA				1	—	EA2/8
SP15B	.	.	Washer, 4BA				1	—	EA2/9
AS3180/12B	.	.	CLIP, cable				1	—	EA2/10
	.	.	Attaching parts for AS3180/12B:—						
A25/1/2B	.	.	Bolt				1	—	EA2/11
AGS2001B1	.	.	Nut, stiff				1	—	EA2/12
EEAS21/2ER	.	.	Washer				1	—	EA2/13
EB7.81.2555	.	.	CLIP, cable				6	—	EA2/14
	.	.	Attaching parts for EB7.81.2555:—						
A25/1C	.	.	Bolt, 2BA				2	—	EA2/15
EA3.75.55	.	.	Washer, 2BA				2	—	EA2/16
EA2.81.183	.	.	FAIRLEAD				4	—	EA2/17
	.	.	Attaching parts for EA2.81.183:—						
AGS2001B1	.	.	Nut, stiff, 4BA				6	—	EA2/18
A31B20	.	.	Screw, cheese head 4BA				6	—	EA2/19
EB7.75.111	.	.	LAGGING, cable, frame 21				1	—	
EB7.81.2559	.	.	PLATE, support between frames 15-16				1	—	EA2/20
	.	.	Attaching parts for EB7.81.2559:—						
A25/2C	.	.	Bolt, 2BA				4	—	EA2/21
AGS2001C1/66	.	.	Nut, stiff, 2BA				4	—	EA2/22
SP15C	.	.	Washer, 2BA				4	—	EA2/23
—	.	.	PLATE, cable support (C/Mod/Can/0284/BC,				1	L73	†
	.	.	Fig. 2) (Mod 5182)						
EB6.81.6237	.	.	PLUG, GROUND SUPPLY, HEATING OF				—	—	†
	.	.	DECCA CRYSTAL OVENS, FRAME 20						
	.	.	INSTALLATION (MOD 4297—S.O.O.)						
	.	.	Spares for:—						
EB6.81.6227	.	.	PLATE, adaptor				1	—	†
	.	.	Attaching parts for EB6.81.6227:—						
A25/1C	.	.	Bolt, 2BA				4	—	†
GCB3LV14	.	.	PLUG, external power supply 28 volt				1	—	†
	.	.	Attaching parts for GCB3LV14:—						
A25/2C	.	.	Bolt, 2BA				6	—	†
EB6.81.6235	.	.	Gasket				1	—	†
SP47C	.	.	Washer				6	—	†

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
EA2.81.839	. . STRAP, frames 13-14	2	—	EA2/24
A31B12	. . Attaching parts for EA2.81.839:— . . Screw, 4BA	2	—	EA2/25
EEAS132/9	. . STRAP, cable c/w buckle, 9" long	8	—	EA2/26
EEAS132/12	. . STRAP, cable c/w buckle, 12" long	4	—	EA2/27
AS1248/1/2B	. . Attaching parts for EEAS132/9 and EEAS132/12:— . . Bolt, 4BA	1	—	EA2/28
EEAS73	. . Plate, clamp	1	—	EA2/29
HELLERMANN HV3254	. . STRAP	QR	—	†
HELLERMANN NY3255	. . STUD	14	—	†
EB7.81.1477	. . STUD, earthing	2	—	EA2/30
EB7.81.809	. EQUIPMENT, WIRING AND ELECTRICAL, BETWEEN FRAMES 21B AND 22 Spares for:—	—	—	
EA2.81.835	. . BRACKET, cable clip support	1	—	EA3/1
A25/1B	. . Attaching parts for EA2.81.835:— . . Bolt, 4BA	2	—	EA3/2
AGS2001B1	. . Nut, stiff, 4BA	2	—	
EA2.81.855 SMITH	. . BRACKET, trimmer box	2	—	EA3/3
WAYMOUTH JLA103/111 SMITH	. . BOX, trimmer cable connector, port	1	—	EA3/4
WAYMOUTH JLA103/41	. . BOX, trimmer cable connector, starboard	1	—	EA3/5
AGS2001C1/66	. . Attaching parts for JLA103/111 and JLA103/41:— . . Nut, stiff, 2BA	2	—	
A31C16	. . Screw, cheese head 2BA	2	—	EA3/6
EB7.81.5807	. . BOX, JUNCTION, NO. 1, ASSEMBLY Spares for:—	1	—	EA3/7
703-1-00249	. . . BLOCK, terminal, 20 way	2	—	EA3/8
A43B24	. . . Attaching parts for 703-1-00249:— . . . Screw, cheese head	2	—	EA3/9
EA1.81.583	. . . BOX, junction, 40 way	1	—	EA3/10
EA1.81.597A	. . . COVER, assembly	1	—	EA3/11
508-4-11290-004	. . . GASKET	2	—	
508-4-11290-005	. . . GASKET	2	—	
703-2-00257	. . . LINK, connecting, 8 way	1	—	
EA1.81.464	. . . PLATE, adapting	2	—	EA3/12
EA1.81.461	. . . PLATE, blanking	1	—	EA3/13
A27AP	. . . Attaching parts for EA1.81.464 and EA1.81.461:— . . . Nut, plain, 6BA	4	—	
A32A10	. . . Screw, round head, 6BA	4	—	EA3/14
SP47A	. . . Washer, spring, 6BA	4	—	
508-1-06413	. . . PLUG, size 'D'	1	—	EA3/15
EEAS146B	. . . SLEEVE, 3/4" long	QR	—	
EEAS146A	. . . SLEEVE, 3/4" long	QR	—	
EEAS146A	. . . SLEEVE, 1/4" long	QR	—	
EEAS146/6	. . . SLEEVE, 3/8" long	QR	—	
508-2-11232-002	. . . SLEEVE	15	—	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
HC490	. . .	TAG, QR	2	—	
HC500	. . .	TAG, QR	2	—	
HC510	. . .	TAG, QR	15	—	
5X9000062	. . .	THIMBLE	15	—	
5X9000064	. . .	THIMBLE	2	—	†
5X9000066	. . .	THIMBLE	2	—	†
		Attaching parts for EB7.81.5807:—			
AGS2001C1/66	. .	Nut, stiff, 2BA	2	—	EA3/16
EB7.81.3061	. .	BOX, JUNCTION, NO. 3, ASSEMBLY (PRE—MOD 3970)	1	—	EA3/17
EB7.81.6055	. .	BOX, JUNCTION, NO. 3, ASSEMBLY (MOD 3970)	1	—	
		Spares for:—			
703-1-00249	. . .	BLOCK, terminal, 20 way	2	—	EA3/18
		Attaching parts for 703-1-00249:—			
A43B24	. . .	Screw, cheese head 4BA	2	—	EA3/19
EA3.81.583	. . .	BOX, junction 40 way	1	—	EA3/20
EB7.81.923	. . .	COVER, assembly	1	—	EA3/21
Z23198	. . .	GASKET	2	—	EA3/22
Z23197	. . .	GASKET	1	—	EA3/23
Z23672	. . .	GROMMET	1	—	EA3/24
Z50210	. . .	LINK, connecting, 2 way	3	—	
Z50217	. . .	LINK, connecting, 9 way	1	—	
EA1.81.464	. . .	PLATE, adaptor	2	—	EA3/25
EA1.81.461	. . .	PLATE, blanking	1	—	EA3/26
		Attaching parts for EA1.81.464 and EA1.81.461:—			
A27AP	. . .	Nut, plain, 6BA	4	—	EA3/27
A32A12	. . .	Screw, round head 6BA	4	—	EA3/28
SP47A	. . .	Washer, spring, 6BA	4	—	EA3/29
CZ50361	. . .	PLUG, size 'D'	1	—	EA3/30
or					
2CZ111229	. . .	PLUG, size 'D'	1	—	
EEAS146A	. . .	SLEEVE, $\frac{3}{4}$ " long, yellow	QR	—	
EEAS146C	. . .	SLEEVE, $\frac{3}{4}$ " long	QR	—	
EEAS146A1	. . .	SLEEVE, $\frac{3}{4}$ " long	QR	—	
EEAS146B	. . .	SLEEVE, $\frac{3}{8}$ " long, yellow	—	—	
Z49428	. . .	SLEEVE	16	—	
Z19924	. . .	TAG, QR	18	—	
703-2-00317-020	. . .	TAG, QR	2	—	
		Attaching parts for EB7.81.3061 and EB7.81.6055:—			
AGS2001C1/66	. .	Nut, stiff, 2BA	4	—	EA3/31
EA2.81.673	. .	CHANNEL, fairlead mounting	2	—	EA3/32
AS3180/3B	. .	CLIP, cable	1	—	EA3/33
AS3180/4B	. .	CLIP, cable	10	—	EA3/34
AS3180/6B	. .	CLIP, cable	5	—	EA3/35
AS3180/16B	. .	CLIP, cable	1	—	EA3/36
		Attaching parts for AS3180/clips:—			
AGS2001B1	. .	Nut, stiff, 4BA (As required)	1	—	EA3/37
A31B12	. .	Screw, cheese head 4BA (As required)	1	—	EA3/38
A31B16	. .	Screw (As required)	1	—	EA3/39
SP15B	. .	Washer (As required)	1	—	EA3/40

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AS3180/8B	. . CLIP, cable	4	—	EA3/39
AS3180/18B	. . CLIP, cable	1	—	EA3/40
	Attaching parts for AS3180/8B and AS3180/18B:—			
A25/1B	. . Bolt, 4BA	1	—	EA3/41
AGS2001B1	. . Nut, stiff, 4BA	1	—	
SP15B	. . Washer, 4BA	1	—	
AS3180/10B	. . CLIP, cable	5	—	EA3/42
508-1-40189-320	. . CONNECTOR, bulkhead, plug/socket	1	—	EA3/43
508-1-40196-320	. . CONNECTOR, bulkhead, plug/socket	1	—	EA3/44
—	. . EQUIPMENT, CRASH TRIP INSTALLATION (MOD 4073) (For aircraft embodying Mod 3302) (Ref. Drgs, EB7.00.271, EB7.81.5821 and EB7.81.6703) Spares for:—	—	—	
EB7.81.5825	. . . BRACKET, mounting relay Attaching parts for EB7.81.5825:—	2	—	EA4/1
A25/1C	. . . Bolt, 2BA	4	—	EA4/2
AGS2001C1/66	. . . Nut, 2BA	4	—	EA4/3
SP13C	. . . Washer	4	—	EA4/4
A260	. . . FILAMENT, 28 volt, 2 watt	1	—	†
EB8.81.6129	. . . GANG, SWITCH, ASSEMBLY Spares for:—	1	—	EA4/5
EB8.81.6129A	 LINK, half Attaching parts for EB8.81.6129A:—	2	—	EA4/6
AGS2002A1	 Nut, 6BA	1	—	EA4/7
A31A10	 Screw, 6BA	1	—	EA4/8
C180A8	. . . LAMP, warning red	1	—	EA4/9
EB8.81.6127	. . . PANEL, engraved (Pre—Mod 5099)	1	—	EA4/10
EB7.81.6695	. . . PANEL, engraved (Alt. R60/60—Mod 5099)	1	—	†
EB7.81.5827	. . . PLATE, mounting relay	1	—	EA4/11
D4600	. . . RELAY, type 20B No. 2 Attaching parts for D4600:—	1	—	EA4/12
AS1246/1B	. . . Screw, 4BA	3	—	EA4/13
AGS2001B1	. . . Nut, 4BA	3	—	EA4/14
SP13B	. . . Washer	3	—	EA4/15
AS10512M1	. . . SHROUD, terminal (Alt. R60/60—Mod 5099)	2	—	†
A258	. . . SLEEVE, cable	1	—	†
B186	. . . SOCKET, connector	1	—	EA4/16
E and I 4146A	. . . SOCKET, test Attaching parts for E and I 4146A:—	1	—	EA4/17
AS1246/2B	. . . Bolt, 4BA	2	—	EA4/18
AGS2001B1	. . . Nut, 4BA	2	—	EA4/19
SP15B	. . . Washer	2	—	EA4/20
8800B111	. . . SWITCH, SP (Pre—Mod 5099)	2	—	EA4/21
EK5.81.925	. . . SWITCH, ASSEMBLY (Alt. R60/60—Mod 5099) Spares for:—	1	—	†
DN260Z74	 CAP, dolly	2	—	†
1367Z2	 KNOB	1	—	†
AS10512A4	 SWITCH	2	—	†
EEAS200	. . . WASHER, locking (Pre—Mod 5099)	2	—	
L1023	. . FILAMENT, 28v, 7 watt	1	—	

R
R
RR
R
R

AP101B-0407-3A

Page EA.7

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
NATIONAL PLASTIC SALES X114	.	.	GROMMET, plastic section 4"				1	—	
5CX4330002	.	.	LAMP, cockpit, Mk. 1A				1	—	EA3/45
A31B16	.	.	Attaching parts for 5CX4330002:— Screw, cheese head, 4BA				3	—	EA3/46
508-1-06459	.	.	PLUG, bulkhead, 26 way				2	—	
10H0540103	.	.	PLUG, bulkhead				2	—	EA3/47
EEAS132/12	.	.	STRAP, cable c/w buckle 12" long				1	—	EA3/48
	.	.	Attaching parts for EEAS132/12:—						
AS1248/1B	.	.	Bolt, 4BA				1	—	EA3/49
AGS2001B1	.	.	Nut, stiff, 4BA				1	—	EA3/50
EEAS73	.	.	Plate, clamp				1	—	EA3/51
EEAS132/9	.	.	STRAP, cable c/w buckle 9" long				1	—	EA3/52
	.	.	Attaching parts for EEAS132/9:—						
EEAS73	.	.	Plate, clamp				1	—	
6M x 1/2 "	.	.	Screw, mush. head self tapping				1	—	EA3/53
HELLERMANN HV3254	.	.	STRAP				QR	—	†
HELLERMANN NY3255	.	.	STUD				6	—	†
DOWTY C18317 Mk. 2	.	.	SWITCH, micro				4	—	EA3/54
	.	.	Attaching parts for C18317 Mk. 2:—						
A25/24C	.	.	Bolt, 2BA				2	—	EA3/55
SP13C	.	.	Washer				2	—	
EA2.81.817	.	.	EQUIPMENT, WIRING AND ELECTRICAL BETWEEN FRAMES 22-23 Spares for:—				—	—	
SMITH WAYMOUTH F.A.A.	.	.	AMPLIFIER				2	—	EA5/1
5CZ1053794	.	.	BLOCK, terminal, 2 way				2	—	EA5/2
	.	.	Attaching parts for 5CZ/1053794:—						
AGS2001A1	.	.	Nut, 6BA				2	—	EA5/3
A33A20	.	.	Screw, 6BA				2	—	EA5/4
SMITH WAYMOUTH XA	.	.	BRACKET, amplifier support				2	—	EA5/5
	.	.	Attaching parts for XA:—						
AS1242/2C	.	.	Bolt, 2BA				4	—	EA5/6
AGS2001C1/66	.	.	Nut, 2BA				4	—	
SP16C	.	.	Washer				4	—	
EA2.81.975	.	.	BRACKET, angle, stringer 13				1	—	EA5/7
	.	.	Attaching parts for EA2.81.975:—						
A25/1B	.	.	Bolt, 4BA				1	—	EA5/8
AGS2001B1	.	.	Nut, 4BA				1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA2.81.837	. . BRACKET, cable clips support Attaching parts for EA2.81.837:—	1	—	EA5/9
A25-1-2B	. . Bolt, 4BA	1	—	EA5/10
A25/1B	. . Bolt, 4BA	1	—	EA5/11
AGS2001B1	. . Nut, 4BA	2	—	
AS3180/3B	. . CLIP, 'P', rubber covered	1	—	EA5/12
AS3180/4B	. . CLIP, 'P', rubber covered	10	—	EA5/13
AS3180/6B	. . CLIP, 'P', rubber covered	6	—	EA5/14
AS180/8B	. . CLIP, 'P', rubber covered Attaching parts for AS3180/clips:—	2	—	EA5/15
AGS2001B1	. . Nut, 4BA	1	—	EA5/16
A31B12	. . Screw, 4BA	1	—	EA5/17
or				
A31B16	. . Screw, 4BA	1	—	
AS3180/7B	. . CLIP, 'P', rubber covered	3	—	EA5/18
AS3180/14B	. . CLIP, 'P', rubber covered Attaching parts for AS3180/7B and AS3180/14B:—	4	—	EA5/19
AGS2001B1	. . Nut, 4BA	1	—	
SP15B	. . Washer	1	—	
EA2.81.1195	. . FAIRLEAD, half Attaching parts for EA2.81.1195:—	2	—	EA5/20
A25/2B	. . Bolt, 4BA	3	—	EA5/21
AGS2001B1	. . Nut, 4BA	3	—	EA5/22
EEAS132/7	. . STRAP, c/w buckle	1	—	EA5/23
EEAS132/9	. . STRAP, c/w buckle Attaching parts for EEAS132/7 and EEAS132/9:—	4	—	EA5/24
AS1248/1B	. . Bolt, 4BA	1	—	EA5/25
or				
AS1248/2B	. . Bolt, 4BA	1	—	
AGS2001B1	. . Nut, 4BA	1	—	EA5/26
EEAS73	. . Plate, clamp	1	—	EA5/27
HELLERMANN				
HV3254	. . STRAP	QR	—	
NY3255	. . STUD	6	—	
EA2.81.997	. EQUIPMENT, WIRING AND ELECTRICAL BETWEEN FRAMES 23-24 Spares for:—	—	—	
EA2.81.841	. . BRACKET Attaching parts for EA2.81.841:—	2	—	EA6/1
A25/1B	. . Bolt, 4BA	1	—	EA6/2
AGS2001B1	. . Nut, 4BA	1	—	EA6/3
SP15B	. . Washer	1	—	EA6/4
EA2.81.999	. . BRACKET, mounting suppressor Attaching parts for EA2.81.999:—	2	—	EA6/5
A25/1B	. . Bolt, 4BA	4	—	EA6/6
AGS2001B1	. . Nut, 4BA	4	—	EA6/7
SP13B	. . Washer	4	—	EA6/8
AS3180/3B	. . CLIP, 'P', rubber covered	6	—	EA6/9
AS3180/4B	. . CLIP, 'P', rubber covered Attaching parts for AS3180/3B and AS3180/4B:—	14	—	EA6/10
AGS2001B1	. . Nut, 4BA	1	—	
A31B12	. . Screw, 4BA	1	—	EA6/11

AP101B-0407-3A

Page EA.7

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
NATIONAL PLASTIC SALES X114	.	.	GROMMET, plastic section 4"				1	—	
5CX4330002	.	.	LAMP, cockpit, Mk. 1A				1	—	EA3/45
A31B16	.	.	Attaching parts for 5CX4330002:— Screw, cheese head, 4BA				3	—	EA3/46
508-1-06459	.	.	PLUG, bulkhead, 26 way				2	—	
10H0540103	.	.	PLUG, bulkhead				2	—	EA3/47
EEAS132/12	.	.	STRAP, cable c/w buckle 12" long				1	—	EA3/48
S1248/1B	.	.	Attaching parts for EEAS132/12:— Bolt, 4BA				1	—	EA3/49
AGS2001B1	.	.	Nut, stiff, 4BA				1	—	EA3/50
EEAS73	.	.	Plate, clamp				1	—	EA3/51
EEAS132/9	.	.	STRAP, cable c/w buckle 9" long				1	—	EA3/52
EEAS73	.	.	Attaching parts for EEAS132/9:— Plate, clamp				1	—	
6M x 1/2 "	.	.	Screw, mush. head self tapping				1	—	EA3/53
HELLERMANN HV3254	.	.	STRAP				QR	—	†
HELLERMANN NY3255	.	.	STUD				6	—	†
DOWTY C18317 Mk. 2	.	.	SWITCH, micro				4	—	EA3/54
A25/24C	.	.	Attaching parts for C18317 Mk. 2:— Bolt, 2BA				2	—	EA3/55
SP13C	.	.	Washer				2	—	
EA2.81.817	.	.	EQUIPMENT, WIRING AND ELECTRICAL BETWEEN FRAMES 22-23 Spares for:—				—	—	
SMITH WAYMOUTH F.A.A.	.	.	AMPLIFIER				2	—	EA5/1
5CZ1053794	.	.	BLOCK, terminal, 2 way				2	—	EA5/2
AGS2001A1	.	.	Attaching parts for 5CZ/1053794:— Nut, 6BA				2	—	EA5/3
A33A20	.	.	Screw, 6BA				2	—	EA5/4
SMITH WAYMOUTH XA	.	.	BRACKET, amplifier support				2	—	EA5/5
AS1242/2C	.	.	Attaching parts for XA:— Bolt, 2BA				4	—	EA5/6
AGS2001C1/66	.	.	Nut, 2BA				4	—	
SP16C	.	.	Washer				4	—	
EA2.81.975	.	.	BRACKET, angle, stringer 13				1	—	EA5/7
A25/1B	.	.	Attaching parts for EA2.81.975:— Bolt, 4BA				1	—	EA5/8
AGS2001B1	.	.	Nut, 4BA				1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA2.81.837	. .	BRACKET, cable clips support					1	—	EA5/9
A25-1-2B	. .	Attaching parts for EA2.81.837:—					1	—	EA5/10
A25/1B	. .	Bolt, 4BA					1	—	EA5/11
AGS2001B1	. .	Nut, 4BA					2	—	
AS3180/3B	. .	CLIP, 'P', rubber covered					1	—	EA5/12
AS3180/4B	. .	CLIP, 'P', rubber covered					10	—	EA5/13
AS3180/6B	. .	CLIP, 'P', rubber covered					6	—	EA5/14
AS180/8B	. .	CLIP, 'P', rubber covered					2	—	EA5/15
AGS2001B1	. .	Attaching parts for AS3180/clips:—					1	—	EA5/16
A31B12	. .	Nut, 4BA					1	—	EA5/17
or		Screw, 4BA							
A31B16	. .	Screw, 4BA					1	—	
AS3180/7B	. .	CLIP, 'P', rubber covered					3	—	EA5/18
AS3180/14B	. .	CLIP, 'P', rubber covered					4	—	EA5/19
AGS2001B1	. .	Attaching parts for AS3180/7B and AS3180/14B:—					1	—	
SP15B	. .	Nut, 4BA					1	—	
EA2.81.1195	. .	Washer							
	. .	FAIRLEAD, half					2	—	EA5/20
A25/2B	. .	Attaching parts for EA2.81.1195:—					3	—	EA5/21
AGS2001B1	. .	Bolt, 4BA					3	—	EA5/22
	. .	Nut, 4BA							
EEAS132/7	. .	STRAP, c/w buckle					1	—	EA5/23
EEAS132/9	. .	STRAP, c/w buckle					4	—	EA5/24
AS1248/1B	. .	Attaching parts for EEAS132/7 and EEAS132/9:—					1	—	EA5/25
or	. .	Bolt, 4BA							
AS1248/2B	. .	Bolt, 4BA					1	—	
AGS2001B1	. .	Nut, 4BA					1	—	EA5/26
EEAS73	. .	Plate, clamp					1	—	EA5/27
HELLERMANN									
HV3254	. .	STRAP					QR	—	
NY3255	. .	STUD					6	—	
EA2.81.997	. .	EQUIPMENT, WIRING AND ELECTRICAL					—	—	
		BETWEEN FRAMES 23-24							
		Spares for:—							
EA2.81.841	. .	BRACKET					2	—	EA6/1
A25/1B	. .	Attaching parts for EA2.81.841:—					1	—	EA6/2
AGS2001B1	. .	Bolt, 4BA					1	—	EA6/3
SP15B	. .	Nut, 4BA					1	—	EA6/4
	. .	Washer							
EA2.81.999	. .	BRACKET, mounting suppressor					2	—	EA6/5
A25/1B	. .	Attaching parts for EA2.81.999:—					4	—	EA6/6
AGS2001B1	. .	Bolt, 4BA					4	—	EA6/7
SP13B	. .	Nut, 4BA					4	—	EA6/8
	. .	Washer							
AS3180/3B	. .	CLIP, 'P', rubber covered					6	—	EA6/9
AS3180/4B	. .	CLIP, 'P', rubber covered					14	—	EA6/10
AGS2001B1	. .	Attaching parts for AS3180/3B and AS3180/4B:—					1	—	
A31B12	. .	Nut, 4BA					1	—	EA6/11
	. .	Screw, 4BA							

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
AS3180/6B	.	.	CLIP, 'P', rubber covered				1	—	EA6/12
A25/2B	.	.	Attaching parts for AS3180/6B:—				1	—	EA6/13
AGS2001B1	.	.	Bolt, 4BA				1	—	
	.	.	Nut, 4BA					—	
AS3180/8B	.	.	CLIP, 'P', rubber covered				3	—	EA6/14
AS3180/14B	.	.	CLIP, 'P', rubber covered				2	—	EA6/15
	.	.	Attaching parts for AS3180/8B and AS3180/14B:—						
A25/1B	.	.	Bolt, 4BA				1	—	EA6/16
AGS2001B1	.	.	Nut, 4BA				1	—	
SP15B	.	.	Washer				1	—	EA6/17
EEAS132/7	.	.	STRAP, c/w buckle				1	—	EA6/18
EEAS132/12	.	.	STRAP, c/w buckle				1	—	EA6/19
	.	.	Attaching parts for EEAS132/7 and EEAS132/2:—						
AS1248/2B	.	.	Bolt, 4BA				1	—	EA6/20
AGS2001B1	.	.	Nut, 4BA				1	—	EA6/21
EEAS73	.	.	Plate, clamping				1	—	EA6/22
HELLERMANN HV3254	.	.	STRAP, $\frac{5}{16}$ " wide				QR	—	
HELLERMANN NY3255	.	.	STUD				6	—	
EL26317	.	.	SUPPRESSOR, Type O, No. 2				2	—	EA6/23
	.	.	Attaching parts for EL26317:—						
A31B20	.	.	Screw, 4BA				4	—	EA6/24
SP13B	.	.	Washer				4	—	EA6/25
EA2.81.821	.	.	EQUIPMENT, WIRING AND ELECTRICAL BETWEEN FRAMES 24 and 26 Spares for:—				—	—	
SMITH WAYMOUTH F.A.A.	.	.	AMPLIFIER				1	—	EA7/1
SMITH WAYMOUTH JY86	.	.	BOX, connection				1	—	EA7/2
	.	.	Attaching parts for JY86:—						
A25/15C	.	.	Bolt, 2BA				2	—	EA7/3
AGS2001C1/66	.	.	Nut, 2BA				2	—	EA7/4
AS2811/5/089	.	.	Tube, distance				2	L62	EA7/5
SP13C	.	.	Washer				2	—	EA7/6
SMITH WAYMOUTH XA	.	.	BRACKET, amplifier support				1	—	EA7/7
	.	.	Attaching parts for XA:—						
AS1242/2C	.	.	Bolt, 2BA				4	—	EA7/8
AGS2001C1/66	.	.	Nut, 2BA				4	—	EA7/9
SP16C	.	.	Washer				4	—	EA7/10
EA2.81.841	.	.	BRACKET, angle, clip support				6	—	EA7/11
	.	.	Attaching parts for EA2.81.841:—						
A25/1B	.	.	Bolt, 4BA				1	—	EA7/12
AGS2001B1	.	.	Nut, 4BA				1	—	EA7/13
SP15B	.	.	Washer				1	—	EA7/14

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AS3180/4B	. . CLIP, 'P', rubber covered	5	—	EA7/15
AS3180/6B	. . CLIP, 'P', rubber covered	1	—	EA7/16
A25/2B	. . Bolt, 4BA	1	—	EA7/17
AGS2001B1	. . Nut, 4BA	1	—	EA7/18
AS3180/7B	. . CLIP, 'P', rubber covered	6	—	EA7/19
AS3180/8B	. . CLIP, 'P', rubber covered	3	—	EA7/20
AS3180-14B	. . CLIP, 'P', rubber covered	5	—	EA7/21
A25/1B	. . Bolt, 4BA	1	—	EA7/22
AGS2001B1	. . Nut, 4BA	1	—	EA7/23
SP15B	. . Washer	1	—	EA7/24
AS3360B3C	. . LEAD, bonding	1	—	EA7/25
A25/1B	. . Bolt, 4BA	1	—	EA7/26
AGS2001B1	. . Nut, 4BA	1	—	EA7/27
SP13B	. . Washer	1	—	EA7/28
AS3360C6C	. . LEAD, bonding	1	—	EA7/29
A25/1C	. . Bolt, 2BA	1	—	EA7/30
AGS2001C1/66	. . Nut, 2BA	1	—	EA7/31
SP13C	. . Washer	1	—	EA7/32
EEAS73	. . PLATE, clamp, strap	6	L72	EA7/33
EEAS132/7	. . STRAP, cable, c/w buckle, 7" long	3	—	EA7/34
EEAS132/9	. . STRAP, cable, c/w buckle, 9" long	3	—	EA7/35
AS1248/2B	. . Bolt, 4BA	1	—	EA7/36
AGS2001B1	. . Nut, 4BA	1	—	EA7/37
HELLERMANN HV3254	. . STRAP, 3" wide	QR	—	
HELLERMANN NY3255	. . STUD	5	—	
EB7.81.921	. EQUIPMENT, WIRING AND ELECTRICAL, BETWEEN FRAMES 27-28	—	—	
703-1-00238	. . BLOCK, terminal, 5 way	1	—	EA8/1
AS1246/5B	. . Bolt, 4BA	2	—	EA8/2
EA2.81.841	. . BRACKET, angle	2	—	EA8/3
A25/1B	. . Bolt, 4BA	1	—	EA8/4
AGS2001B1	. . Nut, 4BA	1	—	EA8/5
SP13B	. . Washer	1	—	EA8/6
AS3180/3B	. . CLIP, 'P', rubber covered	7	—	EA8/7
AS3180/4B	. . CLIP, 'P', rubber covered	10	—	EA8/8
AS3180/5B	. . CLIP, 'P', rubber covered	1	—	EA8/9
A25/1B	. . Bolt, 4BA	1	—	EA8/10
A25/2B	. . Bolt, 4BA (For one AS3180/4B, clip)	1	—	EA8/11
AGS2001B1	. . Nut, 4BA	1	—	EA8/12
AGS2001B3	. . Nut, 4BA (For one AS3180/4B, clip)	1	—	EA8/13

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
AS3180/7B	. . CLIP, 'P', rubber covered	2	—	EA8/14
AS3180/8B	. . CLIP, 'P', rubber covered	2	—	EA8/15
AS3180/14B	. . CLIP, 'P', rubber covered	3	—	EA8/16
	Attaching parts for AS3180, Clips:—			
A25/1B	. . Bolt, 4BA	1	—	EA8/17
AGS2001B1	. . Nut, 4BA	1	—	EA8/18
SP15B	. . Washer	1	—	EA8/19
EEAS146/12	. . SLEEVE	2	—	
EEAS132/7	. . STRAP, c/w buckle, port	1	—	EA8/20
EEAS132/9	. . STRAP, c/w buckle, starboard	1	—	EA8/21
	Attaching parts for EEAS132/7 and EEAS132/9:—			
AS1248/3B	. . Bolt, 4BA	1	—	EA8/22
AGS2001B1	. . Nut, 4BA	1	—	EA8/23
EEAS73	. . Plate, clamping	1	—	EA8/24
HELLERMANN HV3254	. . STRAP	QR	—	
HELLERMANN NY3255	. . STUD	11	—	
EB7.81.937	. . . EQUIPMENT, WIRING AND ELECTRICAL— BETWEEN FRAMES 28-29 Spares for:—	—	—	
EA2.81.841	. . BRACKET, angle	2	—	EA8/25
	Attaching parts for EA2.81.841:—			
A25/1B	. . Bolt, 4BA	1	—	EA8/26
AGS2001B1	. . Nut, 4BA	1	—	EA8/27
SP15B	. . Washer	1	—	EA8/28
AS3180/3B	. . CLIP, 'P', rubber covered	5	—	EA8/29
	Attaching parts for AS3180/3B:—			
A25/1B	. . Bolt, 4BA	1	—	EA8/30
AGS2001B1	. . Nut, 4BA	1	—	EA8/31
AS3180/8B	. . CLIP, 'P', rubber covered	3	—	EA8/32
AS3180/14B	. . CLIP, 'P', rubber covered	2	—	EA8/33
	Attaching parts for AS3180, Clips:—			
A25/1B	. . Bolt, 4BA	1	—	EA8/34
AGS2001B1	. . Nut, 4BA	1	—	EA8/35
SP15B	. . Washer	1	—	EA8/36
508-1-40180-320	. . CONNECTOR, bulkhead, plug/socket	1	—	
508-1-40181-320	. . CONNECTOR, bulkhead, plug/socket	1	—	
CZ62276/5	. . CONNECTOR, bulkhead, plug/socket	1	—	
508-1-40163-320	. . CONNECTOR, bulkhead, socket/plug	1	—	
508-1-40163-321	. . CONNECTOR, bulkhead, socket/plug	1	—	
EB7.82.5013	. . FAIRLEAD, half	2	—	EA8/37
	Attaching parts for EB7.82.5013:—			
A25/3B	. . Bolt, 4BA	2	—	EA8/38
AGS2001B1	. . Nut, 4BA	2	—	EA8/39
SP15B	. . Washer	2	—	EA8/40
EA2.81.185	. . FAIRLEAD, half	2	—	EA8/41
	Attaching parts for EA2.81.185:—			
AGS2001B1	. . Nut, 4BA	3	—	EA8/42
A32B20	. . Screw, 4BA	3	—	EA8/43

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
R L1023	. . FILAMENT, 28 volt, 7 watt	1	—	
R E&I2398	. . LAMP, cockpit, Mk. 1A	1	—	EA8/44
R A32B16	. . Attaching parts for E&I2398			
	. . Screw, 4BA	3	—	EA8/45
508-1-06454	. . PLUG, bulkhead, 4 way	1	—	EA8/46
508-1-06451	. . PLUG, bulkhead, 12 way	1	—	EA8/47
508-1-06452	. . PLUG, bulkhead, 14 way	1	—	EA8/48
508-1-06459	. . PLUG, bulkhead, 26 way	1	—	EA8/49
R WTA601115RAE	. . PLUG, bulkhead	1	—	EA8/50
R	Attaching parts for WTA601115RAE			
AGS2001B1	. . Nut, 4BA	4	—	EA8/51
A32B16	. . Screw, 4BA	4	—	EA8/52
R 10H/0560042	. . SOCKET	2	—	EA8/53
EEAS132/9	. . STRAP, c/w buckle	1	—	EA8/54
	Attaching parts for EEAS132/9:—			
AS1248/3B	. . Bolt, 4BA	1	—	EA8/55
AGS2001B1	. . Nut, 4BA	1	—	EA8/56
EEAS73	. . Plate, clamping	1	—	EA8/57
HELLERMANN				
HY3254	. . STRAP	QR	—	
HELLERMANN				
NY3255	. . STUD	2	—	
EB7.81.919	. EQUIPMENT, WIRING AND ELECTRICAL, BETWEEN FRAMES 29-31	—	—	
	Spares for:—			
EA3.81.1829	. . BAG, stowage	2	—	EA9/1
	Attaching parts for EA3.81.1829:—			
AS1248/1/2B	. . Bolt, 4BA	3	—	EA9/2
AGS2001B1	. . Nut, 4BA	3	—	EA9/3
EB7.81.927	. . BOX, JUNCTION No. 5	1	—	EA9/4
	Spares for:—			
PLESSEY				
703-1-00249	. . . BLOCK, terminal	2	—	EA9/5
	Attaching parts for 703-1-00249:—			
A43B24	. . . Screw, cheese head, 4BA	2	—	EA9/6
EA1.81.583	. . . BOX, junction 40 way	1	—	EA9/7
EB7.81.935	. . . COVER ASSEMBLY	1	—	EA9/8
	Spares for:—			
EEAS117/1	 SCREW, cover	6	S92	EA9/9
EEAS28/2CU	 WASHER	12	DTD124	EA9/10
EEAS42	 WASHER	6	Leather	
PLESSEY				
508-4-11290-004	. . . GASKET	2	—	
508-4-11290-005	. . . GASKET	2	—	
—	. . . LINK, connecting, 3 way	1	—	
EA1.81.463	. . . PLATE, blanking	2	—	EA9/11
EA1.81.461	. . . PLATE, blanking	1	—	EA9/12
	Attaching parts for EA1.81.463 and EA1.81.461:—			
A27AP	. . . Nut, 6BA	4	—	EA9/13
A32A12	. . . Screw, round head, 6BA	4	—	EA9/14
SP47A	. . . Washer, 6BA	4	—	EA9/15

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
508-1-06413	.	.	.	PLUG, 26 way, size 'D'			1	—	
EEAS146B	.	.	.	SLEEVE, $\frac{3}{8}$ " long, yellow			20	—	
EEAS146A	.	.	.	SLEEVE, $\frac{3}{4}$ " long, yellow			18	—	
503-2-11232-002	.	.	.	SLEEVE			18	—	
703-2-00315-020	.	.	.	TAG			18	—	
703-2-00339-020	.	.	.	THIMBLE			18	—	
				Attaching parts for EB7.81.927:—					
AGS2001C1/66	.	.		Nut, 2BA			4	—	EA9/17
A32C16	.	.		Screw, 2BA			4	—	EA9/18
EA2.81.841	.	.		BRACKET			2	—	EA9/19
				Attaching parts for EA2.81.841:—					
A25/1B	.	.		Bolt, 4BA			1	—	EA9/20
AGS2001B1	.	.		Nut, 4BA			1	—	EA9/21
SP15B	.	.		Washer			1	—	EA9/22
EA1.81.252	.	.		BRACKET			1	—	EA9/23
EA2.81.765	.	.		BRACKET, centre camera bay light			1	—	EA9/24
AS3180/3B	.	.		CLIP, 'P', rubber covered			9	—	EA9/25
AS3180/8B	.	.		CLIP, 'P', rubber covered			8	—	EA9/26
AS3180/9B	.	.		CLIP, 'P', rubber covered			2	—	EA9/27
				Attaching parts for AS3180 clips:—					
AGS2001B1	.	.		Nut, 4BA			1	—	EA9/28
A32B12	.	.		Screw, 4BA			1	—	EA9/29
AS3180/14B	.	.		CLIP			3	—	EA9/30
				Attaching parts for AS3180/14B:—					
A25/1B	.	.		Bolt, 4BA			1	—	EA9/31
AGS2001B1	.	.		Nut, 4BA			1	—	EA9/32
SP15B	.	.		Washer, 4BA			1	—	EA9/33
AS3180/18C	.	.		CLIP, 'P', rubber covered			2	—	EA9/34
				Attaching parts for AS3180/18C:—					
AGS2001C1/66	.	.		Nut, 2BA			1	—	EA9/35
A32C16	.	.		Screw, 2BA			1	—	EA9/36
AS493/16	.	.		CLIP, 'P', rubber covered			2	—	EA9/37
				Attaching parts for AS493/16:—					
AGS2001B1	.	.		Nut, 2BA			1	—	EA9/38
A32C16	.	.		Screw, round head, 2BA			1	—	EA9/39
L1023	.	.		FILAMENT, 28 volt, 7 watt			1	—	EA9/40
E&I2398	.	.		LAMP, cockpit Mk. 1A			1	—	EA9/41
				Attaching parts for E&I2398					
A32B16	.	.		Screw, 4BA			3	—	EA9/42
EEAS132/7	.	.		STRAP, c/w buckle			1	—	EA9/43
				Attaching parts for EEAS132/7:—					
AS1248/3B	.	.		Bolt, 4BA			1	—	EA9/44
AGS2001B1	.	.		Nut, 4BA			1	—	EA9/45
EEAS73	.	.		Washer			1	—	EA9/46
HELLERMANN									
HV3254	.	.		STRAP, $\frac{5}{16}$ " wide			QR	—	
HV3341	.	.		STRAP, $\frac{1}{2}$ " wide			QR	—	
HY3255	.	.		STUD			18	—	
HY3342	.	.		STUD			18	—	
BURGESS									
TYPE 1A	.	.		SWITCH			1	—	EA9/47
				Attaching parts for Type 1A:—					
A25/8B	.	.		Bolt, 4BA			2	—	EA9/48
AGS2001B1	.	.		Nut, 4BA			2	—	EA9/49
EA1.81.460	.	.		Washer, plate			1	—	EA9/50

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA2.81.829	. EQUIPMENT, WIRING, TOP TANKS Spares for:—	—	—	
AS3180/4B	. . CLIP, 'P', rubber covered Attaching parts for AS3180/4B:—	25	—	EA2/30A
AGS2001B1	. . Nut, 4BA	1	—	EA2/31
A31B16	. . Screw, 4BA	1	—	EA2/32
EA2.81.831	. EQUIPMENT, WIRING TRANSMITTER CABLE TANK UNIT Spares for:—	—	—	
EA2.81.841	. . BRACKET, cable clip Attaching parts for EA2.81.841:—	1	—	EA2/33
A25/1/2B	. . Bolt, 4BA	1	—	EA2/34
AGS2001B1	. . Nut, 4BA	1	—	EA2/35
AS3180/4B	. . CLIP, 'P', rubber covered Attaching parts for AS3180/4B:—	3	—	EA2/36
AGS2001B1	. . Nut, 4BA	1	—	EA2/37
A31B12	. . Screw, 4BA	1	—	EA2/38
EB7.81.5521	. EQUIPMENT, WIRING D.C. SUPPLIES Spares for:—	—	—	
AS3180/5B	. . CLIP, 'P', rubber covered	31	—	EA2/39
AS3180/8B	. . CLIP, 'P', rubber covered Attaching parts for AS3180 clips:—	4	—	EA2/40
A25/1B	. . Bolt, 4BA	1	—	EA2/41
AGS2001B1	. . Nut, 4BA	1	—	EA2/42
SP15B	. . Washer	1	—	EA2/43
EA2.81.5605	. LAMP, ANTI-COLLISION, LOWER FLASHING INSTALLATION AT FRAME 21 (MOD 3356) Spares for:—	—	—	
EA2.81.5625	. . ANGLE	1	—	EA10/1
EA2.81.5659	. . ANGLE	1	—	EA10/2
EA9.81.5661	. . ANGLE	1	—	EA10/3
EA2.81.5619	. . COVER, dished Attaching parts for EA2.81.5619:—	1	S511	EA10/4
EEAS1/2C	. . Screw, 2BA	16	—	EA10/5
EA2.81.5621	. . DOOR, lamp support	1	L72	EA10/6
5L9952445	. . FILAMENT, 28 volt 40 watt	1	—	EA10/7
EA2.81.5607	. . FRAME, door	1	—	EA10/8
SP93A10	. . GROMMET	1	—	EA10/9
5CX/5315	. . LAMP, Type FNL50	1	—	EA10/10
EA2.81.5617	. . RING, packing lamp	1	—	EA10/11
A31A16	. . SCREW	2	—	EA10/12
EA2.81.5616	. . SEAL, rubber	1	H26	EA10/13
EA2.81.5629	. . STRIP, packing	1	—	EA10/14
EA2.81.5631	. . STRIP, packing	1	—	EA10/15
EA2.81.5633	. . STRIP, packing	1	—	EA10/16
SP47A	. . WASHER	2	—	EA10/17

R
R
R

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EB7.81.35	.	.	.	.	.	LOOMS, CABLE, ASSEMBLY Spares for:—	—	—	
EA2.81.221/2	.	.	.	.	.	CABLE, ASSEMBLY, C1, from distribution box to J.B.1	1	—	
EA2.81.222/2	.	.	.	.	.	CABLE, ASSEMBLY, C1X, from pressure bulkhead to J.B.1	1	—	
EA2.81.225	.	.	.	.	.	CABLE, ASSEMBLY, C4, from pressure bulkhead to J.B.4	1	—	
EA2.81.226/2	.	.	.	.	.	CABLE, ASSEMBLY, C5, from pressure bulkhead to J.B.5	1	—	
EA2.81.228/2	.	.	.	.	.	CABLE, ASSEMBLY, C7, from distribution box to J.B.7	1	—	
EA2.81.237/2	.	.	.	.	.	CABLE, ASSEMBLY, C41, from pressure bulkhead to rear flare bay bulkhead	1	—	
EA2.81.244	.	.	.	.	.	CABLE, ASSEMBLY, 1B, from J.B.1 to flare door terminal board	1	—	
EA2.81.245/2	.	.	.	.	.	CABLE, ASSEMBLY, 1C, from J.B.1 to camera door valve actuator	1	—	
EA2.81.246/2	.	.	.	.	.	CABLE, ASSEMBLY, 1D, from J.B.1 to undercarriage valve actuator	1	—	
EA2.81.248/2	.	.	.	.	.	CABLE, ASSEMBLY, 1G, from J.B.1 to flap transmitter	1	—	
EA2.81.249/2	.	.	.	.	.	CABLE, ASSEMBLY, 1H, 1K from J.B.1 to plug bracket on ventral tank, port and fuel cock actuator	1	—	
EA2.81.250/2	.	.	.	.	.	CABLE, ASSEMBLY, 1J from J.B.1 to fuel cock actuator aft tank	1	—	
EA2.81.254	.	.	.	.	.	CABLE, ASSEMBLY, 1R, 1S from J.B.1 to flare door micro switches	1	—	
EA2.81.261	.	.	.	.	.	CABLE, ASSEMBLY, 3D, from J.B.3 to flare door valve actuator terminal board	1	—	
EA2.81.262/2	.	.	.	.	.	CABLE, ASSEMBLY, 3D1, from terminal board to flare door valve actuator	1	—	
EA2.81.263/2	.	.	.	.	.	CABLE, ASSEMBLY, 3F, from J.B.3 to flap valve actuator	1	—	
EA2.81.264/2	.	.	.	.	.	CABLE, ASSEMBLY, 3H, 3K, from J.B.3 to fuel cock actuator and plug bracket on ventral tank starboard	1	—	
EA2.81.265/2	.	.	.	.	.	CABLE, ASSEMBLY, 3J, from J.B.3 to fuel cock, port	1	—	
EA2.81.269	.	.	.	.	.	CABLE, ASSEMBLY, 3M, from J.B.3 to fuel contents gauge transmitter, upper tank	1	—	
EA2.81.270	.	.	.	.	.	CABLE, ASSEMBLY, 3N, from J.B.3 to fuel transmitter, ventral tank	1	—	
EA2.81.271	.	.	.	.	.	CABLE, ASSEMBLY, 3P, from J.B.3 to fuel contents gauge transmitter, rear tank	1	—	
EA2.81.281	.	.	.	.	.	CABLE, ASSEMBLY, 4A, from J.B.4 to F.52 Camera (Forward Port)	1	—	
EA2.81.278	.	.	.	.	.	CABLE, ASSEMBLY, 4B, from J.B.4 to F.52 Camera (Centre Port)	1	—	
EA2.81.283	.	.	.	.	.	CABLE, ASSEMBLY, 4C, from J.B.4 to F.52 Camera (Forward Port)	1	—	
EA2.81.280	.	.	.	.	.	CABLE, ASSEMBLY, 4D, from J.B.4 to F.52 Camera (Centre Starboard)	1	—	
EA2.81.284	.	.	.	.	.	CABLE, ASSEMBLY, 5A, from J.B.5 to F.52 Camera (Aft Port)	1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA2.81.285	.	.	CABLE, ASSEMBLY, 5B, from J.B.5 to F.52				1	—	
			Camera (Aft Starboard)						
EA2.81.5111	.	.	CABLE, ASSEMBLY, 5D, from J.B.5 to Camera				1	—	
			Door Micro Switch						
EA2.81.293/2	.	.	CABLE, ASSEMBLY, 1M, from J.B.1 to fuel cock				1	—	
			actuator						
EB7.81.553/2	.	.	CABLE, ASSEMBLY, 3A1, from terminal board to				1	—	
			vent valve heater port						
EB7.81.555	.	.	CABLE, ASSEMBLY, 3A2, from terminal board to				1	—	
			vent valve heater starboard						
EA2.81.581/2	.	.	CABLE, ASSEMBLY, 3Q, from J.B.3 to plug break				1	—	
			flare beam, starboard						
EA2.81.584	.	.	CABLE, ASSEMBLY, 1Q, from J.B.1 to plug break				1	—	
			flare beam, port (Pre-Mod 3381)						
EA2.81.584/2	.	.	CABLE, ASSEMBLY, 1Q, from J.B.1 to plug break				1	—	
			flare beam, port (Mod 3381)						
EB7.81.609/2	.	.	CABLE, ASSEMBLY, C3X, from pressure bulkhead				1	—	
			to J.B.3						
EB7.81.611/2	.	.	CABLE, ASSEMBLY, C7X, from pressure bulkhead				1	—	
			to J.B.7						
EB7.81.615/2	.	.	CABLE, ASSEMBLY, C9, from distribution box, to				1	—	
			port wing break						
EB7.81.617/2	.	.	CABLE, ASSEMBLY, C10, from distribution box to				1	—	
			starboard wing break						
EB7.81.623	.	.	CABLE, ASSEMBLY, C33, from main electrical panel				1	—	
			to rear flare bay bulkhead						
EA2.81.774	.	.	CABLE, ASSEMBLY, 6H2, from centre camera bay				1	—	
			lamp to terminal board in rear camera						
			bay						
EB7.81.2565	.	.	CABLE, ASSEMBLY, 4F, from J.B.4 to feeds for				1	—	
			camera bay and flare bay lights						
			(Mod 1038)						
EA2.81.945/2	.	.	CABLE, ASSEMBLY, 3L1, from suppressor to fuel				1	—	
			pump, rear tank						
EA2.81.947/2	.	.	CABLE, ASSEMBLY, 1F and 1T, from J.B.1 to air				1	—	
			break actuator and solenoid valves						
EA2.81.1013	.	.	CABLE, ASSEMBLY, 1L from J.B.1 to suppressor				1	—	
			rear tank						
EA2.81.1015/2	.	.	CABLE, ASSEMBLY, 1L1, from suppressor to fuel				1	—	
			pump, rear tank						
EA2.81.1017	.	.	CABLE, ASSEMBLY, 3L, from J.B.3 to starboard				1	—	
			fuel pump suppressor rear tank						
EB7.81.1369	.	.	CABLE, ASSEMBLY, 3A and 3B, from J.B.3 to fire				1	—	
			extinguisher and ventral heaters						
EB7.81.1117	.	.	CABLE, ASSEMBLY, 3R and 3S, from J.B.3 to port				1	—	
			and starboard flare door micro switches						
EB7.81.5809	.	.	CABLE, ASSEMBLY, 1N and E1, from J.B.1 to main				1	—	
			electrical panel fatigue meter fuse,						
			earth and fatigue meter						
			(Mod 3883) (Pre-Mod 5099)						

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EB7.81.6673	.	.	CABLE, ASSEMBLY, 1N and E1, from J.B.1 to main electrical panel fatigue meter fuse, earth and fatigue meter (Alt. R60/67-Mod 5099)				—	—	
EB7.81.1121	.	.	CABLE, ASSEMBLY, E3, earth connection for J.B.3 (Pre-Mod 5099)				1	—	
R EB7.81.6193	.	.	CABLE, ASSEMBLY, E3, earth connection for J.B.3 (Alt. R60/67-Mod 5099)				1	—	
EB7.81.1123	.	.	CABLE, ASSEMBLY, E4, earth connection for J.B.4 (Pre-Mod 5099)				1	—	
EB7.81.6675	.	.	CABLE, ASSEMBLY, E4, earth connection for J.B.4 (Alt. R60/67-Mod 5099)				1	—	
EB7.81.1125	.	.	CABLE, ASSEMBLY, E5, earth connection for J.B.5 (Pre-Mod 5099)				1	—	
R EB7.81.6195	.	.	CABLE, ASSEMBLY, E5, earth connection for J.B.5 (Alt. R60/67-Mod 5099)				1	—	
EB7.81.1749	.	.	CABLE, ASSEMBLY, 5C, from J.B.5 to survey camera (Mod 1049)				1	—	
EB7.81.1365/2	.	.	CABLE, ASSEMBLY, C3, from distribution box to J.B.3				1	—	
EA4.81.1367/2	.	.	CABLE, ASSEMBLY, C6, from distribution box to rear flare bay bulkhead				1	—	
EB7.81.5493	.	.	CABLE, ASSEMBLY, C31, from connection on port wing leading edge diaphragm to main electrical panel (Mod 3235)				1	—	
EB7.81.5497	.	.	CABLE, ASSEMBLY, C32, from main electrical panel cut-out to starboard wing break (Mod 3235)				1	—	
EB7.81.1473/2	.	.	CABLE, ASSEMBLY, C8X, from pressure bulkhead to J.B.8				1	—	
EB7.81.1475/2	.	.	CABLE, ASSEMBLY, C8, from distribution box to J.B.8				1	—	
EB7.81.5483	.	.	CABLE, ASSEMBLY, C35, from main electrical panel to voltage regulator and to No. 1 generator (Mod 3235)				1	—	
EB7.81.5477	.	.	CABLE, ASSEMBLY, C36, from main electrical panel to voltage regulator, and to No. 2 generator (Mod 3235)				1	—	
EB7.81.5479	.	.	CABLE, ASSEMBLY, C37, from port voltage regulator to No. 1 overvolt relay main electrical panel (Mod 3235)				1	—	
EB7.81.5481	.	.	CABLE, ASSEMBLY, C38, from starboard voltage regulator to No. 2 overvolt relay main electrical panel (Mod 3235)				1	—	
EB7.81.7255	.	.	CABLE, ASSEMBLY, C419, from heavy duty TB, U.H.F. equipment panel to in-line splice at frame 12 (Mod 5022)				1	—	
EB7.81.3161	.	.	CABLE, ASSEMBLY, C71, from I.F.F., J.B., to plug bracket at frame 11, starboard above door frame (Mod 3235)				1	—	
EB7.81.3077	.	.	CABLE, ASSEMBLY, 3W/1, from J.B.3 to rear detectors (Mod 4073)				1	—	
R EB7.81.3083	.	.	CABLE, ASSEMBLY, XX92, between 3 way terminal blocks (Mod 4073)				1	—	
R EB7.81.3085	.	.	CABLE, ASSEMBLY, E3, from J.B.3 to indicator fuse (Mod 4073)				1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EB7.81.6705	. .	CABLE, ASSEMBLY, C3XX, from distribution box to relay box (Alt. R60/60-Mod 5099)	1	—	
EB7.81.3201	. .	CABLE, ASSEMBLY, 3XY, from test socket explosion protection to switch (Mod 3302) (Pre-Mod 5099)	1	—	
EB7.81.6707	. .	CABLE, ASSEMBLY, 3XY, from test socket explosive protection to switch (Alt. R60/60-Mod 5099)	1	—	
EB7.81.3203	. .	CABLE, ASSEMBLY, 3XX, from switch explosion protection to indicator fuse (Mod 3302) (Pre-Mod 5099)	1	—	
EB7.81.6709	. .	CABLE, ASSEMBLY, 3XX, from switch explosion protection to indicator fuse (Alt. R60/60-Mod 5099)	1	—	
EB8.81.2243	. .	CABLE, ASSEMBLY, ES1, from plug bracket on tank to fuse indicator (Mod 2000)	1	—	
EB7.81.3205	. .	CABLE, ASSEMBLY, 3Z, from relay box explosion protection to relay and switch (Mod 3302) (Pre-Mod 5099)	1	—	
EB7.81.6711	. .	CABLE, ASSEMBLY, 3Z, from relay box explosion protection to relay and switch (Alt. R60/60-Mod 5099)	1	—	
EA2.81.5025	. .	CABLE, ASSEMBLY, C214	1	—	
EA2.81.5017	. .	CABLE, ASSEMBLY, C224	1	—	
EA2.81.5019	. .	CABLE, ASSEMBLY, C225	1	—	
EA2.81.5039	. .	CABLE, ASSEMBLY, C212	1	—	
EA2.81.5047	. .	CABLE, ASSEMBLY, C226	1	—	
EA2.81.5049	. .	CABLE, ASSEMBLY, C227	1	—	
EA2.81.5051	. .	CABLE, ASSEMBLY, C231	1	—	
EA2.81.5063	. .	CABLE, ASSEMBLY, 3X	1	—	
EA2.81.5067	. .	CABLE, ASSEMBLY, 3V	1	—	
EA2.81.5069	. .	CABLE, ASSEMBLY, 5G	1	—	
EA2.81.5071	. .	CABLE, ASSEMBLY, 5J	1	—	
EA2.81.5075	. .	CABLE, ASSEMBLY, 5H	1	—	
EB7.81.5733	. .	CABLE, ASSEMBLY, C213	1	—	
EB7.81.5737	. .	CABLE, ASSEMBLY, C453	1	—	
EB7.81.6047	. .	CABLE, ASSEMBLY, 3WA	1	—	
EB7.81.6049	. .	CABLE, ASSEMBLY, 3WB	1	—	
EB7.81.6051	. .	CABLE, ASSEMBLY, 3Y	1	—	
EB7.81.6053	. .	CABLE, ASSEMBLY, C463	1	—	
EB7.81.7355	. .	CABLE, ASSEMBLY, F450 (Mod 5500)	1	—	
SMITH					
WAYMOUTH					
CA14	. .	CONNECTOR	1	—	
CA18	. .	CONNECTOR (Pre-Mod 3853)	3	—	
CA18	. .	CONNECTOR (Mod 3853)	2	—	
CA26	. .	CONNECTOR (Mod 3853)	1	—	
CA38	. .	CONNECTOR	3	—	
CA72	. .	CONNECTOR	1	—	
Z22634	. .	GROMMET, dummy	2	—	
No.4	. .	LEAD, electrical camera control	6	—	
EB7.81.45	. .	LOOMS, CABLE, INSTRUMENT Consisting of:—	—	—	
EB7.81.541	. .	CABLE, ASSEMBLY, AU1A-AU1, from connection at pressure bulkhead to A.M.U. Mk. 4	1	—	
EB7.81.543	. .	CABLE, ASSEMBLY, AU2A-AU2, from connection at pressure bulkhead to wing root connection	1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EB7.81.6673	. . CABLE, ASSEMBLY, 1N and E1, from J.B.1 to main electrical panel fatigue meter fuse, earth and fatigue meter (Alt. R60/67-Mod 5099)	—	—	
EB7.81.1121	. . CABLE, ASSEMBLY, E3, earth connection for J.B.3 (Pre-Mod 5099)	1	—	
R EB7.81.6193	. . CABLE, ASSEMBLY, E3, earth connection for J.B.3 (Alt. R60/67-Mod 5099)	1	—	
EB7.81.1123	. . CABLE, ASSEMBLY, E4, earth connection for J.B.4 (Pre-Mod 5099)	1	—	
EB7.81.6675	. . CABLE, ASSEMBLY, E4, earth connection for J.B.4 (Alt. R60/67-Mod 5099)	1	—	
EB7.81.1125	. . CABLE, ASSEMBLY, E5, earth connection for J.B.5 (Pre-Mod 5099)	1	—	
R EB7.81.6195	. . CABLE, ASSEMBLY, E5, earth connection for J.B.5 (Alt. R60/67-Mod 5099)	1	—	
EB7.81.1749	. . CABLE, ASSEMBLY, 5C, from J.B.5 to survey camera (Mod 1049)	1	—	
EB7.81.1365/2	. . CABLE, ASSEMBLY, C3, from distribution box to J.B.3	1	—	
EA4.81.1367/2	. . CABLE, ASSEMBLY, C6, from distribution box to rear flare bay bulkhead	1	—	
EB7.81.5493	. . CABLE, ASSEMBLY, C31, from connection on port wing leading edge diaphragm to main electrical panel (Mod 3235)	1	—	
EB7.81.5497	. . CABLE, ASSEMBLY, C32, from main electrical panel cut-out to starboard wing break (Mod 3235)	1	—	
EB7.81.1473/2	. . CABLE, ASSEMBLY, C8X, from pressure bulkhead to J.B.8	1	—	
EB7.81.1475/2	. . CABLE, ASSEMBLY, C8, from distribution box to J.B.8	1	—	
EB7.81.5483	. . CABLE, ASSEMBLY, C35, from main electrical panel to voltage regulator and to No. 1 generator (Mod 3235)	1	—	
EB7.81.5477	. . CABLE, ASSEMBLY, C36, from main electrical panel to voltage regulator, and to No. 2 generator (Mod 3235)	1	—	
EB7.81.5479	. . CABLE, ASSEMBLY, C37, from port voltage regulator to No. 1 overvoltage relay main electrical panel (Mod 3235)	1	—	
EB7.81.5481	. . CABLE, ASSEMBLY, C38, from starboard voltage regulator to No. 2 overvoltage relay main electrical panel (Mod 3235)	1	—	
EB7.81.7255	. . CABLE, ASSEMBLY, C419, from heavy duty TB, U.H.F. equipment panel to in-line splice at frame 12 (Mod 5022)	1	—	
EB7.81.3161	. . CABLE, ASSEMBLY, C71, from I.F.F., J.B., to plug bracket at frame 11, starboard above door frame (Mod 3235)	1	—	
EB7.81.3077	. . CABLE, ASSEMBLY, 3W/1, from J.B.3 to rear detectors (Mod 4073)	1	—	
R EB7.81.3083	. . CABLE, ASSEMBLY, XX92, between 3 way terminal blocks (Mod 4073)	1	—	
R EB7.81.3085	. . CABLE, ASSEMBLY, E3, from J.B.3 to indicator fuse (Mod 4073)	1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
R EB7.81.6705	. . CABLE, ASSEMBLY, C3XX, from distribution box to relay box (Alt. R60/60—Mod 5099)	1	—	
EB7.81.3201	. . CABLE, ASSEMBLY, 3XY, from test socket explosion protection to switch (Mod 3302) (Pre—Mod 5099)	1	—	
EB7.81.6707	. . CABLE, ASSEMBLY, 3XY, from test socket explosive protection to switch (Alt. R60/60—Mod 5099)	1	—	
EB7.81.3203	. . CABLE, ASSEMBLY, 3XX, from switch explosion protection to indicator fuse (Mod 3302) (Pre—Mod 5099)	1	—	
EB7.81.6709	. . CABLE, ASSEMBLY, 3XX, from switch explosion protection to indicator fuse (Alt. R60/60—Mod 5099)	1	—	
EB8.81.2243	. . CABLE, ASSEMBLY, ES1, from plug bracket on tank to fuse indicator (Mod 2000)	1	—	
EB7.81.3205	. . CABLE, ASSEMBLY, 3Z, from relay box explosion protection to relay and switch (Mod 3302) (Pre—Mod 5099)	1	—	
EB7.81.6711	. . CABLE, ASSEMBLY, 3Z, from relay box explosion protection to relay and switch (Alt. R60/60—Mod 5099)	1	—	
R EA2.81.5025	. . CABLE, ASSEMBLY, C214	1	—	
R EA2.81.5017	. . CABLE, ASSEMBLY, C224	1	—	
R EA2.81.5019	. . CABLE, ASSEMBLY, C225	1	—	
R EA2.81.5039	. . CABLE, ASSEMBLY, C212	1	—	
R EA2.81.5047	. . CABLE, ASSEMBLY, C226	1	—	
R EA2.81.5049	. . CABLE, ASSEMBLY, C227	1	—	
R EA2.81.5051	. . CABLE, ASSEMBLY, C231	1	—	
R EA2.81.5063	. . CABLE, ASSEMBLY, 3X	1	—	
R EA2.81.5067	. . CABLE, ASSEMBLY, 3V	1	—	
R EA2.81.5069	. . CABLE, ASSEMBLY, 5G	1	—	
R EA2.81.5071	. . CABLE, ASSEMBLY, 5J	1	—	
R EA2.81.5075	. . CABLE, ASSEMBLY, 5H	1	—	
R EB7.81.5733	. . CABLE, ASSEMBLY, C213	1	—	
R EB7.81.5737	. . CABLE, ASSEMBLY, C453	1	—	
R EB7.81.6047	. . CABLE, ASSEMBLY, 3WA	1	—	
R EB7.81.6049	. . CABLE, ASSEMBLY, 3WB	1	—	
R EB7.81.6051	. . CABLE, ASSEMBLY, 3Y	1	—	
R EB7.81.6053	. . CABLE, ASSEMBLY, C463	1	—	
SMITH				
WAYMOUTH				
CA14	. . CONNECTOR	1	—	
CA18	. . CONNECTOR (Pre—Mod 3853)	3	—	
CA18	. . CONNECTOR (Mod 3853)	2	—	
CA26	. . CONNECTOR (Mod 3853)	1	—	
CA38	. . CONNECTOR	3	—	
CA72	. . CONNECTOR	1	—	
R Z22634	. . GROMMET, dummy	2	—	
R No.4	. . LEAD, electrical camera control	6	—	
EB7.81.45	. LOOMS, CABLE, INSTRUMENT Consisting of:—	—	—	
EB7.81.541	. . CABLE, ASSEMBLY, AU1A-AU1, from connection at pressure bulkhead to A.M.U. Mk. 4	1	—	
EB7.81.543	. . CABLE, ASSEMBLY, AU2A-AU2, from connection at pressure bulkhead to wing root connection	1	—	

ELECTRICAL

ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EB7.81.545	. . CABLE, ASSEMBLY, D1C-D1B, from connection at pressure bulkhead to wing root connection	1	—	
EB7.80.865	. METER FATIGUE, BULKHEAD FRAME 21B, INSTALLATION (MOD 2506) Spares for:—	—	—	EA11/1
R 6A5029	. . METER, fatigue, Mk. 3C (Pre—Mod 3245)	1	—	EA11/2
R 6A4664238	. . METER, fatigue, Mk. 13 (Mod 3245) (Pre—Mod 4223)	1	—	
R 6A4327991	. . METER, fatigue, Mk. 16 (Mod 4223) Attaching parts for 6A/5029, 6A/4664238 and 6A/4327991:—	1	—	
A25/1C	. . Bolt, 2BA	4	—	EA11/3
SP15C	. . Washer	4	—	EA11/4
R EB7.80.867	. . MOUNTING Attaching parts for EB7.80.867:—	1	—	EA11/4A
A25/1C	. . Bolt, 2BA	4	—	EA11/5
EB7.80.869	. . TOP HAT, assembly	1	—	EA11/6
EB7.80.873	. . TOP HAT, assembly Attaching parts for EB7.80.869 and EB7.80.873:—	1	—	EA11/7
A25/1C	. . Bolt, 2BA	4	—	EA11/8
AGS2001C1/66	. . Nut	4	—	EA11/9
SP15C	. . Washer	4	—	EA11/10




FIG. 1 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 1A ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 2 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 3 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 4 ELECTRICAL EQUIPMENT IN REAR FUSELAGE

CODE T

SECT. EA




FIG. 5 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 6 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 7 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 8 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT. EA




FIG. 9 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE




FIG. 10 ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

CODE T

SECT.EA