

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
	ENGINE COWLING INSTALLATION PORT (EB8.50.1)	-	-	-	
	Spares for:				
EA1.50.103	CLIP, hook retaining	2	DTD390	C	J2/1
EA1.50.105	CLIP, hook retaining	2	DTD390	C	J2/2
EB8.50.5	COWL, Front Group (Pre Mod 4967)	1	-	P	J1/3
EB8.50.5x7	COWL, Front Group (Mod 3967) (spares supplied to Drg EB8.00.467)	1	-	P	J3/3
	Spares for:				
EB8.50.155	AIR INTAKE, complete (Pre Mod 4967)	1	-	P	J1/4
EB8.50.1643	AIR INTAKE, complete (Mod 4967) #(Spares supplied to Drg EB8.00.746 - 26FZ/44916)	1	-	P	J3/4
	Spares for:				
EB8.50.1643/D	COVER, (Make from 30B/9611218)	3	-	LM	-
EB8.50.191	RING, support (Pre Mod 4967)	1	L72	MR	-
EB8.50.1657	RING, support (Mod 4967)	1	L72	MR	-
EA6.50.551	SEAL, (Make from 26FZ/20518 EEAS 140)	2	-	LM	-
EB8.50.133	BAFFLE, (supplied undrilled)	2	L72	C	J3/7
	Attachment of baffle to cowl				
AS2230/404	Rivet, 1/8 in. c/sunk	6	-	C	J3/8
EB8.50.1097	DUCT, bleed valve	1	-	C	J3/9
	Attachment of duct to cowl				
AS1242/2C	Bolt, 2BA	16	-	C	J3/10
EB8.50.1325	DUCT extractor	1	-	C	J3/11
	Attachment of duct to cowl				
EB8.50.1331	Bolt, 2BA	4	S95	C	J3/12
AS1242/2C	Bolt, 2BA	12	-	C	J3/13
A27/CP	Nut, 2BA	12	-	C	J3/14
A27/CS	Nut, 2BA	2	-	C	J3/15
SP90/C8	Pin, split	2	-	C	J3/16
SP15/C	Washer	14	-	C	J3/17
EB8.00.438	EXHAUST OUTLET, starter	1	-	C	J3/18
	Attachment of outlet to cowl				
AS1242/1C	Bolt, 2BA	8	-	C	J3/19
EB8.50.1541	FERRULE, (Mod 3566) frame 2	1	S966	C	-
EB8.50.1111	GASKET, anti-icing attachment	1	Bestobell	C	J3/21
EB8.50.919	PACKING, anti-corrosive, bleed valve attachment	1	DTD124	C	J3/22
EB8.50.913	PACKING, anti-corrosive, extractor duct	1	DTD124	C	J3/23
EB8.50.915	PACKING, anti-corrosive, extractor duct bracket	2	DTD124	C	J3/24
EB8.50.971	PACKING, asbestos, exhaust tube	1	DTD278A	C	J3/25
EB8.50.929	PANEL, access, low pressure filter	1	-	C	J3/26
EB8.50.985	PANEL, access, low pressure filter	1	-	C	J3/27

POWER INSTALLATION
COWLINGS

Part No.	Description 1 2 3 4 5 6	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate	
EEAS1/2C EB8.50.1105	Attachment of panels to cowl Screw, csk, 2BA PIPE, anti-icing	12 1	S96 -	C C	J3/28 J3/29	R
A25/7C A25/8C SP14/C EB8.50.1329 EB8.50.1327 EB8.50.777 EB8.50.129	Attachment of pipe to cowling Bolt, 2BA Bolt, 2BA Washer, 2BA PLATE, shim, extractor duct PLATE, slide, extractor duct bracket RECEIVER, spigot complete Rim, air duct	2 4 6 2 2 1 2	- - - Lam.Alum L72 - L59	C C C C C C/MR C	J3/30 J3/31 J3/32 J3/33 J3/34 J3/35 J3/36	
AS2230/303 AS2230/405 EB8.50.13	Attachment of rim to air duct Rivet, csk, 5/32 in. dia. Rivet, csk, 1/8 in. dia. COWL, Top Rear Group (Spares supplied to Drg. EB8.00.471)	8 2 1	- - -	C C P	J3/37 J3/38 J1/39 J4/39	
EA1.50.281 EA1.50.282	Spares for: FASTENER, Toggle, Heavy Duty Group FASTENER, Toggle, Heavy Duty Group	2 2	- -	C/MR C/MR	J4/40 J4/41	
EA1.50.95	Spares for: HANDLE, Toggle Fastener Group	1	-	L	J4/42	
Terry 169-1 EA1.50.49	Spares for: RING, split SPRING (19 SWG)	1 1	- DTD215	C C	J4/43 J4/44	R
EA1.50.155 SP90/C8 EA1.50.283 EA1.50.284	Attachment of handle to fastener Pin Pin, split, 1/16 in. dia. FASTENER, Toggle, Light Duty Group FASTENER, Toggle, Light Duty Group	2 2 2 2	S11 - - -	C C C/MR C/MR	J4/45 J4/46 J4/47 J4/48	
EA1.50.97	Spares for: HANDLE, Toggle Fastener Group	1	-	L	J4/49	
Terry 169-1 EA1.50.49	Spares for: RING, split SPRING (19 SWG)	1 1	- DTD215	C C	J4/50 J4/51	R
EA1.50.157 SP90/C8 Dzus FJ5/70	Attachment of handle to fastener Pin Pin, split, 1/16 in. dia. FASTENER	2 2 5	S11 - -	C C C	J4/52 J4/53 J4/54	

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
Dzus FJ5/80	FASTENER	2	-	C	J4/55
Dzus FJ5/90	FASTENER	3	-	C	J4/56
EA1.50.161	PANEL, toggle fastener housing	8	-	C	J4/57
EA1.50.1793	WASHER, cup retaining	10	DTD124A	C	J4/58
EB8.50.15	COWL, Bottom Rear, Group (Pre-Mod.2800) (Spares supplied to Drg. EB8.00.473)	1	-	P	J1/59 J5/59
EB8.50.15/1	COWL, Bottom Rear, Group (Mod.2800) (Pre Mod 5282) (Spares supplied to Drg. EB8.00.473)	1	-	P	-
EB8.50.15/1x9	COWL, Bottom Rear, Group (Mod 5282) (Spares supplied to Drg EB8.00.473)	1	-	P	J1/60
Spares for:					
EB8.50.1385	BOLT, duct spring	6	S95	C	J6/61
EA1.50.65	BRACKET, forward hinge u/c cowl	1	DTD683	C	J5/62
Attachment of bracket to cowl					
A25/20C	Bolt, 2BA	4	-	C	J5/63
A27/CT	Locknut, 2BA	4	-	C	J5/64
SP15/C	Washer, 2BA	4	-	C	J5/65
EA1.50.67	BRACKET, aft hinge u/c cowl door	1	DTD683	C	J5/66
Attachment of bracket to cowl					
A25/20C	Bolt, 2BA	2	-	C	J5/67
A25/21C	Bolt, 2BA	2	-	C	J5/68
A27/CT	Locknut, 2BA	4	-	C	J5/69
SP16/C	Washer, 2BA	2	-	C	J5/70
SP15/C	Washer, 2BA	2	-	C	J5/71
EB8.50.1367	CABLE, Check and Tension Rod Assy.	1	-	C	J5/72
Spares for:					
EB8.50.1365	CABLE	1	-	C	J5/73
EB8.00.441	ROD, tension c/w ends	1	-	C	J5/74
EB8.50.1381	COLLAR, duct spring	6	L65	C	J6/75
EA1.50.317	DOOR, access u/c cowl linkage	1	-	C	J5/76
EB8.00.475	DOOR, Undercarriage Cowl Group (Not supplied with Bottom Rear Cowl Ref. Nos. 13269 or 32892)	1	-	P	J5/77
Spares for:					
EB8.50.1333	BUSH, aft hinge	1	L65	C	J5/78
EB8.50.1335	BUSH, aft hinge	1	L65	C	J5/79
EB8.50.1265	HINGE, half, aft	1	-	C/MR	J5/80
EB8.50.1267	HINGE, half, aft	1	-	C/MR	J5/81
Attachment of half hinge to door					
A25/2C	Bolt, 2BA	4	-	C	J5/82
SP15/C	Washer, 2BA	4	-	C	J5/83
EA1.50.321	HINGE, forward	1	-	C	J5/84
Attachment of hinge to door					
A25/2C	Bolt, 2BA	6	-	C	J5/85
SP15/C	Washer, 2BA	6	-	C	J5/86

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
	Attachment of door to cowl				
AGS899/6	Collar	2	-	C	J5/87
SP4/Z/F10	Pin, shackle	1	-	C	J5/88
SP4/Z/F18	Pin, shackle	1	-	C	J5/89
SP90/E6	Pin, split	2	-	C	J5/90
EA1.50.365	Washer	2	Lam.Alum.	C	J5/91
EB8.50.1637	DUCT, Inboard (Mod.2800) (Supplied to Pt. No. EB8.00.673 for spares purposes)	1	-	C	J6/92
EB8.50.1635	DUCT, Outboard (Mod.2800) (Supplied to Pt. No. EB8.00.671 for spares purposes)	1	-	C	J6/93
EB8.50.991	DUCT, Inboard (Pre-Mod.2800)	1	-	C	J6/94
EB8.50.993	DUCT, Outboard (Pre-Mod.2800)	1	-	C	J6/95
EB8.50.1375	DUCT, connecting	2	-	C	J6/96
EB8.04.6851	DUCT, air scoop	2	-	C	-
	Spares for:				
EB8.50.1575	DUCT, inlet	1	-	C	-
EB8.50.1605	DUCT, inlet	1	-	C	-
EA1.50.281	FASTENER, Toggle, Inboard Group	2	-	C/MR	J4/97 J5/97
EA1.50.282	FASTENER, Toggle, Outboard Group	2	-	C/MR	J4/98 J5/98
	Spares for:				
EA1.50.95	HANDLE, Toggle Fastener Group	2	-	C	J4/99
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/100
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/101
	Attachment of handle to fastener				
EA1.50.155	Pin	2	S11	C	J4/102
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/103
EA1.50.283	FASTENER, Toggle, Inboard Group	1	-	C/MR	J4/104 J5/104
EA1.50.284	FASTENER, Toggle, Outboard Group	1	-	C/MR	J4/105 J5/105 J5/105
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/106
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/107
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/108
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/109
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/110
Dzus FJ5/70	FASTENER	5	-	C	J5/111

R

R

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
Dzus FJ5/80	FASTENER	2	-	C	J5/112
Dzus FJ5/90	FASTENER	3	-	C	J5/113
EB8.50.1607	PANEL, access (Mod. 3160/B)	1	-	C	J5/114
	Spares for:				
Dzus F5/35DS	FASTENER	2	-	C	J5/115
Dzus GF5/175	GROMMET	2	-	C	J5/116
EB8.50.941	PANEL, fire	1	-	C	J5/117
	Attachment of panel to cowl				
AS1242/1B	Bolt, 4BA csk	8	-	C	J5/118
A27/BP	Nut, 4BA	8	-	C	J5/119
EB8.50.949	Tab	4	L72	C	J5/120
SP15/B	Washer, 4BA	8	-	C	J5/121
EA1.50.161	PANEL, toggle housing	6	-	C	J4/122
EEAS120	SEAL, rubber 6 in long (Pre Mod 5282)	2	EEAS120	LM	-
EB8.50.1675	SEAL, P 6 in long (Mod 5282) (Made from Ref.6147759)	2	EEAS842	LM	J5/122
EEAS157	SEAL, top plate	AR	-	C	J5/123
EB8.50.1383	SPRING, duct	6	DTD215	C	J6/124
EA1.50.1793	WASHER, cup retaining for fasteners	10	DTD124A	C	J5/125
EB8.50.1387	WASHER, duct spring	6	L72	C	J6/126
EA1.50.109	FORK-END, toggle hook	2	S11	C	J2/127
EA1.50.135	FORK-END, toggle hook	8	DTD683	C	J2/128
EA1.50.137	FORK-END, toggle hook	8	DTD683	C	J2/129
EA1.50.29	HOOK, toggle	8	S11	C	J2/130
EA1.50.45	HOOK, toggle	10	S11	C	J2/131
EB8.50.19	HOOP, upper cowling, complete	1	-	C	J1/132
EB8.50.21	HOOP, lower cowling, complete	1	-	C	J1/133
EB8.50.9	PANEL, Service Group (Spares supplied to Drg. EB8.00.469)	1	-	L	J1/134 J6/134
	Spares for:				
EB8.50.133	BAFFLE, (supplied undrilled)	1	L72	C	J6/135
	Attachment of baffle to cowl				
AS2230/303	Rivet, 3/32 in. csk.	6	-	C	J6/136
EA1.50.283	FASTENER, Toggle Group	2	-	L/MR	J4/137 J6/137
EA1.50.284	FASTENER, Toggle Group	2	-	L/MR	J4/138 J6/138
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/139
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/140
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/141

POWER INSTALLATION
COWLINGS

Part No.	Description 1 2 3 4 5 6	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/142
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/143
EB8.50.963	PACKING, anti-corrosive for balance piston vent	1	DTD124	C	J6/144
EA1.50.161	PANEL, toggle, housing	4	-	C	J4/145
EB8.50.941	PANEL, fire	1	-	C	J6/145 J5/146 J6/146
	Attachment of panel to cowl				
AS1242/1B	Bolt, 4BA	8	-	C	J5/147 J6/147
A27/BP	Nut, 4BA	8	-	C	J5/148 J6/148
EB8.50.949	Tab	4	L52	C	J5/149 J6/149
SP15/B	Washer, 4BA	8	-	C	J5/150 J6/150
EB8.50.129	RIM, air duct	1	L59	C	J6/151
	Attachment of rim to air duct				
AS2230/303	Rivet, csk, 3/32 in. dia.	8	-	C	J6/152
AS2230/405	Rivet, csk, 1/8 in. dia.	2	-	C	J6/153
EB8.50.951	VENT, balance piston	2	-	C	J6/154
	Attachment of vent to panel				
AS2230/303	Rivet, 3/32 c/sunk	20	-	C	J6/155
AS2051/419BH	Rivet	6	-	C	J6/156
AS2051/413BH	Rivet	6	-	C	J6/157
EA1.50.119	ROD, hook	4	S11	C	J2/158
EA1.50.121	ROD, hook	1	S11	C	J2/159
EA1.50.129	ROD, hook	4	S11	C	J2/160
EA1.50.131	ROD, hook, top cowl	2	S11	C	J2/161
EA1.50.133	ROD, hook, bottom cowl	2	S11	C	J2/162
EB8.50.503	ROD, hook	1	S11	C	J2/163
EB8.50.505	ROD, hook	1	S11	C	J2/164
EB8.50.507	ROD, hook	1	S11	C	J2/165
EB8.50.195	SCREW, cowl attachment	54	S96	C	J3/166
EA1.50.101	SPRING, toggle hook tension	4	DTD215	C	J2/167
	ENGINE COWLING INSTALLATION STARBOARD (EB8.50.3)	-	-	-	
	Spares for:				
EA1.50.103	CLIP, hook retaining	2	DTD390	C	J2/168
EA1.50.105	CLIP, hook retaining	2	DTD390	C	J2/169
EB8.50.7	COWL, Front Group (Pre Mod 4967)	1	-	L	J1/170 J3/171

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate	
	1 2 3 4 5 6					
EB8.50.7x6	COWL, Front Group (Mod 4967) (Spares supplied to Drg EB8.00.468)	1	-	L	J1/171 J3/171	R
	Spares for:					
EB8.50.1031	AIR INTAKE, complete (Pre Mod 4967)	1	-	L	J3/172	
EB8.50.1645	AIR INTAKE, complete (Mod 4967) (Spares supplied to Drg EB8.00.746 - 26FZ/44916)	1	-	L	J3/173	
	Spares for:					
EB8.50.1643/D	COVER, (Make from 30B/9611218)	3	-	LM	-	
EB8.50.191	RING, support (Pre Mod 4967)	1	L72	MR	-	
EB8.50.1657	RING, support (Mod 4967)	1	L72	MR	-	
EA6.50.551	SEAL, (Make from 26FZ/20518 EEAS 140)	1	-	LM	-	R
EB8.50.133	BAFFLE, (Supplied undrilled)	2	L72	C	J3/174	
	Attachment of baffle to cowl					
AS2230/404	Rivet, 1/8 in. csk.	6	-	C	J3/175	
EB8.50.1097	DUCT, bleed valve	1	-	C	J3/176	
	Attachment of duct to cowl					
AS1242/2C	Bolt, 2BA	16	-	C	J3/177	
EB8.50.1325	DUCT, extractor	1	-	C	J3/178	
	Attachment of duct to cowl					
EB8.50.1331	Bolt,	4	S95	C	J3/179	
AS1242/2C	Bolt, 2BA	12	-	C	J3/180	
A27/CP	Nut, 2BA	12	-	C	J3/181	
A27/CS	Nut, 2BA	2	-	C	J3/182	
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J3/183	
SP15/C	Washer	14	-	C	J3/184	
EB8.00.438	EXHAUST OUTLET, starter	1	-	C	J3/185	
	Attachment of outlet to cowl					
AS1242/1C	Bolt, 2BA	8	-	C	J3/186	R
EB8.50.1541	FERRULE, (Mod 3566) frame 2	1	S96	C	-	
EB8.50.1111	GASKET, anti-icing attachment	1	Bestobell	C	J3/187	
EB8.50.919	PACKING, anti-corrosive, bleed valve attachment	1	DTD124	C	J3/188	
EB8.50.913	PACKING, anti-corrosive, extractor duct	1	DTD124	C	J3/189	R
EB8.50.915	PACKING, anti-corrosive, extractor duct bracket	1	DTD124	C	J3/190	R
EB8.50.971	PANEL, asbestos, exhaust tube	1	DTD387A	C	J3/191	
EB8.50.929	PANEL, access, low pressure filter	1	-	C	J3/192	
EB8.50.985	PANEL, access, low pressure filter	1	-	C	J3/193	
	Attachment of panel					
EEAS1/2C	Screw, csk, 2BA	12	HTS	C	J3/194	R
EB8.50.1519	PIPE, anti-icing	1	-	C	J3/195	

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
	Attachment of pipe to cowl				
A25/7C	Bolt, 2BA	2	-	C	J3/196
A25/8C	Bolt, 2BA	4	-	C	J3/197
SP14/C	Washer, 2BA	6	-	C	J3/198
EB8.50.1329	PLATE, shim, extractor duct attachment	2	Lam.Alum.	C	J3/199
EB8.50.1327	PLATE, slide, extractor duct bracket	2	L72	C	J3/200
EB8.50.777	RECEIVER, spigot, complete	1	-	C/MR	J3/201
EB8.50.129	RIM, air duct	2	L59	C	J3/202
	Attachment of rim to air duct				
AS2230/303	Rivet, csk, 3/32 in. dia.	8	-	C	J3/203
AS2230/405	Rivet, csk, 1/8 in. dia.	2	-	C	J3/204
EB8.50.25	COWL, Top Rear Group (Spares supplied to Drq. SC7.00.472)	1	-	L	J1/205
	Spares for:				J4/205
EA1.50.281	FASTENER, Toggle, Heavy Duty Group	2	-	C/MR	J4/206
EA1.50.282	FASTENER, Toggle, Heavy Duty Group	2	-	C/MR	J4/207
	Spares for:				
EA1.50.95	HANDLE, Toggle Fastener Group	1	-	L	J4/208
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/209
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/210
	Attachment of handle to fastener				
EA1.50.155	Pin	2	S11	C	J4/211
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/212
EA1.50.283	FASTENER, Toggle, Light Duty Group	2	-	C/MR	J4/213
EA1.50.284	FASTENER, Toggle Light Duty Group	2	-	C/MR	J4/214
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/215
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/216
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/217
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/218
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/219
Dzus FJ5/70	FASTENER	5	-	C	J4/220
Dzus FJ5/80	FASTENER	2	-	C	J4/221
Dzus FJ5/90	FASTENER	3	-	C	J4/222
EA1.50.161	PANEL, toggle fastener housing	8	-	C	J4/223

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate	
	1 2 3 4 5 6					
EA1.50.1793	WASHER, cup retaining for fasteners	10	DTD124	C	J4/224	
EB8.50.16	COWL, Bottom Rear, Group (Pre-Mod.2800) (Spares supplied to Drg. EB8.00.474)	1	-	L	J1/225 J5/225	
EB8.50.16/1	COWL, Bottom Rear, Group (Mod 2800) (Pre Mod 5282) (Spares supplied to Drg.EB8.00.474)	1	-	L	-	R
EB8.50.16/1x9	COWL, Bottom Rear, Group. (Mod 5282) (Spares supplied to Drg. EB8.00.474)	1	-	L	J1/226	R
	Spares for:					
EB8.50.1640	ANGLE	1	L59	C	-	
EB8.50.1642	ANGLE	1	L59	C	-	
EB8.50.1385	BOLT, duct spring	6	S95	C	J6/227	
EA1.50.66	BRACKET, forward hinge u/c cowl door	1	DTD683	C	J5/228	
	Attachment of bracket to cowl					
A25/20C	Bolt, 2BA	4	-	C	J5/229	
A27/CT	Locknut, 2BA	4	-	C	J5/230	
SP15/C	Washer, 2BA	4	-	C	J5/231	
EA1.50.68	BRACKET, aft hinge, u/c cowl door	1	DTD683	C	J5/232	
	Attachment of bracket to cowl					
A25/20C	Bolt, 2BA	2	-	C	J5/229	
A25/21C	Bolt, 2BA	2	-	C	J5/234	
A27/CT	Locknut, 2BA	4	-	C	J5/235	
SP16/C	Washer, 2BA	2	-	C	J5/236	
SP15/C	Washer, 2BA	2	-	C	J5/237	
EB8.50.1367	CABLE, Check, and Tension Rod Assembly	1	-	C	J5/238	
	Spares for:					
EB8.50.1365	CABLE	1	-	C	J5/239	
EB8.00.441	ROD, tension, c/w ends	1	-	C	J5/240	
EB8.50.1381	COLLAR, duct spring	6	L65	C	J6/241	
EA1.50.318	DOOR, access, u/c cowl linkage	1	-	C	J5/242	
EB8.00.476	DOOR, Undercarriage Cowl Group (Not supplied with Bottom Rear Cowl Ref. Nos. 13270 or 32893)	1	-	P	J5/243	
	Spares for:					
EB8.50.1333	BUSH, aft hinge	1	L65	C	J5/244	
EB8.50.1335	BUSH, aft hinge	1	L65	C	J5/245	
EB8.50.1266	HINGE, half, aft	1	-	C/MR	J5/247	
EB8.50.1268	HINGE, half, aft	1	-	C/MR	J5/248	
	Attachment of half hinge to door					
A25/2C	Bolt, 2BA	4	-	C	J5/249	
SP15/C	Washer 2BA	4	-	C	J5/250	
EA1.50.321	HINGE, forward	1	-	C	J5/251	

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
	Attachment of hinge to door				
A25/2C	Bolt, 2BA	6	-	C	J5/252
SP15/C	Washer, 2BA	6	-	C	J5/253
	Attachment of door to cowl				
AGS899/6	Collar	2	-	C	J5/254
SP4/Z/F10	Pin, shackle	1	-	C	J5/255
SP4/Z/F18	Pin, shackle	1	-	C	J5/256
SP90/E6	Pin, split	2	-	C	J5/257
EA1.50.365	Washer	2	Lam.Alum.	C	J5/258
EB8.50.992	DUCT, inboard (Pre Mod.2800)	1	-	C	J6/259
EB8.50.994	DUCT, outboard (Pre Mod.2800)	1	-	C	J6/260
EB8.50.1638	DUCT, inboard (Supplied to Pt. No. EB8.00.674 for spares purposes) (Mod 2800)	1	-	C	J6/261
EB8.50.1636	DUCT, outboard (Supplied to Pt. No. EB8.00.672 for spares purposes) (Mod 2800)	1	-	C	J6/262
EB8.50.1375	DUCT, connecting	2	-	C	J6/263
EA1.50.281	FASTENER, Toggle, Inboard Group	2	-	C/MR	J4/264
EA1.50.282	FASTENER, Toggle, Outboard Group	2	-	C/MR	J5/264
	Spares for:				J4/265
EA1.50.95	HANDLE, Toggle Fastener Group	1	-	L	J4/266
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/267
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/268
	Attachment of handle to fastener				
EA1.50.155	Pin	2	S11	C	J4/269
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/270
EA1.50.283	FASTENER, Toggle, Inboard Group	1	-	C/MR	J4/271
EA1.50.284	FASTENER, Toggle, Outboard Group	1	-	C/MR	J5/271
	Spares for:				J4/272
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/273
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/274
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/275
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/276
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/277
Dzus FJ5/70	FASTENER	5	-	C	J5/278
Dzus FJ5/80	FASTENER	2	-	C	J5/279

POWER INSTALLATION
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
Dzus FJ5/90 EB8.50.1607	FASTENER PANEL, Access (Mod.3160/B)	3 1	- -	C C	J5/280 J5/281
	Spares for:				
Dzus F5/35DS Dzus GF5/175 EB8.50.941	FASTENER GROMMET PANEL, fire	2 2 1	- - -	C C C	J5/282 J5/283 J5/284
	Attachment of panel to cowl				
AS1242/1B A27/BP EB8.50.949 SP15/B EA1.50.161	Bolt, 4BA csk. Nut, 4BA Tab Washer, 4BA PANEL, toggle housing	8 8 4 8 6	- - L72 - -	C C C C C	J5/285 J5/286 J5/287 J5/288 J4/289
EEAS120 EB8.50.1675	SEAL, rubber 6 in long (Pre Mod 5282) SEAL, P 6 in long (Mod 5282) (Made from Ref.6147759)	2 2	EEAS120 EEAS842	LM LM	- J5/289
EEAS157 EB8.50.1383 EA1.50.1793 EB8.50.1387 EA1.50.109 EA1.50.135 EA1.50.137 EA1.50.29 EA1.50.45 EB8.50.20 EB8.50.21 EB8.50.11	SEAL, top plate SPRING, duct WASHER, cup retaining for fasteners WASHER, duct spring FORK-END, toggle hook FORK-END, toggle hook FORK-END, toggle hook HOOK, toggle HOOK, toggle HOOP, upper cowling, complete HOOP, lower cowling, complete PANEL, Service Group (Spares supplied to Drg. EB8.00.470)	AR 6 10 6 2 8 8 8 8 1 1 1	- DTD215 DTD124A L72 S11 DTD683 DTD683 S11 S11 - - -	C C C C C C C C C C C P	J5/290 J6/291 J5/292 J6/293 J2/294 J2/295 J2/296 J2/297 J2/298 J1/299 J1/300 J1/301 J6/301
	Spares for:				
EB8.50.133	BAFFLE, (Supplied undrilled)	1	L72	C	J6/302
	Attachment of baffle to cowl				
AS2230/303 EA1.50.283 EA1.50.284	Rivet, csk. FASTENER, Toggle Group FASTENER, Toggle Group	6 2 2	- - -	C C/MR C/MR	J6/303 J4/304 J6/304 J4/305 J6/305
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/306
	Spares for:				
Terry 169-1 EA1.50.49	RING, split SPRING (19 SWG)	1 1	- DTD215	C C	J4/307 J4/308
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/309

POWER INSTALLATION
COWLINGS

Canberra P R Mk 9

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	1 2 3 4 5 6				
SP90/C8	Pin split, 1/16 in. dia.	2	-	C	J4/310
EB8.50.963	PACKING anti-corrosive, for balance piston vent	1	DTD124	C	J6/311
EA1.50.161	PANEL, toggle, housing	4	-	C	J4/312
EB8.50.941	PANEL, fire	1	-	C	J6/312
	Attachment of panel to cowling				J5/313
					J6/313
AS1242/1B	Bolt, 4BA	8	-	C	J5/314
A27/BP	Nut, 4BA	8	-	C	J6/314
EB8.50.949	Tab	4	L72	C	J5/315
SP15/B	Washer, 4BA	8	-	C	J6/315
EB8.50.129	RIM, air duct	1	L59	C	J5/316
	Attachment of rim to air duct				J6/316
AS2230/303	Rivet, csk. 3/32 in. dia.	8	-	C	J5/317
AS2230/405	Rivet, csk. 1/8 in. dia.	2	-	C	J6/317
EB8.50.951	VENT, balance piston	2	-	C	J6/318
	Attachment of vent to panel				
AS2230/303	Rivet, 3/32 in.	20	-	C	J6/319
AS2051/419BH	Rivet	6	-	C	J6/320
AS2051/413BH	Rivet	6	-	C	J6/321
EA1.50.119	ROD, hook	4	S11	C	J6/322
EA1.50.121	ROD, hook	1	S11	C	J2/323
EA1.50.129	ROD, hook	4	S11	C	J2/324
EA1.50.131	ROD, hook, top cowl	2	S11	C	J2/325
EA1.50.133	ROD, hook, bottom cowl	2	S11	C	J2/326
EB8.50.503	ROD, hook	1	S11	C	J2/327
EB8.50.505	ROD, hook	1	S11	C	J2/328
EB8.50.507	ROD, hook	1	S11	C	J2/329
EB8.50.195	SCREW, cowl attachment	54	S96	C	J2/330
EA1.50.101	SPRING, toggle hook tension	4	DTD215	C	J2/331
					J2/332
					J3/333
					J2/334