

UNDERCARRIAGE

NOSEWHEEL

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
	EA9.40.1	NOSEWHEEL, ASSEMBLY	—	—	—	
22055	EA9.40.15	Spares for:— BLOCK, flexible hose support	2	LFS21	C	WC5/1
28D/9133011	A25/2C	Attaching parts for EA9.40.15:— Bolt, 2BA	1	—	C	WC5/2
22057	EA9.40.13	Clip	1	L72	C	WC5/3
28M/1012015	AGS2001C1/66	Nut, 2BA	1	—	C	WC5/4
22329	EA9.40.17	Washer, corner	2	L72	C	WC5/5
28D/9140202	AS1246/1C	BOLT, 2BA round head	1	—	C	WC6/75
28M/1006473	A27CT	Attaching parts for AS1246/1C:— Nut, 2BA thin	1	—	C	WC6/76
28W/9419486	SP16B	Washer, 4BA	1	—	C	WC6/77
28W/9416643	SP47C	Washer, 3/16" dia spring	1	—	C	WC6/78
3753	EA1.40.617	BOLT, adjusting, undercarriage door crosshead stop	2	HTS	C	WC5/6
22373	EA9.40.19	BOLT, connecting operating jack to undercarriage locking lever (Pre—Mod 2704)	1	S96	C	WC5/7
32172	EA9.40.21	BOLT, connecting operating jack to undercarriage locking lever (Mod 2704)	1	S96	C	WC5/7
28M/5808571	A27GS	Attaching parts for EA1.40.19 or EA1.40.21:— Nut, slotted 5/16" BSF	1	—	C	WC5/7A
28P/9527619	SP90C7	Pin, split, 1/16" dia	1	—	C	WC5/7B
169	EA1.40.605	BOLT, hydraulic jack anchor	1	S65	C	WC5/8
28M/1011467	A27ES	Attaching parts for EA1.40.605:— Nut, slotted 1/4" BSF	1	—	C	WC5/8A
28P/9527619	SP90C7	Pin, split 1/16" dia	1	—	C	WC5/8B
28W/9419403	SP13G	Washer, 5/16"	1	—	C	WC5/8C
4507	EA3.40.139	BOLT, jack attachment to crosshead	1	S11	C	WC5/9
28M/1011467	A27ES	Attaching parts for EA3.40.139:— Nut, slotted 1/4" BSF	1	—	C	WC5/9A
28P/9527619	SP90C7	Pin, split 1/16" dia	1	—	C	WC5/9B
163	EA1.40.491	BOLT, nosewheel door 'Up' latch forward	1	S11	C	WC6/1
28M/5808571	A27GS	Attaching parts for EA11.40.491:— Nut	1	—	C	WC6/1A
28P/9527619	SP90C7	Pin, split 1/16" dia.	1	—	C	WC6/1B
28W/9419403	SP13G	Washer, 5/16" dia thin	1	—	C	WC6/1C

UNDERCARRIAGE

NOSEWHEEL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
		1 2 3 4 5 6				
164	EA1.40.493	BOLT, nosewheel door 'Up' latch aft	1	S11	C	WC5/10
28M/5808571	A27GS	Attaching parts for EA1.40.493:—	1	—	C	WC5/10A
28P/9527619	SP90C7	Nut, slotted 5/16" BSF	1	—	C	WC5/10B
28W/9419403	SP13G	Pin, 1/16" dia	1	—	C	WC5/10C
		Washer, 5/16" dia thin	1	—	C	WC5/10C
22056	EA9.40.11	BOLT, nose undercarriage jack hinge	1	S96	C	WC5/11
		Attaching parts for EA9.40.11:—				
28M/1011467	A27ES	Nut, slotted 1/4" BSF	1	—	C	WC5/11A
28P/9527619	SP90C7	Pin, split 1/16" dia	1	—	C	WC5/11B
28W/9419407	SP13L	Washer, 7/16" dia plain	2	—	C	WC5/41
1877	EEAS28/30EU	Washer, special 18 SWG	1	DTD124	C	WC5/11C
170	EA1.40.683	BOLT, radius rod to leg	1	S11	C	WC7/71
		Attaching parts for EA1.40.683:—				
28M/9129449	A27LS	Nut, slotted 7/16" BSF	1	—	C	WC7/77
28P/9560929	SP90E8	Pin, split 3/32" dia	1	—	C	WC7/78
202	EA1.40.325	Washer, special	1	—	C	WC7/79
12023	EA3.40.159	BRACKET, UNDERCARRIAGE 'UP' HOOK, ASSEMBLY (PRE—MOD 4449)	1	—	B	WC6/2
1439142	EA3.40.251	BRACKET, UNDERCARRIAGE 'UP' HOOK, ASSEMBLY (MOD 4449—S.O.O.)	1	—	B	WC6/2
		Consisting of:—				
	EA1.40.385	BEAM, BRACKET LOCKING HOOK, ASSEMBLY (PRE—MOD 5100)	1	—	—	WC6/3
	EA3.40.265	BEAM, BRACKET LOCKING HOOK, ASSEMBLY (ALT R60/304—MOD 5100)	1	—	—	WC6/3
		Spares for:—				
	EA1.40.365	BRACKET, beam	1	—	C	WC6/44A
20845	EA1.40.369	LUG (Pre—Mod 5100)	1	L40	C/MR	WC6/4
	EA3.40.263	LUG (Alt R60/304—Mod 5100)	1	L65	C/MR	WC6/4
		Attaching parts for EA3.40.263:—				
28D/9133012	A25/3C	Bolt, 2BA	2	—	C	WC6/4B
28M/9433473	AGS2002C1	Nut, 2BA	2	—	C	WC6/4C
28W/9457834	SP124D	Washer	4	—	C	WC6/4D
25628	EA1.40.377	PLATE, locking	1	L72	C	WC6/5
		Attaching parts for EA1.40.385:—				
28D/1012995	A25/22C	Bolt, 2BA	8	—	C	WC6/6
28M/9403520	A27CP	Nut, 2BA	8	—	C	WC6/7
	EA1.40.381	Tube, distance	8	L62	LM	WC6/8
28W/9416643	SP47C	Washer, spring 2BA	8	—	C	WC6/9
12024	EA3.40.151	BOLT, stop, for buffer, assembly	2	—	C	WC6/10
		Attaching parts for EA3.40.151:—				
28M/4095808	AGS2001J1	Nut, 3/4"	1	MS	C	WC6/11
174	EA1.40.399	Washer, laminum	1	LA	C	WC6/12
28W/9419489	SP16J	Washer	1	—	C	WC6/15

UNDERCARRIAGE

NOSEWHEEL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
		1 2 3 4 5 6				
22251	EA1.40.373	. . BRACKET, hook suspension	1	S11	C	WC6/13
28M/4095808	AGS2001J1	Attaching parts for EA1.40.373:—	1	MS	C	WC6/14
28W/9419489	SP16J	. . Nut, 3/8"	1	—	C	WC6/15
174	EA1.40.399	. . Washer	1	LA	C	WC6/12
		. . Washer, laminum	1	—	C	WC6/12
12025	EA3.40.143	. . HOOK, UNDERCARRIAGE 'UP' LOCK ASSEMBLY (PRE—MOD 4449)	1	—	B	WC6/17
1439143	EA3.40.249	. . HOOK, UNDERCARRIAGE 'UP' LOCK ASSEMBLY (MOD 4449—S.O.O.)	1	—	B	WC6/17
		Consisting of:—				
13109	EA3.40.147	. . . BOLT, special	1	DTD126A	C	WC6/18
	EA1.40.393	. . . BUSH	1	DTD197	—	WC6/19
	EA3.40.145	. . . HOOK, 'Up' latch (Pre—Mod 4449)	1	—	—	WC6/20
	EA3.40.243	. . . HOOK, 'Up' latch (Mod 4449—S.O.O.)	1	HTS	—	WC6/20
28M/9403520	A27CP	. . . NUT, 2BA	1	—	C	WC6/21
28W/9416643	SP47C	. . . WASHER, spring	1	—	C	WC6/22
		Attaching parts for EA3.40.249:—				
171	EA1.40.371	. . Bolt, pivot for hook	1	S11	C	WC6/23
28M/1011467	A27ES	. . Nut, 1/4" BSF	1	—	C	WC6/24
28P/9527619	SP90C7	. . Pin, split	1	—	C	WC6/24A
20846	EA1.40.389	. . SCREW, adjusting, hook stop	1	S11	C/MR	WC6/25
		Attaching parts for EA1.40.389:—				
28M/1011475	A27EP	. . Nut, adjusting 1/4" BSF	1	—	C	WC6/26
4694	EA3.40.93	. . CROSSHEAD, NOSEWHEEL DOORS, C/W VALVE, TRIP, ASSEMBLY	1	—	B/MR	WC5/12
		Spares for:—				
5514	EA3.40.97	. . PIN, roller top	1	S11	C	WC5/13
12926	EA3.40.181	. . PIN, roller bottom	1	S11	C	WC5/14
28P/9496825	SP90C9	. . PIN, split	2	—	C	WC5/15A
178	EA1.40.553	. . ROLLER, guide	2	DTD683	C	WC5/15
5515	EA1.40.561	. . VALVE, trip	1	—	C	WC5/16
		Attaching parts for EA1.40.561:—				
28P/9710567	SP90C5	. . Pin, split	1	—	C	WC5/17A
28S/1011504	A33C32	. . Screw, 2BA, 1" long c/sunk	1	—	C	WC5/17
	EA3.40.95	. . YOKE, crosshead	1	—	—	WC5/18
39181	EA9.40.351	. . LEVER, micro-switch operating, undercarriage door front latch	1	—	C	WC6/27
		Attaching parts for EA9.40.35:—				
28D/9140647	A25/14C	. . Bolt, 2BA	1	HTS	C	WC6/28
28M/1012015	AGS2001C1/66	. . Nut, 2BA	1	MS	C	WC6/29
3755	EA1.40.731	. . Piece, distance	1	—	C	WC6/30
4141	EA1.40.989	. . Shim	2	—	C	WC6/31
	AS2811/7/023	. . Spacer	2	L62	LM	WC6/32
3751	EA1.40.567	. . LEVER, UNDERCARRIAGE SEQUENCE VALVE, ASSEMBLY	1	—	B/MR	WC5/19
		Spares for:—				
179	EA1.40.569	. . TAPPET, valve screw	1	S11	C	WC5/20
		Attaching parts for EA1.40.569:—				
28M/1007403	A27ET	. . Nut, 1/4" BSF, adjusting	1	—	C	WC5/21
		Attaching parts for EA1.40.567:—				
166	EA1.40.581	. . Bolt, fulcrum, undercarriage door actuating sequence valve	1	S11	C	WC5/22
28M/1006939	A27GP	. . Nut, 3/16" BSF	1	—	C	WC5/23
1078	EEAS28/35FU	. . Washer, packing, .33" dia	1	DTD124	C	WC5/24

UNDERCARRIAGE

AP101B-0415-3A

NOSEWHEEL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
		1 2 3 4 5 6				
3754	EA1.40.703	LEVER, BRACKET, UNDERCARRIAGE SEQUENCE VALVE, ASSEMBLY	1	—	B/MR	WC6/33
28D/9140647	A25/14C	Spares for:—	2	—	C	WC6/34A
	EA1.40.707	BOLT, 2BA 1.85" long	1	—	—	WC6/35
	EA1.40.705	BRACKET, valve, sequence, front	1	—	—	WC6/34
28D/9133012 28M/1012015	A25/3C	BRACKET, valve, sequence, rear	2	—	C	WC6/44
	AGS2001C1/66	Attaching parts for EA1.40.707 & EA1.40.705:—	2	—	C	WC6/45
		Bolt, 2BA	2	—	C	WC6/45
1438863	EA1.40.573	Nut, 2BA	1	DTD683	—	WB6/36
13182 28M/5808573 28P/9527619 28W/9419475 45623	EA1.40.709	LEVER, sequence valve operating	1	S11	C	WC6/37
	A27CS	Attaching parts for EA1.40.573:—	1	—	C	WC6/38
	SP90C7	Bolt, operating lever fulcrum	1	—	C	WC6/38A
	SP15C	Nut, 2BA	1	—	C	WC6/40
	EA1.40.711	Pin, split	1	—	C	WC6/41
		Washer, 2BA	2	L40	—	WC6/41
		Washer, fulcrum bolt	2	—	—	WC6/41
28M/9403520 179	A27CP	NUT	2	—	C	WC6/34B
	EA1.40.569	TAPPET, valve screw	1	S11	C	WC6/42
28M/1007403	A27ET	Attaching parts for EA1.40.569:—	1	—	C	WC6/43
		Nut, adjusting	1	—	C	WC6/43
28W/1009699 180	SP55C	WASHER	2	—	C	WC6/34C
	EA1.40.531	LINK DOOR, OPERATING, ASSEMBLY	2	—	C	WC5/25
4778	EA1.40.535	Spares for:—	2	—	C	WC6/26
33793	EA1.40.541	BOLT, eye, assembly	—	—	—	—
		Attaching parts for EA1.40.535:—	—	—	—	—
168 167 28M/1011467 28P/9527619	EA1.40.533	Nut	1	—	—	WC5/28
	EA1.40.595	TUBE, assembly	1	—	C	WC5/30
	EA1.40.593	Attaching parts for EA1.40.533:—	1	—	C	WC5/29
	A27ES	Bolt, link to crosshead	2	—	C	WC5/31
	SP90C7	Bolt, link to door	2	—	C	WC5/31A
8987	EA3.40.169	Nut, 1/4" BSF	1	—	B	WC6/46
5503 5504	EA3.40.133	Pin, split	1	Shore 40	C	WC6/47
	EA3.40.127	MUDGUARD, NOSEWHEEL, ASSEMBLY	1	L72	C	WC6/48
28D/1013177 5505 28M/1007403	AS1242/2E	Consisting of:—	9	HTS	C	WC6/49
	EA3.40.131	FLAP, rubber, nosewheel mudguard	3	S95	C	WC6/51
	A27ET	MUDGUARD, nosewheel	6	MS	C	WC6/50
		Attaching parts for EA3.40.127:—	6	—	—	—

NOSEWHEEL

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
6948	EA3.40.165	. . STAY, mudguard, assembly	1	—	C	WC6/32
6949	EA3.40.167	. . STAY, end, mudguard, attachment	3	DTD683	C	WC6/53
		Attaching parts for EA3.40.167:—				
28D/9133012	A25/3C	. . Bolt, 2BA	12	HTS	C	WC6/54
28M/1006473	A27CT	. . Nut, 2BA	12	MS	C	WC6/55
28W/9419475	SP15C	. . Washer	12	—	C	WC6/56
20930	EA3.40.135	. . STRIP, backing	1	L72	C/MR	WC6/57
		Attaching parts for EA3.40.135:—				
28D/1007974	AS1242/1/2C	. . Bolt, 2BA	3	HTS	C	WC6/58
5506	EA3.40.137	. . Nut, 2BA	3	S95	C	WC6/59
		Attaching parts for EA3.40.169:—				
28D/1011300	A25/7J	. Bolt, 3/8" BSF	3	HTS	C	WC6/60
28W/9419477	SP15J	. Washer, 3/8" BSF	3	LA	C	WC6/61
8988	EA3.40.170	. MUDGUARD, NOSEWHEEL, ASSEMBLY	1	—	B	WC6/62
		Spares for this assembly are identical with those for Part No. EA3.40.169:—				
28N/9156370	SP21	. NIPPLE, lubricating	1	—	C	WC5/45
28M/1007403	A27ET	. NUT, locking 1/4" BSF	1	—	C	WC5/46
3688	EA6.40.37	. ROD, RADIUS, ASSEMBLY (PRE—MOD 4449)	1	—	A	WC7/1
1439144	EA3.40.261	. ROD, RADIUS, ASSEMBLY (MOD 4449—S.O.O.)	1	—	A	WC7/1
		Consisting of:—				
5126	EA3.40.77	. . BRACKET, micro switch (Pre—Mod 4449)	1	L72	C	WC7/2
1439148	EA3.40.255	. . BRACKET, micro switch, assembly (Mod 4449—S.O.O.)	1	—	C	WC7/2
		Attaching parts for EA3.40.77 or EA3.40.255:—				
28D/9436920	A25/1C	. . Bolt, 2BA	3	—	C	WC7/3
28W/9416643	SP47C	. . Washer, spring	3	—	C	WC7/4
3656	EA3.40.65	. . BUSH, spring, plunger	1	DTD197	C	WC7/5
186	EA1.40.621	. . DOWEL	2	S11	C	WC7/6
1893	EA6.40.21	. . END, PLUG, RADIUS ROD, ASSEMBLY	1	—	B	WC7/7
		Spares for:—				
187	EA1.40.363	. . BUSH, bearing	2	DTD197	C	WC7/8
28N/9156370	SP21	. . NIPPLE, lubricating	1	—	C	WC7/9
	EA6.40.31	. . PLUG, end	1	—	C	WC7/7A
4937	EA1.40.311	. . FINGER, operating undercarriage 'up' micro switch	1	L40	C	WC7/10
		Attaching parts for EA1.40.311:—				
4447	EA1.40.321	. . Bolt, bearing, for micro switch operating finger	1	DTD126A	C	WC7/12
28M/9436836	AGS2001C2	. . Nut, 2BA	1	—	C	WC7/13
28W/9419402	SP13C	. . Washer	1	—	C	WC7/14
1894	EA6.40.29	. . FORK, strut end	1	DTD683	C	WC7/15
3655	EA3.40.73	. . HOUSING, spring locking plunger	1	L40	C	WC7/16
		Attaching parts for EA3.40.73:—				
28D/1011240	A25/5E	. . Bolt, 1/4" BSF	4	—	C	WC7/17
28W/9416644	SP47E	. . Washer, 1/4" BSF	4	—	C	WC7/18

UNDERCARRIAGE

NOSEWHEEL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
		1 2 3 4 5 6				
41255	EA9.40.49	LEVER, LOCKING, NOSEWHEEL UNDERCARRIAGE, ASSEMBLY	1	—	B	WC7/19
		Spares for:—				
190	EA1.40.337	BUSH, bearing	2	DTD197	C	WC7/20
28N/9156370	SP21	NIPPLE, lubricating	1	—	C	WC7/21
192	EA1.40.339	ROLLER, assembly	1	—	C	WC7/22
		Attaching parts for EA1.40.339:—				
188	EA1.40.343	Bolt	1	S11	C	WC7/23
28M/1011467	A27ES	Nut, 1/4" BSF	1	—	C	WC7/24
28P/9527619	SP90C7	Pin, split	1	—	C	WC7/25
28W/9419405	SP15E	Washer	1	—	C	WC7/26
191	EA1.40.341	ROLLER, assembly	1	—	C	WC7/27
		Attaching parts for EA1.40.341:—				
189	EA1.40.345	Bolt	1	S11	C	WC7/28
28M/1011467	A27ES	Nut, 1/4" BSF	1	—	C	WC7/29
28P/9527619	SP90C7	Pin, split	1	—	C	WC7/30
		Attaching parts for EA9.40.49:—				
34309	EA9.40.47	Bolt, operating lever bearing	1	S96	C	WC7/32
28M/1011476	A27JS	Nut, 3/8" BSF	1	—	C	WC7/33
28P/9527619	SP90C7	Pin, split	1	—	C	WC7/33A
203	EA1.40.327	Washer, at operating lever bearing	1	DTD126A	C	WC7/35
1889	EA6.40.23	LINK, STAY, NOSEWHEEL UNDERCARRIAGE AT RADIUS ROD, ASSEMBLY	1	—	C	WC7/36
		Spares for:—				
194	EA1.40.359	BUSH, bearing	2	DTD197	C	WC7/37
195	EA1.40.361	BUSH, bearing	2	DTD197	C	WC7/38
28N/9156370	SP21	NIPPLE, lubricating	2	—	C	WC7/39
		Attaching parts for EA6.40.23:—				
184	EA1.40.681	Bolt, connecting radius rod and stay link	1	S11	C	WC7/40
28M/9129449	A27LS	Nut, 7/16" BSF	2	—	C	WC7/41
28P/9560929	SP90E8	Pin, split	1	—	C	WC7/41A
28S/9146378	A35C8	Screw, 2BA	1	—	C	WC7/43
202	EA1.40.325	Washer, cap	2	DTD126A	C	WC7/44
28W/9416643	SP47C	Washer, spring	1	—	C	WC7/45
1100	EEAS37/24A	NIPPLE, 1/4"	24	—	C	WC7/47
6187	EA1.40.415	PAD, switch, undercarriage 'Down' micro switch (Pre—Mod 4449)	1	L40	C	WC7/48
1439145	EA3.40.241	PAD, switch, undercarriage 'Down' micro switch (Mod 4449—S.O.O.)	1	L40	C	WC7/48
		Attaching parts for EA1.40.415 or EA3.40.241:—				
28D/9133012	A25/3C	Bolt, 2BA	3	—	C	WC7/49
28W/9416643	SP47C	Washer, spring	3	—	C	WC7/50

UNDERCARRIAGE

NOSEWHEEL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
		1 2 3 4 5 6				
3659	EA3.40.75	. . PIN, latch	1	S11	C	WC7/51
197	EA1.40.277	. . PLATE, stop stay link	1	S11	C	WC7/52
		Attaching parts for EA1.40.277:—				
28D/1011240	A25/5E	. . Bolt, 1/4" BSF	2	—	C	WC7/53
28W/9416644	SP47E	. . Washer	2	—	C	WC7/54
3657	EA3.40.67	. . SCREW, cap retaining undercarriage locking plunger	1	L40	C	WC7/55
3660	EA3.40.71	. . SCREW, grub latch pin and bush retaining	1	S97	C	WC7/56
199	EA1.40.431	. . SPINDLE, hook latch nosewheel undercarriage stay	1	S11	C	WC7/58
		Attaching parts for EA1.40.431:—				
28N/2001540	AGS2031/4	. . Circlip, 'Seegar' external, 3/16" dia for undercarriage hook latch spindle	2	—	C	WC7/59
6182	EA1.40.309	. . Tube, distance	1	—	—	WC7/60
	EEAS38/4A	. . SPOKE, 1/4" BSF (Make from 28R/6330)	12	S11	LM	WC7/61
3658	EA3.40.69	. . SPRING, compression operating locking plunger, 14 SWG	1	Spring	C	WC7/62
201	EA1.40.313	. . SPRING, leaf, for micro switch operating finger (Pre—Mod 4449)	1	Spring Steel	C	WC7/63
1439146	EA3.40.259	. . SPRING, leaf for micro switch operating lever (Mod 4449—S.O.O.)	1	S513	C	WC7/63
5CW/9438275	BURGESS ↑	. . SWITCH, micro undercarriage 'up' (Pre—Mod 3562)	1	—	B	WC7/64
5CW/9404373	BURGESS MS5752	. . SWITCH, micro undercarriage 'up' (Mod 3562) (Pre—Mod 4080)	1	—	C	WC7/64
5CW/1085884	HONEYWELL 1H.Y1	. . SWITCH, micro undercarriage 'up' (Mod 4080) (Pre—Mod 4959)	1	—	B	WC7/64
5CW/6200653	DOWTY DN1322ZMK3	. . SWITCH, micro undercarriage 'up' (Mod 4959) Attaching parts for Ref 5CW/9438275, 5CW/9504373, 5CW/1085884 or 5CW/6200653:—	1	—	B	WC7/64
28D/1011011	A25/8B	. . Bolt, 4BA	2	—	C	WC7/65
28M/1278189	AGS2001B1	. . Nut, 4BA	2	—	C	WC7/67
28W/9419474	SP15B	. . Washer	2	—	C	WC7/68

UNDERCARRIAGE

NOSEWHEEL

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Mati. Spec.	Cl. of Equip M.R. L.M.	Plate No.
5CW/9994686	BURGESS †	. SWITCH, micro undercarriage 'down' (Pre—Mod 3562)	1	—	B	WC7/64A
5CW/4400240	BURGESS MS5750	. SWITCH, micro undercarriage 'down' (Mod 3562) (Pre—Mod 4080)	1	—	C	WC7/64A
5CW/1085884	HONEYWELL 1H.Y1	. SWITCH, micro undercarriage 'down' (Mod 4080) (Pre—Mod 4959)	1	—	B	WC7/64A
5CW/6200653	DOWTY DN1322ZMK3	. SWITCH, micro undercarriage 'down' (Mod 4959) Attaching parts for Ref. 5CW/9994686, 5CW/4400240, 5CW/1085884 or 5CW/6200653:—	1	—	B	WC7/64A
28D/1214303	AS1242/10B	. Bolt, 4BA	2	—	C	WC7/65A
28M/1278189	AGS2001B1	. Nut, 4BA	2	—	C	WC7/67
28W/9419474	SP15B	. Washer	2	—	C	WC7/68
1895	EA6.40.27	. TUBE, strut, nose, undercarriage Attaching parts for EA6.40.37 or EA3.40.261:—	1	T60	C	WC7/69
161	EA1.40.451	. Bolt, c/w spoke and nut, radius rod strut bearing	1	—	C	WC7/70
28M/9129449	A27LS	. Nut, 7/16" BSF	1	—	C	WC7/72
28P/9560929	SP90E8	. Pin, split	1	—	C	WC7/72A
181	EA1.40.449	. Pin, strut, pivot radius rod bearing	1	S65	C	WC7/73
202	EA1.40.325	. Washer	2	DTD226A	C	WC7/76
3748	EA1.40.455	. SCREW, grub 2BA strut bearing retaining	1	S11	C/MR	WC5/33
28S/9997545	A31C16	. SCREW, 2BA cheese head Attaching parts for A31C16:—	1	—	C	WC5/42
28M/1006473	A27CT	. Nut, 2BA thin	1	—	C	WC5/43
28W/9416643	SP47C	. Washer, spring	1	—	C	WC5/44
343	EA1.31.277 or	. SHIM	2	—	C	WC6/66
22976	EEAS27/8/48	. SPACER	2	L62	LM	WC5/44A
204	AS2811/7/023	. SPRING, return, undercarriage hook (Pre—Mod 4449)	1	—	C	WC6/67
1439147	EA3.40.245	. SPRING, return, undercarriage hook (Mod 4449—S.O.O.)	1	Spring Steel	C	WC5/34
205	EA1.40.601	. SPRING, tension, undercarriage sequence valve, 18 SWG	1	Spring Steel	C	WC6/68
1587	EA1.40.719	. SPRING, forward door latch	1	Spring Steel	C	WC5/35
4693	EA3.40.157	. STOP, door jack extension Attaching parts for EA3.40.157:—	2	S11	C/MR	WC5/36
28M/1011467	A27ES	. Nut, 1/4" BSF	1	—	C	WC5/36A
28P/9527619	SP90C7	. Pin, split	1	—	C	

AP 101B-0415-3A

Page WC.9

UNDERCARRIAGE

NOSEWHEEL

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA1.40.701	. STOP, sequence valve filter	1	S11	WC5/38
SP15C	. Attaching parts for EA1.40.701:— . Washer	1	—	WC5/39
EA9.40.37	. TAPPET, front latch lever	1	—	WC6/69
A27CT	. Attaching parts for EA9.40.37:— . Nut, 2BA	1	—	WC6/70
DUNLOP KK2	. TUBE	2	—	WC6/71
or GOODYEAR GA90	. TUBE	2	—	WC6/71
DUNLOP KKEN14N	. TYRE, 26" x 6.5" x 14"	2	—	WC6/72
or GOODYEAR GA1202	. TYRE, 26" x 6.5" x 14"	2	—	WC6/72
or DUNLOP DR2565	. TYRE, 26" x 6.5" x 14"	2	—	WC6/72
DOWTY 20039.7042	. UNIT, undercarriage (For spares see AP.4515B, Vol. 3, Pt. 1) (Pre Mod 5209)	1	—	WC6/73
R 20039.6040	. UNIT, undercarriage (For spares see AP.4515B, Vol. 3, Pt. 1) (Mod 5209) (Pre Mod 5505)	1	—	WC6/73
R 20039.6041	. UNIT, undercarriage assembly (Mod 5505)	1	—	WC6/73
EA1.40.587	. WASHER, special packing, undercarriage sequence valve, mounting bolt	2	DTD683	WC5/40
DUNLOP AH9590	. WHEEL, landing	2	—	WC6/74