

CANBERRA E Mk. 15

Page RA.1

RADIO **A.R.I.23021, A.D.F., INSTALLATION**

Ref. No.	Part No.	1	2	3	4	5	6	Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
	E.G4.82.1043	A.R.I. 23021, A.D.F., INSTALLATION (SRIM.3533) (MOD. 4799)						Spares for:—	—	—	—	
10HA/16237	†	CONNECTOR, DN.375, pressure bulkhead to aerial loop							1	—	B	
10HA/16238	†	CONNECTOR, PF.375, pressure bulkhead to aerial loop							1	—	B	
10HB/3103	†	CONNECTOR, DM/A/391, aerial loop to junction box, type 1629							1	—	C	
10HB/3113	†	CONNECTOR, DVV.391, pressure bulkhead to receiver							1	—	C	
10HA/16235	†	CONNECTOR, GR/A/375, junction box type 1629, to sense aerial amplifier							1	—	B	
10HB/3102	†	CONNECTOR, DM.391, junction box type 1629 to receiver							1	—	C	
10HB/3120	†	CONNECTOR, DT.391, voltage regulator to receiver							1	—	C	
10HB/3117	†	CONNECTOR, DU.391, pressure bulkhead to receiver							1	—	C	
10HB/10248	†	CONNECTOR, DS.650, pressure bulkhead to receiver							1	—	C	
10HA/16236	†	CONNECTOR, DJ/A/375, sense aerial amplifier to receiver							1	—	B	
10HA/16206	†	CONNECTOR, DK.373, aerial loop to receiver ...							1	—	B	
10HA/16209	†	CONNECTOR, GT.373, sense aerial to sense aerial amplifier							1	—	B	
10HB/10043	†	CONNECTOR, EX.649, radio junction box to pressure bulkhead							1	—	C	
	SCA.78015/130	CONNECTOR, DN.649, radio controller to pressure bulkhead (SRIM.3533) (Mod. 4799)							1	—	—	
10HB/4101310	†	CONNECTOR, DS.649, radio junction box to pressure bulkhead							1	—	C	
	SCA 78015/131	CONNECTOR, DW.649, receiver controller to pressure bulkhead (SRIM.3533) (Mod. 4799)							1	—	—	
10HB/4101312	†	CONNECTOR, PF.649, radio junction box to pressure bulkhead							1	—	C	
10HB/4101313	†	CONNECTOR, PN.649, indicator to radio junction box							1	—	C	
10HB/4101314	†	CONNECTOR, PP.649, indicator to radio junction box							1	—	C	
10HB/10051	†	CONNECTOR, DU.649, power factor transformer to pressure bulkhead							1	—	C	
10HB/13627	†	CONNECTOR, FQ.649, 400 cycle fuse box to power factor transformer							1	—	C	
10HB/10399	†	CONNECTOR, EX.662, pressure bulkhead to voltage regulator							1	—	C	
	E.G4.82.83	EQUIPMENT, A.D.F. IN CENTRE FUSELAGE, INSTALLATION						Spares for:—	—	—	—	
10B/17658	†	AERIAL, sense, 8071 (Alternative to Ref. 31951)							1	—	B	
31951	E.A3.82.427	AERIAL SENSE, ASSEMBLY (Alternative to Ref. 10B/17658)							1	—	B	
		Consisting of:—										
	E.A3.82.437	BUSH							1	—	—	
	E.A3.82.435	CONDUCTOR							1	BS.249	—	
	E.A3.82.439	DISC, insulating							1	BS.2572 or BS.2966	—	
28M/9455059	A 14/EB	NUT, 1/2" BSF							4	—	C	
	E.A3.82.431	PILLAR, centre							1	BS.2572 or BS.2966	—	

RADIO **A.R.I.23021, A.D.F., INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
34732	E.A3.82.429	PILLAR, end ...	...	...	...	...	...	2	LFS	—	
	E.A3.82.433	ROD, antenna, $\frac{3}{8}$ " o/d. x 17 SWG	...	...	...	...	...	1	L.62	—	
28S/9446592	A45/B24	SCREW, 4 BA	...	...	...	...	...	1	—	C	
28W/1010007	SP.22/C	WASHER	...	...	...	...	...	2	—	C	
		Attaching parts for E.A3.82.427:—									
28S/9135205	A33/C28	Screw, 2: BA	...	...	...	...	...	18	—	C	
10U/16964	†	AMPLIFIER, sense aerial, Type 1628	...	...	...	...	...	1	—	A	
	E.G4.82.1105	EQUIPMENT, A.D.F. IN FRONT FUSELAGE, INSTALLATION						—	—	—	
		Spares for:—									
10B/16446	†	AERIAL-LOOP, Type 1324A	...	...	...	...	...	1	—	A	
10D/19525	†	BOX, junction, Type 1629	...	...	...	...	...	1	—	A	
	E.A3.82.5605	BRACKET, assembly, voltage regulator	...	...	...	...	...	1	—	—	
	E.A3.82.5607	BRACKET, assembly, voltage regulator	...	...	...	...	...	1	—	—	
10J/13152	†	CONTROLLER, loop, Type 1342	...	...	...	...	...	1	—	A	
10L/16073	†	CONTROLLER, receiver, Type 1274	...	...	...	...	...	1	—	A	
10Q/16314	†	INDICATOR, bearing, Type 1630, pilot's (NHA-E.G4.80.1183)	...	...	...	...	...	Ref	—	A	
10Q/16314	†	INDICATOR, bearing, Type 1630, navigator's (NHA-E.G4.80.891)	...	...	...	...	...	Ref	—	A	
5UC/6007	W.25385	REGULATOR, voltage, Type 1555A	...	...	...	...	...	1	—	A	
10K/16244	†	TRANSFORMER, power-factor, Type 1571	...	...	...	...	...	1	—	B	
	E.G4.82.85	EQUIPMENT, A.D.F. IN STARBOARD WING, INSTALLATION						—	—	—	
		Spares for:—									
10D/17031	†	RACK, assembly, Type 182	...	...	...	...	...	1	—	A	
10D/19598	†	RECEIVER, AD.70920	...	...	...	...	...	1	—	A	
10K/18225	†	TRANSFORMER, aerial, Type 1343/A	...	...	...	...	...	1	—	B	
10AR/1026	†	TRAY, receiver mounting	...	...	...	...	...	1	—	B	

CANBERRA E Mk. 15

Page RB.1

RADIO **A.R.I.23076, DECCA Mk. 1 (AIR) INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G.4.82.1011	A.R.I.23076, DECCA MK. 1 (AIR) INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
	90G/29816	AERIAL, IN PORT BOMB DOOR, INSTALLATION (SRIM.3775) (MOD. 4799)						—	—	—	
		Spares for:—									
10B/9565490	†	AERIAL, Type 880/A						1	—	B	
		Attaching parts for Ref. 10B/9565490:—									
	90G/29816/19	Gasket, rubber (Make from Ref. 32C/1206557) ...						1	—	LM	
28S/9435717	A33/C20	Screw, 2 BA						30	—	C	
	90G/29769	AMPLIFIER, AERIAL IN PORT BOMB DOOR, INSTALLATION (SRIM.3775) (MOD. 4799)						—	—	—	
		Spares for:—									
10U/17602	†	AMPLIFIER, aerial, Type M108						1	—	B	
		Attaching parts for Ref. 10U/17602:—									
28M/1278190	AG5.2001/C/1	Nut, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
5975-99-970	†	BACKPLATE, assembly, power unit (SCD.78952) (SRIM.3533) (Mod. 4799)						1	—	B	
-3104											
5841-99-952	†	BLOWER, assembly, Type 1610-E (SRIM.3533) (Mod. 4799)						1	—	A	
-6654											
	SCB.79802	CHANNEL, mounting, control unit (Ref. 5975-99-947-9458 modified) (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/71	CONNECTOR, from ECP to power unit and blower relay (SRIM.3533) (Mod. 4799)						Ref	—	—	
	SCA.78015/72	CONNECTOR, from power unit to blower relay and receiver unit "B" (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/73	CONNECTOR, from receiver unit "B" to electrical indicator plug break (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/74	CONNECTOR, from electrical indicators to plug break (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/75	CONNECTOR, between receiver units "A" and "B" (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/76	CONNECTOR, between receiver units "A" and "B" (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/77	CONNECTOR, from power unit to receiver unit "A" (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/78	CONNECTOR, from receiver unit "A" to aerial amplifier (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/79	CONNECTOR, from receiver unit "A" to control unit (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/80	CONNECTOR, from aerial amplifier to aerial (SRIM.3533) (Mod. 4799)						1	—	—	
	E.G.4.82.1091	COOLING SYSTEM FOR RECEIVER UNITS (SRIM.3808) (MOD. 4799)						—	—	—	
		Spares for:—									
28E/2027591	SP.91/L	CLIP, pipe						10	—	C	
	BELLS ASBESTOS	HOSE, flexible, Type BAS.160-2/3/32/12, 2" i/d. (SRIM.3533) (Mod. 4799)						QR	—	—	

Page RB.2

CANBERRA E Mk. 15

RADIO **A.R.I.23076, DECCA Mk. 1 (AIR) INSTALLATION**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5826-99-955 3416-	†	INDICATOR, electrical, Type A274ZF, Green, (SRIM.3533) (Mod. 4799)						1	—	A	
5826-99-955 -3417	†	INDICATOR, electrical, Type A274ZF, Red (SRIM. 3533) (Mod. 4799)						1	—	A	
5826-99-955 -3419	†	INDICATOR, electrical, Type A274ZF, Purple (SRIM.3533) (Mod. 4799)						1	—	A	
5826-99-955 -3418	†	INDICATOR, electrical, Type A274ZF, Lane Indent (SRIM.3533) (Mod. 4799)						1	—	A	
	SCC.79914	MOUNTING ASSEMBLY, RECEIVER SUB-ASSY "A" (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5841-99-952 -6656	†	DUCT, air						1	—	B	
	SCB.79916/1	DUCT, assembly						2	—	—	
		Attaching parts for SCB.79916/1:—									
28D/1007980	AS.1246/1/2C	Bolt, 2 BA						4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	SCC.79341 or	MOUNTING, rack, assembly						1	—	—	
5826-99-956 -5017	†	RACK, electrical equipment						1	—	A	
	SCC.79915	MOUNTING ASSEMBLY, RECEIVER SUB-ASSY "B" (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5841-99-952 -6657	†	DUCT, air						1	—	B	
	SCB.79916/2	DUCT, assembly						1	—	—	
		Attaching parts for SCB.79916/2:—									
28D/1007980	AS.1246/1/2C	Bolt, 2 BA						4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	SCC.79342 or	MOUNTING, rack, assembly						1	—	—	
5826-99-956 -5018	†	RACK, electrical equipment						1	—	A	
10P/16604	†	RECEIVER, sub-assy. "A" (SRIM.3533) (Mod. 4799)						1	—	A	
10P/16605	†	RECEIVER, sub-assy. "B" (SRIM.3533) (Mod. 4799)						1	—	A	
5945-99-956 -5110	†	RELAY, assembly, blower (SRIM.3808) (Mod. 4799)						1	—	B	
10L/17101	†	UNIT, control, at navigator's station (SRIM.3533) (Mod. 4799)						1	—	A	
10K/21518	†	UNIT, power, Type M37 (SRIM.3533) (Mod. 4799) (For mounting tray see part No. SCD.78952 on page RH.1)						1	—	A	

CANBERRA E Mk. 15

Page RC.1

RADIO EQUIPMENT AND WIRING RADIO RELAY BOX

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.82.1087	EQUIPMENT AND WIRING, RADIO RELAY BOX (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5X/1002695	CZ.23212/1	BLOCK , terminal, 20-way						4	—	C	
		Attaching parts for CZ.23212/1:—									
28D/1214867	AS.1246/5B	Bolt, 4 BA						2	—	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						2	—	C	
33626	E.B6.82.1023	BUS-BAR, ASSEMBLY						1	—	B	
		Consisting of:—									
	E.B6.82.1029	BUS-BAR						1	—	—	
28M/5234	A.14/CB	NUT , 2 BA						3	—	C	
28S/9464989	A.43/C28	SCREW , 2 BA						3	—	C	
28W/9419475	SP.15/C	WASHER						3	—	C	
		Attaching parts for E.B6.82.1023:—									
28M/1990760	AGS.2002/C/4	Nut, 2 BA						2	—	C	
28S/1008081	A.33/C10	Screw, 2 BA						2	—	C	
29C/1013428	AGS.2036/C	Washer, shakeproof						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
33627	E.B6.82.1025	BUS-BAR, ASSEMBLY						1	—	B	
		Consisting of:—									
28D/1011030	A.25/2E	BOLT , 1/2" BSF						1	—	C	
	E.B6.82.1029	BUS-BAR						1	—	—	
28M/1007403	A.27/ET	NUT , 1/2" BSF						1	—	C	
28M/5234	A.14/CB	NUT , 2 BA						4	—	C	
28S/9464989	A.43/C28	SCREW , 2 BA						4	—	C	
28W/9419475	SP.15/C	WASHER						4	—	C	
28W/9419487	SP.16/E	WASHER						1	—	C	
		Attaching parts for E.B6.82.1025:—									
28M/1990760	AGS.2002/C/4	Nut, 2 BA						2	—	C	
28S/1008081	A.33/C10	Screw, 2 BA						2	—	C	
29C/1013428	AGS.2036/C	Washer, shakeproof						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
33628	E.B6.82.1027	BUS-BAR, ASSEMBLY						1	—	B	
		Consisting of:—									
28D/1011030	A.25/2E	BOLT , 1/2" BSF						1	—	C	
	E.B6.82.1029	BUS-BAR						1	—	—	
28M/1007403	A.27/ET	NUT , 1/2" BSF						1	—	C	
28M/5234	A.14/CB	NUT , 2 BA						3	—	C	
28S/9464989	A.43/C28	SCREW						3	—	C	
28W/9419475	SP.15/C	WASHER						3	—	C	
28W/9419487	SP.16/E	WASHER						1	—	C	
		Attaching parts for E.B6.82.1027:—									
28M/1990760	AGS.2002/C/4	Nut, 2 BA						2	—	C	
28S/1008081	A33/C10	Screw, 2 BA						2	—	C	
29C/1013428	AGS.2036/C	Washer, shakeproof						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
5X/9010	AS.2722	INSULATOR , bus-bar						6	—	C	
		Attaching parts for AS.2722:—									
28D/1214865	AS.1246/2B	Bolt, 4 BA						2	—	C	

Page RC.2

CANBERRA E Mk. 15

RADIO EQUIPMENT AND WIRING RADIO RELAY BOX

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5X/1004086	Z.50219	LINK,	commoning,	transverse	...	...	...	2	—	C	
5X/1004082	Z.50210	LINK,	commoning,	2-way	...	...	...	8	—	C	
5X/1012212	Z.50218	LINK,	commoning,	10-way	...	...	...	2	—	C	
	†	RELAY AND MOUNTING, INSTALLATION						—	—	—	
		(SRIM.3533) (MOD. 4799)									
	SCC.79487/2	BLOCK,	packing,	10 SWG	...	...	...	2	L.72	—	
	SCA.79513	PLATE,	relay,	18 SWG	...	...	...	1	L.72	—	
	SCB.79488	PLATE,	relay mounting,	18 SWG	...	...	...	1	L.72	—	
		Attaching parts for SCB.79488:—									
28D/9133012	A25/3C	Bolt,	2 BA	...	...	...	...	2	—	C	
	SM-5M-N156	RELAY,	Type 4C	...	...	...	...	1	—	—	
33420	E.B7.81.347	SUPPORT,	terminal block	...	...	...	...	6	—	C	
		Attaching parts for E.B7.81.347:—									
28D/1214867	AS.1246/5B	Bolt,	4 BA	...	...	...	...	2	—	C	
	†	TERMINAL, EARTH, ASSEMBLY						—	—	—	
		Consisting of:—									
28M/1006473	A.27/CT	NUT,	2 BA	...	...	...	...	1	—	C	
28M/1278190	AGS.2001/C/1	NUT,	2 BA	...	...	...	...	1	—	C	
28S/1011481	A.31/C48	SCREW,	2 BA	...	...	...	...	1	—	C	
17519	EEAS.28/4DPH	WASHER	...	...	...	...	...	1	—	C	

Restricted

CANBERRA E Mk. 15

Page RD.1

RADIO **A.R.I.23090/9, COLLINS, H.F. INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.82.1007	A.R.I. 23090/9, COLLINS, H.F. INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
	—	Spares for:—									
		AERIAL WIRE, ASSEMBLY						—	—	—	
		Spares for:—									
	CHELTON 3505	CAP , insulating						1	—	—	
	5399	CAP , insulating						1	—	—	
	5398	CHUCK , assembly						1	—	—	
	3510	CHUCK , assembly						1	—	—	
	CHELTON AS.467/205	PIN , weak, link						1	—	—	
10B/16897	CHELTON 1JWC4063	UNIT , tension, type B or S						1	—	B	
	CHELTON 5048	WIRE , aerial						QR	—	C	
5E/4885	CHELTON Z.5485	AERIAL MAST , type 69						1	—	—	
10B/		Attaching parts for Z5485:—									
28D/1212806	AS.1248/6C	Bolt , 2 BA						12	—	C	
28M/1278190	AGS.2001/C/1	Nut , 2 BA						12	—	C	
	40504	Seal (Made from 32C/628)						1	—	C	
28W/9419402	SP.13/C	Washer						12	—	C	
	E.C3.82.67	AERIAL ATTACHMENT, FITTINGS ON FIN, INSTALLATION						—	—	—	
		Consisting of:—									
	40216	BAR , toggle						1	—	C	
28D/9133011	A25/2C	BOLT , 2 BA						2	—	C	
	40215	EYE-BOLT						1	—	C	
	40219	NUT , special						1	—	C	
28M/5808573	A27/CS	NUT , 2 BA						2	—	C	
	40221	PLATE , adapter						2	—	C	
	40220	PIN						1	—	C	
28P/9486478	SP.90/C5	PIN , split						2	—	C	
28P/9560929	SP.90/E8	PIN , split						1	—	C	
	40217	WASHER						1	—	C	
	40218	WASHER						1	—	C	
28W/9419475	SP.15/C	WASHER						2	—	C	
	E.G4.82.1079	BOX, DISTRIBUTION, H.F., ASSEMBLY (SRIM. 3533) (MOD. 4799)						1	—	—	
		Spares for:—									
	5X/3181	BLOCK , terminal, 20-way						1	—	C	
		Attaching parts for CZ.23712/1:—									
28S/1200033	A31/B24	Screw , 4 BA						2	—	C	
28W/9416642	SP.47/B	Washer						2	—	C	
	E.G4.82.1081	BOX , sub-assembly						1	—	—	
5E/4189	†	CABLE , Uninyvin 8						QR	—	C	
5E/4187	†	CABLE , Uninyvin 12						QR	—	C	
5E/4183	†	CABLE , Uninyvin 20						QR	—	C	
5E/4201	†	CABLE , Uninyvinmetstheath 16						QR	—	C	
	E.G4.82.1083	COVER, ASSEMBLY (SRIMS.3533, 3872) (MOD. 4799)						1	—	—	
		Spares for:—									
20457	EEAS.117/1	SCREW , 4 BA						6	—	C	

CANBERRA E Mk. 15

Page RD.3

RADIO **A.R.I.23090/9, COLLINS, H.F. INSTALLATION**

Ref. No.	Part No.	Description						No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCA.78015/21	CONNECTOR, from pilot's starboard coaming panel and dimmer switch panel, switches to HF distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/22	CONNECTOR, from control unit to HF distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/23	CONNECTOR, from HF distribution box to pre-amplifier Type UA6002 (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/24	CONNECTOR, from HF distribution box to aerial tuner Type 490T/1 (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/25	CONNECTOR, from HF distribution box to trans receiver Type 618T (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/26	CONNECTOR, from trans receiver Type 618T to aerial tuner Type 490T/1 (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/27	CONNECTOR, from trans receiver Type 618T to aerial tuner Type 490T/1 (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/28	CONNECTOR, from HF distribution box to i/c distribution box Type UA6043 (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/29	CONNECTOR, from HF distribution box to 1600 distribution box and ECP (SRIM.3533) (Mod. 4799)						Ref	—	—	
	SCA.78015/30	CONNECTOR, from aerial to aerial tuner Type 490T/1 (SRIM.3533) (Mod. 4799)						1	—	—	
10F/1047561	†	KEY, telegraph (SRIM.3872) (Mod. 4799)						1	—	B	
10AJ/9451643	†	MOUNTING, resilient, Type 3905/1, trans receiver (SRIM.3533) (Mod. 4799)						1	—	A	
		Attaching parts for Ref. 10AJ/9451643:—									
28D/9709461	AS.1242/3C	Bolt, 2 BA						16	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						16	—	C	
28W/9403514	SP.26/C	Washer						16	—	C	
10U/9148966	†	PRE-AMPLIFIER, Type UA6002 (SRIM.3533) (Mod. 4799)						1	—	A	
		Attaching parts for Ref. 10U/9148966:—									
28M/1221216	A125/C66	Nut, 8 UNC						2	—	C	
28W/9156626	SP.122/C	Washer						2	—	C	
10D/23518	†	TRANS-RECEIVER, Type 618T/3 (SRIM.3533) (Mod. 4799)						1	—	A	
	SCD.79005	UNIT, AERIAL TUNER, INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
	E.H8.82.363	CONDUIT, assembly, HF cable						1	—	—	
	E.H8.82.183	CONDUIT, assembly, HF cable						1	—	—	
	SCB.79006	FAIRLEAD, assembly (Make from Ref. 5F/9400956)						1	—	—	
	SCB.79038	FAIRLEAD, assembly (Make from Ref. 5F/9400956)						1	—	—	
		Attaching parts for SCB.79006 or SCB.79038:—									
28D/1011006	A25/5B	Bolt, 4 BA						2	—	C	
28D/9140645	A25/10C	Bolt, 2 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						1	—	C	
28W/9419402	SP.13/C	Washer						1	—	C	

RADIO
A.R.I.23090/9, COLLINS, H.F. INSTALLATION

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCC.79033	FAIRLEAD, INSTALLATION						—	—	—	
	SCB.79036	Spares for:— FAIRLEAD , assembly (Make from Ref. SF/9400956) Attaching parts for SCB.79036:—						1	—	—	
28D/1010029	A25/6B	Bolt, 4 BA						2	—	C	
28D/1011021	A25/16C	Bolt, 2 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						1	—	C	
28W/9419465	SP.13/B	Washer						2	—	C	
28W/9419402	SP.13/C	Washer						1	—	C	
110B/5616480	†	INSULATOR						1	—	C	
	SCD.78916	MOUNTING , structure assembly for aerial tuning unit Attaching parts for SCD.78916:—						1	—	—	
28FP/7002000	AGS.2105/403	Pin, quick release						2	—	C	
28FP/11	AGS.2105/A418	Pin, quick release						2	—	C	
5980-00-871-9123	†	MOUNTING , resilient, Type 790Y/2 for aerial tuning unit Attaching parts for Ref. 5980-00-871-9123:—						1	—	A	
28D/9133011	A25/2C	Bolt, 2 BA						16	—	C	
28W/9419402	SP.13/C	Washer						16	—	C	
1438516	E.H8.82.181	SLEEVE , HF cable conduit						1	—	—	
	E.G7.82.2807	SPARK-GAP, ASSEMBLY Consisting of:—						1	—	B	
	E.G7.82.2811	BLOCK , base, assembly						1	—	—	
	E.G7.82.191	CABLE, ASSEMBLY, HF3 , from spark-gap to aerial post						1	—	—	
	E.G7.82.199	CABLE, ASSEMBLY, EARTH , from spark-gap to earth						1	—	—	
		(See Cable Chart for Breakdown Spares)									
5X/9409403	BULGIN P.92	CAP , valve						2	—	C	
	E.C3.82.419	COVER						1	—	—	
28D/9130080	AS.1242/9B	Attaching parts for E.C3.82.419:—									
28M/1278189	AGS.2001/B/1	Bolt, 4 BA						3	—	C	
28W/9419474	SP.15/B	Nut, 4 BA						3	—	C	
		Washer						3	—	C	
	E.G7.82.2809	SPACER						1	LFS	LM	
	E.E. Co. Ltd. LINCOLN ZD.32664	SPARK-GAP , Type BS142						1	—	B	
28D/9133012	A25/3C	Attaching parts for E.G7.82.2807:—									
28W/9419402	SP.13/C	Bolt, 2 BA						2	—	C	
		Washer						2	—	C	
110D/8726847	†	UNIT , aerial tuning, Type 490T-1						1	—	A	
10L/16857	†	UNIT , control, Type 714E-3, on pilot's starboard coaming panel (SRIM.3533) (Mod. 4799)						1	—	A	

CANBERRA E Mk. 15

Page RE.1

RADIO **A.R.I.18011, I.L.S., INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.82.1051	A.R.I. 18011, I.L.S., INSTALLATION (SRIM.3533) ...						—	—	—	
		(MOD. 4799)									
		Spares for:—									
10B/16706	†	AERIAL , marker, Type 237						1	—	A	
	E.A9.82.197	AERIAL , I.L.S., IN LEADING EDGE, PORT, IN-						—	—	—	
		STALLATION									
		Spares for:—									
10B/16708	†	AERIAL , localiser, Type 239						1	—	A	
		Attaching parts for Ref. 10B/16708:—									
28D/9133011	A25/2C	Bolt, 2 BA						18	—	C	
40233	EEAS 28/3FU	Washer						18	—	C	
	E.A9.82.198	AERIAL , I.L.S., IN LEADING EDGE, STARBOARD,						—	—	—	
		INSTALLATION									
		Spares for:—									
10B/16707	†	AERIAL , glide path, Type 238						1	—	A	
		Attaching parts for Ref. 10B/16707:—									
28D/9133011	A25/2C	Bolt, 2 BA						10	—	C	
40233	EEAS.28/3FU	Washer						10	—	C	
	E.B6.82.175	BOX, JUNCTION, TYPE 164, INSTALLATION ...						—	—	—	
		Spares for:—									
10D/4042156	†	BOX , junction, Type 164						1	—	A	
		Attaching parts for Ref. 10D/4042156:—									
28S/9992522	A32/B16	Screw, 4 BA						4	—	C	
28W/9419465	SP.13/B	Washer						4	—	C	
10HA/4042159	E.A4.82.521	CONNECTOR , shorting, Type 3793, at junction box						1	—	C	
		164									
10HA/11993	E.A4.82.519	CONNECTOR , shorting, Type 3794, at junction box						1	—	C	
		164 (Fitted when zero reader is not used)									
10HB/37	E.A4.82.505	CONNECTOR , B7/20A/R1, pressure bulkhead to						1	—	C	
		junction box 157									
10HB/39	E.A4.82.509	CONNECTOR , B11/20A/R2, pressure bulkhead to						1	—	C	
		junction box 157									
10HB/40	E.A4.82.511	CONNECTOR , B11/30B/R7, junction box 164 to						1	—	C	
		pressure bulkhead									
10HB/41	E.A4.82.513	CONNECTOR , B21/50F/R1, junction box 164 to						1	—	C	
		warning light									
10HB/42	E.A4.82.515	CONNECTOR , B11/30B/R8, junction box 164 to						1	—	C	
		pilot's indicator									
10HB/43	E.A4.82.517	CONNECTOR , B19/50E/R1, terminal block to junc-						2	—	C	
		tion box 157									
10HB/44	E.A4.82.523	CONNECTOR , D267/30B/R16, localiser marker re-						1	—	C	
		ceiver to wing root break									
10HB/45	E.A4.82.525	CONNECTOR , D267/30A/R8, wing root break to						1	—	C	
		port inner wing rib 6 break									
10HB/46	E.A4.82.527	CONNECTOR , D273/30A/R1, inner wing rib 6 break						1	—	C	
		to outer wing rib 2 break, port									
10HB/47	E.A4.82.529	CONNECTOR , D267/30A/R9, outer wing rib 2						1	—	C	
		break to localiser aerial, port									
10HB/48	E.A4.82.531	CONNECTOR , D267/30B/R17, glide path receiver						1	—	C	
		to wing root break									
10HB/49	E.A4.82.533	CONNECTOR , D267/30A/R10, wing root break to						1	—	C	
		inner wing rib 6 break, starboard									

RADIO **A.R.I.18011, I.L.S., INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
10HB/50	E.A4.82.535	CONNECTOR, D273/30A/R2, inner wing rib 6 break to outer wing rib 2 break, starboard						1	—	C	
10HB/51	E.A4.82.537	CONNECTOR, D267/30A/R11, outer wing rib 2 break to glide path aerial, starboard						1	—	C	
10HB/52	E.A4.82.539	CONNECTOR, D267/30B/R18, localiser-marker receiver to marker aerial						1	—	C	
10HB/53	E.A4.82.541	CONNECTOR, D243/20D/R2, pressure bulkhead to junction box 157						1	—	C	
10HB/55	E.A4.82.545	CONNECTOR, D243/30B/R6, pressure bulkhead to junction box 157						1	—	C	
10HB/10494	E.B6.82.955	CONNECTOR, I.L.S.1, pressure bulkhead to junction box 157						1	—	C	
10HB/10495	E.B6.82.957	CONNECTOR, I.L.S.2, radio junction box to pressure bulkhead						1	—	C	
10HB/10496	E.B6.82.1047	CONNECTOR, I.L.S.3, control unit to pressure bulkhead						1	—	C	
10HB/10497	E.B6.82.1055	CONNECTOR, I.L.S.7, control unit to pressure bulkhead						1	—	C	
10HB/10498	E.B6.82.1057	CONNECTOR, I.L.S.8, control unit to pressure bulkhead						1	—	C	
	E.G4.82.1113	EQUIPMENT IN UPPER EQUIPMENT BAY, INSTALLATION (SRIM.3533) (MOD.4799) Spares for:—						—	—	—	
5X/9402803	AS.2635	BLOCK, terminal, 5-way						1	—	C	
		Attaching parts for AS.2635:—									
28S/1200034	A31/B16	Screw, 4 BA						2	—	C	
28W/9419465	SP.13/B	Washer						2	—	C	
5X/9402794	AS.2603	COVER, terminal block						1	—	C	
5X/9402800	AS.2666	LINK, commoning						1	—	C	
5X/9402799	AS.2606	TERMINAL, screwed head, double tier						5	—	C	
5X/9400055	AS.2674	FERRULE						8	—	C	
10Q/4049193	†	INDICATOR, azimuth deviation on pilot's flying panel (NHA-E.G4.80.1183)						Ref	—	A	
	E.A4.82.289	INSTALLATION OF ENGINE BREAK, INNER, PORT Spares for:—						—	—	—	
23864	E.A9.82.171	BRACKET, assembly						1	—	C	
		Attaching parts for E.A9.82.171:—									
28D/1010658	A25/1B	Bolt, 4 BA						4	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						4	—	C	
28W/9419474	SP.13/B	Washer						4	—	C	
10H/19610	†	PLUG, bulkhead, Type 757						1	—	C	

CANBERRA E Mk. 15

Page RE.3/4

RADIO **A.R.I.18011, I.L.S., INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
	E.A4.82.287	INSTALLATION OF ENGINE BREAK, OUTER, PORT						—	—	—	
		Spares for this installation are identical with those for Part No. E.A4.82.289, on page RE 2									
	E.A4.82.290	INSTALLATION OF ENGINE BREAK, INNER, STARBOARD						—	—	—	
		Spares for this installation are identical with those for Part No. E.A4.82.289, on page RE 2									
	E.A4.82.288	INSTALLATION OF ENGINE BREAK, OUTER, STARBOARD						—	—	—	
		Spares for this installation are identical with those for Part No. E.A4.82.289, on page RE 2									
	E.G4.82.1117	RECEIVERS AND JUNCTION BOX, UPPER EQUIPMENT BAY, INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
10D/17815	†	BOX , junction, Type 157						1	—	B	
10AJ/118	†	RACK , mounting, Type 933						1	—	C	
		Attaching parts for Ref. 10AJ/118:—									
28D/1010031	A25/8E	Bolt, 1/2 BSF						4	—	C	
28W/9418921	SP.13/E	Washer						4	—	C	
10D/17818	†	RECEIVER , Type R1964						1	—	A	
10D/17819	†	RECEIVER , Type R1965						1	—	A	
	E.G4.82.1107	UNIT, CONTROL, TYPE 705 AND I.L.S. SWITCH, INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5CW/8815	AS.10512L-1	PLATE , adapter (Alt. R60/61—Mod. 5100) ...						1	—	C	
5CW/4706404	AS.10512M-1	SHROUD , terminal (Alt. R60/61—Mod. 5100) ...						1	—	C	
5CW/1047690	†	SWITCH (Pre-Mod. 5100)						1	—	C	
		Attaching parts for Ref. 5CW/1047690:—									
28S/9419435	A31/B12	Screw, 4 BA						2	—	C	
5CW/9235	AS.10512A-2	SWITCH (Alt. R60/61—Mod. 5100)						1	—	B	
10L/263	†	UNIT , control, Type 705						1	—	A	

Restricted

[illegible]

CANBERRA E Mk. 15

Page RF.1

RADIO **A.R.I.23099, ULTRA UA60, INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.82.1013	A.R.I.23099, ULTRA UA60, INSTALLATION (SRIM. 3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5831-99-945 -2676	†	AMPLIFIER , Type UA6070, on navigator's starboard wall						1	—	A	
6110-99-945 -2673	†	BOX , distribution, Type UA6043 on navigator's starboard wall						1	—	A	
5935-99-948 -3324	†	BOX , jack, Type UA6075W, in starboard wheel well						1	—	A	
5831-99-945 -2674	†	BOX , station, Type UA6014/F, pilot's, first and second navigator's						3	—	A	
	SCB.79380	BRACKET , assembly, jack box (SRIM.3533) (Mod. 4799)						1	L.72	—	
		Attaching parts for SCB.79380:—									
28D/9133011	A25/2C	Bolt, 2	BA	...	...	...	...	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2	BA	...	...	...	...	4	—	C	
28W/9419402	SP.13/C	Washer	...	...	...	...	...	4	—	C	
	E.B6.82.799	CABLE, ASSEMBLY , I/C 29, from external terminal block at frame 19 to bulkhead break at frame 29						1	—	—	
	E.B6.82.797	CABLE, ASSEMBLY , I/C 28, from bulkhead break at frame 29 to terminal block, rear fuselage at frame 32						1	—	—	
	E.G4.82.1123	CABLE, ASSEMBLY , from distribution box to radio junction box and i/c ground crew amplifier switch on pilot's coaming panel (Alt. R60/61—Mod. 5100)						1	—	LM	
	E.G4.82.1125	CABLE, ASSEMBLY , from i/c isolation switch on pilot's coaming panel to radio junction box (Alt. R60/61—Mod. 5100)						1	—	LM	
		(See Cable Chart for Breakdown Spares)									
	SCA.78015/58	CONNECTOR , from amplifier to distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/59	CONNECTOR , from distribution box to pilot's station box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/60	CONNECTOR , from pilot's station box to first navigator's station box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/61	CONNECTOR , between first and second navigator's station boxes (SRIM. 3533) (Mod. 4799)						1	—	—	
	SCA.78015/62	CONNECTOR , from distribution box to second navigator's station box ((SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/63	CONNECTOR , from pilot's station box to throttle box plug break (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/64	CONNECTOR , from first navigator's station box to transmit switch (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/65	CONNECTOR , from second navigator's station box to transmit switch (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/66	CONNECTOR , from transient protection unit to i/c master switch on take-off panel (SRIM.3533) (Mod. 4799)						1	—	—	

RADIO **A.R.I.23099, ULTRA UA60, INSTALLATION**

Ref. No.	Part No.							No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCA.78015/67	CONNECTOR , from distribution box to radio junction box and i/c ground crew amplifier switch on pilot's coaming panel (SRIM.3533) (Mod. 4799) (Pre-Mod. 5100)						1	—	—	
	SCA.78015/68	CONNECTOR , from i/c isolation switch on pilot's coaming panel to radio junction box (SRIM.3533) (Mod. 4799) (Pre-Mod. 5100)						1	—	—	
	SCA.78015/69	CONNECTOR , from distribution box to transient protection unit (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/100	CONNECTOR , from radio junction box to pressure bulkhead (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/101	CONNECTOR , from pressure bulkhead to terminal block at frame 19 (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/102	CONNECTOR , from terminal block at frame 19 to jack box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/56	CONNECTOR , from radio junction box to distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/57	CONNECTOR , from radio junction box to distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.79381	FAIRLEAD , starboard wheel bay (Make from Ref. 5F/9400951) (SRIM.3533) (Mod. 4799)						1	—	LM	
5CW/4400171	NSF.8804/B102 or	SWITCH , transmit, second navigator's						Ref	—	C	
5CW/9240	AS.10512A-7	SWITCH (Alt. R60/61—Mod. 5100)						Ref	—	B	
5CW/9268	AS.10512D-7	SWITCH , tone and transmit, first navigator's ...						Ref	—	B	
5CW/5839	NSF.8810/B104	SWITCH , i/c isolation and ground crew amplifier on pilot's coaming panel and i/c master on take-off panel						Ref	—	C	
5CW/4408107	AS.10512B-2	SWITCH , i/c (Alt. R60/61—Mod. 5100)						Ref	—	B	
5CW/9235	AS.10512A-2	SWITCH , amplifier (Alt. R60/61—Mod. 5100) ...						Ref	—	B	
5CW/1933296	PAGE B1640	SWITCH , push, on pilot's throttle lever						Ref	—	C	
5831-99-948 -3317	†	UNIT , transient protection, Type UA6003						1	—	A	

CANBERRA E Mk. 15

Page RG.1

RADIO **A.R.I.23143/1 AND 23143/4, TWIN P.T.R.175, INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G.4.82 1003	A.R.I. 23143/1 & 23143/4, TWIN P.T.R.175, INSTALLATION (SRIM. 3533) (MOD. 4799)						—	—	—	
	E.B.6.82.335	AERIAL, LOWER, INSTALLATION ...						—	—	—	
10B/2222399	†	AERIAL, Type 16-1 (SRIM. 3800) (Mod. 5049) ...						1	—	A	
28D/1212806	AS.1248/6C	Attaching parts for Ref. 10B/2222399:—									
1438504	E.B.6.82.1415	Bolt, 2 BA ...						6	—	C	
28W/9419402	SP.13/C	Plate, mounting ...						1	—	C	
		Washer ...						6	—	C	
	E.B.6.82.337	STRUCTURE, U.H.F., AERIAL, INSTALLATION						—	—	—	
33434	E.B.6.82.341	Spares for:—									
		BRACKET, support ...						1	S.510	C	
28D/9133012	A25/3C	Attaching parts for E.B.6.82.341:—									
28M/1278190	AGS.2001/C/1	Bolt, 2 BA ...						4	—	C	
28W/9419475	SP.15/C	Nut, 2 BA ...						4	—	C	
		Washer ...						4	—	C	
	E.B.6.82.611	AERIAL, UPPER, INSTALLATION ...						—	—	—	
10B/2222399	†	Spares for:—									
		AERIAL, Type 16-1 (SRIM. 3800) (Mod. 5049) ...						1	—	A	
28D/1212806	AS.1248/6C	Attaching parts for Ref. 10B/2222399:—									
40605	E.B.6.82.1417	Bolt, 2 BA ...						6	—	C	
28W/9419402	SP.13/C	Plate, mounting ...						1	—	C	
		Washer ...						6	—	C	
	SCD.40370	AERIAL, WHIP, AT RIB NO. 4, PORT BOMB DOOR, INSTALLATION (SRIM. 3533) (MOD. 4799)						—	—	—	
10B/9513781	†	Spares for:—									
		AERIAL ...						1	—	A	
28D/1007981	AS.1248/1/2C	Attaching parts for Ref. 10B/9513781:—									
		Bolt, 2 BA ...						4	—	C	
	SCC.31142	CONDUIT, 1" o/d. x 20 SWG ...						1	L.54	—	
28D/9436920	A25/1C	Attaching parts for SCC.31142:—									
28E/1053257	A5 5418/16	Bolt, 2 BA ...						2	—	C	
28M/1278190	AGS.2001/C/1	Clip, "P" ...						1	—	C	
28S/9992533	A32/C20	Nut, 2 BA ...						1	—	C	
28W/9419402	SP.13/C	Screw, 2 BA ...						1	—	C	
		Washer ...						3	—	C	
	SCC.31145	COVER, 16 SWG ...						1	L.72	—	
28D/1007982	AS.1248/1C	Attaching parts for SCC.31145:—									
28D/1013284	AS.1248/2C	Bolt, 2 BA ...						QR	—	C	
		Bolt, 2 BA ...						QR	—	C	
10AL/290	†	GROMMET, Type 123 ...						1	—	C	
	SCD.79442	AERIAL, WHIP, AT RIB 18, PORT BOMB DOOR, INSTALLATION (SRIM. 3533) (MOD. 4799)						—	—	—	
10B/9513781	†	Spares for:—									
		AERIAL ...						1	—	A	
28D/1007981	AS.1248/1/2C	Attaching parts for Ref. 10B/9513781:—									
		Bolt, 2 BA ...						4	—	C	

RADIO **A.R.I.23143/1 AND 23143/4, TWIN P.T.R.175, INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCC.79485	CONDUIT , 1" o/d. x 20 SWG						1	L.54	—	
		Attaching parts for SCC.79485:—									
28D/1200119	A25/4C	Bolt, 2 BA						2	—	C	
28E/1053257	AS.5418/16	Clip, "P"						1	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						1	—	C	
28S/9131095	A31/C14	Screw, 2 BA						1	—	C	
28W/9419402	SP.13/C	Washer						3	—	C	
	SCB.79398	COVER , assembly						1	—	—	
		Attaching parts for SCB.79398:—									
28D/1013284	AS.1248/2C	Bolt, 2 BA						14	—	C	
10AL/290	†	GROMMET , Type 123						1	—	C	
6110-99-945	†	BOX , distribution, Type UA6043 on starboard wall						1	—	A	
-2673		(SRIM. 3533) (Mod. 4799)									
	SCA.78015/1	CONNECTOR , from muting unit interconnecting						1	—	—	
		box No. 1 to MEP (SRIM. 3533) (Mod. 4799)									
	SCA.78015/2	CONNECTOR , from muting unit interconnecting						1	—	—	
		box No. 2 to MEP (SRIM. 3533) (Mod. 4799)									
	SCA.78015/3	CONNECTOR , from radio junction box to ECP						1	—	—	
		(SRIM. 3533) (Mod. 4799)									
	SCA.78015/4	CONNECTOR , from radio junction box to pressure						1	—	—	
		bulkhead (SRIM. 3533) (Mod. 4799)									
	SCA.78015/5	CONNECTOR , from UA6043 distribution box to						1	—	—	
		radio junction box (SRIM. 3533) (Mod. 4799)									
	SCA.78015/6	CONNECTOR , from UA6043 distribution box to						1	—	—	
		radio junction box (SRIM. 3533) (Mod. 4799)									
	SCA.78015/7	CONNECTOR , from radio junction box to CU1607/4						1	—	—	
		and CU1607/7 control units (SRIM. 3533)									
		(Mod. 4799)									
	SCA.78015/8	CONNECTOR , from CU1607/7 control unit to						1	—	—	
		pressure bulkhead (SRIM. 3533) (Mod. 4799)									
	SCA.78015/9	CONNECTOR , from pressure bulkhead to No. 1						1	—	—	
		muting unit interconnecting box (SRIM. 3533) (Mod. 4799)									
	SCA.78015/10	CONNECTOR , from No. 2 muting unit intercon-						1	—	—	
		necting box to control receiver muting									
		(SRIM. 3533) (Mod. 4799)									
	SCA.78015/11	CONNECTOR , from No. 1 muting unit intercon-						1	—	—	
		necting box to No. 1 T/R, PTR175 (SRIM. 3533) (Mod. 4799)									
	SCA.78015/12	CONNECTOR , from No. 1 T/R, PTR175 to upper						1	—	—	
		UHF aerial (SRIM. 3533) (Mod. 4799)									
	SCA.78015/13	CONNECTOR , from No. 2 T/R, PTR175 to lower						1	—	—	
		UHF aerial (SRIM. 3533) (Mod. 4799)									
	SCA.78015/14	CONNECTOR , from CU1607/4 control unit to pres-						1	—	—	
		sure bulkhead (SRIM. 3533) (Mod. 4799)									
	SCA.78015/15	CONNECTOR , from pressure bulkhead to No. 2						1	—	—	
		muting unit interconnecting box (SRIM. 3533) (Mod. 4799)									
	SCA.78015/16	CONNECTOR , from No. 2 muting unit inter-						1	—	—	
		connecting box to No. 2 T/R, PTR175									
		(SRIM. 3533) (Mod. 4799)									
	SCA.78015/17	CONNECTOR , from No. 1 T/R, PTR175 to forward						1	—	—	
		aerial in port bomb-door (SRIM. 3533)									
		(Mod. 4799)									

CANBERRA E Mk. 15

Page RG.3

RADIO **A.R.I.23143/1 AND 23143/4, TWIN P.T.R.175, INSTALLATION**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	SCA.78015/18	CONNECTOR , from No. 2 T/R, PTR175 to rear aerial in port bomb-door (SRIM.3533) (Mod.4799)	1	—	—	
	SCA.78015/110	CONNECTOR , from pilot's starboard instrument panel to radio junction box (SRIM.3533) (Mod.4799)	1	—	—	
	SCA.78015/111	CONNECTOR , from radio junction box to ECP (SRIM.3533) (Mod.4799)	1	—	—	
	E.G4.82.1089	CONTROL, MUTING AND INTERCONNECTING BOX, NO. 2, PTR, REAR FUSELAGE, INSTALLATION (MOD. 4799)	1	—	—	
		Spares for:—				
10AD/9326361	†	BOX , interconnecting	1	—	B	
5E/4189	†	CABLE , Uninyvin 8	QR	—	C	
5E/4185	†	CABLE , Uninyvin 16	QR	—	C	
5X/9400056	AS.2675	FERRULE	2	—	C	
5X/9400055	AS.2674	FERRULE	1	—	C	
5X/9400051	AS.2672	FERRULE	2	—	C	
5X/4491624	12318	LUG	2	—	C	
	E.G5.82.181	PANEL, ASSEMBLY	1	—	—	
		Spares for:—				
5X/9402802	AS.2633	BLOCK , terminal, 19 amp.	1	—	C	
5X/9402792	AS.2651	BLOCK , terminal, 37 amp.	1	—	C	
		Attaching parts for Ref. 5X/9402802 and 5X/9402792:—				
28S/9995376	A32/B20	Screw, 4 BA	2	—	C	
28W/9419465	SP.13/B	Washer	2	—	C	
5CZ/1053794	†	BLOCK , terminal, 2-way	2	—	C	
		Attaching parts for Ref. 5CZ/1053794:—				
28S/1200041	A31/A24	Screw, 6 BA	2	—	C	
28W/9419464	SP.13/A	Washer	2	—	C	
5X/9402796	AS.2601	COVER , 19 amp.	1	—	C	
5X/9435997	AS.2638	COVER , 37 amp.	1	—	C	
10L/9433247	†	CONTROL , muting receiver	1	—	A	
		Attaching parts for Ref. 10L/9433247:—				
28S/1200034	A31/B16	Screw, 4 BA	4	—	C	
28W/9419465	SP.13/B	Washer	4	—	C	
	E.G5.82.183	PLATE, MOUNTING, ASSEMBLY	1	—	—	
		Spares for:—				
28E/9492696	E.B6.82.433	BRACKET , assembly	1	—	—	
10F/9321487	TERRY 80/3	CLIP	1	—	C	
	†	RELAY , magnetic, Type 1741	1	—	B	
		Attaching parts for Ref. 10F/9321487:—				
28S/5694	A32/B40	Screw, 4 BA	2	—	C	
28W/9419465	SP.13/B	Washer	2	—	C	
5X/9402799	AS.2606	SOCKET , assembly, 19 amp.	2	—	C	
5X/9402798	AS.2641	SOCKET , assembly, 37 amp.	2	—	C	
10H/2206		SOCKET , Type 359	1	—	C	
		Attaching parts for E.G4.82.1089:—				
28S/9997545	A31/C16	Screw, 2 BA	8	—	C	

RADIO **A.R.I.23143/1 AND 23143/4, TWIN P.T.R.175, INSTALLATION**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.80.1403	PANEL, ASSEMBLY, INSTRUMENTS, STARBOARD, PILOT'S (MOD. 4799)						Ref	—	—	
		Spares for:—									
5CW/1047692	†	SWITCH , S.P. on/off, tone 1 and 2 ...						Ref	—	C	
5CW/1047693	†	SWITCH , S.P. changeover, pilot's/navigator's ...						Ref	—	C	
	E.G4.80.1333	PANEL, ASSEMBLY, SIDE, NAVIGATOR'S						Ref	—	—	
		Spares for:—									
5CZ/5692	C5165Y Mk.4	INDICATOR , magnetic ...						Ref	—	C	
5CW/9268	AS.10512D-7	SWITCH , tone/transmit ...						Ref	—	B	
	E.G5 82.149	TRANSMITTER/RECEIVER, NO. 2, PTR/175, REAR FUSELAGE, INSTALLATION						—	—	—	
		Spares for:—									
10AS/9428544	†	MOUNTING , Type MT.1477 ...						1	—	A	
		Attaching parts for Ref. 10AS/9428544:—									
28D/9436920	A25/1C	Bolt, 2 BA ...						16	—	C	
28W/9419402	SP.13/C	Washer ...						16	—	C	
10D/9711781	†	TRANSMITTER/RECEIVER, PTR/175 ...						1	—	A	
	SCD.78698	TRANSMITTER/RECEIVER, NO. 1, PT/175, CENTRE FUSELAGE, INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
10AD/9326361	†	BOX , interconnecting ...						1	—	B	
		Attaching parts for Ref. 10AD/9326361:—									
28S/7105755	A217/C14	Screw, 8 UNC ...						4	—	C	
28W/9156626	SP.122/C	Washer ...						4	—	C	
	SCD.78697	BRACKET , assembly, control mounting ...						1	L72	—	
		Attaching parts for SCD.78697:—									
28D/1212315	A60/2E	Bolt, 1/4" BSF ...						4	—	C	
28W/9418921	SP.13/E	Washer ...						4	—	C	
10L/9433247	†	CONTROL , muting, receiver ...						1	—	A	
		Attaching parts for Ref. 10L/9433247:—									
28S/1200034	A31/B16	Screw, 4 BA ...						4	—	C	
28W/9419465	SP.13/B	Washer ...						4	—	C	
10AS/9428544	†	MOUNTING , Type MT.1477 ...						1	—	A	
		Attaching parts for Ref. 10AS/9428544:—									
28D/1007972	A25/1C	Bolt, 2 BA ...						16	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA ...						16	—	C	
28W/9419402	SP.13/C	Washer ...						16	—	C	
10D/9711781	†	TRANSMITTER/RECEIVER, PTR/175 ...						1	—	A	
10L/1070030	†	UNIT , control, Type C.1607/7, navigator's coaming panel (SRIM. 3533) (Mod. 4799)						1	—	A	
10L/9455739	†	UNIT , control, Type C.1607/4, starboard instrument panel						2	—	A	

CANBERRA E Mk. 15

Page RH.1/2

RADIO ZERO READER INSTALLATION

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.82.1067	ZERO READER, INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
	6A/6126	Spares for:—						—	—	—	
	28S/9997545	BOX , junction, Type E						1	—	A	
	28W/9419402	Attaching parts for Ref. 6A/6126:—						—	—	—	
		Screw						2	—	C	
		Washer						2	—	C	
	E.B6.80.637	MOUNTING BOX JUNCTION FOR FLIGHT INSTRUMENT, ASSEMBLY						—	—	—	
	26413	Spares for:—						—	—	—	
	28D/1010658	ANGLE , mounting, assembly						1	—	C	
	28M/1278189	Attaching parts for E.B6.80.639:—						—	—	—	
	28W/9419465	Bolt, 4 BA						3	—	C	
		Nut, 4 BA						3	—	C	
		Washer						3	—	C	
	26412	PLATE , mounting assembly						1	—	C	
	28D/1010658	Attaching parts for E.B6.80.643:—						—	—	—	
	28M/1278189	Bolt, 4 BA						6	—	C	
	28W/9419465	Nut, 4 BA						6	—	C	
		Washer						6	—	C	
	SCD.78951	MOUNTING AND COMPUTER, INSTALLATION (SRIM.3533) (MOD. 4799)						—	—	—	
	6A/3122	Spares for:—						—	—	—	
	SCD.78952	COMPUTER , Type ZL2						1	—	A	
	6A/3359	TRAY, MOUNTING, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	28S/9419435	Spares for:—						—	—	—	
	28M/1278189	BACKPLATE , assembly						1	—	A	
	28W/9419465	Attaching parts for Ref. 6A/3359:—						—	—	—	
		Screw, 4 BA						6	—	C	
		Nut, 4 BA						6	—	C	
		Washer						6	—	C	
	SCB.79726/2	BONDING , strip (SRIM.3533) (Mod. 4799) ...						2	—	—	
	10AS/9469287	DEVICE , lock						3	—	C	
	10AJ/1201981	MOUNTING, AV , 8 lbs (SRIM.3533) (Mod. 4799)						2	—	C	
	10AJ/9433711	MOUNTING, AV , 14 lbs (SRIM.3533) (Mod. 4799)						2	—	C	
	28D/9436920	Attaching parts for Ref. 10AJ/1201981 or 10AJ/9433711:—						—	—	—	
	28M/1278190	Bolt, 2 BA						4	—	C	
		Nut, 2 BA						4	—	C	
	28D/1010132	Attaching parts for SCD.78952:—						—	—	—	
	10A/17930	Bolt, 3" BSF						4	—	C	
		Washer, check						4	—	C	