

A.P.101B-0417-3A

Page M1

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN AIRCRAFT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	ELECTRONIC EQUIPMENT IN AIRCRAFT, ASSEMBLY (EG7.82.11)	-	-	
	Spares for:-			
110D6585073	. BOARD, assembly (Mod 5443) (Service supply, Service fit)	1	-	
6080.8005	. CONTROL, counter measures, 6080.8005 (ARI23165) (Pre Mod 5466)	2	-	1/11
110L/6566362	. CONTROL, modulator (Mod 5443) (Pre Mod 5466)	2	-	1/10
51150/2	. COOLER, liquid, HD609 (ARI23166)	3	-	1/2
	. COUPLER, directional (ARI23165) (Pre Mod 5466)	2	-	1/6
110K/6566361	. GENERATOR, (Mod 5443) (Pre Mod 5466)	2	-	1/20
R C4646	. INDICATOR, control (ARI23166) (Pre Mod 5534)	3	-	1/14
R C4646	. INDICATOR, control (ARI23166) (Mod 5534) (Pre Mod 5535)	1	-	
R 1.156DG14459	. INDICATOR, control E/F band (Mod 5534)	2	-	1/14A
R 1.156DG14468	. INDICATOR, control D band (Mod 5535)	1	-	1/14B
C3324	. INDICATOR, control C3324 (ARI23167)	1	-	1/17
51166.4	. OSCILLATOR, R.F. 0-1104 (ARI23166)	2	-	1/3
51166.1	. OSCILLATOR, R.F. band (ARI23166)	1	-	1/15
PP2679	. PACK, power supply, PP2679 (ARI23167)	1	-	1/18
151060	. PACK, power supply, 6053-8022 (ARI23165) (Pre Mod 5466)	2	-	1/1
TYPE 151061	. RECEIVER, 6053-8021 (ARI23165) (Pre Mod 5466)	2	-	1/16
	. RECEIVER, AN/APR9 IN CENTRE FUSELAGE, INSTALLATION (EG7.82.2913) (SAS4745) (Pre Mod 5466)	-	-	14A/1
	Spares for:-			
SCB71995	. . AMPLIFIER, converter, Type 537G	1	-	14A/2
SCHQ127729A1	. . ANTENNA, assembly, (SRIM 3932)	1	-	14A/3
SCSHQ127783A4	. . CLEAT, cable (SRIM 3932)	3	-	14A/4
90G/72440	. . RELAY, assembly, Type 539	1	-	14A/5
90G/72698	. . SWITCH, Type 563	1	-	14A/6
	Attaching parts for 90G/72698			
A32/C18	. . Screw, 2 BA round head	3	-	14A/7
SP47/C	. . Washer, spring	3	-	14A/8
TN128	. . TUNER	1	-	14A/9
TN1298	. . TUNER	1	-	14A/10
TN130	. . TUNER	1	-	14A/11
or				
TN131	. . TUNER	1	-	14A/12
PP337	. . UNIT, power supply	1	-	14A/13
T915	. TRANSMITTER, T915 (ARI23166)	3	-	1/4
150886	. TRANSMITTER, 6053-8018 (ARI23165) (Pre Mod 5466)	2	-	1/5
T782	. TRANSMITTER, PNT782 (ARI23167)	1	-	1/19
612/DG/14152	. TRANSMITTER, radar, X13919 (ARI18207/1) (Pre Mod 5466)	2	-	1/13
612/DG/14303	. TRANSMITTER, CONTROL, X13920 (ARI18207/1) (Pre Mod 5466)	1	-	1/12
151942	. UNIT, line delay, 151942 (ARI23165) (Pre Mod 5466)	2	-	1/7
	Attaching parts for 151942:-			
A102/2C	. Bolt, 8 UNC, hex head	5	-	1/8
SP122/C	. Washer, 7 UNC, packing	5	-	1/9

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN AIRCRAFT

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	- . UNIT, POWER, FOR AN/APR9 IN REAR FUSELAGE, INSTALLATION (EG7.82.2911) (SAS4745) Spares for:	-	-	25A/1
R	SCSHQ127010 . . ADAPTOR, channel (SRIM3932)	2	-	25A/2
R	A25/2C . . BOLT, 2BA	16	-	25A/3
R	T605 . . MOUNTING, Type T605	1	-	25A/4
R	A125/D66 . . NUT, stiff, 10 UNF	1	-	25A/5
R	SCSHQ127619A4 . . PACKER (SRIM3932)	4	-	25A/6
R	EB6.82.275 . . STRUCTURE, transmitter-receiver mounting	1	-	25A/7
R	CAMBION			
R	190-1629-3-07 . . STUD	1	-	25A/8
R	SCSHQ127011A1 . . TOPHAT, assembly (SRIM3932)	2	-	25A/9
R	PP336 . . UNIT, power supply	1	-	25A/10
R	SP123/D . . WASHER, 10 UNF	16	-	25A/11
R	SP122/D . . WASHER, 10 UNF	1	-	25A/12
R	AGS2037/C . . WASHER, shakeproof	1	-	25A/13

A.P.101B-0417-3A

Page MA1

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE, ASSEMBLY (EG7.82.711) Spares for:	—	—	
R UG27C/U	. ADAPTOR, angle (Pre Mod 5466)	1	—	
R EG7.82.859	. CABLE, ASSEMBLY, CR.11, FROM ARI.23165 GENERATOR, POWER UNIT, AND ARI.18207 REPEATER TO AC/DC DISTRIBUTION BOX, GROUP (Pre Mod 5466) Consisting of:	1	—	
5E/6707476	. . CABLE, unisersil 12	QR	—	
5E/1058078	. . CABLE, unisersil 14	QR	—	
5E/9994047	. . CABLE, unisersil 16	QR	—	
SUPERFLEXIT				
SC001-12-61	. . CONDUIT	1	—	
SUPERFLEXIT				
SC001-16-17	. . CONDUIT	1	—	
SUPERFLEXIT				
SC001-16-18	. . CONDUIT	1	—	
SUPERFLEXIT				
SC001-28-115	. . CONDUIT	1	—	
SUPERFLEXIT				
SCF122(SR)	. . END, conduit	1	—	
(ALC)-12				
SUPERFLEXIT				
SCF1942-SR-16	. . END, conduit	2	—	
SUPERFLEXIT				
SCF1979-SR-28	. . END, conduit	1	—	
508/2/04368	. . FILLER, plug, 12	QR	—	
2CZ138846	. . INSERT, socket	2	—	
2CZ139486	. . INSERT, socket	8	—	
2CZ139487	. . INSERT, socket	4	—	
SUPERFLEXIT				
SCF3017/28/12/16/16	. . JUNCTION, conduit	1	—	
22111033	. . PIN, plug	2	—	
22139494	. . PIN, plug	8	—	
508/2/03547/002	. . PIN, plug	4	—	
UK-AN				
9000/28/20PX	. . PLUG, free	1	—	
EEAS146/16	. . SLEEVE, 1/4" long	QR	—	
EEAS146/12	. . SLEEVE, 1/2" long	QR	—	
EEAS146/B	. . SLEEVE, 1" long	QR	—	
EEAS146/2	. . SLEEVE, 1" long	QR	—	
EEAS146/00	. . SLEEVE, 1" long	QR	—	
EEAS146/B	. . SLEEVE, 1 1/2" long	QR	—	
22139627	. . SLEEVE, packing	QR	—	
22139628	. . SLEEVE, packing	QR	—	
508/1/07000/200	. . SOCKET, free, Mk.7	1	—	
UK-AN				
9000/24/2S	. . SOCKET, free	2	—	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG7.82.860	. CABLE, ASSEMBLY, CR.12, FROM ARI.23166, COOLER, PORT AND STARBOARD, TO AC/DC DISTRIBUTION BOX, GROUP Consisting of:	1	—	
5E/6707476	. . CABLE, uniterail 12	QR	—	
5E/1056078	. . CABLE, uniterail 14	QR	—	
5E/9994047	. . CABLE, uniterail 16	QR	—	
SUPERFLEXIT				
SC001/16/13	. . CONDUIT	1	—	
SUPERFLEXIT				
SC001/16/16	. . CONDUIT	1	—	
SUPERFLEXIT				
SC001/28/65	. . CONDUIT	1	—	
SUPERFLEXIT				
SCF1942/SR/28	. . END, conduit	2	—	
SUPERFLEXIT				
SCF1979/SR/28	. . END, conduit	1	—	
508/2/04367	. . FILLER, plug	QR	—	
508/2/04368	. . FILLER, plug	QR	—	
2CZ138846	. . INSERT, socket	8	—	
2CZ139486	. . INSERT, socket	4	—	
2CZ139487	. . INSERT, socket	2	—	
CF3017/28/16/16	. . JUNCTION, conduit	1	—	
2Z111033	. . PIN, plug	6	—	
2Z139494	. . PIN, plug	4	—	
508/2/03547/002	. . PIN, plug	4	—	
UK-AN				
9000/28/20P	. . PLUG, free	1	—	
EEAS146/12	. . SLEEVE, 1/4" long	QR	—	
EEAS146/16	. . SLEEVE, 1/4" long	QR	—	
EEAS146/B	. . SLEEVE, 1" long	QR	—	
EEAS146/00	. . SLEEVE, 1" long	QR	—	
EEAS146/B	. . SLEEVE, 1 1/4" long	QR	—	

R
R
R

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
2Z139627	. . SLEEVE, packing	QR	-	
2Z139628	. . SLEEVE, packing	QR	-	
UK-AN				
9000/24/2S	. . SOCKET, free	2	-	
R EG7.82.861	. CABLE, ASSEMBLY, CR.13, FROM ARI.23166 COOLER AND ARI.18207 REPEATER AFT TO AC/DC DISTRIBUTION BOX, GROUP (Pre Mod 5466) Consisting of:	1	-	
5E/6407476	. . CABLE, uniteril 12	QR	-	
5E/1056078	. . CABLE, uniteril 14	QR	-	
5E/9994047	. . CABLE, uniteril 16	QR	-	
SC001/12/114	. . CONDUIT	1	-	
SC001/16/21	. . CONDUIT	1	-	
SC001/24/54	. . CONDUIT	1	-	
SCF122/SR/ALC/12	. . END, conduit	1	-	
SCF1942/SR/16	. . END, conduit	1	-	
SCF1970/SR/24	. . END, conduit	1	-	
508/2/04367	. . FILLER, plug	QR	-	
508/2/04368	. . FILLER, plug	QR	-	
2CZ138846	. . INSERT, socket	4	-	
2CZ139486	. . INSERT, socket	2	-	
2CZ139487	. . INSERT, socket	1	-	
SCF2783/24/12/16	. . JUNCTION, conduit	1	-	
2Z111033	. . PIN, plug	8	-	
2Z139494	. . PIN, plug	2	-	
508/2/03547/002	. . PIN, plug	4	-	
UK-AN				
9000/28/20PY	. . PLUG, free	1	-	
EEAS146/16	. . SLEEVE, 1/4" long	QR	-	
EEAS146/12	. . SLEEVE, 1/2" long	QR	-	
EEAS146/00	. . SLEEVE, 1" long	QR	-	
EEAS146/0000	. . SLEEVE, 1" long	QR	-	
EEAS146/0000	. . SLEEVE, 1 1/2" long	QR	-	
2Z139627	. . SLEEVE, packing	QR	-	
2Z139628	. . SLEEVE, packing	QR	-	
508/1/07000/220	. . SOCKET, free, Mk.7	1	-	
UK-AN				
9000/24/2S	. . SOCKET, free	1	-	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matt. Spec.	Plate No.
	1 2 3 4 5 6			
R EG7.82.862	. CABLE, ASSEMBLY, CR.14, FROM ARI.23165 POWER UNIT AFT TO AC/DC DISTRIBUTION BOX, GROUP (Pre Mod 5466) Consisting of:—	1	—	
5E/1056078	. . CABLE, unifersil 14	QR	—	
5E/9994047	. . CABLE, unifersil 16	QR	—	
SC001/16/128	. . CONDUIT	1	—	
SCF1938/SR/16	. . END, conduit	1	—	
SCF1942/SR/16	. . END, conduit	1	—	
2CZ139486	. . INSERT, socket	5	—	
2CZ139487	. . INSERT, socket	2	—	
2Z139494	. . PIN, plug	5	—	
2Z139495	. . PIN, plug	2	—	
UK-AN				
9000/20/15PW	. . PLUG, free	1	—	
EEAS146/16	. . SLEEVE, 1/4" long	QR	—	
EEAS146/00	. . SLEEVE, 1" long	QR	—	
EEAS146/2	. . SLEEVE, 1 1/2" long	QR	—	
2Z139627	. . SLEEVE, packing	QR	—	
2Z139628	. . SLEEVE, packing	QR	—	
UK-AN				
9000/24/2S	. . SOCKET, free	1	—	
R EG7.82.863	. CABLE, ASSEMBLY, CR.15, FROM ARI.23165 GENERATOR AFT TO AC/DC DISTRIBUTION BOX, GROUP (Pre Mod 5466) Consisting of:—	1	—	
5E/1056078	. . CABLE, unifersil 14	QR	—	
5E/9994047	. . CABLE, unifersil 16	QR	—	
SC0001/16/132	. . CONDUIT	1	—	
SCF1938/SR/16	. . END, conduit	1	—	
SCF1942/SR/16	. . END, conduit	1	—	
2CZ139486	. . INSERT, socket	5	—	
2CZ139487	. . INSERT, socket	2	—	
2Z139494	. . PIN, plug	5	—	
2Z139495	. . PIN, plug	2	—	
UK-AN				
9000/20/15P	. . PLUG, free	1	—	
EEAS146/16	. . SLEEVE, 1/4" long	QR	—	
EEAS146/00	. . SLEEVE, 1" long	QR	—	
EEAS146/2	. . SLEEVE, 1 1/2" long	QR	—	
2Z139627	. . SLEEVE, packing	QR	—	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
22139628	. . SLEEVE, packing	QR	—	
UK-AN				
9000/24/2S	. . SOCKET, free	1	—	
EG7.82.864	. CABLE, ASSEMBLY, CR.16, FROM WAVE GUIDE SWITCHES FRAME 13 AND AFT OF FRAME 29 TO AC/DC DISTRIBUTION BOX, GROUP (Pre Mod 5466) Consisting of:—	1	—	
UNINYVIN 20	. . CABLE, uninyvin 20	QR	—	
508/2/04367	. . FILLER, plug	QR	—	
BENDIX				
10-101033-10	. . FILLER, plug	16	—	
508/2/03547/002	. . PIN, plug	9	—	
508/2/05604/002	. . PIN, plug	8	—	
UK-AN				
9000/20/29P	. . PLUG, free	1	—	
EEAS146/20	. . SLEEVE, 1/4" long	QR	—	
EEAS146/6	. . SLEEVE, 1" long	QR	—	
EEAS146/00	. . SLEEVE, 1" long	QR	—	
EEAS146/00	. . SLEEVE 1 1/2" long	QR	—	
BENDIX				
PT06SE.10.6S	. . SOCKET, free	1	—	
BENDIX				
PT06SE.10.6S	. . SOCKET, free	3	—	
TYGADURE				
T120	. . TYGAFLOR	QR	—	
MIDLAND				
SILICONE				
MS944	. . VARNISH	QR	—	
—	. CABLES, CO-AXIAL, IN CENTRE FUSELAGE, INSTALLATION (EG7.82.1713) Spares for:—	—	—	2/34
—	. . BRACKET, MOUNTING, FOR CO-AXIAL CABLE CONNECTIONS, FRAME 19, ASSEMBLY (EG7.82.1789) Spares for:—	—	—	2/19
EG7.82.2845	. . . CHANNEL	1	L72	2/14
EG7.82.1769	. . . BRACKET, ASSEMBLY Consisting of:—	1	L72	2/4
EG7.82.977	 LABEL, "A.R.I.23167"	2	—	2/13
EG7.82.979	 LABEL "PORT ARI.23166"	2	—	2/11
EG7.82.981	 LABEL "STOWAGE ARI.23167"	2	—	2/9
EG7.82.983	 LABEL "STOWAGE, PORT ARI.23166"	2	—	2/8
EG7.82.985	 LABEL "STOWAGE, STBD. ARI.23166"	2	—	2/10
EG7.82.987	 LABEL "STBD. ARI.23166"	2	—	2/5
EG7.82.1771	 MEMBER, channel	1	L72	2/12

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG7.82.1773		MEMBER, side	1	L72	2/6
EG7.82.1775		MEMBER, side	1	L72	2/7
EG7.82.1763		PLATE, radius	4	L72	2/1
AMPHENOL 82-117		SOCKET, stowage Attaching parts for 82-117:—	3	—	2/2
A25/2E		Bolt, 1/4" BSF hex. head	4	—	2/3
AGS2001/E/1		Nut, stiff, 1/4" BSF	4	—	2/17
SP13/E		Washer, 1/4" BSF plain	4	—	2/15
EG7.82.1813		BRACKET, MOUNTING, FOR CO-AXIAL CABLE CONNECTION BETWEEN FRAMES 22 AND 23, ASSEMBLY Spares for:—	1	—	2/20
EG7.82.2843		ANGLE	1	L72	2/33
EG7.82.2844		ANGLE Attaching parts for EG7.82.2843 and 2844:—	1	L72	2/32
A25/1C		Bolt, 2 BA hex. head	2	—	2/31
EG7.82.1815		BRACKET, ASSEMBLY Spares for:—	1	—	2/18
EG7.82.1823		ANGLE	1	L72	2/21
EG7.82.1825		ANGLE	1	L72	2/16
EG7.82.1819		BRACKET, stowage	1	L72	2/36
EG7.82.1821		BRACKET, mounting	1	L72	2/22
EG7.82.1817		PLATE, cover	1	—	2/23
EG7.82.2841		CHANNEL, mounting, 18 SWG Attaching parts for EG7.82.2841:—	1	L72	2/26
A25/1C		Bolt, 2 BA hex. head	4	—	2/27
AGS2001/C/1		Nut, stiff, 2 BA	4	—	2/28
SP13/C		Washer, 2 BA plain	4	—	2/29
AMPHENOL 82-117		SOCKET, stowage Attaching parts for 82-117:—	1	—	2/25
A25/2E		Bolt, 1/4" BSF hex. head	4	—	2/24
AGS2001/E/1		Nut, stiff, 1/4" BSF	4	—	2/25
SP13/E		Washer, 1/4" BSF plain	4	—	2/30
—		BRACKET, MOUNTING, CO-AXIAL CABLE CLAMP BETWEEN FRAMES 13 AND 14, ASSEMBLY (EG7.82.1877) Spares for:—	—	—	3/9
EG7.82.1875		BRACKET, MOUNTING, ASSEMBLY Spares for:—	1	—	3/15
A25/16C		BOLT, 2 BA hex. head	1	—	3/21
A25/16E		BOLT, 1/4" BSF hex. head	1	—	3/22
EG7.82.2347		CLAMP, assembly	1	Tufnol	3/16
AS2306/158		TUBE, distance	1	L72	3/17
AS2308/158		TUBE, distance	1	L72	3/18
SP15/C		WASHER, 2 BA plain	1	—	3/19
SP16/E		WASHER, 1/4" BSF plain Attaching parts for EG7.82.1875:—	1	—	3/20
A25/1C		Bolt, 2 BA hex. head	6	—	3/13
AGS2001/C/1		Nut, stiff, 2 BA	6	—	3/12
SP13/C		Washer, 2 BA plain	6	—	3/14

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG7.82.2125	. . . BRACKET, CO-AXIAL CABLE SUPPORT, FRAME 13, ASSEMBLY Spares for:-	1	-	3/8
A25/15C	. . . BOLT, 2 BA hex. head	4	-	3/6
EG7.82.2127	. . . CLAMP	1	Tufnol	3/4
EG7.82.2563	. . . STRIP, bonding (Make from Ref.42914)	1	L17	3/11
EG7.82.2565	. . . STRIP, bonding	1	L17	3/5
AS2306/138	. . . TUBE, distance	4	L72	3/10
SP16/C	. . . WASHER, 2 BA plain	4	-	3/7
	Attaching parts for EG7.82.2125:-			
A25/4C	. . . Bolt, 2 BA hex. head	8	-	3/2
AGS2001/C/1	. . . Nut, stiff, 2 BA	8	-	3/3
SP16/C	. . . Washer, 2 BA plain	8	-	3/1
X156DG002019	. . . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	5/26
X156DG002018	. . . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	5/28
X156DG002017	. . . CABLE, assembly, flexible co-axial (Mod 5445)	2	-	5/16
X156DG002016	. . . CABLE, assembly, flexible co-axial (Mod 5445)	2	-	5/34
X156DG002014	. . . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	5/33
X156DG002015	. . . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	5/15
MARCONI				
R80-1884-01	. . . CABLE, rigid co-axial, assembly, "E/F" band	1	-	5/17
MARCONI				
R60-1886-01	. . . CABLE, rigid co-axial, assembly, "E/F" band	1	-	5/20
MARCONI				
R60-1888-01	. . . CABLE, rigid co-axial, assembly, "D" band	1	-	5/14
MARCONI				
R60-1890-01	. . . CABLE, rigid co-axial, assembly, "A" band	1	-	5/29
-	. . . CLAMPS, CO-AXIAL, CABLE, FRAME 18, ASSEMBLY (EG7.82.1755) Spares for:-	-	-	4/34
EG7.82.1759	. . . ANGLE, attachment	2	L72	4/37
A25/1C	. . . BOLT, 2 BA hex. head	2	-	4/46
A25/3C	. . . BOLT, 2 BA hex. head	2	-	4/48
A25/14C	. . . BOLT, 2 BA hex. head	2	-	4/57
A25/20C	. . . BOLT, 2 BA hex. head	1	-	4/63
A25/20E	. . . BOLT, 1/4" BSF hex. head	1	-	4/62
EG7.82.1751	. . . CLAMP	1	Tufnol	4/56
EG7.82.1753	. . . CLAMP	1	Tufnol	4/49

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AGS.2001/C/1	. . . NUT, stiff, 2BA	4	—	4/55
EG7.82.1763	. . . PLATE, radius	2	L72	4/50
EG7.82.2567	. . . STRIP, bonding	1	L17	4/58
EG7.82.2571	. . . STRIP, bonding	1	L17	4/47
EG7.82.2573	. . . STRIP, bonding (Make from Ref. 42917)	1	L17	4/51
AS.2306/128	. . . TUBE, distance	2	L72	4/54
AS.2306/188	. . . TUBE, distance	1	L72	4/60
AS.2308/188	. . . TUBE, distance	1	L72	4/59
SP13/C	. . . WASHER, 2BA plain	4	—	4/53
SP16/C	. . . WASHER, 2BA plain	3	—	4/52
SP16/E	. . . WASHER, 1/4" BSF plain	1	—	4/61
—	. . CLAMP, FOR CO-AXIAL CABLE, FLOOR GIRDER 15, ASSEMBLY (EG7.82.1791) Spares for:—	—	—	4/27
EG7.82.1797	. . . PLATE, ADAPTOR, ASSEMBLY Spares for:—	1	—	4/1
A25/17C	 BOLT, 2BA hex. head	1	—	4/11
A25/17E	 BOLT, 1/4" BSF hex. head	1	—	4/23
A25/18C	 BOLT, 2BA hex. head	1	—	4/26
EG7.82.1767	 CLAMP	1	Tufnol	4/14
EG7.82.1809	 PACKING, anchor nut	1	L64	4/8
EG7.82.1811	 PACKING, anchor nut	1	L64	4/2
EG7.82.1803	 PLATE, adaptor	1	L72	4/3
EG7.82.2567	 STRIP, bonding	1	L17	4/15
EG7.82.2569	 STRIP, bonding	1	L17	4/7
AS.2306/168	 TUBE, distance	2	L72	4/16
AS.2308/168	 TUBE, distance	1	L72	4/17
SP13/C	 WASHER, 2BA plain	2	—	4/24
SP13/E	 WASHER, 1/4" BSF plain Attaching parts for EG7.82.1797:—	1	—	4/20
A25/3C	. . . Bolt, 2BA hex. head	5	—	4/4
AGS.2001/C/1	. . . Nut, stiff, 2BA	5	—	4/12
SP13/C	. . . Washer, 2BA plain	5	—	4/10
—	. . CLAMP, FOR CO-AXIAL CABLES, FLOOR GIRDER 16, ASSEMBLY (EG7.82.1793) Spares for:—	—	—	4/28
EG7.82.1799	. . . PLATE, adaptor, assembly Spares for:—	1	—	4/31
A25/17C	 BOLT, 2BA hex. head	1	—	4/42
A25/17E	 BOLT, 1/4" BSF hex. head	1	—	4/45
A25/18C	 BOLT, 2BA hex. head	1	—	4/44

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.1767	 CLAMP	1	Tufnol	4/36
EG7.82.1809	 PACKING, anchor nut	1	L64	4/33
EG7.82.1811	 PACKING, anchor nut	1	L64	4/29
EG7.82.1805	 PLATE, adapter	1	L72	4/30
AS2306/168	 TUBE, distance	2	L72	4/35
AS2308/168	 TUBE, distance	1	L72	4/39
SP13/C	 WASHER, 2 BA plain	2	—	4/40
SP13/E	 WASHER, 1/4" BSF plain	1	—	4/43
	Attaching parts for EG7.82.1799:—			
A25/3C	. . . Bolt, 2 BA hex. head	5	—	4/32
AGS2001/C/1	. . . Nut, stiff, 2 BA	5	—	4/41
SP13/C	. . . Washer, 2 BA plain	5	—	4/38
—	. . CLAMP, FOR CO-AXIAL CABLE, FLOOR GIRDER 17, ASSEMBLY (EG7.82.1795) Spares for:—	—	—	5/30
EG7.82.1801	. . . PLATE, ADAPTER, ASSEMBLY Spares for:—	1	—	5/32
A25/19C	 BOLT, 2 BA hex. head	1	—	5/56
A25/19E	 BOLT, 1/4" BSF hex. head	1	—	5/57
A25/21C	 BOLT, 2 BA hex. head	1	—	5/55
EG7.82.1765	 CLAMP	1	Tufnol	5/52
EG7.82.1809	 PACKING	1	L64	5/35
EG7.82.1811	 PACKING	1	L64	5/37
EG7.82.1807	 PLATE, adapter	1	L72	5/31
AS2306/198	 TUBE, distance	2	L72	5/44
AS2308/198	 TUBE, distance	1	L72	5/50
SP13/C	 WASHER, 2 BA plain	2	—	5/43
SP13/E	 WASHER, 1/4" BSF plain	1	—	5/54
	Attaching parts for EG7.82.1801:—			
A25/3C	. . . Bolt, 2 BA hex. head	5	—	5/27
AGS2001/C/1	. . . Nut, stiff, 2 BA	5	—	5/49
SP13/C	. . . Washer, 2 BA plain	5	—	5/47
—	. . CLAMP, FOR CO-AXIAL CABLE, FLOOR GIRDER 20, ASSEMBLY (EG7.82.1833) Spares for:—	—	—	5/36
EG7.82.1831	. . . PLATE, ADAPTER, ASSEMBLY Spares for:—	1	—	5/38
A25/15C	 BOLT, 2 BA hex. head	2	—	5/48
EG7.82.1829	 CLAMP, assembly	1	Tufnol	5/46
EG7.82.1835	 PLATE, adapter	1	L72	5/39
AS2306/138	 TUBE, distance	2	L72	5/51

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
SP16/C	 WASHER, 2 BA plain Attaching parts for EG7.82.1831:—	2	—	5/45
A52/2C	 Bolt, 2 BA hex. head	4	—	5/40
AGS2001/C/1	 Nut, stiff, 2 BA	4	—	5/42
SP16/C	 Washer, 2 BA plain	4	—	5/41
—	. . . CLAMP, FOR CO-AXIAL CABLE, FLOOR GIRDER 22, ASSEMBLY (EG7.82.1837) Spares for:—	—	—	4/22
EG7.82.1831	 PLATE, ADAPTER, ASSEMBLY Spares for:—	1	—	4/5
A25/15C	 BOLT, 2 BA hex. head	2	—	4/25
EG7.82.1829	 CLAMP, assembly	1	Tufnoi	4/18
EG7.82.1835	 PLATE, adapter	1	L72	4/6
SP16/C	 WASHER, 2 BA plain Attaching parts for EG7.82.1831:—	2	—	4/21
A25/3C	 Bolt, 2 BA hex. head	4	—	4/9
AGS2001/C/1	 Nut, stiff, 2 BA	4	—	4/19
SP16/C	 Washer, 2 BA plain	4	—	4/13
EG7.82.2823	. . . CLAMP, aft of frame 13, assembly Attaching parts for EG7.82.2823:—	1	Tufnoi	5/21
A61/14C	. . . Bolt, 2 BA hex. head	2	—	5/22
AGS2001/C/3	. . . Nut, stiff, 2 BA	2	—	5/23
SP15/C	. . . Washer, 2 BA plain	2	—	5/24
—	. . . FAIRLEAD, CO-AXIAL CABLE, BULKHEAD FRAME 13, ASSEMBLY (EG7.82.1673) Spares for:—	—	—	5/11
EG7.82.1675	. . . FAIRLEAD Attaching parts for EG7.82.1675:—	1	Tufnoi	5/4
A25/6C	. . . Bolt, 2 BA hex. head	6	—	5/6
AGS2001/C/1	. . . Nut, stiff, 2 BA	6	—	6/9
SP16/C	. . . Washer, 2 BA plain	6	—	5/5
—	. . . FAIRLEAD, CO-AXIAL CABLES, FRAME 13, ASSEMBLY (EG7.82.1711) Spares for:—	—	—	5/19
EG7.82.1709	. . . FAIRLEAD Attaching parts for EG7.82.1709:—	1	Tufnoi	5/1
A25/6C	. . . Bolt, 2 BA hex. head	8	—	5/10
AGS2001/C/1	. . . Nut, stiff, 2 BA	8	—	5/12
SP13/C	. . . Washer, 2 BA plain	8	—	5/13
EG7.82.2343	. . . RETAINER Attaching parts for EG7.82.2343:—	1	Tufnoi	5/2
A25/8C	. . . Bolt, 2 BA hex. head	1	—	5/3
AGS2001/C/1	. . . Nut, stiff, 2 BA	1	—	5/7
SP13/C	. . . Washer, 2 BA plain	1	—	5/8
AMPHENOL 57125	. . . PLUG L.T. (Marconi R30 — 9281)	4	—	5/18
EG7.82.2575	. . . STRIP, bonding, cable clamp at floor girder 22 (Make from Ref.42920)	1	L17	5/53
EEAS237/16/AH	. . . WASHER, "D", for bonding clips	4	L72	5/25

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.3029	. CABLE, assembly, 9J3 to 10J1 (Mod.5444)	2	—	
R SCSHQ126679A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126669A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126676A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126677A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126678A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ127608A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ127610A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ127609A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126686A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126687A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126673A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126672A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ127605A1	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126685A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
R SCSHQ126689A2	. CABLE, assembly (SRIM 3932) (Mod.5176) (Pre Mod 5466)	1	—	
TYPE 519B	. COMPARATOR, waveguide, type 519B (Mod. 5083)	1	—	
R E.G7.82.849	. CONNECTOR, assembly, CR.1, from pressure bulkhead to ARI.23165 aft power supply unit (Pre Mod 5466)	1	—	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	E.G7.82.850	CONNECTOR, assembly, CR.2, from pressure bulkhead to ARI.18207 aft repeater (Pre Mod 5466)	1	—	
R	E.G7.82.851	CONNECTOR, assembly, CR.3, from pressure bulkhead to ARI.23165 after generator unit (Pre Mod 5466)	1	—	
	E.G7.82.852	CONNECTOR, assembly, CR.4, from pressure bulkhead to ARI.23166 aft cooler	1	—	
	E.G7.82.853	CONNECTOR, assembly, CR.5, from pressure bulkhead to ARI.23166 cooler, port	1	—	
	E.G7.82.854	CONNECTOR, assembly, CR.6, from pressure bulkhead to ARI.23166 cooler, starboard	1	—	
R	E.G7.82.855	CONNECTOR, assembly, CR.7, from pressure bulkhead to ARI.23165 power unit, forward (Pre Mod 5466)	1	—	
R	E.G7.82.856	CONNECTOR, assembly, CR.8, from pressure bulkhead to ARI.23165 generator unit, forward (Pre Mod 5466)	1	—	
R	E.G7.82.857	CONNECTOR, assembly, CR.9, from pressure bulkhead to ARI.18207 repeater, forward (Pre Mod 5466)	1	—	
R	E.G7.82.865	CONNECTOR, assembly, CR.17, from ARI.23165 forward receiver unit to plug break, frame 29 (Pre Mod 5466)	1	—	
R	E.G7.82.866	CONNECTOR, assembly, CR.18, from ARI.23165 aft receiver unit to plug break, frame 29 (Pre Mod 5466)	1	—	
	E.G7.82.858	CONNECTOR, assembly, CR.10, from pressure bulkhead to ARI.23167 power unit	1	—	
R	E.G7.82.868	CONNECTOR, assembly, CR.20, from ARI.23165 power unit to forward and aft transmitter unit (Pre Mod 5466)	2	—	
R	E.G7.82.869	CONNECTOR, assembly, CR.21, from ARI.23165 transmitter to forward and aft power unit (Pre Mod 5466)	2	—	
R	E.G7.82.870	CONNECTOR, assembly, CR.22, from ARI.23165 to power unit (Pre Mod 5466)	2	—	
R	E.G7.82.873	CONNECTOR, assembly, CR.25, from ARI.23165 transmitter to receiver (Pre Mod 5466)	2	—	
R	E.G7.82.874	CONNECTOR, assembly, CR.26, from ARI.23165 receiver to delay unit (Pre Mod 5466)	2	—	
R	E.G7.82.875	CONNECTOR, assembly, CR.27, from ARI.23165 delay unit to transmitter (Pre Mod 5466)	2	—	
	E.G7.82.876	CONNECTOR, assembly, CR.28, from ARI.23166 cooler to transmitter	2	—	
	E.G7.82.877	CONNECTOR, assembly, CR.29, from ARI.23166 cooler to transmitter	3	—	
	E.G7.82.878	CONNECTOR, assembly, CR.30, from ARI.23166 cooler to transmitter	1	—	
R	E.G7.82.879	CONNECTOR, assembly, CR.31, from ARI.23165 receiver to generator (Pre Mod 5466)	2	—	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
R E.G7.82.880	. CONNECTOR, assembly, CR.32, from ARI.23165 receiver to power unit (Pre Mod 5466)	2	—	
R E.G7.82.881	. CONNECTOR, assembly, CR.33, from ARI.23165 receiver to generator (Pre Mod 5466)	2	—	
R E.G7.82.882	. CONNECTOR, assembly, CR.34, from ARI.23165 receiver to generator (Pre Mod 5466)	2	—	
EG7.82.884	. CONNECTOR, assembly, CR.36, from ARI.23167 power supply to transmitter	1	—	
90G.A1.98160	. ELEMENT, detection, type 519D (Mod. 5083)	1	—	
90G/A1.122116	. ELEMENT, detection, type 519C (Mod. 5083)	3	—	
90G.A1.98159	. ELEMENT, detection, type 519D (Mod. 5083)	1	—	
R —	. TRAY, ASSEMBLIES IN BOMB BAY PACKS, INSTALLATION (E.G7.82.715) (Pre Mod 5466) Spares for:—	—	—	6/23
RAYTHEON CO. MS.91405-A10	. . . BASE, mounting	2	—	6/13
	Attaching parts for MS.91405-A10:—			
A25/1C	. . . Bolt, 2 BA hex. head	16	—	6/14
AGS.2001/C/1	. . . Nut, stiff, 2 BA	16	—	6/15
SP13/C	. . . Washer, 2 BA plain	16	—	6/16
E.G7.82.973	. . . LEAD, FLEXIBLE, ASSEMBLY Spares for:—	32	—	6/12
E.G7.82.788	. . . BOLT, special, 2 BA (May be made from A31/C18)	2	S1	6/9
E.G7.82.791	. . . WASHER, tapped, 2 BA	2	S510	6/11
E.G7.82.757	. . . TRAY, MOUNTING No. 3, ARI.23165 GENERATOR, ASSEMBLY Consisting of:—	1	—	6/20
RAYTHEON MS.91405-A10	. . . BASE, mounting	1	—	6/21
E.G7.82.947	. . . LABEL	1	—	6/22
E.G7.11.477	. . . TRAY, EQUIPMENT, ASSEMBLY Spares for:—	1	L73	6/5
AGS.2001/E/1	 NUT, stiff, 1/4" BSF	2	—	6/1
E.G7.11.193	 PIN, roller	4	S95	6/8
E.G7.11.201	 PIN, locating	2	S95	6/6
E.G7.11.195	 ROLLER	4	S95	6/7
SP13/E	 WASHER, 1/4" BSF plain	2	—	6/2
	Attaching parts for E.G7.11.477:—			
A25/2C	. . . Bolt, 2 BA hex. head	16	—	6/10
AGS.2001/C/1	. . . Nut, stiff, 2 BA	16	—	6/3
SP13/C	. . . Washer, 2 BA plain	16	—	6/4
E.G7.82.759	. . . TRAY, MOUNTING, No. 1, ARI.18207 TRANSMITTER, ASSEMBLY Consisting of:—	1	—	7/46
RAYTHEON MS.91405-B101	. . . BASE, mounting	1	—	7/47

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
42932	E.G7.82.953	LABEL							1	-	-	7/48
	E.G7.11.475	TRAY, EQUIPMENT, ASSEMBLY							1	L73	B	7/3
		Spares for:-										
28M/9480017	AGS.2001/E/1	NUT, stiff, 1/4" BSF							2	-	C	7/1
42929	E.G7.11.193	PIN, roller							4	S95	C	7/9
42930	E.G7.11.201	PIN, locating							2	S95	C	7/6
42931	E.G7.11.195	ROLLER							4	S95	C	7/7
28W/9418921	SP13/E	WASHER, 1/4" BSF plain							2	-	C	7/2
		Attaching parts for E.G7.11.475:-										
28D/9133011	A25/2C	Bolt, 2 BA hex. head							16	-	C	7/8
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							16	-	C	7/4
28W/9419402	SP13/C	Washer, 2 BA plain							16	-	C	7/5
	E.G7.82.761	TRAY, MOUNTING, No. 8, ARI.23166							1	-	-	7/19
		TRANSMITTER, ASSEMBLY										
		Consisting of:-										
R 110AJ/4686761	840-20	BASE, mounting							1	-	B	7/20
43916	E.G7.82.931	LABEL							1	-	C	7/21
42932	E.G7.11.475	TRAY, EQUIPMENT, ASSEMBLY							1	L73	B	7/3
		Spares for:-										
28M/9480017	AGS.2001/E/1	NUT, stiff, 1/4" BSF							2	-	C	7/1
42929	E.G7.11.193	PIN, roller							4	S95	C	7/9
42930	E.G7.11.201	PIN, locating							2	S95	C	7/6
42931	E.G7.11.195	ROLLER							4	S95	C	7/7
28W/9418921	SP13/E	WASHER, 1/4" BSF plain							2	-	C	7/2
		Attaching parts for E.G7.11.475:-										
28D/9133011	A25/2C	Bolt, 2 BA hex. head							16	-	C	7/8
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							16	-	C	7/4
28W/9419402	SP13/C	Washer, 2 BA plain							16	-	C	7/5
10AJ/2226347	E.G7.82.763	TRAY, MOUNTING, No. 2, ARI.23165							1	-	B	7/28
		TRANSMITTER, ASSEMBLY										
		Consisting of:-										
R 110AJ/4686781	RAYTHEON SO.BA-810-840	BASE, mounting							1	-	B	7/29
	E.G7.82.951	LABEL							1	-	-	7/30
42932	E.G7.11.475	TRAY, EQUIPMENT, ASSEMBLY							1	L73	B	7/3
		Spares for:-										
28M/9480017	AGS.2001/E/1	NUT, stiff, 1/4" BSF							2	-	C	7/1
42929	E.G7.11.193	PIN, roller							4	S95	C	7/9
42930	E.G7.11.201	PIN, locating							2	S95	C	7/6
42931	E.G7.11.195	ROLLER							4	S95	C	7/7

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7			
28W/9418921	SP13/E								2	—	C 7/2
28D/9133011	A25/2C								16	—	C 7/8
28M/1278190	AGS.2001/C/1								16	—	C 7/4
28W/9419402	SP13/C								16	—	C 7/5
	E G7.82.765								1	—	— 6/17
R 110AJ/3423882	RAYTHEON MS.91405-A10								1	—	B 6/18
	E G7.82.929								1	—	— 6/19
42928	E G7 11.477								1	L73	B 6/5
28M/9480017	AGS.2001/E/1								2	—	C 6/1
42929	E G7.11.193								4	S95	C 6/8
42930	E G7.11.201								2	S95	C 6/6
42931	E G7 11.195								4	S95	C 6/7
28W/9418921	SP13/E								2	—	C 6/2
28D/9133011	A25/2C								16	—	C 6/10
28M/1278190	AGS.2001/C/1								16	—	C 6/3
28W/9419402	SP13/C								16	—	C 6/4
	E G7 82 767								1	—	— 7/48
R 110AJ/4686780	RAYTHEON MS.91405S-B102								1	—	B 7/50
	43915 E.G7.82.933								1	—	C 7/51
42932	E.G7.11.475								1	L73	B 7/3
28M/9480017	AGS.2001/E/1								2	—	C 7/1
42929	E G7 11.193								4	S95	C 7/9
42930	E G7.11.201								2	S95	C 7/6
42931	E.G7 11.195								4	S95	C 7/7
28W/9418921	SP13/E								2	—	C 7/2
28D/9133011	A25/2C								16	—	C 7/8
28M/1278190	AGS.2001/C/1								16	—	C 7/4
28W/9419402	SP13/C								16	—	C 7/5
	E G7 82.769								1	—	— 7/22
R 110AJ/4686780	RAYTHEON MS.91405S-B102								1	—	B 7/23

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description	1 2 3 4 5 6 7							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
R	42932	E.G7.82.925 E.G7.11.475	LABEL TRAY, EQUIPMENT, ASSEMBLY							1 1	— L73	— B	7/24 7/3
	28M/9480017	AGS.2001/E/1	Spares for:— NUT, stiff, 1/4" BSF							2	—	C	7/1
	42929	E.G7.11.193	PIN, roller							4	S95	C	7/9
	42930	E.G7.11.201	PIN, locating							2	S95	C	7/6
	42931	E.G7.11.195	ROLLER							4	S95	C	7/7
	28W/9418921	SP13/E	WASHER, 1/4" BSF plain							2	—	C	7/2
	28D/9133011	A25/2C	Attaching parts for E.G7.11.475:— Bolt, 2 BA hex. head							16	—	C	7/8
	28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							16	—	C	7/4
	28W/9419402	SP13/C	Washer, 2 BA plain							16	—	C	7/5
	10AJ/2226345	E.G7.82.771	TRAY, MOUNTING, No. 14, ARI.23165 TRANSMITTER, ASSEMBLY							1	—	B	7/16
	110AJ/4686781	RAYTHEON SO.BA-810-B40	Consisting of:— BASE, mounting							1	—	B	7/17
	42932	E.G7.82.949 E.G7.11.475	LABEL TRAY, EQUIPMENT, ASSEMBLY							1 1	— L73	— B	7/18 7/3
	28M/9480017	AGS.2001/E/1	Spares for:— NUT, stiff, 1/4" BSF							2	—	C	7/1
	42929	E.G7.11.193	PIN, roller							4	S95	C	7/9
	42930	E.G7.11.201	PIN, locating							2	S95	C	7/6
42931	E.G7.11.195	ROLLER							4	S95	C	7/7	
28W/9418921	SP13/E	WASHER, 1/4" BSF plain							2	—	C	7/2	
28D/9133011	A25/2C	Attaching parts for E.G7.11.475:— Bolt, 2 BA hex. head							16	—	C	7/8	
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							16	—	C	7/4	
28W/9419402	SP13/C	Washer, 2 BA plain							16	—	C	7/5	
R		E.G7.82.773	TRAY, MOUNTING, No. 10, ARI.23166 LIQUID COOLER, ASSEMBLY							1	—	—	7/13
	110AJ/4686780	RAYTHEON MS.91405S-B102	Consisting of:— BASE, mounting							1	—	B	7/14
	42932	E.G7.82.927 E.G7.11.475	LABEL TRAY, EQUIPMENT, ASSEMBLY							1 1	— L73	— B	7/15 7/3
	28M/9480017	AGS.2001/E/1	Spares for:— NUT, stiff, 1/4" BSF							2	—	C	7/1
	42929	E.G7.11.193	PIN, roller							4	S95	C	7/9
	42930	E.G7.11.201	PIN, locating							2	S95	C	7/6
	42931	E.G7.11.195	ROLLER							4	S95	C	7/7

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
28W/9418921	SP13/E						WASHER, 1/4" BSF plain	2	—	C	7/2
							Attaching parts for E.G7.11.475:—				
28D/9133011	A25/2C						Bolt, 2 BA hex. head	16	—	C	7/8
28M/1278190	AGS 2001/C/1						Nut, stiff, 2 BA	16	—	C	7/4
28W/9419402	SP13/C						Washer, 2 BA plain	16	—	C	7/5
	E G7.82.775						TRAY, MOUNTING, No. 4, ARI.23165	1	—	—	7/25
							POWER SUPPLY, ASSEMBLY				
							Consisting of:—				
110AJ/4686754	RAYTHEON						BASE, mounting	1	—	B	7/26
	MS 91405-B102										
	E G7.82.935						LABEL	1	—	—	7/27
42932	E G7.11.475						TRAY, EQUIPMENT, ASSEMBLY	1	L73	B	7/3
							Spares for:—				
28M/9480017	AGS 2001/E/1						NUT, stiff, 1/4" BSF	2	—	C	7/1
42929	E G7.11.193						PIN, roller	4	S95	C	7/9
42930	E G7.11.201						PIN, locating	2	S95	C	7/6
42931	E G7.11.195						ROLLER	4	S95	C	7/7
28W/9418921	SP13/E						WASHER, 1/4" BSF plain	2	—	C	7/2
							Attaching parts for E.G7.11.475:—				
28D/9133011	A25/2C						Bolt, 2 BA hex. head	16	—	C	7/8
28M/1278190	AGS 2001/C/1						Nut, stiff, 2 BA	16	—	C	7/4
28W/9419402	SP13/C						Washer, 2 BA plain	16	—	C	7/5
	E G7.82.777						TRAY, MOUNTING, No. 12, ARI.23165	1	—	—	7/10
							POWER SUPPLY, ASSEMBLY				
							Consisting of:—				
R 110A/4686754	RAYTHEON						BASE, mounting	1	—	B	7/11
	MS 91405-B102										
	E G7.82.945						LABEL	1	—	—	7/12
42932	E G7.11.475						TRAY, EQUIPMENT, ASSEMBLY	1	L73	B	7/3
							Spares for:—				
28M/9480017	AGS 2001/E/1						NUT, stiff, 1/4" BSF	2	—	C	7/1
42929	E G7.11.193						PIN, roller	4	S95	C	7/9
42930	E G7.11.201						PIN, locating	2	S95	C	7/6
42931	E G7.11.195						ROLLER	4	S95	C	7/7
28W/9418921	SP13/E						WASHER, 1/4" BSF plain	2	—	C	7/2
							Attaching parts for E. G7.11.475:—				
28D/9133011	A25/2C						Bolt, 2 BA hex. head	16	—	C	7/8
28M/1278190	AGS 2001/C/1						Nut, stiff, 2 BA	16	—	C	7/4
28W/9419402	SP13/C						Washer, 2 BA plain	16	—	C	7/5
10AJ/2226350	E G7.82.779						TRAY, MOUNTING, No. 5, ARI.23167	1	—	B	7/40
							POWER SUPPLY, ASSEMBLY				
							Consisting of:—				
110AJ/4686779	016-001927						BASE, mounting	1	—	B	7/41
	E.G7.82.921						LABEL	1	—	—	7/42

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG7.11.475	. . . TRAY, EQUIPMENT, ASSEMBLY Spares for:—	1	L73	7/3
AGS2001/E/1	 NUT, stiff, 1/4" BSF	2	—	7/1
EG7.11.193	 PIN	4	S95	7/9
EG7.11.201	 PIN	2	S95	7/6
EG7.11.195	 ROLLER	4	S95	7/7
SP13/E	 WASHER, 1/4" BSF plain	2	—	7/2
	Attaching parts for EG7.11.475:—			
A25/2C	. . . Bolt, 2 BA hex. head	16	—	7/8
AGS2001/C/1	. . . Nut, stiff, 2 BA	16	—	7/4
SP13/C	. . . Washer, 2 BA plain	16	—	7/5
EG7.82.781	. . TRAY, MOUNTING, No.7 ARI.23167 TRANSMITTER, ASSEMBLY Consisting of:—	1	—	7/37
016-001930	. . . BASE, mounting	1	—	7/38
EG7.82.923	. . . LABEL	1	—	7/39
EG7.11.475	. . . TRAY, EQUIPMENT, ASSEMBLY Spares for:—	1	L73	7/3
AGS2001/E/1	 NUT, stiff, 1/4" BSF	2	—	7/1
EG7.11.193	 PIN	4	S95	7/9
EG7.11.201	 PIN	2	S95	7/6
EG7.11.195	 ROLLER	4	S95	7/7
SP13/E	 WASHER, 1/4" BSF plain	2	—	7/2
	Attaching parts for EG7.11.475:—			
A25/2C	. . . Bolt, 2 BA hex. head	16	—	7/8
AGS2001/C/1	. . . Nut, stiff, 2 BA	16	—	7/4
SP13/C	. . . Washer, 2 BA plain	16	—	7/5
EG7.82.783	. . TRAY, MOUNTING, No.13, ARI.18207 TRANSMITTER, ASSEMBLY Consisting of:—	1	—	7/31
RAYTHEON				
MS91405-B101	. . . BASE, mounting	1	—	7/32
EG7.82.955	. . . LABEL	1	—	7/33
EG7.11.475	. . . TRAY, equipment, assembly Spares for:—	1	L73	7/3
AGS2001/E/1	 NUT, stiff, 1/4" BSF	2	—	7/1
EG7.11.193	 PIN, roller	4	S95	7/9
EG7.11.201	 PIN, locating	2	S95	7/6
EG7.11.195	 ROLLER	4	S95	7/7
SP13/E	 WASHER, 1/4" BSF plain	2	—	7/2
	Attaching parts for EG7.11.475:—			
A25/2C	. . . Bolt, 2 BA hex. head	16	—	7/8
AGS2001/C/1	. . . Nut, stiff, 2 BA	16	—	7/4
SP13/C	. . . Washer, 2 BA plain	16	—	7/5

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.785	. . . TRAY, MOUNTING, No.9, ARI.23166 TRANSMITTER, ASSEMBLY Consisting of:—	1	—	7/34
840-20	 BASE, mounting	1	—	7/35
EG7.82.939	 LABEL	1	—	7/36
EG7.11.475	 TRAY, EQUIPMENT, ASSEMBLY Spares for:—	1	L73	7/3
AGS2001/E/1	 NUT, stiff 1/4" BSF	2	—	7/1
EG7.11.193	 PIN, roller	4	S95	7/9
EG7.11.201	 PIN, locating	2	S95	7/6
EG7.11.195	 ROLLER	4	S95	7/7
SP13/E	 WASHER, 1/4" BSF plain Attaching parts for EG7.11.475:—	2	—	7/2
A25/2C	 Bolt, 2 BA hex. head	16	—	7/8
AGS2001/C/1	 Nut, stiff, 2 BA	16	—	7/4
SP13/C	 Washer, 2 BA plain	16	—	7/5
EG7.82.787	. . . TRAY, MOUNTING, No.7 ARI.23166 TRANSMITTER, ASSEMBLY Consisting of:—	1	—	7/43
840-20	 BASE, mounting	1	—	7/44
EG7.82.937	 LABEL	1	—	7/45
EG7.11.475	 TRAY, EQUIPMENT, ASSEMBLY Spares for:—	1	L73	7/3
AGS2001/E/1	 NUT, stiff, 1/4" BSF	2	—	7/1
EG7.11.193	 PIN, roller	4	S95	7/9
EG7.11.201	 PIN, locating	2	S95	7/6
EG7.11.195	 ROLLER	4	S95	7/7
SP13/E	 WASHER, 1/4" BSF plain Attaching parts for EG7.11.475:—	2	—	7/2
A25/2C	 Bolt, 2 BA hex.head	16	—	7/8
AGS2001/C/1	 Nut, stiff, 2 BA	16	—	7/4
SP13/C	 Washer, 2 BA plain	16	—	7/5
R —	. . . WAVEGUIDES, IN BOMB BAY FORWARD END, INSTALLATION (EG7.82.637) (Pre Mod 5466) Spares for:—	—	—	9/19
MARCONI R60-1761-50 or A102/9C	. . . BOLT, 8 UNC, waveguide at purging point	4	—	9/8
MARCONI R60-1761-51 or A102/4C	. . . BOLT, 8-32 UNC	4	—	
MARCONI R60-1761-52 or A102/1C	. . . BOLT, 8 UNC, waveguide flanges connecting	12	—	9/20
MARCONI R60-1761-53 or A102/3C	. . . BOLT, 8-32 UNC	12	—	
MARCONI R60-1761-54 or A102/7C	. . . BOLT, 8 UNC, waveguide flanges connecting	36	—	9/1
	. . . BOLT, 8-32 UNC	36	—	
	. . . BOLT, 8 UNC, waveguide flanges connecting	12	—	9/7
	. . . BOLT, 8-32 UNC	12	—	
	. . . BOLT, 8 UNC, waveguide flange at spacer	4	—	9/12
	. . . BOLT, 8-32 UNC	4	—	

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
	E.G7.82.1409							1	—	—	8/25
	E.G7.82.2295							1	L72	—	8/17
	E.G7.82.1423							2	Tufnol	—	8/12
	E.G7.82.2297							1	L72	—	8/16
42849	E.G7.82.1391							2	L72	C	8/9
28D/9133013	A25/5C							2	—	C	8/8
28W/9419475	SP15/C							2	—	C	8/6
	E.G7.82.1317							1	L56	—	8/26
28D/9133011	A25/2C							2	—	C	8/19
28D/9133012	A25/3C							1	—	C	8/30
28M/9403520	A27/CP							3	—	C	8/28
28W/9419475	SP15/C							3	—	C	8/29
	E.G7.82.1415							2	L56	—	8/15
28D/9133011	A25/2C							2	—	C	8/10
28D/9133012	A25/3C							1	—	C	8/7
28M/9403520	A27/CP							3	—	C	8/13
28W/9419475	SP15/C							3	—	C	8/12
	E.G7.82.1417							1	L56	—	8/18
28D/9133011	A25/2C							2	—	C	8/11
28D/9133012	A25/3C							1	—	C	8/23
28M/9403520	A27/CP							3	—	C	8/4
28W/9419475	SP15/C							3	—	C	8/21
	E.G7.82.1419							1	L56	—	8/2
28D/9133011	A25/2C							2	—	C	8/14
28D/9133012	A25/3C							1	—	C	8/5
28M/9403520	A27/CP							3	—	C	8/3
28W/9419475	SP15/C							3	—	C	8/1
	E.G7.82.1563							1	—	—	9/33
10AC/0839009	†							2	—	C	9/40
42849	E.G7.82.1391							3	L72	C	9/38
28D/9436920	A25/1C							2	—	C	9/35
28W/9419402	SP13/C							2	—	C	9/36

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
42933	E.G7.82.1659								1	L72	C	9/28
28D/9436920	A25/1C								2	—	C	9/30
28W/9419402	SP13/C								2	—	C	9/32
10AC/9839055	†								2	—	C	9/39
26DK/10317	HELLERMANN EE.11/2								QR	—	C	9/43
33H/270	EC.1099								QR	—	C	9/44
42934	E.G7.82.1609								2	S94	C	9/42
42935	E.G7.82.1579								1	L72	C	9/41
	E.G7.82.2403								1	—	—	10/36
	E.G7.82.2415								1	L72	—	10/24
	E.G7.82.1327								1	Tufnol	—	10/21
	E.G7.82.2417								1	L72	—	10/25
	E.G7.82.1253								1	L72	—	10/23
28D/1200119	A25/4C								4	—	C	10/26
28W/9419475	SP15/C								4	—	C	10/34
	E.G7.82.1257								1	L56	—	10/40
28D/9133011	A25/2C								2	—	C	10/29
28D/9133012	A25/3C								1	—	C	10/39
28M/1278190	AGS.2001/C/1								3	—	C	10/35
28W/9419475	SP15/C								3	—	C	10/33
	E.G7.82.1259								1	L56	—	10/42
28D/9133011	A25/2C								3	—	C	10/38
28M/1278190	AGS.2001/C/1								3	—	C	10/41
28W/9419475	SP15/C								3	—	C	10/37
	E.G7.82.2407								1	L56	—	10/27
28D/9133011	A25/2C								2	—	C	10/22
28D/1200119	A25/4C								1	—	C	10/31
28M/1278190	AGS.2001/C/1								3	—	C	10/32
28W/9419475	SP15/C								3	—	C	10/28
	—								—	—	—	8/36
	E.G7.82.1469								2	—	—	8/39
28D/1011024	A25/21C								3	—	C	8/43
	E.G7.82.1471								1	L72	—	8/34
	E.G7.82.1477								1	L72	—	8/40
28M/1278190	AGS.2001/C/1								3	—	C	8/32

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG7.82.1479		STEADY, switch	1	Tufnol	8/37
AS2809/4/182		TUBE, distance	3	L72	8/41
SP15/C		WASHER, 2BA plain	3	—	8/35
		Attaching parts for EG7.82.1469:			
A25/1C		Bolt, 2BA hex. head	4	—	8/31
SP13/C		Washer, 2BA plain	4	—	8/33
EG7.82.1459		CHANNEL, switch mounting, assembly	1	L72	8/38
		Attaching parts for EG7.82.1459:			
A25/2C		Bolt, 2BA hex. head	10	—	8/42
AGS2001/C/1		Nut, stiff, 2BA	10	—	8/44
SP16/C		Washer, 2BA plain	10	—	8/45
EG7.82.2533		CLIP, bonding, waveguide	1	L59	8/27
		Attaching parts for EG7.82.2533:			
A25/2C		Bolt, 2BA hex. head	1	—	8/24
AGS2001/C/1		Nut, stiff, 2BA	1	—	8/20
SP15/C		Washer, 2BA plain	2	—	8/22
—		MODULATOR, FERRITE, ON FRAME 13, INSTALLATION (EG7.82.2435)	—	—	10/30
		Spares for:			
EG7.82.2437		BRACKET, ferrite modulator, assembly	1	L72	10/5
		Attaching parts for EG7.82.2437:			
A25/3C		Bolt, 2BA hex. head	6	—	10/4
AGS2001/C/1		Nut, stiff, 2BA	6	—	10/3
SP15/C		Washer, 2BA plain	6	—	10/2
EG7.82.2493		BRACKET, flexible waveguide, assembly	1	L72	10/19
		Attaching parts for EG7.82.2493:			
A25/1C		Bolt, 2BA hex. head	2	—	10/20
A25/3C		Bolt, 2BA hex. head	2	—	10/16
AGS2001/C/1		Nut, stiff, 2BA	4	—	10/15
SP15/C		Washer, 2BA plain	4	—	10/13
SP16/C		Washer, 2BA plain	2	—	10/14
EG7.82.2485		MODULATOR, C/W ADAPTOR PLATE, ASSEMBLY	1	—	10/12
		Spares for:			
R D800659-66		MODULATOR, D800659-66 (Mod.5433)	1	—	10/18
		Attaching parts for D800659-66			
AS1242/2B		Bolt, 4BA c'sk head	8	—	10/9
AGS2001/B/1		Nut, stiff, 4BA	8	—	10/11
SP13/B		Washer, 4BA plain	8	—	10/10
EG7.82.2473		PLATE, adaptor, assembly	1	L72	10/17
		Attaching parts for EG7.82.2485:			
A25/3C		Bolt, 2BA hex. head	4	—	10/6
SP15/C		Washer, 2BA plain	4	—	10/7
EG7.82.2519		PLATE, radius	2	L72	10/8
EG7.82.2521		PLATE, radius	1	L72	10/1
R PP/Z086/14/5		NUT, 8 UNC, waveguide flange attachments	32	—	9/6

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
R MARCONI FW61-3938-50	. . PLUG, blanking	1	—	9/4
MS90064-13	. . RING, sealing, at switch flanges	6	—	9/13
†	. . RUBBER, "sorbo", waveguide at clip attachment, 3".25 x 1".0 x 1/8" thick	6	—	9/34
†	. . RUBBER, "sorbo", waveguide at clip attachment, 2".25 x 1".50 x 1/8" thick	1	—	9/27
R 10AS/0830053	. . SEAL, rubber, round section, waveguide flange sealing	30	—	9/3
R 10AS/0839004	. . SHIM, waveguide at transmitter/receiver	1	—	9/5
R R30-9084-50	. . SWITCH, "donian", W.6XA/1 (Pre SAS4745)	2	—	9/21
R R30-9084-50	. . SWITCH, "donian" (SAS4745)	2	—	
	Attaching parts for R30-9084-50:			
A102/3C	. . Bolt, 8 UNC, hex. head	3	—	9/22
SP55/C	. . Washer, 3/16" dia., double spring	3	—	9/23
MARCONI R60-1717-01	. . SPACER, purging point	1	—	9/16
MARCONI R60-1760-01	. . SPACER	1	—	9/10
MARCONI R60-1715-53	. . WAVEGUIDE, "twistaguide", inboard switch to modulator	1	—	9/14
MARCONI R60-1715-52	. . WAVEGUIDE, "twistaguide", modulator to spacer	1	—	9/2
MARCONI R60-1720-01	. . WAVEGUIDE, rigid, assembly, from inboard switch, repeater output line	1	—	9/24
MARCONI R60-1721-01	. . WAVEGUIDE, rigid, assembly, repeater output line	1	—	9/11
MARCONI R60-1722-50	. . WAVEGUIDE, flexible, assembly, output lines to inboard and outboard switches	2	—	9/26
MARCONI R60-1724-01	. . WAVEGUIDE, rigid, assembly, spacer to transmitter	1	—	9/15
MARCONI R60-1724-02	. . WAVEGUIDE, rigid, assembly, outboard switch to receiver line	1	—	9/37
MARCONI R60-1727-50	. . WAVEGUIDE, flexible, assembly, spacer to transmitter	1	—	9/17
MARCONI R60-1728-01	. . WAVEGUIDE, rigid, assembly, outboard switch to repeater, input line	1	—	9/18
MARCONI R60-1729-50	. . WAVEGUIDE, flexible, assembly, outboard	1	—	9/25
MARCONI R60-1730-01	. . WAVEGUIDE, rigid, assembly, outboard switch to receiver line	1	—	9/31
MARCONI R60-1731-01	. . WAVEGUIDE, rigid, assembly, outboard switch to receiver line	1	—	9/29
MARCONI R60-1757-01	. . WINDOW, pressure	5	—	9/9

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
—	WAVEGUIDES IN BOMB BAY, AFT END, INSTALLATION (EG7.82.639) (Pre Mod 5466) Spares for:	—	—	11/9
MARCONI R60-1761-50	. . . BOLT, 8 UNC, waveguide flange at purging point	4	—	11/14
or A102/9C	. . . BOLT, 8-32 UNC	4	—	
MARCONI R60-1761-51 or	. . . BOLT, 8 UNC, waveguide flanges at pressure windows	12	—	11/1
A102/4C	. . . BOLT, 8-32 UNC	12	—	
MARCONI R60-1761-52	. . . BOLT, 8 UNC, waveguide flanges locating	36	—	11/12
or A102/1C	. . . BOLT, 8-32 UNC	36	—	
MARCONI R60-1761-53	. . . BOLT, 8 UNC, waveguides connecting	16	—	11/2
or A102/3C	. . . BOLT, 8-32 UNC	16	—	
MARCONI R60-1761-54	. . . BOLT, 8 UNC, waveguide at spacer	4	—	11/13
or A102/7C	. . . BOLT, 8-32 UNC	4	—	
EG7.82.1611	. . . BRACKET, WAVEGUIDE SUPPORT, FRAMES 26 TO 27, ASSEMBLY Spares for:	1	—	11/43
TB/B610399	. . . BOLT, 8 UNC, waveguide attachment	4	—	11/38
EG7.82.1391	. . . CLIP, assembly Attaching parts for EG7.82.1391:	2	L72	11/31
A25/1C	. . . Bolt, 2BA hex. head	2	—	11/33
SP13/C	. . . Washer, 2BA plain	2	—	11/34
PP/Z086/14/5	. . . NUT, 8 UNC, waveguide bolt	4	—	11/37
HELLERMANN EE11/2	. . . SECTION, extruded Attaching parts for EE11/2:	QR	—	11/41
EC1099	. . . Adhesive	QR	—	11/42
EG7.82.1609	. . . STUD, special	2	S94	11/40
EG7.82.1579	. . . VISOR, assembly	1	L72	11/39
EG7.82.1715	. . . BRACKET, WAVEGUIDE SUPPORT, FRAME 28, ASSEMBLY Spares for:	1	—	12/18
EG7.82.1389	. . . CLIP Attaching parts for EG7.82.1389:	1	L72	12/17
A25/1C	. . . Bolt, 2BA hex. head	2	—	12/19
SP13/C	. . . Washer, 2BA plain	2	—	12/20
EG7.82.1721	. . . BRACKET, SWITCH MOUNTING AT FRAME 24, ASSEMBLY Spares for:	1	—	13/9
EG7.82.1469	. . . BRACKET, SWITCH MOUNTING, ASSEMBLY Consisting of:	2	—	13/15
A25/21C	. . . BOLT, 2BA hex. head	3	—	13/17
EG7.82.1471	. . . BRACKET, switch, assembly	1	L72	13/10
EG7.82.1477	. . . BRACKET, switch, assembly	1	L72	13/14
AGS2001/C/1	. . . NUT, stiff, 2BA	3	—	13/5
EG7.82.1479	. . . STEADY, switch	1	Tufnol	13/13
AS2809/4/182	. . . TUBE, distance	3	L62	13/11

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
SP15/C		WASHER, 2BA plain	3	—	13/8
A25/1C		Attaching parts for EG7.82.1469:	4	—	13/6
SP15/C		Bolt, 2BA hex. head	4	—	13/7
		Washer, 2BA plain	—	—	—
EG7.82.1725		BRACKET, mounting, assembly	1	L72	13/12
EG7.82.2533		CLIP, bonding, waveguide	1	L59	13/1
		Attaching parts for EG7.82.2533:	—	—	—
A25/2C		Bolt, 2BA hex. head	1	—	13/2
AGS2001/C1		Nut, stiff, 2BA	1	—	13/3
SP15/C		Washer, 2BA plain	2	—	13/4
EG7.82.1641		CLAMP, WAVEGUIDE, AT FRAME 29, ASSEMBLY	1	—	13/18
		Spares for:	—	—	—
EG7.82.1649		ANGLE	2	L73	13/20
EG7.82.1301		BOLT, special, 1/4" BSF	2	S96	13/16
EG7.82.1643		BRACKET, assembly	1	L73	13/28
EG7.82.1289		CHANNEL, assembly	2	L72	13/19
		Attaching parts for EG7.82.1289:	—	—	—
A25/2C		Bolt, 2BA hex. head	2	—	13/27
SP13/C		Washer, 2BA plain	2	—	13/26
EG7.82.1273		CLIP, assembly	1	L72	13/22
		Attaching parts for EG7.82.1273:	—	—	—
A25/3C		Bolt, 2BA hex. head	4	—	13/25
EEAS20/3DR		Tab, locking	2	L72	13/24
SP13/C		Washer, 2BA plain	4	—	13/23
EG7.82.1283		SPACER	1	Tufnol	13/21
—		MODULATOR, FERRITE, MOUNTING, FRAME 29, ASSEMBLY (EG7.82.2487)	—	—	12/16
		Spares for:	—	—	—
EG7.82.2479		BRACKET, "TWISTAGUIDE" SUPPORT, ASSEMBLY	1	L72	12/10
		Spares for:	—	—	—
EG7.82.2511		CLIP, assembly	1	L72	12/8
		Attaching parts for EG7.82.2511:	—	—	—
A25/2C		Bolt, 2BA hex. head	4	—	12/14
SP13/C		Washer, 2BA plain	4	—	12/12
		Attaching parts for EG7.82.2479:	—	—	—
A25/3C		Bolt, 2BA hex. head	4	—	12/13
AGS2001/C1		Nut, stiff, 2BA	4	—	12/11
SP16/C		Washer, 2BA plain	4	—	12/15
EG7.82.2485		MODULATOR, C/W ADAPTOR PLATE, ASSEMBLY	1	—	12/2
		Spares for:	—	—	—
D800659-66		MODULATOR, ferrite, type D800659-66 (Mod.5443)	1	—	12/1
		Attaching parts for D800659-66	—	—	—
AS1242/2B		Bolt, 4BA c'sk head	8	—	12/5
AGS2001/B/1		Nut, stiff, 4BA	8	—	12/3
SP13/B		Washer, 4BA plain	8	—	12/4

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.2473	 PLATE, adaptor, assembly	1	L72	12/9
A25/2C	 Attaching parts for EG7.82.2435:	4	—	12/7
SP16/C	 Bolt, 2BA hex. head	4	—	12/6
	 Washer, 2BA plain			
R 10AC/9839055	 NUT, 8 UNC, waveguide attachments	32	—	11/3
MARCONI				
FW61-3938-50	 PLUG, blanking	1	—	11/6
MS90064-13	 RING, sealing, at switch flanges	6	—	11/16
†	 RUBBER, "sorbo", waveguides at clip attachments,	3	—	11/32
	3".25 x 1" x 1/8" thick			
†	 RUBBER, "sorbo", waveguide clamp, frame 29,	1	—	11/27
	3".25 x 2".8 x 1/8" thick			
†	 RUBBER, "sorbo", clip at switch bracket, frame 29,	1	—	11/11
	4".15 x 1".9 x 1/8" thick			
R 10AS/0830053	 SEAL, rubber, round section, at waveguide flanges	30	—	11/5
R 10AS/0839004	 SHIM, waveguide to transmitter/receiver, aft of frame 28	1	—	11/23
MARCONI				
R60-1717-01	 SPACER, purging point	1	—	11/15
MARCONI				
R60-1760-01	 SPACER	1	—	11/8
MARCONI				
R30-9084-50	 SWITCH, "donlan", W6 x A1	2	—	11/21
	 Attaching parts for R30-9084-50:			
A102/3C	 Bolt, 8 UNC hex. head	3	—	11/17
SP55/C	 Washer, 3/16" dia., double spring	3	—	11/18
MARCONI				
R60-1715-54	 WAVEGUIDE, "twistaguide", assembly, modulator to	1	—	11/10
	outboard switch			
MARCONI				
R60-1715-51	 WAVEGUIDE, "twistaguide", assembly, modulator to	1	—	11/4
	purging spacer			
MARCONI				
R60-1716-50	 WAVEGUIDE, flexible, assembly, purging spacer to	1	—	11/19
	transmitter			
MARCONI				
R60-1601-02	 WAVEGUIDE, stepped, twist, assembly, repeater input line	1	—	11/28
MARCONI				
R60-1722-50	 WAVEGUIDE, flexible, assembly, repeater and receiver line	2	—	11/29
MARCONI				
R60-1724-01	 WAVEGUIDE, rigid, assembly, at transmitter	1	—	11/22
MARCONI				
R60-1724-02	 WAVEGUIDE, rigid, assembly, at receiver	1	—	11/36
MARCONI				
R60-1727-50	 WAVEGUIDE, flexible, assembly, stepped waveguide to	1	—	11/25
	repeater, input line			
MARCONI				
R60-1730-01	 WAVEGUIDE, rigid, assembly, outboard switch to repeater,	1	—	11/24
	output line			

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
MARCONI R60-1732-01	. . WAVEGUIDE, rigid, assembly, outboard switch to repeater, output line	1	—	11/26
MARCONI R60-1735-01	. . WAVEGUIDE, rigid, assembly, inboard switch to repeater, input line	1	—	11/29
MARCONI R60-1736-01	. . WAVEGUIDE, rigid, assembly, inboard switch to receiver line	1	—	11/35
MARCONI R60-1737-01	. . WAVEGUIDE, rigid, assembly, inboard switch to receiver line	1	—	11/30
MARCONI R60-1757-01	. . WINDOW, pressure	5	—	11/7
—	. WIRING AND CLIPPING IN CENTRE FUSELAGE PACKS, ASSEMBLY (EG7.82.801) (Pre Mod 5466) Spares for:	—	—	14/29
M.M.M. EC1099	. . ADHESIVE	QR	—	14/39
EEAS552/2	. . BOBBIN, distance	2	L65	14/31
EEAS552/9	. . BOBBIN, distance	2	L65	14/25
EG7.82.837	. . BONDING, flexible, assembly Attaching parts for EG7.82.837:	6	Copper Braid	14/21
A25/2E	. . Bolt, 1/4" BSF hex. head	2	—	14/23
SP13/E	. . Washer, 1/4" BSF plain	2	—	14/24
EG7.82.911	. . CLIP, saddle, assembly Attaching parts for EG7.82.911:	1	L72	14/44
AS1248/1B	. . Bolt, 4BA mushroom head	2	—	14/41
AGS2001/B/1	. . Nut, stiff, 4BA	2	—	14/45
EEAS237/6A	. . Washer, 'D'	2	L72	14/43
EB2.81.1829	. . CLIP, 'P' Attaching parts for EB2.81.1829:	1	—	14/5
A25/1/2B	. . Bolt, 4BA hex. head	1	—	14/4
AGS2001/B/1	. . Nut, stiff, 4BA	1	—	14/2
EEAS237/6A	. . Washer, 'D'	1	L72	14/3
EG7.81.2181	. . CLIP, saddle, assembly	1	—	14/36
EG7.82.2817	. . CLIP, saddle, assembly Attaching parts for EG7.81.2181 and EG7.82.2817:	1	—	14/42
A25/1/2C	. . Bolt, 2BA hex. head	2	—	14/37
AGS2001/C/1	. . Nut, stiff, 2BA	2	—	14/38
SUPERFLEXIT SCF1312-12	. . CLIP, 'P', superflexit conduit	2	—	14/9
SUPERFLEXIT SCF1312-16	. . CLIP, 'P', superflexit conduit Attaching parts for SCF1312-12 and SCF1312-16:	3	—	14/10
A25/1/2B	. . Bolt, 4BA hex. head	1	—	14/13
AGS2001/B/1	. . Nut, stiff, 4BA	1	—	14/8
EEAS237/6A	. . Washer, 'D'	1	L72	14/12

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	DRILLING, DETAILS FOR PACK WIRING							—	—	—	14/30
		ASSEMBLY (E.G7.82.807)										
		Spares for:—										
6734	EEAS.136	BRACKET, clip							8	L72	C	14/1
	E.G7.82.839	BRACKET, clip							1	L72	—	14/16
		Attaching parts for E.G7.82.839:—										
28D/1213043	AS.4566/1B	Bolt, 4 BA mushroom head							2	—	C	14/17
28M/1278189	AGS.2001/B/1	Nut, suff, 4 BA							2	—	C	14/6
28W/9419465	SP13/B	Washer, 4 BA plain							2	—	C	14/11
	E.G7.82.805	RETAINER, cable strap, assembly							17	L72	—	14/26
26DK/10317	HELLERMANN EE.11/2	EXTRUSION, rubber, helsyn 150							QR	—	C	14/40
R 6101462	E.B5.81.8291	PAD, rubber, cable straps							41	—	C	14/28
10H/	AMPHENOL HN.82GB-0510	RECEPTACLE, dummy							2	—	—	14/15
		Attaching parts for HN.82GB-0510:—										
28D/1008147	A25/1A	Bolt, 6 BA hex. head							4	—	C	14/18
	EEAS.588/1	Gasket, viton rubber, 1/32" thick							2	DTD5543	—	14/19
R 5X/4500980	2Z.139689	RECEPTACLE, dummy, UK-AN							2	—	C	14/22
		Attaching parts for 2Z.139689:—										
28D/1010658	A25/1B	Bolt, 4 BA hex. head							4	—	C	14/20
	5X/10361	RECEPTACLE, dummy							1	—	C	14/14
		Attaching parts for 2Z.139691:—										
28D/9436920	A25/1C	Bolt, 2 BA hex. head							4	—	C	14/7
	E.B5.81.7481	STRAP, cable							4	—	—	14/27
	E.B5.81.7483	STRAP, cable							19	—	—	14/33
	E.B5.81.7485	STRAP, cable							18	—	—	14/32
5F/9434857	HV.3341	STRAPPING							QR	—	C	14/34
5F/9138823	NY.3255	STUD							QR	—	C	14/35

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

[illegible]

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	ELECTRONIC EQUIPMENT IN FRONT FUSELAGE ASSEMBLY (EG7.82.1093) (Pre Mod 5466) Spares for:-	-	-	15/4
-	. AERIALS AND RADOMES, FORWARD LOOKING ASSEMBLY (EG7.82.2011) (Pre Mod 5466)	-	-	15/12
-	. AERIALS AND RADOMES, FORWARD LOOKING ASSEMBLY (EG7.82.5031) (Mod 5466) Spares for:-	-	-	
R MARCONI R60-1790-01	. . AERIAL, "I" BAND, cluster, upper and lower (ARI.23165) Attaching parts for R60-1790-01:-	2	-	15/8
A25/3C	. . Bolt, 2 BA hex. head	3	-	15/1
SP15/C	. . Washer, 2 BA plain	3	-	15/3
R MARCONI R60-1539-02	. . AERIAL, "I" band, horn, side, port and starboard (ARI.23165) (Pre Mod.5466)	2	-	15/29
R MARCONI R60-1349	. . AERIAL, "D" band, "TAMAR" (ARI.23166) (Pre Mod 5466) Attaching parts for R60-1349:-	1	-	15/33
AS1242/4/C	. . Bolt, 2 BA c'sk head	10	-	15/40
EG7.10.1655	. . Packing	1	L73	15/39
R MARCONI R60-1632-02	. . AERIAL, "E/F" band, horn, forward looking (ARI.23166) (Pre Mod 5466) Attaching parts for R60-1632-02:-	2	-	15/22
A31/C28	. . Screw, 2 BA cheese head	7	-	15/28
SP15/C	. . Washer, 2 BA plain	7	-	15/30
MARCONI R60-7030-01	. . AERIAL, metric, at centre line (ARI.23167) Attaching parts for R60-7030-01:-	1	-	15/26
A25/4C	. . Bolt, 2 BA hex. head	4	-	15/34
AS1246/3C	. . Bolt, 2 BA round head	4	-	15/27
SP16/C	. . Washer, 2 BA plain	4	-	15/31
R MARCONI R60-7040-50	. . BOLT, special, 8 UNC, "I" band, horn, aerial and waveguide attaching	8	-	15/25
R MARCONI R60-1761-53	. . BOLT, special, 8 UNC, upper and lower "I" band, cluster aerial and waveguides attaching	8	-	15/10
R EG7.82.2549	. . CLEAT, "tee", "I" band, horn, aerial and waveguide, port	1	L65	15/20
R EG7.82.2550	. . CLEAT, "tee", "I" band, horn, aerial and waveguide, starboard Attaching parts for EG7.82.2549 and 2550:-	1	L65	15/21
A25/2C	. . Bolt, 2 BA hex. head	4	-	15/16
AGS2001/C/1	. . Nut, stiff, 2 BA	4	-	15/14
SP15/C	. . Washer, 2 BA plain	4	-	15/15
R 28M/9523249 EG7.10.1249	. . NUT, special, 8 UNC . . RADOME, upper, "I" band cluster, assembly Attaching parts for EG7.10.1249:-	16 1	- L44	15/9 15/7
AS1248/3C	. . Bolt, 2 BA, mushroom head	35	-	15/2
AS1248/3E	. . Bolt, 1/4" BSF mushroom head	2	-	15/6

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
R EG7.10.1529	. . RADOME, lower, "I" band cluster, assembly	1	L44	15/32
AS1248/3C	Attaching parts for EG7.10.1529:	31	—	15/38
AS1242/3E	. . Bolt, 2BA mushroom head	2	—	15/37
AS1242/16E	. . Bolt, 1/4" BSF c'sk head	1	—	15/36
R EG7.10.1253	. . RADOME, side, "I" band, horn aerial, port, assembly	1	L44	15/18
R EG7.10.1254	. . RADOME, side, "I" band, horn aerial, starboard, assembly	1	L44	15/19
AS1248/3C	Attaching parts for EG7.10.1253 and EG7.10.1254:	27	—	15/11
AS1248/3E	. . Bolt, 2BA mushroom head	3	—	15/5
R EG7.10.1255	. . RADOME, forward, "E/F" and "A" band, assembly	1	L44	15/13
AS1248/3E	Attaching parts for EG7.10.1255:	31	—	15/17
10AC/0830053	. . RING, sealing, aerials to waveguides	8	—	15/35
R EG7.82.2603	. . SHIM, for "A" band, horn aerial angle adjustment, 5/16" x .002 lam. (Pre Mod 5466)	14	LA3	15/23
MARCONI				
R60-1757-01	. . WINDOW, pressure	2	—	15/24
EG7.82.1915	. CABLE, ASSEMBLY, NR.37, FROM ARI.18207 CONTROL UNIT TO A.E. OPERATOR'S DIMMER CONTROL PANEL T/B, GROUP	1	—	
	Consisting of:			
5E/9467424	. . CABLE, uninyvin 20	QR	—	
508/1/07776/001	. . CLAMP, cable	1	—	
508/2/07705/300	. . GASKET, outlet	1	—	
508/2/07719/300	. . GASKET, union	1	—	
508/2/07639/001	. . OUTLET, straight	1	—	
508/2/07708/300	. . RING, sealing	1	—	
508/2/07752/007	. . RING, thrust	1	—	
EEAS146/12	. . SLEEVE, 1/2" long (Pre SAS4745)	QR	—	
EEAS146/12/1/2	. . SLEEVE, 1/2" long (SAS4745)	QR	—	
EEAS146/12	. . SLEEVE, 1" long (Pre SAS4745)	QR	—	
EEAS146/12/1	. . SLEEVE, 1" long (SAS4745)	QR	—	
EEAS146/20/0.25	. . SLEEVE, 1/4" long (SAS4745)	QR	—	
EEAS146/20	. . SLEEVE, 3/4" long (Pre SAS4745)	QR	—	
EEAS146/20/1/2	. . SLEEVE, 3/4" long (SAS4745)	QR	—	
EEAS146/6/1/2	. . SLEEVE, 1/2" long (SAS4745)	QR	—	
EEAS146/6/1	. . SLEEVE, 1" long (SAS4745)	QR	—	
HT30	. . SLEEVE, Helsyn 150 white (SAS4745)	QR	—	
508/1/07001/220	. . SOCKET, free, Mk.7	1	—	
HC490	. . TAG, quick release (Pre SAS4745)	2	—	
HC490	. . TAG, QR (SAS4745)	6	—	
SCSHQ126662A2	. CABLE, assembly (SRIM3932) (Mod.5176)	1	—	
SCSHQ126663A2	. CABLE, assembly (SRIM3932) (Mod.5176)	1	—	
SCSHQ126664A2	. CABLE, assembly (SRIM3932) (Mod.5176)	1	—	
SCSHQ126668A2	. CABLE, assembly (SRIM3932) (Mod.5176)	1	—	
SCSHQ127607A1	. CABLE, assembly (SRIM3932) (Mod.5176)	1	—	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	. CABLE, CO-AXIAL IN FRONT FUSELAGE, INSTALLATION (EG7.82.2005) Spares for:-	-	-	
EG7.82.2133	. . BRACKET, CO-AXIAL CABLE SUPPORT FORWARD OF FRAME 1, ASSEMBLY Spares for:-	1	-	16/24
A25/1C	. . . BOLT, 2 BA hex. head	4	-	16/25
A25/15C	. . . BOLT, 2 BA hex. head	3	-	16/22
EG7.82.2423	. . . CHANNEL, assembly	1	L72	16/17
EG7.82.2425	. . . CLAMP, assembly	1	Tufnol	16/19
AS2306/138	. . . TUBE, distance	3	-	16/23
SP13/C	. . . WASHER, 2 BA plain	7	-	16/21
EG7.82.2175	. . BRACKET, CO-AXIAL CABLE SUPPORT, FRAME 12, ASSEMBLY Spares for:-	1	-	16/16
EG7.82.2177	. . . BRACKET, support	1	L72	16/18
EG7.82.2179	. . . CLAMP Attaching parts for EG7.82.2179:-	1	Tufnol	16/20
A25/16C	. . . Bolt, 2 BA hex. head	2	-	16/13
SP15/C	. . . Washer, 2 BA plain	2	-	16/12
EG7.82.2525	. . . LINER (Make from 32C/432 or 158)	2	-	16/15
AS2306/158	. . . TUBE, distance	2	-	16/14
X156DG002021	. . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	
X156DG002026	. . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	
R60-1882-01	. . CABLE, assembly, rigid co-axial, "E/F" band	1	-	
X156DG002020	. . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	
X156DG002022	. . CABLE, assembly, flexible co-axial (Mod 5445)	1	-	
R60-1885-01	. . CABLE, assembly, rigid co-axial "E/F" band	1	-	
R60-1887-01	. . CABLE, assembly, rigid co-axial "D" band	1	-	
R60-1889-01	. . CABLE, assembly, rigid co-axial "A" band	1	-	
EG7.82.2179	. . CLAMP, frame 11 Attaching parts for EG7.82.2179:-	1	Tufnol	16/5
A25/19C	. . Bolt, 2 BA hex. head	2	-	16/6
EG7.82.2251	. . Packing	1	Tufnol	16/1
AS2306/158	. . Tube, distance	2	-	16/3
SP15/C	. . Washer, 2 BA plain	2	-	16/7

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1	2	3	4	5
—	. . . CLIP, FLEXIBLE, CO-AXIAL CABLE, FRAMES "D" AND "E", INSTALLATION (EG7.82.2605) Spares for:—	—	—	16/10
EG7.82.2607	. . . BRACKET	1	L72	16/4
AS3180/6B	. . . CLIP, "P" Attaching parts for AS3180/6B:—	1	—	16/11
A25/2B	. . . Bolt, 4 BA hex. head	1	—	16/9
SP15/B	. . . Washer, 4 BA plain	1	—	16/8
EG7.82.2609	. . . PACKING	1	L72	16/2
—	. . . DUCTS, WAVEGUIDE AND FAIRING, INSTALLATION (EG7.82.2643) (Pre Mod 5466)	—	—	17/20
—	. . . DUCTS, WAVEGUIDE AND FAIRING, INSTALLATION (EG7.82.5003) (Mod 5466) Spares for:—	—	—	
EG7.82.1191	. . . BOLT, special, 2 BA, waveguide clips securing	90	S95	17/5
EG7.82.1211	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.1211:—	1	L72	19/14
A25/3C	. . . Bolt, 2 BA hex. head	4	—	19/13
SP15/C	. . . Washer, 2 BA plain	4	—	19/6
EG7.82.1213	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.1213:—	1	L72	19/18
A25/3C	. . . Bolt, 2 BA hex. head	4	—	19/23
SP15/C	. . . Washer, 2 BA plain	4	—	19/20
EG7.82.1215	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.1215:—	1	L72	19/19
A25/3C	. . . Bolt, 2 BA hex. head	4	—	19/22
SP15/C	. . . Washer, 2 BA plain	4	—	19/21
EG7.82.1217	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.1217:—	1	L72	18/23
A25/3C	. . . Bolt, 2 BA hex. head	4	—	18/29
SP15/C	. . . Washer, 2 BA plain	4	—	18/28
EG7.82.2201	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.2201:—	1	L72	17/26
A25/3C	. . . Bolt, 2 BA hex. head	4	—	17/31
SP15/C	. . . Washer, 2 BA plain	4	—	17/27
EG7.82.2651	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.2651:—	5	L72	17/8
A25/3C	. . . Bolt, 2 BA hex. head	4	—	17/17
SP15/C	. . . Washer, 2 BA plain	4	—	17/12
EG7.82.2653	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.2653:—	1	L72	17/30
A25/3C	. . . Bolt, 2 BA hex. head	4	—	17/35
SP15/C	. . . Washer, 2 BA plain	4	—	17/34
EG7.82.2655	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.2655:—	1	L72	19/16
A25/3C	. . . Bolt, 2 BA hex. head	4	—	19/17
SP15/C	. . . Washer, 2 BA plain	4	—	19/15

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG7.82.2657	. . . BRACKET, waveguide duct, assembly Attaching parts for EG7.82.2657:-	7	L72	18/6
A25/3C	. . . Bolt, 2 BA hex. head	4	-	18/11
SP15/C	. . . Washer, 2 BA plain	4	-	18/10
EG7.82.1329	. . . CLIP, WAVEGUIDE, ASSEMBLY Consisting of:-	12	-	17/14
EG7.82.1331	 CLIP	1	L72	17/13
AGS2001/C/1	 NUT, stiff, 2 BA	4	-	17/3
EG7.82.1337	 PLATE, base	1	L72	17/15
EG7.82.2367	 PLATE, bolt, bearing, 2 BA	2	S510	17/7
EG7.82.2399	 SHIM, laminated, 1/32" thick x .002 lam.	2	Lam.Alum.	17/4
SP15/C	 WASHER, 2 BA plain	4	-	17/6
EG7.82.1345	. . . CLIP, WAVEGUIDE, ASSEMBLY Consisting of:-	15	-	17/25
EG7.82.1341	 CLIP	1	L72	17/24
AGS2001/C/2	 NUT, stiff, 2 BA	4	-	17/23
EG7.82.1343	 PLATE, base	1	L72	17/21
EG7.82.2367	 PLATE, bolt, bearing, 2 BA	2	S510	17/16
EG7.82.2399	 SHIM, 1/32" thick x .002 lam.	2	Lam.Alum.	17/18
SP15/C	 WASHER, 2 BA plain	4	-	17/22
EG7.82.1529	. . . CLIP, WAVEGUIDE, ASSEMBLY Consisting of:-	8	-	18/22
EG7.82.2527	 CLIP	1	L72	18/21
AGS2001/C/1	 NUT, stiff, 2 BA	4	-	18/20
EG7.82.1343	 PLATE, base	1	L72	18/18
EG7.82.2367	 PLATE, bolt, bearing, 2 BA	2	S510	18/16
EG7.82.2399	 SHIM, 1/32" thick x .002 lam.	2	Lam.Alum.	18/17
SP15/C	 WASHER, 2 BA plain	4	-	18/19
EG7.82.2187	. . . CLIP, WAVEGUIDE, ASSEMBLY Consisting of:-	2	-	17/38
EG7.82.2189	 CLIP, half	1	L72	17/39
EG7.82.2191	 CLIP, half	1	L72	17/36
AGS2002/C/1	 NUT, stiff, 2 BA	4	-	17/33
EG7.82.2367	 PLATE, bolt, bearing, 2 BA	1	S510	17/28
EG7.82.2369	 PLATE, bolt, bearing, 2 BA	1	S510	17/37
EG7.82.2399	 SHIM, 1/32" thick x .002 lam.	2	Lam.Alum.	17/29
SP15/C	 WASHER, 2 BA plain	4	-	17/32
EG7.82.2667	. . . CLIP, WAVEGUIDE, ASSEMBLY Consisting of:-	8	-	18/4
EG7.82.2527	 CLIP	1	L72	18/3

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AGS2001/C/1	 NUT, stiff, 2 BA	4	—	18/7
EG7.82.1343	 PLATE, base	1	L72	18/2
EG7.82.2367	 PLATE, bolt, bearing, 2 BA	1	S510	18/5
EG7.82.2669	 PLATE, bolt, bearing, 2 BA	1	S510	18/9
EG7.82.2399	 SHIM, 1/32" thick x .002 lam.	2	Lam. Alum.	18/1
SP15/C	 WASHER, 2 BA plain	4	—	18/8
EG7.82.2533	 CLIP, bonding, waveguides	8	L60	17/19
	Attaching parts for EG7.82.2533:—			
A25/2C	. . . Bolt, 2 BA hex. head	1	—	17/10
AGS2001/C/1	. . . Nut, stiff, 2 BA	1	—	17/2
SP15/C	. . . Washer, 2 BA plain	2	—	17/9
EG7.82.2627	. . . DUCT, waveguide, port, assembly	1	L72	18/12
	Attaching parts for EG7.82.2627:—			
AS1248/3C	. . . Bolt, 2 BA mushroom head	15	—	18/13
SP15/C	. . . Washer, 2 BA plain	2	—	18/14
SP16/C	. . . Washer, 2 BA plain	2	—	18/15
EG7.82.2629	. . . DUCT, waveguide, starboard, assembly	1	L72	18/24
	Attaching parts for EG7.82.2629:—			
AS1248/3C	. . . Bolt, 2 BA mushroom head	17	—	18/25
SP15/C	. . . Washer, 2 BA plain	2	—	18/26
or				
SP16/C	. . . Washer, 2 BA plain	2	—	18/27
R EG7.10.1533	. . . FAIRING, lower "I" band cluster aerial, assembly	1	L44	19/7
	Attaching parts for EG7.10.1533:—			
A25/1C	. . . Bolt, 2 BA hex. head	3	—	19/8
AS1248/1/2C	. . . Bolt, 2 BA mushroom head	5	—	19/9
AS1248/3C	. . . Bolt, 2 BA mushroom head	14	—	19/10
AGS2001/C/1	. . . Nut, stiff, 2 BA	3	—	19/11
SP15/C	. . . Washer, 2 BA plain	3	—	19/12
EG7.10.1537	. . . PANEL, access, assembly (Pre Mod 5466)	1	L44	19/1
	Attaching parts for EG7.10.1537:—			
AS1248/2C	. . . Bolt, 2 BA mushroom head (Pre Mod 5466)	10	—	19/2
R EG7.10.1555	. . . SEAL, lower "I" band aerial aperture (Pre Mod 5466)	1	Neoprene	19/3
	Attaching parts for EG7.10.1555:—			
AS1242/2B	. . . Bolt, 4 BA c'sk head (Pre Mod 5466)	8	—	19/4
EG7.10.1553	. . . Plate, clamp (Pre Mod 5466)	1	L72	19/5
†	. . . RUBBER, "sorbo" waveguides at clips, 2.20" x 3.25" x 1/8" thick	14	—	17/11
EEAS21A/4GR AMPHENOL 57125	. . . WASHER, "D", for bonding clips	16	L72	17/1
EG7.82.1095	. . . PLUG, L.T. (ARI.23167) (Marconi R30-9281)	1	—	
EG7.82.1097	. . . CONNECTOR, assembly, NK.1, from ARI.23165 control unit to pressure bulkhead	1	—	
EG7.82.1099	. . . CONNECTOR, assembly, NK.2, from ARI.18207 aft control unit to pressure bulkhead	1	—	
EG7.82.1101	. . . CONNECTOR, assembly, NR.3, from control modulator to pressure bulkhead	1	—	
	. . . CONNECTOR, assembly, NR.4, from ARI.23166 control unit to pressure bulkhead	1	—	

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	EG7.82.1103	. CONNECTOR, assembly, NR.5, from ARI.23166 port control unit to pressure bulkhead	1	—	
R	EG7.82.1105	. CONNECTOR, assembly, NR.6, from ARI.23166 starboard control unit to pressure bulkhead	1	—	
R	EG7.82.1107	. CONNECTOR, assembly, NR.7, from ARI.23165 forward control unit to pressure bulkhead	1	—	
R	EG7.82.1109	. CONNECTOR, assembly, NR.8, from control modulator to pressure bulkhead	1	—	
R	EG7.82.1111	. CONNECTOR, assembly, NR.9, from ARI.18207 control unit to pressure bulkhead	1	—	
R	EG7.82.1113	. CONNECTOR, assembly, NR.10, from ARI.23167 control unit to pressure bulkhead	1	—	
	—	. WAVEGUIDES IN NOSE, INSTALLATION (EG7.82.2577) Spares for:	1	—	21/14
	152323-1	. . ADAPTOR, test, transmitter	1	—	20/21
	152323-2	. . ADAPTOR, test, transmitter	1	—	20/16
	A25/4C	. . Bolt, 2BA hex. head	4	—	20/17
	AGS2001/C/1	. . Nut, stiff, 2BA	4	—	20/18
	EG7.82.2719	. . Shim	4	LA3	20/19
	SP15/C	. . Washer, 2BA plain	4	—	20/20
	WARD BROOKE WB/UN/1146/S/3W	. . BLOCK, terminal, 3-way	1	—	21/1
R	WARD BROOKE WB/UN/1146/S/5W	. . BLOCK, terminal, 5-way	1	—	21/36
R	MARCONI R60-1761-52	. . BOLT, 8 UNC, waveguide flange attachment	56	—	20/13
R	MARCONI R60-1761-53	. . BOLT, 8 UNC, waveguide flange attachment	56	—	20/9
	EG7.10.965	. . BRACKET, waveguide support, assembly	2	L72	20/11
	EG7.82.2243	. . BRACKET, support, assembly	1	L72	20/14
	A25/1C	. . Bolt, 2BA hex. head	4	—	20/24
	SP15/C	. . Washer, 2BA plain	4	—	20/25
	EG7.82.1391	. . CLIP, waveguide	2	L72	20/26
	A25/1C	. . Bolt, 2BA hex. head	2	—	20/22
	EG7.82.471	. . Shim, laminated	2	LA3	20/27
	SP15/C	. . Washer, 2BA plain	2	—	20/23
	EG7.82.2015	. . CLIP, double, waveguide	2	L72	20/1
	A25/1C	. . Bolt, 2BA hex. head	3	—	20/3
	SP15/C	. . Washer, 2BA plain	3	—	20/5

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG7.82.2533	. . CLIP, bonding Attaching parts for EG7.82.2533:	2	L59	20/2
A25/2C	. . Bolt, 2BA hex. head	1	—	20/6
AGS2001/C/1	. . Nut, stiff, 2BA	1	—	20/4
SP15/C	. . Washer, 2BA plain	2	—	20/8
WARD BROOKE WB/NY/1110/B3	. . COVER, terminal block	1	—	21/5
WARD BROOKE WB/NY/1110/B4	. . COVER, terminal block	1	—	21/35
EG7.82.2691	. . LABEL, engraved, "N.454"	1	L72	21/3
EG7.82.2693	. . LABEL, engraved, "N.455"	1	L72	21/4
EG7.82.2695	. . LABEL, engraved, "F.504B"	1	L72	21/7
EG7.82.2697	. . LABEL, engraved, "F.504A"	1	L72	21/6
R 28M/9523249	. . NUT, 8 UNC, waveguide flange bolt attaching	56	—	20/10
WARD BROOKE WB/1114/28	. . PILLAR, fixing	4	—	21/8
EEAS550/3	. . PLATE, terminal ident	1	L73	21/2
EEAS550/5	. . PLATE, terminal ident	1	L73	21/30
MARCONI MS90064-13	. . RING, rubber sealing	13	—	20/15
MARCONI PF45452/24	. . RING, rubber sealing	42	—	20/12
†	. . RUBBER, "sorbo", waveguide at clipping, 1" x 3".25 x 1/8" thick	9	—	20/7
R MARCONI R30-9084-50	. . SWITCH Attaching parts for R30-9084-50:	4	—	21/22
A204/C20	. . Screw, 8 UNC c'sk head	3	—	21/23
EG7.82.2821	. . Shim, laminated	1	LA3	21/24
MARCONI R60-7037-01	. . WAVEGUIDE, rigid, assembly, forward of frame 'A'	1	—	21/10
MARCONI R60-1705-01	. . WAVEGUIDE, rigid, assembly, forward of frame 'A'	1	—	21/34
MARCONI R60-1706-01	. . WAVEGUIDE, rigid, assembly, forward of frame 'A'	1	—	21/32
MARCONI R60-1707	. . WAVEGUIDE, rigid, assembly, frame 1 to frame 9	2	—	21/21
MARCONI R60-1708	. . WAVEGUIDE, flexible, assembly, forward of frame 10	2	—	21/26
MARCONI R60-1709	. . WAVEGUIDE, rigid, assembly, between frames 9 and 10	1	—	21/19
MARCONI R60-1710	. . WAVEGUIDE, rigid, assembly, between frames 9 and 10	1	—	21/18

ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
10B/9537600	MARCONI R.60-1711-01							WAVEGUIDE, rigid, assembly, frame 10 to frame 12 . .	1	—	C	21/13
10B/9537601	MARCONI R.60-1711-02							WAVEGUIDE, rigid, assembly, frame 10 to frame 12 . .	1	—	C	21/17
10B/9537602	MARCONI R.60-1712							WAVEGUIDE, rigid, assembly, frame 12 to 13	1	—	C	21/15
10B/9537603	MARCONI R.60-1713							WAVEGUIDE, rigid, assembly, frame 12 to 13	1	—	C	21/9
10B/9548592	MARCONI R.60-1896-01							WAVEGUIDE, rigid, assembly, between switch and . . . test adaptor, forward of frame "A"	1	—	C	21/16
10B/9548594	MARCONI R.60-1898-01							WAVEGUIDE, rigid, assembly, between switches forward of frame "A"	1	—	C	21/27
10B/9548593	MARCONI R.60-1897-01							WAVEGUIDE, rigid, assembly, between switch and . . . test adaptor, forward of frame "A"	1	—	C	21/29
10B/9548595	MARCONI R.60-1898-02							WAVEGUIDE, rigid, assembly, between switches forward of frame "A"	1	—	C	21/20
10B/9548590	MARCONI R.60-1719-55							WAVEGUIDE, flexible, assembly, starboard aerial	1	—	C	21/33
10B/9548588	MARCONI R.60-1719-53							WAVEGUIDE, flexible, assembly, upper and lower . . . aerials	2	—	C	21/28
R 10B/9548589	MARCONI R.60-1719-54							WAVEGUIDE, flexible, assembly, port aerial	1	—	C	21/11
10B/9548596	MARCONI R.60-7036-01							WAVEGUIDE, rigid, assembly, from switch to flexible waveguide, starboard	1	—	C	21/25
10B/9548597	MARCONI R.60-7038-01							WAVEGUIDE, rigid, assembly, lower aerial	1	—	C	21/31
10B/9548591	MARCONI R.60-1714-01							WAVEGUIDE, rigid, assembly, from switch to flexible waveguide, port	1	—	C	21/12

[illegible]

A.P.101B-0417-3A

Page MC1

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	ELECTRONIC EQUIPMENT IN REAR FUSELAGE, ASSEMBLY (EG7.82.1519) Spares for:-	-	-	22/5
-	. AERIALS, REAR LOOKING, INSTALLATION (EG7.82.2595) Spares for:-	-	-	22/20
MARCONI R60-1539-02 MARCONI R60-1947-06	. . AERIAL, assembly, "HORN" (ARI.23165)	2	-	22/34
	. . AERIAL, RAYTHEON (ARI.23165) Attaching parts for R60-1947-06:-	1	-	22/30
A174/4C	. . Bolt, 1/4" UNC c'sk head	12	-	22/35
MARCONI R60-7040-50	. . BOLT, special, waveguides and "HORN" aerial securing, at cleats	8	-	22/32
MARCONI R60-1761-52 EG7.82.2549	. . BOLT, 8 UNC, waveguides connecting	8	-	22/24
	. . CLEAT, tee, waveguide and "horn" aerial support, starboard	1	L65	22/21
EG7.82.2550	. . CLEAT, tee waveguide and "horn" aerial support, port Attaching parts for EG7.82.2549 and 2550:-	1	L65	22/26
A25/20C AGS2001/C/1 SP15/C	. . Bolt, 2 BA hex. head	4	-	22/25
	. . Nut, stiff, 2 BA	4	-	22/22
	. . Washer, 2 BA plain	4	-	22/23
R PPZ086-14-5	. . NUT, 8 UNC for waveguide bolts	16	-	22/31
MS90064-13	. . RING, sealing	2	-	22/28
MARCONI	. . RING, sealing	6	-	22/27
MARCONI	. . SHIM,	2	-	22/29
MARCONI R60-1757-01	. . WINDOW, pressure	2	-	22/33
R SCSHQ126667A2	. CABLE, assembly (SRIM 3932) (Mod 5176) (Pre Mod 5466)	1	-	
R SCSHQ126670A2	. CABLE, assembly (SRIM 3932) (Mod 5176) (Pre Mod 5466)	1	-	
R SCSHQ126671A2	. CABLE, assembly (SRIM 3932) (Mod 5176) (Pre Mod 5466)	1	-	
R -	. WAVEGUIDE, FROM AFT END OF BOMB BAY TO TAIL CONE, ASSEMBLY (EG7.82.669) (Pre Mod 5466)	-	-	22/6
R -	. WAVEGUIDES, FROM AFT END OF BOMB BAY TO TAIL CONE, ASSEMBLY (EG7.82.5695) (Mod 5466) Spares for:-	-	-	
-	. . ALTERATIONS TO FRAME 45, ASSEMBLY (EG7.12.185) Spares for:-	-	-	22/3
EG7.82.457	. . . CLIP, waveguide Attaching parts for EG7.82.457:-	1	L72	22/9
A25/1C SP13/C	. . . BOLT, 2 BA hex. head	2	-	22/4
	. . . Washer, 2 BA plain	2	-	22/8

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
MARCONI R60-1761-52	. . . BOLT, 8 UNC, waveguide flange attachments	18	—	22/15
MARCONI R60-1761-54	. . . BOLT, 8 UNC, waveguide attachments	8	—	22/17
MARCONI R60-1761-53	. . . BOLT, 8 UNC, waveguide flange attachment	80	—	22/18
—	. . . BRACKET, WAVEGUIDE MOUNTING FRAME 30, ASSEMBLY (EG7.82.1321) Spares for:—	—	—	22/7
EG7.82.1389	. . . CLIP Attaching parts for EG7.82.1389:—	1	L72	22/19
A25/1C	. . . Bolt, 2 BA hex. head	2	—	22/14
EG7.82.1391	. . . CLIP Attaching parts for EG7.82.1391:—	1	L72	22/1
A25/1C	. . . Bolt, 2 BA hex. head	2	—	22/2
—	. . . BRACKET, SWITCH MOUNTING, FRAME 48, ASSEMBLY (EG7.82.1699) Spares for:—	—	—	23/19
WARD BROOKE WB/UN/1146/S/3W	. . . BLOCK, terminal	1	—	23/3
EG7.82.1469	. . . BRACKET, SWITCH MOUNTING, ASSEMBLY Consisting of:—	2	—	23/18
A25/21C	 BOLT, 2 BA hex. head	3	—	23/20
EG7.82.1471	 BRACKET, switch, assembly	1	—	23/9
EG7.82.1477	 BRACKET, switch, assembly	1	—	23/16
AGS2001/C/1	 NUT, stiff, 2 BA	3	—	23/10
EG7.82.1479	 STEADY, switch	1	Tufnol	23/13
AS2809/4/182	 TUBE, distance	3	L62	23/12
SP15/C	 WASHER, 2 BA plain	3	—	23/11
—	Attaching parts for EG7.82.1469:—			
A25/1C	. . . Bolt, 2 BA hex. head	4	—	23/14
SP13/C	. . . Washer, 2 BA plain	4	—	23/15
EG7.82.1693	. . . BRACKET, CHANNEL, ASSEMBLY Spares for:—	2	L72	23/17
EG7.82.2241	 ANGLE, attachment	1	L72	23/6
EG7.82.2242	 ANGLE, attachment	1	L72	23/5
—	Attaching parts for EG7.82.1693:—			
A25/1C	. . . Bolt, 2 BA hex. head	3	—	23/2
AGS2001/C/1	. . . Nut, stiff, 2 BA	3	—	23/8
SP13/C	. . . Washer, 2 BA plain	3	—	23/7

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R WARD BROOKE WB/NY/1110/B/3 WARD BROOKE WB/1114/28 —	. . . COVER, terminal block . . . PILLAR, fixing . . . BRACKET, WAVEGUIDE MOUNTING, INSTALLATION (EG7.82.1845) Spares for: . . . BRACKET, mounting, assembly Spares for: . . . CLIP Attaching parts for EG7.82.1389: . . . Bolt, 2BA hex. head . . . Washer, 2BA plain	1 2 —	— — —	23/1 23/4 23/25
EG7.82.1847	. . . BRACKET, mounting, assembly Spares for: . . . CLIP	1 1	L72 L72	23/38 23/32
EG7.82.1389	Attaching parts for EG7.82.1389: . . . Bolt, 2BA hex. head . . . Washer, 2BA plain	2 2	— —	23/29 23/27
A25/1C SP13/C	. . . CLIP Attaching parts for EG7.82.1391: . . . Bolt, 2BA hex. head . . . Washer, 2BA plain	1 2 2	L72 — —	23/34 23/35 23/36
EG7.82.1391	. . . CLIP Attaching parts for EG7.82.1391: . . . Bolt, 2BA hex. head . . . Washer, 2BA plain	1 2 2	L72 — —	23/34 23/35 23/36
A25/1C SP13/C	. . . CLIP Attaching parts for EG7.82.1391: . . . Bolt, 2BA hex. head . . . Washer, 2BA plain	1 2 2	L72 — —	23/34 23/35 23/36
EG7.82.1849	. . . DIAPHRAGM	1	L72	23/33
EG7.82.1851	. . . PLATE, top	1	L72	23/30
EG7.82.1853	. . . PLATE, bottom	1	L72	23/40
EG7.82.1861	. . . PLATE, radius	2	L72	23/31
EG7.82.1863	. . . PLATE, radius	2	L72	23/39
EG7.82.1865	. . . PLATE, radius	2	L72	23/21
EG7.82.1867	. . . PLATE, radius	2	L72	23/26
EG7.82.1857	. . . TOP-HAT	1	L72	23/28
EG7.82.1859	. . . TOP-HAT Attaching parts for EG7.82.1847: . . . Bolt, 2BA hex. head . . . Nut, stiff, 2BA . . . Washer, 2BA plain	1 8 8 8	L72 — — —	23/37 23/22 23/23 23/24
A25/2C AGS2001/C/1 SP13/C	. . . CLIP, bonding, waveguides Attaching parts for EG7.82.2533: . . . Bolt, 2BA hex. head . . . Nut, stiff, 2BA . . . Washer, 2BA plain	14 1 1 2	L59 — — —	24/1 24/4 24/5 24/2
EG7.82.2533	. . . CLIP, bonding, waveguides Attaching parts for EG7.82.2533: . . . Bolt, 2BA hex. head . . . Nut, stiff, 2BA . . . Washer, 2BA plain	14 1 1 2	L59 — — —	24/1 24/4 24/5 24/2
A25/2C AGS2001/C/1 SP15/C	. . . CLIP, waveguide, frame 47, port Attaching parts for EG7.82.1141: . . . Bolt, 2BA hex. head . . . Bolt, 2BA round head	1 2 2	L72 — —	25/3 25/1 25/2
EG7.82.1141	. . . CLIP, waveguide, frame 47, port Attaching parts for EG7.82.1141: . . . Bolt, 2BA hex. head . . . Bolt, 2BA round head	1 2 2	L72 — —	25/3 25/1 25/2
A25/2C AS1246/1C	. . . CLIP, waveguide, frame 47, port Attaching parts for EG7.82.1141: . . . Bolt, 2BA hex. head . . . Bolt, 2BA round head	1 2 2	L72 — —	25/3 25/1 25/2
R 10AC/9839055	. . . NUT, 8 UNC, waveguide flange bolt attachments	80	—	22/16
R EG7.82.1533	. . . PLATE, clip support, frame 47, assembly	1	L72	25/9
R 10AS/0830053	. . . RING, sealing, waveguide flanges	52	—	24/9

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
†	.	RUBBER, "sorbo", at waveguide clips, 1" x 3".25 x 1/8" thick	6	—	25/28
†	.	RUBBER, "sorbo", at waveguide clips, 2".3 x 3".25 x 1/8" thick	2	—	25/8
†	.	RUBBER, "sorbo", at waveguide clips, 2".7 x 3".25 x 1/8" thick	12	—	25/27
MARCONI	.	SPACER, waveguides at switches	2	—	22/13
R60-1760-01	.	STRUCTURE, WAVEGUIDE SUPPORT, FRAME 34, PORT, ASSEMBLY (EG7.82.1183)	—	—	25/24
—	.	Spares for:			
EG7.82.1165	.	SUPPORT, WAVEGUIDE, ASSEMBLY	1	—	25/13
EG7.82.1149	.	Consisting of:			
AGS2002/C/1	.	CLIP	1	L72	25/18
EG7.82.2401	.	NUT, stiff, 2BA	4	—	25/23
EG7.82.2371	.	SHIM, laminated	2	Lam. Alum.	25/35
EG7.82.1147	.	STRIP, bolt, 2BA assembly	2	S510	25/36
SP15/C	.	SUPPORT, clip, assembly	1	L72	25/31
EG7.82.1191	.	WASHER, 2BA plain	4	—	25/25
—	.	Attaching parts for EG7.82.1165:			
EG7.82.1191	.	Bolt, special, 2BA	2	S96	25/20
—	.	STRUCTURE, WAVEGUIDE SUPPORT, FRAME 36, PORT, ASSEMBLY (EG7.82.1185)	—	—	25/22
EG7.82.1165	.	Spares for:			
EG7.82.1149	.	SUPPORT, WAVEGUIDE, ASSEMBLY	1	—	25/12
AGS2002/C/1	.	Consisting of:			
EG7.82.2401	.	CLIP	1	L72	25/18
EG7.82.2371	.	NUT, stiff, 2BA	4	—	25/23
EG7.82.1147	.	SHIM, laminated	2	Lam. Alum.	25/35
SP15/C	.	STRIP, bolt, 2BA, assembly	2	S510	25/36
EG7.82.1191	.	SUPPORT, clip, assembly	1	L72	25/31
—	.	WASHER, 2BA plain	4	—	25/25
EG7.82.1191	.	Attaching parts for EG7.82.1165:			
EG7.82.1191	.	Bolt, special, 2BA	2	S96	25/20
—	.	STRUCTURE, WAVEGUIDE SUPPORT, FRAME 38, PORT, ASSEMBLY (EG7.82.1187)	—	—	25/19
EG7.82.1165	.	Spares for:			
EG7.82.1149	.	SUPPORT, WAVEGUIDE, ASSEMBLY	1	—	25/11
EG7.82.1149	.	Consisting of:			
EG7.82.1149	.	CLIP	1	L72	25/18

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description						No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5	6			
AGS2002/C/1	.	.	.	.	NUT, stiff, 2BA		4	—	25/23
EG7.82.2401	.	.	.	.	SHIM, laminated		2	Lam. Alum.	25/35
EG7.82.2371	.	.	.	.	STRIP, bolt, 2BA, assembly		2	S510	25/36
EG7.82.1147	.	.	.	.	SUPPORT, clip, assembly		1	L72	25/31
SP15/C	.	.	.	.	WASHER, 2BA plain		4	—	25/25
EG7.82.1191	.	.	.	.	Attaching parts for EG7.82.1165: Bolt, special, 2BA		2	S96	25/20
—	.	.	.	.	STRUCTURE, WAVEGUIDE SUPPORT, FRAME 40, PORT, ASSEMBLY (EG7.82.1189)		—	—	25/16
R EG7.82.1165	.	.	.	.	Spares for: SUPPORT, WAVEGUIDE, ASSEMBLY		1	—	25/10
EG7.82.1149	.	.	.	.	Consisting of: CLIP		1	L72	25/18
AGS2002/C/1	.	.	.	.	NUT, stiff, 2BA		4	—	25/23
EG7.82.2401	.	.	.	.	SHIM, laminated		2	Lam. Alum.	25/35
EG7.82.2371	.	.	.	.	STRIP, bolt, 2BA, assembly		2	S510	25/36
EG7.82.1147	.	.	.	.	SUPPORT, clip, assembly		1	L72	25/31
SP15/C	.	.	.	.	WASHER, 2BA plain		4	—	25/25
EG7.82.1191	.	.	.	.	Attaching parts for EG7.82.1165: Bolt, special, 2BA		2	S96	25/20
—	.	.	.	.	STRUCTURE, WAVEGUIDE SUPPORT, FRAME 31B TO FRAME 32, ASSEMBLY (EG7.82.2219)		—	—	25/21
A25/2C	.	.	.	.	Spares for: BOLT, 2BA hex. head		8	—	25/29
EG7.82.2561	.	.	.	.	DIAPHRAGM, forward, assembly		1	L72	25/6
EG7.82.2223	.	.	.	.	DIAPHRAGM, aft		1	L72	25/5
EG7.82.2225	.	.	.	.	MEMBER, top-hat, upper		1	L72	25/17
EG7.82.2227	.	.	.	.	MEMBER, top-hat, lower		1	L72	25/26
AGS2001/C/1	.	.	.	.	NUT, stiff, 2BA		8	—	25/34
EG7.82.2229	.	.	.	.	PLATE, top, assembly		1	L72	25/4
EG7.82.2233	.	.	.	.	PLATE, radius		2	L72	25/30
EG7.82.2235	.	.	.	.	PLATE, closing		1	L72	25/7
EG7.82.1165	.	.	.	.	SUPPORT, WAVEGUIDE, ASSEMBLY		1	—	25/15
EG7.82.1149	.	.	.	.	Consisting of: CLIP		1	L72	25/18
AGS2002/C/1	.	.	.	.	NUT, stiff, 2BA		4	—	25/23
EG7.82.2401	.	.	.	.	SHIM, laminated		2	Lam. Alum.	25/35
EG7.82.2371	.	.	.	.	STRIP, bolt, 2BA, assembly		2	S510	25/36
EG7.82.1147	.	.	.	.	SUPPORT, clip, assembly		1	L72	25/31

RADIO AND RADAR
ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
SP15/C	 WASHER, 2BA plain	4	—	25/25
EG7.82.1191	Attaching parts for EG7.82.1165: . . . Bolt, special, 2BA	2	S94	25/20
SP15/C	 WASHER, 2BA plain	4	—	25/33
SP16/C	 WASHER, 2BA plain	4	—	25/32
EG7.82.1165	. . . SUPPORT, WAVEGUIDE, FRAME 42, PORT, ASSEMBLY Consisting of:	1	—	25/14
EG7.82.1149	. . . CLIP	1	L72	25/18
AGS2002/C/1	. . . NUT, stiff, 2BA	4	—	25/23
EG7.82.2401	. . . SHIM, laminated	2	Lam. Alum.	25/35
EG7.82.2371	. . . STRIP, bolt, 2BA, assembly	2	S510	25/36
EG7.82.1147	. . . SUPPORT, clip, assembly	1	L72	25/31
SP15/C	. . . WASHER, 2BA plain	4	—	25/25
EG7.82.1191	Attaching parts for EG7.82.1165: . . Bolt, special, 2BA	2	S94	25/20
MARCONI 30-9084-50	. . SWITCH Attaching parts for R30-9084-50:	2	—	22/10
A102/3C	. . Bolt, 8 UNC, hex. head	3	—	22/11
SP55/C	. . Washer, 3/16" i/d, double spring	3	—	22/12
MARCONI R60-1715-55	. . WAVEGUIDE, twistguide, assembly, at port and starboard aerals	2	—	24/12
MARCONI R60-1601-02	. . WAVEGUIDE, twist, stepped, assembly, aft of frame 48	3	—	24/10
MARCONI R60-1738	. . WAVEGUIDE, rigid, assembly, frame 29 to 30 (Pre Mod 5466)	2	—	24/21
MARCONI R60-1739	. . WAVEGUIDE, rigid, assembly, frame 30 to 31	2	—	24/18
MARCONI R60-1740	. . WAVEGUIDE, flexible, assembly, frame 31	1	—	24/16
MARCONI R60-1741	. . WAVEGUIDE, flexible, assembly, frame 31	1	—	24/15
MARCONI R60-1742	. . WAVEGUIDE, rigid, assembly, frame 31 to 38	2	—	24/13
MARCONI R60-1743	. . WAVEGUIDE, rigid, assembly, frame 38 to 46	1	—	24/8
MARCONI R60-1744	. . WAVEGUIDE, rigid, assembly, frame 38 to 46	1	—	24/7
MARCONI R60-1745	. . WAVEGUIDE, rigid, assembly, frame 46 to 47	2	—	24/3
MARCONI R60-1746	. . WAVEGUIDE, rigid, assembly, frame 47A	2	—	24/6

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
MARCONI R60-1747	.	.	WAVEGUIDE, rigid, assembly, frame 47A to switch frame 48				1	—	24/11
MARCONI R60-1748	.	.	WAVEGUIDE, rigid, assembly, frame 47A to switch frame 48				1	—	24/14
MARCONI R60-1749	.	.	WAVEGUIDE, rigid, assembly, from switch, frame 48 to stepped waveguide, aft of frame 48				2	—	24/17
MARCONI R60-1715-57	.	.	WAVEGUIDE, twistaguide, assembly, aft aerial connecting				1	—	24/19
MARCONI R60-1715-56	.	.	WAVEGUIDE, twistaguide, assembly, aft aerial				1	—	24/20
R —	.	.	WAVEGUIDE MOUNTING BRACKET ASSEMBLY ALTERATIONS AT FRAME 30 (EG7.82.5913) (Mod 5466) Spares for:—				—	—	23A/1
R EG7.82.5869	.	.	ANGLE				1	—	23A/2
R EG7.82.5871	.	.	ANGLE				1	—	23A/3
R EG7.82.5867	.	.	BRACKET, mounting				1	—	23A/4
R EG7.82.5873	.	.	BRACKET, assembly				1	—	23A/5
R —	.	.	WAVEGUIDE MOUNTING BRACKET ALTERATIONS AT FRAME 30A — 31A (EG7.82.5901) (Mod 5466) Spares for:—				—	—	23A/6
R EG7.82.5903	.	.	ANGLE, assembly Spares for:—				1	—	23A/7
R EG7.82.5905	.	.	ANGLE				1	—	23A/8
R AGS2007/C/1	.	.	NUT, anchor				1	—	23A/9
R AGS2018/C/1	.	.	NUT, anchor				1	—	23A/10
R EG7.82.5907	.	.	ANGLE, assembly Spares for:—				1	—	23A/11
R EG7.82.5909	.	.	ANGLE				1	—	23A/12
R AGS2007/C/1	.	.	NUT, anchor				1	—	23A/13
R AGS2018/C/1	.	.	NUT, anchor				1	—	23A/14
R EG7.82.5915	.	.	DIAPHRAGM				1	—	23A/15
R EG7.82.5911	.	.	PACKER				1	—	23A/16

RADIO AND RADAR

ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

A.P.101B-0417-3A

RADIO AND RADAR

Page MD1

GREEN SATIN (ARI.5851)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R -	GREEN SATIN, ARI.5951, ASSEMBLY (EG7.82.3013) (Mod.5249) (Pre-Mod.5466) Spares for:-						-	-	26/37
R ED9/8001/ASSY C	.	AERIAL,	type	501A	(Mod.5249)		1	-	26/38
SIS6416	.	AMPLIFIER,	ground	position	indicator		1	-	26/46
10AR6196849	.	BACKPLATE,	trans/receiver				1	-	26/17
10AR6196850	.	BACKPLATE,	tracking	unit			1	-	26/23
10AR6196851	.	BACKPLATE,	electrical	indicator			1	-	26/31
6B6349756	.	BACKPLATE,	ground	position	indicator		1	-	26/33
R ED9/12118	.	COMPUTER,	DA - GS	(Mod.5249)			1	-	26/22
6B541	.	INDICATOR,	ground	position,	Mk.4		1	-	26/34
R ED9/12123	.	INDICATOR,	DA - GS	(Mod.5249)			1	-	26/32
TYPE 957	.	PLUG,	shorting,	type	957		1	-	26/19
TYPE TR3710	.	RECEIVER,	transmitter,	type	TR.3710		1	-	26/18
6B655	.	TRAY,	mounting,	amplifier			1	-	26/51

RADIO AND RADAR

GREEN SATIN (ARI.5851)

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R -	GREEN SATIN IN FRONT FUSELAGE	-	-	26/48
	ASSEMBLY (EG7.82.153) (Pre Mod 5466)			
	Spares for:-			
EG7.82.159	. CONNECTOR, L.P., from electrical indicator	1	-	26/39
EG7.82.161	. CONNECTOR, L.D., from ground position	1	-	26/50
EG7.82.167	. CONNECTOR, L.C., from electrical indicator	1	-	26/49
EG7.82.171	. CONNECTOR, L.U., from ground position	1	-	26/47
EG7.82.173	. CONNECTOR, L.T., from amplifier to	1	-	26/45
	ground position indicator			

A.P.101B-0417-3A

Page MD3

RADIO AND RADAR

GREEN SATIN (ARI.5851)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R —	GREEN SATIN IN CENTRE FUSELAGE, ASSEMBLY (EG7.82.155) (Pre Mod 5466)	—	—	26/35
R 10H/0540019	Spares for:	1	—	26/21
EG7.82.991	. ADAPTOR, socket to socket, buradep style ABR-4F	1	—	26/15
	. CABLE, ASSEMBLY, L.J., FROM TEST POINT CONNECTION AND PLUG BREAK TO T.R. TYPE 3710, GROUP			
	Consisting of:			
5E/0149558	. . CABLE, uniradio 70	QR	—	
5E/1934441	. . CABLE, minyvin 22	QR	—	
5E/9433957	. . CABLE, uniradio 96	QR	—	
508/1/07780/003	. . CLAMP, cable	1	—	
10H/9464003	. . COVER, angle	1	—	
508/2/07706/200	. . GASKET, outlet	1	—	
508/2/07724/200	. . GASKET, union	1	—	
10H/4699273	. . GROMMET (Pre SAS4745)	1	—	
508/2/07644/003	. . OUTLET, straight	1	—	
10H/4709596	. . PLUG, 12-way	1	—	
AMPHENOL				
31GB-226-4	. . PLUG, type UK-BNC	1	—	
508/2/07713/200	. . RING, sealing	1	—	
508/2/07758/007	. . RING, thrust	1	—	
EEAS146/EQ	. . SLEEVE, 1/2" long	QR	—	
RAYCHEM				
D123	. . SLEEVE, solder	C	—	
EEAS146/6	. . SLEEVE, 1" long	QR	—	
RAYCHEM	. . SLEEVE, S.C.L., 1/4" white	QR	—	
EEAS146/00	. . SLEEVE, 1" long	QR	—	
EEAS146/0	. . SLEEVE, 1 1/2" long	QR	—	
5F/	. . SLEEVING, P.V.C., 15 mm bore, 5 mm wall, black	QR	—	
508/1/40129/320	. . SOCKET, fixed, Mk.4	1	—	
10H/9002877	. CAP, blanking	1	—	26/20
EG7.82.1195	. CONNECTOR, L.A., from transmitter receiver type TR.3710 to tracking unit type 100	1	—	26/28
EG7.82.163	. CONNECTOR, L.D./1, from pressure bulkhead to tracking unit type 100	1	—	26/40
EG7.82.169	. CONNECTOR, L.C./1, from pressure bulkhead to tracking unit type 100	1	—	26/41
EG7.82.175	. CONNECTOR, L.M., from terminal block to transmitter receiver type TR.3710	1	—	26/26
EG7.82.177	. CONNECTOR, L.N./A., from terminal block to transmitter receiver type TR.3710	1	—	26/27

RADIO AND RADAR
GREEN SATIN (ARI.5851)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG7.82.1197	. CONNECTOR, L.G., from transmitter receiver type 3710 to tracking unit type 100	1	—	26/25
EG7.82.1205	. CONNECTOR, L.B./B., from tracking unit to bulkhead plug socket in fuselage, port wing	1	—	26/36
EG7.82.1203	. CONNECTOR, L.H., from transmitter receiver type TR.3710 to test point adaptor	1	—	26/16
508/1/40196/320	. PLUG, socket, bulkhead, 25-way, fuselage connection, port wing	1	—	26/42
—	. TRANSFORMER, 'GREEN SATIN' SUPPLY, INSTALLATION (EG7.82.821) (Pre Mod 5466) Consisting of:	—	—	26/30
WARD BROOKE WB/UN/1146/S/3W	. . BLOCK, connector Attaching parts for WB/UN/1146/S/3W:	1	—	26/12
A25/3B	. . Bolt, 4BA hex. head	2	—	26/2
SP13/B	. . Washer, 4BA plain	2	—	26/1
EG7.82.833	. . BRACKET, terminal block mounting Attaching parts for EG7.82.833:	1	—	26/3
A25/1C	. . Bolt, 2BA hex. head	2	—	26/4
AGS2001/C/1	. . Nut, stiff, 2BA	2	—	26/6
SP13/C	. . Washer, 2BA plain	2	—	26/5
EG7.81.1649	. . COVER, terminal block Attaching parts for EG7.81.1649:	1	—	26/19
A25/1/2B	. . Bolt, 4BA hex. head	2	—	26/24
—	. . MOUNTING, TRANSFORMER, ASSEMBLY (EG7.82.823) (Pre Mod 5466) Spares for:	—	—	26/8
EG7.82.829	. . . ANGLE, support	1	L72	26/13
EG7.82.825	. . . PLATE, mounting, assembly Attaching parts for EG7.82.825:	1	—	26/9
A25/1/2B	. . . Bolt, 4BA hex. head	7	—	26/10
AGS2001/B/1	. . . Nut, stiff, 4BA	7	—	26/11
EEAS550/3	. . PLATE, terminal ident, 3-way	1	L73	26/14
M.A.M.	. . SLEEVE, 3 mm i/d x 3/8" long, grade CXH, pink	3	—	—
E.E. CO., B'FORD Type A.E.5705	. . TRANSFORMER, 1 KVA, 3-phase, 200-116V Attaching parts for AE.5705:	1	—	26/7
A25/1C	. . Bolt, 2BA hex. head	4	—	26/29

A.P.101B-0417-3A

Page MD5

RADIO AND RADAR

GREEN SATIN (ARI.5851)

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R —	GREEN SATIN IN PORT WING	—	—	26/44
EG7.82.1207	ASSEMBLY (EG7.82.157) (Pre Mod 5466) Spares for:—			
	. CONNECTOR, L.B./B1, from plug socket in fuselage frame 22 to aerial system type 501 in port wing	1	—	26/43

A.P.101B-0417-3A

Page ME1

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	—	H.F. RADIO 681 T-3 (COLLINS), INSTALLATION (EG7.82.181) (Pre Mod 5466)	—	—	27/7
R	—	H.F. RADIO 681 T-3 (COLLINS) INSTALLATION (EG7.82.5221) (Mod 5466) Spares for:—	—	—	
R	10L 0198405	. CONTROL UNIT, type 714E/3/M53	1	—	27/1
R	110D 6043307	. RECEIVER/TRANSMITTER, type 681T/3/M15	1	—	27/10
R	110D 3338518	. TUNING UNIT, type 180/L3A	1	—	27/3

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

	Part Number	Description	No. Off	Mati. Spec.	Plate No.
		1 2 3 4 5 6			
R	—	H.F. RADIO IN FRONT FUSELAGE ASSEMBLY (EG7.82.183) (Pre Mod 5466)	—	—	27/2
R	—	H.F. RADIO IN FRONT FUSELAGE ASSEMBLY (EG7.82.5223) (Mod 5466) Spares for:—	—	—	
	UG27C/U	. ADAPTER, angle	2	—	27/12
	UG306A/U	. ADAPTER	1	—	27/4
	UG646/U	. ADAPTER	1	—	27/5
	—	. BOX, H.F. DISTRIBUTION, INSTALLATION (EG7.82.1685) Spares for:—	—	—	27/15
	EG7.82.577	. . BOX, H.F. DISTRIBUTION AND WIRING, ASSEMBLY Spares for:—	1	—	27/17
R	703-1-00249	. . . BLOCK, terminal, 20-way Attachments:—	1	—	27/25
	A43/B24	. . . Screw, 4 BA cheese head	2	—	27/33
	SP47/B	. . . Washer, 4 BA spring	2	—	27/32
	EG7.82.579	. . . BOX, distribution, sub-assembly	1	L59	27/23
R	TYPE B-19.006 RED	. . . CABLE, type B, 19.006, red	QR	—	
R	TYPE B-19.0076 BLUE	. . . CABLE, type B, 19.0076 blue	QR	—	
R	UNINYVIN 8	. . . CABLE, uninyvin 8	QR	—	
R	UNINYVIN 12	. . . CABLE, uninyvin 12	QR	—	
R	UNINYVIN 16	. . . CABLE, uninyvin 16	QR	—	
R	UNINYVIN 18	. . . CABLE, uninyvin 18	QR	—	
	↑	. . . CORD, braided nylon No. 3 1/32" dia.	QR	—	
	EG7.82.583	. . . COVER, H.F. DISTRIBUTION BOX ASSEMBLY Spares for:—	1	—	27/30
R	BOSTIK 771	 CEMENT, bostik 771	QR	—	27/26
R	32C4382997	 RUBBER, synthetic, .14 dia.	QR	DTD552	27/28
R	EEAS117/1	 SCREW, cover, 4 BA	6	S92	27/38
	EEAS28/2/CU	 WASHER	12	S515	27/37
	EEAS42	 WASHER, leather, .30" o/d x .156" i/d	6	—	27/36
R	30A9140209	 WIRE, locking, 20 SWG	QR	—	27/35
	508/2/04367	. . . FILLER, plug	19	—	
	508/2/04368	. . . FILLER, plug	9	—	
	508/2/06923	. . . FILLER, plug	2	—	
	508/2/06924	. . . FILLER, plug	4	—	
	2Z.138846	. . . INSERT, socket	7	—	
	2Z.138935	. . . INSERT, socket	6	—	
	2Z.138939	. . . INSERT, socket	2	—	
	2Z.139487	. . . INSERT, socket	1	—	

A.P.101B-0417-3A

Page ME3

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
508/1/04585/002	.	.	.	INSERT, socket			1	~	
508/1/05601/002	.	.	.	INSERT, socket			59	~	
508/1/05602/002	.	.	.	INSERT, socket			14	~	
5X4491423	.	.	.	LINK, commoning, 4-way			1	~	
703-1-00249	.	.	.	LINK, commoning, 2-way			1	~	
2Z.111033	.	.	.	PIN, plug			7	~	
508/2/05603/002	.	.	.	PIN, plug			39	~	
508/2/05604/002	.	.	.	PIN, plug			6	~	
UKAN									
8000/20/29P	.	.	.	PLUG, fixed			1	~	
UKAN									
8000/32/7P	.	.	.	PLUG, fixed			1	~	
EEAS146/8	.	.	.	SLEEVE, 3/4" long, pink			QR	~	
EEAS146/12	.	.	.	SLEEVE, 3/4" long, pink			QR	~	
EEAS146/EQ	.	.	.	SLEEVE, 3/4" long, pink			QR	~	
M.A.M.	.	.	.	SLEEVE, 3/8" long x 3 m/m i/d, grade CXH			20	~	
2Z.139622	.	.	.	SLEEVE, packing, pink			98	~	
2Z.139623	.	.	.	SLEEVE, packing, blue			2	~	
2Z.139626	.	.	.	SLEEVE, packing, white			1	~	
2Z.139628	.	.	.	SLEEVE, packing, black			5	~	
UKAN									
8000/16/1S	.	.	.	SOCKET, fixed			1	~	27/29
UKAN/16/1S/W	.	.	.	SOCKET, fixed			1	~	27/27
UKAN									
8000/16/1S/Z	.	.	.	SOCKET, fixed			1	~	27/16
UKAN									
8000/24/11S	.	.	.	SOCKET, fixed			1	~	27/18
UKAN									
8000/28/21S	.	.	.	SOCKET, fixed			1	~	27/31
UKAN									
8000/32/6S	.	.	.	SOCKET, fixed			1	~	27/34
HV3254	.	.	.	STRAP, nylon			QR	~	
HV3255	.	.	.	STUD, nylon			QR	~	
HC490	.	.	.	TAG, quick release			26	~	
HC500	.	.	.	TAG, quick release			1	~	
HC510	.	.	.	TAG, quick release			5	~	
2Z.139597	.	.	.	WASHER, panel packing			3	~	
2Z.139599	.	.	.	WASHER, panel packing			1	~	
2Z.139601	.	.	.	WASHER, panel packing			1	~	
2Z.139602	.	.	.	WASHER, panel packing			1	~	

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
2Z.139603	. . . WASHER, panel packing Attaching parts for EG7.82.577:-	2	—	
A25/1C	. . Bolt, 2 BA hex. head	4	—	27/21
SP15/C	. . Washer, 2 BA plain	4	—	27/19
EG7.82.2433	. CABLE, ASSEMBLY, HF.11, FROM NAVIGATOR'S COAMING PANEL TO TUNING LIGHT, PORT FIXED PANEL, GROUP Consisting of:-	1	—	
UNINYVIN 22	. . CABLE, uninyvin 22	QR	—	
EEAS146/22	. . SLEEVE, 3/4" long	QR	—	
EEAS146/12	. . SLEEVE, 1/2" long	QR	—	
EEAS146/12	. . SLEEVE, 1-1/2" long	QR	—	
HC296	. . TAG, ring tongue	2	—	
HC490	. . TAG, quick release	1	—	
—	. CONDUIT, H.F. CABLE, INSTALLATION (EG7.82.2329) Spares for:-	—	—	27/6
EG7.82.2337	. . CLAMP, conduit Attaching parts for EG7.82.2337:-	2	Tufnol	27/14
G.K.N.				
ART.1498	. . Screw, 0 BA x 3/4" long, nylon cheese head	1	—	27/20
EG7.82.2331	. . CONDUIT	1	Fibre- glass	27/24
EG7.82.2333	. . CONDUIT	1	Fibre- glass	27/8
EG7.82.2335	. . FAIRLEAD, 'stand off' Attaching parts for EG7.82.2335:-	2	Tufnol	27/22
A25/4C	. . Bolt, 2 BA hex. head	2	—	27/13
AGS2001/C/1	. . Nut, stiff, 2 BA	2	—	27/9
SP15/C	. . Washer, 2 BA plain	2	—	27/11
EG7.82.187	. CONNECTOR, H.F. 1, from H.F. distribution box to transmitter receiver	1	—	
EG7.82.189	. CONNECTOR, H.F. 2, from aerial tuning unit type 180-L3A to aerial post	1	—	
EG7.82.193	. CONNECTOR, H.F. 4, from transmitter/receiver to aerial tuning unit type 180-L3A	1	—	
EG7.82.195	. CONNECTOR, H.F. 5, from transmitter/receiver to aerial tuning unit type 180-L3A	1	—	
EG7.82.197	. CONNECTOR, H.F. 6, from H.F. distribution box to control unit type 714E-3 (Pre Mod 5466)	1	—	
EG7.82.5327	. CONNECTOR, H.F. 6 (Mod 5466)	1	—	
EG7.82.591	. CONNECTOR, H.F. 7, from H.F. distribution box to aerial tuning unit type 180-L3A	1	—	
EG7.82.593	. CONNECTOR, H.F. 8, from H.F. distribution box to UA.60 junction box	1	—	

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.595	. CONNECTOR, H.F. 9, FROM INTER PHONE AMPLIFIER TO H.F. DISTRIBUTION BOX, GROUP Consisting of:—	1	—	
UA6002	. . AMPLIFIER, interphone	1	—	
508/2/04367	. . FILLER, plug	2	—	
508/2/05603/002	. . PIN, plug	3	—	
508/2/05604/002	. . PIN, plug	4	—	
UK-AN				
9000/16/1P(N)	. . PLUG, free	1	—	
508/2/05851/004	. . RING, anti chafe	1	—	
EEAS146/22	. . SLEEVE, 1/2" long, pink	QR	—	
EEAS146/000	. . SLEEVE, 1" long, pink	QR	—	
EEAS146/000	. . SLEEVE, 1 1/2" long, pink	QR	—	
22139622	. . SLEEVE, packing, pink	4	—	
22139623	. . SLEEVE, packing, blue	1	—	
RAYCHEM D121	. . SLEEVE, solder, low temp.	2	—	
5F/4342140	. . TUBING, S.C.L. 3/16" grey	QR	—	
5E/0149438	. . WIRE, equip., 19.0076, blue	QR	—	
R EG7.82.597	. CONNECTOR, H.F.10, from H.F. distribution box to navigator's coaming panel T/B (Pre Mod 5466)	1	—	
R EG7.82.5931	. CONNECTOR, H.F.10 (Mod 5466)	1	—	
—	. MAST, H.F. "STAND-OFF" AERIAL, INSTALLATION (EG7.82.2339) Spares for:—	—	—	28/48
R CHELTON 3-3	. . MAST, aerial, stand-off (Pre Mod 5357)	1	—	28/49
R 3-3 MOD 1	. . MAST, aerial, stand-off (Mod 5357) Attaching parts for 3-3 or 3-3 MOD 1	1	—	
R AS1248/8C	. . Bolt, 2 BA mushroom head	12	—	28/45
AGS2002/C/1	. . Nut, stiff, 2 BA	12	—	28/47
SP15/C	. . Washer, 2 BA plain	12	—	28/46
—	. MAST, H.F. AERIAL AND SPARK-GAP, INSTALLATION (EG7.82.2341) Spares for:—	—	—	28/55
CHELTON ELECT 3-2	. . MAST, H.F. aerial Attaching parts for 3-2:—	1	—	28/53
AS1248/8C	. . Bolt, 2 BA mushroom head	12	—	28/50
AGS2002/C/1	. . Nut, stiff, 2 BA	12	—	28/54
SP15/C	. . Washer, 2 BA plain	12	—	28/52
EG7.82.2807	. . SPARK-GAP, ASSEMBLY Consisting of:—	1	—	28/10
EG7.82.2811	. . BLOCK, base, assembly	1	—	28/7

RADIO AND RADAR
H.F. RADIO INSTALLATION (ARI.23090)

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG7.82.191	. . .	CABLE, ASSEMBLY, H.F.3, FROM SPARK-GAP TAIL TO AERIAL POST, GROUP	1	—	
		Consisting of:			
R 5E/9993758		CABLE, uninyvin 12	QR	—	
EEAS146/12		SLEEVE, 1" long, pink	QR	—	
EEAS146/12		SLEEVE, 1½" long, pink	1	—	
ROSS COURTNEY WE554		TAG, crown end, brass	1	—	
EG7.82.199	. . .	CABLE, ASSEMBLY, SPARK-GAP EARTH, FROM SPARK-GAP TAIL TO EARTH POINT, GROUP	1	—	
		Consisting of:			
R 5E/9993758		CABLE, uninyvin 12	QR	—	
EEAS146/12		SLEEVE, 1" long, pink	QR	—	
EEAS146/12		SLEEVE, 1½" long, pink	QR	—	
HC312		TAG, ring tongue	1	—	
BULGIN P92	. . .	CAP, valve	2	—	
EC3.82.419	. . .	COVER	1	—	28/17
		Attaching parts for EC3.82.419:			
AS1242/9B	. . .	Bolt, 4BA c'sk head	3	—	28/1
AGS2001/B/1	. . .	Nut, stiff, 4BA	3	—	28/6
SP15/B	. . .	Washer, 4BA plain	3	—	28/5
EG7.82.2809	. . .	SPACER	1	LFS	28/9
E.E.CO., LINCOLN BS142	. . .	SPARK-GAP	1	—	28/12
		Attaching parts for EG7.82.2807:			
AS1248/3C	. .	Bolt, 2BA mushroom head	2	—	28/3
SP15/C	. .	Washer, 2BA plain	2	—	28/2
—	. .	MOUNTING, AERIAL TUNING UNIT, INSTALLATION (EG7.82.381)	—	—	28/43
		Spares for:			
A25/1C	. .	BOLT, 2BA hex. head, support attachments	14	—	28/24
R 10A/9451644	. .	MOUNTING, type 350, D.3, 'COLLINS'	1	—	28/37
		Attaching parts for type 350:			
A25/1C	. .	Bolt, 2BA hex. head	16	—	28/33
AGS2001/C/1	. .	Nut, stiff, 2BA	16	—	28/36
SP15/C	. .	Washer, 2BA plain	16	—	28/35
AGS2001/C/1	. .	NUT, stiff, 2BA	14	—	28/22
EEAS146/18	. .	SLEEVE, 1¼" long	1	—	
NL8140	. .	SLEEVE, insulating	1	—	
HC1290	. .	SPLICE, in line connector	1	—	

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG7.82.247	.	.	.	PLATFORM, assembly			1	L72	28/28
EG7.82.253	.	.	.	STRUT, support			1	L72	28/27
EG7.82.254	.	.	.	STRUT, support			1	L72	28/29
SP15/C	.	.	.	WASHER, 2 BA plain			14	—	28/23
—	.	.	.	TRAY, TRANSMITTER RECEIVER AND SUPPORT STRUCTURE, INSTALLATION (EG7.82.1885) Spares for:—			—	—	28/32
EG7.82.1887	.	.	.	STRUCTURE, SUPPORT, ASSEMBLY Spares for:—			1	—	28/11
EG7.82.1961	.	.	.	RAIL, SUPPORT, ASSEMBLY Spares for:—			1	—	28/13
EG7.82.2509	.	.	.	BLOCK, anchor nut, packing			2	BS2572 Type F3	28/25
EG7.82.349	.	.	.	STAY Attaching parts for EG7.82.349:—			2	L72	28/26
A25/1C	.	.	.	Bolt, 2 BA hex. head			1	—	28/18
A25/2C	.	.	.	Bolt, 2 BA hex. head			1	—	28/19
AGS2001/C/1	.	.	.	Nut, stiff, 2 BA			1	—	28/20
SP15/C	.	.	.	Washer, 2 BA plain			2	—	28/21
A25/2E	.	.	.	Bolt, 1/4" BSF hex. head			2	—	28/34
A25/28E	.	.	.	Bolt, 1/4" BSF hex. head			2	—	28/8
AGS2001/E/1	.	.	.	Nut, stiff, 1/4" BSF			4	—	28/30
SP15/E	.	.	.	Washer, 1/4" BSF plain			4	—	28/31
R TYPE 390-J1	.	.	.	TRAY, mounting, type 390-J1 Attaching parts for 390-J1:—			1	—	28/4
A25/2C	.	.	.	Bolt, 2 BA hex. head			16	—	28/14
AGS2001/C/1	.	.	.	Nut, stiff, 2 BA			16	—	28/15
SP15/C	.	.	.	Washer, 2 BA plain			16	—	28/16
R CHELTON 5503	.	.	.	WIRE, aerial (Pre Mod 5357)			QR	—	28/44
R 5503A	.	.	.	WIRE, aerial (Mod 5357)			QR	—	

RADIO AND RADAR

H.F. RADIO INSTALLATION (ARI.23090)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
—	H.F. RADIO IN REAR FUSELAGE, ASSEMBLY (EG7.82.185) Spares for:—						—	—	28/38
CHELTON 5436	. CAP, for ball socket						1	—	28/39
CHELTON 6188	. CAP, for chuck						1	—	28/40
—	. FITTINGS, AERIAL ATTACHMENT ON FIN, INSTALLATION (EC3.82.67) Consisting of:—						—	—	28/51
EC3.82.71	. . BAR, toggle						1	—	28/65
A25/2C	. . BOLT, 2 BA hex. head						2	—	28/66
EC3.82.69	. . EYE-BOLT						1	—	28/62
EC3.82.77	. . NUT, special						1	—	28/61
A27/CS	. . NUT, 2 BA slotted						2	—	28/58
EC3.82.79	. . PIN						1	—	28/56
SP90/C5	. . PIN, split						2	—	28/57
SP90/E8	. . PIN, split						1	—	28/67
EC3.82.81	. . PLATE, adapter						2	—	28/60
EC3.82.73	. . WASHER						1	—	28/63
EC3.82.75	. . WASHER						1	—	28/64
SP15/C	. . WASHER, 2 BA plain						2	—	28/59
CHELTON 6186	. UNIT, chuck						1	—	28/41
CHELTON 8-2	. UNIT, tension						1	—	28/42

A.P.101B-0417-3A

Page MF1

RADIO AND RADAR

1520.I.F.F./SSR INSTALLATION (ARI.23134)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R -						1520.I.F.F./SSR INSTALLATION (EG7.82.2851) (MOD 4493)	-	-	
R -						ALTS TO GA OF IFF (EG7.82.5237) (Mod 5466)	-	-	
						Spares for:-			
R -						. I.F.F. IN FRONT FUSELAGE (EG7.82.2853)	-	-	29/1
R -						. I.F.F. IN FRONT FUSELAGE (EG7.82.5239) (Mod 5466)	-	-	
						Spares for:-			
R EG7.82.2859						. . CABLE, ASSEMBLY, I.F.I., FROM TRANSPONDER CONTROL UNIT TO PRESSURE BULKHEAD, GROUP (Pre Mod 5466)	1	-	29/2
						Spares for:-			
R UNIMINYVIN 22						. . . CABLE, uniminyvin 22	QR	-	
1402-1-12-22						. . . CLAMP, cable	1	-	
HELLERMANN									
419206						. . . PLUG, filler	18	-	
HELLERMANN, D.									
460-22-55S						. . . PLUG, free, 55-way	1	-	
HELLERMANN, D.									
466-22-55S-081						. . . PLUG, free, 55-way-angle	1	-	
EEAS146/00						. . . SLEEVE, 1" long	QR	-	
EEAS146/00						. . . SLEEVE, 1-1/2" long	QR	-	
EEAS146/12						. . . SLEEVE, 1/2" long	QR	-	
EEAS146/12						. . . SLEEVE, 3/4" long	QR	-	
EEAS146/22						. . . SLEEVE, 1/4" long	QR	-	
EEAS146/22						. . . SLEEVE, 3/4" long	QR	-	
HV3341						. . . STRAPPING	QR	-	
OP3342						. . . STUD	QR	-	
HC295						. . . TAG, ring tongue	3	-	
HC296						. . . TAG, ring tongue	2	-	
HC490						. . . TAG, quick release	1	-	
R EG7.82.5325						. . CABLE, assembly (Mod 5466)	1	-	
COSSER									
16929						. . UNIT, control, transponder, set	1	-	29/3

RADIO AND RADAR

1520.I.F.F./SSR INSTALLATION (ARI.23134)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	. I.F.F. IN CENTRE FUSELAGE (EG7.82.2855) Spares for:—	—	—	29/4
—	. . AERIAL, UPPER, INSTALLATION (EB6.90.157) Spares for:—	—	—	29/5
R 10B4280400	. . . AERIAL, omni, type 100B Attaching parts for 10B4280400:—	1	—	29/6
EB6.90.175	. . . BLOCK, packing	1	—	29/7
AS1242/6C	. . . Bolt, 2 BA c'sk head	12	—	29/8
EB6.90.167	. . . Seal, linatex, 7/16"	1	DTD900	29/9
EB6.90.173	. . . MOUNTING, sub-assembly	1	—	29/10
EB6.90.165	. . . SEAL, skin, linatex, 3/64"	1	DTD900	29/11
EG7.82.2895	. . CABLE, ASSEMBLY, I.F.3, FROM T/R TO PRESSURE BULKHEAD, GROUP Spares for:—	1	—	29/12
—	. . . CABLE, uniminyvin	QR	—	
HELLERMANN, D.				
1402-1-12-22	. . . CLAMP, cable	1	—	
1402-1-12-10	. . . CLAMP, cable	1	—	
CANNON				
038819-0003	. . . CONTACT	56	—	
038819-0001	. . . CONTACT	56	—	
038998-0000	. . . JUNCTION, shell	1	—	
036049-0003	. . . PLUG, filler	42	—	
HELLERMANN, D.				
419206	. . . PLUG, filler	9	—	
566-22-55P	. . . PLUG, free, 55-way	1	—	
466-10-65	. . . PLUG, free, 6-way	1	—	
CANNON				
DPJM98-335-B	. . . PLUG, 98-way	1	—	
EEAS146/EQ	. . . SLEEVE, 3/8" long	QR	—	
EEAS146/00	. . . SLEEVE, 1-1/2" long	QR	—	
EEAS146/00	. . . SLEEVE, 1" long	QR	—	
EEAS146/6	. . . SLEEVE, 3/4" long	QR	—	
EEAS146/6	. . . SLEEVE, 1/2" long	QR	—	
EEAS146/22	. . . SLEEVE, 3/4" long	QR	—	
EEAS146/22	. . . SLEEVE, 1/4" long	QR	—	
HV3254	. . . STRAPPING, 1/2" wide	QR	—	
OP3255	. . . STUD	QR	—	
HC294	. . . TAG, ring tongue	23	—	
HC296	. . . TAG, ring tongue	QR	—	
EG7.82.2863	. . CABLE, ASSEMBLY, T.F., FROM UPPER AERIAL PLUG ASSEMBLY TO SWITCH UNIT PLUG ASSEMBLY, GROUP (MOD 4865, PART A) Spares for:—	1	—	29/13
R UNIRADIO 67	. . . CABLE, uniradio 67	QR	—	
SIS6448	. . . PLUG, type 119(CS)	1	—	
AMPHENOL				
82-GB-556-2	. . . PLUG, type UKC-2	1	—	
EEAS146/2	. . . SLEEVE, 1" long	QR	—	
EEAS146/2	. . . SLEEVE, 1-1/2" long	QR	—	

A.P.101B-0417-3A

RADIO AND RADAR

Page MF3

1520.I.F.F./SSR INSTALLATION (ARI.23134)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R	10B/4280400	—						I.F.F. IN REAR FUSELAGE (E.G7.82.2857)	—	—	—	29/14
		—						Spares for:—	—	—	—	29/15
		—						AERIAL, LOWER, INSTALLATION (E.B6.90.159) ..	—	—	—	29/16
		—						Spares for:—	—	—	—	29/17
		—						AERIAL, omni, type 100B	1	—	A	29/18
		—						Attaching parts for 10B/4280400:—	—	—	—	29/19
	26571	E.B6.90.163						Block, backing	1	—	C	29/20
	28D/1204937	AS.1242/6C						Bolt, 2 BA c'sk head	12	—	C	29/21
	26573	E.B6.90.167						Seal, aerial, 7/16" linatex	1	DTD900	C	29/22
	26570	E.B6.90.161						MOUNTING, sub-assembly	1	—	C	29/23
	26572	E.B6.90.165						SEAL, skin 3/64" linatex	1	DTD900	C	29/24
	10HB/4699441	E.G7.82.2865						CABLE, ASSEMBLY, I.F.4, FROM LOWER AERIAL .	1	—	B	29/25
								PLUG UNIT TO SWITCH UNIT PLUG				
								ASSEMBLY, GROUP				
								Spares for:—				
R	5E/9100295	—						CABLE, unradio 67	QR	—	C	29/26
	10H/9321722	SIS.6448						PLUG, type 119 (CS)	1	—	B	29/27
		AMPHENOL						PLUG, type UKC-2	1	—	—	29/28
		82-GB-556-2										
		EEAS.146/2						SLEEVE, 1" long	QR	—	—	29/29
		EEAS.146/2						SLEEVE, 1-1/2" long	QR	—	—	29/30
		E.G7.82.2867						CABLE, ASSEMBLY, I.F.5, FROM SWITCH UNIT ...	1	—	—	29/31
								PLUG ASSEMBLY TO T/R PLUG				
								ASSEMBLY, GROUP				
								Spares for:—				
	5E/9100295	—						CABLE, unradio 67	QR	—	C	29/32
		AMPHENOL						PLUG, type UKC-2	2	—	—	29/33
		82-GB-556-2										
		EEAS.146/2						SLEEVE, 1" long	QR	—	—	29/34
		EEAS.146/2						SLEEVE, 1-1/2" long	QR	—	—	29/35
R		—						GUARD, AERIAL, INSTALLATION (E.B6.90.187) ..	—	—	—	29/36
		—						Spares for:—	—	—	—	29/37
	26566	E.B6.90.197						BRACKET, attachment	4	—	C	29/38
		—						Attaching parts for E.B6.90.197:—	—	—	—	29/39
	28D/1010658	A25/1B						Bolt, 4 BA hex. head	4	—	C	29/40
	28M/1278189	AGS.2001/B/1						Nut, stiff, 4 BA	4	—	C	29/41
	28W/9419465	SP.13/B						Washer, 4 BA plain	4	—	C	29/42
	26567	E.B6.90.189						GUARD, assembly	1	—	C	29/43
		—						Attaching parts for E.B6.90.189:—	—	—	—	29/44
	28D/7002428	A25/6C						Bolt, 2 BA hex. head	4	—	C	29/45
	28M/1278190	AGS.2001/C/1						Nut, stiff, 2 BA	4	—	C	29/46
	28W/9419402	SP.13/C						Washer, 2 BA plain	4	—	C	29/47

RADIO AND RADAR

1520.I.F.F./SSR INSTALLATION (ARI.23134)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R	-	PANEL, AERIAL SWITCH PLUG BREAK,							-	-	-	
	-	ASSEMBLY (E.G7.82.2905)							-	-	-	
		(Mod. 4885 Part A)										
		Spares for:-										
	E.G7.82.2903	BRACKET, and plate assembly							1	-	-	
		Attaching parts for E.G7.82.2903:-										
28D/1010658	A25/1B	Bolt, 4 BA hex. head							4	-	C	
28W/9419465	SP13/B	Washer, 4 BA plain							4	-	C	
5895-99-965-3378	COSSER 16928	TRANSMITTER, receiver							1	-	A	30/8
	-	TRAY, STRUCTURE, INSTALLATION (E.G7.80.2029)							-	-	-	30/9
		Spares for:-										
	E.G7.82.2879	STRUCTURE, SUPPORT, ASSEMBLY							1	-	-	30/10
		Spares for:-										
	E.G7.82.2881	PLATE, MOUNTING, ASSEMBLY							1	-	-	30/11
		Attaching parts for E.G7.82.2881:-										
28D/1011242	A25/7E	Bolt, 1/4" BSF hex. head							6	-	C	30/12
28M/9480017	AGS.2001/E/1	Nut, stiff, 1/4" BSF							6	-	C	30/13
28W/9471273	SP124/E	Washer, 1/4" BSF plain							6	-	C	30/14
5820-99-107-5637	COSSER 16946	TRAY, MOUNTING, ASSEMBLY							1	-	A	30/15
		Attaching parts for 16946:-										
28D/1011030	A25/2E	Bolt, 1/4" BSF hex. head							4	-	C	30/16
28W/9471273	SP124/E	Washer, 1/4" BSF plain							4	-	C	30/17
	E.G7.82.2885	WASHER, spacing							6	-	-	30/18
	E.B6.90.53	TRAY, mounting, sub-assembly							1	-	-	30/19
		Attaching parts for E.B6.90.53:-										
28D/1007981	AS.1248/1/2C	Bolt, 2 BA mushroom head							4	-	C	30/20
28D/1007982	AS.1248/1C	Bolt, 2 BA mushroom head							28	-	C	30/21
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							32	-	C	30/22
28W/9419402	SP13/C	Washer, 2 BA plain							32	-	C	30/23
5895-99-107-1521	COSSER 16941	UNIT, switch, aerial							1	-	A	30/24
		Attaching parts for 16941:-										
28D/9140638	A25/4B	Bolt, 4 BA hex. head							3	-	C	30/25
28W/9419465	SP13/B	Washer, 4 BA plain							3	-	C	30/26

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1 2 3 4 5 6 7				
10H/0970099	508/2/07755/007	RING, thrust	1	-	C	
5K/9107065	EEAS.146/A	SLEEVE, 3/4" long	QR	-	C	
5K/9107069	EEAS.146/E	SLEEVE, 1" long	QR	-	C	

RADIO AND RADAR

I.F.F.10 INSTALLATION (ARI.5848)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	I.F.F. IN REAR FUSELAGE, ASSEMBLY (E.G7.82.207) . . .							—	—	—	29/27
		Spares for:—										
08E/8850/ 101965	UG.212U	ADAPTOR, angle							1	—	C	29/22
	—	AERIAL, LOWER, INSTALLATION (E.B6.90.159)							—	—	—	29/26
		Spares for:—										
10B/20275	†	AERIAL, omni, type 100B							1	—	A	29/33
		Attaching parts for 10B/20275:—										
26571	E.B6.90.163	Block, packing							1	—	C	29/37
28D/1204937	AS.1242/6C	Bolt, 2 BA c'sk head							12	—	C	29/39
26573	E.B6.90.167	Seal, aerial, 1/16" linatex							1	DTD.900	C	29/36
		MOUNTING, assembly							1	—	C	29/28
26572	E.B6.90.165	SEAL, skin, 3/64" linatex							1	DTD.900	C	29/32
10HA/17366	†	CABLE, assembly, type C.267/10/B/1338, from switch . .							1	—	B	
		unit to omni aerial										
33691	E.A3.90.311	CABLE, assembly, I.F.9, from coder to transmitter/							1	—	B	
		receiver										
	E.G7.82.2253	CABLE, ASSEMBLY, I.F.2, FROM TRANSMITTER/							1	—	LM	
		RECEIVER TO JUNCTION BOX, GROUP										
		(Make from 10HB/6277)										
		Consisting of:—										
5E/3079	†	CABLE, quinipren 6							QR	—	C	
33H/56	†	CEMENT, bostik 771							QR	—	C	
04A/6500/ 000354	AH.3057/6	CLAMP, cable							1	—	C	
5K/87	AGS.1658/0	NUT, cable gland							1	—	C	
5K/9107066	EEAS.146/A	SLEEVE, 3/4" long							QR	—	C	
5K/9107066	EEAS.146/A1	SLEEVE, 3/4" long							QR	—	C	
5K/9107068	EEAS.146/D1	SLEEVE, 1" long							QR	—	C	
5K/34	AGS.1688/2	SLEEVE, slotted, type 1							1	—	C	
5936-99- 9403077	AH.3108A/14S/5S	SOCKET							1	—	B	
5X/7298	Z.19974	THIMBLE, quick release							5	—	C	
32B/498	†	THREAD, waxed linen, No. 18							QR	—	C	
	E.G7.82.2255	CABLE, ASSEMBLY, I.F.3, FROM AERIAL SWITCH							1	—	LM	
		UNIT TO I.F.F. JUNCTION BOX, GROUP										
		(Make from 10HB/6278)										
		Consisting of:—										
5E/3074	†	CABLE, tripren 6							QR	—	C	

A.P.101B-0417-3A		RADIO AND RADAR						Page MF7			
I.F.F.10 INSTALLATION (ARI.5848)											
Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
33H/56	†	CEMENT, bostik 771						QR	—	C	
10H/0119877	508/2/07705/200	GASKET, outlet						1	—	C	
10H/0970108	508/2/07719/200	GASKET, union						1	—	C	
5K/87	AGS.1658/0	NUT, cable gland						1	—	C	
10H/0970069	CZ.49181	OUTLET, angle						1	—	C	
10H/0970102	508/2/07746/009	RING, compression						1	—	C	
10H/0970096	508/2/07752/007	RING, thrust						1	—	C	
10H/0970114	Z.62240	SLEEVE, cable						1	—	C	
5K/9107065	EEAS.146/A	SLEEVE, 3/4" long						QR	—	C	
5K/9107066	EEAS.146/A1	SLEEVE, 3/4" long						QR	—	C	
5K/9107071	EEAS.146/0	SLEEVE, 1" long						QR	—	C	
5K/33	AGS.1688/1	SLEEVE, slotted, type 1						1	—	C	
10H/0560100	CZ.49015	SOCKET, free Mk. 4, 3-way						1	—	C	
5X/7298	Z.19924	TAG, quick release						3	—	C	
32B/498	†	THREAD, waxed linen, No. 18						QR	—	C	
10HB/1482	†	CONNECTOR, type CA.267/10/B/1156, from switch						1	—	B	
		unit to transmitter receiver									
10HB/1483	†	CONNECTOR, type CA.267/10/B/1157, from switch						1	—	B	
		unit to upper aerial									
	—	GUARD, AERIAL, INSTALLATION (E.B6.90.187)						—	—	—	29/14
		Spares for:—									
26566	E.B6.90.197	BRACKET, attachment						4	—	C	29/3
		Attaching parts for E.B6.90.197:—									
28D/1010658	A.25/1B	Bolt, 4 BA hex. head						4	—	C	29/6
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA						4	—	C	29/8
28W/9419465	SP.13/B	Washer, 4 BA plain						4	—	C	29/7
26567	E.B6.90.189	GUARD, assembly						1	—	C	29/15
		Attaching parts for E.B6.90.189:—									
28D/7002428	A.25/6C	Bolt, 2 BA hex. head						4	—	C	29/12
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA						4	—	C	29/10
28W/9419402	SP.13/C	Washer, 2 BA plain						4	—	C	29/11
	—	MOUNTING, I.F.F. JUNCTION BOX AND SWITCH						—	—	—	30/15
		UNIT, ASSEMBLY (E.G7.82.2017)									
		Spares for:—									
	E.G7.82.2267	BOX, I.F.F. JUNCTION, ASSEMBLY						1	—	—	30/16
		Spares for:—									
	E.B6.90.303	BOX, JUNCTION, ASSEMBLY						1	—	—	30/12
		Spares for:—									
25930	EEAS.87	NUT, side anchor, 4 BA						4	—	C	30/11

RADIO AND RADAR

I.F.F.10 INSTALLATION (ARI.5848)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
1438680	EEAS.15/37/70DR							PACKING	4	L72	C	30/8
25929	EEAS.15/37/70JR							PACKING	4	L72	C	30/10
26584	E.B6.90.199							COVER, ASSEMBLY	1	—	B	30/7
								Spares for:—				
5CW/4860	ZA.2404							GUARD, switch	1	—	B	30/3
								Attaching parts for ZA.2404:—				
28S/1012450	A.32/B10							Screw, 4 BA round head	2	—	C	30/1
28W/1206041	AGS.2035/B							Washer, 4 BA shakeproof	2	—	C	30/4
5CW/5826	D.5401/1							SWITCH	4	—	B	30/2
								Attaching parts for E.B6.90.199:—				
32368	E.A9.81.4357							Screw, cover	1	—	C	30/5
1066	EEAS.28/2/CU							WASHER	8	S.515	C	30/9
1108	EEAS.42							WASHER, leather	4	—	C	30/6
								Attaching parts for E.G7.82.2257:—				
28D/1010658	A.25/1B							Bolt, 4 BA hex. head	4	—	C	30/13
28W/9419465	SP.13/B							Washer, 4 BA plain	4	—	C	30/14
10F/19511	†							SWITCH-UNIT	1	—	B	30/17
								Attaching parts for 10F/19511:—				
28D/9140638	A.25/4B							Bolt, 4 BA hex. head	3	—	C	30/18
28W/9419465	SP.13/B							Washer, 4 BA plain	3	—	C	30/19
	—							TRAY, STRUCTURE, INSTALLATION (E.B6.90.51) ..	—	—	—	30/21
								Spares for:—				
37707	E.B6.90.719							MOUNTING, ASSEMBLY	1	—	C	30/22
								Spares for:—				
	E.B6.90.111							ANGLE	2	—	—	30/30
								Attaching parts for E.B6.90.111:—				
28D/1010658	A.25/1B							Bolt, 4 BA hex. head	3	—	C	30/27
28M/1278189	AGS.2001/B/1							Nut, stiff, 4 BA	3	—	C	30/28
28W/9419474	SP.15/B							Washer, 4 BA plain	3	—	C	30/29
5K/3410	AS.3360/C/3E							LEAD, bonding	1	—	C	30/32
10AJ/162	†							MOUNTING, anti-vibration	4	—	B	30/41
								Attaching parts for 10AJ/162:—				
28D/1010031	A.25/8E							Bolt, 1/4" BSF hex. head	4	—	C	30/36
28D/7002413	A.25/14E							Bolt, 1/4" BSF hex. head	4	—	C	30/34
28M/9480017	AGS.2001/E/1							Nut, stiff, 1/4" BSF	4	—	C	30/44
28W/9418921	SP.13/E							Washer, 1/4" BSF plain	4	—	C	30/43
10A/17930	†							Washer, check	4	—	C	30/42
32662	E.B6.90.721							NUT, RETAINING, ASSEMBLY	2	—	C	30/45
								Spares for:—				
	E.B6.90.123							BLOCK, hinge	1	—	—	30/38
	E.B6.90.121							NUT, knurled	1	—	—	30/40
	E.B6.90.119							PIN	1	—	—	30/37
	E.B6.90.723							SCREW	1	—	—	30/39

A.P.101B-0417-3A

Page MF9

RADIO AND RADAR I.F.F.10 INSTALLATION (ARI.5848)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index No.
		1	2	3	4	5	6	7				
		Attaching parts for E.B.90.719—										
28D/9436920	A.25/1C	Bolt, 2 BA hex. head	...	...	...	...	...	...	16	—	C	30/31
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	...	...	...	...	...	...	16	—	C	30/35
28W/9419402	SP.13/C	Washer, 2 BA plain	...	...	...	...	...	...	16	—	C	30/33
10AJ.646	↑	MOUNTING , coder, KY95							1	—	A	30/20
		Attaching parts for 10AJ.646—										
28D/1009984	A.25/7B	Bolt, 4 BA hex. head	...	...	...	...	...	...	16	—	C	30/23
28M/1278189	AGS.2001/B/1	Nut, stiff, 4BA	...	...	...	...	...	...	16	—	C	30/26
	32555 E.A3.90.309	Piece, packing	...	...	...	...	...	...	4	LFS.23	C	30/24
28W/9419465	SP.13/B	Washer, 4 BA plain	...	...	...	...	...	...	16	—	C	30/25

Restricted

[illegible]

A.P.101B-0417-3A

Page MG1

RADIO AND RADAR
 RADIO ALTIMETER (ARI.23061) (PRE SRIM 3367)
 RADIO ALTIMETER (ARI.23172) (SRIM 3367)

R
R

R

R

R

R

R

R

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
	RADIO ALTIMETER, ARI.23061, ASSEMBLY (EG7.82.353) (PRE SRIM 3367)	-	-	31/37
	RADIO ALTIMETER, ARI.23172, ASSEMBLY (EG7.82.353) (SRIM 3367)	-	-	
	Spares for:			
10U/1038541	. AMPLIFIER, type 16089 (Pre Srim 3367)	1	-	31/38
10U/9542618	. AMPLIFIER, type 16089 (Srim 3367)	1	-	
10L/1037449	. CONTROL UNIT, type 16095	1	-	31/34
10D/1037447	. RECEIVER, transmitter, type 16098 (Pre Srim 3367)	1	-	31/1
10D/9542617	. RECEIVER, transmitter, type 16098 (Srim 3367)	1	-	
10B/1046011	. SWITCH, aerial and coupling unit	2	-	31/9

RADIO AND RADAR
RADIO ALTIMETER (ARI.23061) (PRE SRIM 3367)
RADIO ALTIMETER (ARI.23172) (SRIM 3367)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	RADIO ALTIMETER IN FRONT FUSELAGE (EG7.82.399) Spares for:—	—	—	31/49
UG306A/U	. ADAPTOR, right angle	1	—	31/40
10D/4696726	. BOX, junction, type 16107	1	—	31/35
10D/4277189	. BOX, junction, type 16507 Attaching parts for 10D/4277189:—	1	—	31/41
A31/B10	. Screw, 4BA cheese head	4	—	31/42
SP47/B	. Washer, 4BA spring	4	—	31/43
508/1/03442/003	. CAP, protection	1	—	
EG7.82.529	. CONNECTOR, R.A.2, from junction box type 16507 to pressure bulkhead	1	—	
EG7.82.531	. CONNECTOR, R.A.2A, from junction box type 16107 to pressure bulkhead	1	—	
EG7.82.535	. CONNECTOR, R.A.4, from junction box type 16107 to control unit type 16095	1	—	
EG7.82.539	. CONNECTOR, R.A.5A, from junction box type 16107 to pressure bulkhead	1	—	
EG7.82.541	. CONNECTOR, R.A.7, from junction box type 16107 to electrical indicator "height" at pilot's panel	1	—	
EG7.82.543	. CONNECTOR, R.A.9, from junction box type 16107 to terminal block on pilot's flying panel	1	—	
—	. MOUNTING OF RADAR AND RADAR EQUIPMENT IN UPPER EQUIPMENT BAY, ASSEMBLY (EG7.82.3049) (MOD.5428) (PRE MOD.5466)	—	—	31/44
—	. MOUNTING OF RADIO AND RADAR EQUIPMENT IN UPPER EQUIPMENT BAY (EG7.82.6015) (MOD.5466) Spares for:—	—	—	—
10AR/4280395	. . BACK-PLATE, tray, for coupling unit	1	—	31/39
EG7.10.97	. . CHANNEL, RADIO ALTIMETER AMPLIFIER MOUNTING, ASSEMBLY Spares for:—	2	—	31/46
EG7.10.99	. . . CHANNEL	1	L72	31/45
10AJ/1201994	. . . MOUNTING, A.V., type 963 Attaching parts for 10AJ/1201994:—	2	—	31/51
A25/1B	. . . Bolt, 4BA hex. head	8	—	31/50
AGS2001/B/1	. . . Nut, stiff, 4BA	8	—	31/53
SP15/B	. . . Washer, 4BA plain	8	—	31/52
A25/7B	. . . Attaching parts for EG7.10.97:— Bolt, 4BA hex. head	4	—	31/48
10A/4702149	. . . Washer, check	4	—	31/47
10AJ/4306051	. . MOUNTING, type 9274, for transmitter receiver Attaching parts:—	1	—	31/33
A25/14E	. . Bolt, 1/4" BSF hex. head	4	—	31/21
AGS2001E1	. . Nut, stiff, 1/4" BSF	4	—	31/23
SP13/E	. . Washer, 1/4" BSF plain	4	—	31/22
WTD143536	. . MOUNTING, type 7548, for coupling unit Attaching parts:—	1	—	31/30
A25/7B	. . Bolt, 4BA hex. head	4	—	31/24
WT33047/C7	. . Washer, check	4	—	31/25

A.P.101B-0417-3A

Page MG3

RADIO AND RADAR

RADIO ALTIMETER (ARI.23061) (PRE SRIM 3367)

RADIO ALTIMETER (AIR.23172) (SRIM 3367)

R
R

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
10AJ/1037400	. . MOUNTING, type 16097, for amplifier Attaching parts for 10AJ/1037400	1	—	31/36
A25/1C	. . Bolt, 2 BA hex. head	4	—	31/26
AGS2001/C/1	. . Nut, stiff, 2 BA	4	—	31/28
SP13/C	. . Washer, 2 BA plain	4	—	31/27
—	. . SWITCHES, AERIAL INSTALLATION AND CONTROL UNIT (EG7.82.3043) (Mod.5428) (Pre Mod.5466) Spares for:—	—	—	43/1
EG7.81.4037	. . . BLOCK, fuse, assembly Spares for:—	1	—	43/2
CZ52815 or 703-1-00416 EG7.81.4039	 BLOCK, fuse LABEL Attaching parts for EG7.81.4037:—	1 1	— —	43/3 43/4
A31/B6	. . . Screw, 4 BA	2	—	43/5
SP47/B	. . . Washer, spring	2	—	43/6
AS10 or 5CZ/5216 EG7.81.4035	. . . FUSE, 10A . . . PLATE (Ref 30B/9611218) Attaching parts for EG7.81.4035	1 1	— 18 SWG	43/7 43/8
A31/B20	. . . Screw, 4 BA	4	—	43/9
WB1114/22	. . . Spacer	4	—	43/10
—	. . SWITCHES, AERIAL INSTALLATION AND CONTROL UNIT (EG7.82.6011) (Mod.5466) Spares for:—	—	—	43/11
EG7.81.4037	. . . BLOCK, fuse, assembly Spares for:—	1	—	43/12
CZ52815 or 703-1-00416 EG7.81.4039	 BLOCK, fuse LABEL Attaching parts for EG7.81.4037:—	1 1	— —	43/13 43/14
A31/B6	. . . Screw, 4 BA	2	—	43/15
SP47/B	. . . Washer, spring	2	—	43/16
72541-022-0	. . . BLOCK, terminal Attaching parts:—	1	—	43/17
36765-502-0	. . . Pillar, fixing	2	—	43/18
AGS2001/B/1	. . . Nut, stiff	2	—	43/19
SP15/B	. . . Washer	2	—	43/20
41852-822-0	. . . COVER, terminal block	1	—	43/21
AS10	. . . FUSE, 10A	1	—	43/22
EG7.81.5653	. . . PLATE Attaching parts:—			43/23
A31/B20	. . . Screw, 4 BA	4	—	43/24
WB1114/22	. . . Spacer	4	—	43/25
EEAS550-2 GRADE CXH	. . . PLATE, ident . . . SLEEVE, 3mm 1/D x 3/8" long	1 QR	— —	43/26 43/27
10H/4695561	. PLUG, dummy, type 106	1	—	
10H/4695502	. PLUG, dummy, type 107	1	—	

RADIO AND RADAR
 RADIO ALTIMETER (ARI.23061) (PRE SRIM 3367)
 RADIO ALTIMETER (ARI.23172) (SRIM 3367)

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
-	RADIO ALTIMETER IN CENTRE FUSELAGE, ASSEMBLY (EG7.82.401) Spares for:—	—	—	31/29
EG7.82.525	. CONNECTOR, R.A.1 from distributor box No. 1 break to junction box type 16507 and transmitter receiver type 16098	1	—	
EG7.82.533	. CONNECTOR, R.A.3, from junction box type 16507 to transmitter receiver type 16098	1	—	
EG7.82.537	. CONNECTOR, R.A.5, from pressure bulkhead to transmitter receiver type 16098	1	—	

AP101B-0417-3A

RADIO AND RADAR
RADIO ALTIMETER (ARI.23061) (PRE SRIM 3367)
RADIO ALTIMETER (ARI.23172) (SRIM 3367)

R
R

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
-	RADIO ALTIMETER IN REAR FUSELAGE ASSEMBLY (EG7.82.403) Spares for:-	-	-	31/18
-	UNITS, RADIO ALTIMETER IN REAR FUSELAGE HATCH, INSTALLATION (EG7.82.709) Spares for:-	-	-	31/19
EG7.82.713	AERIAL, HORN, RADIO ALTIMETER Mk 7, ASSEMBLY Spares for:-	2	-	31/20
10D/1042242	HORN, waveguide Attaching parts for EG7.82.713:-	1	-	31/10
AS1248/2C	Bolt, 2BA mushroom head	60	-	31/12
10HB/9529594	CONNECTOR, aerial (Pre srim 3367)	2	-	31/8
10HB/9542631	CONNECTOR, aerial receive (Srim 3367)	1	-	
10HB/9542632	CONNECTOR, aerial transmit (Srim 3367)	1	-	31/54
EG7.82.549	CONNECTOR, RA28, from transmitter receiver type 16098 to aerial switch and coupling units	1	-	31/5
EG7.82.813	FAIRLEAD, assembly Attaching parts for EG7.82.813:-	1	-	31/14
A25/3C	Bolt, 2BA hex head	4	-	31/13
EG7.82.831	STRIP, bonding, copper, 28 SWG (Make from 30B/1071)	2	BS899	31/7
10AJ/698	TRAY, mounting, type 16096 Attaching parts for 10AJ/698:-	1	-	31/2
A25/10E	Bolt, 1/4" BSF hex head	4	-	31/3
WT33047	Washer, check	4	-	31/4
10D/1039075	UNIT, delay, type 16119 Attaching parts for 10D/1039075:-	1	-	31/16
AS1246/3C	Bolt, 2BA round head	3	-	31/15
EEAS238/1A	WASHER, 'D', clipping attachments	8	L72	31/11
EEAS240/1A	WASHER, 'D', clipping attachments	2	L72	31/17
EEAS240/3A	WASHER, 'D', clipping attachments	1	L72	31/6

R
R
R

A.P.101B-0417-3A

Page MH1

RADIO AND RADAR

RADIO COMPASS (ARI.5877)

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	-	RADIO COMPASS, A.R.I.5877, ASSEMBLY (EG7.82.241) (Pre Mod 5466)	-	-	
R	-	RADIO COMPASS, A.R.I.5877, ASSEMBLY (EG7.82.5235) (Mod 5466) Spares for:-	-	-	
	UG/30/U	. ADAPTER (SRIM 3932) (Mod 5176)	1	-	
R	10B4307188	. AERIAL, loop, type 8280	1	-	32/2
R	10U4307199	. AMPLIFIER, R.F., type 8281	1	-	32/10
R	10U4307201	. AMPLIFIER, I.F., type 8282	1	-	32/23
R	10AR4307167	. BACK-PLATE, control unit	1	-	32/14
R	5CZ4350507	. BOX, junction, 6-way	1	-	32/22
	SCSHQ127090A1	. CONNECTOR (SRIM 3932) (Mod 5176)	1	-	
	SCSHQ127090A2	. CONNECTOR (SRIM 3932) (Mod 5176)	1	-	
R	10AC4307203	. COUPLING, straight, type 512	1	-	32/17
R	TYPE 310/78	. DRIVE, tuning, type 310/78	1	-	32/18
R	10P4698455	. FILTER, voice range, type 1275 (Pre Mod 5466)	1	-	32/13
R	10Q16357	. INDICATOR, bearing, type 9551	1	-	32/5
R	10AJ4307200	. MOUNTING, R.F., type 8288	1	-	32/11
R	10AJ4307202	. MOUNTING, I.F., type 8289	1	-	32/24
R	10L4418805	. UNIT, control, type 8283	1	-	32/15
R	10AD4307190	. UNIT, Q.E. corrector	1	-	32/8

RADIO AND RADAR

RADIO COMPASS (ARI.5877)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
—	RADIO COMPASS IN FRONT FUSELAGE, ASSEMBLY (EG7.82.395)	—	—	
	Spares for:—			
EG7.82.2871	. CONNECTOR, ASSEMBLY, Q.D. FROM R.F. AMPLIFIER, NAVIGATOR'S STATION, TO PLUG BREAK, SENSE AERIAL, RIB 3-4, PORT WING, GROUP (MOD 4715)	—	—	32/29
	Consisting of:—			
EG7.82.543	. . ADAPTER	1	L64	32/39
EG9.82.389	. . BOARD, tag, assembly	1	—	32/40
HELLERMANN SR5267	. . BUNG, pressure	1	—	32/1
UNIRADIO 64	. . CABLE, uniradio 64	QR	—	32/34
MAGNETIC DEVICES				
SR12J	. . CONNECTOR, co-ax. pattern 12	1	—	32/35
10H0970113	. . NUT, coupling	1	—	32/41
AP1696	. . PLUG, co-ax, straight	1	—	32/30
CANNON				
PC60912/2	. . SLEEVE, inner	1	—	32/31
CANNON				
PC60913/2	. . SLEEVE, outer	1	—	32/36
EEAS146/6	. . SLEEVE, 1/2" long	QR	—	32/37
EEAS146/2	. . SLEEVE, 1" long	QR	—	32/42
EEAS146/2	. . SLEEVE, 1.1/2" long	QR	—	32/32
EG9.82.397	. . SPACER	1	—	32/33
EG7.82.429	. CONNECTOR, assembly, Q.A. from Q.E. connector unit to loop aerial	1	—	32/7
EG7.82.431	. CONNECTOR, assembly, Q.B. from pressure bulkhead to Q.E. connector unit.	1	—	32/9
EG7.82.433	. CONNECTOR, assembly, Q.B.1 from bearing indicator to pressure bulkhead	1	—	32/4
EG7.82.435	. CONNECTOR, assembly, A.C. from bearing indicator to R.F. amplifier	1	—	32/6
EG7.82.439	. CONNECTOR, assembly, Q.E. from control unit to R.F. amplifier (Pre Mod 5466)	1	—	32/20
EG7.82.5329	. CABLE, assembly, Q.E. (Mod 5466)	1	—	
EG7.82.441	. CONNECTOR, assembly, Q.G. from control unit to electrical control panel	1	—	32/19

A.P.1018-0417-3A

RADIO AND RADAR

Page MH3

RADIO COMPASS (ARI.5877)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.443	. CONNECTOR, assembly, Q.H., from I.F. amplifier to R.F. amplifier	1	-	32/36
CS5411/13	. CONNECTOR (Mod.4926) (Pre-Mod.5466)	1	-	32/43
EG7.82.5517	. CABLE, assembly, Q.J. (Mod.5466)	1	-	
EG7.82.447	. CONNECTOR, assembly, Q.K., from A.C. supply junction box to radio compass bearing indicator	1	-	32/21
EG7.82.449	. CONNECTOR, assembly, Q.L./144, from A.C. supply junction box to radio magnetic indicator at pilot's panel	1	-	32/12
EG7.82.451	. CONNECTOR, assembly, Q.L., from A.C. supply junction box to radio magnetic indicator at navigator's panel	1	-	32/35
EG7.82.455	. WASHER, special, between loop aerial and structure	4	Neoprene	32/3

RADIO AND RADAR

RADIO COMPASS (ARI.5877)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	RADIO COMPASS IN PORT WING, ASSEMBLY (EG7.82.397) Spares for:-	-	-	33/1
-	. AERIAL, SENSE, RADIO COMPASS INSTALLATION (EG7.82.35) Spares for:-	-	-	33/2
EG7.82.2631	. . AERIAL, SENSE, RADIO COMPASS, GROUP Consisting of:-	1	-	33/3
EG7.82.2637	. . . AERIAL, assembly	2	L54	33/4
EG7.82.2639	. . . CLIP, aerial support	1	L72	33/9
	Attaching parts for EG7.82.2639:-			
AS1248/3C	. . . Bolt, 2 BA mushroom head	2	-	33/13
AGS2002/C/1	. . . Nut, stiff, 2 BA	2	-	33/11
SP15/C	. . . Washer, 2 BA plain	2	-	33/12
EG7.82.47	. . . CONDUCTOR, aerial, assembly	1	B11	33/14
EG7.82.39	. . . INSULATOR, forward	1	L44	33/16
EG7.82.2633	. . . INSULATOR, centre	1	L44	33/6
EG7.82.2635	. . . INSULATOR, aft	1	L44	33/5
AGS2002/C/4	. . . NUT, stiff, 2 BA	4	-	33/28
EB8.82.1173	. . . PAD, rubber	1	-	
†	. . . RUBBER, 'sorbo', 1.0" x 1.5" x 1/8" thick	2	-	33/8
A33/C18	. . . SCREW, 2 BA c'sk head	2	-	33/15
EG7.82.2889	. . . SPACER (Mod 4715)	1	-	33/23
SP56/C	. . . WASHER, 2 BA spring	3	-	33/33
-	. ALTERATIONS, TO PORT WING, ASSEMBLY (EG7.20.779) Spares for:-	-	-	33/22
EG7.82.2765	. . . BRACKET	1	L72	33/26
EG7.20.785	. . . LANDING, panel	1	L73	33/19
EG7.20.787	. . . PANEL, access	1	L73	33/17
	Attachments for EG7.82.787:-			
EEAS1/1.1/2C	. . . Screw, 2 BA 120° c'sk head	16	S96	33/18
EG7.20.781	. . . STIFFENER	1	L72	33/21
EG7.20.783	. . . STIFFENER	2	L72	33/7
EG7.20.791	. . . STRINGER	2	EEDX33	33/24
AS1242/8C	. . BOLT, 2 BA c'sk head, sense aerial insulator attachments to rib	18	-	33/20

A.P.101B-0417-3A

RADIO AND RADAR

Page MH5

RADIO COMPASS (ARI.5877)

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
R 10HB/6242884	E.G7.82.2871	CONNECTOR, ASSEMBLY, Q.D.1, FROM PLUG BREAK TO SENSE AERIAL PORT WING, RIBS 3 AND 4, GROUP (MOD. 4715)						1	—	B	33/27
	5E/3897	Consisting of:—									
	†	CABLE, unitersil 14						QR	—	C	33/25
R	EEAS.146/12	SLEEVE, 1" long						QR	—	—	33/21
R	10H/540014	SOCKET, coax fixed, type SR.2E						1	—	C	33/29
R	5X/9450380	TAG, ring tongue						1	—	C	33/30
R	5F/4342141	RAYCHEM TUBING, S.C.L. 1/4" grey						QR	—	C	33/32

A.P.101B-0417-3A

Page MJ1

RADIO AND RADAR

TACAN (ARI.18107/4)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R -	ALTS TO GA OF TACAN (EG7.82.5241)						-	-	
	(Mod 5466)								
-	TACAN, ARI.18107/4, INSTALLATION						-	-	34/1
	(EG7.82.127)								
	Spares for:-								
R RT220CARN21	. TRANS/RECEIVER (Pre Mod 5466)						1	-	34/5
R RT636ARN72	. TRANS/RECEIVER (Mod 5466)						1	-	
R 1LRU164A	. UNIT, control, type 7750 (Pre Mod 5466)						1	-	34/15
R 1LRU164E	. UNIT, control, type 9273A (Mod 5466)						1	-	
WTD143220	. UNIT, coupling, type 9546						1	-	34/10

RADIO AND RADAR

TACAN (ARI.18107/4)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	TACAN IN FRONT FUSELAGE, ASSEMBLY (EG7.82.129) Spares for:-	-	-	34/2
UG212C/U	. ADAPTER, angle, series HN	1	-	34/6
EG7.82.133	. CONNECTOR, No. 1, from pressure bulkhead to indicator type 9547 at pilot's panel	1	-	34/16
EG7.82.135	. CONNECTOR, No. 1A, from coupling unit type 9546 to pressure bulkhead	1	-	34/9
EG7.82.137	. CONNECTOR, No. 2, from pressure bulkhead to indicator type 9547 at navigator's panel (Pre-Mod.5466)	1	-	34/17
EG7.82.5469	. CONNECTOR, No. 2 (Mod.5466)	1	-	
EG7.82.139	. CONNECTOR, No. 2A, from coupling unit type 9546 to pressure bulkhead	1	-	34/8
R CS5411/14	. CONNECTOR, No. 3 (Mod.4926) (Pre-Mod.5466)	1	-	34/14
EG7.82.5471	. CONNECTOR, No. 3 (Mod.5466)	1	-	
EG7.82.143	. CONNECTOR, No. 3A, from transmitter receiver type RT220C to pressure bulkhead	1	-	34/4
EG7.82.145	. CONNECTOR, No. 4, from transmitter receiver type RT220C to coupling unit type 9546	1	-	34/7
EG7.82.147	. CONNECTOR, No. 5, from coupling unit type 9546 to transmitter receiver type RT220C and DC distribution box No. 2	1	-	34/11
EG7.82.149	. CONNECTOR, No. 6, from omni aerial type 1008 to transmitter receiver type RT220C	1	-	34/13
22139599	. WASHER, panel packing	3	-	34/18

A.P.101B—0417—3A

Page MJ3

RADIO AND RADAR
TACAN (ARI.18107/4)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R 10B/4280400 28D/1013172	—	TACAN IN CENTRE FUSELAGE,							—	—	—	34/3
	—	ASSEMBLY (E.G7.82.131)							—	—	—	34/12
	†	AERIAL, TACAN, INSTALLATION (E.G7.82.703)							1	—	A	34/19
	E.G7.82.795	AERIAL, omni, type 100B							1	L65	—	34/20
	AS.1242/5C	Block, packing							12	—	C	34/21
		Bolt, 2 BA c'sk head										

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	-	U.A.60 INTERCOM, ASSEMBLY (EG7.82.357) (Pre Mod 5466)	-	-	35/23
R	-	U.A.60, INTERCOM, ASSEMBLY (EG7.82.5217) (Mod 5466) Spares for:-	-	-	44/1
	UA6070	. AMPLIFIER	1	-	35/22
R	A691-5	. AMPLIFIER (Mod 5466)	1	-	44/2
R	UA6016/5F	. BOX, station, pilot's, navigator's and A.E.O's (Pre Mod 5466)	3	-	35/10
R	8-9992-683-0	. BOX, station TYPE UA6018-3F (Mod 5466)	2	-	44/3
R	8-9992-684-0	. BOX, station TYPE UA6118-1F (Mod 5466)	1	-	44/4
R	B47221-007-0	. BOX, distribution TYPE UA6042 (Mod 5466)	2	-	44/5
R	8-9992-686-0	. BOX, distribution: TYPE UA6147-1 (Mod 5466)	1	-	44/6
R	UA6043/7	. BOX, junction, inter-connection (Pre Mod 5466)	1	-	35/20
R	SC5411/9	. CONNECTOR, from TB3668/1 to PL10 (Mod 4926) (Pre Mod 5466)	1	-	35/41
	2/SC95437	. LABEL (Mod 4926)	3	-	35/42
R	8804-8102	. SWITCH, press to test	1	-	35/43
	AS10512A-7	. SWITCH, press to test	1	-	35/44
	-	. SWITCH, TRANSMIT, AEO's FOOT OPERATED, INSTALLATION (EG7.81.4047) (Mod 5438) Spares for:-	-	-	
	WB/UN/1146/S/5/B or HWB/UN/1146/S/5 /B	. . BLOCK, terminal	1	-	42/1
	UNIMINYVIN 20 AS3180/3B	. . CABLE . . CLIP, 'P'	QR 1	-	42/2 42/3
	AGS2001/B/1 A31/B16	Attaching parts for AS3180/3B:- . . Nut, stiff, 4 BA . . Screw, 4 BA cheese head	1 1	-	42/4 42/5
	AS3180/3B	. . CLIP, 'P'	2	-	42/6
	AGS2001/B/1 A31/B20 SP15/B	Attaching parts for AS3180/3B:- . . Nut, stiff, 4 BA . . Screw, 4 BA cheese head . . Washer	1 1 1	-	42/7 42/8 42/9
R	EG7.82.3025	. . CONNECTOR, UA60, No. 13 (Pre Mod 5466) Spares for:-	1	-	42/10
	UNIMINYVIN 20 419743 467-12-3S or 6432-1-A-12-3S or 6432-1-C-12 UKAN 9000-22-14P or 508-1-05372-121	. . . CABLE . . . INSERT, socket . . . NUT, jam . . . NUT, jam . . . NUT, sealing . . . PLUG, free, 19-way . . . PLUG, free, 19-way	QR 3 1 1 1 1	-	

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
508/2/05604/002	. . .	PLUG, contact	19	-	
508/2/04367	. . .	PLUG, filler	11	-	
508/2/05851/007	. . .	RING, anti-chafe	1	-	
508/2/15662	. . .	SLEEVE, packing	8	-	
EEAS146-6- 1/2"	. . .	SLEEVE	QR	-	
EEAS146-6- 1"	. . .	SLEEVE	QR	-	
EEAS146-12- 1/2"	. . .	SLEEVE	QR	-	
EEAS146-12- 1"	. . .	SLEEVE	QR	-	
EEAS146-20- 1/4"	. . .	SLEEVE	QR	-	
EEAS146-20- 1/2"	. . .	SLEEVE	QR	-	
EEAS146-20- 3/4"	. . .	SLEEVE	QR	-	
EEAS146-20- 1"	. . .	SLEEVE	QR	-	
HC294D	. . .	TAG, RT	1	-	
HC490	. . .	TAG, QR	3	-	
EG7.82.5523	. . .	CONNECTOR, UA60, No.13 (Mod 5466)	1	-	
EG7.82.3027	. . .	CONNECTOR, UA60, No.14 Spares for:-	1	-	42/11
UNIMINYVIN 20	. . .	CABLE	QR	-	
466-12-3-P-059	. . .	PLUG, free, straight	1	-	
or					
6432-IF-12-3P	. . .	PLUG, free, straight	1	-	
and 6432-D-12	. . .	CLAMP	1	-	
0641-12-1656	. . .	PLUG, pin	3	-	
EEAS146-12- 1"	. . .	SLEEVE	QR	-	
EEAS146-12- 1/2"	. . .	SLEEVE	QR	-	
EEAS146-20- 3/4"	. . .	SLEEVE	QR	-	
EEAS146-20- 1/4"	. . .	SLEEVE	QR	-	
HC294	. . .	TAG, RT	3	-	
AGS2007/B/1	. . .	NUT, anchor	3	-	42/12
508/2/05851/007	. . .	RING, anti-chafe	1	-	42/13
AS10512-M2	. . .	SHROUD	1	-	42/14
508/2/15662	. . .	SLEEVE, packing, green	8	-	42/15
EEAS146-20- 1/4"	. . .	SLEEVE	QR	-	42/16
EEAS146-20- 3/4"	. . .	SLEEVE	QR	-	42/17
YB6.82.671	. . .	SWITCH, feet, assembly	1	-	42/18
		Attaching parts for YB6.82.671:-			
A32/B20	. . .	Screw, 4 BA round head	3	-	42/19
AS10512E-4	. . .	SWITCH	1	-	42/20
HC294D	. . .	TAG, RT	6	-	42/21
HC294	. . .	TAG, RT	6	-	42/22
LKOB-HS-8	. . .	TIE, insulok, black	QR	-	42/23

A.P.101B-0417-3A

Page MK1B

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	—	U.A.60 INTERCOM IN FRONT FUSELAGE, ASSEMBLY (EG7.82.417) (Pre Mod 5466)	—	—	35/24
R	—	U.A.60 INTERCOM IN FRONT FUSELAGE, (EG7.82.5219) (Mod 5466) Spares for:—	—	—	44/7
	—	. AMPLIFIER, AND JUNCTION BOX, FRAMES 6 AND 7, INSTALLATION (EG7.82.1131) Spares for:—	—	—	35/7
	EG7.82.1135	. . ANGLE, assembly	2	L72	35/3
	EG7.82.915	. . LABEL, engraved	1	L72	35/1
	EG7.82.1133	. . PLATE, mounting, assembly Attaching parts for EG7.82.1133:—	1	L72	35/2
	AS1248/1C	. . Bolt, 2 BA mushroom head	6	—	35/4
R	—	. BLOCK TERMINAL, MIC/TEL, INSTALLATION (EG7.82.1201) (Pre Mod 5466) Spares for:—	—	—	35/6
	1240	. . BLOCK, terminal, type B, No. 1	6	—	35/5
	MARTIN BAKER A/MBEU/125EE	. . BRACKET, tel/mic Attaching parts for A/MBEU/125EE:—	2	—	35/18
	A25/1C	. . Bolt, 2 BA head	8	—	35/17
	AGS2001/C/1	. . Nut, stiff, 2 BA	8	—	35/16
	SP15/C	. . Washer, 2 BA plain	8	—	35/15
	EA3.82.53	. . PIECE, packing	2	LFS21	35/8
R	—	. BLOCK, TERMINAL, MIC/TEL AND OVERRIDE INSTALLATION (EG7.82.5653) (Mod 5466) Spares for:—	—	—	44/8
R	TYPE B No. 1	. . BLOCK, terminal Attaching parts:—	4	—	44/9
R	AGS2001/A/1	. . Nut, 6 BA	2	—	44/10
R	A33/A24	. . Screw, 6 BA, c'sk head	2	—	44/11
R	72541-030-0	. . BLOCK, terminal, 10-way Attaching parts:—	1	—	44/12
R	36765-502-0	. . Pillar, fixing	2	—	44/13
R	72541-025-0	. . BLOCK, terminal, 5-way Attaching parts:—	4	—	44/14
R	36765-502-0	. . Pillar, fixing	2	—	44/15
R	A/MBEU/125EE	. . BRACKET, Tel/Mic Attaching parts:—	2	—	44/16
R	A25/1C	. . Bolt, 2 BA	4	—	44/17
R	AGS2001/C/1-66	. . Nut, 2 BA	4	—	44/18
R	SP15/C	. . Washer	4	—	44/19

A.P.101B-0417-3A

Page MK2A

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

Part Number	Description						No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.82.5657	.	.	BRACKET				1	1.2mm-L164	44/20
R EG7.82.5659	.	.	BRACKET				1	1.2mm-L164	44/21
R 41851-830-0	.	.	COVER				1	—	44/22
R 41851-825-0	.	.	COVER				4	—	44/23
R AGS2007/B/1	.	.	NUT, anchor, 4 BA				8	—	44/24
R —	.	.	EARTH, POINT E35, E36 and E37				—	—	
			Consisting of:—						
R A54C	.	.	NUT, 2 BA				1	—	44/25
R AGS2001/C/4	.	.	NUT, stiff, 2 BA				1	—	44/26
R A43/C24	.	.	SCREW, 2 BA, cheese head				1	—	44/27
R SP25/C	.	.	WASHER				4	—	44/28
R EA3.82.59/1	.	.	CABLE, ASSEMBLY, RT1, FROM TERMINAL BOARD TO MIC/TEL AT PILOT'S SEAT, GROUP (Pre Mod 5466)				1	—	35/39
R EA3.82.131	.	.	CABLE, ASSEMBLY, RT22, FROM TERMINAL BOARD TO A.E.O's MIC/TEL				1	—	35/40
R EG7.82.5525	.	.	CONNECTOR, No.15 (Mod 5466)				1	—	
R EG7.82.5527	.	.	CONNECTOR, No.16 (Mod 5466)				1	—	
R EG7.82.5529	.	.	CONNECTOR, No.17 (Mod 5466)				1	—	
R EG7.82.5531	.	.	CONNECTOR, No.18 (Mod 5466)				1	—	
R EG7.82.5533	.	.	CONNECTOR, No.19 (Mod 5466)				1	—	
R EG7.82.5541	.	.	CONNECTOR, No.23 (Mod 5466)				1	—	
R EG7.82.5535	.	.	CONNECTOR, No.24 (Mod 5466)				1	—	
R EG7.82.5543	.	.	CONNECTOR, No.25 (Mod 5466)				1	—	
R EG7.82.5537	.	.	CONNECTOR, No.26 (Mod 5466)				1	—	
R EG7.82.5545	.	.	CONNECTOR, No.27 (Mod 5466)				1	—	
R EG7.82.5539	.	.	CONNECTOR, No.28 (Mod 5466)				1	—	
R EG7.82.5651	.	.	CABLE, assembly, RT20 (Mod 5466)				1	—	
R EG7.82.5655	.	.	CABLE, assembly, No.29 (Mod 5466)				1	—	
R EG7.82.5725	.	.	CONNECTOR, No.30 (Mod 5466)				1	—	
R EG7.82.5719	.	.	CONNECTOR, No.31 (Mod 5466)				1	—	
R EG7.82.5721	.	.	CONNECTOR, No.32 (Mod 5466)				1	—	
R EG7.82.5723	.	.	CONNECTOR, No.33 (Mod 5466)				1	—	

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

Part Number	Description 1 2 3 4 5 6	No. Off	Mati. Spec.	Plate No.

A.P.101B-0417-3A

Page MK3

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.607	. CONNECTOR, UA60, No.1, from pilot's station box to UA60 junction box socket	1	—	35/11
EG7.82.609	. CONNECTOR, UA60, No.2, between pilot's and navigator's station box	1	—	35/26
EG7.82.611	. CONNECTOR, UA60, No.3, between A.E.O's and navigator's station box	1	—	35/25
EG7.82.613	. CONNECTOR, UA60, No.4, from A.E.O's station box to UA60 junction box plug	1	—	35/12
EG7.82.615	. CONNECTOR, UA60, No.5, from UA60 junction box plug to JB14 and pressure bulkhead	1	—	35/14
R EG7.82.619	. CONNECTOR, UA60, No.6 from pilot's station box to pilot's tel/mic socket T/B pilot's pitot switch T/B and pilot's dimmer (Pre Mod 5466)	1	—	35/9
R EG7.82.621 or EG7.82.2909	. CONNECTOR, UA60, No.7, from navigator's station box to navigator's tel/mic socket T/B, navigator's dimmer and navigator's pitot switch (Pre Mod 5466)	1	—	35/27
R EG7.82.623	. CONNECTOR, UA60, No.8, from A.E.O's station box to A.E.O's tel/mic socket T/B, A.E.O's pitot switch and A.E.O's dimmer (Pre Mod 5466)	1	—	35/13
EG7.82.625	. CONNECTOR, UA60, No.9, from ground crew amplifier UA60 to UA60 junction box	1	—	35/21
R 1200-001	. RECORDER (DAVALL) (Mod 5466)	1	—	44/29
R 5905-99-0135501	. RESISTOR, 3K, Type MR6 (Mod 5466)	1	—	
R EEAS200	. RING, locking (Pre Mod 5466)	1	Nylon	35/36
R A31/C12	. SCREW, 2 BA cheese head (Mod 5466)	3	—	
R A32/C16	. SCREW, 2 BA round head (Mod 5466)	4	—	
R EEAS563	. SLEEVE, special (Pre Mod 5466)	1	Rubber	35/38
R 36161-506-0	. SPACER (Mod 5466)	1	—	
WT25432	. SOCKET, type 359	1	—	35/19
N.S.F.	. SWITCH, tumbler "press to transmit" at navigator's side table	1	—	35/37
R 8804/B102	. TAG, RT (Mod 5466)	2	—	
R HC294	. UNIT, interface (Mod 5466)	1	—	44/30
R SEM/CAN/0150	. WASHER (Mod 5466)	7	—	
R SP125/D				

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
	—	U.A.60 INTERCOM. IN CENTRE FUSELAGE ASSEMBLY (EG7.82.419) Spares for:—	—	—	36/9
R	1240	. BLOCK, terminal, 2-way type B	4	—	36/11
R	AGS2001/A/1	Attaching parts for 1240:—			
	A45/A20	. Nut, stiff, 6 BA	2	—	36/12
	SP47/A	. Screw, 6 BA c'sk head	2	—	36/13
		. Washer, 6 BA spring	2	—	36/14
R	WTA106590	. CONNECTOR, type 3570, for external intercom, starboard wheel bay	1	—	36/1
R		Attaching parts for WTA106590:—			
	A25/4C	. Bolt, 2 BA hex, head	4	—	36/2
	AGS2001/C/1	. Nut, stiff, 2 BA	4	—	36/4
	EA3.82.17	. Plate, doubling	1	L72	36/3
	EG7.82.617	. CONNECTOR, UA.60, No. 5C, from pressure bulkhead to tel/mic socket T/B, frame 18-19	1	—	36/10
	EG7.82.627	. CONNECTOR, UA.60, No. 10, from tel/mic socket T/B frame 18-19 to external I/C connector T/B, starboard wheel bay	1	—	36/15
	EG7.82.629	. CONNECTOR, UA.60, No. 11, from external I/C connector T/B, starboard wheel bay to tel/mic socket aft T/B, frame 25-26	1	—	36/16
	EG7.82.631	. CONNECTOR, UA.60, No. 12, from tel/mic socket aft T/B frame 25-26 to tel/mic socket, frame 29	1	—	36/17
	—	. SOCKET, TEL/MIC, AFT, INSTALLATION (EG7.82.817)	—	—	36/25
R	1240	. . BLOCK, terminal, type B, 2-way, No. 1	2	—	36/11
R		Attaching parts for 1240:—			
	AGS2001/A/1	. . Nut, stiff, 6 BA	4	—	36/12
	A33/A20	. . Screw, 6 BA c'sk head	4	—	36/22
R	WT25432	. . SOCKET, type 359	1	—	36/21
	—	. SOCKET, TEL/MIC, FORWARD, INSTALLATION (EG7.82.819) Spares for:—	—	—	36/26
R	1240	. . BLOCK, terminal, type B, 2-way, No. 1	2	—	36/11
R		Attaching parts for 1240:—			
	AGS2001/A/1	. . Nut, stiff, 6 BA	4	—	36/12
	A33/A28	. . Screw, 6 BA c'sk head	4	—	36/23
	EG7.82.841	. . PIECE, packing, socket mounting clips (Make from 32B/1250418)	1	BS3396	35/20
	EG7.82.843	. . PIECE, packing, terminal block mounting (Make from 32B/1250418)	2	BS3396	36/19
R	WT25432	. SOCKET, type 359	1	—	36/21

AP101B-0417-3A

Page MK5

RADIO AND RADAR

RADIO AND INTERCOM (U.A.60) (AR1.23099/7)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
	. SOCKET AND FAIRLEAD, ON REAR BOMB BAY BULKHEAD, FRAME 29, INSTALLATION (EG7.82.845) Spares for:—	—	—	36/27
R 1240	. . BLOCK, terminal, type B, 2-way No. 1	2	—	36/11
R	Attaching parts for 1240:—			
AGS2001/A/1	. . Nut, stiff, 6 BA	4	—	36/12
A33/A20	. . Screw, 6 BA c'sk head	4	—	36/22
SP15/A	. . Washer, 6 BA plain	4	—	36/18
EG7.82.847	. . FAIRLEAD, half	2	BS2966	36/6
	Attaching parts for EG7.82.847:—			
AGS2001/A/1	. . Nut, stiff, 6 BA	4	—	36/7
A31/A14	. . Screw, 6 BA cheese head	4	—	36/5
R WT25432	. . SOCKET, type 359	1	—	36/21
EEAS238/1/A	. . WASHER, 'D', clip attachment	3	L72	36/8
AS2305/025	. . TUBE, distance, clipping frame 19	1	—	36/24

A.P.101B-0417-3A

RADIO AND RADAR
U.H.F. INSTALLATION (ARI.23301/1) (ARI.23300)

R

R

R

R

R

R

R

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	GA OF TWIN PTR1751W UHF AND STANDBY UHF IN A/C (EG7.82.3031) (Mod 5428) (Pre Mod 5466) (Pre Mod 5543) (Pre Mod 5544)	—	—	37/1
—	GA OF TWIN PTR1751W UHF AND STANDBY UHF IN A/C (EG7.82.5981) (Mod 5466) (Pre Mod 5543) (Pre Mod 5544)	—	—	
—	GA OF TWIN PTR1751WW, UHF SYSTEM IN A/C (EG7.82.4053) (Mod 5543) (Mod 5544) Spares for:—	—	—	
CP191999	. BOX, inter-connecting (Mod 4926)	2	—	37/2
EG7.81.4043	. CABLE, assembly 2F135 (Mod 5428)	1	—	
630-1-43409	. PLATE, blanking (Mod 5428) (Service supply)	2	—	37/25
A34-3603-01	. PLUG-MUTING (Mod 5428) (Service supply)	2	—	37/26
—	. ROUTING AND CLIPPING No.1 AND No.2 T/R UNIT SUPPLY CABLES (EG7.82.6009) (Mod 5466) Spares for:—	—	—	
AS3181-4B	. . CLIP, "P" Attaching parts:—	6	—	37/27
A25-1B	. . Bolt, 4BA	1	—	37/28
AGS2001B1	. . Nut, stiff, 4BA	1	—	37/29
EEAS238-1A	. . Washer, "D"	1	—	37/30
PAN6483AA	. . RETAINER, cable	2	—	37/31
PAN6481B1-01B	. . TIE, cable	QR	—	37/32
630-1-37851-018	. TRANSCIVER-UHF, PTR1751W (Mod 5428) (Service supply) (Pre Mod 5543)	2	—	37/8
630-1-37851-118	. TRANSCIVER-UHF, PTR1751WW (Mod 5543)	2	—	
PV1748B	. TRAY, assembly (Mod 5428) (Service supply)	2	—	37/9
630-1-37854-010	. UNIT, control, PV1754L (Mod 5428) (Service supply) (Pre Mod 5544)	2	—	37/6
630-1-37854-018	. UNIT, control, PV1754W (Mod 5544)	2	—	
630-1-37846-001	. UNIT, interface, PV1746B (Mod 5428) (Service supply) (Pre Mod 5543)	2	—	37/7
630-1-37846-101	. UNIT, interface, PV1746BB (Mod 5543)	2	—	

RADIO AND RADAR

U.H.F. INSTALLATION (ARI.18124/1)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
—	U.H.F. IN CENTRE FUSELAGE, ASSEMBLY (EG7.82.107)						—	—	37/5
	Spares for:—								
CHELTON	. AERIAL, U.H.F., type 16-1 (Mod.4926) (For attaching parts see Drawing SC95400) (SRIM 3668)						1	—	
EB6.82.1417	. . PLATE, mounting						1	L72	37/22
CHELTON	. AERIAL, U.H.F., type 16-1 (Mod.4926) (For attaching parts see Drawing SC95400) (SRIM 3668)						1	—	
108/2222399									
EG7.82.603	. CONNECTOR, U.H.F. 7, from magnetic relay type 1741 to upper aerial						1	—	37/4

RADIO AND RADAR

U.H.F. INSTALLATION (ARI.23301/1)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	U.H.F. IN FRONT FUSELAGE, ASSEMBLY (EG7.82.3035) (Mod 5428) (Pre Mod 5466)	—	—	38/1
—	U.H.F. IN FRONT FUSELAGE (EG7.82.5983) (Mod 5466) Spares for:—	—	—	
—	. BOX, INTER-CONNECTING AND MUTING BIAS UNIT, INSTALLATION (EG7.82.307) Spares for:—	—	—	38/9
AS2654	. . BLOCK, connector	2	—	38/15
703-1-00232	. . BLOCK, terminal, 3-way	1	—	38/16
5E/9467424	. . CABLE, uninyvin 20	QR	—	38/18
AS2655	. . COVER, connector block	2	—	38/21
703-1-00263	. . COVER, terminal block	1	—	38/22
AS2672	. . FERRULE, 4 amp	2	—	38/24
AS2696	. . LUG, adapter, 2-way, 19 amp	1	—	38/20
EG7.82.551	. . PANEL, assembly Attaching parts for EG7.82.551:—	1	L72	38/13
AS1248/1/2C	. . Bolt, 2 BA mushroom head	6	—	38/12
Z28426	. . PILLAR, terminal block fixing	2	—	38/19
M.A.M.	. . SLEEVE, 3/8" long, 3 mm i/d, pink, grade CXH	QR	—	38/23
EEAS146/20	. . SLEEVE, 3/4" long	QR	—	38/17
HC490	. . TAG, quick release	1	—	38/14
EG7.82.121	. CABLE, ASSEMBLY, RT.430, FROM TERMINAL BLOCK, PILOT'S FIXED PANEL TO TERMINAL BLOCK, V.H.F. EQUIPMENT PANEL, GROUP Consisting of:—	1	—	38/7
5E/9467424	. . CABLE, uninyvin 20	QR	—	
EEAS146/20	. . SLEEVE, 3/4" long, pink	QR	—	
EEAS146/14	. . SLEEVE, 1.1/2" long, pink	QR	—	
HC490	. . TAG, quick release	4	—	
EG7.82.123	. CABLE, ASSEMBLY, RT.431, FROM JUNCTION BOX UA.6043 TO INTER-CONNECTING BOX AND TERMINAL BLOCK, V.H.F. EQUIPMENT PANEL, GROUP (Pre Mod 5466) Consisting of:—	1	—	38/8
5E/1062269	. . CABLE, uninyvinmetsheath 20	QR	—	
5E/9467424	. . CABLE, uninyvin 20	QR	—	
33H/9130065	. . COMPOUND, sealing, bostik 771	QR	—	
508/1/07777/001	. . CLAMP, cable	1	—	
508/2/07705/300	. . GASKET, outlet	1	—	

RADIO AND RADAR
U.H.F. INSTALLATION (ARI.23301/1)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
508/2/07648/001 NO.671	. . . OUTLET, angle	1	—	
	. . . PAINT, black, No.671	QR	BS381C	
508/1/07023/220	. . . PLUG, free, Mk.7, 6-way	1	—	
508/2/07709/300	. . . RING, sealing (Pre SAS4745)	1	—	
508/2/07708/300	. . . RING, sealing (SAS4745)	1	—	
508/2/07752/007	. . . RING, thrust (SAS4745)	1	—	
EEAS146/20	. . . SLEEVE, 3/4" long	QR	—	
EEAS146/4	. . . SLEEVE, 1" long	QR	—	
EEAS146/12	. . . SLEEVE, 1" long	QR	—	
EEAS146/4	. . . SLEEVE, 1.1/2" long	QR	—	
CANNON				
MC11E-10-6SN	. . . SOCKET	1	—	
NY18007A	. . . STRAP, nylon	QR	—	
NY3255	. . . STUD, nylon	QR	—	
HC490	. . . TAG, quick release	1	—	
SCL-3-16	. . . TUBING, S.C.L., 3/16" grey	QR	—	
5K/	. . . WIRE, tinned copper, 32 SWG	QR	—	
EG7.82.5521	. . . CABLE, ASSEMBLY, RT.431 (Mod.5466)	1	—	
EG7.82.957	. . . CONNECTOR, U.H.F.1, from pilot's fixed panel plug break to inter-connecting box ARC.52	1	—	38/3
EG7.82.111	. . . CONNECTOR, U.H.F.2, from control unit, pilot's fixed panel to inter-connecting box ARC.52	1	—	38/2
EG7.82.113	. . . CONNECTOR, U.H.F.3, from transmitter receiver ARC.52 to pressure bulkhead	1	—	38/4
EG7.82.115	. . . CONNECTOR, U.H.F.3A, from pressure bulkhead to magnetic relay, type 1741	1	—	38/5
EG7.82.117	. . . CONNECTOR, U.H.F.4, from transmitter receiver ARC.52 to inter-connecting box	1	—	38/11
EG7.82.959	. . . CONNECTOR, U.H.F.5, from inter-connecting box to muting bias unit	1	—	38/10
EG7.82.605	. . . CONNECTOR, U.H.F.6, from magnetic relay, type 1741, to lower aerial	1	—	38/6
CS5411/6 or	. . . CONNECTOR (Mod.4926)	1	—	
EG7.82.2907	. . . CABLE, assembly, U.H.F.2/2 (Pre Mod.5466)	1	—	
EG7.82.5547	. . . CABLE, assembly, U.H.F.2/2 (Mod.5466)	1	—	
EG7.82.5965	. . . CABLE, assembly, U.H.F.9 (Mod.5466)	1	—	
EG7.82.5967	. . . CABLE, assembly, U.H.F.10 (Mod.5466)	1	—	
EG7.82.5969	. . . CABLE, assembly, U.H.F.12 (Mod.5466)	1	—	
CS5411/11	. . . CONNECTOR (Mod.4926)	1	—	
CS5411/2	. . . CONNECTOR (Mod.4926)	1	—	
CS5411/4	. . . CONNECTOR (Mod.4926)	1	—	
CS5411/3	. . . CONNECTOR (Mod.4926)	1	—	
CS5411/5	. . . CONNECTOR (Mod.4926)	1	—	
CS5411/1	. . . CONNECTOR (Mod.4926)	1	—	
CS5411/10	. . . CONNECTOR (Mod.4926)	1	—	

AP101B-0417-3A

RADIO AND RADAR

V.H.F. INSTALLATION ARI.23288/3

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
-	V.H.F. IN AIRCRAFT, ASSEMBLY (EG7.82.3033) (Mod 5428) Spares for:—						-	-	39/2
R 10AD/9444583	. BOX, inter-connecting, type E.J.B.21A.3 (Pre-Mod 5504)						1	-	39/11
R A37-0557-01	. BOX, inter-connecting (Mod 5504)						1	-	
AA1209-1	. PLUG, dummy (Mod 5428) (Service supply)						1	-	39/9
AA1206-1	. TRAY, mounting (Mod 5428) (Service supply)						1	-	39/24
AA1201-2	. TRANSMITTER-RECEIVER (Mod 5428) (Service supply)						1	-	39/10
AA1202-2	. UNIT, control (Mod 5428) (Service supply)						1	-	39/5

RADIO AND RADAR

V.H.F. INSTALLATION (ARI.23117/2)

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
—		V.H.F. IN FRONT FUSELAGE, ASSEMBLY (EG7.82.405) Spares for:—	—	—	39/1
—		. BONDING OF REDUNDANT AERIALS, ASSEMBLY (EG7.82.2379) Spares for:—	—	—	39/6
EG7.82.2381		. . BRACKET, connector Attaching parts for EG7.82.2381:—	2	BSS265	39/20
4101/8/1/2		. . Screw, self-tapping, round head	4	—	39/23
FILMS & EQUIP.		. . COVER, code R.F.C.E., CAT. No. DC.239	2	—	39/22
EG7.82.2359		. . LEAD, bonding, assembly	2	—	39/15
10H/4306905		. . SOCKET, type 684	2	—	39/17
EC4.82.563		. . WASHER, bonding	2	—	39/21
EA6.82.73		. . WASHER	2	—	39/19
EG7.82.459		. CONNECTOR, V.H.F.1, from junction box type M.15 to control unit	1	—	39/7
EG7.82.461		. CONNECTOR, V.H.F.2, from junction box type M.15 to UA.6043 junction box	1	—	39/8
EG7.82.463		. CONNECTOR, V.H.F.3, from junction box type M.15 to pressure bulkhead	1	—	39/12
—		. TRAY, MOUNTING, INSTALLATION (EG7.82.479) Consisting of:—	—	—	39/18
10AJ/9478301		. . TRAY, mounting, V.H.F. transmitter receiver Attaching parts for 10AJ/9478301:—	1	—	39/24
A25/2C		. . Bolt, 2 BA hex. head	16	—	39/25
AGS2001/C/1		. . Nut, stiff, 2 BA	16	—	39/27
SP15/C		. . Washer, 2 BA plain	16	—	39/26

A.P.101B-0417-3A

Page MM3

RADIO AND RADAR
V.H.F. INSTALLATION (ARI.23117/2)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index	
		1	2	3	4	5	6	7					
R	10B/1037196	140/LRU-67C	V.H.F. IN CENTRE FUSELAGE, ASSEMBLY							—	—	—	39/3
			(E.G.7.82.407) Spares for:—										
	28D/9709461	AS.1242/3C	AERIAL, V.H.F., IN CENTRE FUSELAGE,							—	—	—	39/13
	10HB/9557319	E.G.7.82.465	INSTALLATION (E.G.7.82.705) Consisting of:—										
			AERIAL, V.H.F.							1	—	A	39/14
			Attaching parts for 140/LRU-67C:—										
			Bolt, 2 BA c'sk head							10	—	C	39/16
			CONNECTOR, V.H.F. 3A, from pressure bulkhead to V.H.F. aerial							1	—	B	39/4

A.P.101B-0417-3A

Page MN1

RADIO AND RADAR

V.O.R./I.L.S. INSTALLATION (ARI.23118)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R -	V.O.R./I.L.S. INSTALLATION (EG7.82.355) (Pre Mod 5466)	-	-	40/2
R -	V.O.R./I.L.S. INSTALLATION (EG7.82.5231) (Mod 5466)	-	-	
	Spares for:-			
10AD/4309259	. BOX, interconnecting, type M.7 (Pre Mod 5251)	1	-	40/8
EJ821B-1	. BOX, interconnecting, type M7A (Mod 5251)	1	-	
10AD/4309260	. BOX, marker backplate junction, type M.8	1	-	40/7
10K/4704436	. PACK, power, V.H.F. receiver	1	-	40/12
10K/4704434	. PACK, power, 'GLIDE SLOPE', receiver	1	-	40/14
10K/4704435	. PACK, power, 'MARKER' receiver	1	-	40/10
10D/9702192	. RECEIVER, 'GLIDE SLOPE' type 6404M (Pre Mod 5251)	1	-	40/13
W10458-ED- B ISS 5	. RECEIVER, 'GLIDE SLOPE', type 6404ME (Mod 5251)	1	-	
10D/9704803	. RECEIVER, V.H.F. type 6401M	1	-	40/11
10D/9702193	. RECEIVER, 'MARKER', type 6403M	1	-	40/9
10W0135710	. RESISTOR, 33 ohms, pattern R02-B (SAS 4745)	3	-	
10L/9702196	. UNIT, control, type 7430M	1	-	40/3
10D/9702194	. UNIT, navigation, type 6402MA	1	-	40/15

RADIO AND RADAR

V.O.R./I.L.S. INSTALLATION (ARI.23118)

Part Number	Description					No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5			
-	V.O.R./I.L.S. IN FRONT FUSELAGE, ASSEMBLY (EG7.82.409) (Pre-Mod.5466)					-	-	40/1
-	V.O.R./I.L.S. IN FRONT FUSELAGE, ASSEMBLY (EG7.82.5231) (Mod.5466)					-	-	
	Spares for:-							
EG7.82.1433	. CONNECTOR, V.O.R./I.L.S. 1, from inter-connection Junction box to radio fuse and relay box and V.O.R./I.L.S. indicator RL-7003-184B					1	-	40/18
EG7.82.1435	. CONNECTOR, V.O.R./I.L.S. 2, from radio fuse and relay box and inter-connection junction box to G.4B master indicator C.L. type E					1	-	40/19
EG7.82.1437	. CONNECTOR, V.O.R./I.L.S. 3, from radio fuse and relay box to navigator's radio magnetic indicator					1	-	40/20
EG7.82.1439	. CONNECTOR, V.O.R./I.L.S. 4, from radio fuse and relay box to pilot's radio magnetic indicator					1	-	40/17
EG7.82.1441	. CONNECTOR, V.O.R./I.L.S. 5, from inter-connection junction box to navigation control unit type 7430-M and V.O.R./I.L.S. voice range selector switch panel (Pre-Mod.5466)					1	-	40/4
EG7.82.5513	. CONNECTOR, V.O.R./I.L.S.5 (Mod.5466)					1	-	
CS5411/12	. CONNECTOR (Mod.4926) (Pre-Mod.5466)					1	-	40/6
EG7.82.5515	. CONNECTOR, V.O.R./I.L.S.6 (Mod.5466)					1	-	
EG7.82.1445	. CONNECTOR, V.O.R./I.L.S.7, from marker inter-connection junction box to UA.6043/7 junction box (Pre-Mod.5466)					1	-	40/5
EG7.82.1447	. CONNECTOR, V.O.R./I.L.S.8, from marker inter-connection junction box to pilot's flying panel					1	-	40/16
EG7.82.1449	. CONNECTOR, V.O.R./I.L.S.9, from inter-connection junction box to pressure bulkhead					1	-	40/21
EG7.82.1451	. CONNECTOR, V.O.R./I.L.S.10, from marker junction box to pressure bulkhead					1	-	40/23
EG7.82.1453	. CONNECTOR, V.O.R./I.L.S.11, from inter-connection junction box to pressure bulkhead					1	-	40/22
10W/0135473	. RESISTOR, style R030, 200 ohms					1	-	
10W/0128476	. RESISTOR, style R030, 240 ohms					1	-	
10W/0135483	. RESISTOR, style R030, 510 ohms					2	-	
-	. TRAY, MOUNTING, V.O.R./I.L.S. INSTALLATION (EG7.82.387)					-	-	40/24
	Spares for:-							
	. . TRAY, MOUNTING, V.O.R./I.L.S. TO PLATFORM, ASSEMBLY (EG7.82.389)					-	-	40/26
	Consisting of:-							
EG7.82.391	. . . PLATFORM, MOUNTING, ASSEMBLY					1	-	40/31
	Consisting of:-							
EG7.82.367	 MEMBER, channel, assembly					2	L72	40/32

A.P.101B-0417-3A

Page MN3

RADIO AND RADAR
V.O.R./I.L.S. INSTALLATION (ARI.23118)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R	10D/4309262	E.G7.82.371						MEMBER, channel, assembly	1	L72	—	40/29
		E.G7.82.375						MEMBER, channel, assembly	1	L72	—	40/33
		ELLIOT EMT/21C						TRAY, mounting, type M35	1	—	B	40/25
R	28D/1011029 28W/9419405 10D/4309263	A.25/1E SP.15/E ELLIOT EMT/21B	Attaching parts for EMT/21C:—									
			Bolt, 1/4" BSF hex. head							4	—	C 40/28
			Washer, 1/4" BSF plain							4	—	C 40/27
			TRAY, mounting, type M.36							1	—	B 40/30
			Attaching parts for EMT/21B:—									
			Bolt, 1/4" BSF hex. head							4	—	C 40/28
			Washer, 1/4" BSF plain							4	—	C 40/27

RADIO AND RADAR
V.O.R./I.L.S. INSTALLATION (ARI.23118)

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
	—	V.O.R./I.L.S. IN CENTRE FUSELAGE, ASSEMBLY (E.G7.82.411)						—	—	—	41/22
		Spares for:—									
10HB/9557208	E.G7.82.895	CONNECTOR, I.L.S.11A, from pressure bulkhead to frame 29 bulkhead						1	—	B	41/20
10HB/9557211	E.G7.82.899	CONNECTOR, I.L.S.10A, from pressure bulkhead to marker aerial, starboard wing						1	—	B	41/21
10HB/9557227	E.G7.82.900	CONNECTOR, I.L.S.9A, from pressure bulkhead to starboard wing root						1	—	B	41/19

V.O.R./I.L.S. INSTALLATION (ARI.23118)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	-	V.O.R./I.L.S. IN REAR FUSELAGE, AND TAIL UNIT, ASSEMBLY (E.G7.82.413) Spares for:-							-	-	-	41/17
	-	AERIALS, V.O.R./I.L.S. IN FIN, INSTALLATION (E.G7.82.707) Consisting of:-							-	-	-	41/27
108/9570378	140/LRU/A99A	AERIAL, "localiser" Attaching parts for 140/LRU/A99A:-							2	-	A	41/25
28DU/9480272	A173/4D	Bolt; 10 UNF c'sk head							12	-	C	41/26
28DU/9480273	A173/5D	Bolt; 10 UNF c'sk head							8	-	C	41/24
26DK/4716	NAT. PLASTICS X.114	EXTRUSION, section, P.V.C.							QR	-	C	41/18
42984	E.G7.82.809	FAIRLEAD, assembly Attaching parts for E.G7.82.809:-							1	-	C	41/31
28D/1008149	A25/2B	Bolt; 4 BA hex. head							4	-	C	41/30
R 10AD/1078789	133/LRU/14A	UNIT, balance Attaching parts for 133/LRU/14A:-							1	-	C	41/29
28D/1010658	A25/1B	Bolt; 4 BA hex. head							4	-	C	41/28
10HB/9557209	E.G7.82.896	CONNECTOR, I.L.S.11B, from frame 29 bulkhead plug to balance unit							1	-	B	41/23
10HB/9557210	E.G7.82.897	CONNECTOR, I.L.S.11C, from balance unit to localiser aerial							2	-	B	41/32

RADIO AND RADAR
V.O.R./I.L.S. INSTALLATION (ARI.23118)

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Ct. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	V.O.R./I.L.S. IN STARBOARD WING, ASSEMBLY							—	—	—	41/12
	—	(E.G7.82.415)							—	—	—	41/6
	—	Spares for:—							—	—	—	41/6
	—	AERIAL, MARKER, INSTALLATION							—	—	—	41/6
	—	(E.A3.82.5329)							—	—	—	41/6
	—	Consisting of:—							—	—	—	41/6
R 10B/4697308	†	AERIAL, marker, type 237							1	—	A	41/8
		Attaching parts for 10B/4697308:—							—	—	—	41/8
28D/1214297	AS.1242/ 1/2B	Bolt, 4 BA c'sk head							4	—	C	41/7
	—	AERIAL, GLIDE PATH, INSTALLATION							—	—	—	41/5
	—	(E.A3.82.5331)							—	—	—	41/5
	—	Consisting of:—							—	—	—	41/5
R 10B/4709699	†	AERIAL, glide path, type 238							1	—	A	41/1
		Attaching parts for 10B/4709699:—							—	—	—	41/1
28D/9133011	A25/2C	Bolt, 2 BA hex. head							10	—	C	41/2
28S/9148382	A45/A6	Screw, 6 BA c'sk head							2	—	C	41/4
28W/9419475	SP15/C	Washer, 2 BA plain							10	—	C	41/3
10HB/9557228	E.G7.82.901	CONNECTOR, I.L.S.15, from starboard wing root to							1	—	B	41/16
		inner wing rib 6 (Identical to connector							—	—	—	41/16
		type D267/30A/R10 Ref. 10HB/49)							—	—	—	41/16
10HB/9557229	E.G7.82.902	CONNECTOR, I.L.S.16, from inner wing rib 6 to							1	—	B	41/11
		outer wing rib 2 (Identical to connector							—	—	—	41/11
		type D273/30A/R2 Ref. 10HB/50)							—	—	—	41/11
10HB/9557230	E.G7.82.903	CONNECTOR, I.L.S.17, from outer wing rib 2 to							1	—	B	41/9
		glide path aerial							—	—	—	41/9
	—	WIRING, AT BREAK ON INNER WING, RIB 6,							—	—	—	41/14
	—	ASSEMBLY (E.A3.82.5312)							—	—	—	41/14
	—	Spares for:—							—	—	—	41/14
R 10H/0540103	†	PLUG, bulkhead, type 757							1	—	B	41/15
	—	WIRING, AT BREAK ON OUTER WING RIB 2,							—	—	—	41/13
	—	ASSEMBLY (E.A3.82.5314)							—	—	—	41/13
	—	Spares for:—							—	—	—	41/13
R 10H/0540103	†	PLUG, bulkhead, type 757							1	—	B	41/10

A.P.101B-0417-3A

Page MP1

RADIO AND RADAR
SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	GA OF SYLVANIA COMMS JAMMER (ARI.23362) (EG7.82.5245) (Mod.5466) Spares for:—	—	—	45/1
57125	. ADAPTER	1	—	
UG578U	. ADAPTER, straight	1	—	45/2
02-1278104-1	. AMPLIFIER, RF Power Spares for:—	1	—	45/3
R EBO13509	. . TRAY	1	—	45/3A
F1-30	. ATTENUATOR	1	—	45/4
F1-60	. ATTENUATOR	1	—	45/5
02-1279600-1	. CONTROLLER	1	—	45/6
02-1278108-1	. EXCITER Spares for:—	1	—	45/7
404-50L-1DPX2-1	. . TRAY Attaching parts for 02-1278108-1:—	1	—	45/8
A25/4C	. Bolt, 2 BA	16	—	45/9
AS3360E6E	. LEAD, bonding Attaching parts:—	1	—	45/10
A25/2E	. Bolt, 1/4" 8SF	1	—	45/11
SP122/E	. Washer	1	—	45/12
02-1278109-1	. PROCESSOR	1	—	45/13
02-1278105-1	. RECEIVER 1 AND 2 Spares for:—	RF	—	45/14
R SR2020-4	. . RECEIVER	2	—	45/14A
R PS2020-4	. . UNIT, power supply	1	—	45/14B
ZFSC2-1W	. SPLITTER	1	—	45/15
D2123Q1-OS	. SWITCH 2	1	—	45/16

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R -	GA OF SYLVANIA COMMS JAMMER IN FRONT	-	-	
R	FUSELAGE (EG7.82.5247)			
R	(Mod 5466)			
R	Spares for:-			
R EG7.82.5467	. CABLE, assembly, SCJ1	1	-	
R EG7.82.5555	. CABLE, assembly, SCJ2	1	-	
R EG7.82.5559	. CABLE, assembly, SCJ21	1	-	

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R -	GA OF SYLVANIA COMMS JAMMER IN CENTRE FUSELAGE (EG7.82.5249) (Mod 5466) Spares for:-						-	-	46/1
R 72541-025-0	. BLOCK, terminal						2	-	46/2
R 36765-502-0	Attaching parts:- . Pillar, fixing						2	-	46/3
R EG7.82.5865	. BRACKET (Make from EEDX90) Attaching parts:-						1	-	46/5
R A25/2C	. Bolt, 2 BA						2	-	46/6
R AGS2001/C/1-66	. Nut, 2 BA						2	-	46/7
R SP124/D	. Washer						2	-	46/8
R EG7.82.5557	. CABLE, assembly, SCJ2A						1	-	
R EG7.82.5549	. CABLE, assembly, SCJ8						1	-	
R EG7.82.5551	. CABLE, assembly, SCJ9						1	-	
R EG7.82.5553	. CABLE, assembly, SCJ10						1	-	
R EG7.82.5615	. CABLE, assembly, SCJ11						1	-	
R EG7.82.5491	. CABLE, assembly, SCJ12						1	-	
R EG7.82.5283	. CABLE, assembly, SCJ13						1	-	
R EG7.82.5493	. CABLE, assembly, SCJ15						1	-	
R EG7.82.5495	. CABLE, assembly, SCJ16						1	-	
R EG7.82.5499	. CABLE, assembly, SCJ18						1	-	
R EG7.82.5501	. CABLE, assembly, SCJ19						1	-	
R EG7.82.5503	. CABLE, assembly, SCJ20						1	-	
R EG7.82.5561	. CABLE, assembly, SCJ21A						1	-	
R EG7.82.5617	. CABLE, assembly, SCJ22						1	-	
R EG7.82.5621	. CABLE, assembly, SCJ24						1	-	
R EG7.82.5619	. CABLE, assembly, SCJ23						1	-	
R AGS2080/12	. CLIP, "P"						1	-	46/9
R A25/1C	Attaching parts:- . Bolt, 2 BA						1	-	46/10
R AGS2001/C/1-66	. Nut, 2 BA						1	-	46/11
R SP124/D	. Washer						1	-	46/12
R 41851-825-0	. COVER						2	-	46/13
R -	. EQUIPMENT FRAME ASSEMBLY (EG7.82.5077) (Mod 5466) Spares for:-						-	-	46/14
R EG7.82.5109	. . . ANGLE						1	1.2mm-L164	46/15
R EG7.82.5110	. . . ANGLE						1	1.2mm-L164	46/16
R EG7.11.5239	. . . CHANNEL, assembly						2	-	46/17
R EG7.11.199	. . . BLOCK						4	-	46/18
R EG7.11.198	. . . BLOCK, bearing						2	L65	46/19
R EG7.11.197	. . . BLOCK, bearing						2	L65	46/20

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
R EG7.11.189	. . .	BRACKET, 18 SWG	1	L73	46/21
R EG7.11.191	. . .	BRACKET, 18 SWG	1	L73	46/22
R EG7.11.981	. . .	CHANNEL, assembly	1	—	46/23
		Spares for:—			
R EG7.11.187	. . .	CHANNEL, 18 SWG	1	L73	46/24
R EG7.11.193	. . .	PIN	2	—	46/25
R EG7.11.201	. . .	PIN, locating	1	—	46/26
		Attaching parts:—			
R AGS2001/E/1-66	. . .	Nut, stiff, 1/4"	1	—	46/27
R SP13/E	. . .	Washer	1	—	46/28
R EG7.11.195	. . .	ROLLER	2	—	46/29
		Attaching parts for EG7.11.5239:—			
R A25/1C	. .	Bolt, 2 BA	4	—	46/30
R AGS2001/C/1-66	. .	Nut, stiff, 2 BA	4	—	46/31
R SP122/D	. .	Washer	4	—	46/32
R EG7.82.5889	. .	LABEL	1	—	46/33
R EG7.82.5081	. .	PACKING, (LFS21 x 1/8" thick)	1	—	46/34
		Attaching parts:—			
R AS1242/2C	. .	Bolt, 2 BA, c'sk head	4	—	46/35
R AGS2001/C/1-66	. .	Nut, stiff, 2 BA	4	—	46/36
R SP122/D	. .	Washer	4	—	46/37
R EG7.82.5079	. .	TRAY	1	1.2mm-L164	46/38
R 77522-315-0	. .	LINK, 5-way	1	—	
R 77522-314-0	. .	LINK, 4-way	1	—	
R AGS2007/B/1	. .	NUT, anchor, 4 BA	4	—	46/39
R	. .	EARTH POINT, E16			
		Consisting of:—			
R A54/C	. .	NUT, 2 BA, thin	2	—	46/40
R AGS2001/C/4	. .	NUT, stiff, 2 BA	1	—	46/41
R A43/C40	. .	SCREW, 2 BA, cheese head	1	—	46/42
R SP124/D	. .	WASHER	2	—	46/43
R SP25/C	. .	WASHER	2	—	46/44
R —	. .	INSTALLATION, PORT WING ROOT	—	—	47/1
		FAIRLEAD (EG7.11.5201)			
		(Mod 5466)			
		Spares for:—			
R EG7.82.5305	. .	FAIRLEAD, half	2	—	47/2
		Attaching parts:—			
R A25/3C	. .	Bolt, 2 BA	2	—	47/3
R AGS2002/C/1	. .	Nut, stiff, 2 BA	2	—	47/4
R SP13/C	. .	Washer	2	—	47/5

A.P.101B-0417-3A

Page MP5

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	. INSTALLATION, STARBOARD WING ROOT DOUBLER AND FAIRLEAD (EG7.11.5203) (Mod 5466). Applicable to aircraft WD955 only. Spares for:—	—	—	47/6
R	EG7.81.5199	. . FAIRLEAD, half Attaching parts:—	2	—	47/7
R	A25/3C	. . Bolt, 2 BA	2	—	47/8
R	AGS2001/C/1-66	. . Nut, stiff, 2 BA	2	—	47/9
R	SP13/C	. . Washer	2	—	47/10
R	EG7.11.5241	. . PLATE, doubling, 14 SWG	1	L165	47/11
R	—	. INSTALLATION, BOMB DOOR TRACK BRACKET (EG7.11.5207) (Mod 5466) Spares for:—	—	—	47/12
R	EG7.11.5209	. . BRACKET	1	1.6mm-L164	47/13
R	AGS2081/12	. . CLIP, "P" Attaching parts:—	1	—	47/14
R	A25/2C	. . Bolt, 2 BA	1	—	47/15
R	AGS2001/C/1-66	. . Nut, stiff, 2 BA	1	—	47/16
R	SP13/C	. . Washer	2	—	47/17
R	—	. INSTALLATION OF EQUIPMENT STRUCTURE, PACK BAY FORWARD (EG7.11.5113) (Mod 5466) Spares for:—	—	—	48/1
R	A25/2E	. . BOLT, 1/4" BSF	2	—	48/2
R	—	. . INSTALLATION of RF Exciter equipment mounting structure, pack bay (EG7.11.5031) Spares for:—	—	—	48/3
R	EG7.11.5077	. . . CHANNEL, mounting (Drilled) Spares for:—	1	—	48/4
R	EG7.11.5081	 CHANNEL, mounting (Blank)	1	1.6mm-L164	48/5
R	EG7.11.5079	. . . CHANNEL, mounting (Drilled) Spares for:—	1	—	48/6
R	EG7.11.5081	 CHANNEL, mounting (Blank)	1	1.6mm-L164	48/7
R	AGS2007/C/1	. . . NUT, anchor, 2 BA	16	—	48/8
R	AGS2007/E/1	. . . NUT, anchor, 1/4" BSF	1	—	48/9
R	EG7.11.5149	. . . PACKING	2	1.6mm-L164	48/10
R	AS4574/1	. . . PACKING	4	—	48/11

A.P.101B-0417-3A

Page MP7

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	EG7.11.589	. . . BRACKET, 18 SWG	1	L73	50/6
R	EG7.11.583	. . . CHANNEL, 18 SWG	1	L73	50/7
R		. . . EARTH STRAP (Supplied with processor)			
		Attaching parts:—			
R	A25/2C	. . . Bolt, 2 BA	1	—	50/8
R	SP15/C	. . . Washer	1	—	50/9
R	AGS2001/C/1-66	. . . NUT, stiff, 2 BA	3	—	50/10
R	EG7.11.5033	. . . PACKING	1	1.6mm-L164	50/11
R	A415	. . . PIN, pip	1	—	50/12
R	EG7.11.591	. . . PLATE, 18 SWG	1	L73	50/13
R	EG7.11.585	. . . STRIP, 18 SWG	1	L73	50/14
R	SP122/D	. . . WASHER	3	—	50/15
R	EG7.82.5889	. . . LABEL	1	—	48/12
R	EG7.82.5887	. . . LABEL	1	—	48/13
R	EG7.82.5881	. . . LABEL	1	—	48/14
R	EG7.82.5883	. . . LABEL	1	—	48/15
R	EG7.82.5879	. . . LABEL	1	—	48/16
R	AGS2097E9E	. . . LEAD, bonding	1	—	48/17
R	AGS2097E12E	. . . LEAD, bonding	1	—	48/18
R	AGS2097E18E	. . . LEAD, bonding	1	—	48/19
R	21FAC420	. . . NUT, stiff, 1/4", 20 UNC	4	—	48/20
R	SP122/E	. . . WASHER, 1/4" BSF	2	—	48/21
R	—	. . . INSTALLATION of ARI.23562 power amplifier and mounting in pack bay (EG7.82.5013) (Mod 5466) Spares for:—	—	—	51/1
R	EG7.82.5053	. . . CHANNEL, assembly, LH	1	—	51/2
R	EG7.82.5054	. . . CHANNEL, assembly, RH Spares for:—	1	—	51/3
R	EG7.82.5051	. . . ANGLE, L.H.	1	1.2mm-L165	51/4
R	EG7.82.5052	. . . ANGLE, R.H.	1	1.2mm-L165	51/5
R	EG7.82.5057	. . . ANGLE, L.H.	1	1.2mm-L165	51/6
R	EG7.82.5058	. . . ANGLE, R.H.	1	1.2mm-L165	51/7
R	EG7.82.5059	. . . BLOCK, bearing, 0.38" thick	4	L65	51/8
R	EG7.82.5061	. . . BLOCK, 0.312" thick	4	L65	51/9
R	EG7.82.5055	. . . CHANNEL, L.H.	1	1.6mm-L165	51/10
R	EG7.82.5056	. . . CHANNEL, R.H.	1	1.6mm-L165	51/11
R	EG7.82.5063	. . . CLEAT	1	1.6mm-L165	51/12
R	EG7.82.5065	. . . CLEAT	1	1.6mm-L165	51/13
R	EG7.11.193	. . . PIN	2	—	51/14
R	EG7.11.201	. . . PIN, locating Attaching parts:—	1	—	51/15
R	AGS2001/E/1/66	. . . Nut, 1/4" BSF	1	—	51/16
R	SP122/E	. . . Washer	1	—	51/17
R	EG7.11.195	. . . ROLLER	2	—	51/18

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R						Attaching parts for EG7.82.5053 and EG7.82.5054:—			
R	A25/2E	.	.	Bolt, 1/4" BSF			8	—	51/19
R	AGS2001/E/1/66	.	.	Nut, stiff, 1/4" BSF			8	—	51/20
R	SP122/E	.	.	Washer			8	—	51/21
R	EG7.82.5885	.	.	LABEL			1	—	51/22
R	CSP48E25H25	.	.	LEAD, bonding			2	—	51/23
				Attaching parts:—					
R	A25/2E	.	.	Bolt, 1/4" BSF			1	—	51/24
R	SP122/E	.	.	Washer			1	—	51/25
R	AGS2007/E/1	.	.	NUT, anchor			2	—	51/26
R	A415	.	.	PIN, pip			2	—	51/27
R	EEAS21A/6HR	.	.	PLATE, radius			QR	—	51/28
R	—	.		INSTALLATION of data-bus junction box (EG7.82.5333) (Mod 5466) Spares for:—			—	—	52/1
R	EG7.82.5779	.	.	ANGLE, mounting			1	—	52/2
				Attaching parts:—					
R	A25/18E	.	.	Bolt, 1/4" BSF			1	—	52/3
R	A25/18C	.	.	Bolt, 2 BA			1	—	52/4
R	A25/19C	.	.	Bolt, 2 BA			1	—	52/5
R	SP15/C	.	.	Washer			2	—	52/6
R	SP15/E	.	.	Washer			1	—	52/7
R	EG7.82.5781	.	.	ANGLE, mounting			1	—	52/8
				Attaching parts:—					
R	A25/18E	.	.	Bolt, 1/4" BSF			1	—	52/9
R	A25/18C	.	.	Bolt, 2 BA			1	—	52/10
R	A25/19C	.	.	Bolt, 2 BA			1	—	52/11
R	SP15/C	.	.	Washer			2	—	52/12
R	SP15/E	.	.	Washer			1	—	52/13
R	EG7.82.5335	.	.	BOX, junction, assembly			1	—	52/14
				Spares for:—					
R	72544-030-0	.	.	BLOCK, terminal			6	—	52/15
				Attaching parts:—					
R	A31/B24	.	.	Screw, 4 BA, cheese head			2	—	52/16
R	SP122/C	.	.	Washer			2	—	52/17
R	EG7.82.5347	.	.	COVER, JB			1	—	52/18
				Spares for:—					
R	RTV-116-19	.	.	ADHESIVE			QR	—	
	or								
R	MA509	.	.	ADHESIVE					

A.P.101B-0417-3A

RADIO AND RADAR

Page MP9

SYLVANIA COMMS JAMMER (ARI.23362)

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	EG7.82.5349	 COVER, JB, engraved	1	--	52/19
R	641-0032	 GASKET	QR	--	52/20
	or				
R	25-1374-0007	 GASKET			
		Attaching parts for EG7.82.5347:--			
R	EEAS117/1	 Screw	8	--	52/21
R	EEAS42	 Washer, leather	8	--	52/22
R	EEAS28/2CU	 Washer	16	--	52/23
R		 EARTH POINT	7	--	
		Consisting of:--			
R	AGS2001/C/4	 NUT, stiff, 2 BA	1	--	52/24
R	A54/C	 NUT, thin, 2 BA	2	--	52/25
R	A43/C32	 SCREW, 2 BA, cheese head	1	--	52/26
R	SP25/C	 WASHER	2	--	52/27
R	SP124/D	 WASHER	2	--	52/28
R	EE11/2	 EXTRUSION	QR	--	52/29
R	CSP48D18K18	 LEAD, bonding	1	--	52/30
		Attaching parts:--			
R	A25/3C	 Bolt, 2 BA	1	--	52/31
R	AGS2001/C/1-66	 Nut, 2 BA	1	--	52/32
R	SP25/C	 Washer	1	--	52/33
R	SP15/C	 Washer	1	--	52/34
R	EEAS551/20	 PLATE, ident.	6	--	52/35
R	RR0722-9012	 SHELL, jam nut connector	6	--	52/36
R	EG7.82.5337	 SHELL, box, assembly	1	--	52/37
		Spares for:--			
R	EG7.82.5785	 ANGLE	1	--	52/38
R	EG7.82.5783	 ANGLE	1	--	52/39
R	A25/1C	 BOLT, 2 BA	4	--	52/40
R	EG7.82.5345	 BRACKET, mounting, assembly	2	--	52/41
		Spares for:--			
R	EG7.82.5897	 BRACKET, mounting	1	--	52/42
R	AGS2007/B/1	 NUT, anchor, 4 BA	6	--	52/43
R	EEAS269	 NUT, side, anchor	8	--	52/44
R	AGS2007/C/1	 NUT, anchor, 2 BA	8	--	52/45
R	AGS2001/C/1-66	 NUT, 2 BA	4	--	52/46
R	EEAS15/37/70JR	 PLATE, packing	8	--	52/47
R	PAN6483AA	 RETAINER	8	--	52/48
R	EG7.82.5339	 SHELL	1	--	52/49
R	SP122/D	 WASHER	4	--	52/50
R	EG7.82.5465	 WIRING DIAGRAM, ARI.23362 JB	1	--	
		Attaching parts for EG7.82.5335:--			
R	A25/1C	 Bolt, 2 BA	8	--	52/51
R	SP15C	 Washer	8	--	52/52

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R —	. INSTALLATION, R.F. FILTER (EG7.82.5311) (Mod 5466) Spares for:—	—	—	53/1
R EG7.11.5215	. . BRACKET	1	1.6mm-L164	53/2
R EG7.11.5217	. . BRACKET	1	1.6mm-L164	53/3
R EG7.11.5213	. . CHANNEL	1	1.6mm-L164	53/4
R (S)HPL-158-160- 15-150-34A-34A	. . FILTER, RF	1	—	53/5
R 21FAC-420	. . NUT, stiff, 1/4", 20 UNC	6	—	53/6
R SP122/E	. . WASHER	6	—	53/7
R —	. INSTALLATION of Attenuator splitter box and SW2 (EG7.82.5685) (Mod 5466) Spares for:—	—	—	53/8
R LN29911-03X28	. . BOLT, pan head	4	—	53/9
R AS3180/11C	. . CLAMP, loop Attaching parts:—	2	—	53/10
R EG7.82.5713	. . Block, packing	1	—	53/11
R A25/6C	. . Bolt, 2 BA	1	—	53/12
R AS1242/4C	. . Bolt, 2 BA, c'sk head	1	—	53/13
R EEAS237/6A	. . Washer "D"	1	—	53/14
R EG7.82.5711	. . MEMBER, "Z" assembly Spares for:—	1	—	53/15
R EG7.82.5709	. . . MEMBER, "Z"	1	1.2mm-L73	53/16
R AGS2007/B/1	. . . NUT, anchor, 4 BA	1	—	53/17
R AGS2018/B/1	. . . NUT, anchor, 4 BA	2	—	53/18
R EG7.82.5717	. . MEMBER, "Z" assembly Spares for:—	1	—	53/19
R EG7.82.5715	. . . MEMBER, "Z"	1	1.2mm-L73	53/20
R AGS2007/B/1	. . . NUT, anchor, 4 BA	1	—	53/21
R AGS2018/B/1	. . . NUT, anchor, 4 BA	2	—	53/22
R EG7.82.5707	. . PLATE, mounting, assembly Spares for:—	1	—	53/23
R AGS2007/C/1	. . . NUT, anchor, 2 BA	4	—	53/24
R LN29691A03M	. . . NUT, anchor	4	—	53/25
R EG7.82.5793	. . . PACKING	1	—	53/26
R EG7.82.5705	. . . PLATE, mounting Attaching parts for EG7.82.5707:—	1	1.2mm-L73	53/27
R A25/1B	. . Bolt, 4 BA	6	—	53/28

A.P.101B-0417-3A

Page MP11

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R —	.	PROCESSOR	assembly				—	—	53/29
			(EG7.82.5637) (Mod 5466)						
			Spares for:—						
R EG7.82.5083	.	ANGLE					1	1.6mm-L164	53/30
R EG7.82.5085	.	ANGLE					1	1.6mm-L164	53/31
R 02-1278109-1	.	PROCESSOR	(Called up on EG7.82.5245)				—	—	53/32
			Attaching parts:—						
R A25/1C	.	Bolt, 2	BA				4	—	53/33
R AGS2001/C/1	.	Nut, stiff, 2	BA				4	—	53/34
R SP15/C	.	Washer					4	—	53/35
R —	.	PLUG, BREAK	in starboard wing				—	—	53/36
			root (EG7.81.4057) (Mod 5466)						
			Spares for:—						
R EG7.81.4059	.	FAIRLEAD, half					2	BS2572 TYPE F3	53/37
			Attaching parts:—						
R A25/3C	.	Bolt, 2	BA				2	—	53/38
R AGS2002/C/1	.	Nut, 2	BA				2	—	53/39
R SP13/C	.	Washer					2	—	53/40
R EG7.81.4061	.	PLATE, doubling					1	—	53/41

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R -	GA OF SYLVANIA COMMS JAMMER IN WINGS (EG7.82.5251/2) (Mod 5466) Spares for:-						-	-	54/1
R EG7.82.5497	. CABLE, assembly, SCJ 17, port						1	-	54/2
R EG7.82.5281	. CABLE, assembly, SCJ 14, starboard						1	-	54/3
R -	. INSTALLATION of Sylvania aerial (EG7.20.1301/2) (Mod 5466) Spares for:-						-	-	54/4
R 27-1278102-1	. . AERIAL, port and starboard Attaching parts:-						1	-	54/5
R CSP124-3-13	. . Bolt, 10 UNF						22	-	54/6
R 6930A-AN313A	. . Gasket						1	-	54/7
R -	. . ALTS to lower wing skin, port and starboard (EG7.20.1303/4) (Mod 5466) Spares for:-						-	-	55/1
R EA3.20.4185	. . . DOUBLER, port						1	-	55/2
R EA3.20.4186	. . . DOUBLER, starboard						1	-	55/3
R EG7.20.1305	. . . INSERT, port, 18 SWG						1	L165	55/4
R EG7.20.1306	. . . INSERT, starboard, 18 SWG						1	L165	55/5
R AGS2012/C/1	. . . NUT, anchor, 2 BA						6	-	55/6
R EG7.20.1607	. . . PACKER						1	-	55/7
R EA3.20.4109	. . . PANEL Attaching parts:-						1	-	55/8
R EEAS8/1A	. . . Packing						6	-	55/9
R EEAS1/1C	. . . Screw, 2 BA, c'sk head						6	-	55/10
R EEAS72/1	. . . PACKING, wedge						14	-	55/11
R EG7.20.1309	. . . PLATE, port, 18 SWG						1	L165	55/12
R EG7.20.1310	. . . PLATE, starboard, 18 SWG						1	L165	55/13
R EG7.20.1311	. . . PLATE, port, 18 SWG						1	L165	55/14
R EG7.20.1312	. . . PLATE, starboard, 18 SWG						1	L165	55/15
R EG7.20.1315	. . . PLATE, port, 18 SWG						1	L165	55/16
R EG7.20.1316	. . . PLATE, starboard, 18 SWG						1	L165	55/17
R EG7.20.1317	. . . PLATE, port, 18 SWG						1	L165	55/18
R EG7.20.1318	. . . PLATE, starboard, 18 SWG						1	L165	55/19
R EG7.20.1313	. . . STRAP, butt, port, 18 SWG						1	L165	55/20
R EG7.20.1314	. . . STRAP, butt, starboard, 18 SWG						1	L165	55/21
R EG7.20.1307	. . . STRAP, butt, port, 18 SWG						1	L165	55/22
R EG7.20.1308	. . . STRAP, butt, starboard, 18 SWG						1	L165	55/23
R EG7.20.1319	. . . STRINGER, port						1	EEDX33	55/24
R EG7.20.1320	. . . STRINGER, starboard						1	EEDX33	55/25
R EG7.20.1327	. . . STRINGER, port						1	EEDX33	55/26
R EG7.20.1328	. . . STRINGER, starboard						1	EEDX33	55/27

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Mtl. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.20.1329	.	.	.	STRINGER, port			1	EEDX33	55/28
R EG7.20.1330	.	.	.	STRINGER, starboard			1	EEDX33	55/29
R EG7.20.1331	.	.	.	STRINGER, port			1	EEDX33	55/30
R EG7.20.1332	.	.	.	STRINGER, starboard			1	EEDX33	55/31
R EG7.20.1333	.	.	.	STRINGER, port			1	EEDX33	55/32
R EG7.20.1334	.	.	.	STRINGER, starboard			1	EEDX33	55/33
R EG7.20.1335	.	.	.	STRINGER, port			1	EEDX33	55/34
R EG7.20.1336	.	.	.	STRINGER, starboard			1	EEDX33	55/35
R EG7.20.1337	.	.	.	STRINGER, port			1	EEDX33	55/36
R EG7.20.1338	.	.	.	STRINGER, starboard			1	EEDX33	55/37
R EG7.20.1339	.	.	.	STRINGER, port			1	EEDX33	55/38
R EG7.20.1340	.	.	.	STRINGER, starboard			1	EEDX33	55/39
R EA3.20.999	.	.	.	STRINGER			3	-	55/40
R EG7.20.1325	.	.	.	PLATE, sole, port			1	L65	54/8
R EG7.20.1326	.	.	.	PLATE, sole, starboard			1	L65	54/9
R -	.	.	.	STRUCTURE, aerial mounting port (EG7.20.1379) (Mod 5466) Spares for:-			-	-	56/1
R EG7.20.1343	.	.	.	ANGLE, assembly Spares for:-			1	-	56/2
R EG7.20.1361	.	.	.	ANGLE			1	1.6mm-L164	56/3
R AS26007/D	.	.	.	NUT, anchor, 10 UNF			11	-	56/4
R EG7.20.1321	.	.	.	PLATE, throat			1	L65	56/5
R EG7.20.1344	.	.	.	ANGLE, assembly Spares for:-			1	-	56/6
R EG7.20.1362	.	.	.	ANGLE			1	1.6mm-L164	56/7
R AS26007/D	.	.	.	NUT, anchor, 10 UNF			11	-	56/8
R EG7.20.1322	.	.	.	PLATE, throat			1	L65	56/9
R EG7.20.1347	.	.	.	ANGLE			1	1.6mm-L164	56/10
R EG7.20.1349	.	.	.	ANGLE			1	1.6mm-L164	56/11
R EG7.20.1357	.	.	.	ANGLE			1	1.6mm-L164	56/12
R EG7.20.1359	.	.	.	ANGLE			1	1.6mm-L164	56/13
R EG7.20.1367	.	.	.	ANGLE			1	1.6mm-L164	56/14
R EG7.20.1369	.	.	.	ANGLE			1	1.6mm-L164	56/15
R EG7.20.1371	.	.	.	ANGLE			1	1.6mm-L164	56/16
R EG7.20.1377	.	.	.	ANGLE			1	1.6mm-L164	56/17
R EG7.20.1383	.	.	.	ANGLE			1	1.6mm-L164	56/18
R EG7.20.1385	.	.	.	ANGLE			1	1.6mm-L164	56/19
R EG7.20.1391	.	.	.	ANGLE			1	1.6mm-L164	56/20
R EG7.20.1393	.	.	.	ANGLE			1	1.6mm-L164	56/21
R EG7.20.1397	.	.	.	ANGLE			1	1.6mm-L164	56/22
R EG7.20.1399	.	.	.	ANGLE			1	1.6mm-L164	56/23
R EG7.20.1489	.	.	.	ANGLE			1	-	56/24
R EG7.20.1491	.	.	.	ANGLE			1	-	56/25
R EG7.20.1493	.	.	.	ANGLE			1	-	56/26
R EG7.20.1495	.	.	.	ANGLE			1	-	56/27

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

	Part Number	Description						No. Off	Matl. Spec.	Plate No.
		1	2	3	4	5	6			
R	EG7.20.1355		PACKING					1	1.6mm-L164	56/28
R	—		REPAIR, rib 3B (EG7.20.1387)					—	—	57/1
			port (Mod 5466)							
			Spares for:—							
R	EG7.20.1443		ANGLE	16	SWG			1	L164	57/2
R	EG7.20.1445		ANGLE	16	SWG			1	L164	57/3
R	EG7.20.1447		ANGLE	16	SWG			1	L164	57/4
R	EG7.20.1449		ANGLE	16	SWG			1	L164	57/5
R	EG7.20.1451		ANGLE	16	SWG			1	L164	57/6
R	EG7.20.1453		ANGLE	16	SWG			1	L164	57/7
R	EG7.20.1455		ANGLE	16	SWG			1	L164	57/8
R	EG7.20.1457		ANGLE	16	SWG			1	L164	57/9
R	EG7.20.1459		ANGLE	16	SWG			1	L164	57/10
R	EG7.20.1461		ANGLE	16	SWG			1	L164	57/11
R	EG7.20.1463		ANGLE	16	SWG			1	L164	57/12
R	EG7.20.1465		ANGLE	16	SWG			1	L164	57/13
R	EG7.20.1467		ANGLE	16	SWG			1	L164	57/14
R	EG7.20.1469		ANGLE	16	SWG			1	L164	57/15
R	EG7.20.1471		ANGLE	16	SWG			1	L164	57/16
R	EG7.20.1483		ANGLE	16	SWG			1	L164	57/17
R	EG7.20.1473		CLEAT					1	1.6mm-L164	57/18
R	EG7.20.1474		CLEAT					2	1.6mm-L164	57/19
R	EG7.20.1475		CLEAT					2	1.6mm-L164	57/20
R	EG7.20.1476		CLEAT					2	1.6mm-L164	57/21
R	EG7.20.1477		CLEAT					2	1.6mm-L164	57/22
R	EG7.20.1478		CLEAT					2	1.6mm-L164	57/23
R	EG7.20.1479		CLEAT					1	1.6mm-L164	57/24
R	EG7.20.1481		CLEAT					3	1.6mm-L164	57/25
R	EG7.20.1482		CLEAT					1	1.6mm-L164	57/26
R	EG7.20.1485		PACKING					1	—	57/27
R	EG7.20.1487		PACKING					1	—	57/28
R	—		REPAIR, rib 4A (EG7.20.1409)					—	—	58/1
			port (EG7.20.1409)							
			Spares for:—							
R	EG7.20.1411		ANGLE	16	SWG			1	L164	58/2
R	EG7.20.1413		ANGLE	16	SWG			1	L164	58/3
R	EG7.20.1415		ANGLE	16	SWG			1	L164	58/4
R	EG7.20.1417		ANGLE	16	SWG			1	L164	58/5
R	EG7.20.1419		ANGLE	16	SWG			1	L164	58/6
R	EG7.20.1421		ANGLE	16	SWG			1	L164	58/7
R	EG7.20.1423		ANGLE	16	SWG			1	L164	58/8
R	EG7.20.1425		ANGLE	16	SWG			1	L164	58/9
R	EG7.20.1427		ANGLE	16	SWG			1	L164	58/10
R	EG7.20.1429		ANGLE	16	SWG			1	L164	58/11
R	EG7.20.1431		ANGLE	16	SWG			1	L164	58/12
R	EG7.20.1433		ANGLE	16	SWG			1	L164	58/13
R	EG7.20.1435		ANGLE	16	SWG			1	L164	58/14
R	EG7.20.1437		ANGLE	16	SWG			1	L164	58/15

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description					No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5 6			
R EG7.20.1439	.	.	.	.	ANGLE 16 SWG	1	L164	58/16
R EG7.20.1441	.	.	.	.	ANGLE 16 SWG	1	L164	58/17
R EG7.20.1473	.	.	.	.	CLEAT	1	1.6mm-L164	58/18
R EG7.20.1474	.	.	.	.	CLEAT	2	1.6mm-L164	58/19
R EG7.20.1475	.	.	.	.	CLEAT	2	1.6mm-L164	58/20
R EG7.20.1476	.	.	.	.	CLEAT	2	1.6mm-L164	58/21
R EG7.20.1477	.	.	.	.	CLEAT	2	1.6mm-L164	58/22
R EG7.20.1478	.	.	.	.	CLEAT	2	1.6mm-L164	58/23
R EG7.20.1479	.	.	.	.	CLEAT	2	1.6mm-L164	58/24
R EG7.20.1481	.	.	.	.	CLEAT	1	1.6mm-L164	58/25
R EG7.20.1482	.	.	.	.	CLEAT	2	1.6mm-L164	58/26
R EG7.20.1487	.	.	.	.	PACKING	1	1.2mm-L165	58/27
R EG7.20.1373	.	.	.	.	STIFFENER	1	EEJ59	56/29
R EG7.20.1375	.	.	.	.	STIFFENER	1	EEJ59	56/30
R EG7.20.1403	.	.	.	.	STIFFENER	1	EEJ59	56/31
R EG7.20.1405	.	.	.	.	STIFFENER	1	EEJ59	56/32
R EG7.20.1345	.	.	.	.	WEB	1	1.2mm-L164	56/33
R EG7.20.1365	.	.	.	.	WEB	1	1.2mm-L164	56/34
R EG7.20.1381	.	.	.	.	WEB	1	1.2mm-L164	56/35
R EG7.20.1389	.	.	.	.	WEB	1	1.2mm-L164	56/36
R -	.	.	.	.	STRUCTURE, aerial mounting, starboard (EG7.20.1380) (Mod 5466) Spares for:-	-	-	59/1
R EG7.20.1343	.	.	.	.	ANGLE, assembly Spares for:-	1	-	59/2
R EG7.20.1361	.	.	.	.	ANGLE	1	1.6mm-L164	59/3
R AS26007/D	.	.	.	.	NUT, anchor, 10 UNF	11	-	59/4
R EG7.20.1321	.	.	.	.	PLATE, throat	1	L65	59/5
R EG7.20.1344	.	.	.	.	ANGLE, assembly Spares for:-	1	-	59/6
R EG7.20.1362	.	.	.	.	ANGLE	1	1.6mm-L164	59/7
R AS26007/D	.	.	.	.	NUT, anchor, 10 UNF	11	-	59/8
R EG7.20.1322	.	.	.	.	PLATE, throat	1	L65	59/9
R EG7.20.1348	.	.	.	.	ANGLE	1	1.6mm-L164	59/10
R EG7.20.1349	.	.	.	.	ANGLE	1	1.6mm-L164	59/11
R EG7.20.1358	.	.	.	.	ANGLE	1	1.6mm-L164	59/12
R EG7.20.1360	.	.	.	.	ANGLE	1	1.6mm-L164	59/13
R EG7.20.1367	.	.	.	.	ANGLE	1	1.6mm-L164	59/14
R EG7.20.1370	.	.	.	.	ANGLE	1	1.6mm-L164	59/15
R EG7.20.1378	.	.	.	.	ANGLE	1	1.6mm-L164	59/16
R EG7.20.1384	.	.	.	.	ANGLE	1	1.6mm-L164	59/17
R EG7.20.1386	.	.	.	.	ANGLE	1	1.6mm-L164	59/18
R EG7.20.1372	.	.	.	.	ANGLE	1	1.6mm-L164	59/19
R EG7.20.1392	.	.	.	.	ANGLE	1	1.6mm-L164	59/20
R EG7.20.1394	.	.	.	.	ANGLE	1	1.6mm-L164	59/21
R EG7.20.1490	.	.	.	.	ANGLE	1	-	59/22
R EG7.20.1492	.	.	.	.	ANGLE	1	-	59/23

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
R EG7.20.1494		ANGLE	1	—	59/24
R EG7.20.1496		ANGLE	1	—	59/25
R EG7.20.1355		PACKING	1	1.6mm-L164	59/26
R EG7.20.1401		PACKING	1	1.6mm-L164	59/27
R —		REPAIR, rib 3B, starboard (EG7.20.1388) (Mod 5466) Spares for:—	—	—	60/1
R EG7.20.1444		ANGLE 16 SWG	1	L164	60/2
R EG7.20.1446		ANGLE 16 SWG	1	L164	60/3
R EG7.20.1448		ANGLE 16 SWG	1	L164	60/4
R EG7.20.1450		ANGLE 16 SWG	1	L164	60/5
R EG7.20.1452		ANGLE 16 SWG	1	L164	60/6
R EG7.20.1454		ANGLE 16 SWG	1	L164	60/7
R EG7.20.1456		ANGLE 16 SWG	1	L164	60/8
R EG7.20.1458		ANGLE 16 SWG	1	L164	60/9
R EG7.20.1460		ANGLE 16 SWG	1	L164	60/10
R EG7.20.1462		ANGLE 16 SWG	1	L164	60/11
R EG7.20.1464		ANGLE 16 SWG	1	L164	60/12
R EG7.20.1466		ANGLE 16 SWG	1	L164	60/13
R EG7.20.1468		ANGLE 16 SWG	1	L164	60/14
R EG7.20.1470		ANGLE 16 SWG	1	L164	60/15
R EG7.20.1472		ANGLE 16 SWG	1	L164	60/16
R EG7.20.1484		ANGLE 16 SWG	1	L164	60/17
R EG7.20.1473		CLEAT	2	1.6mm-L164	60/18
R EG7.20.1474		CLEAT	1	1.6mm-L164	60/19
R EG7.20.1475		CLEAT	2	1.6mm-L164	60/20
R EG7.20.1476		CLEAT	2	1.6mm-L164	60/21
R EG7.20.1477		CLEAT	2	1.6mm-L164	60/22
R EG7.20.1478		CLEAT	2	1.6mm-L164	60/23
R EG7.20.1480		CLEAT	1	1.6mm-L164	60/24
R EG7.20.1481		CLEAT	1	1.6mm-L164	60/25
R EG7.20.1482		CLEAT	3	1.6mm-L164	60/26
R EG7.20.1485		PACKING	1	1.2mm-L165	60/27
R EG7.20.1487		PACKING	1	1.2mm-L165	60/28
R —		REPAIR, rib 4A, starboard (EG7.20.1410) (Mod 5466) Spares for:—	—	—	61/1
R EG7.20.1412		ANGLE 16 SWG	1	L164	61/2
R EG7.20.1414		ANGLE 16 SWG	1	L164	61/3
R EG7.20.1416		ANGLE 16 SWG	1	L164	61/4
R EG7.20.1418		ANGLE 16 SWG	1	L164	61/5
R EG7.20.1420		ANGLE 16 SWG	1	L164	61/6
R EG7.20.1422		ANGLE 16 SWG	1	L164	61/7
R EG7.20.1424		ANGLE 16 SWG	1	L164	61/8
R EG7.20.1426		ANGLE 16 SWG	1	L164	61/9
R EG7.20.1428		ANGLE 16 SWG	1	L164	61/10
R EG7.20.1430		ANGLE 16 SWG	1	L164	61/11
R EG7.20.1432		ANGLE 16 SWG	1	L164	61/12

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description					No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5 6			
R EG7.20.1434	.	.	.	ANGLE	16 SWG	1	L164	61/13
R EG7.20.1436	.	.	.	ANGLE	16 SWG	1	L164	61/14
R EG7.20.1438	.	.	.	ANGLE	16 SWG	1	L164	61/15
R EG7.20.1440	.	.	.	ANGLE	16 SWG	1	L164	61/16
R EG7.20.1442	.	.	.	ANGLE	16 SWG	1	L164	61/17
R EG7.20.1473	.	.	.	CLEAT		2	1.6mm-L164	61/18
R EG7.20.1474	.	.	.	CLEAT		1	1.6mm-L164	61/19
R EG7.20.1475	.	.	.	CLEAT		2	1.6mm-L164	61/20
R EG7.20.1476	.	.	.	CLEAT		2	1.6mm-L164	61/21
R EG7.20.1477	.	.	.	CLEAT		2	1.6mm-L164	61/22
R EG7.20.1478	.	.	.	CLEAT		2	1.6mm-L164	61/23
R EG7.20.1480	.	.	.	CLEAT		2	1.6mm-L164	61/24
R EG7.20.1481	.	.	.	CLEAT		2	1.6mm-L164	61/25
R EG7.20.1482	.	.	.	CLEAT		1	1.6mm-L164	61/26
R EG7.20.1487	.	.	.	PACKING		1	1.2mm-L165	61/27
R EG7.20.1374	.	.	.	STIFFENER		1	EEJ59	59/28
R EG7.20.1376	.	.	.	STIFFENER		1	EEJ59	59/29
R EG7.20.1404	.	.	.	STIFFENER		1	EEJ59	59/30
R EG7.20.1406	.	.	.	STIFFENER		1	EEJ59	59/31
R EG7.20.1346	.	.	.	WEB		1	1.2mm-L164	59/32
R EG7.20.1366	.	.	.	WEB		1	1.2mm-L164	59/33
R EG7.20.1382	.	.	.	WEB		1	1.2mm-L164	59/34
R EG7.20.1390	.	.	.	WEB		1	1.2mm-L164	59/35
R -	.	.	.	INSTALLATION of aerial feeder		-	-	62/1
				cables, port (EG7.82.5285)				
				(Mod 5466)				
				Spares for:-				
R EG7.20.5107	.	.	.	BRACKET	18 SWG	1	L164	62/2
R EG7.20.5101	.	.	.	BRACKET	18 SWG	11	L164	62/3
R AGS2081/6	.	.	.	CLIP, pipe		12	-	62/4
				Attaching parts:-				
R A25/2C	.	.	.	Bolt, 2 BA		1	-	62/5
R AGS2001/C/1-66	.	.	.	Nut, stiff, 2 BA		1	-	62/6
R SP13/C	.	.	.	Washer		1	-	62/7
R -	.	.	.	CONDUIT, over jet pipe, port		-	-	62/8
				installation (EG7.20.5103)				
				(Mod 5466)				
				Spares for:-				
R EG7.20.5111	.	.	.	BRACKET	16 SWG	2	L163	62/9
R EG7.20.5113	.	.	.	BRACKET, assembly		1	-	62/10
				Spares for:-				
R EG7.20.5115	.	.	.	BRACKET	16 SWG	1	L163	62/11
R AGS2007/C/1	.	.	.	NUT, anchor, 2 BA		1	-	62/12
R AGS2101/21	.	.	.	CLIP, pipe		1	-	62/13
				Attaching parts:-				
R A25/2C	.	.	.	Bolt, 2 BA		1	-	62/14
R SP13/C	.	.	.	Washer		1	-	62/15

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R EC2.20.2553	.	.	.	CLIP, pipe			2	—	62/16
				Attaching parts:—					
R A25/1C	.	.	.	Bolt, 2 BA			2	—	62/17
R AGS2001/C/1-66	.	.	.	Nut, stiff, 2 BA			2	—	62/18
R SP13/C	.	.	.	Washer			2	—	62/19
R SP91/L	.	.	.	CLIP, hose			4	—	62/20
R EC2.20.2537	.	.	.	CONDUIT, 2.5" O/D	20 SWG		1	L54	62/21
R EC2.20.3077	.	.	.	CONDUIT, 2.5" O/D	20 SWG		1	L54	62/22
R EC2.20.2539	.	.	.	END-CONDUIT 2.5" O/D	20 SWG		1	L54	62/23
R EG7.20.5117	.	.	.	PACKER	12 SWG		2	L164	62/24
R EG7.20.5119	.	.	.	PLATE, doubling	16 SWG		2	L164	62/25
R EC2.20.2549	.	.	.	SLEEVE, 2.5" O/D	20 SWG		2	L54	62/26
R —	.	.	.	MOD to main spar web aerial			—	—	62/27
				access hole, port					
				(EG7.20.5105) (Mod 5466)					
				Spares for:—					
R EG7.82.5303	.	.	.	FAIRLEAD, half			2	BS.2572	62/28
				Attaching parts:—				TYPE F3	
R A25/4C	.	.	.	Bolt, 2 BA			2	—	62/29
R SP13/C	.	.	.	Washer			2	—	62/30
R EG7.20.1605	.	.	.	PLATE, doubling, assembly			1	—	62/31
				Spares for:—					
R AGS2007/C/1	.	.	.	NUT, anchor, 2 BA			4	—	62/32
R EG7.20.5109	.	.	.	PLATE			1	2mm-L164	62/33
R —	.	.	.	INSTALLATION of aerial feeder cables,			—	—	63/1
				starboard (EG7.82.5286)					
				(Mod 5466)					
				Spares for:—					
R EG7.20.5107	.	.	.	BRACKET	18 SWG		1	L164	63/2
R EG7.20.5101	.	.	.	BRACKET	18 SWG		11	L164	63/3
R AGS2081/12	.	.	.	CLIP, pipe			12	—	63/4
				Attaching parts:—					
R A25/2C	.	.	.	Bolt, 2 BA			1	—	63/5
R AGS2001/C/1-66	.	.	.	Nut, stiff, 2 BA			1	—	63/6
R SP13/C	.	.	.	Washer			1	—	63/7
R —	.	.	.	CONDUIT, over jet pipe, starboard			—	—	63/8
				installation (EG7.20.5104)					
				(Mod 5466)					
				Spares for:—					
R EG7.20.5111	.	.	.	BRACKET	16 SWG		2	L163	63/9
R EG7.20.5113	.	.	.	BRACKET, assembly			1	—	63/10
				Spares for:—					
R EG7.20.5115	.	.	.	BRACKET	16 SWG		1	L163	63/11
R AGS2007/C/1	.	.	.	NUT, anchor, 2 BA			1	—	63/12

RADIO AND RADAR

SYLVANIA COMMS JAMMER (ARI.23362)

Part Number	Description						No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5	6			
R AGS2101/21	.	.	.	CLIP, pipe			1	—	63/13
R A25/2C	.	.	.	Attaching parts:—			1	—	63/14
R SP13/C	.	.	.	Bolt, 2 BA			1	—	63/15
R EC2.20.2553	.	.	.	Washer			2	—	63/16
R A25/1C	.	.	.	CLIP, pipe			2	—	63/17
R AGS2001/C/1-66	.	.	.	Attaching parts:—			2	—	63/18
R SP13/C	.	.	.	Bolt, 2 BA			2	—	63/19
R SP91/L	.	.	.	Nut, stiff, 2 BA			2	—	63/20
R EC2.20.2537	.	.	.	Washer			4	—	63/21
R EC2.20.3077	.	.	.	CLIP, hose			1	L54	63/22
R EC2.20.2539	.	.	.	CONDUIT, 2.5" O/D	20 SWG		1	L54	63/23
R EG7.20.5117	.	.	.	CONDUIT, 2.5" O/D	20 SWG		1	L54	63/24
R EG7.20.5119	.	.	.	END-CONDUIT, 2.5" O/D	20 SWG		2	L164	63/25
R EC2.20.2549	.	.	.	PACKER	12 SWG		2	L164	63/26
R —	.	.	.	PLATE, doubling	16 SWG		2	L54	63/27
R —	.	.	.	SLEEVE, 2.5" O/D	20 SWG		—	—	63/28
R —	.	.	.	MOD to main spar web aerial			—	—	63/29
R —	.	.	.	access hole, starboard			—	—	63/30
R —	.	.	.	(EG7.20.5106) (Mod 5466)			—	—	63/31
R —	.	.	.	Spares for:—			—	—	63/32
R EG7.82.5301	.	.	.	FAIRLEAD, half			2	BS.2572	63/33
R A25/4C	.	.	.	Attaching parts:—			2	TYPE F3	63/34
R SP13/C	.	.	.	Bolt, 2 BA			2	—	63/35
R EG7.20.1605	.	.	.	Washer			2	—	63/36
R —	.	.	.	PLATE, doubling, assembly			1	—	63/37
R —	.	.	.	Spares for:—			—	—	63/38
R AGS2007/C/1	.	.	.	NUT, anchor, 2 BA			4	—	63/39
R EG7.20.5109	.	.	.	PLATE			1	2mm-L164	63/40

OMEGA NAVIGATION SYSTEM

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	GA OF OMEGA NAVIGATION SYSTEM (EG7.82.5985) (Mod.5466) Spares for:—	—	—	64/1
R	6-714AM042S	. AERIAL, "OMEGA"	1	—	64/2
R	64-55800	. INVERTER, F145E Attaching parts:—	1	—	84/7
R	PAN3009-05-010	. Bolt, hex. head	2	—	84/8
R	LN9025-0510L	. Washer	2	—	84/9
R	—	. PICTORIAL VIEW OF OMEGA INVERTER/ CONTROL BOX/CONDUIT (EG7.82.6017) Spares for:—	—	—	—
R	AS3180-3B	. . CLAMP Attaching parts:—	2	—	64/3
R	A25-1B	. . Bolt, 4 BA, hex. head	1	—	64/9
R	AGS2001/B/1	. . Nut, stiff, 4 BA	1	—	64/10
R	EEAS238-1A	. . Washer, "D"	QR	—	64/11
R	AS3180-4B	. . CLAMP Attaching parts:—	2	—	64/12
R	A25-1B	. . Bolt, 4 BA, hex. head	1	—	64/13
R	AGS2001/B/1	. . Nut, stiff, 4 BA	1	—	64/14
R	EEAS238-1A	. . Washer, "D"	QR	—	64/15
	D8350	. THERMOMETER	1	—	64/4
	457348-03	. TRAY, RPU Mounting	1	—	64/5
	D60071	. UNIT, Airspeed	1	—	64/6
	458100	. UNIT, Control	1	—	64/7
R	457300-04-12- 211-08-96	. UNIT, Receiver, processor	1	—	64/8

OMEGA NAVIGATION SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R -	GA OF OMEGA NAVIGATION SYSTEM IN FRONT FUSELAGE (EG7.82.5987) (Mod.5466) Spares for:-	-	-	65/1
R -	. BOX, inverter control assembly, installation (EG7.82.5961) Spares for:-	-	-	-
R EG7.82.5949	. . BOX, inverter control assembly Spares for:-	1	-	83/1
R CML25289	. . . BOX, die cast assembly	1	-	83/2
R 72541-025-0	. . . BLOCK, terminal, 5-way Spares for:-	1	-	83/3
R 41851-825-0	 COVER, T.B.	1	-	83/4
R EEAS550-5	 PLATE, ident.	1	-	83/5
R CXH3MM	 SLEEVE, pink, 3/8" lens Attaching parts for 7254-025-0:-	QR	-	†
R AGS2001/B/1	. . . Nut, stiff, 4 BA	2	-	83/6
R 36765-502-0	. . . Pillar, fixing	2	-	83/7
R SP15/B	. . . Washer, 4 BA	2	-	83/8
R EG7.82.5955	. . . BRACKET, assembly Spares for:-	2	-	83/9
R EG7.82.5953	 BRACKET	1	EEJ-71	83/10
R AGS2007/B/1	 NUT, anchor, 4 BA	2	-	83/11
R PAN6553	. . . CONTACTOR 25 amp Attaching parts for PAN6553:-	1	-	83/12
R AS1248-1B	. . . Bolt, 4 BA, mushroom hd.	4	-	83/13
R Z23672	. . . GROMMET	1	-	83/14
R EG7.82.5947	. . . PLATE, base, 1.6 mm thick	1	L156	83/15
R EG7.82.5945	. . . PLATE, mounting assembly Spares for:-	1	-	83/16
R 142-60999-011	 CAPACITOR (3900 μF)	2	-	83/17
R 543-018	 CLIP, retaining Attaching parts for 543-018:-	3	-	83/18
R AGS2001/B/1	 Nut, stiff, 4 BA	2	-	83/19
R A33/B12	 Screw, 4 BA, c'sk hd.	2	-	83/20
R SP15/B	 Washer, 4 BA	2	-	83/21
R AGS2007/C/1	 NUT, anchor, 2 BA	2	-	83/22
R AGS2019/C/1	 NUT, anchor, 2 BA	1	-	83/23
R EG7.82.5943	 PLATE, mounting, 2.0 mm thick Attaching parts for EG7.82.5943:-	1	L165	83/24
R AS1248-2C	 Bolt, 2 BA, mushroom hd.	3	-	83/25
R G198-1-1-7-19	. . . SLEEVE	QR	-	†
R G198-1-1-11-19	. . . SLEEVE	QR	-	†
R 36162-503-0	. . . SPACER	2	-	†

OMEGA NAVIGATION SYSTEM

Part Number	Description	No. Off	Mati. Spec.	Plate No.
	1 2 3 4 5 6			
R HC294	. . . TAG, R.T.	4	-	†
R HC314A	. . . TERMINATION, R.T.	6	-	†
R PAN6461-29	. . . TERMINATION, R.T.	8	-	†
R PAN6461-69	. . . TERMINATION, R.T.	6	-	†
R PAN6423AP030	. . . WIRE, elect.	QR	-	†
R PAN6423AP006	. . . WIRE, elect.	QR	-	†
	Attaching parts for EG7.82.5949:-			
R A25-1C	. . Bolt, 2 BA, hex. hd	4	-	83/26
R AGS2007/C/1	. . Nut, anchor, 2 BA	4	-	83/27
R EG7.82.5473	. CABLE, assembly, ONS 1	1	-	65/2
	Spares for:-			
R LMS-12	. . CABLE	1	-	65/3
R EG7.82.5935	. CABLE, assembly, ONS 4	1	-	†
R EG7.82.5939	. CABLE, assembly, ONS 5	1	-	†
R EG7.82.5937	. CABLE, assembly, ONS 6	1	-	†
R EG7.82.5941	. CABLE, assembly, ONS 7	1	-	†
R EG7.82.5963	. CABLE, assembly, ONS 8	1	-	†
R -	. EARTH POINT E26	-	-	
	Consisting of:-			
R AGS2001/C/4	. . NUT, stiff, 2 BA	1	-	65/4
R A54C	. . NUT, thin, 2 BA	2	-	65/5
R A43/C40	. . SCREW, 2 BA, cheese hd	1	-	65/6
R SP25/C	. . WASHER	2	-	65/7
R SP124/D	. . WASHER	2	-	65/8
R -	. INSTALLATION of total head thermometer (EG7.10.5033)	-	-	65/9
	Spares for:-			
R EG7.10.5035	. . PLATE, doubler	1	-	65/10
	Spares for:-			
R AGS2023/C/1	. . . NUT, anchor, 2 BA	4	-	65/11
R D8350	. . THERMOMETER	1	-	65/12
	Attaching parts:-			
R AS1246-2C	. . Bolt, 8-32 UNC, pan hd	4	-	65/13
R EG7.10.5037	. . Seal, rubber	1	-	65/14
R -	. INSTALLATION, inverter mounting bracket (EG7.10.5247)	-	-	84/1
	Spares for:-			
R EG7.10.5263	. . PACKING, 4 mm x 1.0" x 4.2"	2	L164	84/2
R EG7.10.5265	. . PACKING, fwd, 3 mm thick	1	L164	84/3
R EG7.10.5266	. . PACKING, aft, 3 mm thick	1	L164	84/4
R AS2811-5-093	. . SPACER	3	-	84/5
R AS2811-5-087	. . SPACER	3	-	84/6

OMEGA NAVIGATION SYSTEM

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	EG7.10.5249	. . . TRAY, mounting assembly Spares for:—	1	—	84/10
R	EG7.10.5253	. . . ANGLE, fwd, 1.6 mm thick	1	L165	84/11
R	EG7.10.5254	. . . ANGLE, aft, 1.6 mm thick	1	L165	84/12
R	EG7.10.5255	. . . ANGLE, bulb, 7.7" lens	1	EEDX68	84/13
R	EG7.10.5257	. . . CHANNEL	1	—	84/14
R	EG7.10.5259	. . . CLEAT, fwd, 1.2 mm thick	1	L165	84/15
R	EG7.10.5260	. . . CLEAT, aft, 1.2 mm thick	1	L165	84/16
R	LN29982A05	. . . NUT, anchor	2	—	84/17
R	EG7.10.5251	. . . PLATE, 1.6 mm thick	1	L165	84/18
R	EG7.10.5261	. . . STRIP, 3 mm x 0.9" x 8.15" Attaching parts for EG7.10.5249:—	1	L165	84/19
R	A25-13C	. . Bolt, 2 BA, hex. hd	2	—	84/20
R	A25-12C	. . Bolt, 2 BA, hex. hd	4	—	84/21
R	AGS2001C1-66	. . Nut, stiff, 2 BA	6	—	84/22
R	SP122/D or SP125/D	. . Washer, 2 BA	6	—	84/23
R	—	. ALTERATIONS TO OMEGA SUPPLIES (EG7.82.5973) (Mod.5466)	—	—	—
R	—	. INSTALLATION of conduit assembly (EG7.82.5977) Spares for:—	—	—	84/24
R	AS4525-12	. . CLAMP Attaching parts for AS4525-12:—	2	—	84/25
R	A25-2C	. . Bolt, 2 BA, hex. hd	1	—	84/26
R	AGS2001C1-66	. . Nut, stiff, 2 BA	1	—	84/27
R	EEAS237-7AH	. . Washer, "D"	1	—	84/28
R	SP47/C	. . Washer	1	—	84/29
R	EG7.82.5979	. . CONDUIT, assembly, 18 mm O/D x 0.8 mm wall thickness	1	BACM123	84/30

OMEGA NAVIGATION SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	GA OF OMEGA NAVIGATION SYSTEM IN CENTRE FUSELAGE (EG7.82.5989) (Mod 5466) Spares for:-	-	-	66/1
-	. ALTS to floor, frame 27 to 29 for Omega navigation system (EG7.11.5245) Spares for:-	-	-	66/2
EG7.11.5247	. . PLATE 18 SWG	1	L72	66/3
PAN6483/A	. . RETAINER, cable	4	-	66/4
A25/1C	. BOLT, 2 BA	2	-	66/5
EG7.82.5475	. CABLE, assembly, ONS 2	1	-	66/6
-	. EARTH POINT E29, E31 and E38 Consisting of:-	-	-	
AGS2001/C/4	. . NUT, stiff, 2 BA	1	-	66/7
A54/C	. . NUT, thin, 2 BA	2	-	66/8
A43/C40	. . SCREW, 2 BA, cheese head	1	-	66/9
SP25/C	. . WASHER	2	-	66/10
SP124/D	. . WASHER	2	-	66/11
EG7.82.5697	. FAIRLEAD Attaching parts:-	2	LFS21	66/12
A25/3B	. Bolt, 4 BA	4	-	66/13
AGS2001/B/1	. Nut, stiff, 4 BA	4	-	66/14
-	. INSTALLATION of receiver processor unit mounting structure (EG7.82.5005) Spares for:-	-	-	66/15
EG7.82.5037	. . CHANNEL Attaching parts:-	2	1.2mm-L164	66/16
A25/2J	. . Bolt, 3/8" BSF	2	-	66/17
SP124/J	. . Washer	2	-	66/18
EG7.82.5039	. . CHANNEL, assembly Spares for:-	1	-	66/19
EG7.82.5041	. . . CHANNEL	1	1.2mm-L164	66/20
AGS2007/C/1	. . . NUT, anchor Attaching parts for EG7.82.5039:-	2	-	66/21
A25/1C	. . Bolt, 2 BA	8	-	66/22
AGS2001/C/1-66	. . Nut, stiff, 2 BA	8	-	66/23
SP124/D	. . Washer	8	-	66/24
EG7.82.5787	. . CHANNEL, assembly Spares for:-	1	-	66/25
EG7.82.5041	. . . CHANNEL	1	1.2mm-L164	66/26
EE11-2	. . . EXTRUSION, 2"	QR	-	66/27
AGS2007/C/1	. . . NUT, anchor Attaching parts for EG7.82.5787:-	2	-	66/28
A25/1C	. . Bolt, 2 BA	8	-	66/29
AGS2001/C/1-66	. . Nut, stiff, 2 BA	8	-	66/30
SP124/D	. . Washer	8	-	66/31

OMEGA NAVIGATION SYSTEM

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	. INSTALLATION of Omega junction box (EG7.82.5565) Spares for:—	—	—	67/1
R	EG7.82.5567	. . . ANGLE, mounting, assembly Spares for:—	2	—	67/2
R	EG7.82.5597	 ANGLE	1	EEDX271	67/3
R	AGS2007/C/1	 NUT, anchor	1	—	67/4
R	EG7.82.5569	. . . BRACKET, mounting, assembly Spares for:—	2	—	67/5
R	EG7.82.5595	 BRACKET	1	EEJ225	67/6
R	AGS2007/C/1	 NUT, anchor	1	—	67/7
R	—	. . . BOX, junction, assembly (EG7.82.5571) Spares for:—	—	—	67/8
R	72544-030-0	 BLOCK, terminal Attaching parts:—	1	—	67/9
R	EEAS551/20	 Plate, ident	1	—	67/10
R	A31/B20	 Screw	2	—	67/11
R	SP122/C	 Washer	2	—	67/12
R	CZ52815	 BLOCK, fuse Attaching parts:—	1	—	67/13
R	A31/B8	 Screw	2	—	67/14
R	SP122/C	 Washer	2	—	67/15
R	EG7.82.5573	 BOX, junction, assembly Spares for:—	1	—	67/16
R	EG7.82.5583	 ANGLE, assembly Spares for:—	2	—	67/17
R	EG7.82.5585	 ANGLE 18 SWG	1	L164	67/18
R	AGS2007/C/1	 NUT, anchor	2	—	67/19
R	EG7.82.5599	 ANGLE, mounting	4	EEDX271	67/20
R	EG7.82.5579	 BRACKET, assembly Spares for:—	1	—	67/21
R	EG7.82.5581	 BRACKET 20 SWG	1	L164	67/22
R	AGS2007/B/1	 NUT, anchor	2	—	67/23
R	EEAS269	 NUT, anchor	8	—	67/24
R	EEAS15/37/70JR	 PACKING	8	—	67/25
R	EG7.82.5577	 SHELL, junction box, 18 SWG	1	L59	67/26
R	EG7.82.5593	 CHASSIS 18 SWG Attaching parts:—	1	L164	67/27
R	A31/C18	 Screw, cheese head	4	—	67/28
R	SP122/D	 Washer	4	—	67/29

OMEGA NAVIGATION SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.82.5575	. . . COVER, assembly	1	—	67/30
	Spares for:—			
BOSTIK 1777	 CEMENT	QR	—	†
EG7.82.5587	 COVER, engraved, assembly	1	—	67/31
RIBBONSEAL 79	 STRIP, 0.14" dia x 36"	QR	Syn rubber	67/32
	Attaching parts for EG7.82.5575:—			
EEAS117/1	. . . Screw	8	—	67/33
EEAS42	. . . Washer, leather, 0.05" thick	8	—	67/34
EEAS28/2CU	. . . Washer	16	—	67/35
—	. . . Wire, locking 20 SWG	QR	OTD189	67/36
EG7.82.5639	. . . DIAGRAM, wiring	1	—	
—	EARTH POINT	—	—	
	Consisting of:—			
A54/C	 NUT, thin	2	—	67/37
AGS2001/C/4	 NUT, stiff	1	—	67/38
SP124/D	 WASHER	4	—	67/39
A43/C40	 SCREW	1	—	67/41
6027-12-3SN	. . . JAM NUT, connector	1	—	67/42A
6027-12-3PN	. . . JAM NUT, connector	1	—	67/42
6027-16-26PN	. . . JAM NUT, connector	1	—	67/43
GES03822	. . . RECTIFIER	1	—	67/44
	Attaching parts:—			
AGS2001/A/3	. . . Nut, stiff	2	—	67/45
A31/A8	. . . Screw	2	—	67/46
SP122/A	. . . Washer	2	—	67/47
RD6528	. . . TRANSFORMER	1	—	67/48
	Attaching parts:—			
A31/A8	. . . Screw	4	—	67/49
SP122/A	. . . Washer	4	—	67/50
	Attaching parts for EG7.82.5571:—			
A25/2C	. . . Screw	4	—	67/51
SP122/D	. . . Washer	4	—	67/52
CSP48C13J13	. LEAD, bonding	1	—	66/32
AS1242/1C	. SCREW, 2 BA, c'sk head	4	—	
SP15/C	. WASHER	2	—	

OMEGA NAVIGATION SYSTEM

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	GA OF OMEGA NAVIGATION SYSTEM IN REAR FUSELAGE (EG7.82.5991) (Mod.5466) Spares for:—	—	—	68/1
R	EG7.82.5933	. CABLE, assembly, ONS3 (Made from LITTON AERO Part No. 458472-03-30)	1	—	68/2
R	—	. INSTALLATION of sole plate (EG7.82.6013) Spares for:—	—	—	68/3
R	EG7.12.5063	. . . ANGLE, 16 SWG	1	L165	68/4
R	EG7.12.5065	. . . ANGLE, assembly Spares for:—	1	—	68/5
R	EG7.12.5067	. . . ANGLE, 16 SWG	1	L165	68/6
R	AS8602D	. . . NUT, anchor	1	—	68/7
R	EG7.12.5053	. . . CLEAT, 20 SWG	2	L165	68/8
R	EG7.12.5055	. . . PACKER, assembly Spares for:—	1	—	68/9
R	AS8602/D	. . . NUT, anchor	2	—	68/10
R	EG7.12.5057	. . . PACKER	1	L65	68/11
R	EG7.12.5056	. . . PACKER, assembly Spares for:—	1	—	68/12
R	AS8602/D	. . . NUT, anchor	2	—	68/13
R	EG7.12.5058	. . . PACKER	1	L65	68/14
R	EG7.12.5059	. . . PACKER, assembly Spares for:—	2	—	68/15
R	AS8602/D	. . . NUT, anchor	1	—	68/16
R	EG7.12.5061	. . . PACKER	1	L65	68/17
R	EG7.12.5051	. . . PLATE, sole	1	—	68/18
R	—	. INSTALLATION of blanking plate (EG7.12.5083) Spares for:—	—	—	—
R	EG7.12.5081	. . . PLATE, blanking, 12 SWG Attaching parts:—	1	L165	68/22
R	A173-3D	. . . Bolt, 10-32 UNF, c'sk hd	1	—	68/23
R	A173-5D	. . . Bolt, 10-32 UNF, c'sk hd	2	—	68/24
R	A173-8D	. . . Bolt, 10-32 UNF, c'sk hd	4	—	68/25
	—	. INSTALLATION of Omega antenna coupler guard. (EG7.82.5359) Spares for:—	—	—	69/1
	EB6.90.197	. . . BRACKET Attaching parts:—	2	—	69/2
	A25/1C	. . . Bolt	4	—	69/3
	AGS2001/C/1-66	. . . Nut, stiff	4	—	69/4
	SP122/D	. . . Washer	4	—	69/5

OMEGA NAVIGATION SYSTEM

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG7.82.5601	. . .	BRACKET	1	-	69/6
	. . .	Attaching parts:-			
A25/1C	. . .	Bolt	4	-	69/7
AGS2001/C/1-66	. . .	Nut, stiff	4	-	69/8
SP122/D	. . .	Washer	4	-	69/9
EG7.82.5683	. . .	BRACKET 18 SWG	1	S510	69/10
	. . .	Attaching parts:-			
A25/1C	. . .	Bolt	4	-	69/11
AGS2001/C/1-66	. . .	Nut, stiff	4	-	69/12
SP122/D	. . .	Washer	4	-	69/13
EG7.82.5361	. . .	GUARD, assembly	1	-	69/14
	. . .	Spares for:-			
EG7.82.5363	. . .	BOARD, guard	1	1/4" Plywood	69/15
	. . .	Attaching parts:-			
AS1242/8C	. . .	Bolt	6	-	69/16
AGS2001/C/1-66	. . .	Nut, stiff	6	-	69/17
SP122/D	. . .	Washer	12	-	69/18
EB6.90.191	. . .	GUARD, aerial	1	-	69/19
EB6.90.195	. . .	PLUG	4	-	69/20
	. . .	Attaching parts for EG7.82.5361:-			
A25/6C	. . .	Bolt	4	-	69/21
AGS2001/C/1-66	. . .	Nut, stiff	4	-	69/22
SP122/D	. . .	Washer	4	-	69/23
PAN6483/BA	. . .	RETAINER, cable	11	-	68/19
PAN6483/AA	. . .	RETAINER, cable	10	-	68/20
PAN6481/B1/018	. . .	TIE, cable	QR	-	68/21

R
R
R



A.P.101B-0417-3A

Page MR1

I/J BAND JAMMER SYSTEM

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R -						GA OF I/J BAND JAMMER SYSTEM (EG7.82.5257) (Mod 5466) Spares for:-	-	-	
R -						. GA OF I/J BAND JAMMER SYSTEM IN FRONT FUSELAGE (EG7.82.5259) See page MR2	-	-	
R -						. GA OF I/J BAND JAMMER SYSTEM IN CENTRE FUSELAGE (EG7.82.5261) See page MR5	-	-	
R -						. GA OF I/J BAND JAMMER SYSTEM IN REAR FUSELAGE (EG7.82.5271) See page MR10	-	-	
R 236577-1						. UNIT. CONTROL	2	-	70/2
R 236576-1						. UNIT, MAIN	2	-	71/2

I/J BAND JAMMER SYSTEM

	Part Number	Description 1 2 3 4 5 6	No. Off	Mati. Spec.	Plate No.
R	—	GA OF I/J BAND JAMMER SYSTEM IN FRONT FUSELAGE (EG7.82.5259) (Mod 5466) Spares for:—	—	—	70/1
R	EG7.82.5479	. CABLE, assembly, BJF1	1	—	
R	EG7.82.5485	. CABLE, assembly, BJR1	1	—	
R	—	. INSTALLATION of forward looking radomes and aerals (EG7.82.5031) See page MB1	—	—	
R	—	. INSTALLATION of wave guides in nose (EG7.82.5011) Spares for:—	—	—	70/3
R	EG7.82.2249	. . . ANGLE, attachment	1	—	70/4
R	EG7.10.965	. . . BRACKET, assembly Spares for:—	2	—	70/5
R	EG7.10.967	. . . BRACKET, support	1	—	70/6
R	AGS2007/C/1	. . . NUT, anchor, 2 BA	3	—	70/7
R	AGS2018/C/1	. . . NUT, anchor, 2 BA	1	—	70/8
R	EG7.82.2243	. . . BRACKET, assembly Spares for:—	1	—	70/9
R	EG7.82.2245	. . . BRACKET	1	—	70/10
R	EG7.82.2247	. . . BRACKET	1	—	70/11
R	AGS2007/C/1	. . . NUT, anchor, 2 BA Attaching parts for EG7.82.2243:—	4	—	70/12
R	A25/1C	. . . Bolt, 2 BA	2	—	70/13
R	SP124/D	. . . Washer	2	—	70/14
R	WBUN1146-5-3W	. . . BLOCK, terminal, 3-way Attaching parts:—	1	—	70/15
R	WBNY111083	. . . Cover	1	—	70/16
R	WB1114-28	. . . Pillar, fixing	2	—	70/17
R	EEAS550-3	. . . Plate, ident	1	—	70/18
R	EG7.82.1391	. . . CLIP, wave guide Attaching parts:—	2	—	70/19
R	A25/1C	. . . Bolt, 2 BA	2	—	70/20
R	SP124/D	. . . Washer	2	—	70/21
R	EG7.82.2015	. . . CLIP, wave guide Attaching parts:—	2	—	70/22
R	A25/1C	. . . Bolt, 2 BA	3	—	70/23
R	SP124/D	. . . Washer	3	—	70/24
R	EG7.82.2533	. . . CLIP, bonding Attaching parts:—	2	—	70/25
R	A25/2C	. . . Bolt, 2 BA	1	—	70/26
R	AGS2001/C/1-66	. . . Nut, stiff, 2 BA	1	—	70/27
R	SP124/D	. . . Washer	2	—	70/28

I/J BAND JAMMER SYSTEM

	Part Number	Description						No. Off	Matl. Spec.	Plate No.
		1	2	3	4	5	6			
R	EG7.82.5743	. .	CLIP					2	—	70/29
			Attaching parts:—							
R	A25/5C	. .	Bolt, 2 BA					2	—	70/30
R	EG7.82.5745	. .	Packer					2	—	70/31
R	—	. .	Strip (Sorbo rubber 1/8" x 1" x 3.25")					1	—	70/32
R	SP124/D	. .	Washer					2	—	70/33
R	AS3360/C/3C	. .	LEAD, bonding					2	—	70/34
			Attaching parts:— (2 leads together)							
R	A25/1C	. .	Bolt, 2 BA					1	—	70/35
R	SP124/D	. .	Washer					2	—	70/36
R	EG7.82.2697	. .	LABEL					1	—	70/37
R	EG7.82.2695	. .	LABEL					1	—	70/38
R	EG7.82.5843	. .	PLATE, spreader					2	—	70/39
			Attaching parts:—							
R	A102/4C	. .	Bolt, 8-32 UNC					4	—	70/40
R	5841-99-9529685	. .	SWITCH, DON-LAN					2	—	70/41
			Attaching parts:—							
R	A204/C20	. .	Screw, 8-32 UNC, c'sk head					3	—	70/42
R	EG7.82.2821	. .	Shim					1	—	70/43
R	EG7.82.471	. .	SHIM (Fit 2 if required)					2	—	70/44
R	—	. .	WAVEGUIDE TO WAVEGUIDE CONNECTION (Typical)					—	—	—
			Consisting of:—							
R	R60-1761-53	. . .	BOLT, special					4	—	70/45
R	5310-99-952-3249	. . .	NUT					4	—	70/46
R	5985-99-083-0053	. . .	RING, sealing					2	—	70/47
R	R60-1711-01	. .	WAVEGUIDE, assembly					1	—	70/48
R	R60-1710	. .	WAVEGUIDE, assembly					1	—	70/49
R	R60-1709	. .	WAVEGUIDE, assembly					1	—	70/50
R	R60-1708	. .	WAVEGUIDE, assembly, flexible					2	—	70/51
R	R60-1707	. .	WAVEGUIDE, assembly					2	—	70/52
R	R60-1705	. .	WAVEGUIDE, assembly					1	—	70/53
R	R60-1706	. .	WAVEGUIDE, assembly					1	—	70/54
R	R60-1711-02	. .	WAVEGUIDE, assembly					1	—	70/55
R	CS3764	. .	WAVEGUIDE, assembly					1	—	70/56
R	CS3762	. .	WAVEGUIDE, assembly					1	—	70/57
R	R60-7038-01	. .	WAVEGUIDE, assembly					1	—	70/58
R	R60-1719-54	. .	WAVEGUIDE, assembly, flexible					1	—	70/59

I/J BAND JAMMER SYSTEM

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	R60-1719-55	. . WAVEGUIDE, assembly, flexible	1	—	70/60
R	R60-7037-01	. . WAVEGUIDE, assembly	1	—	70/61
R	R60-1719-53	. . WAVEGUIDE, assembly, flexible	2	—	70/62
R	CS3809/3	. . WAVEGUIDE, assembly	1	—	70/63
R	CS3813	. . WAVEGUIDE, assembly	1	—	70/64
R	CS4056	. . WAVEGUIDE, assembly, flexible	2	—	70/65
R	—	. . WAVEGUIDE TO SWITCH CONNECTION (Typical) Consisting of:—	—	—	—
R	R60-1761-52	. . . BOLT	4	—	70/66
R	5985-99-083-0053	. . . RING, sealing	1	—	70/67
R	MS90064-13	. . . RING, sealing	1	—	70/68
R	SP47/X	. . . WASHER, spring	4	—	70/69

I/J BAND JAMMER SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	GA OF I/J BAND JAMMER SYSTEM IN CENTRE FUSELAGE (EG7.82.5261) (Mod.5466) Spares for:—	—	—	71/1
EG7.82.5481	. CABLE, assembly, BJF2	1	—	
EG7.82.5487	. CABLE, assembly, BJR2	1	—	
EG7.82.5483	. CABLE, assembly, BJF3	1	—	
EG7.82.5489	. CABLE, assembly, BJR3	1	—	
R —	. GA of wave guides in pack bay (EG7.82.5029) Spares for:—	—	—	71/3
R —	. . ALTS to waveguide installation in centre fuselage (EG7.82.5033) (Mod.5466) Spares for:—	—	—	85/1
R EG7.82.6023	. . . ARM, link Attaching parts:— (At upper pivot)	1	L165 x 2 mm	85/2
R A256/D0426	. . . Bolt, 1/4" UNF	1	—	85/3
R AN310-4	. . . Nut, 1/4" slotted	1	—	85/4
R SP90/B	. . . Pin, split	1	—	85/5
R EG7.82.6027	. . . Spacer	1	S130	85/6
R SP123/E	. . . Washer	QR	—	85/7
R SP126/E	. . . Washer	QR	—	85/8
R EG7.82.6019	. . . BRACKET, upper pivot	1	L65 x 1.6 mm	85/9
R EG7.82.6025	. . . CLAMP, waveguide Spares for:—	2	—	85/10
R EG7.82.6025A	 CLAMP	1	—	85/11
R EG7.82.6025B	 SPACER/PACKER Attaching parts for EG7.82.6025:—	1	L65	85/12
R A25-4C	. . . Bolt, 2 BA, hex hd	2	—	85/13
R A25-8C	. . . Bolt, 2 BA, hex hd	2	—	85/14
R SP124/D	. . . Washer	4	—	85/15
R EG7.82.6021	. . . PIVOT, guide support Spares for:—	1	—	85/16
R EG7.82.6021A	 CHANNEL	1	L165 x 1.6 mm	85/17
R AGS2007/C/1	 NUT, anchor, 2 BA Attaching parts for EG7.82.6021:—	4	—	85/18
R A256/D0426	. . . Bolt, 1/4" UNF	1	—	85/19
R AN310-4	. . . Nut, 1/4" slotted	1	—	85/20
R SP90/B	. . . Pin, split	1	—	85/21
R EG7.82.6027	. . . Spacer	1	S130	85/22
R SP123/E	. . . Washer	QR	—	85/23
R SP126/E	. . . Washer	QR	—	85/24
R AGS567/A	. . . Washer, fibre	2	—	85/25
R EG7.82.6029	. . . PACKING	QR	L164 x 1.6 mm	85/26
R EG7.82.6031	. . . PACKING	QR	L164 x 3 mm	85/27
R EG7.82.6033	. . . PACKING	QR	L164 x 1.6 mm	85/28
R EG7.82.6035	. . . PACKING	QR	L164 x 2.5 mm	85/29
R EG7.82.6037	. . . PACKING	QR	L164 x 1.6 mm	85/30
R EG7.82.6039	. . . PACKING	QR	L164 x 2.5 mm	85/31

I/J BAND JAMMER SYSTEM

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG7.82.5809	.	.	ANGLE, 16 SWG				2	L164	71/4
EG7.82.5811	.	.	ANGLE, 16 SWG				2	L164	71/5
EG7.82.5791	.	.	ANGLE, support				2	EEJ441	71/6
EG7.82.5701	.	.	BRACKET, 1.2 mm				4	L165	71/7
EG7.82.5703	.	.	BRACKET, 1.2 mm				1	L165	71/8
EG7.82.5739	.	.	BRACKET, 18 SWG				1	L164	71/9
EG7.82.5731	.	.	BRACKET, 18 SWG				1	L164	71/10
EG7.82.5737	.	.	BRACKET, 16 SWG				1	L164	71/11
			Attaching parts:—						
A25/2C	.	.	Bolt, 2 BA				4	—	71/12
SP124/D	.	.	Washer, plain				4	—	71/13
EG7.82.5747	.	.	BRACKET, 16 SWG				2	L164	71/14
EG7.82.5749	.	.	BRACKET, 16 SWG				1	L164	71/15
EG7.82.5807	.	.	BRACKET, 16 SWG				1	L164	71/16
CS5469	.	.	BLANK, pressure				4	—	71/17
			Attaching parts:—						
A102/9C	.	.	Bolt				4	—	71/18
A125C-66	.	.	Nut				4	—	71/19
SP122/C	.	.	Washer				4	—	71/20
EG7.82.5733	.	.	CLIP, 18 SWG				7	L164	71/21
			Attaching parts:—						
A25/1C	.	.	Bolt, 2 BA				1	—	71/22
A25/2C	.	.	Bolt, 2 BA				1	—	71/23
SP124/D	.	.	Washer				2	—	71/24
EG7.82.5179	.	.	CLIP, 1.2 mm				2	L164	71/28
			Attaching parts:—						
A25/1C	.	.	Bolt, 2 BA				2	—	71/29
SP124/D	.	.	Washer				2	—	71/30

I/J BAND JAMMER SYSTEM

Part Number	Description 1 2 3 4 5 6	No. Off	Mati. Spec.	Plate No.

I/J BAND JAMMER SYSTEM

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG7.82.1389	. .	CLIP (at sub-frame)	2	—	71/31
A25/1C	. .	Attaching parts:— Bolt, 2 BA	2	—	71/32
EG7.82.5173	. .	Packer	1	BS2572-LFS	71/33
SP124/D	. .	Washer, plain	2	—	71/34
EG7.82.1389	. .	CLIP (at frame 13)	2	—	71/35
A25/1C	. .	Attaching parts:— Bolt, 2 BA	1	—	71/36
A25/2C	. .	Bolt, 2 BA	1	—	71/37
SP124/D	. .	Washer, plain	2	—	71/38
EG7.82.2533	. .	CLIP, bonding (at frame 29)	4	—	71/39
A25/1C	. .	Attaching parts:— Bolt, 2 BA	1	—	71/40
AGS2001/C/1-66	. .	Nut, stiff, 2 BA	1	—	71/41
SP124/D	. .	Washer, plain	2	—	71/42
EG7.82.2533	. .	CLIP, bonding (at frame 13 to 24 and sub-frame)	34	—	71/43
A25/2C	. .	Attaching parts:— Bolt, 2 BA	1	—	71/44
AGS2001/C/1-66	. .	Nut, stiff, 2 BA	1	—	71/45
SP124/D	. .	Washer, plain	2	—	71/46
	. .	EARTH POINT (2 positions on frame 29) Consisting of:—	2	—	
A25/2C	. . .	BOLT, 2 BA	1	—	72/1
AGS2001/C/1-66	. . .	NUT, stiff, 2 BA	1	—	72/2
SP124/D	. . .	WASHER, plain	1	—	72/3
	. .	EARTH POINT (On frames 13, 14, 15, 17, 19, 21, 23 and on sub-frame at 5 positions) Consisting of:—	11	—	
A25/1C	. . .	BOLT, 2 BA	1	—	72/4
SP124/D	. . .	WASHER, plain	1	—	72/5
AS3360/C/4C	. .	LEAD, bonding	11	—	72/6
AS3360/C/6C	. .	LEAD, bonding	16	—	72/7
EG7.82.5169	. .	MEMBER, "T"	3	EEDX344	72/8
EG7.82.5171	. .	MEMBER, "T"	3	EEDX344	72/9
AGS2007/C/1	. .	NUT, anchor (on frame 13)	4	—	72/10
EG7.82.5181	. .	PACKER	2	BS2572-LFS	72/12
EG7.82.5803	. .	PACKER	6	BS2572-LFS	72/13

I/J BAND JAMMER SYSTEM

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.82.5813	.	.	.	PACKER	16 SWG		1	L164	72/14
R EG7.82.5175	.	.	.	PLATE, stiffener			2	2mm-L164	72/15
R EG7.82.5177	.	.	.	PLATE, stiffener			1	2mm-L164	72/16
R SIC6316	.	.	.	RING, sealing			4	-	72/17
R SIC6772	.	.	.	RING, sealing			30	-	72/18
R EG7.82.5805	.	.	.	SPACER			2	BS2572-LFS	72/19
R CS3807/3	.	.	.	WAVEGUIDE			2	-	72/20
R CS3817	.	.	.	WAVEGUIDE			1	-	72/21
R CS3816	.	.	.	WAVEGUIDE			1	-	72/22
R CS4056	.	.	.	WAVEGUIDE			4	-	72/23
R CS3960	.	.	.	WAVEGUIDE			1	-	72/24
R CS3811/2	.	.	.	WAVEGUIDE			1	-	72/25
R CS3770	.	.	.	WAVEGUIDE			1	-	72/26
R CS3811/1	.	.	.	WAVEGUIDE			1	-	72/27
R CS3812	.	.	.	WAVEGUIDE			1	-	72/28
R CS4057	.	.	.	WAVEGUIDE			2	-	72/29
R CS4055	.	.	.	WAVEGUIDE			2	-	72/30
R CS3810	.	.	.	WAVEGUIDE			2	-	72/31
R CS3809/1	.	.	.	WAVEGUIDE			1	-	72/32
R CS3809/2	.	.	.	WAVEGUIDE			1	-	72/33
R CS3808	.	.	.	WAVEGUIDE			2	-	72/34
R CS3807/1	.	.	.	WAVEGUIDE			1	-	72/35
R CS3807/2	.	.	.	WAVEGUIDE			1	-	72/36
R -	.	.	.	WAVEGUIDES TO MAIN UNIT			-	-	
				ARI.23363					
				Attaching parts:-					
R R60-1761-52	.	.	.	Bolt			8	-	72/37
R SP122/C	.	.	.	Washer			8	-	72/38
R SP47/X	.	.	.	Washer, spring			8	-	72/39
R -	.	.	.	WAVEGUIDE FLANGE TO FLANGE CONNECTION			-	-	
				(Typical)					
				Attaching parts:-					
R A102/3C	.	.	.	Bolt			4	-	72/40
R A125/C66	.	.	.	Nut, self locking			4	-	72/41
R SP122/C	.	.	.	Washer			8	-	72/42
R -	.	.	.	INSTALLATION OF ARI.23363 main units			-	-	73/1
				mounting structure in pack bay,					
				aft (EG7.82.5025)					
				Spares for:-					
R A102/5E	.	.	.	BOLT, 1/4" UNF			20	-	73/2
R A25/1C	.	.	.	BOLT, 2 BA			4	-	73/3
R A25/1G	.	.	.	BOLT, 5/16" BSF			6	-	73/4
R EG7.82.5877	.	.	.	LABEL			1	-	73/5
R EG7.82.5875	.	.	.	LABEL			1	-	73/6
R AGS2007/C/1	.	.	.	NUT, anchor, 2 BA			4	-	73/7

I/J BAND JAMMER SYSTEM

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	. . . STRUCTURE, equipment mounting (EG7.82.5043) Spares for:—	—	—	73/8
R	EG7.11.5239	. . . CHANNEL, assembly Spares for:—	3	—	73/9
R	EG7.11.199	 BLOCK	4	—	73/10
R	EG7.11.198	 BLOCK, bearing	2	—	73/11
R	EG7.11.197	 BLOCK, bearing	2	—	73/12
R	EG7.11.189	 BRACKET	1	—	73/13
R	EG7.11.191	 BRACKET	1	—	73/14
R	EG7.11.981	 CHANNEL, assembly Spares for:—	1	—	73/15
R	EG7.11.187	 CHANNEL	1	—	73/16
R	EG7.11.193	 PIN	2	—	73/17
R	EG7.11.201	 PIN, locating Attaching parts:—	1	—	73/18
R	AGS2001/E/1-66	 Nut, stiff, 1/4" BSF	1	—	73/19
R	SP13E	 Washer	1	—	73/20
R	EG7.11.195	 ROLLER Attaching parts for EG7.11.5239:—	2	—	73/21
R	AS1242/3C	 Bolt, 2 BA, c'sk head	8	—	73/22
R	AGS2001/C/1-66	 Nut, stiff, 2 BA	8	—	73/23
R	SP122/D	 Washer	8	—	73/24
R	EG7.82.5875	 LABEL	1	—	73/25
R	EG7.82.5133	 PACKING	6	—	73/26
R	EG7.82.5045	 PLATE	1	—	73/27
R	EG7.82.5139	 PLATE	1	—	73/28
R	—	. . . STRUCTURE, equipment, mounting (EG7.82.5044) Spares for:—	—	—	73/29
R	EG7.11.5239	. . . CHANNEL, assembly Spares for:—	3	—	73/30
R	EG7.11.199	 BLOCK	4	—	73/31
R	EG7.11.198	 BLOCK, bearing	2	—	73/32
R	EG7.11.197	 BLOCK, bearing	2	—	73/33
R	EG7.11.189	 BRACKET	1	—	73/34
R	EG7.11.191	 BRACKET	1	—	73/35
R	EG7.11.981	 CHANNEL, assembly Spares for:—	1	—	73/36
R	EG7.11.187	 CHANNEL	1	—	73/37
R	EG7.11.193	 PIN	2	—	73/38
R	EG7.11.201	 PIN, locating Attaching parts:—	1	—	73/39
R	AGS2001/E/1-66	 Nut, stiff, 1/4" BSF	1	—	73/40
R	SP13/E	 Washer	1	—	73/41

I/J BAND JAMMER SYSTEM

Part Number	Description						No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.11.195	.	.	.	.	ROLLER		2	-	73/42
R AS1242/3C	.	.	.	.	Attaching parts for EG7.11.5239:-		8	-	73/43
R AGS2001/C/1-66	.	.	.	.	Bolt, 2 BA, c'sk head		8	-	73/44
R SP122/D	.	.	.	.	Nut, stiff, 2 BA		8	-	73/45
R EG7.82.5877	.	.	.	.	Washer		1	-	73/46
R EG7.82.5133	.	.	.	.	LABEL		6	-	73/47
R EG7.82.5046	.	.	.	.	PACKING		1	-	73/48
R EG7.82.5140	.	.	.	.	PLATE		1	-	73/49
R SP122/G	.	.	.	.	PLATE		6	-	73/50
R SP122/E	.	.	.	.	WASHER		20	-	73/51
R SP122/D	.	.	.	.	WASHER		4	-	73/52

I/J BAND JAMMER SYSTEM

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	—	GA OF I/J BAND JAMMER SYSTEM IN REAR FUSELAGE (EG7.82.5271) (Mod 5466) Spares for:—	—	—	
R	—	. AERIALS, REAR LOOKING, INSTALLATION (EG7.82.2595) (See page MC1)	—	—	
R	—	. WAVEGUIDES, FROM AFT END OF BOMB BAY TO TAIL CONE ASSEMBLY (EG7.82.5695) (See page MC1)	—	—	

E S M RECEIVER ARI.23361/0

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	GA OF ESM RECEIVER ARI.23361/0 SPECTRUM ANALYSER (EG7.82.5291) (Mod 5466) Spares for:—	—	—	74/1
R	UG306AU or G35028	. ADAPTER	1	—	74/2
R	A691/5	. ADAPTER	1	—	
R	JLA2-11110	. AMPLIFIER	1	—	74/3
R	SCSHQ127729A1	. ANALYSER, spectrum	1	—	74/4
R	TEK4041	. ANTENNA, assembly (See page M1)	1	—	
R	—	. COMPUTER, controller	1	—	74/5
R	—	. CLIPPING of aerial feeder cable on bulkhead 29 (EG7.82.5929) Spares for:—	—	—	75/1
R	PAN6483/AA	. RETAINER, cable	4	—	75/2
R	LKOB-HS-B	. TIE, cable, insulok	QR	—	75/3
R	118-0070-00	. DETECTOR, audio	1	—	74/6
R	—	. GA of ESM Receiver ARI.23361-0 in front fuselage (EG7.82.5253) Spares for:—	—	—	
R	EG7.82.5663	. CABLE, assembly, ESM1	1	—	
R	EG7.82.5665	. CABLE, assembly, ESM1A	1	—	
R	EG7.82.5667	. CABLE, assembly, ESM2	1	—	
R	EG7.82.5671	. CABLE, assembly, ESM3	1	—	
R	EG7.82.5679	. CABLE, assembly, ESM5	1	—	
R	EG7.82.5673	. CABLE, assembly, ESM7	1	—	
R	EG7.82.5899	. CABLE, assembly, ESM6	1	—	
R	—	. GA of Spectrum Analyser mounting in aircraft (EG7.82.3161) Spares for:—	—	—	
R	—	 INSTALLATION of Analyser in crate (EG7.82.3163) Spares for:—	—	—	
R	EG7.82.3157	 CRATE, mounting/rail assembly Spares for:—	1	—	74/7
R	EG7.82.3103	 CRATE, assembly Spares for:—	1	—	74/8
R	EG7.82.3111	 BAR, support, top	2	—	74/9
R	EG7.82.3113	 BAR, support	4	—	74/10
R	EG7.82.3115	 BOLT, retainer	2	—	74/11
R	EG7.82.3107	 HOUSING, quick release	2	—	74/12
R	A58/ST	 NUT, 3/4" BSF	2	—	74/13

E S M RECEIVER ARI.23361/0

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.82.3121	.	.	.	.	.	SIDEPLATE, port	1	—	74/14
						Attaching parts:—			
R A27/ES	.	.	.	.	.	Nut, 1/4" BSF, slotted	6	—	74/15
R SP90/C8	.	.	.	.	.	Pin, split	6	—	74/16
R SP124/E	.	.	.	.	.	Washer	6	—	74/17
R EG7.82.3123	.	.	.	.	.	SIDEPLATE, stbd.	1	—	74/18
						Attaching parts:—			
R A27/ES	.	.	.	.	.	Nut, 1/4" BSF, slotted	6	—	74/19
R SP90/C8	.	.	.	.	.	Pin, split	6	—	74/20
R SP124/E	.	.	.	.	.	Washer	6	—	74/21
R EG7.82.3109	.	.	.	.	.	SPIGOT, fixed	2	—	74/22
R SP124/S	.	.	.	.	.	WASHER	2	—	74/23
R SP125/E	.	.	.	.	.	WASHER (if required)	2	—	74/24
R EG7.82.3155	.	.	.	.	.	RAIL, male	2	—	74/25
						Attaching parts:—			
R AS1242/11E	.	.	.	.	.	Bolt, 1/4" BSF, c'sk head	3	—	74/26
R A27/ES	.	.	.	.	.	Nut, 1/4" BSF, slotted	3	—	74/27
R SP90/C8	.	.	.	.	.	Pin, split	3	—	74/28
R SP125/E	.	.	.	.	.	Washer	3	—	74/29
R PR1422	.	.	.	.	.	SEALANT	QR	—	
R —	.	.	.	.	.	GA of ESM Receiver, ARI.23361-0	—	—	
						in centre fuselage			
						(EG7.82.5255)			
						Spares for:—			
R EG7.82.5669	.	.	.	.	.	CABLE, assembly, ESM2A	1	—	
R EG7.82.5845	.	.	.	.	.	GUARD, aerial, footstep assembly	1	—	75/4
						Spares for:—			
R EG7.82.5837	.	.	.	.	.	ANGLE	1	—	75/5
R EG7.82.5838	.	.	.	.	.	ANGLE	1	—	75/6
R EG7.82.5829	.	.	.	.	.	LEG, assembly	2	—	75/7
R EG7.82.5823	.	.	.	.	.	MEMBER, fore/aft assembly	2	—	75/8
R EG7.82.5833	.	.	.	.	.	MEMBER, support assembly	2	—	75/9
R EG7.82.5819	.	.	.	.	.	MEMBER, cross assembly	2	—	75/10
						Attaching parts:—			
R A25/1C	.	.	.	.	.	Bolt, 2 BA	2	—	75/11
R SP124/D	.	.	.	.	.	Washer, plain	2	—	75/12
R EG7.82.5817	.	.	.	.	.	MEMBER, cross	1	—	75/13
						Attaching parts:—			
R A25/1C	.	.	.	.	.	Bolt, 2 BA	2	—	75/14
R SP124/D	.	.	.	.	.	Washer, plain	2	—	75/15

E S M RECEIVER ARI.23361/0

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	EG7.82.5827	. . PLATE, gusset	8	~	75/16
R	EG7.82.5835	. . STEP	1	~	75/17
		Attaching parts:—			
R	AS1248/4C	. . Bolt, mushroom head, 2 BA	4	~	75/18
R	—	. . WALKWAY (3M's) BAe, bin No. 3953-432-1	QR	~	75/19
		Attaching parts for EG7.82.5845:—			
R	A25/1C	. Bolt, 2 BA	4	~	75/20
R	A25/2C	. Bolt, 2 BA	4	~	75/21
R	AGS2001/C/1-66	. Nut, stiff, 2 BA	4	~	75/22
R	SP124/D	. Washer, plain	8	~	75/23
R	EG7.82.5891	. PLATE, retaining	1	~	74/30
		Attaching parts:—			
R	EG7.82.5893	. Screw, special, 4-40 UNC	2	~	74/31
R	AGS2035/A	. Washer	2	~	74/32
R	523-862	. SCREW, pan head	4	~	74/33
R	AGS2035/B	. WASHER	4	~	74/34

E S M RECEIVER ARI.23361/0

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	—	ALTERATIONS REQUIRED TO SPECTRUM ANALYSER FOR INSTALLATION IN AIRCRAFT (EG7.82.3117) (Mod 5466) Spares for:—	—	—	76/1
R	492P	. ANALYSER, spectrum	1	—	76/2
R	EG7.82.5727	. COVER, sealing Attaching parts:—	1	—	76/3
R	A205/A6	. Screw, pan head, 4-40 UNC	2	—	76/4
R	EG7.82.5607	. GASKET	4	—	76/5
R	EG7.82.3119	. PACKING	2	—	76/6
R	EG7.82.5895	. PILLAR, spacing	2	—	76/7
R	PAN6480/K06	. TUBING, heatshrink	QR	—	

ARI.23166 AND ARI.23167

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R	—	GA OF ARI.23166 AND ARI.23167 IN AIRCRAFT (EG7.82.5211) (Mod 5466) Spares for:—					—	—	77/1
R	TYPE 644	. AERIAL, NARDA horn					2	—	77/2
R	HD609	. COOLER, liquid, ARI.23166					3	—	77/3
R	—	. GA of ARI.23166/7, equipment in centre fuselage (EG7.82.5215) Spares for:—					—	—	78/1
R	EG7.82.1713	. . CABLES, co-axial in centre fuselage installation (EG7.82.1713) (See page MA5)					—	—	
R	EG7.82.852	. . CONNECTOR, assembly CR4 (See page MA11)					1	—	
R	EG7.82.853	. . CONNECTOR, assembly CR5 (See page MA11)					1	—	
R	EG7.82.854	. . CONNECTOR, assembly CR6 (See page MA11)					1	—	
R	EG7.82.858	. . CONNECTOR, assembly CR10 (See page MA11)					1	—	
R	EG7.82.860	. . CONNECTOR, assembly CR12					1	—	
R	EG7.82.5647	. . CONNECTOR, assembly CR13					1	—	
R	EG7.82.876	. . CONNECTOR, assembly CR28 (See page MA11)					2	—	
R	EG7.82.877	. . CONNECTOR, assembly CR29 (See page MA11)					3	—	
R	EG7.82.878	. . CONNECTOR, assembly CR30 (See page MA11)					1	—	
R	EG7.82.884	. . CONNECTOR, assembly CR36 (See page MA12)					1	—	
R	—	. . INSTALLATION of tray assemblies in bomb bay packs (EG7.82.5649) Spares for:—					—	—	78/2
R	EG7.82.973	. . . LEAD, flexible Spares for:—					12	—	78/3
R	EG7.82.789	 BOLT, special, 2 BA					2	S1	78/4
R	EG7.82.791	 WASHER, tapped, 2 BA					2	S510	78/6
R	EG7.82.761	 TRAY, No.8					1	—	78/7
R	EG7.82.767	 TRAY, No.5					1	—	78/8
R	EG7.82.769	 TRAY, No.6					1	—	78/9
R	EG7.82.773	 TRAY, No.10					1	—	78/10
R	EG7.82.779	 TRAY, No.5 (For Alt 15H equipment)					1	—	78/11
R	EG7.82.781	 TRAY, No.7 (For Alt 15H equipment)					1	—	78/12
R	EG7.82.785	 TRAY, No.9					1	—	78/13
R	EG7.82.787	 TRAY, No.7					1	—	78/14

ARI.23166 AND ARI.23167

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	—	. GA of ARI.23166/7 in front fuselage (EG7.82.5213) Spares for:—	—	—	79/1
R	—	. . ANTENNA, "D" band installation (EG7.82.3063) Spares for:—	—	—	79/2
R	EG7.82.5755	. . . ANGLE	4	1.6mm-L165	79/3
R	4-40	. . . ANTENNA, "D" Attaching parts:—	1	—	79/4
R	AS1248/4C	. . . Bolt, mushroom head, 2 BA	6	—	79/5
R	6930A4/40	. . . Gasket	1	—	79/6
R	SP124/D	. . . Washer	6	—	79/7
R	EG7.82.5753	. . . BASE, mounting bracket	1	1.6mm-L165	79/8
R	A25/2C	. . . BOLT, 2 BA	8	—	79/9
R	AGS2007/C/2	. . . NUT, anchor	6	—	79/10
R	EG7.82.3133	. . . PACKER	2	L165	79/11
R	EG7.82.3135	. . . PACKER	2	L165	79/12
R	—	. . . PACKING (For aircraft WD955, WJ981 and WJ607)	1	1.25mm-L164	—
R	EG7.82.3065	. . . PLATE, assembly Spares for:—	1	—	79/13
R	EG7.82.3069	 PACKING 16 SWG	1	L165	79/14
R	EG7.82.3067	 PANEL 14 SWG	1	L165	79/15
R	SP124/D	. . . WASHER	8	—	79/16
R	—	. . CABLES, co-axial in front fuselage (EG7.82.5007) Spares for:—	—	—	—
R	UG27CU	 ADAPTER	1	—	—
R	79825	 ADAPTER	2	—	—
R	2-156DG14469	. . . CABLE, assembly "S"	1	—	—
R	2-156DG14466	. . . CABLE, assembly "S"	1	—	—
R	X156DG002020	. . . CABLE, co-ax, "S" Band	2	—	—
R	X156DG002021	. . . CABLE, co-ax, "M" Band	1	—	—
R	EG7.82.3091	. . . CONNECTOR, CR38	1	—	—
R	EG7.82.3093	. . . CONNECTOR, CR39	1	—	—
R	EG7.82.3095	. . . CONNECTOR, CR40	1	—	—
R	—	. . . MOUNTING of aerial switch unit Type AA27703-1 (EG7.82.3081) Spares for:—	—	—	77/12
R	EG7.82.3083	 PLATE, mounting assembly Spares for:—	1	—	77/13
R	LN29990A04M	 NUT, anchor	3	—	77/14
R	EG7.82.5801	 PLATE, mounting Attaching parts for EG7.82.3083:—	1	—	77/15
R	A25/2C	 Bolt, 2 BA	2	—	77/16
R	AGS2001/C/1-66	 Nut, stiff, 2 BA	2	—	77/17
R	SP124/D	 Washer	2	—	77/18
R	AA27703-1	 UNIT-SWITCH	1	—	77/19
R	EG7.82.5511	. . . CONNECTOR, assembly NR4	1	—	—
R	EG7.82.5519	. . . CONNECTOR, assembly NR10	1	—	—
R	EG7.82.5505	. . . CONNECTOR, CR41	1	—	—
R	EG7.82.5507	. . . CONNECTOR, CR42	1	—	—
R	EG7.82.5509	. . . CONNECTOR, CR43	1	—	—
R	EG7.82.5767	. . . CONNECTOR, assembly, NR5	1	—	—
R	EG7.82.5769	. . . CONNECTOR, assembly, NR6	1	—	—

ARI.23166 AND ARI.23167

Part Number	Description						No. Off	Matl. Spec.	Plate No.	
	1	2	3	4	5	6				
R	—	. . . INSTALLATION of NARDA horn aerals (EG7.10.5001) Spares for:—						—	—	80/1
R	EG7.10.10135	 ANGLE						1	1.2mm-L164	80/2
R	EG7.10.10136	 ANGLE						1	1.2mm-L164	80/3
R	EG7.10.5027	 ANGLE						1	EEJ96/18 or 1.2mm-L164	80/4
R	EG7.10.5028	 ANGLE						1	EEJ96/18 or 1.2mm-L164	80/5
R	EG7.10.10117	 BRACKET, mounting Attaching parts:—						2	—	80/6
R	A25/3C	 Bolt, 2 BA						4	—	80/7
R	A59/3E	 Bolt, 1/4" BSF						1	—	80/8
R	SP124/D	 Washer						4	—	80/9
R	SP122/E	 Washer						1	—	80/10
R	EG7.10.10118	 BRACKET, mounting Attaching parts:—						2	—	80/11
R	A25/3C	 Bolt, 2 BA						4	—	80/12
R	A59/3E	 Bolt, 1/4" BSF						1	—	80/13
R	SP124/D	 Washer						4	—	80/14
R	SP122/E	 Washer						1	—	80/15
R	EG7.10.10129	 BRACKET, assembly Spares for:—						8	—	80/16
R	EG7.10.5015	 BRACKET						1	1.6mm-S514	80/17
R	AGS2007/E/1	 NUT, anchor						1	—	80/18
R	EEAS18/5/ER	 PACKING						1	—	80/19
		Attaching parts for EG7.10.10129:—								
R	A25/8E	 Bolt, 1/4" BSF						2	—	80/20
R	AGS2001/E/1-66	 Nut						2	—	80/21
R	SP124/E	 Washer						2	—	80/22
R	EG7.10.10137	 BRACKET, assembly Spares for:—						2	—	80/23
R	EG7.10.5003	 BRACKET						1	1.6mm-L164	80/24
R	EE11/2	 SECTION, extruded						QR	—	80/25
		Attaching parts for EG7.10.10137:—								
R	A25/2C	 Bolt, 2 BA						2	—	80/26
R	EEAS27/22/HR	 Washer						2	—	80/27
R	EG7.10.10138	 BRACKET, assembly Spares for:—						2	—	80/28
R	EG7.10.5004	 BRACKET						1	—	80/29
R	EE11/2	 SECTION, extruded						QR	—	80/30
		Attaching parts for EG7.10.10138:—								
R	A25/2C	 Bolt, 2 BA						2	—	80/31
R	EEAS27/22/HR	 Washer						2	—	80/32

ARI.23166 AND ARI.23167

	Part Number	Description						No. Off	Matl. Spec.	Plate No.
		1	2	3	4	5	6			
R	EG7.10.10139	. . .	BRACKET, assembly					2	—	80/33
			Spares for:—							
R	EG7.10.5005		BRACKET					1	1.6mm-L164	80/34
R	AGS2007/C/1		NUT, anchor					4	—	80/35
R	EE11/2		SECTION, extruded					QR	—	80/36
			Attaching parts for EG7.10.10139:—							
R	A25/2C	. . .	Bolt, 2 BA					4	—	80/37
R	EEAS27/22/HR	. . .	Washer					4	—	80/38
R	EG7.10.10141	. . .	BRACKET, assembly					2	—	80/39
			Spares for:—							
R	EG7.10.5007		BRACKET					1	2mm-L164	80/40
R	AGS2007/C/1		NUT, anchor					2	—	80/41
R	EE11/2		SECTION, extruded					QR	—	80/42
			Attaching parts for EG7.10.10141:—							
R	A25/3C	. . .	Bolt, 2 BA					2	—	80/43
R	EG7.10.10145	. . .	Packer, 0.2" thick					2	L164	80/44
R	—	. . .	BRACKET, co-ax, cable support					—	—	81/1
			installation (EG7.82.2133)							
			Spares for:—							
R	EG7.82.2423		CHANNEL, assembly					1	—	81/2
			Spares for:—							
R	EG7.82.2137		CHANNEL					1	—	81/3
R	AGS2007/C/1		NUT, anchor					3	—	81/4
R	AGS2018/C/1		NUT, anchor					4	—	81/5
			Attaching parts for EG7.82.2423:—							
R	A25/1C		Bolt, 2 BA					4	—	81/6
R	SP13/C		Washer					4	—	81/7
R	EG7.82.2425		CLAMP, assembly					1	—	81/8
			Spares for:—							
R	EG7.82.2139		CLAMP					1	—	81/9
R	EG7.82.2427		LINER					2	—	81/10
R	EG7.82.2429		LINER					2	—	81/11
			Attaching parts for EG7.82.2425:—							
R	A25/15C		Bolt, 2 BA					3	—	81/12
R	AS2230/404		Rivet, c'sk head, 1/8" dia.					2	—	81/13
R	AS2306/138		Tube, distance					3	—	81/14
R	SP13/C		Washer					3	—	81/15
R	EG7.82.2421		DIAPHRAGM	18	SWG			1	L72	81/16
R	EG7.82.2422		DIAPHRAGM	18	SWG			1	L72	81/17
R	EG7.82.2431		PLATE					1	—	81/18
R	EG7.10.10107	. . .	CHANNEL					1	1.2mm-L164	82/1

ARI.23166 AND ARI.23167

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.10.10109	.	.	.	CHANNEL, assembly			1	-	82/2
				Spares for:-					
R EG7.10.5023	.	.	.	CHANNEL			1	EEDX278	82/3
R AGS2007/E/1	.	.	.	NUT, anchor			2	-	82/4
R AGS2007/C/1	.	.	.	NUT, anchor			8	-	82/5
				Attaching parts for EG7.10.10109:-					
R A25/2E	.	.	.	Bolt, 1/4" BSF			8	-	82/6
R AGS2001/E/1-66	.	.	.	Nut			8	-	82/7
R SP124/E	.	.	.	Washer			8	-	82/8
R EG7.10.10111	.	.	.	CHANNEL			1	EEDX278	82/9
				Attaching parts:-					
R A25/3E	.	.	.	Bolt, 1/4" BSF			1	-	82/10
R SP124/E	.	.	.	Washer			1	-	82/11
R EG7.10.10112	.	.	.	CHANNEL			1	EEDX278	82/12
				Attaching parts:-					
R A25/3E	.	.	.	Bolt, 1/4" BSF			1	-	82/13
R SP124/E	.	.	.	Washer			1	-	82/14
R EG7.10.10113	.	.	.	CHANNEL, assembly			1	-	82/15
				Spares for:-					
R EG7.10.5017	.	.	.	CHANNEL			1	EEDX278	82/16
R AGS2007/C/1	.	.	.	NUT, anchor			8	-	82/17
				Attaching parts for EG7.10.10113:-					
R A25/3C	.	.	.	Bolt, 2 BA			8	-	82/18
R SP124/D	.	.	.	Washer			8	-	82/19
R EG7.10.10115	.	.	.	CHANNEL, assembly			1	-	82/20
				Spares for:-					
R EG7.10.5019	.	.	.	CHANNEL			1	EEDX278	82/21
R AGS2007/C/1	.	.	.	NUT, anchor			8	-	82/22
R EG7.10.10151	.	.	.	CHANNEL, assembly			2	-	82/23
				Spares for:-					
R EG7.10.5021	.	.	.	CHANNEL			1	-	82/24
R AGS2007/C/1	.	.	.	NUT, anchor			2	-	82/25
R EG7.10.10143	.	.	.	CHANNEL, assembly			1	-	82/26
				Spares for:-					
R EG7.10.5009	.	.	.	CHANNEL			1	1.2mm-L164	82/27
R AGS2007/C/1	.	.	.	NUT, anchor			3	-	82/28
R EG7.10.10144	.	.	.	CHANNEL, assembly			1	-	82/29
				Spares for:-					
R EG7.10.5010	.	.	.	CHANNEL			1	1.2mm-L164	82/30
R AGS2007/C/1	.	.	.	NUT, anchor			3	-	82/31

ARI.23166 AND ARI.23167

Part Number	Description						No. Off	Mati. Spec.	Plate No.
	1	2	3	4	5	6			
R EG7.10.5029	.	.	.	.	CHANNEL, assembly		1	—	82/32
R EG7.10.5031	.	.	.	.	Spares for:—		1	1.2mm-L164	82/33
R AGS2007/C/1	.	.	.	.	CHANNEL		3	—	82/34
R EG7.10.5030	.	.	.	.	NUT, anchor		1	—	82/35
R EG7.10.5032	.	.	.	.	CHANNEL, assembly		1	1.2mm-L164	82/36
R AGS2007/C/1	.	.	.	.	Spares for:—		3	—	82/37
R EG7.10.10119	.	.	.	.	CHANNEL		8	1.6mm-L164	82/38
	.	.	.	.	NUT, anchor			or	
	.	.	.	.	CLEAT			EEJ90-	
R EG7.10.10121	.	.	.	.	CLEAT		2	16SWG	82/39
	.	.	.	.	CLEAT			1.6mm-L164	
	.	.	.	.	CLEAT			or	
R EG7.10.10122	.	.	.	.	CLEAT		2	EEJ90-	82/40
	.	.	.	.	CLEAT			16 SWG	
	.	.	.	.	CLEAT			1.6mm-L164	
	.	.	.	.	CLEAT			or	
R EG7.10.10123	.	.	.	.	CLEAT		1	EEJ90-	82/41
R EG7.10.10124	.	.	.	.	CLEAT		1	16SWG	
R EG7.10.10125	.	.	.	.	CLEAT		1	1.2mm-L164	82/42
R EG7.10.10126	.	.	.	.	CLEAT		1	1.2mm-L164	82/43
R EG7.10.10103	.	.	.	.	DIAPHRAGM		1	1.2mm-L164	82/44
R EG7.10.10147	.	.	.	.	LABEL		1	1.2mm-L164	82/45
R EG7.10.10148	.	.	.	.	LABEL		1	—	82/46
R EG7.10.10127	.	.	.	.	PACKER		4	—	82/47
R EG7.10.5001A	.	.	.	.	PACKING, 0.3mm to 2 mm		QR	L65	82/48
R EG7.10.10105	.	.	.	.	PLATE		1	L164	82/49
R EG7.10.10106	.	.	.	.	PLATE		1	1.2mm-L164	82/50
R EG7.10.10149	.	.	.	.	POINTER		1	1.2mm-L164	82/51
R EG7.10.10150	.	.	.	.	POINTER		1	1.2mm-L164	82/52
R C4646	.	.	.	.	INDICATOR, control (ARI23166) (Pre Mod 5534)		3	—	82/53
R C4646	.	.	.	.	INDICATOR, control (ARI23166) (Mod 5534)		1	—	77/4
	.	.	.	.	(Pre Mod 5535)				
R 1.156DG14469	.	.	.	.	INDICATOR, control E/F band (Mod 5534)		2	—	77/4A
R 1.156DG14468	.	.	.	.	INDICATOR, control D band (Mod 5535)		1	—	77/4B
C3324	.	.	.	.	INDICATOR, control, ARI23167		1	—	77/5
RFO-1104/	.	.	.	.	OSCILLATOR, ARI23166		2	—	77/6
ALT21A	.	.	.	.	OSCILLATOR, ARI23166		1	—	77/7
RFBAND1/	.	.	.	.	OUTLET, Type "N"		2	—	77/8
ALT21A	.	.	.	.	PACK, power supply, ARI23167		1	—	77/9
TYPE 10-10	.	.	.	.	(Alternative to Liquid cooler HD609)				
PP2679	.	.	.	.	TRANSMITTER, T915, ARI23166		3	—	77/10
T915	.	.	.	.	TRANSMITTER, T782, ARI23167		1	—	77/11
T782	.	.	.	.	(Alternative to T915 and RFBAND1/ALT21A)				




FIG.1 ELECTRONIC EQUIPMENT IN AIRCRAFT

T MK 17. SECT M




FIG 2 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG.3 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•




FIG 4 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Restricted

TMK.17 SECT M

•

•

•

•

•

•




FIG5 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Restricted

T MK 17 SECT M

•

•

•

•

•

•

•




FIG. 6 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG 7 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG.8 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG 9. ELECTRONIC EQUIPMENT IN FUSELAGE
Restricted

•

•

•

•

•

•

•

Restricted




FIG 10 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Restricted

T MK17 SECT M

•

•

•

•

•

•

•





FIG II. ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Restricted

TMK 17. SECT M






FIG. 12 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG 13. ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

Restricted

TMK 17. SECT M

•

•

•

•

•

•

•




FIG.14 ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG 14A ELECTRONIC EQUIPMENT IN CENTRE FUSELAGE

T MK 17 SECT M

●

●

●

●

●

●

●




FIG15. ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Restricted

TMK 17. SECT M

1

2

3

4

5

6

7




FIG. 16 ELECTRONIC EQUIPMENT IN FRONT FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG.17 ELECTRONIC EQUIPMENT IN FRONT FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG 18 ELECTRONIC EQUIPMENT IN FRONT FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG.19 ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

●

●

●

●

●

●

●




FIG.20 ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

Restricted

T MK.17 SECT M

•

•

•

•

•

•

•




FIG.21 ELECTRONIC EQUIPMENT IN FRONT FUSELAGE

•

•

•

•

•

•

•




FIG.22 ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Restricted

T.MK.17 SECT M

•

•

•

•

•

•

•




FIG.23 ELECTRONIC EQUIPMENT IN REAR FUSELAGE

Restricted

●

●

●

●

●

●

●




FIG.23A ELECTRONIC EQUIPMENT IN REAR FUSELAGE






FIG.24 ELECTRONIC EQUIPMENT IN REAR FUSELAGE
Restricted

•

•

•

•

•

•

•




FIG.25 ELECTRONIC EQUIPMENT IN REAR FUSELAGE
Restricted

•

•


•

•

•

•

•



●

●

●

●

●

●

●

●




FIG.26 RADIO AND RADAR GREEN SATIN (ARI.585I)

10

11

12

13

14

15

16




FIG.27 RADIO AND RADAR H.F. RADIO INSTALLATION (ARI.23090)

Restricted

T.MK 17. SECT M

●

●

●

●

●

●

●




FIG.28 RADIO AND RADAR H.F. RADIO INSTALLATION (ARI.23090)

●

●●

●

●●

●

●●

●●●
●

Restricted

A.L.6




FIG. 29. 1520. I.F.F./SSR. (A.R.I. 23134).
Restricted

T.M.K.7/SECT M

1

2

3

4

5

6

7




FIG 30. 1520. I.F.F./SSR.(A.R.I.23134).

Restricted

T.MK 17. SECT M.








FIG.31 RADIO AND RADAR RADIO ALTIMETER

Restricted










FIG. 33 RADIO COMPASS (ARI.5877)

●

●

●

●

●

●

●




FIG. 34 TACAN (A.R.I. 18107/4)

Restricted






FIG.35 RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

T.MK.17 SECT.M



Restricted

AL 2




FIG. 36 RADIO AND INTERCOM (U.A. 60) (ARI. 23099/7)

Restricted

T MK 17 SECT M

●

●

●

●

●

●

●




FIG.37 U.H.F. INSTALLATION (ARI.18124/1)

T.MK.17 SECT.M






FIG. 38 U.H.F. INSTALLATION (ARI. 18124/1)

Restricted

●

●

●

●

●

●

●




FIG. 39 V.H.F. INSTALLATION (ARI. 23117/1)
Restricted

●

●

●

●

●

●

●




FIG.40 V.O.R./I.L.S. INSTALLATION (ARI.23118)
Restricted

●

●

●

●

●

●

●




FIG.4I .VOR./I.L.S. INSTALLATION (A.R.I. 23118)
Restricted

●

●

●

●

●

●

●




FIG.42 RADIO & INTERCOM (U.A.60) (ARI. 23099/7)

1

2

3

4

5

6

7




FIG.43 RADIO AND RADAR EQUIPMENT






FIG 44 RADIO AND INTERCOM (U.A.60) (ARI.23099/7)

T.MK17.SECT M






FIG 45 RADIO AND RADAR (ARI 23362)






FIG 46 RADIO AND RADAR (ARI 23362)

T.MK 17 SECT M






FIG 47 RADIO AND RADAR (ARI 23362)

•

•

•

•

•

•

•




FIG 48 RADIO AND RADAR (ARI 23362)

•

•

•

•

•

•




FIG 49 RADIO AND RADAR (ARI 23362)

•

•

•

•

•

•

•




FIG 50 RADIO AND RADAR (ARI 23362)

•

•

•

•

•

•

•




FIG 51. RADIO AND RADAR (ARI 23362)






FIG.52 RADIO AND RADAR (ARL 23362)

•

•

•

•

•

•

•






FIG 53 RADIO AND RADAR (ARI 23362)





DETAIL A

FIG.54 RADIO AND RADAR (ARI.23362)






FIG 55 RADIO AND RADAR (ARL23362)






FIG.56 RADIO AND RADAR (ARI. 23362)

T.MK.17 SECT. M

•

•

•

•

•

•

•




FIG.57 RADIO AND RADAR (ARI.23362)






FIG.58 RADIO AND RADAR (ARL23362)






FIG.59 RADIO AND RADAR (ARI.23362)

T.MK.17 SECT. M






FIG.60 RADIO AND RADAR (ARI.23362)






FIG.61 RADIO AND RADAR (ARI.23362)






FIG.62 RADIO AND RADAR (ARI.23362)

•

•


•

•

•

•

•



•

•

•

•

•

•

•




FIG.64 OMEGA NAVIGATION SYSTEM






FIG.65 OMEGA NAVIGATION SYSTEM






FIG.66 OMEGA NAVIGATION SYSTEM






FIG 67 OMEGA NAVIGATION SYSTEM






FIG.68 OMEGA NAVIGATION SYSTEM

T.MK.17 SECT.M







FIG 69 OMEGA NAVIGATION SYSTEM

T MK 17. SECT M

•

•

•

•

•

•

•




FIG 70 I/J BAND JAMMER SYSTEM






FIG. 71 I/J BAND JAMMER SYSTEM






FIG 72 I/J BAND JAMMER SYSTEM






FIG 73 I/J BAND JAMMER SYSTEM

T.MK 17 SECT M






FIG 74 ESM RECEIVER ARI 23361/0







FIG 75 ESM RECEIVER ARI 23361/0

•

•

•

•

•

•

•




FIG 76 ESM RECEIVER ARI 23361/0

•

•

•

•

•

•

•






FIG 77 ARI 23166 AND ARI 23167





•

•

•

•

•

•




FIG 79 ARI 23166 AND ARI 23167






FIG 80 ARI 23166 AND ARI 23167






FIG 81 ARI 23166 AND ARI 23167






FIG 82 ARI 23166 AND ARI 23167

•

•

•

•

•

•




FIG.83 OMEGA NAVIGATION SYSTEM






FIG.84 OMEGA NAVIGATION SYSTEM






FIG.85 I/J BAND JAMMER SYSTEM

