

TANKS

JETTISON WING FUEL TANK, 250-GALLON, PORT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG7.00.237	JETTISONABLE WING FUEL TANK 250 GAL., INSTALLATION PORT (WITH VORTEX GENERATORS LESS DETONATORS) Consisting of:-						1	-	1/23
-	. ATTACHMENT DETAILS DROP TANK TO WING GROUP (EG7.00.61) Consisting of:-						-	-	
EA1.20.2031	. . BOLT, explosive						3	L.40	1/49
EG7.81.2796	. . DETONATOR FORWARD EXPLOSIVE BOLT GROUP Consisting of:-						1	-	1/7
EG7.81.2081	. . . CONDUIT DETONATOR ASSEMBLY (Pre-Mod 5267)						1	-	1/8
EG7.81.4023	. . . CONDUIT DETONATOR ASSEMBLY (Mod 5267) Spares for:-						1	-	
EA1.81.939	 PLUG, detonator						1	-	1/20
A.E.I. TWT11	 TUBING, P.T.F.E.						QR	-	1/22
R 12G9635205	. . . DETONATOR, No.109, Mk.2						1	-	1/29
EEAS146/6	. . . SLEEVE, 1" long						QR	-	1/4
EA1.81.938	. . . SPRING						1	-	1/21
EA1.81.428	. . . TUBE, detonator						1	-	1/27
EG7.81.2797	. . DETONATOR REAR OUTBOARD EXPLOSIVE BOLT GROUP Consisting of:-						1	-	1/9
EG7.81.2082	. . . CONDUIT DETONATOR ASSEMBLY (Pre-Mod 5267)						1	-	1/10
EG7.81.4026	. . . CONDUIT DETONATOR ASSEMBLY (Mod 5267) Spares for:-						1	-	
EA1.81.939	 PLUG, detonator						1	-	1/20
A.E.I. TWT11	 TUBING, P.T.F.E.						QR	-	1/22
R 12G9635205	. . . DETONATOR No.109 Mk.2						1	-	1/29
EEAS146/6	. . . SLEEVE, 1" long						QR	-	1/4
EA1.81.938	. . . SPRING						1	-	1/21
EA1.81.428	. . . TUBE, detonator						1	-	1/27
EG7.81.2817	. . DETONATOR REAR INBOARD EXPLOSIVE BOLT GROUP Consisting of:-						1	-	1/11
EG7.81.2819	. . . CONDUIT DETONATOR ASSEMBLY (Pre-Mod 5267)						1	-	1/12
EG7.81.4027	. . . CONDUIT DETONATOR ASSEMBLY (Mod 5267) Spares for:-						1	-	
EA1.81.939	 PLUG, detonator						1	-	1/20
A.E.I. TWT11	 TUBING, P.T.F.E.						QR	-	1/22
R 12G9635205	. . . DETONATOR No.109 Mk.2						1	-	1/39
EEAS146/6	. . . SLEEVE, 1" long						QR	-	1/4
EA1.81.938	. . . SPRING						1	-	1/21
EA1.81.428	. . . TUBE, detonator						1	-	1/27

TANKS

JETTISON WING FUEL TANK 250-GALLON PORT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AGS2002Q1	. . NUT, stiff, 5/8" BSF	3	—	1/31
EA1.57.1239	. . PIPE, air break c/w stop	1	—	1/48
EA1.57.1241	. . PIPE, fuel break c/w stop	1	—	1/47
EA1.20.8833	. . WASHER, special explosive bolt	3	L.40	1/65
EA1.20.10505	. . WASHER, special explosive bolt	3	DTD124	1/45
EA3.62.217	. TANK DROP GROUP (LESS ATTACHMENTS)	1	—	1/25
or				
BRISTOL A/C				
75.04.001				
	Spares for:-			
EA3.62.113	. . BLOCK, contact navigation light	1	—	1/32
	Attaching parts for EA3.62.113:-			
A33B16	. . Screw, 4 BA c'sk head	2	—	1/30
EA3.62.151	. . BODY, filler cap	1	—	1/18
	Attaching parts for EA3.62.151:-			
AS4563/1C	. . Bolt, 2 BA c'sk head	18	—	1/14
EA2.62.57	. . Ring, nut	1	—	1/16
EA2.62.71	. . Washer, sealing	1	—	1/17
EA3.62.191	. . CAP FILLER C/W INWARD VENT VALVE ASSEMBLY	1	—	1/1
	Spares for:-			
EA3.62.219	. . . RING, locking (Mod 5239)	1	—	1/67
EA2.62.143	. . . WASHER, sealing filler cap	1	—	1/15
EA3.62.197	. . . WASHER, sealing vent valve head	1	—	1/13
—	. . FUEL PIPE AND MOUNTING ASSEMBLY (EA3.62.73)	—	—	1/50
	Spares for:-			
EA2.62.77	. . . BOLT-RING	1	—	
EA2.62.227	. . . CLIP	1	—	1/61
EA2.62.229	. . . CLIP	1	—	1/60
SP91C	. . . CLIP (Alt R60/91 Mod 5101)	1	—	1/54
SP91J	. . . CLIP, (Alt R60/91 Mod 5101)	1	—	1/53
EA2.62.123	. . . DISH, fuel pipe assembly	1	—	
EEAS164/20/25	. . . HOSE, fuel break pipe 1-1/4" i/d x 1-5/8" o/d x 2-1/2" long (Make from 32C/377)	1	DTD625 Type1	1/57
EEAS164/8/28	. . . HOSE, air break pipe, 1/2" i/d x 25/32" o/d x 2".8 long (Make from 32C/408)	1	DTD625 Type1	1/58
EA2.62.189	. . . PIPE, vent assembly	1	—	
EA2.62.197	. . . PLUG, stack fuel assembly	1	—	
EA1.57.339	. . . PLUG, wooden	1	—	
EA1.57.341	. . . PLUG, wooden	1	—	
EA2.62.203	. . . RING, joint	1	—	
EA2.62.79	. . . WASHER, jointing	1	—	
EA2.62.81	. . . WASHER,	1	—	
EL1100	. . LAMP, filament	1	—	1/44
E & I 7733	. . LAMP, navigation type 'B'	1	—	1/41
	Attaching parts for E & I 7733:-			
AGS2002A1	. . Nut, stiff 6 BA	4	—	1/43
EA3.62.77	. . PANEL, access top skin	1	—	1/3
	Attaching parts for EA3.62.77:-			
AS1248/1C	. . Bolt, 2 BA c'sk head	18	—	1/2
EA2.62.57	. . Ring nut	1	—	1/6
EA2.62.71	. . Washer sealing	1	—	1/5

TANKS

JETTISON WING FUEL TANK, 250-GALLON, PORT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R EA3.62.115	. . SEAL 'P' (Pre Mod.5282) (Make from EEAS121) (26FZ/4432)	1	—	1/28
R EA3.62.223	. . SEAL 'P' (Mod.5282) (Make from EEAS843) (26FZ/6147758)	1	—	1/28
EA3.62.189	. . SOCKET, EARTHING, GROUP Consisting of:	1	—	1/62
EA3.62.181	. . . CAP, sealing	1	L40	1/46
EA3.62.177	. . . SOCKET, earth plug	1	L40	1/59
EA3.62.183	. . . SPRING	1	DTD215	1/52
4100/4/3/8"	. . Attaching parts for EA3.62.189: Screw, self tapping, type Z	6	—	1/55
EA3.62.185	. . Washer, sealing	1	Neo-K-Tex	1/56
EA1.20.10897	. . VALVE, DRAIN, GROUP Spares for:	1	—	1/36
EA1.20.10901	. . . PLUG, DRAIN, GROUP Spares for:	1	—	1/37
EA1.20.10903	 PLUG, housing	1	L40	1/38
EA1.20.10907	 PLUG, 3/4" BSP	1	L40	1/39
EA1.20.10905	 RING, hycatrol	1	Grade H.E.4	1/40
EA3.62.117	. . WASHER, special, 1/32"	50	Petrolite	
EA1.20.2903	. . WASHER, sealing	4	Neo-K-Tex	
EA2.62.59	. . WASHER, explosives bolt housing	3	—	
EA2.62.61	. . WASHER	3	—	

TANKS

JETTISON WING FUEL TANK, 250-GALLON, STARBOARD

Ref. No.	Part No.	Description							No. off	Mtl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
43134	E.G7.00.28 ²³⁸	JETTISONABLE WING FUEL TANK,							1	—	A	1/24
		250 GAL., INSTALLATION, STARBOARD (WITH VORTEX GENERATORS, (LESS DETONATORS) Consisting of:—										
	—	ATTACHMENT DETAILS, DROP TANK TO							—	—	—	
		WING, GROUP, (E.G7.00.62) Spares for this group are identical with those for group Pt. No. E.G7.00.61 on page Q1										
14684	E.A3.62.218 or BRISTOL A/c 75.04.0002	TANK, DROP, GROUP							1	—	A	1/26
		(LESS ATTACHMENTS) Spares for this group are identical with those for group Pt. No. E.A3.62.217 on page Q2 except for the following deletions and additions Delete:—										
	—	FUEL PIPE AND MOUNTING, ASSEMBLY							—	—	—	1/50
		(E.A2.62.73)										
R 5CX/4330018	†	LAMP, navigation, type B							1	—	B	1/41
		Add:—										
	—	FUEL PIPE AND MOUNTING, ASSEMBLY							—	—	—	1/51
		(E.A2.62.74) Spares for this assembly are identical with those for Pt. No. E.A2.62.73 on page Q2, except Ref. 1438654 and 1438655 are deleted and replaced by:—										
1438658	E.A2.62.124	DISH, fuel pipe, assembly							1	—	MR	
1438608	E.A2.62.190	PIPE, vent, assembly							1	—	MR	
R 5CX/1043490	†	LAMP, navigation, type B							1	—	B	1/42

TANKS

WINDOW DISPENSING CONTAINER, PORT

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
EG7.00.231	CONTAINER, WINDOW DISPENSING, PORT, ASSEMBLY (EG7.84.1) Spares for:—	1	—	
—	. CONTAINER, WING TIP (EG7.84.5) Spares for:—	—	—	
EG7.84.249	. . BUSH, fork-end mounting Attaching parts for EG7.84.249:—	1	L65	3/27
EEAS1/2C	. . Screw, 2 BA 120° c'sk head	3	S96	3/35
AGS2002/C/1	. . Nut, 2 BA, stiff	3	—	3/37
SP15/C	. . Washer, 2 BA plain	3	—	3/36
EG7.84.251	. . FORK-END, locking strut pivot Attaching parts for EG7.84.251:—	1	L65	3/33
A29/ES	. . Nut, 1/4" BSF slotted	1	—	3/30
SP90/C5	. . Pin, split	1	—	3/29
SP15/E	. . Washer, 1/4" BSF plain	1	—	3/28
EG7.84.9	. . FAIRING, HOSE, HINGED, ASSEMBLY Spares for:—	1	—	2/4
EG7.84.1221	. . . BRACKET, stop mounting Attaching parts for EG7.84.1221:—	2	L73	2/14
AGS2002/C/1	. . . Nut, 2 BA stiff	3	—	2/15
EEAS1/3C	. . . Screw, 2 BA, 120° c'sk head	1	S96	2/21
EEAS1/4C	. . . Screw, 2 BA, 120° c'sk head	2	S96	2/20
SP15/C	. . . Washer, 2 BA plain	3	—	2/18
EG7.84.215	. . . BRACKET, support	1	L72	3/1
EG7.84.203	. . . BUSH, hinge	4	Phos. Bronze	2/1
—	. . . FAIRING, INSTALLATION (EG7.84.1209) Spares for:—	—	—	3/19
EG7.84.1211	 FAIRING Attaching parts for EG7.84.1211:—	1	Spruce	3/20
4111/6-1/4	 Screw, P.K. No.6 round head	6	S.S.	3/24
4111/6-3/4	 Screw, P.K. No.6 round head	14	S.S.	3/25
13-98-062 or KING A/C	. . . FASTENER, attachment fitting (AS4788)	2	—	2/19
D18219	. . . FASTENER, attachment fitting	2	—	2/19
EG7.84.207	. . . PACKING, support bracket	1	L72	3/4
EA3.62.43	. . . PLATE, lamp mounting	1	—	3/2
EEAS541	. . . SEAL	QR	Synthetic Rubber	3/18
EG7.84.1215	. . . SHIM, stop mounting	2	LA3	2/13
EG7.84.183	. . . SPIGOT, locating, male	1	S96	3/3
EG7.84.1213	. . . STOP	2	L65	2/10
EG7.84.115	. . HOUSING, spigot, guide rail Attaching parts for EG7.84.115:—	1	S96	3/14
EEAS1/2C	. . Screw, 2 BA, 120° c'sk head	2	S96	3/9
EG7.84.219	. . Shim	1	LA3	3/16
SP15/C	. . Washer, 2 BA plain	2	—	3/17
EG7.84.116	. . HOUSING, spigot, guide rail Attaching parts for EG7.84.116:—	1	S96	3/15
EEAS1/2C	. . Screw, 2 BA, 120° c'sk head	2	S96	3/9
EG7.84.219	. . Shim	1	LA3	3/16
SP15/C	. . Washer, 2 BA plain	2	—	3/17

TANKS

WINDOW DISPENSING CONTAINER, PORT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA2.62.47	. . HOUSING, bolt, forward Attaching parts for EA2.62.47:—	1	—	4/20
A60/18E	. . Bolt, 1/4" BSF, hex. head	6	—	4/25
A27/ET	. . Nut, 1/4" BSF, thin	6	—	4/23
SP15/E	. . Washer, 1/4" BSF, plain	6	—	4/24
EA2.62.49	. . HOUSING, bolt, aft, inboard Attaching parts for EA2.62.49:—	1	—	4/15
A60/19E	. . Bolt, 1/4" BSF, hex. head	4	—	4/14
A27/ET	. . Nut, 1/4" BSF, thin	4	—	4/12
SP15/E	. . Washer, 1/4" BSF, plain	4	—	4/13
EA2.62.51	. . HOUSING, bolt, aft, outboard Attaching parts for EA2.62.51:—	1	—	4/10
A60/19E	. . Bolt, 1/4" BSF, hex. head	4	—	4/11
A27/ET	. . Nut, 1/4" BSF, thin	4	—	4/7
SP15/E	. . Washer, 1/4" BSF, plain	4	—	4/8
R 13-98-049	. . HOUSING, fastener (AS4788)	2	—	2/12
or				
R C18217	. . HOUSING, fastener	2	—	
EA3.62.155	. . PACKING, taper, forward bolt housing	1	L72 or L73	4/19
EA2.62.141	. . PACKING, forward bolt housing	1	—	4/17
EA3.62.111	. . PACKING, bolt, housing, aft, inboard	1	—	4/1
EA3.62.109	. . PACKING, bolt, housing, aft, outboard	1	—	4/2
EG7.84.399	. . PAD, compression, diaphragm 5 Attaching parts for EG7.84.399:—	1	L65	2/23
A25/4C	. . Bolt, 2 BA, hex. head	4	—	2/22
EG7.84.671	. . Shim	1	LA3	2/25
EG7.84.1091	. . PANEL, access, inboard, forward diaphragm 3	1	—	4/22
EG7.84.521	. . PANEL, access, outboard forward Attaching parts for EG7.84.521:—	1	—	5/28
EEAS1/1E	. . Screw, 1/4" BSF, 120° c'sk head	18	S96	5/24
EG7.84.523	. . PANEL, access, inboard Attaching parts for EG7.84.523:—	1	—	5/26
EEAS1/1E	. . Screw, 1/4" BSF, 120° c'sk head	18	S96	5/25
EG7.84.525	. . PANEL, access, outboard, aft Attaching parts for EG7.84.525:—	1	—	5/30
EEAS1/1E	. . Screw, 1/4" BSF, 120° c'sk head	18	S96	5/23
SP113/E14	. . PIN, shear, nose hinge	4	—	2/2
EA3.62.53	. . PLATE, sealing, bolt housing Attaching parts for EA3.62.53:—	3	L72	4/4
A33/C16	. . Screw, 2 BA c'sk head	12	—	4/3
EG7.84.113	. . RAIL, loading Attaching parts for EG7.84.113:—	1	L73	3/12
A25/1C	. . Bolt, 2 BA, hex. head	1	—	3/8
EEAS1/1C	. . Screw, 2 BA, 120° c'sk head	17	S96	3/5
EEAS1/5C	. . Screw, 2 BA, 120° c'sk head	2	S96	3/11
AGS2002/C/1	. . Nut, stiff, 2 BA	20	—	3/6
SP15/C	. . Washer, 2 BA plain	20	—	3/7

A.P.101B-0417-3A

Page QB3

TANKS **WINDOW DISPENSING CONTAINER, PORT**

Ref. No.	Part No.	1	2	3	4	5	6	7	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
43532	E.G7.84.114								RAIL , loading	1	L73	MR	3/13
									Attaching parts for E.G7.84.114—				
28D/9436920	A.25/1C								Bolt, 2 BA hex. head	1	—	C	3/8
1025	EEAS.1/1C								Screw, 2 BA 120° c'sk head	17	S96	C	3/5
1030	EEAS.1/5C								Screw, 2 BA 120° c'sk head	2	S96	C	3/11
28M/9433473	AGS.2002/C/1								Nut, stiff, 2 BA	20	—	C	3/6
28W/9419474	SP.15/C								Washer, 2 BA plain	20	—	C	3/7
26DK/12928	EEAS.321								SEAL , aft edge hinged nose	QR	Butyl Rubber	C	3/21
	—								SEALS, CARTRIDGE DISCHARGER, INSTALLATION (E.G7.84.35)	—	—	—	5/20
									Spares for:—				
	E.G7.84.1019								PLATE , sealing, inboard, inboard forward matrix	1	L72	—	5/12
	E.G7.84.1021								PLATE , sealing, outboard, inboard forward matrix	1	L72	—	5/14
	E.G7.84.1023								PLATE , sealing, inboard, outboard forward matrix	1	L72	—	5/16
	E.G7.84.1025								PLATE , sealing, outboard, outboard forward matrix	1	L72	—	5/18
	E.G7.84.1027								PLATE , sealing, inboard, aft matrix	1	L72	—	5/1
	E.G7.84.1029								PLATE , sealing, outboard, aft matrix	1	L72	—	5/7
	E.G7.84.1031								PLATE , sealing, forward and aft ends of matrices, except aft diaphragm 6	5	L72	—	5/10
	E.G7.84.1049								PLATE , sealing, aft, aft matrix	1	L72	—	5/5
28S/1011490	A.32/C/16								SCREW , 2 BA round head	9	—	C	5/11
28S/1007443	A.32/C/18								SCREW , 2 BA round head	48	—	C	5/3
28S/1011491	A.32/C24								SCREW , 2 BA round head	4	—	C	5/9
28S/1011492	A.32/C28								SCREW , 2 BA round head	4	—	C	5/6
28S/9137828	A.32/C32								SCREW , 2 BA round head	1	—	C	5/4
42601	WILKINSON AP/100								SEAL , 'P'	QR	S/H 40-50	C	5/22
6159	E.A2.62.221								SHIM , laminated, forward bolt housing	2	—	C	4/26
6160	E.A2.62.223								SHIM , laminated, outboard, aft bolt housing	2	—	C	4/9
42592	E.G7.84.1215								SHIM , laminated, stop mounting	2	LA3	C	2/11
6161	E.A2.62.225								SHIM , laminated, inboard, aft bolt housing	2	—	C	4/16
43552	E.G7.84.1213								STOP , nose fastener	2	L65	C	2/9
	E.A3.62.115								STRIP , sealing (Make from Ref. 4432)	1	—	LM	2/3
	E.G7.84.1115								STRIP , rubbing, guide rail spigot housing, ".75 x 1".65 x $\frac{1}{16}$ " thick (Make from 32C/432 or 32C/612)	2	DTD. 900/4195	LM	3/10
42602	E.G7.84.243								STRUT , locking, hinged nose, assembly	1	—	B	3/32
									Spares for:—				
	EEAS.315/4								LANYARD (Make from 26DK/2381)	1	—	LM	3/22
28FP/9485292	A.405								PIN , pip, $\frac{1}{4}$ " dia.	1	—	C	3/23
									Attaching parts for E.G7.84.243—				
28N/1046381	SP.121/E								Collar	1	—	C	3/26
28P/16322	SP.113/E4								Pin, shear	1	—	C	3/34
28P/9486478	SP.90/C5								Pin, split	1	—	C	3/31

TANKS

WINDOW DISPENSING CONTAINER, PORT

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
42603	E.G7.84.665	TOP-HAT, assembly, station 106, centre arming lever							1	—	C	2/16
6153	E.A2.62.59	WASHER, sealing, bolt housings							3	—	C	4/5
6154	E.A2.62.61	WASHER, sealing, bolt housings							3	—	C	4/6
	—	DISPENSER, CONVENTIONAL WINDOW							—	—	—	6/2
		(E.G7.84.11)										
		Spares for:-										
42604	E.G7.84.17	CHUTE, RELEASE, ASSEMBLY							1	—	B	6/3
		Spares for:-										
26DK/8576	EEAS.290	SEAL, $\frac{7}{32}$ " o/d x 30" long							1	Neoprene	C	6/4
26DK/12928	EEAS.321	SEAL, $\frac{5}{16}$ " o/d x 1.85" long							2	Butyl Rubber	C	6/5
	EEAS.315/4	LANYARD, pip pin retaining							1	—	LM	6/33
		(Make from 26DK/2381)										
	E.G7.84.15	MAGAZINE, CONVENTIONAL WINDOW							1	—	—	6/9
		Spares for:-										
42605	E.G7.84.257	HOUSING, spigot, stripper unit							4	L65	C	6/18
		Attaching parts for E.G7.84.257 -										
28D/9133011	A.25/2C	Bolt, 2 B.A. hex. head							8	—	C	6/13
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							8	—	C	6/21
42606	E.G7.84.273	Shim							4	LA3	C	6/19
28W/9419474	SP.15/C	Washer, 2 BA plain							8	—	C	6/20
	E.G7.84.271	HOUSING, retaining pin							1	S96	—	6/30
42607	E.G7.84.1129	LID, MAGAZINE, ASSEMBLY							1	L73	B	6/1
		Spares for:-										
28FP/1014631	A.3/25	FASTENER, dzus							11	—	C	6/31
28FP/9138002	GA.3/175	GROMMET, dzus							11	—	C	6/32
28N/9411950	AS.1878/445	HINGE							1	—	LM	6/8
26DK/8576	EEAS.290	SEAL, $\frac{7}{32}$ " o/d x 12".25 long							1	Neoprene	C	6/6
42608	E.G7.84.267	ROLLER, magazine							2	Nylon 66	C	6/23
	E.G7.84.265	SPINDLE, roller							2	L65	—	6/22
26DK/12928	EEAS.321	SEAL, $\frac{5}{16}$ " o/d x 11".25 long							1	Butyl Rubber	C	6/7
42609	E.G7.84.259	SPIGOT, front							2	S96	C	6/15
		Attaching parts for E.G7.84.259 -										
28M/9480017	AGS.2001/E/1	Nut, stiff, $\frac{1}{4}$ " BSF							2	—	C	6/17
28W/9419405	SP.15/E	Washer, $\frac{1}{4}$ " BSF plain							2	—	C	6/16
42610	E.G7.84.261	SPIGOT, rear							2	S96	C	6/27
		Attaching parts for E.G7.84.261 -										
1028	EEAS.1/3C	Screw, 2 BA 120°c°sk head							4	—	C	6/28
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							4	—	C	6/25
28W/9419474	SP.15/C	Washer, 2 BA plain							4	—	C	6/26
42611	E.G7.84.325	STOP, rubber, rear spigot, $\frac{7}{8}$ " o/d x $\frac{1}{2}$ " l/d x $\frac{1}{2}$ " long							2	DTD.625	C	6/29
28FP/9469299	A.409	PIN, pip, $\frac{1}{4}$ " dia. retaining front end							1	—	C	6/24
10AS/3735	TILTMAN LANGLEY 167156	STRIPPER, window, low temperature							1	—	A	6/10
		Attaching parts for 167156 -										
28N/1046382	SP.121/C	Collar, $\frac{1}{4}$ "							4	—	C	6/11
28P/16272	SP.113/C7½	Pin, shear, $\frac{1}{4}$ "							4	—	C	6/14
28P/9486478	SP.90/C5	Pin, split							4	—	C	6/12

A.P.101B-0417-3A

TANKS

Page QB5

WINDOW DISPENSING CONTAINER, PORT

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	ELECTRICAL, EQUIPMENT, PORT CONTAINER							—	—	—	7/1
		(E.G7.81.307)										
		Spares for:—										
26DK/4716	NATIONAL PLASTICS X.114	BEADING, P.V.C., diaphragm 1 and 2, and wing connection							QR	—	C	7/3
5CZ/4329841	WARD BROOKE WB/UN/1146/S/3/W	BLOCK, terminal, 3-way							1	—	C	7/7
		Attaching parts for 5CZ/4329841:—										
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA							2	—	C	7/10
5CZ/9523382	WARD BROOKE WB/1114/28	Pillar, fixing							2	—	C	7/14
42612	E.G7.81.329	BOLT, special, earthing, distributor box							1	S1	C	7/12
5CZ/1035005	WARD BROOKE WB/NY/1110/B/3	COVER, terminal block							1	—	C	7/9
33H/	†	COMPOUND, sealing, bostik 2102							QR	DTD900/4686	C	7/16
5F/9445824	SUPERFLEXIT SC.001-10/18	CONDUIT, nose hinge							1	—	C	7/6
5X/6156860	SUPERFLEXIT SCF.1312-10	CLIP, "P", nose hinge							2	—	—	7/22
	E.G7.81.2061	FAIRLEAD, assembly, diaphragm 4							1	—	—	7/15
		Attaching parts for E.G7.81.2061:—										
28D/9133011	A25/2C	Bolt, 2 BA hex. head							4	—	C	7/11
	—	LOOMS, CABLE (E.G7.81.319)							—	—	—	7/2
		Spares for:—										
	E.G7.81.527	CABLE, ASSEMBLY, P.451, FROM WING-TIP							1	—	—	7/5
		BREAK TO STRIPPER UNIT, GROUP										
		Spares for:—										
5E/9993758	†	CABLE, uninyvin 12							QR	—	C	
5E/9568884	†	CABLE, unyvinmetsheath 16							QR	—	C	
5E/9467424	†	CABLE, uninyvin 20							QR	—	C	
5E/9467180	†	CABLE, uniersil 20							QR	—	C	
10AD/9443891	CC.610/037	CLAMP, cable							1	—	C	
10AD/1107228	508/1/07779/001	CLAMP, cable							1	—	C	
10H/1107227	508/1/07777/001	CLAMP, cable							1	—	C	
26DK/23707	EEAS.559/6	CLIP, bonding, assembly							1	—	C	
10AR/9504382	508/2/07706/300	GASKET, outlet							1	—	C	
5X/4501236	508/2/07705/300	GASKET, outlet							1	—	C	
10AS/9525135	508/2/07722/300	GASKET, union							1	—	C	

TANKS

WINDOW DISPENSING CONTAINER, PORT.

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R	10AS/1051288	508/2/07721/300						GASKET, union	1	—	C	7/4
	10H/	508/2/07852/001						OUTLET, angle	1	—	—	
R	10H/0142912	508/2/07648/001						OUTLET, angle	1	—	C	
	10H/	BMS FIX.32-7P						PLUG, fixed	1	—	—	
R	5X/9717835	508/2/04388						PLUG, filler, 12	5	—	C	
R	5X/9717833	508/2/04387						PLUG, filler 16	15	—	C	
R	10AD/9152321	22.111033						PLUG, pin 12	7	—	C	
R	10AD/9472687	508/2/03547/002						PLUG, pin 16	8	—	C	
R	10AD/5809603	508/2/06604/002						PLUG, pin 18/20	20	—	C	
R	10AS/1051296	508/2/07709/300						RING, sealing	1	—	C	
R	10AS/0142929	508/2/07710/300						RING, sealing	1	—	C	
R	10AC/0970097	508/2/07757/007						RING, thrust	1	—	C	
R	10AC/0970095	508/2/07754/007						RING, thrust	1	—	C	
R		EEAS.146/2						SLEEVE, 1-1/2" long	QR	—	—	
R		EEAS.146/2						SLEEVE, 1" long	QR	—	—	
R		EEAS.146/6						SLEEVE, 1" long	QR	—	—	
R		EEAS.146/12						SLEEVE, 1" long	QR	—	—	
R		EEAS.146/16						SLEEVE, 1/4" long	QR	—	—	
	10H/9550790	691(ET)-10-3S						SOCKET, free, Mk. 6, 3-way	1	—	B	
R	10H/9532017	508/1/07009/220						SOCKET, free, Mk. 7 (T4) 100°C	1	—	—	
R	10H/944063	508/1/07000/220						SOCKET, free, Mk. 7 (T4) 100°C	1	—	C	
	5X/9462951	HC.294						TERMINAL, ring tag	2	—	C	
R	5X/5808952	22.139603						WASHER, panel packing	1	—	C	
		E.G7.81.529						CABLE, P.453, ASSEMBLY, FROM TEST	1	—	—	
								SOCKET TO FILTER AND DISTRIBUTION BOX, GROUP				
								Spares for:—				
R	5E/9012998	†						CABLE, uninyvin 16	QR	—	C	
		PC.68-10						CAP, blanking	1	—	—	
R	10AD/9443891	CC.610/037						CLAMP, special, Mk. 6	2	—	C	
	10H/9557011	691(ET)-10-3P						PLUG, free, Mk. 6, 3-way	1	—	C	

A.P.101B-0417-3A

Page Q87

TANKS

WINDOW DISPENSING CONTAINER, PORT

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R		EEAS.146/6						SLEEVE, 3/4" long	QR	—	—	
R		EEAS.146/16						SLEEVE, 1/4" long	QR	—	—	
	10H/9550790	681(ET)-10-3S						SOCKET, fixed, Mk. 6, 3-way	1	—	C	
		—						LIGHT, NAVIGATION, PORT,	—	—	—	7/17
								ASSEMBLY (E.G7.81.403)				
								Spares for:—				
R	5E/9467424	†						CABLE, uninylvin 20	QR	—	C	7/27
	5L/9952431	†						LAMP, filament, 28v, 24w	1	—	C	7/21
R	5CX/4330018	†						LAMP, navigation, type 'B', port	1	—	C	7/18
								Attaching parts for 5CX/4330018:—				
R	28M/9418829	AGS.2002/A/1						Nut, stiff, 6 BA	4	—	C	7/23
	5F/9133798	HT.30						SLEEVE, Helsyn 150, white, 1/2" long	1	—	C	7/26
R		EEAS.146/12						SLEEVE, 1-1/2" long	QR	—	—	7/25
R		EEAS.146/12						SLEEVE, 1" long	QR	—	—	7/20
R		EEAS.146/20						SLEEVE, 3/4" long	QR	—	—	7/19
	5X/9462951	HC.294						TERMINAL, ring tag	2	—	C	7/24
	5K/	M.A.M.						SLEEVE, 3 m/m i/d, pink, 3/8" long	3	—	—	7/8
		CXH										
	26DK/7410	EEAS.232						WASHER, tapped, 4 BA, earth bolt	1	L72	C	7/13
		—						DISCHARGER, CARTRIDGE, INSTALLATION	—	—	—	9/2
								(E.G7.84.13)				
								Spares for:—				
	42613	E.G7.84.837						BRACKET, bearing, lock-notched	3	—	C	9/34
								Attaching parts for E.G7.84.837:—				
	42614	E.G7.84.873						Bolt, 2 BA special	3	—	C	9/38
	42615	E.G7.84.871						Bolt, 5/16" BSF special	3	—	C	9/27
	42616	E.G7.84.947						BOLT, special, turnbuckle attaching	6	BAC.M37	C	10/23
	42617	E.G7.84.963						CRANK, ASSEMBLY, OUTBOARD	1	—	C	12/23
								TORQUE TUBE				
								Spares for:—				
R	28N/4186638	HOFFMANN CJ.0						JOINT, self aligning	1	—	C	12/13
								Attaching parts for E.G7.84.963:—				
	28D/1010030	A.25/7C						Bolt, 2 BA hex. head	1	—	C	12/16
	28M/1278190	AGS.2001/C/1						Nut, stiff, 2 BA	1	—	C	12/22
	42618	E.G7.84.965						CRANK, ASSEMBLY, INBOARD TORQUE	1	—	C	12/12
								TUBE				
								Spares for:—				
R	28N/4186638	HOFFMANN CJ.0						JOINT, self aligning	1	—	C	12/1
								Attaching parts for E.G7.84.965:—				
	28D/1010030	A.25/7C						Bolt, 2 BA hex. head	1	—	C	12/2
	28M/1278190	AGS.2001/C/1						Nut, stiff, 2 BA	1	—	C	12/11

TANKS

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
42619	E.G7.84.1035	HOUSING, bearing, torque tubes, assembly	2	—	C	12/14
28D/9133011	A.25/2C	Attaching parts for E.G7.84.1035:—				
28M/9403520	A.27/CP	Bolt, 2 BA hex. head	4	—	C	12/3
42620	E.G7.84.675	Nut, 2 BA plain	4	—	C	12/4
42621	E.G7.84.843	HOUSING, spring, stay bar	3	S96	C	9/35
		LEVER, ARMING, SUB-ASSEMBLY,	1	—	B	9/37
		STATION 104				
		Spares for:—				
	E.G7.84.677	BAR, stay	1	S96	—	9/25
		Attaching parts for E.G7.84.677:—				
42627	E.G7.84.863	Pin	1	S96	C	9/26
1439307	E.G7.84.865	BUSH, pivot, top bracket	2	P.T.F.E.	C	9/7
	E.G7.84.1243	LATCH	1	S96	—	9/21
42622	E.G7.84.877	LINK, ARMING, FRONT,	1	—	B	9/14
		INBOARD, ASSEMBLY				
		Spares for:—				
	E.G7.84.1043	EYE-END, ASSEMBLY	1	—	—	9/12
		Spares for:—				
	E.G7.84.875	EYE-END	1	S96	—	9/20
28N/4186638	HOFFMANN	JOINT, self-aligning	1	—	C	9/11
	CJ.0					
26DK/4131	E.B2.47.375	FORK-END	1	S95	C	9/16
28M/1007403	A.27/ET	NUT, 1/4" BSF thin	2	—	C	9/13
	E.G7.84.879	ROD	1	S96	—	9/15
		Attaching parts for E.G7.84.877:—				
42623	E.G7.84.855	Bolt, 4 BA special	1	BAC.M37	C	9/10
26DK/3477	E.B2.47.441	Bolt, 4 BA special	1	BAC.M37	C	9/17
26DK/3485	E.B2.47.443	Nut, 4 BA special	1	BAC.M37	C	9/24
42624	E.G7.84.857	Nut, 4 BA, slotted, special	1	BAC.M37	C	9/8
28P/9559603	SP.90/C6	Pin, split	2	—	C	9/9
42625	E.G7.84.1201	PLATE, spring	1	S513	C	9/30
		Attaching parts for E.G7.84.1201:—				
28S/9451798	A.36/B14	Screw, 4 BA round head	2	—	C	9/33
28W/9128182	SP.55/B	Washer, 4 BA spring	2	—	C	9/31
43090	E.G7.84.1289	SLEEVE	1	T35	C	9/19
42626	E.G7.84.1241	SPRING, stay bar	1	DTD865	C	9/18
		Attaching parts for E.G7.84.1241:—				
42627	E.G7.84.863	Pin	1	S96	C	9/23
42628	E.G7.84.845	LEVER, ARMING, SUB-ASSEMBLY,	1	—	B	11/34
		STATION 106				
		Spares for:—				
	E.G7.84.677	BAR, stay	1	S96	—	11/27
		Attaching parts for E.G7.84.677:—				
42627	E.G7.84.863	Pin	1	S96	C	11/28
1439307	E.G7.84.865	BUSH, pivot, top bracket	2	P.T.F.E.	C	11/18
	E.G7.84.1243	LATCH	1	Spec. D.Q. S96	—	11/14

TANKS

WINDOW DISPENSING CONTAINER, PORT

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
R	42629	E.G7.84.849	LINK, ARMING, ASSEMBLY, CENTRE						1	—	B	11/22
			INBOARD									
		E.G7.84.903	EYE-END, ASSEMBLY						1	S92	—	11/21
			Spares for:—									
	28N/4186638	HOFFMANN CJ.0	JOINT, self-aligning						1	—	C	11/20
	26DK/4131	E.B2.47.375	FORK-END						1	S95	C	11/36
	28M/1007403	A.27/ET	NUT, 1/4" BSF thin						1	—	C	11/24
		E.B2.47.405	ROD-END						1	BAC.M37	—	11/23
			Attaching parts for E.G7.84.849:—									
	42623	E.G7.84.855	Bolt, 4 BA, special						1	BAC.M37	C	11/19
R	26DK/3477	E.B2.47.441	Bolt, 4 BA, special						1	BAC.M37	C	11/32
	42624	E.G7.84.857	Nut, 4 BA, slotted, special						1	BAC.M37	C	11/17
	26DK/3485	E.B2.47.443	Nut, 4 BA special						1	BAC.M37	C	11/29
	28P/9559603	SP.90/C6	Pin, split						2	—	C	11/16
	42625	E.G7.84.1201	PLATE, spring						1	S513	C	11/33
			Attaching parts for E.G7.84.1201:—									
	28S/9451798	A.36/B14	Screw, 4 BA round head						2	—	C	11/30
	28W/9128182	SP.55/B	Washer, 4 BA, spring						2	—	C	11/31
	43090	E.G7.84.1289	SLEEVE						1	T35	C	11/25
	42626	E.G7.84.1241	SPRING, stay bar						1	DTD.865	C	11/15
R			Attaching parts for E.G7.84.1241:—									
	42627	E.G7.84.863	Pin						1	S96	C	11/26
	42630	E.G7.84.847	LEVER, ARMING, SUB-ASSEMBLY, STATION 110						1	—	B	10/21
			Spares for:—									
		E.G7.84.677	BAR, stay						1	S96	—	10/17
			Attaching parts for E.G7.84.677:—									
	42627	E.G7.84.863	Pin						1	S96	C	10/16
	1439307	E.G7.84.865	BUSH, pivot, top bracket						2	P.T.F.E.	C	10/6
		E.G7.84.1243	LATCH						1	S96	—	10/2
	42631	E.G7.84.853	LINK, ARMING, ASSEMBLY, REAR						1	—	B	10/10
R			Spares for:—									
		E.G7.84.903	EYE-END, ASSEMBLY						1	—	—	10/9
			Spares for:—									
	28N/4186638	HOFFMANN CJ.0	JOINT, self-aligning						1	—	C	10/8
		E.G7.84.909	FORK-END						1	S96	—	10/13
	28M/1007403	A.27/ET	NUT, 1/4" BSF thin						1	—	C	10/12
		E.B2.47.405	ROD-END						1	BAC.M37	—	10/11
			Attaching parts for E.G7.84.853:—									
	42623	E.G7.84.855	Bolt, 4 BA special						2	BAC.M37	C	10/7
	42624	E.G7.84.857	Nut, 4 BA slotted, special						2	BAC.M37	C	10/5
R	28P/9559603	SP.90/C6	Pin, split						2	—	C	10/4

TANKS
WINDOW DISPENSING CONTAINER, PORT

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
42625	E.G7.84.1201							PLATE, spring	1	S513	C	10/18
								Attaching parts for E.G7.84.1201:—				
28S/9451798	A.36/B14							Screw, 4 BA round head	2	—	C	10/20
28W/9128182	SP.55/B							Washer, 4 BA spring	2	—	C	10/19
43090	E.G7.84.1289							SLEEVE	1	T35	—	10/14
42626	E.G7.84.1241							SPRING, stay bar	1	DTD865	C	10/3
								Attaching parts for E.G7.84.1241:—				
42627	E.G7.84.863							Pin	1	S96	C	10/15
43125	E.G7.84.1309							LEVER, idler, assembly	1	L65	C	11/1
								Spares for:—				
R 28N/4186638	HOFFMANN C.J.O							JOINT	2	—	C	11/2
42633	E.G7.84.851							LINK, ARMING, ASSEMBLY, CENTRE OUTBOARD	1	—	B	11/8
								Spares for:—				
26DK/4131	E.B2.47.375							FORK-END	2	S95	C	11/12
28M/1007403	A.27/ET							NUT, 1/4" BSF thin	2	—	—	11/10
	E.B2.47.405							ROD-END	2	BAC.M37	C	11/9
								Attaching parts for E.G7.84.851:—				
26DK/3477	E.B2.47.441							Bolt, 4 BA special	2	BAC.M37	C	11/7
26DK/3485	E.B2.47.443							Nut, 4 BA special	2	BAC.M37	C	11/11
R 28P/9559603	SP.90/C6							Pin, split	2	—	C	11/6
R 7B/9632735	AIR-LOG LTD. D.104084/91							MATRIX, assembly	3	—	A	9/3
R 7B/9632738	AIR-LOG LTD. D.104084/89							PLATE, reaction, assembly	3	—	A	9/4
								Attaching parts for 7B/9632738:—				
26DK/33098	EEAS.100/4E							Bolt, 1/4" BSF 90° c'sk head (rear plate)	14	S97	C	9/6
1438524	EEAS.100/3-1/2E							Bolt, 1/4" BSF 90° c'sk head (forward plates)	12	S97	C	9/5
	E.G7.84.937							RAMP, mounting, aft, centre and rear arming levers	2	S96	—	12/37
								Attaching parts for E.G7.84.937:—				
1025	EEAS.1/1C							Screw, 2 BA 120° c'sk head	4	S96	C	12/28
28M/1006473	A.27/CT							Nut, 2 BA thin	4	—	C	12/30
	E.G7.84.985							Shim	2	LA3	—	12/32
	E.G7.84.939							RAMP, mounting, aft, front arming lever	1	S96	—	12/39
								Attaching parts for E.G7.84.939:—				
1028	EEAS.1/3C							Screw, 2 BA 120° c'sk head	2	S96	C	12/31
28M/1006473	A.27/CT							Nut, 2 BA thin	2	—	C	12/34
	E.G7.84.987							Shim	1	LA3	—	12/35
	E.G7.84.941							RAMP, mounting, forward, front and rear arming levers	2	S96	—	12/41
								Attaching parts for E.G7.84.941:—				
1028	EEAS.1/3C							Screw, 2 BA 120° c'sk head	4	S96	C	12/29
28M/1006473	A.27/CT							Nut, 2 BA thin	4	—	C	12/36
	E.G7.84.985							Shim	2	LA3	—	12/33
	E.G7.84.1303							SHAFT, idler lever	1	S96	—	11/5
								Attaching parts for E.G7.84.1303:—				
28D/9436920	A.25/1C							Bolt, 2 BA hex. head	4	—	C	11/4
28M/1006473	A.27/CP							Nut, 2 BA plain	4	—	C	11/3

A.P.101B-0417-3A

TANKS

Page QB11

WINDOW DISPENSING CONTAINER, PORT

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
42636	E.G7.84.1217							SPRING, bar stay	3	DTD215	C	9/36
								Attaching parts for E.G7.84.1217:-				
42637	E.G7.84.949							Pin	3	—	C	9/32
42638	E.G7.84.681							SPRING, tension, arming levers	6	DTD215	C	9/29
	E.G7.84.1313							TUBE, TORQUE, ASSEMBLY, PORT INBOARD	1	—	—	12/8
								Spares for:-				
42639	GLACIER METAL							BUSH, mounting bracket	2	P.T.F.E.	C	12/6
	10.DU.12											
	E.G7.84.975							BRACKET, mounting	1	S96	—	12/21
	E.G7.84.976							BRACKET, mounting	1	S96	—	12/15
	E.G7.84.977							BRACKET, support	1	S96	—	12/9
42640	E.G7.84.979							CRANK, outboard	1	S96	C	12/10
43425	E.G7.84.1321							CRANK, inboard	1	S96	C	12/5
	E.G7.84.1315							TUBE, TORQUE, ASSEMBLY, FRONT	1	—	—	12/20
								OUTBOARD				
								Spares for:-				
42639	GLACIER METAL							BUSH, mounting bracket	2	P.T.F.E.	C	12/18
	10.DU.12											
	E.G7.84.975							BRACKET, mounting	1	S96	—	12/26
	E.G7.84.976							BRACKET, mounting	1	S96	—	12/27
	E.G7.84.977							BRACKET, support	1	S96	—	12/22
42640	E.G7.84.979							CRANK, inboard	1	S96	C	12/23
43426	E.G7.84.1319							CRANK, outboard	1	S96	C	12/17
	E.G7.84.955							TUBE, TORQUE, ASSEMBLY, REAR	1	—	—	10/27
								Spares for:-				
42639	GLACIER METAL							BUSH, mounting bracket	2	P.T.F.E.	C	10/29
	10.DU.12											
	E.G7.84.975							BRACKET, mounting	1	S96	—	10/30
	E.G7.84.976							BRACKET, mounting	1	S96	—	10/32
	E.G7.84.977							BRACKET, support	1	S96	—	10/25
42640	E.G7.84.979							CRANK	2	S96	C	10/31
42643	E.G7.84.967							CRANK, REAR, ASSEMBLY	1	—	C	10/24
								Spares for:-				
28N/13510	HOFFMANN							JOINT, self aligning	1	—	C	10/28
	CJ.0											
R 7B/9632739	†							UNIT, distributor, No. 2, Mk. 1	1	—	A	
								Attaching parts for 7B/9632739:-				
28D/1011240	A25/5E							Bolt, 1/4" BSF hex. head	6	—	C	

WINDOW DISPENSING CONTAINER, PORT

[illegible]

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description					No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5 6			
EG7.00.232	CONTAINER, WINDOW DISPENSING STARBOARD, ASSEMBLY (EG7.84.2)					1	—	
—	Spares for:—					—	—	
—	CONTAINER, WING TIP (EG7.84.7)					—	—	
—	Spares for:—					—	—	
EG7.84.249	. . . BUSH, fork-end mounting					1	L65	3/27
—	Attaching parts for EG7.84.249:—					—	—	
EEAS1/2C	. . . Screw, 2 BA 120° c'sk head					3	S96	3/35
AGS2002/C/1	. . . Nut, stiff, 2 BA					3	—	3/37
SP15/C	. . . Washer, 2 BA plain					3	—	3/36
EG7.84.251	. . . FORK-END, locking strut pivot					1	L65	3/33
—	Attaching parts for EG7.84.251:—					—	—	
A29/ES	. . . Nut, 1/4" BSF slotted					1	—	3/30
SP90/C5	. . . Pin, split					1	—	3/29
SP15/E	. . . Washer, 1/4" BSF plain					1	—	3/28
EG7.84.9	. . . FAIRING, NOSE, HINGED, ASSEMBLY					2	—	2/4
—	Spares for:—					—	—	
EG7.84.1221	. . . BRACKET, stop mounting					2	L73	2/14
—	Attaching parts for EG7.84.1221:—					—	—	
AGS2002/C/1	. . . Nut, stiff, 2 BA					3	—	2/15
EEAS1/3C	. . . Screw, 2 BA 120° c'sk head					1	S96	2/21
EEAS1/4C	. . . Screw, 2 BA 120° c'sk head					2	S96	2/20
SP15/C	. . . Washer, 2 BA plain					3	—	2/18
EG7.84.215	. . . BRACKET, support					1	L72	3/1
EG7.84.203	. . . BUSH, hinge					4	Phos. Bronze	2/1
—	. . . FAIRING, INSTALLATION (EG7.84.1209)					—	—	3/19
—	Spares for:—					—	—	
EG7.84.1211	. . . FAIRING					1	Spruce	3/20
—	Attaching parts for EG7.84.1211:—					—	—	
4111/6-1/4	. . . Screw, P.K. No. 6 round head					6	S.S.	3/24
4111/6-3/4	. . . Screw, P.K. No. 6 round head					14	S.S.	3/25
13-98-062	. . . FASTENER, attachment fitting (AS4788)					2	—	2/19
or								
KING A/C								
D18219	. . . FASTENER, attachment fittings					2	—	2/19
EG7.84.207	. . . PACKING, support bracket					1	L72	3/4
EA3.62.43	. . . PLATE, lamp mounting					1	—	3/2
EEAS541	. . . SEAL					QR	Synthetic Rubber	3/18
EG7.84.1215	. . . SHIM, stop mounting					1	LA3	2/13
EG7.84.183	. . . SPIGOT, locating, male					1	S96	3/3
EG7.84.1213	. . . STOP					2	L65	2/10
EG7.84.115	. . . HOUSING, spigot, guide rail					1	S96	3/14
—	Attaching parts for EG7.84.115:—					—	—	
EEAS1/2C	. . . Screw, 2 BA 120° c'sk head					2	S96	3/9
EG7.84.219	. . . Shim					1	LA3	3/16
SP15/C	. . . Washer, 2 BA plain					2	—	3/17

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG7.84.116	. . HOUSING, spigot, guide rail Attaching parts for EG7.84.116:—	1	S96	3/15
EEAS1/2C	. . Screw, 2 BA 120° c'sk head	2	S96	3/9
EG7.84.219	. . Shim	1	LA3	3/16
SP15/C	. . Washer, 2 BA plain	2	—	3/17
EA2.62.48	. . HOUSING, bolt, forward Attaching parts for EA2.62.48:—	1	—	4/21
A60/18E	. . Bolt, 1/4" BSF hex. head	6	—	4/25
A27/ET	. . Nut, 1/4" BSF thin	6	—	4/23
SP15/E	. . Washer, 1/4" BSF plain	6	—	4/24
EA2.62.49	. . HOUSING, bolt, aft, inboard Attaching parts for EA2.62.49:—	1	—	4/15
A60/19E	. . Bolt, 1/4" BSF hex. head	4	—	4/14
A27/ET	. . Nut, 1/4" BSF thin	4	—	4/12
SP15/E	. . Washer, 1/4" BSF plain	4	—	4/13
EA2.62.51	. . HOUSING, bolt, aft, outboard Attaching parts for EA2.62.51:—	1	—	4/10
A60/19E	. . Bolt, 1/4" BSF hex. head	4	—	4/11
A27/ET	. . Nut, 1/4" BSF thin	4	—	4/7
SP15/E	. . Washer, 1/4" BSF plain	4	—	4/8
13-98-049 or	. . HOUSING, fastener (AS4788)	2	—	2/12
C18217	. . HOUSING, fastener	2	—	
EA3.62.155	. . PACKING, taper, forward bolt housing	1	—	4/19
EA2.62.142	. . PACKING, forward bolt housing	1	—	4/18
EA3.62.111	. . PACKING, bolt housing, aft, inboard	1	—	4/1
EA3.62.109	. . PACKING, bolt housing, aft, outboard	1	—	4/2
EG7.84.400	. . PAD, compression, diaphragm 5 Attaching parts for EG7.84.400:—	1	L65	2/24
A25/4C	. . Bolt, 2 BA hex. head	4	—	2/22
EG7.84.671	. . Shim	1	LA3	2/25
EG7.84.1091	. . PANEL, access, inboard, forward diaphragm 3	1	—	4/22
EG7.84.522	. . PANEL, access, outboard, forward Attaching parts for EG7.84.522:—	1	—	5/29
EEAS1/1E	. . Screw, 1/4" BSF 120° c'sk head	18	S96	5/24
EG7.84.524	. . PANEL, access, inboard Attaching parts for EG7.84.524:—	1	—	5/27
EEAS1/1E	. . Screw, 1/4" BSF 120° c'sk head	18	S96	5/25
EG7.84.526	. . PANEL, access, outboard, aft Attaching parts for EG7.84.526:—	1	—	5/31
EEAS1/1E	. . Screw, 1/4" BSF 120° c'sk head	18	S96	5/23
SP113/E14	. . PIN, shear, nose hinge	4	—	2/2
EA3.62.53	. . PLATE, sealing, bolt housing Attaching parts for EA3.62.53:—	3	L72	4/4
A33/C16	. . Screw, 2 BA c'sk head	12	—	4/3
EG7.84.113	. . RAIL, loading Attaching parts for EG7.84.113:—	1	L73	3/12
A25/1C	. . Bolt, 2 BA hex. head	1	—	3/8
EEAS1/1C	. . Screw, 2 BA 120° c'sk head	17	S96	3/5
EEAS1/5C	. . Screw, 2 BA 120° c'sk head	2	S96	3/11
AGS2002/C/1	. . Nut, stiff, 2 BA	20	—	3/6
SP15/C	. . Washer, 2 BA plain	20	—	3/7

A.P.101B-0417-3A

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Ref. No.	Part No.	1	2	3	4	5	6	7	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
43532	E.G7.84.114								RAIL , loading	1	L73	MR	3/13
									Attaching parts for E.G7.84.114—				
28D/9436920	A.25/1C								Bolt, 2 BA hex. head	1	—	C	3/8
1025	EEAS.1/1C								Screw, 2 BA 120° c'sk head	17	S96	C	3/5
1030	EEAS.1/5C								Screw, 2 BA 120° c'sk head	2	S96	C	3/11
28M/9433473	AGS.2002/C/1								Nut, stiff, 2 BA	20	—	C	3/6
28W/9419474	SP.15/C								Washer, 2 BA plain	20	—	C	3/7
26DK/12928	EEAS.321								SEAL , aft edge, hinged nose	QR	Butyl Rubber S/H 35-40	C	3/21
	—								SEALS, CARTRIDGE DISCHARGER, INSTALLATION (E.G7.84.36)	—	—	—	5/21
									Spares for:—				
	E.G7.84.1020								PLATE , sealing, inboard, inboard forward matrix	1	L72	—	5/13
	E.G7.84.1022								PLATE , sealing, outboard, inboard forward matrix	1	L72	—	5/15
	E.G7.84.1024								PLATE , sealing, inboard, outboard forward matrix	1	L72	—	5/17
	E.G7.84.1026								PLATE , sealing, outboard, forward matrix	1	L72	—	5/19
	E.G7.84.1028								PLATE , sealing, inboard, aft matrix	1	L72	—	5/2
	E.G7.84.1030								PLATE , sealing, outboard, aft matrix	1	L72	—	5/8
	E.G7.84.1031								PLATE , sealing, forward and aft ends of matrices, except aft of diagram 6	5	L72	—	5/10
	E.G7.84.1049								PLATE , sealing, aft, aft matrix	1	L72	—	5/5
28S/1011490	A.32/C16								SCREW , 2 BA round head	9	—	C	5/11
28S/1007443	A.32/C18								SCREW , 2 BA round head	48	—	C	5/3
28S/1011491	A.32/C24								SCREW , 2 BA round head	4	—	C	5/9
28S/1011492	A.32/C28								SCREW , 2 BA round head	4	—	C	5/6
28S/9137828	A.32/C32								SCREW , 2 BA round head	1	—	C	5/4
42601	WILKINSON AP/100								SEAL , 'P'	QR	S/H 40-50	C	5/22
6159	E.A2.62.221								SHIM , laminated, forward bolt housing	2	—	C	4/26
6160	E.A2.62.223								SHIM , laminated, outboard, aft bolt housing	2	—	C	4/9
42592	E.G7.84.1215								SHIM , laminated, stop mounting	2	LA3	—	2/11
6161	E.A2.62.225								SHIM , laminated, inboard aft bolt housing	2	—	MR	4/16
43552	E.G7.84.1213								STOP , nose fastener	2	L65	—	2/9
	E.A3.62.115								STRIP , sealing (Make from Ref. 4432)	1	—	LM	2/3
	E.G7.84.1115								STRIP , rubbing, guide rail spigot housing, ".75 x 1".65 x $\frac{1}{16}$ " thick (Make from 32C/432 or 32C/612)	2	DTD.900/4195	LM	3/10
42602	E.G7.84.243								STRUT, LOCKING, HINGED NOSE, ASSEMBLY	1	—	B	3/32
									Spares for:—				
	EEAS.315/4								LANYARD (Make from 26DK/2381)	1	—	LM	3/22
28FP/9485292	A.405								PIN , pip, $\frac{1}{4}$ " dia.	1	—	C	3/23
									Attaching parts for E.G7.84.243—				
28N/1046381	SP.121/E								Collar	1	—	C	3/26
28P/16322	SP.113/E4								Pin, shear	1	—	C	3/34
28P/9486478	SP.90/C5								Pin, split	1	—	C	3/31

TANKS **WINDOW DISPENSING CONTAINER, STARBOARD**

Ref. No.	Part No.	1	2	3	4	5	6	7	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
42647	E.G7.84.666								TOP-HAT, assembly, station 106, centre arming lever	1	—	C	2/17
6153	E.A2.62.59								WASHER, sealing, bolt housing	3	—	C	4/5
6154	E.A2.62.61								WASHER, sealing, bolt housing	3	—	C	4/6
—	—								DISPENSER, CONVENTIONAL, WINDOW (E.G7.84.11)	—	—	—	6/2
									Spares for:-				
42604	E.G7.84.17								CHUTE, RELEASE, ASSEMBLY	1	—	B	6/3
									Spares for:-				
26DK/8576	EEAS.290								SEAL, $\frac{7}{32}$ " x 30" long	1	Neoprene	C	6/4
26DK/12928	EEAS.321								SEAL, $\frac{5}{16}$ " o/d x 1".85 long	2	Butyl Rubber	C	6/5
	EEAS.315/4								LANYARD, pip pin retaining	1	—	LM	6/33
									(Make from 26DK/2381)				
	E.G7.84.15								MAGAZINE, CONVENTIONAL WINDOW, ASSEMBLY	1	—	—	6/9
									Spares for:-				
42605	E.G7.84.257								HOUSING, spigot, stripper unit	4	L65	C	6/18
									Attaching parts for E.G7.84.257 -				
28D/9133011	A.25/2C								Bolt, 2 BA hex. head	8	—	C	6/13
28M/1278190	AGS.2001/C/1								Nut, stiff, 2 BA	8	—	C	6/21
42606	E.G7.84.273								Shim	4	LA3	C	6/19
28W/9419474	SP.15/C								Washer, 2 BA plain	8	—	C	6/20
	E.G7.84.271								HOUSING, retaining pin	1	S96	—	6/30
42607	E.G7.84.1129								LID, MAGAZINE, ASSEMBLY	1	L73	B	6/1
									Spares for:-				
28FP/1014631	A.3/25								FASTENER, dzus	11	—	C	6/31
28FP/9138002	G.A3/175								GROMMET, dzus	11	—	C	6/32
28N/9511950	AS.1878/445								HINGE	1	—	LM	6/8
26DK/8576	EEAS.290								SEAL, $\frac{7}{32}$ " o/d x 12".25 long	1	Neoprene	C	6/6
42608	E.G7.84.267								ROLLER, magazine	2	Nylon 66	C	6/23
	E.G7.84.265								SPINDLE, roller	2	L65	—	6/22
26DK/12928	EEAS.321								SEAL, $\frac{5}{16}$ " o/d x 11".25 long	1	Butyl Rubber	C	6/7
42609	E.G7.84.259								SPIGOT, front	2	S96	C	6/15
									Attaching parts for E.G7.84.259 -				
28N/9480017	AGS.2001/E/1								Nut, stiff, $\frac{1}{4}$ " BSF	2	—	C	6/17
28W/9419405	SP.15/E								Washer, $\frac{1}{4}$ " BSF plain	2	—	C	6/16
42610	E.G7.84.261								SPIGOT, rear	2	S96	C	6/27
									Attaching parts for E.G7.84.261 -				
1028	EEAS.1/3C								Screw, 2 BA 120°c'sk head	4	S96	C	6/28
28M/1278190	AGS.20001/C/1								Nut, stiff, 2 BA	4	—	C	6/25
28W/9419474	SP.15/C								Washer, 2 BA plain	4	—	C	6/26
42611	E.G7.84.325								STOP, rubber, rear spigot	2	DTD.625	C	6/29
28FP/9469299	A.409								PIN, pip, $\frac{1}{4}$ " dia., retaining port end	1	—	C	6/24
10AS/3735	TILTMAN LANGLEY 167156								STRIPPER, window, low temperature	1	—	A	6/10
									Attaching parts for 10AS/3735 -				
28N/1046382	SP.121/C								Collar, $\frac{1}{4}$ "	4	—	C	6/11
28P/16272	SP.113/C7½								Pin, shear	4	—	C	6/14
28P/9486478	SP.90/C5								Pin, split	4	—	C	6/12

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
-	ELECTRICAL EQUIPMENT, STARBOARD CONTAINER (EG7.81.308) Spares for:—	-	-	8/10
NAT.PLASTICS X114	BEADING, PVC, diaphragm 1 and 2 and wing connection	QR	-	8/13
WARD BROOKE WB/UN/1146/S/3/W	BLOCK, terminal, 3-way	1	-	8/24
	Attaching parts for WB/UN/1146/S/3/W			
AGS2001/B/1	Nut, stiff, 4BA	2	-	8/23
WARD BROOKE WB/1114/28	Pillar, fixing	2	-	8/26
EG7.81.329	BOLT, special, earthing, distributor box	1	S1	8/16
WARD BROOKE WB/NY/1110/B/3	COVER, terminal block	1	-	8/28
BOSTIK2101	COMPOUND, sealing, bostik 2102	QR	DTD900/4686	8/27
SUPERFLEXIT SC001-10/18	CONDUIT, nose hinge	1	-	8/15
SUPERFLEXIT SCF1312-10	CLIP, 'P', hose hinge	2	-	8/31
EG7.81.2061	FAIRLEAD, assembly, diaphragm 4 Attaching parts for EG7.81.2061:—	1	-	8/30
A25/2C	Bolt, 2BA hex head	4	-	8/29
EG7.81.2063	FAIRLEAD, assembly, diaphragm 4 Attaching parts for EG7.81.2063:—	1	-	8/21
A25/2C	Bolt, 2BA hex head	4	-	8/22
EG7.81.2065	FAIRLEAD, assembly, diaphragm 4 Attaching parts for EG7.81.2065:—	1	-	8/19
A25/2B	Bolt, 4BA hex head	4	-	8/20
-	LOOMS, CABLE (EG7.81.320) Spares for:—	-	-	8/11
EG7.81.528	CABLE, ASSEMBLY, S451 FROM WING TIP BREAK TO STRIPPER UNIT, GROUP Spares for:—	1	-	8/14
UNINYVIN 12	CABLE, uninyvin 12	QR	-	
UYVINMET-SHEATH 16	CABLE, uyvinmetsheath 16	QR	-	
UNINYVIN 20	CABLE, uninyvin 20	QR	-	
UNTERSIL 20	CABLE, uniersil 20	QR	-	
CC610/037	CLAMP, cable	1	-	
508/1/07779/001	CLAMP, cable	1	-	
508/1/07777/001	CLAMP, cable	1	-	
EEAS559/6	CLIP, bonding	1	-	
508/2/07706/300	GASKET, outlet	1	-	
508/2/07705/300	GASKET, outlet	1	-	

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
508/2/07722/300	 GASKET, union	1	-	
508/2/07721/300	 GASKET, union	1	-	
508/2/07652/001	 OUTLET, angle	1	-	
508/2/07649/001	 OUTLET, angle	1	-	
BMS.FIX32-7P	 PLUG, fixed	1	-	
508/2/04368	 PLUG, filler 12	5	-	
508/2/04367	 PLUG, filler 16	15	-	
2Z111033	 PLUG, pin 12	7	-	
508/2/03547/002	 PLUG, pin 16	8	-	
508/2/05604/002	 PLUG, pin 16/20	20	-	
508/2/07709/300	 PLUG, sealing	1	-	
508/2/07710/300	 RING, sealing	1	-	
508/2/07757/007	 RING, thrust	1	-	
508/2/07754/007	 RING, thrust	1	-	
EEAS146/2	 SLEEVE, 1-1/2" long	QR	-	
EEAS146/2	 SLEEVE, 1" long	QR	-	
EEAS146/6	 SLEEVE, 1" long	QR	-	
EEAS146/12	 SLEEVE, 1" long	QR	-	
EEAS146/16	 SLEEVE, 1/4" long	QR	-	
691 (ET)-10-3S	 SOCKET, free, Mk 6 3-way	1	-	
508/1/07009/220	 SOCKET, free Mk 7 (T4) 100°C	1	-	
508/1/07000/220	 SOCKET, free Mk 7 (T4) 100°C	1	-	
HC294	 TERMINAL, ring rag	2	-	
2Z139603	 WASHER, panel packing	1	-	
EG7.81.530	 CABLE, ASSEMBLY, S453, FROM FILTER AND DISTRUTOR BOX TO TEST SOCKET, GROUP Spares for:—	1	-	8/18
UNINYVIN 16	 CABLE, uninyvin 16	QR	-	
PC68.10	 CAP, blanking	1	-	
CC610/037	 CLAMP, special, Mk 6	2	-	
691 (ET)-10-3P	 PLUG, free, Mk 6 3-way	1	-	

AP101B-0417-3A

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EEAS146/6	 SLEEVE, 3/4" long	QR	-	
EEAS146/16	 SLEEVE, 1/4" long	QR	-	
681(ET)-10-3S	 SOCKET, fixed, Mk 6, 3-way	1	-	
-	 LIGHT, NAVIGATION, STARBOARD, ASSEMBLY (EG7.81.404)	-	-	8/12
	Spares for:—			
R UNINYVIN 20	 CABLE, uninyvin 20	QR	-	8/5
R 5L9952431	 LAMP, filament, 28v, 24w	1	-	8/1
R 5CX1043420	 LAMP, navigation, type 'B', starboard	1	-	8/2
	Attaching parts for 5CX/1043420:—			
AGS2002/A/1	 Nut, stiff, 6BA	4	-	8/9
R HT30-1/2	 SLEEVE, Helsyn 150, white, 1/2" long	1	-	8/6
EEAS146/12	 SLEEVE, 1-1/2" long	QR	-	8/8
EEAS146/12	 SLEEVE, 1" long	QR	-	8/4
EEAS146/20	 SLEEVE, 3/4" long	QR	-	8/3
HC294	 TERMINAL, ring tag	2	-	8/7
M.A.M.	 SLEEVE, 3 m/m i/d, pink, 3/8" long	3	-	8/25
CXH				
EEAS232	 WASHER, tapped 4BA, earth bolt	1	-	8/17
-	 DISCHARGER, CARTRIDGE, INSTALLATION (EG7.84.14)	-	-	9/1
	Spares for:—			
EG7.84.837	 BRACKET, bearing, lock-notched	3	S96	9/34
	Attaching parts for EG7.84.837:—			
EG7.84.873	 Bolt, 2BA special	3	S96	9/28
EG7.84.871	 Bolt, 5/16" BSF special	3	S96	9/27
EG7.84.947	 Bolt, special, turn buckle attaching	6	BAC.M37	10/23
EG7.84.963	 CRANK, ASSEMBLY, OUTBOARD TORQUE TUBE	1	-	12/23
	Spares for:—			
HOFFMANN CJ0	 JOINT, self aligning	1	-	12/13
	Attaching parts for EG7.84.963:—			
A25/7C	 Bolt, 2BA hex head	1	-	12/16
AGS2001/C/1	 Nut, stiff, 2BA	1	-	12/22
EG7.84.965	 CRANK, ASSEMBLY, INBOARD TORQUE TUBE	1	-	12/12
	Spares for:—			
HOFFMANN CJ0	 JOINT, self aligning	1	-	12/1
	Attaching parts for EG7.84.965:—			
A25/7C	 Bolt, 2BA hex head	1	-	12/2
AGS2001/C/1	 Nut, stiff, 2BA	1	-	12/11

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG7.84.1035	.	.	.	.	.	HOUSING, bearing torque tube, assembly Attaching parts for EG7.84.1035:—	2	—	12/14
A25/2C	.	.	.	.	.	Bolt, 2 BA hex head	4	—	12/3
A27/CP	.	.	.	.	.	Nut, 2BA plain	4	—	12/4
EG7.84.675	.	.	.	.	.	HOUSING, spring, stay bar	3	S96	9/35
EG7.84.844	.	.	.	.	.	LEVER, ARMING, SUB-ASSEMBLY, STATION 104 Spares for:—	1	—	9/38
EG7.84.677	.	.	.	.	.	BAR, stay Attaching parts for EG7.84.677:—	1	S96	9/25
EG7.84.863	.	.	.	.	.	Pin	1	S96	9/26
EG7.84.865	.	.	.	.	.	BUSH, pivot, top bracket	2	PTFE	9/7
EG7.84.1244	.	.	.	.	.	LATCH	1	S96	9/22
EG7.84.877	.	.	.	.	.	LINK, ARMING, ASSEMBLY, FRONT INBOARD Spares for:—	1	—	9/14
EG7.84.1043	.	.	.	.	.	EYE-END, ASSEMBLY Spares for:—	1	—	9/12
EG7.84.875	.	.	.	.	.	EYE-END	1	S96	9/20
HOFFMANN	.	.	.	.	.	JOINT, self aligning	1	—	9/11
CJ0	.	.	.	.	.				
EB2.47.375	.	.	.	.	.	FORK-END	1	S95	9/16
A27/ET	.	.	.	.	.	NUT, 1/4" BSF thin	2	—	9/13
EG7.84.879	.	.	.	.	.	ROD	1	S96	9/15
EG7.84.855	.	.	.	.	.	Attaching parts for EG7.84.877:— Bolt, 4BA special	1	BAC.M37	9/10
EG2.47.441	.	.	.	.	.	Bolt, 4BA special	1	BAC.M37	9/17
EB2.47.443	.	.	.	.	.	Nut, 4BA special	1	BAC.M37	9/24
EG7.84.857	.	.	.	.	.	Nut, 4BA slotted, special	1	BAC.M37	9/8
SP90/C6	.	.	.	.	.	Pin, split	1	—	9/9
EG7.84.1201	.	.	.	.	.	PLATE, spring Attaching parts for EG7.84.1201:—	1	S513	9/30
A36/B14	.	.	.	.	.	Screw, 4BA round head	2	—	9/33
SP55/B	.	.	.	.	.	Washer, 4BA spring	2	—	9/31
EG7.84.1289	.	.	.	.	.	SLEEVE	1	T35	9/19
EG7.84.1241	.	.	.	.	.	SPRING, stay bar Attaching parts for EG7.84.1241:—	1	DTD215	9/18
EG7.84.863	.	.	.	.	.	Pin	1	S96	9/23
EG7.84.846	.	.	.	.	.	LEVER, ARMING, SUB-ASSEMBLY, STATION 106 Spares for:—	1	—	11/35
EG7.84.677	.	.	.	.	.	BAR, stay Attaching parts for EG7.84.677:—	1	S96	11/27
EG7.84.863	.	.	.	.	.	Pin	1	S96	11/28
EG7.84.865	.	.	.	.	.	BUSH, pivot, top bracket	2	PTFE	11/18
EG7.84.1244	.	.	.	.	.	LATCH	1	S96	11/13

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG7.84.849	.	.	.	.	LINK, ARMING, ASSEMBLY, CENTRE INBOARD		1	-	11/22
EG7.84.903	.	.	.	.	Spares for:— EYE-END		1	S92	11/21
HOFFMANN CJO	.	.	.	.	Spares for:— JOINT, self aligning		1	-	11/20
EB2.47.375	.	.	.	.	FORK-END		1	S95	11/36
A27/ET	.	.	.	.	NUT, 1/4" BSF thin		1	-	11/24
EB2.47.405	.	.	.	.	ROD-END		1	BAC.M37	11/23
EG7.84.855	.	.	.	.	Attaching parts for EG7.84.849:— Bolt, 4BA special		1	BAC.M37	11/19
EB2.47.441	.	.	.	.	Bolt, 4BA special		1	BAC.M37	11/32
EG7.84.857	.	.	.	.	Nut, 4BA slotted special		1	BAC.M37	11/17
EB2.47.443	.	.	.	.	Nut, 4BA special		1	BAC.M37	11/29
SP90/C6	.	.	.	.	Pin, split		2	-	11/16
EG7.84.1201	.	.	.	.	PLATE, spring		1	S513	11/33
A36/B14	.	.	.	.	Attaching parts for EG7.84.1201:— Screw, 4BA round head		2	-	11/30
SP55/B	.	.	.	.	Washer, 4BA spring		2	-	11/31
EG7.84.1289	.	.	.	.	SLEEVE		1	T35	11/25
EG7.84.1241	.	.	.	.	SPRING, stay bay		1	DTD865	11/15
EG7.84.863	.	.	.	.	Attaching parts for EG7.84.1241:— Pin		1	S96	11/26
EG7.84.848	.	.	.	.	LEVER, ARMING, SUB-ASSEMBLY, STATION 110		1	-	10/22
EG7.84.677	.	.	.	.	Spares for:— BAR, stay		1	S95	10/17
EG7.84.863	.	.	.	.	Attaching parts for EG7.84.677:— Pin		1	S96	10/16
EG7.84.865	.	.	.	.	BUSH, pivot, top bracket		2	PTFE	10/6
EG7.84.1244	.	.	.	.	LATCH		1	S96	10/1
EG7.84.853	.	.	.	.	LINK, ARMING, ASSEMBLY, REAR		1	-	10/10
EG7.84.903	.	.	.	.	Spares for:— EYE-END, ASSEMBLY		1	-	10/9
HOFFMANN CJO	.	.	.	.	Spares for:— JOINT, self aligning		1	-	10/8
EG7.84.909	.	.	.	.	FORK-END		1	S96	10/13
A27/ET	.	.	.	.	NUT, 1/4" BSF thin		1	-	10/12
EB2.47.405	.	.	.	.	ROD-END		1	BAC.M37	10/11
EG7.84.855	.	.	.	.	Attaching parts for EG7.84.853:— Bolt, 4BA special		2	BAC.M37	10/7
EG7.84.857	.	.	.	.	Nut, 4BA slotted, special		2	BAC.M37	10/5
SP90/C6	.	.	.	.	Pin, split		2	-	10/4

TANKS

WINDOW DISPENSING CONTAINER, STARBOARD

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG7.84.1201	.	.	.	PLATE, spring			1	S513	10/18
	.	.	.	Attaching parts for EG7.84.1201:—					
A36/B14	.	.	.	Screw, 4BA round head			2	—	10/20
SP55/B	.	.	.	Washer, 4BA spring			2	—	10/19
EG7.84.1289	.	.	.	SLEEVE			1	T35	10/14
EG7.84.1241	.	.	.	SPRING, stay bar			1	DTD865	10/3
	.	.	.	Attaching parts for EG7.84.1241:—					
EG7.84.863	.	.	.	Pin			1	S96	10/15
EG7.84.1309	.	.	.	LEVER, idle, assembly			1	L65	11/1
	.	.	.	Spares for:—					
HOFFMANN	.	.	.	JOINT, self aligning			2	—	11/2
CJ0	.	.	.						
EG7.84.851	.	.	.	LINK, ARMING, ASSEMBLY, CENTRE			1	—	11/8
	.	.	.	OUTBOARD					
	.	.	.	Spares for:—					
EB2.47.375	.	.	.	FORK-END			2	S95	11/12
A27/ET	.	.	.	NUT, 1/4" BSF thin			2	—	11/10
EB2.47.405	.	.	.	ROD-END			2	BAC.M37	11/9
	.	.	.	Attaching parts for EG7.84.851:—					
EB2.47.441	.	.	.	Bolt, 4BA special			2	BAC.M37	11/7
EB2.47.443	.	.	.	Nut, 4BA special			2	BAC.M37	11/11
SP90/C6	.	.	.	Pin, split			2	—	11/6
AIR-LOG LTD	.	.	.	MATRIX, assembly			3	—	9/3
D104084/91	.	.	.						
AIR-LOG LTD	.	.	.	PLATE, reaction, assembly			3	—	9/4
D104084/89	.	.	.						
	.	.	.	Attaching parts for D104084/89:—					
EEAS100/4E	.	.	.	Bolt, 1/4" BSF 90° c'sk head (rear plate)			14	S97	9/6
EEAS100/3-1/2E	.	.	.	Bolt, 1/4" BSF 90° c'sk head (forward plates)			14	S97	9/5
EG7.84.938	.	.	.	RAMP, mounting, aft, centre and rear arming			2	S96	12/38
	.	.	.	levers					
	.	.	.	Attaching parts for EG7.84.938:—					
EEAS1/1C	.	.	.	Bolt, 2BA 120° c'sk head			4	S96	12/28
A27/CT	.	.	.	Nut, 2BA thin			4	—	12/30
EG7.84.985	.	.	.	Shim			2	LA3	12/32
EG7.84.940	.	.	.	RAMP, mounting, aft, front arming lever			1	S96	12/40
	.	.	.	Attaching parts for EG7.84.940:—					
EEAS1/3C	.	.	.	Screw, 2BA 120° c'sk head			2	S96	12/31
A27/CT	.	.	.	Nut, 2BA thin			2	—	12/34
EG7.84.987	.	.	.	Shim			1	LA3	12/35
EG7.84.942	.	.	.	RAMP, mounting, forward, front and rear arming			2	S96	12/42
	.	.	.	levers					
	.	.	.	Attaching parts for EG7.84.942:—					
EEAS1/3C	.	.	.	Screw, 2BA 120° c'sk head			4	S96	12/29
A27/CT	.	.	.	Nut, 2BA thin			4	—	12/36
EG7.84.985	.	.	.	Shim			2	LA3	12/33
EG7.84.1303	.	.	.	SHAFT, idler lever			1	S96	11/5
	.	.	.	Attaching parts for EG7.84.1303:—					
A25/1C	.	.	.	Bolt, 2BA hex head			4	—	11/4
A27/CP	.	.	.	Nut, 2BA thin			4	—	11/3
EG7.84.1217	.	.	.	SPRING, bar stay			3	DTD215	9/36
	.	.	.	Attaching parts for EG7.84.1217:—					
EG7.84.949	.	.	.	Pin			3	—	9/32




FIG 1 JETTISON WING FUEL TANK 250 GALLON PORT AND STBD

T.MK. 17, SECT Q




FIG 2 WINDOW DISPENSING CONTAINER PORT AND STARBOARD WING

Restricted




FIG 3 WINDOW DISPENSING CONTAINER PORT AND STARBOARD WING

Restricted

T MK 17 SECT Q




FIG4 WINDOW DISPENSING CONTAINER PORT AND STARBOARD WING
Restricted

Restricted

AL 4




FIG 5 WINDOW DISPENSING CONTAINER PORT AND STARBOARD WING

Restricted

T MK 17 SECT Q





FIG 6 WINDOW DISPENSING CONTAINER PORT AND STARBOARD WING
Restricted






FIG.8 WINDOW DISPENSING CONTAINER(STBD WING)
Restricted




FIG.9 WINDOW DISPENSING CONTAINER (PORT AND STBD WING)




FIG. 10 WINDOW DISPENSING CONTAINER (PORT AND STBD WING)

Restricted




FIG.11 WINDOW DISPENSING CONTAINER (PORT AND STBD WING)

Restricted




FIG.12 WINDOW DISPENSING CONTAINER (PORT AND STBD WING)