

AP.101B-0418-3A

FUSELAGE

Page H1

FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R —	NOSE FUSELAGE ASSEMBLY (EG9.00.5) (Pre-Mod 5349)	—	—	1/1
R EG9.00.285	NOSE FUSELAGE ASSEMBLY (Spares condition based on EG9.00.5 to LTF standard) (Mod 5349) Spares for:-	1	—	
EG9.75.5	. AIR VENTILATED SUIT SYSTEM (See page NA1)	—	—	
—	. BLAST COOLING FOR INVERTER TYPE 103A AND 108A ASSEMBLY (EG9.74.1) Spares for:-	—	—	1/2
AGS605/3 or	. . CLIP, hose	2	—	1/3
SP91L	. . CLIP, hose	2	—	1/3
EG9.74.3	. . INTAKE, air assembly Attaching parts for EG9.74.3:-	1	—	1/4
AS1248/1C	. . Bolt, 2 BA mushroom head	9	—	1/5
AGS2001C1	. . Nut, stiff, 2 BA	9	—	1/6
SP13C	. . Washer, 2 BA plain	9	—	1/7
EG9.74.13	. . PIPE, inverter cooling	1	L.54 or L.59	1/8
BELLS ASBESTOS BAS161/1/2/36/12	. . SLEEVE, connecting	1	—	1/9
BELLS ASBESTOS BAS184-2	. . TAPE, bedding	QR	—	1/10
EG9.75.3	. CABIN PRESSURE SYSTEM (See page NB1)	—	—	
EG9.74.19	. COLD AIR TO PILOT, ASSEMBLY (See page NF1)	—	—	
—	. COMPASS G4B INSTALLATION (EG9.80.727) Spares for:-	—	—	1/11
—	. . PANEL CONTROL G4B INSTALLATION (EA3.80.1327) Spares for:-	—	—	1/12
R 15402-0	. . . PANEL, control type A Attaching parts for 15402-0:-	1	—	1/13
A32C16	. . . Screw, 2 BA round head	4	—	1/14
EA1.47.5	. CONTROLS ENGINE ASSEMBLY (See page DC1)	—	—	
EA3.45.3	. CONTROLS FLYING ASSEMBLY (See page DH1)	—	—	
EG9.76.1	. DEMISTING SYSTEM ASSEMBLY (See page NG1)	—	—	
EG9.81.5	. ELECTRICAL EQUIPMENT IN FRONT FUSELAGE (See page EA1)	—	—	
EG9.80.1	. EQUIPMENT IN PRESSURE CABIN (See page F1)	—	—	

FUSELAGE
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	GEAR EMERGENCY RELEASE MECHANISM BOMB DOORS AND UNDERCARRIAGE ASSEMBLY (EA1.45.749) Spares for:-	—	—	2/1
—	BRACKETS AND HANDLE AT FRAMES 1 AND 2 ASSEMBLY (EA1.45.815) Spares for:-	—	—	2/2
EA1.45.1041	BRACKET, bottom frame 1	1	L.72	2/3
EA2.45.201	BRACKET, top frame 1	1	L.72	2/4
EA1.45.831	BRACKET, bottom frame 2	1	L.72	2/5
EA1.45.829	BRACKET, top frame 2 Attaching parts for EA1.45.1041, EA2.45.201, EA1.45.831 and EA1.45.829:-	1	L.72	2/6
A25/1C	Bolt, 2 BA hex head	3	—	2/7
AGS2001C1	Nut, stiff, 2 BA	3	—	2/8
SP15C	Washer, 2 BA plain	3	—	2/9
EA3.45.633	HANDLE, operating assembly (Mod 5220) Attaching parts for EA3.45.633:-	1	L.72	2/10
A25/1C	Bolt, 2 BA hex head	4	—	2/11
SP15C	Washer, 2 BA plain	4	—	2/12
AS107 or AS1151	PULLEY, shrouded PULLEY shrouded (Alternative to AS.107) Attaching parts for AS107:-	2 2	— —	2/13
A25/8E	Bolt, 1/4" BSF hex head	1	—	2/14
AGS2001E1	Nut stiff, 1/4" BSF	1	—	2/15
SP16E	Washer, 1/4" BSF plain	1	—	2/16
R 5E/5253563	WIRE, copper enamelled	QR	—	
—	BRACKETS AND LEVER AT FRAME 4 ASSEMBLY (EA1.45.813) Spares for:-	—	—	2/17
EA1.45.875	BRACKET, bottom inboard	1	L.72	2/18
EA1.45.877	BRACKET, bottom outboard	1	L.72	2/19
EA1.45.871	BRACKET, top inboard	1	L.72	2/20
EA1.45.873	BRACKET, top outboard Attaching parts for EA1.45.875, EA1.45.877, EA1.45.871 and EA1.45.873:-	1	L.72	2/21
AS1242/1C	Bolt, 2 BA c'sk head (as required)	1	—	2/22
A25/1C	Bolt, 2 BA hex head (as required)	11	—	2/23
AGS2001C1	Nut, stiff 2 BA (as required)	12	—	2/24
SP15C	Washer, 2 BA plain (as required)	12	—	2/25
EA1.45.883	FAIRLEAD Attaching parts for EA1.45.883:-	1	LFS.21	2/26
A25/6C	Bolt, 2 BA hex head	2	—	2/27
AGS2001C1	Nut, stiff, 2 BA	2	—	2/28
EA3.45.295	LEVER, assembly Attaching parts for EA3.45.295:-	1	—	2/29
A25/3E	Bolt, 1/4" BSF hex head	1	—	2/30
AGS2001E1	Nut, stiff 1/4" BSF	1	—	2/31
SP16E	Washer, 1/4" BSF plain	1	—	2/32

FUSELAGE
FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EEAS15/75/150/ ER		PLATE, link, lower	2	L72	2/33
EA1.45/909		PLATE, link, upper	2	—	2/34
AGS899/2		Attaching parts for EA1.45.909:— Collar	1	—	2/35
SP4Y/B14		Pin, shackle	1	—	2/36
EA1.45.1317		Tube, distance	2	—	2/37
AS1151		PULLEY, shrouded (Alternative to AS107) Attaching parts for AS1151:—	2	—	2/38
A25/8E		Bolt, 1/4" BSF hex. head	1	—	2/39
A25/9E		Bolt, 1/4" BSF hex. head	1	—	2/40
AGS2001/E/1		Nut, stiff, 1/4" BSF	1	—	2/41
SP16/E		Washer, 1/4" BSF plain	1	—	2/42
5E/5253563		WIRE, copper, enamelled (SAS4746)	QR	—	
EA3.45.275		CABLES, BOMB AND UNDERCARRIAGE, ASSEMBLY Spares for:—	1	—	2/43
EA2.45.413		BARREL, pressure seal	1	—	2/44
AGS2030/147		CIRCLIP, internal, 3/4" bore	1	—	2/45
EA1.45.1129		ROLLER, aft end bomb door	1	—	2/46
SP8Y/13		ROLLER	3	—	2/47
EA1.45.889		WASHER, felt, pressure seal	7	DTD590 R64 Felt	2/48
EA1.45.891		WASHER, retaining, pressure seal	1	LFS21	2/49
EA1.45.275A		WIRE, flexible steel, bomb door	1	6WT/4	2/50
EA1.45.275B		WIRE, flexible steel, undercarriage	1	6WT/4	2/51
EA1.45.883		FAIRLEAD, frame 3 Attaching parts for EA1.45.883:—	1	LFS21	2/52
A25/6C		Bolt, 2 BA hex. head	2	—	2/53
AGS2002/C/1		Nut, stiff, 2 BA	2	—	2/54
EA1.45.881		FAIRLEAD, frames 5 to 11 Attaching parts for EA1.45.881:—	7	LFS21	2/55
A25/6C		Bolt, 2 BA hex. head	2	—	2/56
AGS2002/C/1		Nut, stiff, 2 BA	2	—	2/57
EA1.45.1121		FAIRLEAD, frame 12A Attaching parts for EA1.45.1121:—	1	LFS21	2/58
AS1242/5B		Bolt, 4 BA c'sk head	2	—	2/59
AGS2001/B/1		Nut, stiff, 4 BA	2	—	2/60
A33/B24		Screw, 4 BA c'sk head	2	—	2/61
SP15/B		Washer, 4 BA plain	2	—	2/62
EA2.45.415		WASHER, wedge, pressure bulkhead Attaching parts for EA2.45.415:—	2	—	2/63
A25/10C		Bolt, 2 BA hex. head	2	—	2/64
AGS2001/C/1		Nut, stiff, 2 BA	2	—	2/65
—		HYDRAULIC EQUIPMENT IN FRONT FUSELAGE (EG9.73.5) (See page NV1)	—	—	

FUSELAGE
FRONT FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R —	INSULATION, CABIN (EG9.17.1)						—	—	
	Spares for:—								
R Bostic CS2558	.	.	.	ADHESIVE			QR	—	
R EG9.17.23	.	.	.	BLANKET			1	—	36/1
R EG9.17.25	.	.	.	BLANKET			1	—	36/2
R EG9.17.27	.	.	.	BLANKET			1	—	36/3
R EG9.17.29	.	.	.	BLANKET			1	—	36/4
R EG9.17.31	.	.	.	BLANKET			1	—	36/5
R EG9.17.33	.	.	.	BLANKET			1	—	36/6
R EG9.17.35	.	.	.	BLANKET			1	—	36/7
R EG9.17.37	.	.	.	BLANKET			1	—	36/8
R EG9.17.39	.	.	.	BLANKET			1	—	36/9
R EG9.17.41	.	.	.	BLANKET			1	—	36/10
R EG9.17.43	.	.	.	BLANKET			1	—	36/11
R EG9.17.45	.	.	.	BLANKET			1	—	36/12
R EG9.17.47	.	.	.	BLANKET			1	—	36/13
R EG9.17.49	.	.	.	BLANKET			1	—	36/14
R EG9.17.3	.	.	.	BLANKET			1	—	36/15
R EG9.17.51	.	.	.	BLANKET (Pre Mod.4470)			1	—	36/16
R EG9.17.89	.	.	.	BLANKET (Mod.4470)			1	—	36/17
R EG9.17.5	.	.	.	BLANKET			1	—	36/18
R EG9.17.7	.	.	.	BLANKET			1	—	36/19
R EG9.17.53	.	.	.	BLANKET			1	—	36/20
R EG9.17.55	.	.	.	BLANKET			1	—	36/21
R EG9.17.57	.	.	.	BLANKET			1	—	36/22
R EG9.17.59	.	.	.	BLANKET			1	—	36/23
R EG9.17.61	.	.	.	BLANKET			1	—	36/24
R EG9.17.63	.	.	.	BLANKET			1	—	36/25
R EG9.17.65	.	.	.	BLANKET			1	—	36/26
R EG9.17.67	.	.	.	BLANKET			1	—	36/27
R EG9.17.69	.	.	.	BLANKET			1	—	36/28
R EG9.17.71	.	.	.	BLANKET			1	—	36/29
R EG9.17.73	.	.	.	BLANKET			1	—	36/30
R EG9.17.75	.	.	.	BLANKET			1	—	36/31
R EG9.17.77	.	.	.	BLANKET			1	—	36/32
R EG9.17.79	.	.	.	BLANKET			1	—	36/33
R EG9.17.81	.	.	.	BLANKET			1	—	36/34
R EG9.17.83	.	.	.	BLANKET			1	—	36/35
R EG9.17.9	.	.	.	BLANKET			1	—	36/36
R EG9.17.11	.	.	.	BLANKET			1	—	36/37
R EG9.17.13	.	.	.	BLANKET			1	—	36/38
R EG9.17.15	.	.	.	BLANKET			1	—	36/39
R EG9.17.17	.	.	.	BLANKET			1	—	36/40
R EG9.17.191	.	.	.	BLANKET			1	—	36/41
R EG9.17.85	.	.	.	BLANKET			1	—	36/42
R EG9.17.87	.	.	.	BLANKET			1	—	36/43

AP101B-0418-3A

Page H3B

FUSELAGE

FRONT FUSELAGE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EG9.80.563	.	.	INSULATION, passengers floor				1	-	36/44
EB6.17.137	.	.	MAT, rubber				1	-	36/45
EB6.17.135	.	.	MAT, rubber				1	-	36/46
EG9.17.21	.	.	MAT, floor				1	-	36/47
EB7.17.35	.	.	PAD, insulation (Pre—Mod 5513)				1	-	36/48
EB7.17.37	.	.	PAD, insulation				1	-	36/49
EA3.17.5339	.	.	PAD, insulation				1	-	36/50
EA3.17.5341	.	.	PAD, insulation				1	-	36/51
EA3.17.5349	.	.	PAD, insulation				1	-	36/52
EA3.17.5385	.	.	PAD, insulation				1	-	36/53
EA3.17.5387	.	.	PAD, insulation				1	-	36/54
-			NOSE, UNDERCARRIAGE ASSEMBLY (EA9.40.1) (See page RB1)				-	-	
-	.	.	OXYGEN DEMAND SYSTEM, ASSEMBLY (EG9.71.1) (See page NAA1)				-	-	

FUSELAGE

FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG9.80.197	. PITOT AND STATIC PIPES (See page NAC1)	—	—	
EG9.10.1	. STRUCTURE, FRONT FUSELAGE (See page HA1)	—	—	
—	. TUNNEL, BOMB AIMER'S, ASSEMBLY (EG9.10.115) Spares for:—	—	—	3/1
EA3.10.2311	. . COVER, hand pump	1	L59	3/2
EG9.10.113	. . FAIRING, channel Attaching parts for EG9.10.113:—	1	—	3/3
AS1248/2B	. . Bolt, 4BA mushroom head	6	—	3/4
EB6.10.333	. . PLATFORM, BOMB AIMER'S CHEST, AND CUSHION, ASSEMBLY Spares for:—	1	—	3/5
EA3.10.2853	. . . CUSHION Spares for:—	1	—	3/6
708A	 PLATE, clinch	11	—	3/7
N608	 SOCKET	11	—	3/8
EB6.10.329	. . . PLATFORM, BOMB AIMER'S, ASSEMBLY Spares for:—	1	—	3/9
EB6.10.319	 SPIGOT	1	S92	3/10
EB6.10.320	 SPIGOT	1	S92	3/11
—	. . . TUNNEL, ACCESSORIES, ASSEMBLY (EG9.10.117) Spares for:—	—	—	3/12
EA3.10.2297	 COVER, inner	1	—	3/13
EA3.10.2303	 GUARD, pedal	1	—	3/14

AP101B-0418-3A

Page HA.1

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
—		FRONT FUSELAGE STRUCTURE, ASSEMBLY (EG9.10.1) (EA3.10.1) Spares for:—	—	—	4/1
—		ALTERATIONS TO NAVIGATOR'S HATCH LONGERONS AND FORWARD AND AFT MEMBERS (EA3.10.6387) (Alt. R60/88) Spares for:—	—	—	
EA3.10.6417	. .	ANGLE, LH	1	—	37/1
EA3.10.6418	. .	ANGLE, RH	1	—	37/2
EA3.10.6419	. .	ANGLE, LH	1	—	37/3
EA3.10.6420	. .	ANGLE, RH	1	—	37/4
EA3.10.6421	. .	ANGLE, LH	1	—	37/5
EA3.10.6422	. .	ANGLE, RH	1	—	37/6
EA3.10.6427	. .	ANGLE, LH	3	—	37/7
EA3.10.6428	. .	ANGLE, RH	3	—	37/8
EA3.10.6429	. .	ANGLE, LH	1	—	37/9
EA3.10.6430	. .	ANGLE, RH	1	—	37/10
EA3.10.65	. .	ANGLE, LH	1	—	37/11
EA3.10.66	. .	ANGLE, RH	1	—	37/12
EA3.10.6395	. .	ARCH, forward member (Pre—Mod 5349)	1	—	37/13
EA3.00.5737	. .	ARCH, forward member (Mod 5349)	1	—	
EA3.10.6399	. .	ARCH, aft member (Pre—Mod 5349)	1	—	37/14
EA3.00.5735	. .	ARCH, aft member (Mod 5349)	1	—	
EA3.10.561	. .	ARM, steady	23	—	37/15
EA3.10.173	. .	CLEAT	2	—	37/16
EA3.10.171	. .	CLEAT	2	—	37/17
EA3.10.6415	. .	DIAPHRAGM, LH	1	—	37/18
EA3.10.6416	. .	DIAPHRAGM, RH	1	—	37/19
EA3.10.6501	. .	DIAPHRAGM, LH	1	—	37/20
EA3.10.6502	. .	DIAPHRAGM, RH	1	—	37/21
EA3.10.6503	. .	DIAPHRAGM, LH	1	—	37/22
EA3.10.6504	. .	DIAPHRAGM, RH	1	—	37/23
EA3.10.6505	. .	DOUBLING, LH	1	—	37/24
EA3.10.6506	. .	DOUBLING, RH	1	—	37/25
EA3.10.6389	. .	FRAME, bolt assembly (Pre—Mod 5349)	1	—	37/26
EA3.00.5783	. .	FRAME, bolt assembly (Mod 5349)	1	—	
		Spares for:—			
EA3.10.6391	. . .	BLOCK, corner	2	—	37/27
EA3.10.6393	. . .	BLOCK, corner	2	—	37/28
EA3.10.1981	. . .	BLOCK	30	—	37/29
EA3.10.161	. . .	FRAME, bolt, forward	1	—	37/30
EA3.10.163	. . .	FRAME, bolt, aft	1	—	37/31
EA3.10.165	. . .	FRAME, bolt, LH	1	—	37/32
EA3.10.166	. . .	FRAME, bolt, RH	1	—	37/33
AGS2008/E/1	. . .	NUT, anchor, 1/4" BSF thin	68	—	37/34
		Attachments for:—			
EA1.10.1029	. .	Bolt, explosive	34	—	37/35
EA3.10.6407	. .	Bush	21	—	37/36
EA3.10.6511	. .	Bush	2	—	37/37
A27LT	. .	Nut, thin, 7/16" BSF	34	—	37/38
EA3.10.6411	. .	Tube, distance	2	—	37/39
EA3.10.6413	. .	Tube, distance	21	—	37/40
AGS2035L	. .	Washer, shakeproof 7/16" BSF	34	—	37/38A

R

R

FUSELAGE

AP101B-0418-3A

FRONT FUSELAGE STRUCTURE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R EA3.10.6401	.	.	.	.	.	FITTING, forward, LH	1	—	38/1
R EA3.10.6403	.	.	.	.	.	FITTING, aft, LH	1	—	38/2
R A59/7E	.	.	.	.	.	Attachments for EA3.10.6401 and EA3.10.6403:—			
R A59/5E	.	.	.	.	.	Bolt, 1/4" BSF	3	—	38/3
R A59/3E	.	.	.	.	.	Bolt, 1/4" BSF	4	—	38/4
R A25/3C	.	.	.	.	.	Bolt, 1/4" BSF	4	—	38/5
R A27/CP	.	.	.	.	.	Bolt, 2BA	5	—	38/6
R A27/EP	.	.	.	.	.	Nut, 2BA, plain	5	—	38/7
R SP124/E	.	.	.	.	.	Nut, 1/4" BSF, plain	11	—	38/8
R SP125/E	.	.	.	.	.	Washer, thin	4	—	38/9
R SP125/C	.	.	.	.	.	Washer, thick	4	—	38/10
R	.	.	.	.	.	Washer, thick	5	—	38/11
R EA3.10.6402	.	.	.	.	.	FITTING, forward, RH	1	—	38/12
R EA3.10.6404	.	.	.	.	.	FITTING, aft, RH	1	—	38/13
R	.	.	.	.	.	Attachments for EA3.10.6402 and EA3.10.6404:—			
R A59/7E	.	.	.	.	.	Bolt, 1/4" BSF	3	—	38/14
R A59/5E	.	.	.	.	.	Bolt, 1/4" BSF	4	—	38/15
R A59/3E	.	.	.	.	.	Bolt, 1/4" BSF	4	—	38/16
R A25/3C	.	.	.	.	.	Bolt, 2BA	5	—	38/17
R A27/CP	.	.	.	.	.	Nut, 2BA, plain	5	—	38/18
R A27/EP	.	.	.	.	.	Nut, 1/4" BSF, plain	11	—	38/19
R SP124/E	.	.	.	.	.	Washer, thin	4	—	38/20
R SP125/E	.	.	.	.	.	Washer, thick	4	—	38/21
R SP125/C	.	.	.	.	.	Washer, thick	5	—	38/22
R EA3.10.6513	.	.	.	.	.	GUSSET, LH	1	—	38/23
R EA3.10.6514	.	.	.	.	.	GUSSET, RH	1	—	38/24
R EA3.10.6433	.	.	.	.	.	LONGERON, escape hatch, LH	1	—	38/25
R EA3.10.6435	.	.	.	.	.	LONGERON, escape hatch RH	1	—	38/26
R EA3.10.45	.	.	.	.	.	LONGERON, member, LH	1	—	38/27
R EA3.10.46	.	.	.	.	.	LONGERON, member, RH	1	—	38/28
R EA3.10.6497	.	.	.	.	.	PACKING	1	—	38/29
R EA3.10.6499	.	.	.	.	.	PACKING	1	—	38/30
R EA3.10.6481	.	.	.	.	.	PANEL, skin, LH	1	—	38/31
R EA3.10.6482	.	.	.	.	.	PANEL, skin, RH	1	—	38/32
R EA3.10.515	.	.	.	.	.	PANEL, skin	1	—	38/33
R EA3.10.1097	.	.	.	.	.	PANEL, skin	1	—	38/34
R EA3.10.503	.	.	.	.	.	PANEL, skin	1	—	38/35
R EA3.10.1099	.	.	.	.	.	PANEL, skin	1	—	38/36
R EA3.10.519	.	.	.	.	.	PANEL, skin	1	—	38/37
R EA3.10.6431	.	.	.	.	.	PLATE, tie	1	—	38/38
R EA3.10.6432	.	.	.	.	.	PLATE, tie	1	—	38/39
R EA3.10.6515	.	.	.	.	.	REINFORCING, LH	1	—	38/41
R EA3.10.6516	.	.	.	.	.	REINFORCING, RH	1	—	38/42
R EA3.10.549	.	.	.	.	.	SEAL, pressure	1	—	37/41
R EA3.10.6489	.	.	.	.	.	SHIM	2	—	38/44
R EA3.10.6491	.	.	.	.	.	SHIM	2	—	38/45
R EA3.10.6493	.	.	.	.	.	SHIM	2	—	38/46
R EA3.10.6495	.	.	.	.	.	SHIM	2	—	38/47
R EA3.10.6397	.	.	.	.	.	STIFFENER	1	—	38/48
R EA3.10.6483	.	.	.	.	.	STRAP, butt	2	—	38/49
R EA3.10.6485	.	.	.	.	.	STRAP, butt	2	—	38/50
R EA3.10.6487	.	.	.	.	.	STRAP, butt	2	—	38/51
R EA3.10.471	.	.	.	.	.	WEDGE, packing	10	—	38/52

AP101B-0418-3A

Page HA1B

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.10.391	. ARM, steady, L.H., for escape hatch explosive bolt Attaching parts for EA3.10.391:—	1	EEDX90	4/2
A61/2C	. Bolt, 2BA, hex. head	2	—	4/3
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/4
EA3.10.392	. ARM, steady, R.H., for escape hatch explosive bolt Attaching parts for EA3.10.392:—	1	EEDX90	4/5
A61/2C	. Bolt, 2BA, hex. head	2	—	4/3
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/4
EA3.10.561	. ARM, steady, for escape hatch explosive bolt Attaching parts for EA3.10.561:—	24	L72	4/6
A25/3C	. Bolt, 2BA, hex. head (at 2 positions)	2	—	4/7
A61/2C	. Bolt, 2BA, hex. head (at 6 positions)	2	—	4/8
A61/3C	. Bolt, 2BA, hex. head	2	—	4/9
A27/CP	. Nut, 2BA, plain (at 2 positions)	2	—	4/10
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/11
EA3.10.2551	. ARM, steady, L.H., for escape hatch explosive bolt Attaching parts for EA3.10.2551:—	1	L72	4/12
A61/3C	. Bolt, 2BA, hex. head	2	—	4/13
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/14
EA3.10.2552	. ARM, steady, R.H., for escape hatch explosive bolt Attaching parts for EA3.10.2552:—	1	L72	4/15
A61/3C	. Bolt, 2BA, hex. head	2	—	4/13
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/14
EA3.10.2583	. ARM, steady, for escape hatch explosive bolt Attaching parts for EA3.10.2583:—	3	EEDX90	4/16
A61/3C	. Bolt, 2BA, hex. head	2	—	4/17
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/18
EA3.10.2584	. ARM, steady, for escape hatch explosive bolt Attaching parts for EA3.10.2584:—	3	EEDX90	4/19
A61/3C	. Bolt, 2BA, hex. head	2	—	4/17
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/18
EA1.10.1029	. BOLT, special, navigator's escape hatch	34	L40	4/20
EA3.10.2581	. BRACKET, hinge Attaching parts for EA3.10.2581:—	1	L40	4/21
R AS1242/4C	. Bolt, 2BA, csk head	2	—	4/22
or				
R AS1242/5C	. Bolt, 2BA, csk head	2	—	4/23
R AS1242/6C	. Bolt, 2BA, csk head	2	—	4/24
or				
R AS1242/7C	. Bolt, 2BA, csk head	2	—	4/25
R AGS2001/C/1	. Nut, stiff, 2BA	4	—	4/26
R SP13/C	. Washer, 2BA plain	4	—	4/27
R EA1.20.1033	. Washer, special	8	Lam. Alum.	4/28

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.10.2582	. BRACKET, hinge Attaching parts for EA3.10.2582:—	1	L40	4/29
AS1242/4C or AS1242/5C AS1242/6C or AS1242/7C	. Bolt, 2BA, csk head	2	—	4/22
AGS2001/C/1 SP13/C	. Bolt, 2BA, csk head	2	—	4/23
EA1.20.1033	. Bolt, 2BA, csk head	2	—	2/24
	. Nut, stiff, 2BA	2	—	4/25
	. Washer, 2BA, plain	4	—	4/26
	. Washer, special	4	—	4/27
		8	Lam. Alum.	4/28
EA1.10.1163 or EA3.10.6407 EA1.10.1165 or EA3.10.6409	. BUSH, navigator's escape hatch explosive bolt	21	L40	4/30
EA3.10.3021 EA3.10.3019	. BUSH, navigator's hatch explosive bolt	21	—	4/31
	. BUSH, navigator's escape hatch explosive bolt	11	L40	4/31
	. BUSH, navigator's hatch explosive bolt	11	—	4/32
	. CAP, sealing, for escape hatch pivot	2	L40	4/32
	. COLLAR, sealing, for escape hatch pivot	2	L40	4/33
EA1.10.939	. DOOR, NOSE UNDERCARRIAGE, PORT, GROUP (Supplied to Part No. EA3.00.149 spares purposes) Spares for:—	1	—	5/1
EA1.10.957	. BLOCK, catch Attaching parts for EA1.10.957:—	2	—	5/2
EA1.10.961	. Bolt, special	4	—	5/3
EA1.10.963	. Shim	1	—	5/4
SP47/C	. Washer, 2BA, spring	4	—	5/5
EA1.10.1367	. BRACKET, door pick-up Attaching parts for EA1.10.1367:—	1	—	5/6
EA1.10.2707	. Bolt, special (Make from A25/3C)	8	—	5/7
EA1.10.1369	. Shim	1	—	5/8
EA1.10.1271	. HINGE (Make from AS1880 Ref. 28N/9486785)	1	—	5/9
EA1.10.1413	. HINGE	1	—	5/10
EA1.10.955	. PAD, rubber	1	—	5/13
EA1.10.2655	. PAD, stop	1	—	5/13
EA3.10.2811	. SEAL, 'P' (Pre—Mod 5282) (Make from EEAS122) (26FZ/4756)	1	—	5/13
EA3.10.6583	. SEAL, 'P' (Mod 5282) (Make from EEAS844) (26FZ/6147755) Attaching parts for EA3.10.2811 and 6583:—	1	—	5/14
AGS2001/A/1	. Nut, stiff, 6BA	16	—	5/15
A33/A12	. Screw, 6BA, csk head	16	—	5/11
EA1.10.949	. SHIM	1	Light Alloy	5/12
EA1.10.2065	. SPUR	1	—	5/12

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA1.10.2513	. . STRIP, securing	1	—	5/16
EA1.10.2515	. . STRIP, securing	1	—	5/17
EEAS6C	. . WASHER, cap	2	DTD.124A	5/18
EA1.10.940	. DOOR NOSE UNDERCARRIAGE STARBOARD GROUP (Supplied to Part No. EA3.00.150 for spares purposes) Spares for:-	1	—	5/19
EA3.10.3129	. . BLOCK, nose wheel door latch Attaching parts for EA3.10.3129:-	1	—	5/20
EA1.10.983	. . Bolt, special	2	—	5/21
SP47C	. . Washer, 2 BA spring	2	—	5/22
EA1.10.1367	. . BRACKET, door pick-up Attaching parts for EA1.10.1367:-	1	—	5/6
EA1.10.2707	. . Bolt, special (make from A25/3C)	8	—	5/7
EA1.10.1369	. . Shim	1	—	5/8
EA1.10.2071	. . BRACKET, roller Attaching parts for EA1.10.2071:-	1	—	5/23
A25/3C	. . Bolt, 2 BA hex head	2	—	5/24
A27CP	. . Nut, 2 BA plain	2	—	5/25
EA1.10.2077	. . Washer, special	2	—	5/26
EA3.10.3085	. . BRACKET, spring seating Attaching parts for EA3.10.3085:-	1	L.40	5/27
A25/3C	. . Bolt, 2 BA hex head	2	—	5/28
AGS2002C1	. . Nut, stiff, 2 BA	2	—	5/29
SP16C	. . Washer, 2 BA plain	2	—	5/30
EA1.10.1272	. . HINGE, assembly (Make from AS1880 Ref 28N/9486785)	1	—	5/31
EA1.10.1414	. . HINGE	1	—	5/32
EA3.10.3193	. . HOOK, door latch forward Attaching parts for EA3.10.3193:-	1	S.11	5/33
EA1.10.971	. . Pin pivot	1	—	5/34
EA1.45.989	. . Shim	1	—	5/35
EA3.10.3239	. . HOOK, door latch aft Attaching parts for EA3.10.3239:-	1	S.11	5/36
EA3.10.3375	. . Packing	5	L.72	5/37
EA1.10.971	. . Pin, pivot	1	—	5/38
SP15G	. . Washer, 5/16" BSF plain	1	—	5/39
EA1.10.955	. . PAD, rubber	1	—	5/9
EA1.10.1725	. . PLATE, cover Attaching parts for EA1.10.1725:-	1	—	5/40
A33B12	. . Screw 4 BA c'sk head	2	—	5/41
EA3.10.3211	. . ROD CONNECTING NOSE UNDERCARRIAGE DOOR HOOKS ASSEMBLY Consisting of:-	1	—	5/42
R EA3.10.3083	. . . COLLAR, spring adjusting	1	L.40	5/43
EA3.10.3207	. . . FORK-END	1	S.96	5/44
EA3.10.3213	. . . FORK-END	1	S.96	5/45
R A27CP	. . . NUT, 2 BA plain	2	—	5/46
R A27CPL	. . . NUT, 2 BA plain L.H.	1	—	5/47
R EA3.10.3209	. . . ROD, connecting	1	S.96	5/48
R EA3.20.2271	. . . SPRING Attaching parts for EA3.10.3211:-	1	DTD239A	5/49
R AGS899/1	. . Collar, shackle pin	2	—	5/50
R SP4Y/A7	. . Pin, shackle	2	—	5/51
R SP90A2	. . Pin, split	2	—	5/52

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA1.10.2075	. . ROLLER Attaching parts for EA1.10.2075:-	1	—	5/53
EA1.10.2073	. . Pin	1	—	5/54
EA3.10.2811	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS122) (26FZ/4756)	1	—	5/13
EA3.10.6583	. . SEAL, 'P' (Mod 5282) (Make from EEAS844) (26FZ/6147755) Attaching parts for EA3.10.2811 and EA3.10.6583:-	1	—	5/13
AGS2001A1	. . Nut, stiff, 6 BA	16	—	5/14
A33A12	. . Screw, 6 BA c'sk head	16	—	5/15
EA1.10.949	. . SHIM	1	Light Alloy	5/11
EA1.10.2145	. . STRIP, securing seal	1	—	5/55
EA1.10.2515	. . STRIP, securing seal	1	—	5/17
EEAS6C	. . WASHER, cap	2	DTD124A	5/18
EA1.10.1189	. DOOR, access, hydraulic reservoir	1	L.72	5/56
—	. DOOR EQUIPMENT WITH A.D.F. LOOP AERIAL INSTALLATION (EG9.10.109) Spares for:-	—	—	6/1
A25/7J	. . BOLT, 3/8" BSF hex head door hinge attachment	2	—	6/2
EEAS136	. . BRACKET, bonding lead attachment	2	L.72	6/3
EG9.82.99	. . DOOR EQUIPMENT HATCH AND STRUCTURE FOR A.D.F. LOOP AERIAL GROUP Spares for:-	1	—	6/4
EG7.10.227	. . . BLOCK, insulation	1	Tufnol	6/5
EA9.11.1681	. . . BRACKET, jury strut pivot	1	L.72	6/6
EA1.10.511	. . . LINK, connecting Attaching parts for EA1.10.511:-	2	—	6/7
SP4Y/B2	. . . Pin, shackle	1	—	6/8
SP90C4	. . . Pin, split	1	—	6/9
AS2866P	. . . LOCK Spares for:-	1	—	6/10
FGS50	 KEY	1	—	
or				
FFE4	 KEY Attaching parts for AS2866P:-			
EA1.10.2421	. . . Ring, packing	1	L.72	6/11
A33B12	. . . Screw, 4 BA c'sk head	11	—	6/12
EA3.82.363	. . . PANEL, dielectric	1	—	6/13
EA3.82.379	. . . PANEL, equipment access	1	L.72	6/14
EA1.10.2423	. . . PANEL, removable Attaching parts for EA1.10.2423:-	1	L.72	6/15
AS1248/1/2B	. . . Bolt, 4 BA mushroom head	26	—	6/16
EA1.10.549	. . . ROD, door lock	2	L.64	6/17
EA3.82.381	. . . SEAL, dielectric panel 1/16" thick	1	Neo-K-Tex	6/18
EA1.10.2425	. . . STRIP, sealing 1/2" wide (Make from EEAS141/1, Ref 12713)	1	—	6/19
EEAS237/11A	. . . WASHER, 'D'	1	L.72	6/20

FUSELAGE
FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	. . FRAME HATCH MODIFICATION (EA3.82.391) Spares for:-	—	—	6/21
EA3.82.395	. . . BRACKET, for plate L.H.	1	L.27	6/22
EA3.82.397	. . . BRACKET, for plate R.H.	1	L.72	6/23
EA3.82.393	. . . PLATE, strut roller slot	1	L.72	6/24
—	. . HINGES ATTACHMENT TO FUSELAGE ASSEMBLY (EA3.82.399) Spares for:-	—	—	6/25
EA3.82.401	. . . BRACKET, hinge assembly	1	—	6/26
EA3.82.402	. . . BRACKET, hinge assembly	1	—	6/27
EA3.82.409	. . . PLATE, lipped	1	—	6/28
EA3.82.415	. . . ROLLER Attaching parts for EA3.82.415:-	2	L.40	6/29
EA3.82.411	. . . Bolt, special 2 BA	1	L.40	6/30
A27CS	. . . Nut, 2 BA slotted	1	—	6/31
SP90C7	. . . Pin split	1	—	6/32
EA3.82.413	. . . Tube, distance 3/8" o/d x 17 SWG	1	L.62	6/33
SP15E	. . . Washer, 1/4" BSF plain	8	—	6/34
EA3.82.543	. . . SHIM, laminated	4	Alum Alloy	6/35
AGS2001J3	. . NUT, stiff, 3/8" BSF door hinge bolt attachment	2	—	6/36
EA3.82.421	. . STRUT, door assembly Attaching parts for EA3.82.421:-	1	—	6/37
A25/9E	. . Bolt, 1/4" BSF hex head	1	—	6/38
A27CS	. . Nut, 2 BA slotted	1	—	6/39
A27ES	. . Nut, 1/4" BSF slotted	1	—	6/40
SP90C7	. . Pin split	2	—	6/41
EA9.11.1677	. . Roller	1	T.45	6/42
EA9.11.1679	. . Tube distance	1	T.35	6/43
EEAS27/46EU	. . Washer, special	2	S.515	6/44
EA3.10.1401	. DOOR MAIN ENTRANCE ASSEMBLY (File door skin line until door fits freely in the frame clearance around door skin line 0".100±0".020) Spares for:-	1	—	7/1
EA1.10.1143	. . BOLT, assembly door forward	1	—	7/2
EA1.10.1145	. . BOLT, assembly door aft	1	—	7/3
EA3.10.2313	. . FAIRING, handle internal Attaching parts for EA3.10.2313:-	1	—	7/4
AS1248/2C	. . Bolt, 2 BA mushroom head	13	—	7/5
EA1.10.1785	. . HANDLE, door internal Attaching parts for EA1.10.1785:-	1	—	7/6
AS1248/2C	. . Bolt, 2 BA mushroom head	1	—	7/7
AGS585C	. . Washer, 2 BA spring	1	—	7/8
SP13C	. . Washer, 2 BA plain	1	—	7/9
AS2549	. . HANDLE, door outer	1	—	7/10
EA1.10.813	. . LEVER, cranked forward Attaching parts for EA1.10.813:-	1	DTD124A	7/11
A25/6C	. . Bolt, 2 BA hex head	1	—	7/12
EA1.10.1149	. . Tube, distance	1	—	7/13

FUSELAGE
FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA1.10.1337	. . LEVER, cranked aft Attaching parts for EA1.10.1337:-	1	DTD124A	7/14
A25/6C	. . Bolt, 2 BA hex head	1	—	7/12
EA1.10.1149	. . Tube distance	1	—	7/13
EA1.10.821	. . LINK, coupling crank lever to door handle Attaching parts for EA1.10.821:-	1	—	7/15
SP4Y/B4	. . Pin shackle	2	—	7/16
SP90A3	. . Pin split	2	—	7/17
SP13C	. . Washer, 2 BA plain	2	—	7/18
AS2864P	. . LOCK, flush fitting door Spares for:-	1	—	7/19
R FGS50 or R FFE4	. . . KEY Attaching parts for AS2864P:-	1	—	
AS1248/1B	. . Bolt, 4 BA mushroom head	4	—	7/20
A33/B20	. . Screw, 4 BA c'sk head	11	—	7/21
EA1.10.1319	. . PLATE, swivel door strap	1	L.72	7/22
EA1.10.1651	. . SEAL, cabin weather (Make from 32C/652)	A/R	—	
R —	. . STOWAGE FOR UNDERCARRIAGE FLAP AND BOMB DOOR LOCK PINS (CM.015) Consisting of:-	—	—	
R CM015FIG2	. . . PANEL, stowage mounting	1	—	
R CM015FIG3	. . . PLATE, backing	1	—	
R CM015FIG4	. . . POCKET, and flap Attaching parts for CM015FIG2, CM015FIG3 and CM015FIG4:-	1	—	
R AS2923/1/2C	. . . Bolt, mushroom head 2 BA	6	—	
R 4101-10-1/2	. . . Screw, PK	4	—	
R AGS2001C1	. . . Nut, stiff 2 BA	6	—	
R SP10C	. . . Washer	12	—	
R EA3.83.299	. . . LOCK, undercarriage safety (Ref only)	—	—	
R EA3.83.175	. . . LOCK, flap switch (Ref only)	—	—	
R EA3.83.151	. . . LOCK, bomb door (Ref only)	—	—	
EA3.10.2813	. . STRAP, support strut stowage	1	—	7/23
EA3.10.1459	. . TUBE, stay door prop	1	—	7/24
EA3.10.157	. FRAME, bolt navigator's escape hatch	1	—	8/1
or R EA3.10.6389	. FRAME, bolt navigator's escape hatch (Pre Mod 5349)	1	—	
R EA3.00.5783	. FRAME, bolt assembly (Spares for EA3.10.6389) (Mod 5349)			
EA1.10.1153	. HANDLE, main door jettison Attaching parts for EA1.10.1153:-	1	L.40	7/25
AS1248/5B	. Bolt, 4 BA mushroom head	1	—	7/26
AGS2035B	. Washer, 4 BA shakeproof	1	—	7/27

FUSELAGE

FRONT FUSELAGE STRUCTURE

	Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
R	EA3.00.5325	. HATCH NAVIGATOR'S ESCAPE ASSEMBLY (EA3.10.6301) (Pre-Mod 5349) Spares for:-	1	—	8/2
R	1240	. . BLOCK, terminal	1	—	8/3
R	A33A20	. . Attaching parts for 1240:- . . Screw, 6 BA c'sk head	2	—	8/4
	EA3.81.5849	. . CABLE ASSEMBLY N417, FROM T/B ON BLANKING PLATE, TO BUTT CONNECTOR GROUP Consisting of:-	1	—	
R	UNTERSIL20	. . . CABLE, untersil 20	QR	—	
R	CD2313	. . . CONNECTOR, butting 2-way	1	—	
	EEAS146/12	. . . SLEEVE, binding, 1/2" long	QR	—	
	EEAS146/20	. . . SLEEVE, ident, 3/4" long	QR	—	
	EEAS146/12	. . . SLEEVE, ident 1" long	QR	—	
R	5X/6958	. . . TAG, ring tongue	—	—	
	EA3.10.6109	. . CHANNEL, butt connector Attaching parts for EA3.10.6109:-	1	L.72	8/5
	A25/2C	. . Bolt, 2 BA hex head	4	—	8/6
	AGS2001C1	. . Nut, stiff 2 BA	4	—	8/7
	SP16C	. . Washer, 2 BA plain	4	—	8/8
	MARTIN BAKER MB/EU320EE	. . CLIP, safety harness stowage Attaching parts for MB/EU320EE .	4	—	8/9
	A25/5B	. . Bolt, 4 BA hex head	4	—	8/10
	AGS2001B1	. . Nut, stiff 4 BA	4	—	8/11
R	EA3.10.2277	. . Piece packing	1	LFS21	8/12
	EA3.10.2281	. . Piece packing	2	LFS21	8/13
	SP15B	. . Washer, 2 BA plain	4	—	8/14

FUSELAGE
FRONT FUSELAGE STRUCTURE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
MARTIN BAKER MB/EU/321/EE	. .	CLIP, parachute harness stowage	4	—	8/15
A25/5B	. .	Attaching parts for MB/EU/321/EE:— Bolt, 4BA, hex. head	4	—	8/16
AGS2001/B/1	. .	Nut, stiff, 4BA	4	—	8/17
EA3.10.2275	. .	Piece, packing	1	LFS21	8/18
EA3.10.2279	. .	Piece, packing (at 2 positions)	2	LFS21	8/19
EA3.10.6135	. .	Piece, packing (at 2 positions)	1	LFS21	8/20
SP15/B	. .	Washer, 4BA, plain	4	—	8/21
EA6.10.2683	. .	CURTAIN, window blackout	2	—	8/22
EA6.10.2589	. .	FAIRING, canopy	1	L72	8/23
EB7.10.5093	. .	FORK-END (Mod 5093)	1	S94	8/24
AGS2001/C/1	. .	Attaching parts for EB7.10.5093:— Nut, stiff, 2BA	1	—	8/25
SP15/C	. .	Washer, 2BA, plain	1	—	8/26
EA3.80.6659	. .	EYEBOLT (Mod 5093)	1	—	
EA3.10.6111	. .	HOLDER, spigot	1	L65	8/27
A25/4E	. .	Attaching parts for EA3.10.6111:— Bolt, 1/4" BSF hex. head	2	—	8/28
SP16/E	. .	Washer, 1/4" BSF plain	2	—	8/29
EA3.10.111	. .	PLATE, window securing	1	L72	8/30
AGS2001/C/1	. .	Attaching parts for EA3.10.111:— Nut, stiff, 2BA	48	—	8/31
EEAS1/1C	. .	Screw, 2BA, 120 deg csk. head	42	S96	8/32
EEAS1/2C	. .	Screw, 2BA, 120 deg csk. head	6	S96	8/33
SP15/C	. .	Washer, 2BA, plain	48	—	8/34
EA3.10.6275	. .	PLATE, window securing	1	L72	8/35
AGS2001/C/1	. .	Attaching parts for EA3.10.6275:— Nut, stiff, 2BA	48	—	8/36
EEAS1/1C	. .	Screw, 2BA, 120 deg csk. head	46	S96	8/37
EEAS1/2C	. .	Screw, 2BA, 120 deg csk. head	2	S96	8/38
SP15/C	. .	Washer, 2BA, plain	48	—	8/39
EA3.10.3765	. .	PLATE, blanking, periscope	1	L40	8/40
EA3.10.6121	. .	RING, packing	1	L72	8/41
EA3.10.6137	. .	RING, packing, 3/32" thick	1	Langite	8/42
EA3.10.6247	. .	RING, packing, 1/32" thick	1	Langite	8/43
EEAS1/1C	. .	SCREW, 2BA, 120 deg, csk. head, canopy fairing	10	S96	8/44
EEAS1/2E	. .	SCREW, 1/4" BSF, 120 deg, csk. head, canopy fairing	2	S96	8/45
EA3.10.309	. .	SEAL, rubber strip, 38" long (Make from Ref. 208)	2	—	8/46
EA3.10.311	. .	SEAL, rubber strip, 64" long (Make from Ref. 208)	1	—	8/47
EA3.10.313	. .	SEAL, rubber strip, 61" long (Make from Ref. 208)	1	—	8/48
EA3.80.1787	. .	STRIP, securing, window curtain	2	L72	8/49
AS1246/1B	. .	Attaching parts for EA3.80.1787:— Bolt, 4BA, round head	3	—	8/50
AGS2001/B/1	. .	Nut, stiff, 4BA	3	—	8/51
EA3.10.6099	. .	SPIGOT, screwed, 3/8" BSF	2	S96	8/52
EA3.10.305	. .	WINDOW, perspex, 0" .5 thick	2	DTD846	8/53
EA3.10.985	. .	Attaching parts for EA3.10.305:— Bush, rubber	20	Natural Rubber SH35/45	8/54
AGS2001/C/1	. .	Nut, stiff	20	—	8/55
EEAS1/6C	. .	Screw, 2BA, 120 deg, csk. head	20	S96	8/56
EA3.10.307	. .	Seat, rubber	2	Natural Rubber SH35/45	8/57
SP15/C	. .	Washer, 2BA, plain	20	—	8/58

FUSELAGE

FRONT FUSELAGE STRUCTURE

FRONT COLLIER STRUCTURE					
Part Number	Description	No. Off	Matl. Spec.	Plate No.	
	1 2 3 4 5 6				
R	—	.	HATCH, NAVIGATOR'S ASSEMBLY	—	—
R	EA3.00.5713	.	HATCH, NAVIGATOR'S	1	39/1
			(Spares for EA3.10.6301 modified to EA3.10.6461) (Alt R60/44) (Mod 5349)		
R	EA3.00.5793	.	KIT, LOOSE EQUIPMENT FOR NAVIGATOR'S HATCH (LOOSE EQUIPMENT KIT IS ESSENTIAL REQUIREMENT WITH HATCH) (Mod 5349) Comprising:—	1	—
R	TYPE B No. 1	.	BLOCK, terminal	1	39/2
R	EEAS1/1C	.	BOLT	10	39/3
R	AS1246/1B	.	BOLT	6	39/4
R	A25/1B	.	BOLT	3	39/5
R	EA3.10.6477	.	BOLT, special	68	39/6
R	EA3.81.5849	.	CABLE, assembly	1	39/7
R	AS3180/4B	.	CLIP 'P'	3	39/8
R	EA6.10.2683	.	CURTAIN	2	39/9
R	EA6.10.2589	.	FAIRING, canopy	1	39/10
R	EB7.10.5093	.	FORK-END	1	39/11
R	AGS2007C1	.	NUT, anchor	10	39/12
R	AGS2001C1	.	NUT, stiff	2	39/13
R	AGS2001B1	.	NUT, stiff	6	39/14
R	EA3.80.1787	.	PLATE	2	L72 x 20 SWG 39/15
R	AS2230-303	.	RIVET	20	39/16
R	ND	.	SCREW, hook	8	39/17
R	A33A20	.	SCREW	2	39/18
R	EEAS1/2E	.	SCREW	2	39/19
R	A33B6	.	SCREW	4	39/20
R	EA3.10.309	.	SEAL, rubber (Make from 26FZ/208-EEAS74)	2	39/21
R	EA3.10.311	.	SEAL, rubber (Make from 26FZ/208-EEAS74)	1	39/22
R	EA3.10.313	.	SEAL, rubber (Make from 26FZ/208-EEAS74)	1	39/23
R	SP15C	.	WASHER	2	39/24
R	SP15B	.	WASHER	3	39/25
R	ND	.	WIRE, 8" long	4	39/26
			(For installation details of the above refer to drawings EA3.10.6301 and EA3.10.6461)		

AP101B-0418-3A

Page HA7B

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	. HOOD, COUPE, ASSEMBLY TO FUSELAGE (EA3.10.3481) Spares for:—	—	—	9/1
EA3.10.2085	. . BOLT, special, explosive hood fixing	2	L40	9/2
EA3.10.2221	. . BOLT, special, explosive hood fixing	27	L40	9/3
EA1.10.1035	. . BUSH, coaming tube explosive bolt	31	L40	9/4
EA1.10.1167	. . BUSH, coaming tube explosive bolt entry	2	L40	9/5
EA1.10.1169	. . BUSH, coaming tube explosive bolt entry	30	L40	9/6
EA1.10.1435	. . BUSH, coaming tube explosive bolt	1	L40	9/7
EA3.00.509	. . HOOD, COUPE, C/W EDGE, MEMBER, GROUP (EA3.15.125) Spares for:—	1	—	9/8
EA3.10.3479	. . . BRACKET, hinge Attaching parts for EA3.10.3479:—	1	L40	9/9
AS1242/18C	. . . Bolt, 2BA, csk. head	2	—	9/10
AS1242/3E	. . . Bolt, 1/4" BSF, csk. head	2	—	9/11
A27/CT	. . . Nut, 2BA, thin	2	—	9/12
EA3.10.3061	. . . Shim	2	Lam. Alum.	9/13
EA3.10.3063	. . . Shim	2	Lam. Alum.	9/14
SP13/C	. . . Washer, 2BA, plain	2	—	9/15
EA3.10.3480	. . . BRACKET, hinge Attaching parts for EA3.10.3480:—	1	L40	9/16
AS1242/18C	. . . Bolt, 2BA, csk. head	2	—	9/17
AS1242/3E	. . . Bolt, 1/4" BSF, csk. head	2	—	9/18
A27/CT	. . . Nut, 2BA, thin	2	—	9/19
EA3.10.3061	. . . Shim	2	Lam. Alum.	9/20
EA3.10.3063	. . . Shim	2	Lam. Alum.	9/21
SP13/C	. . . Washer, 2BA, plain	2	—	9/22
EA6.10.2587	. . . FAIRING, canopy, forward section Attaching parts for EA6.10.2587:—	1	L72	9/23
AS1242/13C	. . . Bolt, 2BA, csk. head	6	—	9/24
EA6.10.2679	. . . STRIP, rubber (Make from 32C/537)	QR	Linatex	9/25
or EA2.10.661	. . . Strip, rubber	QR	Natural Rubber	9/26
EA3.15.115	. . . HOOD, ASSEMBLY Spares for:—	1	—	9/27
EA1.15.9	 BRACKET, fastener	1	L40	9/28
EA1.15.13	 BRACKET, hinge	1	L40	9/29
EA3.15.95	 BUSH, rubber, for attachment screws	148	Natural Rubber	9/30
R EA1.81.689/1	 CABLE, ASSEMBLY, N47A, HEATED WINDSCREEN TO COUPE BREAK, GROUP Consisting of:—	1	—	9/31
DUPREN 6 1252	 CABLE, dupren 6	QR	—	
—	 PLUG, 2 way, type R	1	—	
—	 SLEEVE, No. 1 x 3/4"	4	—	
—	 SLEEVE, No. 2 x 3/4"	2	—	

FUSELAGE
FRONT FUSELAGE STRUCTURE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R TYPE R No.3	.	.	.	.	.	SLEEVE, No.3 x 1"	1	—	
EA1.15.19	.	.	.	.	.	SOCKET, 2-way, type 2	1	—	
	.	.	.	.	.	EYE-BOLT, 2 BA	1	DTD126A	9/32
	.	.	.	.	.	Attaching parts for EA1.15.19:—			
A25/6C	.	.	.	.	.	Bolt, 2 BA hex. head	1	—	9/33
A27/CP	.	.	.	.	.	Nut, 2 BA plain	1	—	9/34
EA3.15.129	.	.	.	.	.	LANDING, door (D.V. window)	1	L72	9/35
	.	.	.	.	.	Attaching parts for EA3.15.129:—			
AS1242/13B	.	.	.	.	.	Bolt, 4 BA c'sk head	20	—	9/36
AS1242/14B	.	.	.	.	.	Bolt, 4 BA c'sk head	4	—	9/37
A27/ET	.	.	.	.	.	Nut, 4 BA thin	4	—	9/38
AGS2002/B/1	.	.	.	.	.	Nut, stiff, 4 BA	20	—	9/39
EA1.15.17	.	.	.	.	.	NUT, knurled, 2 BA	1	L40	9/40
EA3.15.107	.	.	.	.	.	RING, packing, perspex door landing	1	L40	9/41
EA3.15.133	.	.	.	.	.	RING, sealing, door landing	1	L72	9/42
EA3.15.87	.	.	.	.	.	SEALING, rubber, between edge member and hood, 1/16" x 1-1/4" x 216" long (Make from 32C/271)	1	Natural Rubber	9/43
EA3.15.135	.	.	.	.	.	SEAL, rubber, 1/32" thick, door landing, inboard	1	SH30	9/44
EA1.15.23	.	.	.	.	.	SPRING, 20 SWG	1	Spring Steel	9/45
EA3.15.131	.	.	.	.	.	WASHER, sealing, door landing, outboard	1	Rubber SH30/40	9/46
EA3.15.105	.	.	.	.	.	WINDOW, DIRECT VISION, GROUP (PRE MOD.4333) Consisting of:—	1	—	10/1
AS1242/13B	.	.	.	.	.	BOLT, 4 BA c'sk head	10	—	10/2
AS1242/14B	.	.	.	.	.	BOLT, 4 BA c'sk head	6	—	10/3
EA1.15.161	.	.	.	.	.	BRACKET, fastener	1	L40	10/4
EA1.15.163	.	.	.	.	.	BRACKET, hinge, c/w bushes	1	L65	10/5
A27/ET	.	.	.	.	.	NUT, 4 BA thin	16	—	10/6
EA1.15.173	.	.	.	.	.	PACKING, fastener bracket	1	Lam. Alum.	10/7
EA1.15.175	.	.	.	.	.	PACKING, hinge bracket	1	Lam. Alum.	10/8
EA3.15.69	.	.	.	.	.	PANEL, c/w elements	1	Glass	10/9
EA1.15.151	.	.	.	.	.	PLATE, 16 SWG	1	L73	10/10
EA3.15.127	.	.	.	.	.	RING, panel frame	1	LFS26	10/11
EA1.15.145	.	.	.	.	.	RING, rubber insulator	1	SH40	10/12
EA1.15.147	.	.	.	.	.	RING, rubber sealing	1	SH40	10/13
EA1.15.155	.	.	.	.	.	RING, rubber sealing	1	Rubber	10/14
EA1.15.157	.	.	.	.	.	RING, clamping	1	L72	10/15
EA3.15.111	.	.	.	.	.	TERMINAL	4	BSS249	10/16

FUSELAGE
FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.15.139	. . . WINDOW, DIRECT VISION, GROUP (MOD.4333) Spares for this group are identical to those for Part No.EA3.15.105 on page HA9, except for the following deletions and additions:— Delete:—	1	—	10/17
R EA3.15.69	 PANEL, c/w elements Add:—	1	Glass	10/9
R BOSTIC No.3	 ADHESIVE (SAS4746)	QR	DTD900-4418	10/35
R EA3.15.137	 PANEL, c/w elements	1	Glass	10/18
R AHO.18822/15	 RING, sealing (SAS4746)	1	—	10/36
EA3.10.2223	 MEMBER, edge, coupe hood Spares for:—	1	—	10/19
EEAS603/J	 NUT, anchor, floating, double lug	32	—	10/34
EA3.10.3451	 PLATE, attachment, port	1	L72	10/20
EA3.10.3453	 PLATE, attachment, starboard	1	L72	10/21
EA3.10.3455	 PLATE, attachment, rear	1	L72	10/22
EA3.10.3457	 PLATE, attachment, front	1	L72	10/23
EA3.10.2249	. . . SEAL, rubber, coaming tube to canopy, 1/8" x 1-1/4" (Make from 32C/519)	QR	Linatex	10/24
EA3.10.2251	. . . SEAL, rubber, coaming tube to canopy, 1/16" x 1-1/4" (Make from 32C/271)	QR	Linatex	10/25
EA3.10.2245	. . . TUBE, COAMING, COUPE, GROUP Spares for:—	1	—	10/26
EA3.16.5025	 BRACKET, eye-bolt, pilot's guide rail attachment	2	S96	10/27
EA1.10.1657	 CLIP, top half, air drier mounting	4	DTD124	10/28
EA1.10.1659	 CLIP, bottom half, air drier mounting	4	DTD124	10/29
EA1.10.1663	 NUT, knurled	8	L40	10/30
EA3.10.2773	 PLATE, blast	1	L72	10/31
EA1.10.847	 WASHER, saddle, pilot's seat, rear fixing	2	L40	10/32
EA1.10.849	 WASHER, saddle, pilot's seat, rear fixing	2	L40	10/33
EA3.10.17	. . . KEEL-UNIT, COMPLETE, ASSEMBLY	1	—	11/1
EA3.00.285	. . . KEEL-UNIT, ASSEMBLY (REPAIR) Spares for:—	1	—	11/2
EA3.11.655	. . . BOLT, special	4	—	11/3
EA3.10.885	. . . DOOR, probe access Attaching parts for EA3.10.885:—	1	—	11/4
AS1248/1C	. . . Bolt, 2 BA mushroom head	12	—	11/5

A.P.101B—0418—3A

Page HA10A

FUSELAGE
FRONT FUSELAGE STRUCTURE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
	—	SKINNING, PRESSURE CABIN KEEL UNIT ASSEMBLY (E.A3.10.11)						—	—	—	11/6
	—	Spares for:—						—	—	—	
R	—	DELETION OF K AERIAL (E.A3.10.6615) (Mod. 5223)						—	—	—	
	—	Spares for:—						—	—	—	
R	E.A3.10.6535	CLEAT						1	L.73 x 18 SWG	LM	
R	E.A3.10.6519	PANEL, skin, starboard						1	L.72 x 20 SWG	LM	
R	E.A3.10.6521	PANEL, skin, port						1	L.72 x 20 SWG	LM	
R	E.A3.10.6533	STRAP, butt, 10.5" approx.						1	L.73 x 18 SWG	LM	
R	E.A3.10.6527	STRINGER, port, outboard (Make from EEDX.68, Ref. 26/FZ/475, 19" long approx.)						1	EEDX.68	LM	
R	E.A3.10.6525	STRINGER, port, inboard (Make from EEDX.68, Ref. 26FZ/4475, 28" long approx.)						1	EEDX.68	LM	
R	E.A3.10.6523	STRINGER, centre (Make from EEDX.68, Ref. 26FZ/4475, 28" long approx.)						1	EEDX.68	LM	
R	E.A3.10.6531	STRINGER, starboard, outboard (Make from EEDX.68, Ref. 26FZ/4475 19" long, approx.)						1	EEDX.68	LM	
R	E.A3.10.6529	STRINGER, starboard, inboard (Make from EEDX.68, Ref. 26FZ/4475 28" long approx.)						1	EEDX.68	LM	
R	4378	E.A3.10.2373	PANEL, skin, starboard (Pre-Mod. 5223)					1	—	C	
R	4377	E.A3.10.2371	PANEL, skin, port (Pre-Mod. 5223)					1	—	C	
	4690	E.A1.10.829	PLUG, drain, assembly Consisting of:—					1	—	B	11/7
	4232	E.A1.10.827	HOUSING					1	L.40	C	11/8
	5084	ANGUS OR.12	RING, sealing					1	SH.60	C	11/10
	4231	E.A1.10.825	SCREW, special					1	L.4	C	11/11

FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index

AP.101B-0418-3A

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	STRUCTURE MAIN FLOOR PRESSURE CABIN KEEL—UNIT ASSEMBLY (EA3.10.9)	—	—	11/12
	Spares for:-			
EA3.10.2383	BOLT, special bracket mounting	4	S.96	11/13
EA1.10.217	BRACKET MOUNTING L.H. NOSEWHEEL	1	—	11/14
or	PIVOT SHAFT ASSEMBLY			
EA1.10.219				
	Spares for:-			
EA1.10.2685	CAP,	1	—	11/15
SP21	NIPPLE	1	—	11/16
EA1.10.217A	SPIGOT	1	S.94, S.95 or S.96	11/17
EA1.10.218	BRACKET, MOUNTING R.H. NOSEWHEEL	1	—	11/18
or	PIVOT SHAFT ASSEMBLY			
EA1.10.220				
	Spares for:-			
EA1.10.2685	CAP	1	—	11/19
SP21	NIPPLE	1	—	11/20
EA1.10.217A	SPIGOT	1	S.94, S.95 or S.96	11/21
EA1.10.231	BUSH	2	DTD217	11/22
—	BULKHEAD PRESSURE ASSEMBLY (EA3.10.37)	—	—	11/23
	Spares for:-			
EA9.10.5091	BRACKET FORWARD LATCH ASSEMBLY	1	—	11/24
	Spares for:-			
EA3.10.1739	BLOCK	1	—	11/25
	Attaching parts for EA3.10.1739:-			
A25/25E	Bolt, 1/4" BSF hex head	2	—	11/26
A27ET	Nut, 1/4" BSF thin	2	—	11/27
AS2811/6/135	Tube, distance	2	L.62	11/28
EA1.10.1429	PLATE	1	—	11/29
	Attaching parts for EA1.10.1429:-			
A45C16	Screw 2 BA c'sk head	2	—	11/30
EA9.10.5093	PLATE, side	1	—	11/31
EA9.10.5095	PLATE, side	1	—	11/32
EA1.10.1431	SHIM	1	—	11/33
NORMALAIR				
506713	CAP, blanking ground pressure test valve	1	—	11/34
NORMALAIR				
504600	CONNECTOR, ground pressurising	1	—	11/35
EA1.10.621	STRINGER, port (Pre-Mod 5223)	1	—	
EA1.10.619	STRINGER, port inboard (Pre-Mod 5223)	1	—	
EA1.10.617	STRINGER, centre (Pre-Mod 5223)	1	—	
EA1.10.622	STRINGER, starboard outboard (Pre-Mod 5223)	1	—	
EA1.10.620	STRINGER, starboard inboard (Pre-Mod 5223)	1	—	
EA3.10.2793	WASHER, special	4	L.40	11/36
EA3.10.2381	WINDOW, aerial (Pre-Mod 5223)	1	—	
—	MOUNTING FOR CONTROL PANEL TYPE15 ASSEMBLY (EG9.81.517)	—	—	12/1
	Spares for:-			
EG9.81.999	CHANNEL, assembly	1	EEDX320	12/2
	Attaching parts for EG9.81.999:-			
A25/1E	Bolt, 1/4" BSF hex head	2	—	12/3
SP15E	Washer, 1/4" BSF plain	2	—	12/4
EG9.81.1000	CHANNEL, assembly	1	EEDX320	12/5
	Attaching parts :-			
A25/1E	Bolt, 1/4" BSF hex head	2	—	12/6
SP15E	Washer, 1/4" BSF plain	2	—	12/7

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG9.10.121	. NOSE PERSPEX ASSEMBLY Spares for:—	1	—	12/8
EA2.10.659	. . BUSH, rubber nose fixing bolts (Make from 26FZ/4166)	64	Natural Rubber	12/9
EA2.10.1501	. . BUSH, rubber nose fixing bolts	34	Natural Rubber	12/10
EA2.10.653	. . RING, half retaining window inner seal	1	L.72	12/11
EA2.10.655	. . RING, half retaining window inner seal	1	L.72	12/12
EA2.10.1601	. . RING, half retaining window seal	1	L.72	12/13
EA2.10.1603	. . RING, half retaining window seal	1	L.72	12/14
EA2.10.685	. . RING, rubber inner seal	1	H.R.C.	12/15
EA2.10.1503	. . RING, rubber window seal	1	H.R.C.	12/16
EA2.10.665	. . STRAP joint assembly	4	—	12/17
EA2.10.657	. . STRIP sealing, 1/32" x 0.9" x 95"	1	Natural Rubber	12/18
EA2.10.661	. . STRIP, inner retaining ring seal 1/32" x 3/4" x 95"	1	Natural Rubber	12/19
EA2.10.687	. . WINDOW, observation	1	Triplex Glass	12/20
EA1.10.1131	. PIECE, distance	21	T.4	12/21
EA1.10.1133	. PIECE, distance	13	T.4	12/22
EA3.10.6411	. PIECE, distance	2	—	
EA3.10.6413	. PIECE, distance	21	—	
EA3.10.3007	. PLATE, nut for navigator's lamp mounting bracket (Pre-Mod.3423)	1	—	12/23
EA3.10.3821	. PLATE, nut for navigator's lamp mounting bracket (Mod.3423)	1	S.3 or S.82	12/24
EA3.10.3247	. PLATE, access door hinge and jettison mechanism inspection pressure sealing	1	—	7/28
EA2.10.707	. RAMP BOMB AIMER'S ASSEMBLY Spares for:—	1	—	12/25
EA2.10.709	. . SPIGOT, assembly Attaching parts for EA2.10.709:—	2	—	12/26
AS1246/1C	. . Bolt, 2 BA round head	4	—	12/27
EA3.10.6477	. SCREW, special (Alt R60/44 (Mod.5102))	68	—	13/1
EA3.10.549	. SEAL, pressure navigator's escape hatch	1	BTR8853	13/2
EA1.10.1171	. SEAL, door pressure cabin entrance	1	BTR8853	
EA3.10.651	. SHIM, escape hatch steady arm	76	L.72	13/3
EA3.10.2549	. SHIM, escape hatch steady arm	8	—	13/4
—	. SKINNING STRUCTURE PRESSURE BULKHEAD TO FRAME 12 ASSEMBLY (EA3.10.13) Spares for:—	—	—	
EA1.10.187	. . DOOR ACCESS V.H.F. MAIN ELECTRICAL PANEL AND GROUND FLIGHT SWITCH GROUP (Supplied to Part No. EA3.00.151 for spares purposes) Spares for:—	2	—	13/5
AS2850P	. . . LOCK, L.H. FLUSH TYPE ASSEMBLY Spares for:—	1	—	13/6
AS2552	 HANDLE	1	—	13/7
FGS50	 KEY	1	—	
or FFE4	 KEY Attaching parts for AS2850P:—			
AS1248/1/2B	. . . Bolt, 4 BA mushroom head	4	—	13/8
A33B20	. . . Screw, 4 BA c'sk head	11	—	13/9

FRONT FUSELAGE STRUCTURE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EA1.10.1919	.	.	.	.	SEAL, section (Make from EEAS141/1, Ref. 12713)		1	—	13/10
EA1.10.1815	.	.	.	.	STAY, door		1	—	13/11
EA3.10.2805	.	.	.	.	STOWAGE, DOOR SUPPORT STRUT, ASSEMBLY		1	—	13/12
	.	.	.	.	Spares for:—				
EA3.10.2809	.	.	.	.	PLATE, stiffening		1	L.73	13/13
EA3.10.2807	.	.	.	.	STRAP		1	—	13/14
EEAS27/27/DU	.	.	.	.	WASHER, for door stay attachment		1	S.515	13/15
EA1.10.1033	.	.	.	.	PLUG, forward jacking point housing		1	L.40	13/16
EEAS1/3C	.	.	.	.	SCREW, 2 BA 120 deg. c'sk head		24	S.96	13/17
—	.	.	.	.	STRUCTURE, PRESSURE BULKHEAD TO FRAME 12, ASSEMBLY (EA3.10.15)		—	—	
	.	.	.	.	Spares for:—				
EA3.10.6375	.	.	.	.	CLEAT, nose undercarriage hook return spring (Mod.4449)		1	L.72	
—	.	.	.	.	FRAME 12A, JOINT, FORWARD PORTION, ASSEMBLY (EA1.10.55)		—	—	14/1
	.	.	.	.	Spares for:—				
EA3.71.389	.	.	.	.	BEAM, oxygen bottle mounting		2	—	14/2
EA1.10.909	.	.	.	.	BRACKET, door lock, starboard (Supplied to Part No.EA3.00.596 for spares purposes)		1	—	14/3
EA1.10.1621	.	.	.	.	BRACKET, door lock, port		1	L.72	14/4
EA6.10.775	.	.	.	.	BRACKET, oxygen cylinder cradle		2	L.72	14/5
EA3.71.403	.	.	.	.	BRACKET, oxygen mounting beam		7	L.72	14/6
EA1.10.557	.	.	.	.	BRACKET, strut pick-up		1	L.72	14/7
EA3.10.6571	.	.	.	.	BRACKET (Note: Still used on A/C with front fuselage married up)		1	—	
EA1.10.1179	.	.	.	.	BRACKET (Note: Used on A/C with front fuselage de-married)		1	—	
EA3.10.2447	.	.	.	.	GUARD, assembly Attaching parts for EA3.10.2447:—		1	L.72	14/8
A32/C16	.	.	.	.	Screw, 2 BA round head		4	—	14/9
EA3.10.3353	.	.	.	.	GUARD, lock lever, assembly Attaching parts for EA3.10.3353:—		1	L.72	14/10
A32/C16	.	.	.	.	Screw, 2 BA round head		4	—	14/11
—	.	.	.	.	INSTALLATION OF ATTACHMENT LUG BOLTS (EA3.10.6573) (Alt. R60/301—Mod.5102)		—	—	
	.	.	.	.	Spares for:—				
EA1.10.1177	.	.	.	.	PLATE, tie (Pre-Alt. R60/301—Mod.5102)		1	—	
EA3.10.6575	.	.	.	.	PLATE, tie (Alt. R60/301—Mod.5102)		1	—	
EA3.10.2455	.	.	.	.	PLATE, reinforcing (Pre-Alt. R60/301—Mod.5102)		1	—	
EA3.10.6577	.	.	.	.	PLATE, reinforcing (Alt. R60/301—Mod.5102)		1	—	
EA6.10.1815	.	.	.	.	PLATE, reinforcing (Pre-Alt. R60/301—Mod.5102)		1	—	
EA3.10.6579	.	.	.	.	PLATE, nut (Alt. R60/301—Mod.5102) Attaching parts:—		1	—	
AS1242/2C	.	.	.	.	Bolt, c'sk, 2 BA		3	—	
AGS2019/C1	.	.	.	.	Nut, anchor		3	—	

FUSELAGE

FRONT FUSELAGE STRUCTURE

	Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
R	EK5.10.803		LEVER, LOCK, ASSEMBLY (Alt. R60/15— Mod.5102) Consisting of:—	1	—	14/12
R	EK5.10.807		BRACKET (Alt. R60/15—Mod.5102)	1	—	14/13
	EA3.10.3159		LEVER, ASSEMBLY Attaching parts for EA3.10.3159:—	1	—	14/14
	EA3.10.3219		Bolt, shoulder, 5/16" BSF	1	S.96	14/15
	A27/GS		Nut, 5/16" BSF slotted	1	—	14/16
	SP90/C7		Pin, split	1	—	14/17
	SP15/G		Washer, 5/16" BSF plain	1	—	14/18
	EA1.10.1407		Washer, spacing	1	—	14/19
R	EK5.10.805		LEVER, LOCK ASSEMBLY (Alt. R60/15—Mod.5102) Consisting of:—	1	—	14/20
R	EK5.10.808		BRACKET (Alt. R60/15—Mod.5102)	1	—	14/21
	EA3.10.3335		LEVER, assembly Attaching parts for EA3.10.3335:—	1	—	14/22
	EA3.10.3219		Bolt, shoulder, 5/16" BSF	1	S.96	14/23
	A27/GS		Nut, 5/16" BSF slotted	1	—	14/24
	SP90/C7		Pin, split	1	—	14/25
	SP15/G		Washer, 5/16" BSF plain	1	—	14/26
	EA1.10.1407		Washer, spacing	1	—	14/27

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

FUSELAGE
FRONT FUSELAGE STRUCTURE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
—		STIFFENER, VERTICAL, CENTRE, PORT, ASSEMBLY (EA9.10.4545) (Mod 1740) Spares for:—	—	—	15/11
EA3.10.3197		CHANNEL	1	—	15/12
EA9.10.4439		PLATE, reinforcing (Mod 1740)	1	—	15/13
—		STIFFENER, VERTICAL, CENTRE, STARBOARD, ASSEMBLY (EA3.10.3206) Spares for:—	—	—	15/14
ASD292.RS/1		ANGLE, inner joint (Repair) (Make from EEJ270, Ref. 7109)	1	L72	15/15
EA3.10.3199		CHANNEL	1	—	15/16
ASD292.RS/5S		INSERTION, channel, starboard (Repair) (Make from EA3.10.3199, Ref. 22326)	1	—	15/17
ASD292.RS/6S		INSERTION, plate, reinforcing (Repair) (Make from EA3.10.3203, Ref. 22328 or 30B/9611240)	1	L73	15/18
EA3.10.3203		PLATE, reinforcing	1	L73	15/19
ASD292.RS/4S		STRAP, joint, forward, outer, starboard (Repair) (Pre Mod 856)	1	—	15/20

AP101B-0418-3A

FUSELAGE

Page HA15

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
ASD292RS/4S	 STRAP, joint, forward, outer, starboard (Repair) (Mod.856 A/C)	1	—	15/21
ASD292RS/3	 STRAP, joint, forward, leveller, 14 SWG (Repair) (Make from 30B/9611242)	1	L.73	15/22
ASD292RS/2	 STRAP, joint, aft, 14 SWG (Repair)	1	S.514	15/23
EA3.10.3223	. . . STRUT, bracing, assembly Attaching parts for EA3.10.3223:—	2	—	14/28
A25/6E	. . . Bolt, 1/4" BSF hex. head	2	—	14/29
A27/EP	. . . Nut, 1/4" BSF plain	2	—	14/30
SP15/E	. . . Washer, 1/4" BSF plain	1	—	14/31
SP16/E	. . . Washer, 1/4" BSF plain	1	—	14/32
EA1.10.1345	. SOCKET, front frame entrance door bolt Attaching parts for EA1.10.1345:—	1	L.40	17/1
AS1242/4C	. Bolt, 2 BA c'sk head	2	—	17/2
AS1242/5C	. Bolt, 2 BA c'sk head	2	—	17/3
AGS2001/C/1	. Nut, stiff, 2 BA	4	—	17/4
EA1.10.1347	. SOCKET, rear frame entrance door bolt Attaching parts for EA1.10.1347:—	1	L.40	17/5
AS1242/4C	. Bolt, 2 BA c'sk head	2	—	17/2
AS1242/5C	. Bolt, 2 BA c'sk head	2	—	17/3
AGS2001/C/1	. Nut, stiff, 2 BA	4	—	17/4
S4/250	. SPRING, "dzus", hydraulic reservoir access door	6	—	5/57
EA3.10.3255	. STRAP, main door jettison handle stowage	1	—	7/30
—	. STRUCTURE, NOSE, FORWARD OF FRAME 1, ASSEMBLY (EG9.10.103) (EA3.10.6507) Spares for:—	—	—	16/1
EB6.10.295	. . BRACKET, spigot Attaching parts for EB6.10.295:—	2	S.1 or S.91	16/2
AS1242/12B	. . Bolt, 4 BA c'sk head	4	—	16/3
AGS2001/B/1	. . Nut, stiff, 4 BA	4	—	16/4
SP13/B	. . Washer, 4 BA plain	4	—	16/5
EA3.10.1583	. . PANEL, access to air drier tube Attaching parts for EA3.10.1583:—	1	L.72	16/6
A25/1C	. . Bolt, 2 BA hex. head	2	—	16/7
AS1248/ 1/2C	. . Bolt, 2 BA mushroom head	4	—	16/8
SP15/C	. . Washer, 2 BA plain	2	—	16/9
EG9.10.119	. . PANEL, access Attaching parts for EG9.10.119:—	1	L.72	16/10
AS1248/1B	. . Bolt, 4 BA mushroom head	10	—	16/11
EA1.10.829	. . PLUG, drain assembly Spares for:—	1	—	
EA1.10.827	. . . HOUSING	1	L.40	
ANGUS				
O.R.12	. . . RING, "O" sealing	1	—	
EA1.10.825	. . . SCREW, special	1	L.40	

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
R EA2.10.471	. . WINDOW, bomb aimer's Attaching parts for EA2.10.471:—	1	—	16/12
AS1242/12C	. . Bolt, 2 BA c'sk head	20	—	16/13
EA3.10.983	. . Bush, rubber (May be made from 32C/4656883)	20	—	16/14
EA2.10.477	. . Frame, seal retaining	1	—	16/15
AGS2001/C/3	. . Nut, stiff, 2 BA	20	—	16/16
EA2.10.473	. . Seal, rubber, outer	1	Natural Rubber	16/17
EA2.10.475	. . Seal, rubber, inner	1	Natural Rubber	16/18
—	. STRUCTURE, IN PRESSURE CABIN (EA3.10.7)	—	—	
EA3.10.279	. . FRAME, 7A, port assembly (Alt. R60/88)	1	—	
EA3.10.281	. . FRAME, 8A, port assembly (Alt. R60/88)	1	—	
EA3.10.282	. . FRAME, 8A, stbd. assembly (Alt. R60/88)	1	—	
EA3.10.283	. . FRAME, 9A, port assembly (Alt. R60/88)	1	—	
EA3.10.284	. . FRAME, 9A, stbd. assembly (Alt. R60/88)	1	—	
EA3.10.1813	. . HINGE, casting assembly (Mod.5028)	1	—	
EA3.10.1815	. . HINGE, casting assembly (Mod.5028)	1	—	
EEAS20/3/DR	. TAB, locking	2	L.72	4/34
EA1.20.1033	. WASHER, special	16	Lam. Alum.	4/35
EA3.10.3023	. WASHER, sealing, escape hatch pivot	2	Natural Rubber	4/36
—	. WINDOW, PASSENGER'S, INSTALLATION (EG9.10.55) Spares for:—	—	—	17/6
† EA3.10.361	. . CEMENT, boscoprene 2100 . . WINDOW, passenger's, c/w valve Attaching parts for EA3.10.361:—	QR 1	—	17/7
AS1242/14C	. . Bolt, 2 BA c'sk head	16	—	17/8
EA3.10.983	. . Bush, rubber (May be made from 32C/4656883)	16	Natural Rubber	17/9
AGS2001/C/1	. . Nut, stiff, 2 BA	16	—	17/10
EA3.10.153	. . Seal, rubber	1	Natural Rubber	17/11
EA3.10.155	. . Seal, rubber	1	Natural Rubber	17/12
EA3.10.151	. . Strip, seal retaining	1	L.72	17/13
EA3.10.361	. WINDOW, navigator's, c/w valve (Mod.5032) Spares for:—	1	—	17/7
EA3.76.5055	. . ELBOW	1	—	
A27/GT	. . NUT, thin, hex.	1	—	
SP124/G	. . WASHER	1	—	
AS8596	. . WASHER	2	—	
AS1242/12C	. . Bolt, 2 BA c'sk head	16	—	17/14
EA3.10.983	. Bush, rubber (May be made from 32C/4656883)	16	Natural Rubber	17/9
AGS2001/C/1	. Nut, stiff, 2 BA	16	—	17/10
EA3.10/153	. Seal, rubber	1	Natural Rubber	17/11
EA3.10.155	. Seal, rubber	1	Natural Rubber	17/12
EA3.10.151	. Strip, seal retaining	1	L.72	17/13

A.P.101B-0413-3A

Page HB1

FUSELAGE
CENTRE FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	CENTRE FUSELAGE, ASSEMBLY (E.G9.00.7)							—	—	—	
	E.G9.75.57	Spares for:— AIR VENTILATED SUIT SYSTEM (See page N1)							—	—	—	
	E.G7.75.5	CABIN PRESSURE SYSTEM (See page NC1)							—	—	—	
	—	CABIN PRESSURE SYSTEM, ALTERATIONS (E.G9.75.123)							—	—	—	18/1
	—	Spares for:—							—	—	—	
28E/9130219	AGS.605/4 or	CLIP, hose (Pre-Alt. R60/91—Mod. 5102)							14	—	C	18/2
R 28E/4710971 6812	SP.91/N	CLIP, hose (Alt. R60/91—Mod. 5102)							14	—	C	18/2
	EEAS.66/14	RING, clamping							14	L.72	C	18/3
	—	CAMERA STRUCTURE INSTALLATION (E.G9.83.1)							—	—	—	18/4
	—	Spares for:—							—	—	—	
	E.A1.83.77	MOUNTING, camera, assembly							1	—	—	18/5
	—	Attaching parts for E.A1.83.77:—							—	—	—	
28D/1011029	A25/1E	Bolt, 1/4" BSF hex. head							2	—	C	18/6
28D/1008151	A25/4E	Bolt, 1/4" BSF hex. head							2	—	C	18/7
28M/9480017	AGS.2001/E/1	Nut, stiff, 1/4" BSF							4	—	C	18/8
3616	E.A1.83.97	RAIL, camera							2	T.4	C	18/9
	—	Attaching parts for E.A1.83.97:—							—	—	—	
28FP/9432062	A.413	Pin, 'pip'							2	—	C	18/10
28W/9419405	SP.15/E	Washer, 1/4" BSF plain							2	—	C	18/11
	E.A1.47.125	CONTROLS, ENGINE (See page DB1)							—	—	—	
	E.A3.45.379	CONTROLS, FLYING (See page DJ1)							—	—	—	
	E.G9.81.7	ELECTRICAL EQUIPMENT (See page E1)							—	—	—	
	E.A1.60.1	FIRE PROTECTION SYSTEM (See page NK1)							—	—	—	
	E.A1.57.729	FUEL SYSTEM (PRE-MOD. 648) (See page NL1)							—	—	—	
	E.A3.57.67	FUEL SYSTEM (MOD. 648) (See page NL15)							—	—	—	
	—	GEAR, EMERGENCY RELEASE, BOMB DOOR AND UNDERCARRIAGE, ASSEMBLY (E.A1.45.923)							—	—	—	19/1
	—	Spares for:—							—	—	—	
7809	E.A3.45.281	CABLE, AFT CONTROL, EMERGENCY RELEASE GEAR, UNDERCARRIAGE, GROUP							1	—	B	19/2
	—	Consisting of:—							—	—	—	
28U/4063	SP.8/Y/13	ROLLER							2	—	C	19/3
	E.A1.45.905	TUBE, 5/16" o/d x 20 SWG (Make from 30B/1786)							1	T.4	LM	19/4
28X/3495	W9/4P	WIRE, rope, 5 cwt.							QR	—	C	19/5

FUSELAGE
CENTRE FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
7810	E.A3.45.283	CABLE, AFT CONTROL, EMERGENCY RELEASE GEAR, BOMB DOOR, GROUP Consisting of:—							1	—	B	19/6
R 28U/4063 28X/3495 7808	E.A1.45.1129	ROLLER, special							1	S.1	—	19/7
	SP.8/Y/13	ROLLER							1	—	C	19/8
	W9/4P	WIRE, rope, 5 cwt.							QR	—	C	19/9
	E.A1.45.1211	CLEAT, angle, fairlead support, frame 13							2	L.72	C	19/10
28D/1200149	A25/4C	Attaching parts for E.A1.45.1211:—							1	—	C	19/11
28M/9433473	AGS.2002/C/1	Bolt, 2 BA hex. head							1	—	C	19/12
28W/9419475	SP.15/C	Nut, stiff, 2 BA							1	—	C	19/13
		Washer, 2 BA plain										
28N/1045681	AGS.899/1	COLLAR, shackle pin							2	—	C	19/14
7811	E.A3.45.245	FAIRLEAD, bomb door release cable, floor girder 15, starboard							1	LFS.21	C	19/15
		Attaching parts for E.A3.45.245:—										
28D/1214299	AS.1242/5B	Bolt, 4 BA c'sk head							2	—	C	19/16
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA							2	—	C	19/17
28W/9419474	SP.15/B	Washer, 4 BA plain							2	—	C	19/18
7804	E.A1.45.879	FAIRLEAD, undercarriage release cable, floor girder 15, port							1	LFS.21	C	19/19
		Attaching parts for E.A1.45.879:—										
28D/9133013	A25/5C	Bolt, 2 BA hex. head							2	—	C	19/20
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							2	—	C	19/21
7805	E.A1.45.1123	FAIRLEAD, bomb door and undercarriage release cable, frame 13							1	LFS.21	C	19/22
		Attaching parts for E.A1.45.1123:—										
28D/1011006	A25/5B	Bolt, 4 BA hex. head							2	—	C	19/23
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA							2	—	C	19/24
28W/9419474	SP.15/B	Washer, 4 BA plain							2	—	C	19/25
28K/4070321	SP.3/412	JOINT, fork, 4 BA, R.H., undercarriage cable							1	—	C	19/26
28K/4070322	SP.3/412L	JOINT, fork, 4 BA, L.H., undercarriage cable							1	—	C	19/27
28K/4070323	SP.3/413	JOINT, fork, 2 BA, R.H., bomb door cable							1	—	C	19/28
28K/4070324	SP.3/413L	JOINT, fork, 2 BA, L.H., bomb door cable							1	—	C	19/29
28M/1006504	A27/BT	NUT, 4 BA, thin, undercarriage cable tension rod locking							1	—	C	19/30
28M/13141	A27/BTL	NUT, 4 BA, thin, L.H., undercarriage cable tension rod locking							1	—	C	19/31
28M/1006473	A27/CT	NUT, 2 BA, thin, bomb door cable tension rod locking							1	—	C	19/32
28M/13253	A27/CTL	NUT, 2 BA, thin, L.H., bomb door cable tension rod locking							1	—	—	19/33
28P/7002435	SP.4Y/A3	PIN, shackle, undercarriage release cable							2	—	C	19/34
28P/814	SP.4Y/A4	PIN, shackle, undercarriage and bomb door cables to rotary valve lever							2	—	C	19/35
28P/1207864	SP.4Y/B4	PIN, shackle, bomb door release cable							2	—	C	19/36
28P/1202557	SP.90/A5	PIN, split							6	—	C	19/37

AP101B-0418-3A

FUSELAGE

Page HB3

CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
—	. . . PULLEYS, ON FLOOR GIRDER 14, FOR BOMB DOOR AND UNDERCARRIAGE CABLES, ASSEMBLY (EA1.45.859) Spares for:—	—	—	20/1
EA1.45.839	. . . BRACKET, pulley	1	—	20/2
EA1.45.841	. . . BRACKET, pulley, upper Attaching parts for EA1.45.841:—	1	L.72	20/3
A25/1C	. . . Bolt, 2 BA hex. head	3	—	20/4
AGS2001/C/1	. . . Nut, stiff, 2 BA	3	—	20/5
SP15/C	. . . Washer, 2 BA plain	3	—	20/6
EA1.45.843	. . . BRACKET, pulley, lower Attaching parts for EA1.45.843:—	1	L.72	20/7
A25/1C	. . . Bolt, 2 BA hex. head	3	—	20/8
AGS2001/C/1	. . . Nut, stiff, 2 BA	3	—	20/9
SP15/C	. . . Washer, 2 BA plain	3	—	20/10
EA1.45.1005	. . . BRACKET, pulley	1	—	20/11
EA1.45.863	. . . FAIRLEAD Attaching parts for EA1.45.863:—	1	LFS.21	20/12
A25/9C	. . . Bolt, 2 BA hex. head	2	—	20/13
AGS2001/C/1	. . . Nut, stiff, 2 BA	2	—	20/14
AS1151	. . . PULLEY, shrouded Attaching parts for AS1151:—	4	—	20/15
A25/12E	. . . Bolt, 1/4" BSF hex. head (1 position)	1	—	20/16
A25/13E	. . . Bolt, 1/4" BSF hex. head (2 positions)	1	—	20/17
A25/17E	. . . Bolt, 1/4" BSF hex. head (1 position)	1	—	20/18
AGS2001/E/1	. . . Nut, stiff, 1/4" BSF	1	—	20/19
EA1.45.835	. . . Packing (2 positions)	1	Tufnol	20/20
EA1.45.845	. . . Washer, wedge (1 position)	1	L.40	20/21
EA1.45.1015	. . . Washer, wedge (1 position)	1	L.40	20/22
EA1.45.1311	. . . Washer, special (1 position)	1	Lam. Alum.	20/23
EEAS28/53/HR	. . . Washer (1 position)	1	—	20/24
SP15/E	. . . Washer, 1/4" BSF plain (2 positions)	1	—	20/25
SP16/E	. . . Washer, 1/4" BSF plain (2 positions)	1	—	20/26
AS108	. . . PULLEY, shrouded	2	—	20/27
or AS1152	. . . PULLEY, shrouded (Alternative to AS108) Attaching parts for AS108 or AS1152:—	—	—	
A25/11E	. . . Bolt, 1/4" BSF hex. head (1 position)	1	—	20/28
A25/20E	. . . Bolt, 1/4" BSF hex. head (1 position)	1	—	20/29
AGS2001/E/1	. . . Nut, stiff, 1/4" BSF	1	—	20/30
EA1.45.837	. . . Packing	1	Tufnol	20/31
SP15/E	. . . Washer, 1/4" BSF plain	1	—	20/32
EA1.45.1127	. . . RETAINER, cable Attaching parts for EA1.45.1127:—	2	—	19/39
AGS2002/B/1	. . . Nut, stiff, 4 BA	1	—	19/40
A31/B12	. . . Screw, 4 BA cheese head	1	—	19/41
SP8/Y/1	. . . ROD, tension, undercarriage cable	1	—	19/42
SP8/Y/2	. . . ROD, tension, bomb door cable	1	—	19/43
AGS4561/2	. . . TAB, locking (Refer to SEM041 for installation) (SAS4746)	2	—	
5E/5253563	. . . WIRE, copper enamelled (Refer to SEM041 for installation) (SAS4746)	QR	—	

FUSELAGE
CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EG9.73.121	. HYDRAULIC, EQUIPMENT (See page NU1)	—	—	
—	. PANEL, INVERTER CONTROL, AND ARMAMENT SAFETY BREAK, FRAME 12 AND 13, ASSEMBLY (EG9.81.47) Spares for:—	—	—	21/1
EG7.81.3217	. . PANEL, ACCESS, ASSEMBLY Spares for:—	1	—	21/2
A4/35	. . . FASTENER, "dzus"	8	—	21/3
GA4/250	. . . GROMMET, "dzus"	8	—	21/4
EB6.81.5259	. . . LANYARD, assembly	1	—	21/5
EG7.81.365	. . PLUG, SHORTING, ASSEMBLY Consisting of:—	1	—	21/6
EF3.81.11881	. . . CAP, protective	1	L.59	21/7
—	. . . CONNECTIONS, SHORTING PLUG, ASSEMBLY (EG7.81.387) Consisting of:—	—	—	21/8
R UNTERSIL 16	 CABLE, untersil 16	QR	—	21/9
508/2/04368	 FILLER, plug	1	—	21/10
508/2/04548/001	 PIN, plug, 12/16	9	—	21/11
22139627	 SLEEVE, sealing, red	8	—	21/12
EG7.81.451	. . . LANYARD, ASSEMBLY Consisting of:—	1	—	21/13
A.M.P.34318	 CONNECTOR, parallel	2	—	21/14
AGS796/B	 EYE-BOLT, 4 BA	1	—	21/15
R 26DK/2381	 LINE, nylon, 66-3/32" dia. x 14" long	QR	—	21/16
EB6.81.4027	 PENNANT, "ARMAMENT SAFETY BREAK", ASSEMBLY Consisting of:—	1	—	21/17
EB6.81.4029	 PENNANT	1	Cotton	21/18
EB6.81.4049	 POUCH, assembly	1	Cotton	21/19
EF3.81.11889	 RING, lanyard attachment	1	DTD.189	21/20
EEAS146/20	 SLEEVE, 1-1/2" long	1	—	21/21
EF3.81.13155	. . . NUT, outlet, modified	1	—	21/22
690(ET)16-9P	. . . PLUG, free, 9-way, Mk.6	1	—	21/23
S4/200	. . SPRING, "dzus"	8	—	21/24
EEAS15/71/100GR	. . STRIP, packing, mounting tray anchor nut	4	L.72	22/24
EA9.81.3661	. . TRAY, MOUNTING, INVERTER CONTROL PANEL, ASSEMBLY Spares for:—	1	—	22/1
EA9.81.3675	. . . BRACKET, catch securing	2	L.72	22/2

AP101B-0418-3A

FUSELAGE

CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA9.81.3677	. . . CATCH, control panel Attaching parts for EA9.81.3677:—	2	L72	22/3
EA9.81.3671	. . . Circlip	1	DTD215	22/4
EA9.81.3673	. . . Nut, special, 1/4" BSF	1	S1	22/5
EA9.81.3667	. . . Screw, knurled	1	S92	22/6
SP13/E	. . . Washer, 1/4" BSF plain	1	—	22/7
SP13/A	. . . Washer, 6BA plain	1	—	22/8
AGS163/D	. . . Washer, double spring	1	—	22/9
EA9.81.3669	. . . DOWEL, locating Attaching parts for EA9.81.3669:—	2	L64	22/10
AGS2002/C/1	. . . Nut, stiff, 2BA	1	—	22/11
TYPE 967	. . . MOUNT, anti-vibration, 4 lb Attaching parts for Type 967:—	2	—	22/12
AGS2001/C/1	. . . Nut, stiff, 2BA	4	—	22/13
A31/C20	. . . Screw, 2BA cheese head	4	—	22/14
SP13/C	. . . Washer, 2BA plain	4	—	22/15
TYPE 968	. . . MOUNT, anti-vibration, 6 lb Attaching parts for Type 968:—	2	—	22/16
AGS2001/C/1	. . . Nut, stiff, 2BA	4	—	22/17
A31/C20	. . . Screw, 2BA cheese head	4	—	22/18
SP13/C	. . . Washer, 2BA plain	4	—	22/19
EA9.81.3683	. . . PILLAR Attaching parts for EA9.81.3683:—	2	L64	22/20
AGS2001/B/1	. . . Nut, stiff, 4BA Attaching parts for EA9.81.3661:—	1	—	22/21
A25/10E	. . . Bolt, 1/4" BSF hex head	4	—	22/22
WT33047	. . . Washer, check	8	—	22/23
EA3.57.5043	. PIPE, FUEL TRANSFER AND VENT, AUXILIARY FUEL TANK, ASSEMBLY (MOD 3757) (See page NL19)	—	—	
EA3.80.657	. PITOT AND STATIC PIPES (See page NAB1)	—	—	
EG9.11.1	. STRUCTURE, CENTRE FUSELAGE (See page HC1)	—	—	
EG9.56.1	. TANK, 300 GALLON, FORWARD INSTALLATION (MOD 4473) (See page QB1)	—	—	

R



A.P.101B-0418-3A

FUSELAGE
CENTRE FUSELAGE STRUCTURE

Page HC1

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
	—	STRUCTURE, CENTRE FUSELAGE, ASSEMBLY (E.G9.11.1) Spares for:—						—	—	—	
	13091 E.A3.11.655	BOLT, special (Make from A25/4E)						10	—	C	26/1
	7275 E.A3.11.677	BOLT, special (Make from A25/4C)						10	—	C	26/2
R	1438951 E.A1.11.1603	BOLT, special attachment, bulkhead to floor girder at frame 17						2	S.11	C	26/3
R	1438952 E.A1.11.1605	BOLT, special attachment, bulkhead to floor girder at frame 17						5	S.11	C	26/4
	41 E.A1.11.163	BULKHEAD, rear fuel tank (Pre-Mod. 55)						1	—	A	26/5
	3503 E.A3.11.15	BULKHEAD, rear fuel tank (Mod. 55)						1	—	A	26/6
	42 E.A1.11.313	BULKHEAD, fuel tank, at frame 17 (Pre-Mod. 55)						1	—	A	26/7
	4773 E.A1.11.3551	BULKHEAD, fuel tank, at frame 17 (Mod. 55)						1	—	A	26/8
	28N/9513425 AGS.899/12	COLLAR, shackle pin, hydraulic jack pick-up bracket connecting pin, forward						1	—	C	28/1
	28N/4043777 AGS.899/18	COLLAR, shackle pin, hydraulic jack pick-up bracket connecting pin, aft						1	—	C	28/2
	1438748 E.G9.11.3	DOOR, BOMB, PORT, ASSEMBLY Spares for:—						1	—	B	23/1
	11491 E.A1.11.823	BRACKET, DOOR, ROLLER GUIDE, FRAME 15, ASSEMBLY Spares for:—						1	L.40	B	23/2
	237 E.A1.11.837	ROLLER Attaching parts for E.A1.11.837:—						1	L.40	C	23/3
	236 E.A1.11.1615	Bolt, special, c/w lubricating nipple						1	—	C	23/4
	28M/1011470 A27/GT	Nut, 5/16" BSF thin						1	—	C	23/5
	11588 E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 20 SWG						1	T.45	C	23/6
	28W/9419476 SP.15/G	Washer, 5/16" BSF plain						1	—	C	23/7
	15825 E.A1.11.1573	Attaching parts for E.A1.11.823:—						2	S.96	C	23/8
	28D/1011240 A25/5E	Bolt, special, 1/4" BSF Bolt, 1/4" BSF hex. head						2	—	C	23/9
	11492 E.A1.11.825	BRACKET, DOOR, ROLLER GUIDE, FRAME 17, ASSEMBLY Spares for:—						1	L.40	B	23/10
	237 E.A1.11.837	ROLLER Attaching parts for E.A1.11.837:—						1	L.40	C	23/3
	236 E.A1.11.1615	Bolt, special, c/w lubricating nipple						1	—	C	23/4
	28M/1011470 A27/GT	Nut, 5/16" BSF thin						1	—	C	23/5
	11588 E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/6
	28W/9419476 SP.15/G	Washer, 5/16" BSF plain						1	—	C	23/7
	15825 E.A1.11.1573	Attaching parts for E.A1.11.825:—						2	S.96	C	23/8
	28D/1011240 A25/5E	Bolt, special, 1/4" BSF Bolt, 1/4" BSF hex. head						2	—	C	23/9
	11493 E.A1.11.827	BRACKET, DOOR, ROLLER GUIDE, FRAME 19, ASSEMBLY Spares for:—						1	L.40	B	23/11
	237 E.A1.11.837	ROLLER Attaching parts for E.A1.11.837:—						1	L.40	C	23/3
	236 E.A1.11.1615	Bolt, special, c/w lubricating nipple						1	—	C	23/4
	28M/1011470 A27/GT	Nut, 5/16" BSF thin						1	—	C	23/5
	11588 E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/6
	28W/9419476 SP.15/G	Washer, 5/16" BSF plain						1	—	C	23/7
	15825 E.A1.11.1573	Attaching parts for E.A1.11.827:—						2	S.96	C	23/8
	28D/1011240 A25/5E	Bolt, special, 1/4" BSF Bolt, 1/4" BSF hex. head						2	—	C	23/9

FUSELAGE
CENTRE FUSELAGE STRUCTURE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
11494	E.A1.11.829	BRACKET, DOOR ROLLER GUIDE, FRAME 23, ASSEMBLY						1	L.40	B	23/12
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/13
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/14
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/15
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/16
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/17
		Washer, 5/16" BSF plain						1	—	C	23/17
28D/1011240	A25/5E	Attaching parts for E.A1.11.829:— Bolt, 1/4" BSF hex. head						4	—	C	23/18
11495	E.A1.11.831	BRACKET, DOOR, ROLLER GUIDE, FRAME 25, ASSEMBLY						1	L.40	B	23/19
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/13
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/14
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/15
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/16
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/17
		Washer, 5/16" BSF plain						1	—	C	23/17
28D/1011240	A25/5E	Attaching parts for E.A1.11.831:— Bolt, 1/4" BSF hex. head						4	—	C	23/18
11496	E.A1.11.833	BRACKET, DOOR, ROLLER GUIDE, FRAME 27B, ASSEMBLY						1	L.40	B	23/20
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/13
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/14
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/15
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/16
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/17
		Washer, 5/16" BSF plain						1	—	C	23/17
28D/1011240	A25/5E	Attaching parts for E.A1.11.833:— Bolt, 1/4" BSF hex. head						4	—	C	23/18
11497	E.A1.11.845	BRACKET, ROLLER, MOUNTING, BOMB DOOR CENTRE TRACK, GROUP						1	—	B	23/21
241	E.A1.11.847	Spares for:— ROLLER, locating						1	BSS.369	C	23/22
28D/1212730	AS.1242/30E	Attaching parts for E.A1.11.847:—						1	—	C	23/23
28M/1011475	A27/EP	Bolt, 1/4" BSF c'sk head						1	—	C	23/24
239	E.A1.11.853	Nut, 1/4" BSF plain						1	S.94, S.95 or S.96	C	23/25
244	E.A1.11.857	Pin, special						1	—	C	23/26
28W/9994217	SP.18/E	Washer, special						1	DTD.124	C	23/27
		Washer, 1/4" BSF plain						1	—	C	23/27
242	E.A1.11.849	ROLLER, main						1	BSS.369	C	23/28
240	E.A1.11.855	Attaching parts for E.A1.11.849:— Pin, special						1	S.94, S.95 or S.96	C	23/29

FUSELAGE

CENTRE FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA1.11.1365	. . . ROLLER, main Attaching parts for EA1.11.1365:-	1	BSS369	23/30
A27EP	. . . Nut, 1/4" BSF plain	1	—	23/31
EA1.11.851	. . . Pin, special, 1/4" BSF	1	S.94, S.95 or S.96	23/32
EA1.11.1367	. . . Washer, special	1	S.94, S.95 or S.96	23/33
SP13E	. . . Washer, 1/4" BSF plain Attaching parts for EA1.11.845:-	2	—	23/34
A25/6E	. . Bolt, 1/4" BSF hex head	2	—	23/35
A25/10J	. . Bolt, 3/8" BSF hex head	1	—	23/36
AGS2001J1	. . Nut, stiff, 3/8" BSF	1	—	23/37
EA1.11.1327	. . Stud, special 3/8" BSF	1	HTS.SH	23/38
SP47E	. . Washer, 1/4" BSF spring	2	—	23/39
SP47J	. . Washer, 3/8" BSF spring	1	—	23/40
EA1.11.1177	. . CONNECTION, main hinge stay forward Attaching parts for EA1.11.1177:-	1	L.40	24/1
A25/3C	. . Bolt, 2 BA hex head	4	—	24/2
EA1.11.1179	. . CONNECTION, main hinge stay aft Attaching parts for EA1.11.1179:-	1	L.40	24/3
A25/3C	. . Bolt, 2 BA hex head	4	—	24/4
—	. . DUCT CONDUIT ATTACHMENT (EG9.82.573) Spares for:-	—	—	24/5
AS3180/5C	. . . CLIP, 'P' Attaching parts for AS3180/5C:-	1	—	24/6
A25/1C	. . . Bolt, 2 BA hex head	1	—	24/7
SP13C	. . . Washer, 2 BA plain	1	—	24/8
EB6.82.737	. . . DUCT, cable Attaching parts for EB6.82.737:-	1	—	24/9
AS1246/1C	. . . Bolt, 2 BA round head	2	—	24/10
A25/1C	. . . Bolt, 2 BA hex head	1	—	24/11
AS3181/16C	. . . Clip, 'P'	1	—	24/12
SP15C	. . . Washer, 2 BA plain	1	—	24/13
EA1.11.1441	. . FLAP, roller spring hinged clearance	1	—	25/1
EA1.11.2563	. . FLAP, hinged	1	—	25/2
EA1.11.933	. . HINGE BOMB DOOR MAIN BRACKET REAR END ASSEMBLY Spares for:-	1	—	25/3
EA1.11.927	. . . BEARING, journal	1	DTD197	25/4
EA1.11.929	. . . BEARING, journal	1	DTD197	25/5
EA1.11.1467	. . . BRACKET Attaching parts for EA1.11.1467:-	1	L.40	25/6
A25/1C	. . . Bolt, 2 BA hex head	2	—	25/7
SP47C	. . . Washer, 2 BA spring Attaching parts for EA1.11.933:-	2	—	25/8
A25/4E	. . Bolt, 1/4" BSF hex head	6	—	25/9
A25/7J	. . Bolt, 3/8" BSF hex head	2	—	25/10
A25/7L	. . Bolt, 7/16" BSF hex head	2	—	25/11
EA1.11.2621	. . Shim laminated	1	Lam Alum	25/12

FUSELAGE
CENTRE FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA1.11.935	. . HINGE BOMB DOOR MAIN BRACKET FORWARD END ASSEMBLY (Supplied to Part No. EA3.00.1001 for spares purposes) Spares for:-	1	L.40	25/13
EA1.11.929	. . . BEARING, journal	1	DTD.197	25/14
EA1.11.931	. . . BEARING, journal	1	DTD.197	25/15
EA1.11.1467	. . . BRACKET Attaching parts for EA1.11.1467:-	1	L.40	25/16
A25/3C	. . . Bolt, 2 BA hex head	2	—	25/17
A27CP	. . . Nut, 2 BA plain Attaching parts for EA1.11.935:-	2	—	25/18
A25/4C	. . Bolt, 2 BA hex head	6	—	25/19
A25/6G	. . Bolt, 5/16" BSF hex head	2	—	25/20
EA1.11.1601	. . Bolt, special 7/16" BSF	2	HTS.S11	25/21
EA1.11.3197	. . Shim, laminated	1	Lam Alum	25/22
EA1.11.1607	. . HINGE, flap roller clearance (Make from AS1878/15, Ref 28N/10786	1	—	25/23
EG5.82.261	. . PANEL, removable aerial aperture Attaching parts for EG5.82.261:-	1	—	24/14
AS1248/1C	. . Bolt, 2 BA mushroom head	4	—	24/15
AS1248/2C	. . Bolt, 2 BA mushroom head	1	—	24/16
AS1248/3C	. . Bolt, 2 BA mushroom head	1	—	24/17
EG5.82.293	. . PANEL, access Attaching parts for EG5.82.293:-	1	—	24/18
AS1248/2C	. . Bolt, 2 BA mushroom head	9	—	24/19
R EA3.11.117	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	—	24/20
R EA3.11.5191	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	—	24/20
R EA3.11.119	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	—	24/21
R EA3.11.5193	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	—	24/21
R EA3.11.121	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	—	24/22
R EA3.11.5195	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	—	24/22
EA1.11.1309	. . SPRING, leaf outboard clearance flap	1	Spring	25/24
EA1.11.1311	. . SPRING, leaf inboard clearance flap	1	Steel Spring Steel	25/25
EA1.11.1205	. . STAY, main hinge support assembly Attaching parts for EA1.11.1205:-	1	—	24/23
EA1.11.1231	. . Bolt, eye stay connection to door hinge	1	L.40	25/26
A25/3C	. . Bolt, 2 BA hex head	2	—	24/24
A27EP	. . Nut, 1/4" BSF plain	1	—	25/27
A27CP	. . Nut, 2 BA plain	2	—	24/25
EA1.11.1207	. . STAY, main hinge support assembly Attaching parts for EA1.11.1207:-	1	—	24/26 24/27
EA1.11.1231	. . Bolt, eye stay connection to door hinge	1	L.40	25/26
A25/3C	. . Bolt, 2 BA hex head	2	—	24/27
A27EP	. . Nut, 1/4" BSF plain	1	—	25/27
A27CP	. . Nut, 2 BA plain	2	—	24/28

A.P.101B-0418-3A		FUSELAGE CENTRE FUSELAGE STRUCTURE					Page HC5					
Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
3081	E.A1.11.1098	DOOR, BOMB, STARBOARD, ASSEMBLY							1	—	A	23/41
		Spares for:—										
11491	E.A1.11.823	BRACKET, DOOR, ROLLER GUIDE, FRAME 15, ASSEMBLY							1	L.40	B	23/2
		Spares for:—										
237	E.A1.11.837	ROLLER							1	L.40	C	23/3
		Attaching parts for E.A1.11.837:—										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple							1	—	C	23/4
28M/1011470	A27/GT	Nut, 5/16" BSF thin							1	—	C	23/5
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22SWG							1	T.45	C	23/6
28W/9419476	SP.15/G	Washer, 5/16" BSF plain							1	—	C	23/7
		Attaching parts for E.A1.11.823:—										
15825	E.A1.11.1573	Bolt, special, 1/4" BSF							2	S.96	C	23/8
28D/1011240	A25/5E	Bolt, 1/4" BSF hex. head							2	—	C	23/9
		BRACKET, DOOR ROLLER GUIDE, FRAME 17, ASSEMBLY							1	L.40	B	23/10
		Spares for:—										
237	E.A1.11.837	ROLLER							1	L.40	C	23/3
		Attaching parts for E.A1.11.837:—										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple							1	—	C	23/4
28M/1011470	A27/GT	Nut, 5/16" BSF thin							1	—	C	23/5
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG							1	T.45	C	23/6
28W/9419476	SP.15/G	Washer, 5/16" BSF plain							1	—	C	23/7
		Attaching parts for E.A1.11.825:—										
15825	E.A1.11.1573	Bolt, special, 1/4" BSF							2	S.96	C	23/8
28D/1011240	A25/5E	Bolt, 1/4" BSF hex. head							2	—	C	23/9
		BRACKET, DOOR ROLLER GUIDE, FRAME 19, ASSEMBLY							1	L.40	B	23/11
		Spares for:—										
237	E.A1.11.837	ROLLER							1	L.40	C	23/3
		Attaching parts for E.A1.11.837:—										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple							1	—	C	23/4
28M/1011470	A27/GT	Nut, 5/16" BSF thin							1	—	C	23/5
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG							1	T.45	C	23/6
28W/9419476	SP.15/G	Washer, 5/16" BSF plain							1	—	C	23/7
		Attaching parts for E.A1.11.827:—										
15825	E.A1.11.1573	Bolt, special, 1/4" BSF							2	—	C	23/8
28D/1011240	A25/5E	Bolt, 1/4" BSF hex. head							2	—	C	23/9
		BRACKET, DOOR ROLLER GUIDE, FRAME 23, ASSEMBLY							1	L.40	B	23/12
		Spares for:—										
237	E.A1.11.837	ROLLER							1	L.40	C	23/13
		Attaching parts for E.A1.11.837:—										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple							1	—	C	23/14
28M/1011470	A27/GT	Nut, 5/16" BSF thin							1	—	C	23/15
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG							1	T.45	C	23/16
28W/9419476	SP.15/G	Washer, 5/16" BSF plain							1	—	C	23/17
		Attaching parts for E.A1.11.829:—										
28D/1011240	A.25/5E	Bolt, 1/4" BSF hex. head							4	—	C	23/18
		BRACKET, DOOR ROLLER GUIDE, FRAME 25, ASSEMBLY							1	L.40	B	23/19
		Spares for:—										
237	E.A1.11.837	ROLLER							1	L.40	C	23/13
		Attaching parts for E.A1.11.837:—										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple							1	—	C	23/14

FUSELAGE
CENTRE FUSELAGE STRUCTURE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
28M/1011470	A27/GT							Nut, 5/16" BSF thin	1	—	C	23/15
11588	E.A1.11.1617							Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16
28W/9419476	SP.15/G							Washer, 5/16" BSF plain	1	—	C	23/17
								Attaching parts for E.A1.11.831:—				
28D/1011240	A25/5E							Bolt, 1/4" BSF hex. head	4	—	C	23/18
11496	E.A1.11.833							BRACKET, DOOR ROLLER GUIDE, FRAME 27B, ASSEMBLY	1	L.40	B	23/20
								Spares for:—				
237	E.A1.11.837							ROLLER	1	L.40	C	23/13
								Attaching parts for E.A1.11.837:—				
236	E.A1.11.1615							Bolt, special, c/w lubricating nipple	1	—	C	23/14
28M/1011470	A27/GT							Nut, 5/16" BSF thin	1	—	C	23/15
11588	E.A1.11.1617							Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16
28W/9419476	SP.15/G							Washer, 5/16" BSF plain	1	—	C	23/17
								Attaching parts for E.A1.11.833:—				
28D/1011240	A25/5E							Bolt, 1/4" BSF hex. head	4	—	C	23/18
11497	E.A1.11.846							BRACKET, ROLLER MOUNTING, BOMB DOOR CENTRE TRACK, GROUP	1	DTD.300 Casting	B	23/42
								Spares for:—				
241	E.A1.11.847							ROLLER, locating	1	BSS.369	C	23/22
								Attaching parts for E.A1.11.847:—				
28D/1212730	AS.1242/30E							Bolt, 1/4" BSF c'sk head	1	—	C	23/23
28M/1011475	A27/EP							Nut, 1/4" BSF plain	1	—	C	23/24
239	E.A1.11.853							Pin, special	1	S.4, S.95 or S.96	C	23/25
244	E.A1.11.857							Washer, special	1	DTD.124	C	23/26
28W/9994217	SP.18/E							Washer, 1/4" BSF plain	1	—	C	23/27
242	E.A1.11.849							ROLLER, main	1	BSS.369	C	23/28
								Attaching parts for E.A1.11.849:—				
240	E.A1.11.855							Pin, special	1	S.94, S.95 or S.96	C	23/29
243	E.A1.11.1365							ROLLER, main	1	BSS.369	C	23/30
								Attaching parts for E.A1.11.1365:—				
28M/1011475	A27/EP							Nut, 1/4" BSF plain	1	—	C	23/31
238	E.A1.11.851							Pin, special, 1/4" BSF	1	S.94, S.95 or S.96	C	23/32
245	E.A1.11.1367							Washer, special	1	S.94, S.95 or S.96	C	23/33
28W/9418921	SP.13/E							Washer, 1/4" BSF plain	2	—	C	23/34
								Attaching parts for E.A1.11.846:—				
28D/1008145	A25/6E							Bolt, 1/4" BSF hex. head	2	—	C	23/35
28D/1011302	A25/10J							Bolt, 3/8" BSF hex. head	1	—	C	23/36
28M/10292	AGS.2001/J/1							Nut, stiff, 3/8" BSF	1	—	C	23/37
15807	E.A1.11.1327							Stud, special, 3/8" BSF	1	HTS.S11	C	23/38
28W/9416644	SP.47/E							Washer, 1/4" BSF spring	2	—	C	23/39
28W/9416646	SP.47/J							Washer, 3/8" BSF spring	1	—	C	23/40
15799	E.A1.11.1178							CONNECTING, main hinge stay, forward	1	L.40	C	24/29
								Attaching parts for E.A1.11.1178:—				
28D/9133012	A25/3C							Bolt, 2 BA hex. head	4	—	C	24/2
15801	E.A1.11.1180							CONNECTION, main hinge stay, aft	1	DTD.683	C	24/30
								Attaching parts for E.A1.11.1180:—				
28D/9133012	A25/3C							Bolt, 2 BA hex. head	4	—	C	24/4
247	E.A1.11.1441							FLAP, roller, spring hinged clearance	1	—	C	25/1
6868	E.A1.11.2563							FLAP, hinged	1	—	C	25/2

FUSELAGE

CENTRE FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA1.11.934	. . HINGE BOMB DOOR MAIN BRACKET REAR END ASSEMBLY Spares for:-	1	L.40	25/28
EA1.11.927	. . . BEARING, journal	1	DTD197	25/4
EA1.11.929	. . . BEARING, journal	1	DTD197	25/5
EA1.11.1468	. . . BRACKET Attaching parts for EA1.11.1468:-	1	L.40	25/29
A25/1C	. . . Bolt, 2 BA hex head	2	—	25/7
SP47C	. . . Washer, 2 BA spring Attaching parts for EA1.11.934:-	2	—	25/8
A25/4E	. . Bolt, 1/4" BSF hex head	6	—	25/9
A25/7J	. . Bolt, 3/8" BSF hex head	2	—	25/10
A25/7L	. . Bolt, 7/16" BSF hex head	2	—	25/11
EA1.11.2621	. . Shim laminated	1	Lam Alum	25/12
EA11.936	. . HINGE BOMB DOOR MAIN BRACKET FORWARD END ASSEMBLY (Supplied to Part No. EA3.00.1002 for spares purposes) Spares for:-	1	L.40	25/30
EA1.11.929	. . . BEARING, journal	1	DTD197	25/14
EA1.11.931	. . . BEARING, journal	1	DTD197	25/15
EA1.11.1468	. . . BRACKET Attaching parts for EA1.11.1468:-	1	L.40	25/31
A25/3C	. . . Bolt, 2 BA hex head	2	—	25/17
A27CP	. . . Nut, 2 BA plain Attaching parts for EA1.11.936:-	2	—	25/18
A25/4C	. . Bolt, 2 BA hex head	6	—	25/19
A25/5G	. . Bolt, 3/8" BSF hex head	2	—	25/20
EA1.11.1601	. . Bolt, special 7/16" BSF	2	HTS.S11	25/27
EA1.11.3197	. . Shim laminated	1	—	25/22
EA1.11.1607	. . HINGE, flap roller clearance (Make from AS1878/15, Ref. 28N/9511950)	1	—	25/23
R EA3.11.117	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	—	24/20
R EA3.11.5191	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	—	24/20
R EA3.11.119	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	—	24/21
R EA3.11.5193	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	—	24/21
R EA3.11.121	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	—	24/22
R EA3.11.5195	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	—	24/22
EA1.11.1309	. . SPRING, leaf outboard clearance flap	1	Spring Steel	25/24
EA1.11.1311	. . SPRING, leaf inboard clearance flap	1	Spring Steel	25/25
EA1.11.1205	. . STAY, main hinge support assembly Attaching parts for EA1.11.1205:-	1	—	24/23
EA1.11.1231	. . Bolt, eye stay connection to door hinge	1	L.40	25/26
A25/3C	. . Bolt, 2 BA hex head	2	—	24/24
A27EP	. . Nut, 1/4" BSF plain	1	—	25/27
A27CP	. . Nut, 2 BA plain	2	—	24/25
EA1.11.1207	. . STAY, main hinge support assembly Attaching parts for EA1.11.1207:-	1	—	24/26
EA1.11.1231	. . Bolt, eye stay connection to door hinge			25/26
A25/3C	. . Bolt, 2 BA hex head	2	—	24/27
A27EP	. . Nut, 1/4" BSF plain	1	—	25/27
A27CP	. . Nut, 2 BA plain	2	—	24/28