

AP101B-0418-3A

SERVICES
OXYGEN SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
—	OXYGEN DEMAND SYSTEM, ASSEMBLY (EG9.71.1) Spares for:—	—	—	
R —	. BOMB AIMER'S OXYGEN SYSTEM (EG9.71.107) (SAS 4746) Spares for:—	—	—	
R 6D1648	. . ADAPTOR, elbow	1	—	95/1
R CM0544FIG 1	. . BRACKET	1	—	95/2
R EB6.71.99	. . BRACKET	1	—	95/3
R AS4525/14	. . CLIP Attaching parts for AS4525/14:—	1	—	95/4
R A25/18	. . Bolt, 4 BA	1	—	95/5
R AGS2001/B/1	. . Nut, stiff, 4 BA	1	—	95/6
R EEAS/21/2/DR	. . Washer 'D'	1	—	95/7
R SP14B	. . Washer	1	—	95/8
R AS4525/14	. . CLIP Attaching parts for AS4525/14:—	2	—	95/9
R A25/18	. . Bolt, 4 BA	1	—	95/10
R AGS2002/B/1	. . Nut, stiff, 4 BA	1	—	95/11
R EEAS/21/2/DR	. . Washer 'D'	1	—	95/12
R AS4525/14	. . CLIP	1	—	95/13
R AS2294/6	. . CLIP Attaching parts for AS2294/6:—	3	—	95/14
R AS1248/1B	. . Bolt, mush head, 4 BA	1	—	95/15
R AGS2002/B/1	. . Nut, stiff, 4 BA	1	—	95/16
R SP13B	. . Washer	1	—	95/17
R AGS1102/BB	. . COUPLING, pipe	1	—	95/18
R AGS1118/BB	. . COUPLING, pipe	1	—	95/19
R EB7.71.53	. . FAIRLEAD Attaching parts for EB7.71.53:—	1	—	95/20
R A25/18	. . Bolt, 4 BA	4	—	95/21
R AGS2001/B/1	. . Nut, stiff, 4 BA	4	—	95/22
R SP14B	. . Washer	4	—	95/23
R CM0544FIG 2	. . FAIRLEAD Attaching parts for CM0544 FIG 2:—	1	—	95/24
R A25/18	. . Bolt, 4 BA	4	—	95/25
R AGS2001/B/1	. . Nut, stiff, 4 BA	4	—	95/26
R SP14B	. . Washer	4	—	95/27

SERVICES
OXYGEN SYSTEM

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
R 6D1580	.	.	.	.	.	HOSE Attaching parts for 6D1580:—	QR	—	95/28
R SP91E	.	.	.	.	.	Clip, hose	2	—	95/29
R 32C/1275037	.	.	.	.	.	HOSE Attaching parts for 32C/1275037:—	QR	—	95/30
R SP91F	.	.	.	.	.	Clip, hose	2	—	95/31
R DN/1245Z/MK14	.	.	.	.	.	INDICATOR, electro magnetic Attaching parts for DN/1245Z/MK14:—	1	—	95/32
R AS1248/1C	.	.	.	.	.	Bolt, mush head, 2 BA	2	—	95/33
R AS3360/B/3/B	.	.	.	.	.	LEAD, bonding	2	—	95/34
R EB7.71.91	.	.	.	.	.	PIPE	1	—	95/35
R EB7.71.93	.	.	.	.	.	PIPE	1	—	95/36
R EB7.71.95	.	.	.	.	.	PIPE	1	—	95/37
R EB7.71.97	.	.	.	.	.	PIPE	1	—	95/38
R 6D2671	.	.	.	.	.	REGULATOR, oxygen, MK17F Attaching parts for 6D2671:—	1	—	95/39
R AS1248/1B	.	.	.	.	.	Bolt, mush head, 4 BA	4	—	95/40
R 6D1817	.	.	.	.	.	SOCKET, QR	1	—	95/41

AP101B-0418-3A

SERVICES
OXYGEN SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
-	OXYGEN DEMAND SYSTEM, ASSEMBLY (EG9.71.1) Spares for:-	-	-	
-	CIRCUIT, OXYGEN DEMAND EQUIPMENT, ASSEMBLY (EB6.71.7) Spares for:-	-	-	84/1
R IN14286-1	. . CABLE, operating, anchor section	3	-	84/3
R 6D/2243838	. . CLIP, aerolex, type D	3	-	84/4
R 18861B	. . CYLINDER, oxygen, 750 litre	5	-	84/5
R 18854B	. . CYLINDER, oxygen, 2250 litre	2	-	84/6
R 6D/2244018	. . FILTER, oxygen, Mk. 1	1	-	84/7
R OP10074ISSUE 3	. . FLANGE, L.P. connector	3	-	84/8
R 6D/2244063	. . GAUGE, oxygen pressure, Mk.4	2	-	84/9
R OP570	. . HOSE, low pressure oxygen, Mk. 7, 4 ft. long	3	-	84/10
R 6D/2243528	. . PIECE, connecting, 2-way	1	-	84/11
R OP6450	. . REGULATOR, oxygen demand, Mk. 17E	3	-	84/12
R 6D/2678	. . SET, emergency oxygen, Mk. 7J	3	-	84/13
R IN14291-1	. . SOCKET, anchor	3	-	84/14
R 6D/2243622	. . SOCKET, quick release, Mk.9	3	-	84/15
R GA1409	. . TUBE, assembly, upper oxygen	3	-	84/16
R 6D/2243797	. . UNION, blanking	4	-	84/17
R GA3150ISSUE A	. . VALVE, check, internal	4	-	84/18
R 6D/2244070	. . VALVE, pressure reducing, Mk. 1A	2	-	84/20
R GA3030	. . VALVE, oxygen charging, Type 1 (Mod. 5268)	1	-	84/2A
R GA3070	. . VALVE, line, Type 1 (Mod. 5268)	2	-	84/2
-	CYLINDER, OXYGEN, ASSEMBLY (EG9.71.95) Spares for:-	-	-	85/1
EEAS91/4	. . CLIP, pipe, double, 3/16" o/d Attaching parts for EEAS91/4:-	3	L72	85/2
A25/2B	. . Bolt, 4 BA hex. head	1	-	85/3
AGS2001/B/1	. . Nut, stiff, 4 BA	1	-	85/4
SP15/B	. . Washer, 4 BA plain	1	-	85/5
AS1900/A	. . CLIP, cable	21	-	85/6
EA1.71.111	. . FAIRLEAD Attaching parts for EA1.71.111:-	1	LFS21	85/7
A25/2B	. . Bolt, 4 BA hex. head	3	-	85/8
AGS2001/B/1	. . Nut, stiff, 4 BA	3	-	85/9
SP15/B	. . Washer, 4 BA plain	3	-	85/10
R	. . MOUNTING, oxygen charging valve installation (EA3.71.589) (Mod 5268) Spares for:-	-	-	85/36
R EA1.71.89	. . . LABEL	1	-	85/37
R EA3.71.539	. . . PLATE, adaptor assembly Spares for:-	1	-	85/38
R AGS2018/C/2	. . . NUT, anchor	2	-	85/39
R EA3.71.585	. . . PLATE, adaptor, 1.2 mm thick (30B/9611244) Attaching parts for EA3.71.539:-	1	L73	85/40
R A25/1C	. . . Bolt, 2 BA hex head	4	-	85/41
R AGS2002/C/1	. . . Nut, 2 BA	4	-	85/42
R SP15/C	. . . Washer, 2 BA	4	-	85/43
EA1.71.61	. . PAD, mounting, oxygen bottle	2	Rubber S/H.40-45	85/11
EA1.71.115	. . PAD, mounting, oxygen bottle	1	BS.F62	85/12
EA3.71.417	. . PAD, mounting, oxygen bottle	1	Rubber S/H.40-45	85/13

SERVICES
OXYGEN SERVICES

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA1.71.65	. . . PIECE, distance	20	L62	85/14
EG7.71.19	. . . PIPE, assembly	1	T51	85/15
EB6.71.43	. . . PIPE, assembly, from 2,250 litre oxygen cylinder to coupling forward of frame 12	1	T51	85/16
EB6.71.47	. . . PIPE, assembly, from 750 litre oxygen cylinder to pressure bulkhead	1	T51	85/17
EB6.71.49	. . . PIPE, assembly, from coupling forward of frame 12A to coupling aft of frame 9	1	T51	85/18
EA3.71.163	. . . PIPE, assembly, from charging valve to filter	1	T51	85/19
EA3.71.169	. . . PIPE, assembly, oxygen cylinder interconnection	2	T51	85/20
EA3.71.177	. . . PIPE, assembly, oxygen bottle interconnection	1	T51	85/21
EA3.71.179	. . . PIPE, assembly, oxygen bottle interconnection	2	T51	85/22
EA3.71.181	. . . PIPE, assembly, oxygen bottle interconnection	1	T51	85/23
EA3.71.419	. . . PIPE, assembly, oxygen bottle interconnection	1	T51	85/24
EA3.71.421	. . . PIPE, assembly, interconnection, from 2.250 litre oxygen bottle to 3-way connection	1	T51	85/25
EA3.71.423	. . . PIPE, assembly, oxygen bottle interconnection	1	T51	85/26
EA3.71.431	. . . PIPE, assembly, from 3-way piece inter- connection for 2,250 and 750 litre oxygen bottle to charging valve filter	1	T51	85/27
EA3.71.437	. . . PIPE, assembly, oxygen bottle interconnection	2	T51	85/28
EA3.71.439	. . . PIPE, assembly, interconnection, from 3-way tee-piece to 750 litre oxygen bottle	1	T51	85/29
AS2381	. . . ROD, tension, 1/4" BSF	4	—	85/30
EA1.71.63	. . . SCREW, trunnion, for bottle straps	10	S1	85/31
EA1.71.37	. . . STRAP, oxygen bottle, 750 litre	10	DTD390	85/32
EA1.71.39	. . . STRAP, oxygen bottle, 750 litre	10	DTD390	85/33
EA3.71.391	. . . STRAP, oxygen bottle, 2,250 litre	4	L72	85/34
EA3.71.399	. . . STRAP, oxygen bottle, 2,250 litre	4	L72	85/35
—	. . . NAVIGATOR'S OXYGEN SYSTEM, ASSEMBLY (EG9.71.89) Spares for:—	—	—	86/1
EEAS136	. . . BRACKET, for bonding clip	2	L72	86/2
EB7.71.49	. . . CLAMP, bracket, navigator's pressure reducing valve mounting Attaching parts for EB7.71.49:—	1	T35	86/3
A25/17B	. . . Bolt, 4 BA hex. head	2	—	86/4
AGS2002/B/1	. . . Nut, stiff, 4 BA	2	—	86/5
AS4525/5	. . . CLIP, pipe, 5/16" o/d bonding Attaching parts for AS4525/5:—	6	L72	86/6
A25/1C	. . . Bolt, 2 BA hex. head	1	—	86/7
AGS2002/C/1	. . . Nut, stiff, 2 BA	1	—	86/8
EEAS22/2/ERH	. . . Washer, 'D' (at 2 positions)	1	L72	86/9
EEAS237/11/ AH	. . . Washer, 'D' (at 4 positions)	1	L72	86/10

AP.101B-0418-3A

SERVICES
OXYGEN SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
AS4525/3	. . . CLIP, pipe 3/16" o/d bonding	13	L.72	86/11
—	. . . FITTINGS OXYGEN ON PRESSURE BULKHEAD ASSEMBLY (EA3.71.505)	—	—	87/1
	Spares for:-			
EA3.57.21	. . . BRACKET, mounting oxygen master valve	1	DTD625	87/2
EB7.71.21	. . . BRACKET, assembly	2	L.72	87/3
	Attaching parts for EB7.71.21:-			
A25/1C	. . . Bolt, 2 BA hex head	4	—	87/4
AGS2001C1	. . . Nut, stiff, 2 BA	4	—	87/5
SP15C	. . . Washer, 2 BA plain	4	—	87/6
—	. . . RELEASE EMERGENCY OXYGEN PASSENGER'S INSTALLATION (EA3.71.543)	—	—	87/7
	Spares for:-			
EA3.71.541	 RELEASE EMERGENCY OXYGEN ASSEMBLY	1	—	87/8
	Spares for:-			
EB6.71.591	 CABLE, emergency release assembly	1	—	87/9
EB6.71.581	 TUBE, assembly	1	—	87/10
—	 RELEASE, EMERGENCY OXYGEN NAVIGATOR'S INSTALLATION (EB7.71.5053)	—	—	87/11
	Spares for:-			
EB7.71.5047	 PLATE, radius	1	L.72	87/12
EB7.71.5049	 RELEASE EMERGENCY OXYGEN ASSEMBLY	1	—	87/13
	Spares for:-			
EB6.71.591	 CABLE, emergency release assembly	1	—	87/14
EB7.71.5051	 TUBE, assembly	1	—	87/15
AGS1112B	 UNION, body bulkhead fitting	2	—	87/16
	Attaching parts for AGS1112B:-			
A25/2B	. . . Bolt, 4 BA hex head	6	—	87/17
EEAS69/2	. . . Gasket	1	Neo-K-Tex	87/18
AGS2001B1	. . . Nut, stiff, 4 BA	6	—	87/19
AGS1115/2	. . . Washer, plate	1	—	87/20
EB7.71.55	. . . HOSE, coupling 7/8" i/d x 1-1/4" o/d x 3" long	4	DTD625	86/12
—	. . . MOUNTING NAVIGATORS OXYGEN REGULATOR ASSEMBLY (EG9.71.51)	—	—	86/13
	Spares for:-			
EG9.71.71	. . . PANEL, mounting	1	L.72	86/14
	Attaching parts for EG9.71.71:-			
AS1248/1B	. . . Bolt, 4 BA mushroom head	12	—	86/15

SERVICES
OXYGEN SYSTEM

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
		1 2 3 4 5 6			
R	EA3.71.587	. . MOUNTING ASSEMBLY OXYGEN LINE VALVE (Mod 5268) Spares for:-	1	—	86/30
R	A25/1C	. . . BOLT, 2 BA	2	—	86/39
R	EA3.57.21	. . . BRACKET, mounting	1	DTD825	86/31
R	EA3.71.591	. . . LABEL, 0.9mm thick (30B/9611220) (Mod 5268)	1	L.72	86/32
	EA3.71.539	. . . PLATE, adaptor assembly Spares for:-	1	—	86/35
R	AGS2018C2	 NUT, anchor	2	—	86/36
	EA3.71.585	 PLATE, adaptor 1.2mm thick (30B/9611244) Attaching parts for EA3.71.539:-	1	L.73	86/37
	A61/1C	. . . Bolt, 2 BA	4	—	86/38
	EG9.80.309	. . . STOP, navigators folding table Attaching parts for EG9.80.309:-	1	BS2572	86/16
	AS1242/15C	. . . Bolt, 2 BA c'sk head	1	—	86/17
	AS1242/18C	. . . Bolt, 2 BA c'sk head	1	—	86/18
	EG9.71.9	. . PIPE, assembly intermediate pressure from reducing valve to tee coupling 5/16" x o/d x 22 SWG	1	L.54	86/19
	EG9.71.11	. . PIPE, assembly intermediate pressure from tee at reducing valve to navigator's oxygen regulator 5/16" o/d x 22 SWG	1	L.54	86/20
	EG9.71.13	. . PIPE, assembly H.P. from tee coupling to reducing valve at coaming tube 3/16" o/d x 22 SWG	1	T.51	86/21
	EG9.71.17	. . PIPE, L.P. between hose couplings under navigators floor 7/8" o/d x 22 SWG	1	L.54	86/22
	EG9.71.19	. . PIPE, L.P. from hose coupling at navigators floor to hose coupling under floor frame 6, 7/8" o/d x 22 SWG	1	L.54	86/23
	EG9.71.21	. . PIPE, L.P. from oxygen regulator to hose coupling at navigators floor 7/8" o/d x 22 SWG	1	L.54	86/24
	EG9.71.23	. . PIPE, assembly intermediate pressure from tee at reducing valve outlet line to passengers oxygen regulator 5/16" o/d x 22 SWG	1	L.54	86/25
	EG9.71.81	. . PIPE, assembly H.P. from tee coupling at navigators reducing valve to main H.P. line 3-way piece frame 5 starboard 3/16" o/d x 22 SWG	1	T.51	86/26
	EG9.71.83	. . PIPE, assembly H.P. from tee coupling at navigators reducing valve to main H.P. line 3-way piece frame 5 port 3/16" o/d x 22 SWG	1	T.51	86/27
	EB7.71.67	. . PIPE, assembly H.P. from stop valve to reducing valve tee port	1	T.51	86/28
	EA3.71.453	. . PIPE, assembly H.P. from oxygen valve to pressure bulkhead connection port	1	T.51	86/29

SERVICES
OXYGEN SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EEAS22/2ERH	. . WASHER, 'D'	20	L.72	86/34
—	. PASSENGERS OXYGEN SYSTEM ASSEMBLY (EG9.71.91) Spares for:-	—	—	87/21
EEAS136	. . BRACKET, pipe clip	3	L.72	87/22
AS4525/3	. . CLIP, pipe 3/16" o/d Attaching parts for AS4525/3:-	5	L.72	87/23
A25/1C	. . Bolt, 2 BA hex head	1	—	87/24
AGS2002C1	. . Nut, stiff 2 BA	1	—	87/25
EEAS22/2ERH	. . Washer, 'D'	1	L.72	87/26
AS4525/5	. . CLIP, pipe 5/16" o/d Attaching parts for AS4525/5:-	3	L.72	87/27
A25/1C	. . Bolt, 2 BA hex head	1	—	87/28
AGS2002C1	. . Nut, stiff 2 BA	1	—	87/29
EEAS22/2ERH	. . Washer, 'D'	1	L.72	87/30
EB7.71.55	. . HOSE, coupling 7/8" i/d x 1-1/4" o/d x 3" long (Make from 32C/445)	3	DTD625 Type 1	87/31
R EB7.71.77	. . LABEL	1	—	
EG9.71.15	. . PIPE, L.P. from hose coupling frame 8 to passenger's oxygen regulator forward of frame 7 7/8" o/d x 20 SWG	1	L.54	87/32
EG8.71.97	. . PIPE, L.P. from hose coupling to passenger's demand oxygen hose connection 7/8" o/d x 20 SWG	1	L.54	87/33
EA3.71.503	. . PIPE, assembly H.P. from oxygen valve to pressure bulkhead connection starboard	1	T.51	87/34
EA3.71.507	. . PIPE, assembly H.P. from supply tee to stop valve on pressure bulkhead starboard	1	T.51	87/35
R EA3.71.539	. . PLATE, adaptor assembly (Mod 5268) Spares for:-	1	—	87/37
AGS2018C2	. . NUT, anchor	2	—	87/38
R EA3.71.585	. . PLATE, adaptor, 1.2mm (30B/9611244) Attaching parts for EA3.71.539:-	1	L.73	87/39
A61/1C	. . Bolt, 2 BA	4	—	87/40
A25/1C	. . Bolt, 2 BA	2	—	87/41
EEAS22/1ERH	. . WASHER, 'D'	3	L.72	
EEAS239/2AH	. . WASHER, 'D'	4	L.72	87/36
—	. PILOT'S OXYGEN SYSTEM ASSEMBLY (EG9.71.93) Spares for:-	—	—	88/1
EEAS136	. . BRACKET, pipe clip	10	L.72	88/2
EB7.71.43	. . BRACKET, pipe support frame 3 assembly Attaching parts for EB7.71.43:-	1	DTD124	88/3
A25/1B	. . Bolt, 4 BA hex head	2	—	88/4
AGS2002B1	. . Nut, stiff, 4 BA	2	—	88/5
SP15B	. . Washer, 4 BA plain	2	—	88/6
EB7.71.47	. . BRACKET, reducing valve mounting aft of frame 1	1	DTD124	88/7
—	. . BRACKET, PULL-OFF CONNECTOR MOUNTING INSTALLATION (EG7.71.85) Spares for:-	—	—	88/8
EB6.71.243	. . . BRACKET, mounting	1	L.72	88/9

SERVICES
OXYGEN SYSTEM

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EB7.71.49	. . CLAMP, bracket reducing valve mounting aft of frame 1	1	T.35	88/10
A25/17B	Attaching parts for EB7.71.49:-			
AGS2002B1	. . Bolt, 2 BA hex head	2	—	88/11
	. . Nut, stiff, 4 BA	2	—	88/12
AS4525/3	. . CLIP, pipe 3/16" o/d	5	—	88/13
EB7.71.169	. . CLIP, half pipe clamping forward of frame 3	1	DTD124	88/14
	Attaching parts for EB7.71.169:-			
A25/1B	. . Bolt, 4 BA hex head	2	—	88/15
AGS2002B1	. . Nut, stiff, 4 BA	2	—	88/16
SP15B	. . Washer, 4 BA plain	2	—	88/17
—	. . GUARD PIPE AFT OF FRAME 3 INSTALLATION (EG9.71.101) Consisting of:-	—	—	88/18
EG7.71.147	. . . GUARD, pipe assembly	1	L.72	88/19
4101/7/3/8"	Attaching parts for EG7.71.147:-			
	. . . Screw, self tapping round head	6	—	88/20
EG9.71.103	. . . PACKING, pipe guard 16 SWG	1	L.72	88/21
EB7.71.55	. . HOSE, connecting 7/8" i/d x 1.1/4" o/d x 3" long (Make from 32C/445)	5	DTD625	88/22
—	. . MOUNTING PILOTS DEMAND OXYGEN REGULATOR ASSEMBLY (EB7.71.51) Spares for:-	—	—	88/23
EB6.71.105	. . . BRACKET, mounting assembly	1	—	88/24
6D/575	. . PIECE, connecting 2-way Mk.3A	3	—	88/25
EG9.71.25	. . PIPE, assembly H.P. from supply tee to oxygen contents gauge at pilot's panel between frames 2 and 3 starboard 3/16" o/d x 22 SWG	1	T.51	88/26
EG9.71.27	. . PIPE, assembly H.P. from forward supply line tee forward of frame 2 to pilot's panel forward oxygen contents gauge between frames 2 and 3 starboard 3/16" o/d x 22 SWG	1	T.51	88/27
EG9.71.29	. . PIPE assembly H.P. from non-return valve forward of frame 2 to supply line tee at oxygen contents gauge between frames 2 and 3 starboard 3/16" o/d x 22 SWG	1	T.51	88/28
EG9.71.31	. . PIPE, assembly H.P. from supply line tee frame 5 to tee at oxygen contents gauge, between frames 2 and 3 starboard 3/16" o/d x 22 SWG	1	T.51	88/29

A.P.101B-0418-3A		SERVICES OXYGEN SYSTEM						Page NAA7				
Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index	
		1	2	3	4	5	6					7
1438819	E.G7.71.37							PIPE, assembly, H.P., from connector aft of frame 2 to 3-way connector aft of frame 5, port, 3/16" o/d x 22 SWG	1	T.51	C	88/30
1438820	E.G7.71.39							PIPE, assembly, H.P., from connector aft of frame 1, to connector aft of frame 2, port, 3/16" o/d x 22 SWG	1	T.51	C	88/31
1438821	E.G7.71.43							PIPE, assembly, H.P., transverse, between connectors aft of frame 1, 3/16" o/d x 22 SWG	1	T.51	C	88/32
34956	E.G7.71.87							PIPE, L.P., from hose coupling to demand oxygen regulator aft of frame 3, 7/8" o/d x 22 SWG	1	T.9 or L.54	C	88/33
1438822	E.G7.71.89							PIPE, L.P., between hose couplings aft of frame 3, 7/8" o/d x 22 SWG	1	T.9 or L.54	B	88/34
1438823	E.G7.71.93							PIPE, L.P., from hose coupling, frame 3, to hose coupling, forward of frame 4, 7/8" o/d x 22 SWG	1	T.9 or L.54	B	88/35
1438824	E.G7.71.95							PIPE, L.P., between hose couplings forward of frame 4, 7/8" o/d x 22 SWG	1	T.9 or L.54	B	88/36
34957	E.G7.71.101							PIPE, assembly, intermediate pressure, from connector aft of frame 2, to oxygen regulator aft of frame 3, 5/16" o/d x 22 SWG	1	L.54	C	88/37
1438825	E.G7.71.103							PIPE, assembly, intermediate pressure from connector aft of frame 1 to connector aft of frame 2, port, 5/16" o/d x 22 SWG	1	L.54	C	88/38
1438826	E.G7.71.105							PIPE, assembly, intermediate pressure, transverse, between connectors, aft of frame 1, 5/16" o/d x 22 SWG	1	L.54	C	88/39
34958	E.G7.71.107							PIPE, assembly, intermediate pressure, from connector to reducing valve, aft of frame 1, 5/16" o/d x 22 SWG	1	L.54	C	88/40
1438827	E.G7.71.109							PIPE, assembly, H.P., from connector to 3-way piece, aft of frame 1, 3/16" o/d x 22 SWG	1	T.51	C	88/41
34959	E.G7.71.111							PIPE, assembly, H.P., from 3-way piece to reducing valve, forward of frame 2, starboard, 3/16" o/d x 22 SWG	1	T.51	C	88/42
1438828	E.G7.71.117							PIPE, assembly, H.P., between 3-way connectors, forward of frame 2, starboard, 3/16" o/d x 22 SWG	1	T.51	C	88/43
	—							RELEASE, PILOT'S EMERGENCY OXYGEN, INSTALLATION (E.G7.71.77) Spares for:—	—	—	—	88/44
34962	E.G7.71.79							RELEASE, EMERGENCY OXYGEN, ASSEMBLY Spares for:—	1	—	B	88/45
34485	E.B6.71.591							CABLE, emergency release, assembly	1	—	C	88/46

SERVICES
OXYGEN SYSTEM

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
26DK/33179	E.G7.71.83							LABEL, engraved, "ON/OFF INTERNAL LIGHTS ECP"	1	L.72	—	88/47
	E.G7.71.151							TUBE and bracket, assembly	1	—	—	88/48
	EEAS.21A/4/DR							WASHER, 'D', clip attachment	12	L.72	—	88/49
	EEAS.21/9/DR							WASHER, 'D', clip attachment	11	L.72	C	88/50
	EEAS.22/2/ERH							WASHER, 'D', clip attachment	4	L.72	—	88/51

A.P.101B-0418-3A		SERVICES PITOT AND STATIC PIPES, CENTRE FUSELAGE					Page NAB1			
Ref. No.	Part No.	Description					No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7		
	—	PITOT AND STATIC PIPES IN CENTRE FUSELAGE, ASSEMBLY (E.A3.80.657)					—	—	—	89/1
		Spares for:—								
28F/13603	AGS.838/8	BUSH, rubber, union					11	—	C	89/2
5526	EEAS.91/3	CLIP, pipe, double, 3/8" o/d					2	L.72	C	89/3
6443	E.A1.80.891	FAIRLEAD, frames 14, 16 and 17					3	LFS.21	C	89/4
		Attaching parts for E.A1.80.891:—								
28D/1011013	A25/13B	Bolt, 4 BA hex. head, frames 14, 15 and 17					2	—	C	89/5
28D/1212276	A25/15B	Bolt, 4 BA hex. head, frame 16					2	—	C	89/6
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA					2	—	C	89/7
28W/9419474	SP.15/B	Washer, 4 BA plain					2	—	C	89/8
		FAIRLEAD, frame 15					1	LFS.21	C	89/9
	7796	Attaching parts for E.A3.80.1655:—								
28D/1011013	A25/13B	Bolt, 4 BA hex. head					2	—	C	89/10
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA					2	—	C	89/11
28W/9419474	SP.15/B	Washer, 4 BA plain					2	—	C	89/12
		NUT, union					11	—	C	89/13
28F/1013780	AGS.838/4	PIPE, static, from transport joint union to drain trap, 5/16" o/d x 22 SWG					1	L.54	—	89/14
	E.A3.80.1637	PIPE, static, from drain trap to A.M.U. coupling, 5/16" o/d x 22 SWG					1	L.54	—	89/15
	E.A3.80.1639	PIPE, pitot, from drain trap to tee union aft of frame 17, 5/16" o/d x 22 SWG					1	L.54	—	89/16
	E.A3.80.1641	PIPE, pitot, from transport joint union to drain trap, 5/16" o/d x 22 SWG					1	L.54	—	89/17
	E.A3.80.1643	PIPE, pitot, from tee union aft of frame 17 to A.M.U. coupling, 5/16" o/d x 22 SWG					1	L.54	—	89/18
	3400	PIPE, drain, reservoir					2	L.54	C	89/19
28F/1046323	AGS.838/6	TRAP, drain					1	—	C	89/20
28F/1046307	AGS.838/1	UNION, body, straight					1	—	C	89/21
28F/1046308	AGS.838/2	UNION, body, tee					3	—	C	89/22
5259	EEAS.21/2/ERH	WASHER, 'D'					14	L.72	C	89/23
28F/11697	AGS.838/7	WASHER, rubber					1	—	C	89/24

SERVICES
PITOT AND STATIC PIPES
IN FRONT FUSELAGE

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6				
R	EG9.80.277	PIPE, static, from tee aft of frame A, to zero reader tee-piece, 5/16" o/d x 22 SWG	1	L54	90/19
R	EG9.80.449	PIPE, pitot, from tee at pilot's flying panel to flexible hose connection, 5/16" o/d x 22 SWG	1	L54	91/9
	EG9.80.451	PIPE, static, between low pressure tees aft of frame 1, 5/16" o/d x 22 SWG	1	L54	91/10
	EG9.80.455	PIPE, static, from low pressure tee at pilot's flying panel to machmeter, 5/16" o/d x 22 SWG	1	L54	91/11
	EG9.80.463	PIPE, static, from flexible hose at pilot's panel to main static line tee aft of frame 1, 5/16" o/d x 22 SWG	1	L54	91/12
	EG9.80.465	PIPE, static, from flexible hose at pilot's panel to main pitot line tee, aft of frame 1, 5/16" o/d x 22 SWG	1	L54	91/13
	EG9.80.467	PIPE, static, from coupling aft of frame 4 to drain trap tee aft of frame 5, 5/16" o/d x 22 SWG	1	L54	90/20
	EG9.80.469	PIPE, pitot, from coupling aft of frame 4 to drain trap tee aft of frame 5, 5/16" o/d x 22 SWG	1	L54	90/21
	EG9.80.471	PIPE, static, from drain trap tee, to tee for navigator's panel run, forward of frame 6, 5/16" o/d x 22 SWG	1	L54	90/22
	EG9.80.473	PIPE, pitot, from drain trap tee to tee for navigator's panel run, forward of frame 6, 5/16" o/d x 22 SWG	1	L54	90/23
	EG9.80.475	PIPE, static, from tee forward of frame 6, to adaptor outlet at pressure bulkhead, 5/16" o/d x 22 SWG	1	L54	90/24
	EG9.80.477	PIPE, pitot, from tee forward of frame 6 to adaptor outlet at pressure bulkhead, 5/16" o/d x 22 SWG	1	L54	90/25
	EG9.80.479	PIPE, pitot, from tee to coupling, navigator's panel pipe run, forward of frame 6, 5/16" o/d x 22 SWG	1	L54	90/26
	EG9.80.481	PIPE, static, from tee to coupling, navigator's panel pipe run, forward of frame 6, 5/16" o/d x 22 SWG	1	L54	90/27
	EG9.80.497	PIPE, static, from low pressure tee to elbow at altimeter, navigator's panel pipe run, 5/16" o/d x 22 SWG (Mod. 4866 Part A)	1	L54	90/28
	EG4.80.517	PIPE, pitot, assembly (Mod. 4866 Part A)	1	—	
	EG4.80.1071	PIPE, static, assembly (Mod. 4866 Part A)	1	—	
	EG4.80.1073	PIPE, static, assembly (Mod. 4866 Part A)	1	—	
	EG4.80.1075	PIPE, static, assembly (Mod. 4866 Part A)	1	—	
	EG4.80.1081	PIPE, static, assembly (Mod. 4866 Part A)	1	—	
	EG4.80.1083	PIPE, static, assembly (Mod. 4866 Part A)	1	—	

AP 101B-0418-3A

SERVICES
PITOT AND STATIC PIPES
IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EG9.80.499	. PIPE, pitot, from hose connection to tee at A.S.I. navigator's panel pipe run, 5/16" o/d x 22 SWG	1	L54	90/29
EG9.80.501	. PIPE, static, from hose connection to tee at A.S.I. navigator's panel pipe run, 5/16" o/d x 22 SWG	1	L54	90/30
EG9.80.503	. PIPE, pitot, from coupling to hose connection, for navigator's panel, between frames 5 and 6, 5/16" o/d x 22 SWG	1	L54	90/31
EG9.80.505	. PIPE, static, from coupling to hose connection, for navigator's panel, between frames 5 and 6, 5/16" o/d x 22 SWG	1	L54	90/32
R EA3.80.1571	. PIPE, static, from tee at centre line to starboard static vent, forward of frame A (Pre Mod 5197)	1	L54	91/14
R EA3.80.6683	. PIPE, static, assembly, 5/16" o/d x 22 SWG	1	L54	
R EA3.80.1573	. PIPE, static, from tee at centre line to port static vent, forward of frame A (Pre Mod 5197)	1	L54	91/15
R EA3.80.6681	. PIPE, static, assembly, 5/16" o/d x 22 SWG (Mod 5197)	1	L54	
EA3.80.1575	. PIPE, static, from static vent tee to tee for zero reader and main static line, between frame A and frame 1	1	L54	91/16
EA3.80.1579	. PIPE, static, between tee and drain trap tee, frame 1	1	L54	91/17
EA3.80.1581	. PIPE, static, from drain trap tee frame 1 to tee for run to pilot's flying panel	1	L54	91/18
EA3.80.1603	. PIPE, static, from drain trap tee aft of pressure bulkhead to coupling aft of frame 12	1	L54	90/33
EA3.80.1617	. PIPE, pitot, from drain trap tee aft of frame 1 to tee for run to pilot's flying panel	1	L54	90/35
EA3.80.1745	. PIPE, pitot, from coupling aft of frame A to tee at frame 1	1	L56	90/36
EA3.80.2385	. PIPE, pitot, from drain trap tee, frame A to coupling aft of frame A	1	L56	90/37
EA3.80.1751	. PIPE, pitot, between tee unions, frame 1	1	L54	90/38
EB6.80.679	. PIPE, pitot, from connection aft of bomb aimer's window to drain tee, frame A	1	L54	90/39
EB6.80.681	. PIPE, pitot, from drain trap tee frame A, to union adapter	1	L54	90/40
EA3.80.2389	. PIPE, pitot, from pressure head to coupling, aft of bomb aimer's window	1	L56	90/41
EA3.80.2737	. PIPE, static, from tee aft of frame 1 to drain trap tee aft of frame 4	1	L54	90/42
EA3.80.2739	. PIPE, pitot, from tee aft of frame 1 to tee aft of frame 4	1	L54	90/43
EG9.80.1113	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EG4.80.1149	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EG9.80.1105	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EB6.80.675	. PIPE, static, from drain trap tee to zero reader hose coupling forward of frame 1	1	L54	90/44
EG9.80.1157	. PIPE, flex, static assembly (Mod 4866 Part A)	1	—	
EG9.80.1139	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EG9.80.1141	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EG9.80.1143	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EA3.80.6563	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EA3.80.6603	. PIPE, flex, static, assembly (Mod 4866 Part A)	1	—	
EG7.80.2071	. PIPE, static, assembly (Mod 4866 Part A)	1	—	
EG4.80.1057	. PIPE, static, assembly (Mod 4866 Part B)	1	—	
EG9.80.1109	. PIPE, static, assembly (Mod 4866 Part B)	1	—	
EG9.80.1107	. PIPE, flex, static, assembly (Mod 4866 Part B)	1	—	
EG9.80.1111	. PIPE, flex, static, assembly (Mod 4866 Part B)	1	—	

SERVICES
PITOT AND STATIC PIPES
IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EEAS20/2/CR	. TAB, locking	1	L72	90/45
EA3.80.1671	. TUBE, adapter, 5/16" o/d x 20 SWG	5	L54	91/19
AS2811/5/09	. TUBE, distance, for clip at flying panel	1	L62	91/20
AS2811/5/10	. TUBE, distance, for clip at flying panel	1	L62	91/21
EG9.80.281	. TUBE, flexible rubber, static, for navigator's panel, ".30 i/d x 9/16" o/d x 8" long (Make from 32C/679)	1	Maricon Type H	90/46
EG9.80.287	. TUBE, flexible, rubber, static line to zero reader, 15" long (Make from Dunlop AH-032434/30.8)	1	—	90/47
EG9.80.519	. TUBE, flexible rubber, pitot line to pilot's panel, ".30 i/d x 9/16" o/d x 10" long (Make from 32C/679)	1	Maricon Type H	91/22
EG9.80.989	. TUBE, flexible rubber, pitot, for navigator's panel, ".30 i/d x 9/16" o/d x 6".5 long (Make from 32C/679)	1	Maricon Type H	90/48
EA3.80.2839	. TUBE, flexible rubber (Make from 32C/679)	1	Maricon Type H	91/23
EA1.80.711	. UNION, bulkhead, pitot static lines at pressure bulkhead Attaching parts for EA1.80.711:—	1	L65	91/24
A25/2B	. Bolt, 4 BA hex. head	6	—	91/25
AGS2001/B/1	. Nut, stiff, 4 BA	6	—	91/26
EA1.80.713	. Ring, sealing	1	Neo-K-Tex	91/27
SP13/B	. Washer, 4 BA plain	12	—	91/28
AGS1115/3	. Washer, plate	1	—	91/29
KOLLSMAN L83271-00-000	. UNIT, pressure error correction	1	—	
EA3.80.1997	. VENT, static, assembly (Pre Mod 5197) Spares for:—	2	—	91/30
EA3.80.2001	. . PACKING	1	—	91/31
EA3.80.2005	. . PLATE, clamping	1	—	91/32
EA3.80.2003	. . SEALING	1	—	91/33
EA3.80.1999	. . VENT, static Spares for:—	1	—	91/34
EA3.80.1769	. . . BUSH Attaching parts for EA3.80.1997:—	1	—	91/35
BA4	. Nut, aerotight, 4 BA	4	—	91/36
AGS1582C	. Washer, 4 BA	4	—	91/37
EB7.80.769	. VENT, static, assembly, port (Mod 5197)	1	—	91/38
EB7.80.770	. VENT, static, assembly, stbd (Mod 5197) Spares for:—	1	—	91/39
EB7.80.777	. . PACKING, port and stbd	1	—	91/40
EB7.80.773	. . PLATE, clamping, port	1	—	91/41
EB7.80.774	. . PLATE, clamping, stbd	1	—	91/42
EB7.80.775	. . SEAL, port and stbd	1	—	91/43
EB7.80.771	. . VENT, static, port	1	—	91/44
EB7.80.772	. . VENT, static, stbd Attaching parts for EB7.80.769 or EB7.80.770:—	1	—	91/45
EA9.80.1179 or	. Bolt, special	4	—	91/46
EA9.80.1273	. Bolt, special	4	—	
AGS2001B4	. Nut, stiff, 4 BA	4	—	91/47
AGS1582C	. Washer, plain, 4 BA	4	—	91/48
EEAS21/2/DO	. WASHER, 'D' pipe clip from pressure head	1	L59	
EEAS21/4/ER/H	. WASHER, 'D', for bonding clips	2	L72	
EEAS239/1/AH	. WASHER, 'D', for bonding clips	5	L72	90/49

AP101B-0418-3A

SERVICES
PITOT AND STATIC PIPES,
PORT MAINPLANE

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
—	PITOT AND STATIC PIPES, IN PORT MAINPLANE ASSEMBLY (EA3.80.659)						—	—	92/1
	Spares for:—								
R AGS838/8	. BUSH, rubber (Mod. 5198)						12	—	92/5
R AGS838/9	. BUSH, rubber (Mod. 5198)						2	—	92/6
R EEAS91/2	. CLIP (Mod. 5198)						4	—	92/7
—	. MOUNTING OF AIR MILEAGE UNIT, ASSEMBLY (EA1.80.781)						—	—	92/2
	Spares for:—								
R 6B4343636	. UNIT, air mileage, Mk. 4A						1	—	92/3
	Attaching parts for 6B/4343636:—								
A25/3C	. Bolt, 2 BA hex. head						6	—	92/4
R AGS838/4	. NUT, union (Mod. 5198)						12	—	92/8
R EB2.70.1037	. PIECE, spacing (Mod. 5198)						2	—	92/9
EA3.80.659E	. PIPE, drain, reservoir, 5/16" o/d x 22 SWG						2	L54	92/10
R AGS838/6	. TRAP, drain (Mod. 5198)						2	—	92/11
EA3.80.1817	. TUBE, pitot, from drain trap to A.M.U.						1	L54	92/12
EA3.80.1823	. TUBE, pitot, from drain trap to wing fuselage coupling						1	L54	92/13
EA3.80.1819	. TUBE, static, from drain trap to A.M.U.						1	L54	92/14
EA3.80.1821	. TUBE, static, from drain trap to wing fuselage coupling						1	L54	92/15
AGS838/2	. UNION, body, tee						4	—	92/16

A.P.101B-0418-3A		SERVICES AIR VENTILATED SUIT SYSTEM IN CENTRE FUSELAGE					Page N1	
Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index		
		1 2 3 4 5 6 7						
	—	AIR VENTILATED SUIT SYSTEM IN CENTRE FUSELAGE, ASSEMBLY (E.G9.75.57) Spares for:—	—	—	—			
40653	E.A3.75.643	BRACKET, attachment, for pipe clips	6	L.72	C	1/1		
6734	EEAS.136	BRACKET, attachment, for clips	3	L.72	C	1/2		
32774	E.A3.73.971	CLAMP, pipe, forward face of frame 13	1	LFS.21, 23 or 26	C	1/3		
		Attaching parts for E.A3.73.971:—						
28D/1212276	A25/15B	Bolt, 4 BA hex. head	2	—	C	1/4		
28M/9403519	A27/BP	Nut, 4 BA plain	2	—	C	1/5		
28W/9416642	SP.47/B	Washer, 4 BA spring	2	—	C	1/6		
	E.G9.75.71	CLIP, U, pipe saddle at frames 20 and 21	2	L.72	—	1/7		
		Attaching parts for E.G9.75.71:—						
28D/1017157	A25/25C	Bolt, 2 BA hex. head (at frame 20)	2	—	C	1/8		
28D/1212399	A25/28C	Bolt, 2 BA hex. head (at frame 21)	1	—	C	1/9		
28D/1212400	A25/29C	Bolt, 2 BA hex. head (at frame 21)	1	—	C	1/10		
28W/9419402	SP.13/C	Washer, 2 BA plain	3	—	C	1/11		
	E.G9.75.73	CLIP, U, pipe saddle, at frame 23	1	L.72	—	1/12		
	E.G9.75.69	Attaching parts for E.G9.75.73:— Block, packing	1	BS.2572 Type F3	—	1/13		
28D/9133013	A25/5C	Bolt, 2 BA hex. head	2	—	C	1/14		
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	2	—	C	1/15		
28W/9419402	SP.13/C	Washer, 2 BA plain	4	—	C	1/16		
	E.G9.75.75	CLIP, 'P', frames 22, 23 and 24	3	L.72	—	1/17		
	—	CUT-IN, COLD AIR, PIPE RUN ACROSS BOMB BAY, AFT OF FRAME 20, INSTALLATION (E.A3.75.585) Spares for:—	—	—	—			
15181	E.B6.75.213	CLIP, pipe saddle	2	L.72	C	1/18		
		Attaching parts for E.B6.75.213:—						
28D/9133012	A25/3C	Bolt, 2 BA hex. head	2	—	C	1/19		
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	2	—	C	1/20		
28474	E.B6.75.593	Packing, fibre	2	LFS.21	C	1/21		
28W/9419475	SP.15/C	Washer, 2 BA plain	2	—	C	1/22		
32775	E.A3.75.605	PIPE, assembly, from starboard wing connection to tee joint	1	L.56	C	2/1		
32776	E.A3.75.607	PIPE, assembly, from tee joint to coupling, port	1	T.26	C	2/2		
15183	E.B6.75.219	PIPE, assembly, from coupling to port wing connection	1	L.56	C	2/3		
1438788	E.G9.75.63	FAIRLEAD, assembly, frame 19	1	BS.2572 Type F3	C	1/23		
		Attaching parts for E.G9.75.63:—						
28D/9140649	A25/23C	Bolt, 2 BA hex. head	2	—	C	1/24		
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	2	—	C	1/25		
	E.G9.75.87	Strip, capping	1	L.72	LM	1/26		
28W/9419402	SP.13/C	Washer 2 BA plain	4	—	C	1/27		

SERVICES
AIR VENTILATED SUIT SYSTEMS
IN CENTRE FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1 2 3 4 5 6 7				
1438789	E.G9.75.65	FAIRLEAD, frame 20 and 21	2	BS.2572 Type F3	C	1/28
32764	E.G9.75.127	PACKING, fairlead, at frame 22	1	L.72	—	1/29
	E.A3.04.14151	PIPE, assembly, from coupling forward of frame 13, to coupling aft of frame 13, port	1	L.54	C	2/4
32765	E.A3.04.14153	PIPE, assembly, from coupling aft of frame 13, to coupling aft of frame 17, port	1	L.54	C	2/5
32773	E.A3.04.14215	PIPE, assembly, from coupling aft of frame 17, port, to water extractor	1	L.54	C	2/6
32769	E.A3.75.599	PIPE, bend, assembly, from water extractor forward of frame 20	1	L.54 or L.59	C	2/7
1439021	E.G9.75.121	PIPE, assembly, from water extractor bend pipe, forward of frame 20 to coupling forward of frame 21, port	1	L.54	C	2/8
32768	E.A3.75.597	PIPE, assembly, from tee piece aft of frame 20 to coupling forward of frame 22, starboard	1	L.54	C	2/9
1438791	E.G9.75.61	PIPE, assembly, from coupling forward of frame 21, to coupling aft of frame 24, port	1	L.54	C	2/10
32767	E.A3.75.595	PIPE, assembly, from coupling forward of frame 22 to coupling aft of frame 24, starboard	1	L.54	C	2/11
32771	E.A3.75.629	PIPE, assembly, from coupling aft of frame 24 to coupling aft of frame 28, port	1	L.54	C	2/12
32766	E.A3.75.593	PIPE, assembly, from coupling aft of frame 24 to coupling aft of frame 28, starboard	1	L.54	C	2/13
32760	E.A3.75.631	PIPE, assembly, transverse, bend, from coupling aft of frame 28, port, to centre coupling forward of frame 29	1	—	C	2/14
32772	E.A3.75.633	PIPE, assembly, transverse, bend, from coupling aft of frame 28, starboard, to centre coupling forward of frame 29	1	—	C	2/15
	—	SEPARATOR, WATER, INSTALLATION (E.G9.75.129) Spares for:—	—	—	—	
32752	E.A3.04.14131	BRACKET, assembly	1	L.72	—	2/16
	E.A3.04.14133	CHANNEL, assembly	1	L.72	—	2/17
	E.A3.04.14141	CHANNEL	1	L.72	—	2/18
	E.A3.04.14143	CLIP, attachment, for water extractor Attaching parts for E.A3.04.14143:—	1	—	C	2/19
28D/9436920	A25/1C	Bolt, 2 BA, hex. head	2	—	C	2/20
28W/9419402	E.A3.04.14201	Pad, stress	2	—	—	2/21
	SP.13/C	Washer, 2 BA, plain	2	—	C	2/22
32751	E.A3.75.613	CONNECTION, water extractor vent pipe	1	L.65	C	2/23
27UA/1952	GODFREY 119013	EXTRACTOR, water, WE5, Mk. 4	1	—	A	2/24
32750	E.A3.04.14145	PIPE, assembly, water extractor vent	1	—	C	2/25
981	EEAS.20/2/DR	TAB, locking	1	L.72	C	2/26
5259	EEAS.21/2/ERH	WASHER, 'D', clip attachments	34	L.72	C	1/30

A.P.101B-0418-3A

SERVICES
AIR VENTILATED SUIT SYSTEM
IN FRONT FUSELAGE

Page NA1

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1 2 3 4 5 6 7				
	—	AIR VENTILATED SUIT SYSTEM IN FRONT FUSELAGE, ASSEMBLY (E.G9.75.5) Spares for:—	—	—	—	3/1
	—	CONNECTION AT FRAME 12, INSTALLATION (E.G9.75.9) Consisting of:—	—	—	—	3/2
28D/9133011	A.25/2C	BOLT, 2 BA hex. head	6	—	C	3/3
28F/9486111	AGS.1142/H	NIPPLE, adaptor, 1" o/d pipe	1	—	C	3/4
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA	6	—	C	3/5
26DK/24406	EEAS.20/9/DR	TAB, locking	1	L.72	C	3/6
32745	E.A3.04.14101	WASHER, plate	1	—	C	3/7
	—	CONNECTION, PIPE, PRESSURE BULKHEAD, ASSEMBLY (E.A3.04.14015) Spares for:—	—	—	—	4/1
28F/9996122	AGS.1112/H	BODY, union, flanged bulkhead	1	—	C	4/2
		Attaching parts for AGS.1112/H:—				
28D/9133011	A.25/2C	Bolt, 2 BA hex. head	6	—	C	4/3
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	6	—	C	4/4
26DK/4762	EEAS.20/3/DU	Tab, locking	2	S.515	C	4/5
28F/14657	AGS.1115/10	Washer, plate	1	—	C	4/6
37856	E.A4.75.253	Washer, sealing	1	—	C	4/8
28W/9419402	SP.13/C	Washer, 2 BA plain	6	—	C	4/7
33350	E.B6.75.1037	DUCTING "FLEXFLYTE", from pilot's control valve tapered pipe to connection at pressure bulkhead	1	—	C	3/8
26DK/10317	EE.11/2 E.G9.75.19	EXTRUSION, section PIPE, assembly, from coupling, forward of frame 11 to connection at frame 12, 1" o/d x 22 SWG	QR 1	— L.54	C —	3/9 3/10
	E.G9.75.21	PIPE, assembly, from coupling at frame 10 to coupling forward of frame 11, 1" o/d x 22 SWG	1	L.54	—	3/11
1438779	E.G9.75.23	PIPE, assembly, from coupling at frame 10, to pressure bulkhead, 1" o/d x 22 SWG	1	L.54	C	3/12
	—	PIPES, GROUND SUPPLY CONNECTION, PRESSURE RELIEF AND REDUCING VALVES, FRAMES 12-13, INSTALLATION (E.G9.75.35) Spares for:—	—	—	—	4/9
32759	E.A3.04.14221	BLOCK, mounting, pressure relief valve Attaching parts for E.A3.04.14221:—	1	—	C	4/10
28D/1011023	A.25/20C	Bolt, 2 BA hex. head	2	—	C	4/11
28W/9419475	SP.15/C	Washer, 2 BA plain	2	—	C	4/12
	E.G9.75.41	BRACKET, assembly Attaching parts for E.G9.75.41:—	1	L.72	—	4/13
28D/9436920	A.25/1C	Bolt, 2 BA hex. head	2	—	C	4/14
28M/9403520	A.27/CP	Nut, 2 BA plain	2	—	C	4/15
28W/9419475	SP.15/C	Washer, 2 BA plain	2	—	C	4/16

SERVICES
AIR VENTILATED SUIT SYSTEM
IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6 : 7				
28D/9133011	A.25/2C	Attaching parts for E.C4.75.19 or						2	—	C	4/41
28M/1278190	AGS.2001/C/1	E.A3.75.609:—						1	—	C	4/42
28W/9419402	SP.13/C	Bolt, 2 BA hex. head						2	—	C	4/43
		Nut, stiff, 2 BA									
		Washer, 2 BA plain									
26DK/36439	EEAS.21A/8/ER	WASHER, 'D', clip attachment						1	L.72	C	4/44

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	CABIN PRESSURE SYSTEM IN FRONT FUSELAGE, ASSEMBLY (EG9.75.3) Spares for:—	—	—	
EA3.75.83	. ADAPTER, non-return valve mounting	1	Mag. Alloy	5/1
R GODFREY 22688	. ADAPTER, water extractor drain	1	—	6/1
EA3.75.177	. BRACKET, pipe support clip	4	L72	7/1
EA3.75.283	. BRACKET, pipe mounting	1	L72	7/2
EA3.75.547	. BRACKET, pipe support clip	1	L72	5/2
EB6.75.369	. BRACKET, water extractor forward support Attaching parts for EB6.75.369:—	1	L72	6/2
A25/11C	. Bolt, 2 BA hex. head	4	—	6/3
AGS2001/C/1	. Nut, stiff, 2 BA	4	—	6/4
AS2811/5/093	. Piece, distance	4	L62	6/5
SP15/C	. Washer, 2 BA plain	4	—	6/6
EB6.75.591	. BRACKET, water extractor aft support Attaching parts for EB6.75.591:—	1	L72	6/7
A25/11C	. Bolt, 2 BA hex. head	4	—	6/8
AGS2001/C/1	. Nut, stiff, 2 BA	4	—	6/9
AS2811/5/093	. Piece, distance	4	L62	6/10
SP15/C	. Washer, 2 BA plain	4	—	6/11
EB6.75.621	. BRACKET, pipe support clip, aft of frame 1 Attaching parts for EB6.75.621:—	1	L72	6/12
AS1246/1/2B	. Bolt, 4 BA round head	2	—	6/13
AGS2001/B/2	. Nut, stiff, 4 BA	2	—	6/14
EB6.75.699	. BRACKET, pipe support, frame 12A Attaching parts for EB6.75.699:—	1	L72	6/15
A25/1B	. Bolt, 4 BA hex. head	1	—	6/16
A25/1C	. Bolt, 2 BA hex. head	1	—	6/17
AGS2001/B/1	. Nut, stiff, 4 BA	1	—	6/18
AGS2001/C/1	. Nut, stiff, 2 BA	1	—	6/19
SP15/B	. Washer, 4 BA plain	1	—	6/20
SP15/C	. Washer, 2 BA plain	1	—	6/21
EEAS136	. BRACKET, pipe support clip	1	—	7/3
—	. CABIN PRESSURE STATIC LINE, ASSEMBLY (EG9.75.109) Spares for:—	—	—	8/1
EEAS136	. . BRACKET, pipe support clip	3	—	8/2
EA3.80.2473	. . BRACKET, clip support, frame 7 Attaching parts for EA3.80.2473:—	1	—	8/3
A25/1B	. . Bolt, 4 BA hex. head	2	—	8/4
A27/BP	. . Nut, 4 BA plain	2	—	8/5
SP47/B	. . Washer, 4 BA spring	2	—	8/6
EEAS91/2	. . CLIP, pipe, double	13	L72	8/7
EEAS143/7 or	. . CLIP, pipe, single (Pre Alt.R60/91 — Mod 5102)	8	L72	8/8
AS4525/5	. . CLIP, pipe (Alt. R60/91 — Mod 5102)	8	—	8/8
EG9.80.537	. . PIPE, static vent, from coupling aft of frame 4 to coupling aft of frame 5, 5/16" o/d x 22 SWG	1	L54	8/9

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG9.80.539		. . PIPE, static, vent, from coupling aft of frame 5 to coupling aft of frame 7, 5/16" o/d x 22 SWG	1	L54	8/10
EG9.80.541		. . PIPE, static vent, from coupling aft of frame 7 to drain pipe tee at pressure bulkhead, 5/16" o/d x 22 SWG	1	L54	8/11
EA3.80.1649		. . PIPE, drain, from tee aft of frame A, and tee pressure bulkhead	2	L54	8/12
EA3.80.1965		. . PIPE, static vent, from tee to master control valve, at pressure bulkhead	1	L56	8/13
EA3.80.1971		. . PIPE, static vent, from drain trap tee aft of frame A to coupling aft of frame 4, 5/16" o/d x 22 SWG	1	L56	8/14
EA3.80.1973		. . PIPE, static vent, from tee piece at frame 'B', to tee piece aft of frame 'A', 5/16" o/d x 22 SWG	1	L56	8/15
R EA3.80.1975		. . PIPE, static vent, from tee piece at frame 'B', to static vent connection in fuselage skin, port, 5/16" o/d x 22 SWG (Pre Mod 5197)	1	L56	8/16
R EA3.80.6685		. . PIPE, static, assembly, 5/16" o/d x 22 SWG (Mod 5197)	1	L54	
R EA3.80.1977		. . PIPE, static vent, from tee piece at frame 'B', to static vent connection in fuselage skin, starboard, 5/16" o/d x 22 SWG (Pre Mod 5197)	1	L56	8/17
R EA3.80.6687		. . PIPE, static, assembly, 5/16" o/d x 22 SWG	1	L54	
EA1.75.105		. CLIP, pipe, frames 2 and 6 Attaching parts for EA1.75.105:—	2	L72	7/4
A25/1C		. Bolt, 2 BA hex. head	2	—	7/5
AGS2001/C/1		. Nut, stiff, 2 BA	2	—	7/6
SP15/C		. Washer, 2 BA plain	2	—	7/7
EA2.75.37		. CLIP, pipe, 1-1/2" dia. Attaching parts for EA2.75.37:—	5	L72	7/8
A25/1C		. Bolt, 2 BA hex. head	2	—	7/9
AGS2001/C/1		. Nut, stiff, 2 BA	2	—	7/10
SP15/C		. Washer, 2 BA plain	2	—	7/11
EB6.75.623		. CLIP, pipe Attaching parts for EB6.75.623:—	1	S3	7/12
AS1246/1/2B		. Bolt, 4 BA round head	2	—	7/13
AGS2001/B/2		. Nut, stiff, 4 BA	2	—	7/14
EEAS143/26 or AS4525/16		. CLIP 'P', pipe support (Pre Alt.R60/91 — Mod 5102)	1	L72	5/3
A25/1B		. CLIP, 'P' (Alt R60/91 — Mod 5102) Attaching parts for EEAS 143/26:—	1	L72	5/3
		. Bolt, 4 BA hex. head	1	—	5/4
EB7.75.125		. CONNECTOR, flanged, main pipe, frame 3 Attaching parts for EB7.75.125:—	1	L44	7/15
A25/2B		. Bolt, 4 BA hex. head	6	—	7/16
AGS2001/B/1		. Nut, stiff, 4 BA	6	—	7/17
EB7.75.129		. Ring, half bolt	2	L59	7/18
SP15/B		. Washer, 4 BA plain	6	—	7/19

A.P.101B-0418-3A

Page NB3

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
6977	E.B7.75.126	CONNECTOR, flanged, main pipe, frame 4							1	L.44	C	7/20
28D/1008149	A25/2B	Attaching parts for E.B7.75.126:—							6	—	C	7/21
28M/1278189	AGS.2001/B/1	Bolt, 4 BA hex. head							6	—	C	7/22
18659	E.B7.75.129	Nut, stiff, 4 BA							2	L.59	C	7/23
28W/9419474	SP.15/B	Ring, half bolt							6	—	C	7/24
6978	E.B7.75.127	CONNECTOR, flanged, main pipe, frame 5							1	L.44	C	7/25
28D/1008149	A25/2B	Attaching parts for E.B7.75.127:—							6	—	C	7/26
28M/1278189	AGS.2001/B/1	Bolt, 4 BA hex. head							6	—	C	7/27
18660	E.B7.75.131	Nut, stiff, 4 BA							2	L.59	C	7/28
28W/9419474	SP.15/B	Ring, half bolt							6	—	C	7/29
6504	E.B6.75.379	COUPLING, water extractor drain pipe, frame 11							1	L.65	C	6/22
	—	DEMISTER, INNER CANOPY, ASSEMBLY							—	—	—	9/1
		(E.G9.76.63)										
		Spares for:—										
4612	E.A3.76.241	FLANGE, assembly							1	—	C	9/2
1438990	E.G9.76.45	PIPE, demister, assembly							1	L.54	B	9/3
4614	E.A3.76.223	VALVE, butterfly							1	—	B	9/4
	—	DIFFUSER, PILOT'S, ASSEMBLY (E.B7.75.63)							—	—	—	9/5
		Spares for:—										
19913	E.B7.75.29	BRACKET, diffuser mounting							1	L.59	C	9/6
28D/1007979	AS.1246/1B	Attaching parts for E.B7.75.29:—							2	—	C	9/7
28M/1278189	AGS.2001/B/1	Bolt, 4 BA round head							2	—	C	9/8
28W/9419465	SP.13/B	Nut, stiff, 4 BA							2	—	C	9/9
19914	E.B7.75.31	CLIP, diffuser retaining							1	L.59	C	9/10
28D/9140645	A25/10C	Attaching parts for E.B7.75.31:—							1	—	C	9/11
28M/1278190	AGS.2001/C/1	Bolt, 2 BA hex. head							1	—	C	9/12
18185	AS.2811/5/095	Nut, stiff, 2 BA							1	L.62	C	9/13
28W/9419402	SP.13/C	Tube, distance							1	—	C	9/14
6980	E.B7.75.23	DIFFUSER, assembly							1	—	C	9/15
R 27UA/4611972	GODFREY 22697/B	EXTRACTOR, water, type WE30, Mk. 2B							1	—	A	6/23
		Attaching parts for 22697/B:—										
16568	E.B6.75.397A	Lagging							1	L.44	C	10/1
16569	E.B6.75.399A	Lagging							1	L.44	C	10/2
12027	E.B7.75.83	FAIRLEAD, navigator's fishtail connecting pipe at frame 3							1	LFS.21	C	
28D/1008149	A25/2B	Attaching parts for E.B7.75.83:—							4	—	C	
28M/1278189	AGS.2001/B/1	Bolt, 4 BA hex. head							4	—	C	
		Nut, stiff, 4 BA										

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	FAIRLEAD, AT FRAME A, INSTALLATION (E.G9.75.113) Consisting of:—							—	—	—	11/1
1438796	E.G9.75.115	FAIRLEAD, assembly							1	BS.2572 F.3	C	11/2
28D/1011026	A25/26C	Attaching parts for E.G9.75.115:—							2	—	C	11/3
28M/1278190	AGS.2001/C/1	Bolt, 2 BA hex. head							2	—	C	11/4
	—	NUT, stiff, 2 BA							—	—	—	11/5
5722	E.B7.75.21	FISHTAIL PILOT'S, ASSEMBLY (E. B7.75.59) Consisting of:—							1	L.59	C	11/6
28D/1010658	A25/1B	FISHTAIL							4	—	C	11/7
34918	E.G7.75.249	Attaching parts for E.B7.75.21:—							1	L.59	C	11/8
28D/9436920	A25/1C	Bolt, 4 BA hex. head							1	—	C	11/9
28M/1278190	AGS.2001/C/1	FISHTAIL, navigator's, frame 5							1	—	C	11/10
28W/9419475	SP.15/C	Attaching parts for E.G7.75.249:—							1	—	C	11/11
	—	Bolt, 2 BA hex. head							1	—	C	11/12
R 1438797	E.G9.75.105	Nut, stiff, 2 BA							1	Bells Asbestos	B	11/12
	—	Washer, 2 BA plain							1	—	—	11/13
R	E.K5.75.425	HOSE, flexible, from main branch pipe, frame 2 to frame 4, for pilot's diffuser and navigator's fishtail and louvre (Bells BAS.102/1/1" bore x 57" .5 long) (Pre-Mod. 5236)							1	—	—	11/13
	—	HOSE, flexible (Mod. 5236)							—	—	—	11/14
16606	E.B7.75.41	LOUVRE, PILOT'S (PEDAL GUARD), ASSEMBLY (E.B7.75.61) Spares for:—							1	L.72	C	11/14
28D/9140202	AS.1246/1C	BRACKET, punkah louvre mounting							3	—	C	11/15
28M/1278190	AGS.2001/C/1	Attaching parts for E.B7.75.41:—							3	—	C	11/16
5042	THERMO TANKS DAR.2	Bolt, 2 BA round head							1	—	C	11/17
28D/1213215	AS.2922/4B	LOUVRE, "punkah"							3	—	C	11/18
28M/1278189	AGS.2001/B/1	Attaching parts for DAR.2:—							3	—	C	11/19
28W/9143227	SP.14/B	Bolt, 4 BA round head							3	—	C	11/20
	—	Nut, stiff, 4 BA							—	—	—	12/1
12028	E.B7.75.33	Washer, 4 BA plain							1	L.59	C	12/2
28D/7002428	A25/6C	LOUVRE, PILOT'S (STARBOARD SIDE), ASSEMBLY (E.B7.75.65) Spares for:—							2	—	C	12/3
28M/1278190	AGS.2001/C/1	BOX, louvre, assembly							2	—	C	12/4
21707	AS.2811/5/046	Attaching parts for E.B7.75.33:—							2	L.62	C	12/5
16604	E.B7.75.35	Bolt, 2 BA hex. head							1	L.72	C	12/6
28D/1010658	A25/1B	Nut, stiff, 2 BA							1	—	C	12/7
28M/1278189	AGS.2001/B/1	Tube, distance							1	—	C	12/8
28S/9008390	4101/10/3/8"	BRACKET, louvre box mounting, L.H.							1	—	C	12/9
28W/9419465	SP.13/B	Attaching parts for E.B7.75.35:—							1	—	C	12/10
	—	Bolt, 4 BA hex. head							1	—	C	12/10
	—	Nut, stiff, 4 BA							1	—	C	12/10
	—	Screw, self tapping, round head							1	—	C	12/10
	—	Washer, 4 BA plain							1	—	C	12/10

A.P.101B—0418—3A

Page NB5

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
16605	E.B7.75.37	BRACKET, louvre box mounting, R.H.						1	L.72	C	12/11
28D/1010658	A25/1B	Attaching parts for E.B7.75.37:—						1	—	C	12/12
28M/1278189	AGS.2001/B/1	Bolt, 4 BA hex. head						1	—	C	12/13
28S/9008390	4101/10/3/8"	Nut, stiff, 4 BA						1	—	C	12/14
28W/9419465	SP.13/B	Screw, self-tapping, round head						1	—	C	12/15
16608	E.B7.75.523	BRACKET, demand, oxygen, hose clip attachment						1	L.72	C	12/16
20635	E.B7.75.55	LOUVRE, punkah, type DAR.2						1	—	C	12/17
28D/1213214	AS.2922/3B	Attaching parts for E.B7.75.55:—						3	—	C	12/18
28W/9143227	SP.14/B	Bolt, 4 BA round head						3	—	C	12/19
—	—	LOUVRE, "PUNKAH", PASSENGER'S, ASSEMBLY (E.G9.75.101)						—	—	—	12/20
5042	THERMO TANKS DAR.2	Spares for:—						1	—	C	12/21
28D/1214866	AS.1246/4B	LOUVRE, "punkah"						3	—	C	12/22
28M/1278189	AGS.2001/B/1	Attaching parts for DAR.2:—						3	—	C	12/23
28W/9419465	SP.13/B	Bolt, 4 BA round head						3	—	C	12/24
1730	E.A3.75.167	NOZZLE, hot air, bomb aimer's window						1	—	C	13/1
5723	E.B7.75.69	PIPE, branch, assembly, for pilot's louvre, passenger's louvre, and canopy demisting						1	L.54	C	13/2
R 28E/9129562	AGS.605/3 or	Attaching parts for E.B7.75.69:—						6	—	C	10/3
R 28E/2027591	SP.91/L	Clip, hose (Pre-Alt. R60/91—Mod. 5102)						6	—	C	10/3
18665	E.B7.75.209A	Clip, hose (Alt. R60/91—Mod. 5102)						1	L.44	C	10/4
18666	E.B7.75.211A	Cover, lagging, outer						1	L.44	C	10/5
18687	E.B7.75.597A	Cover, lagging, outer						2	L.44	C	10/6
5724	E.B7.75.71	PIPE, branch, for pilot's louvre						1	L.54	C	13/3
5730	E.B7.75.89	PIPE, branch, main, between frames 1 and 2						1	L.54	C	13/4
R 28E/9129562	AGS.605/3 or	Attaching parts for E.B7.75.89:—						2	—	C	10/7
R 28E/2027591	SP.91/L	Clip, hose (Pre-Alt. R60/91—Mod. 5102)						6	—	C	10/3
R 28E/9130219	AGS.605/4 or	Clip, hose (Alt. R60/91—Mod. 5102)						3	—	C	10/8
R 28E/4710971	SP.91/N	Clip, hose (Pre-Alt. R66/91—Mod. 5102)						3	—	C	10/8
16616	E.B7.75.205A	Clip, hose (Alt. R60/91—Mod. 5102)						2	L.44	C	10/9
16638	E.B7.75.511A	Cover, lagging, outer						1	L.44	C	10/10
18684	E.B7.75.513A	Cover, lagging, outer						1	L.44	C	10/11
1438798	E.G9.75.89	PIPE, branch, assembly, run to navigator's louvre and pilot's diffuser, frame 4, port						1	L.54	B	13/5
5728	E.B7.75.79	PIPE, flanged, canopy demisting, aft of frame 2						1	L.54	C	13/6
R 28E/9129092	AGS.605/2 or	Attaching parts for E.B7.75.79:—						3	—	C	10/12
R 28E/6250283	SP.91/J	Clip, hose (Pre-Alt. R60/91—Mod. 5102)						3	—	C	10/12
18670	E.B7.75.219A	Clip, hose (Alt. R60/91—Mod. 5102)						1	L.44	C	10/13
37441	E.B7.75.805A	Cover, lagging, outer						1	L.44	C	10/14

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
1438799	E.G9.75.91	PIPE, branch, assembly, for navigator's fishtail and pilot's diffuser, frame 4							1	L.54	B	13/7
1438800	E.G9.75.93	PIPE, assembly, for navigator's fishtail							1	L.54	C	13/8
5737	E.B7.75.223	PIPE, flexible (Pre-Mod. 5236)							1	—	C	13/9
	E.A3.75.685	PIPE, flexible (Mod. 5236)							1	—	—	
5742	E.B7.75.233	PIPE, flexible (Pre-Mod. 5236)							1	—	C	13/10
	E.A3.75.677	PIPE, flexible (Mod. 5236)							1	—	—	
5743	E.B7.75.237	PIPE, flexible (Pre-Mod. 5236)							1	—	C	13/11
	E.A3.75.679	PIPE, flexible (Mod. 5236)							1	—	—	
	E.A3.04.11029	PIPE, flexible (Pre-Mod. 5236)							1	—	—	
	E.A3.75.701	PIPE, flexible (Mod. 5236)							1	—	—	
	E.A3.04.11899	PIPE, flexible (Pre-Mod. 5236)							1	—	—	
	E.A3.75.705	PIPE, flexible (Mod. 5236)							1	—	—	
1738	E.A3.75.279	PIPE, bend, between nose frames A and B							1	L.54	C	13/12
1739	E.A3.75.281	PIPE, bend at nose frame B							1	L.54	C	13/13
1336	E.A3.75.287	PIPE, assembly, from pressure control valve to master unit, at pressure bulkhead							1	L.56	C	13/14
5900	E.B6.75.367	PIPE, assembly, water extractor drain							1	—	C	6/24
20866	E.B6.75.687	PIPE, bend, from non-return valve to hose coupling at frame 9							1	L.44	C	13/15
28E/9130219	AGS.605/4	Attaching parts for E.B6.75.687:—										
	or	Clip, hose (Pre-Alt. R60/91—Mod. 5102)							2	—	C	10/15
28E/4710971	SP.91/N	Clip, hose (Alt. R60/91—Mod. 5102)							2	—	C	
16564	E.B6.75.385	Cover, lagging, outer							1	L.44	C	10/16
16565	E.B6.75.387	Cover, lagging, outer							1	L.44	C	10/17
20867	E.B6.75.689	PIPE, bend, from hose coupling to water extractor forward coupling							1	L.44	C	13/16
28E/9130219	AGS.605/4	Attaching parts for E.B6.75.689:—										
	or	Clip, hose (Pre-Alt. R60/91—Mod. 5102)							2	—	C	10/18
28E/4710971	SP.91/N	Clip, hose (Alt. R60/91—Mod. 5102)							2	—	C	
16566	E.B6.75.389	Cover, lagging							1	—	C	10/19
16567	E.B6.75.391	Cover, lagging							1	—	C	10/20
20868	E.B6.75.691	PIPE, bend, from hose coupling between frames 11 and 12, to coupling aft of frame 12							1	L.44	C	13/17
32B/1256480	†	Attaching parts for E.B6.75.691:—										
	†	Lagging, fibre glass							QR	—	C	10/21
32B/	†	Tape, adhesive							QR	—	C	10/22
20869	E.B6.75.693	PIPE, from water extractor aft coupling, to hose coupling between frames 11 and 12							1	—	C	13/18
28E/9130219	AGS.605/4	Attaching parts for E.B6.75.693:—										
	or	Clip, hose (Pre-Alt. R60/91—Mod. 5102)							2	—	C	10/23
28E/4710971	SP.91/N	Clip, hose (Alt. R60/91—Mod. 5102)							2	—	C	
12058	E.B6.75.393	Lagging							1	—	C	10/24
12059	E.B6.75.395	Lagging							1	—	C	10/25
12243	E.B6.75.695	PIPE, main continuation, between frames 3 and 4							1	L.44	C	13/19
28D/121965	A61/2B	Attaching parts for E.B6.75.695:—										
18683	E.B7.75.505	Bolt, 4 BA hex. head							2	—	C	10/26
16615	E.B7.75.203A	Clip, lagging							2	—	C	10/27
28M/1956039	AGS.2001/B/3	Cover, lagging, outer							2	L.44	C	10/28
28W/9419474	SP.15/B	Nut, stiff, 4 BA							2	—	C	10/29
		Washer, 4 BA plain							2	—	C	10/30

AP101B-0418-3A

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EB7.75.781	. .	PIPE, main continuation, between frames 5 and 6	1	L44	13/20
	. .	Attaching parts for EB7.75.781:—			
AGS605/4	. .	Clip, hose (Pre Alt. R60/91—Mod 5102)	3	—	10/31
or					
SP91/N	. .	Clip, hose (Alt. R60/91—Mod 5102)	—	—	
EB7.75.195A	. .	Cover, lagging, outer	1	L44	10/32
EB7.197A	. .	Cover, lagging, outer	1	L44	10/33
EB7.75.199A	. .	Cover, lagging, outer	2	L44	10/34
EB7.75.783	. .	PIPE, flanged main, at forward face of pressure bulkhead	1	L44	13/21
	. .	Attaching parts for EB7.75.783:—			
AGS605/4	. .	Clip, hose (Pre Alt R60/91—Mod 5102)	4	—	10/35
or					
SP91/N	. .	Clip, hose (Alt. R60/91—Mod 5102)	—	—	
EB7.75.155A	. .	Cover, lagging, outer	1	L44	10/36
EB7.75.157A	. .	Cover, lagging, outer	1	L44	10/37
EB7.75.159A	. .	Cover, lagging, outer	1	L44	10/38
EB7.75.525A	. .	Cover, lagging, outer	1	L44	10/39
EB7.75.791	. .	PIPE, branch, pilot's fishtail	1	L44	13/22
	. .	Attaching parts for EB7.75.791:—			
32B1256480	. .	Lagging, fibre glass blanket	QR	—	10/40
32B/	. .	Tape, adhesive	QR	—	10/41
EB7.75.793	. .	PIPE, main continuation, between frames 4 and 5	1	L44	13/23
	. .	Attaching parts for EB7.75.793:—			
A61/2B	. .	Bolt, 4BA hex head	2	—	10/26
EB7.75.505	. .	Clip, lagging	2	L44	10/27
EB7.75.201A	. .	Cover, lagging, outer	2	L44	10/42
AGS2001/B/3	. .	Nut, stiff, 4BA	2	—	10/29
SP15/B	. .	Washer, 4BA plain	2	—	10/30
EB7.75.5279	. .	PIPE, flexible (Pre—Mod 5236)	1	—	13/26
EA3.75.677	. .	PIPE, flexible (Mod 5236)	1	—	
EB7.75.5271	. .	PIPE, flexible (Pre—Mod 5236)	1	—	13/24
EB7.75.995	. .	PIPE, flexible (Mod 5236)	1	—	
EB7.75.5275	. .	PIPE, flexible (Pre—Mod 5236)	1	—	13/25
EA3.75.673	. .	PIPE, flexible (Mod 5236)	1	—	
EA9.75.10229	. .	PIPE, flexible (Pre—Mod 5236)	1	—	13/27
EA3.75.701	. .	PIPE, flexible (Mod 5236)	1	—	
EEAS66/14	. .	RING, clamping, at connecting sleeve	8	L72	13/28
EB7.75.613	. .	SEAL, canopy demister pipe flange at frame 2	2	—	7/30
EA3.75.145	. .	SLEEVE, pipe connecting, 1".5 i/d x 2".5 long	5	SILASTIC	6/25
or					
DUNLOP					
DAS582/24/2.5	. .	SLEEVE, pipe connecting, 2.5" i/d x 3.0" long	5	SILASTIC	10/43
EA3.75.147	. .				
or					
DUNLOP					
DAS582/40/3.0					
	. .	Attaching parts for EA3.75.147:—			
AGS605/5	. .	Clip, hose (Pre—Alt. R60/91—Mod 5102)	2	—	10/44
or					
SP91/P	. .	Clip, hose (Alt. R60/91—Mod 5102)	2	—	10/44
EB7.75.415A	. .	Cover, outer	2	L44	10/45

SERVICES
CABIN PRESSURE SYSTEM
IN FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EB6.75.1107 or DUNLOP DAS582/16/2.5 EB6.75.377	. SLEEVE, pipe connecting, 1".0 i/d x 2".5 long	1	Bells Asbestos	7/31
A25/11C AGS2001/C/1 SP90/C5 EA3.04.10989 EB6.75.383 AS2811/5/093 SP15/C	. STRAP, water extractor securing Attaching parts for EB6.75.377:— . Bolt, 2BA hex head . Nut, stiff, 2BA . Pin, split . Stud . Trunnion . Tube, distance . Washer, 2BA plain	2 1 2 1 1 1 1 2	L72 — — — S92 S92 L62 —	6/26 6/27 6/28 6/29 6/30 6/31 6/32 6/33
EEAS20/5/BR AS2811/5/050 NORMALAIR 500326	. TAB, locking . TUBE, distance, pipe clip, frame 3 . UNIT, master valve Attaching parts for 500326:— . Bolt, 1/4" BSF hex head . Nut, stiff, 1/4" BSF . Washer, 1/4" BSF plain	1 1 1 3 3 3	L72 L62 — — — —	6/34 6/35 5/5 5/6 5/7 5/8
NORMALAIR 527060	. VALVE, pressure control Attaching parts for 527060:— . Bolt, 1/4" hex head . Nut, 1/4" BSF thin . Stud . Washer, 1/4" BSF plain . Washer, 1/4" BSF spring	1 7 1 1 11 11	— — — S92 — —	5/9 5/10 5/11 5/12 5/13 5/14
NORMALAIR 500457	. VALVE, non-return Attaching parts for 500457:— . Bolt, 2BA hex head . Bolt, 2BA hex head . Clip, hose (Pre—Alt. R60/91—Mod 5102)	1 2 10 2	— — — —	5/15 5/16 5/17 5/18
or SP91/R EB7.75.509A EB7.75.697A AGS2001/C/1 EB7.75.133 EA1.75.131 SP15/C SP47/C	. Clip, hose (Alt. R60/91—Mod 5102) . Cover, outer lagging . Cover, outer lagging . Nut, stiff, 2BA . Ring, half bolt . Washer, jointing . Washer, 2BA plain . Washer, 2BA spring	2 1 1 10 2 2 12 2	— L44 L44 — L59 Langite — —	5/18 5/19 5/20 5/21 5/22 5/23 5/24 5/25
EA3.75.95	. WASHER, sealing, main air line at pressure bulkhead	2	Langite	5/26
EA3.75.139	. WASHER, special, air pipe flange, forward face of pressure bulkhead	1	L72	5/27
EEAS239/3/AH	. WASHER, 'D', clip attachments	7	L72	7/32

SERVICES
CABIN PRESSURE SYSTEM
IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	CABIN PRESSURE SYSTEM IN CENTRE FUSELAGE, ASSEMBLY (EG7.75.5) Spares for:—	—	—	14/1
EB6.75.639	. BRACKET, for starboard cabin pressure wing to fuselage pipe, between frames 16 and 17 Attaching parts for EB6.75.639:—	1	L59	14/2
A25/5C	. Bolt, 2 BA hex. head	2	—	14/3
AGS2001/C/1	. Nut, stiff, 2 BA	2	—	14/4
SP15/C	. Washer, 2 BA plain	2	—	14/5
EA2.75.37	. CLIP, pipe saddle, for port and starboard elbows and transverse pipe, frame 16 Attaching parts for EA2.75.37:—	3	L72	14/6
A25/2C	. Bolt, 2 BA hex. head	2	—	14/7
A25/3C	. Bolt, 2 BA hex. head (at packing)	2	—	14/8
AGS2001/C/1	. Nut, stiff, 2 BA	2	—	14/9
EB6.75.595	. Packing (at 1 position)	1	LFS.21	14/10
SP15/C	. Washer, 2 BA plain	2	—	14/11
EA1.75.105	. CLIP, pipe between frames 12 and 17 Attaching parts for EA1.75.105:—	4	L72	15/1
A25/1C	. Bolt, 2 BA hex. head	2	—	15/2
AGS2001/C/1	. Nut, stiff, 2 BA	2	—	15/3
SP15/C	. Washer, 2 BA plain	2	—	15/4
EB6.75.181	. CLIP, for transverse pipe at frame 16 Attaching parts for EB6.75.181:—	4	L72	14/12
A25/2C	. Bolt, 2 BA hex. head	2	—	14/13
AGS2001/C/1	. Nut, stiff, 2 BA	2	—	14/14
SP15/C	. Washer, 2 BA plain	2	—	14/15
EA4.75.321	. CONNECTOR, straight (Mod. 5257)	1	—	14/19
EB6.75.641	. FAIRLEAD, for port cabin pressure wing to fuselage pipe between frames 16 and 17 Attaching parts for EB6.75.641:—	1	LFS.21	15/6
A25/4C	. Bolt, 2 BA hex. head	6	—	15/7
AGS2001/C/1	. Nut, stiff, 2 BA	6	—	15/8
SP15/C	. Washer, 2 BA plain	6	—	15/9
AGS1170/K	. NIPPLE, 1-1/2" o/d pipe Attaching parts for AGS1170/K:—	1	—	14/16
AGS605/3	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	2	—	14/17
or				
SP91/L	. Clip, hose (Alt. R60/91—Mod. 5102)	2	—	14/17
EB6.75.179A	. Cover, outer	2	L44	14/18
EA3.75.55	. PIPE, from rubber connection at frame 12 to rubber connection at frame 13, 2-1/2" o/d x 20 SWG Attaching parts for EA3.75.55:—	1	L54	15/10
AGS605/4	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	2	—	15/11
or				
SP91/N	. Clip, hose (Alt. R60/91—Mod. 5102)	2	—	15/11
EB6.75.129A	. Cover, outer	1	L44	15/12
EB6.75.131A	. Cover, outer	1	—	15/13

R

SERVICES
CABIN PRESSURE SYSTEM
IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EA3.75.57	. PIPE, between rubber connections, frames 13 to frame 14 and frame 14 to frame 15, 2-1/2" o/d x 20 SWG Attaching parts for EA3.75.57:—	2	L54	15/14
AGS605/4 or SP91/N	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	4	—	15/15
EB6.75.133A	. Clip, hose (Alt. R60/91—Mod. 5102)	—	—	—
EB6.75.135A	. Cover, outer, aft of frame 13	2	L44	15/16
EB6.75.137A	. Cover, outer, forward of frame 14	2	L44	15/17
EB6.75.139A	. Cover, outer, aft of frame 14	1	L44	15/18
EB6.75.141A	. Cover, outer, aft of frame 14	1	L44	15/19
EB6.75.141A	. Cover, outer	1	L44	15/20
EB6.75.143A	. Cover, outer	1	L44	15/21
EA3.75.59	. PIPE, from rubber connection at frame 15 to rubber connection at frame 16, 2-1/2" o/d x 20 SWG Attaching parts for EA3.75.59:—	1	L54	15/22
AGS605/4 or SP91/N	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	2	—	15/23
EB6.75.707A	. Clip, hose (Alt. R60/91—Mod. 5102)	—	—	—
EB6.75.709A	. Cover, outer	1	L44	15/24
	. Cover, outer	1	L44	15/25
EA3.75.61	. PIPE, from rubber connection, frame 16 to rubber connection at elbow pipe, forward of frame 17, 2-1/2" o/d x 20 SWG Attaching parts for EA3.75.61:—	1	L54	15/26
R 32B1250460	. Lagging, fibreglass blanket	QR	—	15/27
EB6.75.151	. PIPE, bend, assembly, from coupling to reducing tee union at frame 16, starboard, 1-1/2" o/d x 20 SWG Attaching parts for EB6.75.151:—	1	L54	14/20
R 32B1250460	. Lagging, fibreglass blanket	QR	—	14/21
EB6.75.153	. PIPE, assembly, transverse, from coupling at frame 16, starboard to 4-way piece aft of frame 16, port Attaching parts for EB6.75.153:—	1	L54	14/22
EB6.75.183	. Clip	6	—	14/23
AGS605/3 or SP91/L	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	2	—	14/24
EB6.75.167A	. Clip, hose (Alt. R60/91—Mod. 5102)	2	—	14/24
EB6.75.169A	. Cover, outer	2	L44	14/25
EB6.75.175A	. Cover, outer	2	L44	14/26
EB6.75.177A	. Cover, outer	2	L44	14/27
EB6.75.613A	. Cover, outer	1	L44	14/28
R 32B1250460	. Cover, outer	1	L44	14/29
	. Lagging, fibreglass blanket	QR	—	14/30
EB6.75.503	. PIPE, assembly, from port wing connection to special 4-way piece between frames 16 and 17, 1-1/2" o/d x 20 SWG Attaching parts for EB6.75.503:—	1	L54	14/31
R 32B1250460	. Lagging, fibreglass blanket	QR	—	14/32

AP101B-0418-3A

Page NC3

SERVICES
CABIN PRESSURE SYSTEM
IN CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EB6.75.505	. PIPE, assembly, from starboard wing connection to tee union between frames 16 and 17, 1-1/2" o/d x 20 SWG Attaching parts for EB6.75.505:—	1	L54	14/33
AGS605/2 or SP91/J	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	1	—	14/34
AGS605/3 or SP91/L	. Clip, hose (Alt. R60/91—Mod. 5102)	1	—	14/34
	. Clip, hose (Pre—Alt. R60/91—Mod. 5102)	3	—	14/35
	. Clip, hose (Alt. R60/91—Mod. 5102)	3	—	14/35
EB6.75.163A	. Cover, outer	1	L44	14/36
EB6.75.165A	. Cover, outer	1	L44	14/37
EB6.75.541A	. Cover, outer	1	L44	14/38
EB6.75.543A	. Cover, outer	1	L44	14/39
EB6.75.507	. PIPE, elbow, between port wing and fuselage connections forward of frame 17 Attaching parts for EB6.75.507:—	1	L54	15/28
32B1250460	. Lagging, fibreglass blanket	QR	—	15/29
EA3.75.147 or DUNLOP DAS582/40/3.0	. SLEEVE, pipe connecting 2.5" i/d x 3.0" long	7	Silastic	15/5

R
R

AP101B-0418-3A

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
—	CABIN PRESSURE AND COLD AIR SYSTEM IN PORT WING, ASSEMBLY (EA3.04.9547) Spares for:—	—	—	
EB6.75.501	. ADAPTOR, oil vapour breather pipe	1	L65	16/1
EB6.75.1557	. CLAMP, assembly, matched pairs	7	—	16/2
A25/15E	Attaching parts:—			
AGS2001/E/2	. Bolt, 1/4" BSF hex head	2	—	16/3
SP13/E	. Nut, stiff, 1/4" BSF	2	—	16/4
	. Washer, 1/4" BSF plain	2	—	16/5
R 50270	. CLAMP, pipe, jointing, segmented, at Marston cooler	4	—	17/1
EEAS143/17	. CLIP, pipe, single, rib 2 (Pre—Alt. R60/91—Mod 5102)	1	L72	18/1
or				
AS4525/4	. CLIP, pipe (Alt. R60/91—Mod 5102)	1	—	18/1
EB6.75.461	. CONNECTION, tapered duct, from cold air unit junction pipe	1	L59	18/2
	Attaching parts for EB6.75.461:—			
R EB6.75.523A	. Lagging	2	L44	16/6
—	. DUCTS AND AIR COOLER, ASSEMBLY (EA3.75.641) Spares for:—	—	—	17/2
EA3.75.639	. . DUCT, air inlet, assembly (Pre Mod 4858)	1	L59	17/3
EA3.75.5155	. . DUCT, air inlet, assembly (Mod 4858)	1	—	17/46
	Attaching parts for EA3.75.639 and EA3.75.5155:—			
EEAS1/1C	. . Screw, 2BA 120° csk head	16	S96	17/4
EB6.75.735	. . DUCT, air outlet, assembly	1	L59	17/5
	Attaching parts for EB6.75.735:—			
EEAS1/1C	. . Screw, 2BA 120° csk head	2	S96	17/6
—	. . MARSTON COOLER, INSTALLATION (EB6.75.317) Spares for:—	—	—	17/7
EB6.75.343	. . . BRACKET, bottom support, assembly	2	DTD124	17/8
	Attaching parts for EB6.75.343:—			
A25/16C	. . . Bolt, 2BA hex head	2	—	17/9
AGS2001/C/1	. . . Nut, stiff, 2BA	2	—	17/10
AS2809/4/139	. . . Piece, distance	2	L62	17/11
SP15/C	. . . Washer, 2BA plain	2	—	17/12
EB6.75.345	. . . BRACKET, top support, assembly	1	L72	17/13
	Attaching parts for EB6.75.345:—			
A25/16C	. . . Bolt, 2BA hex head	3	—	17/14
AGS2001/C/1	. . . Nut, stiff, 2BA	3	—	17/15
AS2809/4/139	. . . Piece, distance	3	L62	17/16
SP15/C	. . . Washer, 2BA plain	3	—	17/17
R D106/6A	. . . COOLER, air, secondary (EB6.75.321)	1	—	17/18
	Attaching parts for D106/6A:—			
A25/5E	. . . Bolt, 1/4" BSF hex head	1	—	17/19
SP15/E	. . . Washer, 1/4" BSF plain	1	—	17/20
EB6.75.351	. . . Washer, felt, on support bracket	1	DTD590	17/21

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Part Number	Description	No. Off	Matl. Spec.	Plate No.
1 2 3 4 5 6				
EB6.75.335	. . STRAP, JOINT, FOR ATTACHMENT OF AIR DUCTS TO MARSTON COOLER, ASSEMBLY Consisting of:—	2	—	17/22
A25/8C	. . . BOLT, 2BA hex head	2	—	17/23
AGS2001/C/1	. . . NUT, stiff, 2BA	2	—	17/24
EB6.75.339	. . . STRAP, clamping	1	L59	17/25
EB6.75.337	. . . STRAP, joint	1	L59	17/26
EA3.04.10947	. FAIRLEAD, rib 1 Attaching parts for EA3.04.10947:—	1	—	18/3
A25/4C	. Bolt, 2BA hex head	4	—	18/4
AGS2001/C/1	. Nut, stiff, 2BA	4	—	18/5
SP15/C	. Washer, 2BA plain	4	—	18/6
EB6.75.673	. NIPPLE, special	1	—	18/7
EB6.75.455	. PIPE, assembly, continuation, from non-return valve and mixing valve tee piece through rib 2 Attaching parts for EB6.75.455:—	1	T26	18/8
AGS605/3 or SP91/L	. Clip, hose (Pre—Alt. R60/91—Mod 5102)	2	—	16/7
EA3.75.651A	. Cover, outer	1	L44	16/8
EA3.75.653A	. Cover, outer	1	L44	16/9
EB6.75.457	. PIPE, assembly, continuation, from non-return valve and mixing valve tee piece through rib 1 Attaching parts for EB6.75.457:—	1	L56	18/9
AGS605/3 or SP91/L	. Clip, hose (Pre—Alt. R60/91—Mod 5102)	4	—	16/10
EB6.75.533A	. Lagging	1	L44	16/11
EB6.75.535A	. Lagging	1	L44	16/12
EB6.75.625A	. Lagging	1	L44	16/13
EB6.75.627A	. Lagging	1	L44	16/14
EB6.75.459	. PIPE, assembly, junction, from cold air unit Attaching parts for EB6.75.459:—	1	L54	18/10
AGS605/3 or SP91/L	. Clip, hose (Pre—Alt. R60/91—Mod 5102)	2	—	16/15
EB6.75.519A	. Lagging	1	L44	16/16
EB6.75.521A	. Lagging	1	L44	16/17
EB6.75.463	. PIPE, assembly, breather oil vapour outlet	1	L56	18/11
EB6.75.467	. PIPE, assembly, from cold air unit compressor connection at rib 1	1	L54	18/12
EB6.75.469	. PIPE, assembly, from cold air unit turbine connection at rib 1	1	L54	18/13
EB6.75.471	. PIPE, assembly, from Marston cooler to connection at rib 1	1	L54	17/27
EB6.75.775	. PIPE, assembly, from cold air unit compressor connection to pipe joint at rib 2 Attaching parts for EB6.75.775:—	1	L54	18/14
AGS605/3 or SP91/L	. Clip, hose (Pre—Alt. R60/91—Mod 5102)	2	—	16/18
EB6.75.513A	. Lagging	1	L44	16/19
EB6.75.515A	. Lagging	1	L44	16/20

AP101B-0418-3A

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EA3.04.9549	PIPE, assembly, from non-return valve and mixing valve tee piece to connection between ribs 2 and 3	1	L54	18/15
AGS605/3 or SP91/L	Attaching parts for EA3.04.9549:— Clip, hose (Pre—Alt. R60/91—Mod 5102)	2	—	16/21
EA3.04.10959	Clip, hose (Alt. R60/91—Mod 5102)	2	—	16/21
EA3.04.10961	Lagging	1	L44	16/22
—	Lagging	1	L44	16/23
—	PIPE, RUN IN PORT WHEEL BAY, ASSEMBLY (EB6.75.19) Spares for:—	—	—	19/1
EB6.75.207	ADAPTOR, bulkhead Attaching parts for EB6.75.207:—	1	L40	19/2
A25/2C	Bolt, 2BA hex head	6	—	19/3
AGS2001/C/1	Nut, stiff, 2BA	6	—	19/4
EEAS20/1/DR	Tab, locking	2	L72	19/5
ASG1115/13	Washer, plate	1	—	19/6
EB6.75.201	PIPE, assembly, from fuselage bulkhead adaptor to pipe joint in wheel well bay	1	L56	19/7
EB6.75.203	PIPE, assembly, between rib A and E	1	L56	19/8
EB6.75.205	PIPE, assembly, from mixing valve bulkhead adaptor to pipe joint on rib E	1	L56	19/9
EEAS66/1	RING, clamping	1	L72	16/24
AS5402	RING, sealing, type A, between pipe flanges	9	—	16/25
EA3.75.145 or DUNLOP	SLEEVE, pipe connecting 1.5" i/d x 2.5" long	2	Silastic	18/16
DAS582/24/2.5	SLEEVE, pipe connecting 2.5" i/d x 3.0" long	1	Silastic	18/17
EA3.75.147 or DUNLOP	STRIP, bonding, 22 SWG	1	BS265	18/18
DAS582/40/3.0	UNIT, COLD AIR, INSTALLATION (EA3.04.10927) Spares for:—	—	—	18/19
EB6.75.725	UNIT, COLD AIR, ASSEMBLY Spares for:—	1	—	18/20
—	DIPSTICK and filler, oil level	1	—	18/21
GODFREY 23421HX GODFREY 23414	UNIT, cold air, ACRE9, Mk. 10E Attaching parts for EB6.75.199:—	1	—	18/22
A25/1C	Bolt, 2BA hex head	16	—	18/23
AGS586/C	Washer, 2BA spring	32	—	18/24
EB6.75.479	VALVE, CONSTANT FLOW, INSTALLATION Spares for:—	—	—	16/26
EB6.75.481	VALVE, CONSTANT FLOW, ASSEMBLY Spares for:—	1	—	16/27
EB6.75.579	ADAPTOR, special	1	L40	16/28
EB6.75.491	PIPE, assembly, flanged Attaching parts for EB6.75.491:—	1	L56	16/29
A25/2C	Bolt, 2BA hex head	12	—	16/30
SP13/C	Washer, 2BA plain	12	—	16/31

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
NORMALAIR 49776	. . . WASHER, sealing	1	—	16/32
NORMALAIR 502090	. . . VALVE, constant flow	1	—	16/33
AGS805/3	Attaching parts for EB6.75.479:— . Clip, hose (Pre—Alt. R60/91—Mod 5102)	2	—	16/34
or SP91/L	. Clip, hose (Alt. R60/91—Mod 5102)	2	—	16/34
EB6.75.517A	. Lagging	1	L44	16/35
EB6.75.629A	. Lagging	1	L44	16/36
—	. VALVE, RELIEF, AND PIPES, COLD AIR UNIT, INSTALLATION (EB6.75.727) Spares for:—	—	—	17/28
A25/6C	. . BOLT, 2BA hex head, bracket clip clamping	4	—	17/29
EB6.75.733	. . BRACKET, pipe support on cooler, assembly Attaching parts for EB6.75.733:—	1	DTD124	17/30
A25/1E	. . Bolt, 1/4" BSF hex head	2	—	17/31
SP13/E	. . Washer, 1/4" BSF plain	2	—	17/32
EB6.75.1557	. . CLAMP, assembly, matched pairs Attaching parts for EB6.75.1557:—	3	—	17/33
A25/15E	. . Bolt, 1/4" BSF hex head	2	—	17/34
AGS2002/E/2	. . Nut, stiff, 1/4" BSF	2	—	17/35
SP13/E	. . Washer, 1/4" BSF plain	2	—	17/36
EB6.75.731	. . COVER, valve case, assembly Attaching parts for EB6.75.731:—	1	L54	17/37
A25/1E	. . Bolt, 1/4" BSF hex head	2	—	17/38
AGS2001/C/1	. . NUT, stiff, 2BA, bracket clamp bolt attachment	4	—	17/39
EB6.75.737	. . PIPE, assembly, bend, relief valve pipe joint	1	L59	17/40
EB6.75.739	. . PIPE, assembly, from relief valve pipe joint to inlet tee piece	1	L54	17/41
EB6.75.741	. . PIPE, assembly, inlet tee piece, from pipe joint at rib 1 to Marston cooler	1	L54	17/42
AS5402	. . RING, sealing, between pipe flanges	3	—	17/43
EB6.75.729	. . VALVE, relief, assembly	1	—	17/44
SP13/C	. . WASHER, 2BA plain, bracket clamp bolt attachment	4	—	17/45
—	. VALVES AND PIPING, INSTALLATION (EA3.04.10937) Spares for:—	—	—	20/1
EB6.75.257	. . BRACKET, support, for non-return valve	1	L72	20/2
EB6.75.1557	. . CLAMP, assembly, matched pairs Attaching parts for EB6.75.1557:—	5	—	21/1
A25/15E	. . Bolt, 1/4" BSF hex head	2	—	21/2
AGS2001/E/2	. . Nut, stiff, 1/4" BSF	2	—	21/3
SP13/E	. . Washer, 1/4" BSF plain	2	—	21/4

A.P.101B—0418—3A

Page ND5

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Ref. No.	Part No.	Description							No. off	Mtl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
27UA/518	GODFREY 50270							CLAMP, segmented	3	—	C	20/3
6990	E.B6.75.261							CONNECTOR, flanged, non-return valve end fitting	1	L.40	C	20/4
6991	E.A4.75.183							ELBOW, from engine connection to non-return valve	1	T.45	C	20/5
								Attaching parts for E.A4.75.183:—				
28D/9133011	A25/2C							Bolt, 2 BA hex. head	6	—	C	20/6
12714	E.B6.75.447A							Cover, outer	1	L.44	C	21/5
12369	E.B6.75.449A							Cover, outer	1	L.44	C	21/6
28M/1278190	AGS.2001/C/1							Nut, stiff, 2 BA	6	—	C	20/7
28W/9419402	SP.13/C							Washer, 2 BA plain	6	—	C	20/8
16448	E.B7.50.25							FITTING, end, for pipe connection to hot air valve	1	L.40	C	20/9
12078	E.B6.75.669							GASKET, non-return valve joint	2	Aero Permanite	C	20/10
12079	E.B6.75.675							GASKET, hot air valve joint	3	Aero Permanite	C	20/11
16556	E.B6.75.233							PIPE, assembly, from mixing valve to constant flow valve	1	—	C	20/12
								Attaching parts for E.B6.75.233:—				
R 28E/9129562	AGS.605/3 or							Clip, hose (Pre-Alt. R60/91—Mod. 5102)	2	—	C	21/9
R 28E/2027591	SP.91/L							Clip, hose (Alt. R60/91—Mod. 5102)		—	C	
26628	E.B6.75.279A							Cover, outer	1	L.44	C	21/10
26629	E.B6.75.281A							Cover, outer	1	L.44	C	21/11
13026	E.B6.75.235							PIPE, assembly, from mixing valve to connection at rib 2	1	T.26	C	20/13
								Attaching parts for E.B6.75.235:—				
R 28E/9129562	AGS.605/3 or							Clip, hose (Pre-Alt. R60/91—Mod. 5102)	2	—	C	21/12
R 28E/2027591	SP.91/L							Clip, hose (Alt. R60/91—Mod. 5102)		—	C	
26630	E.B6.75.283A							Cover, outer	1	L.44	C	21/13
26631	E.B6.75.285A							Cover, outer	1	L.44	C	21/14
16557	E.B6.75.237							PIPE, assembly, from mixing valve to tee piece at rib 3	1	T.26	C	20/14
								Attaching parts for E.B6.75.237:—				
R 28E/9129562	AGS.605/3 or							Clip, hose (Pre-Alt. R60/91—Mod. 5102)	2	—	C	21/15
R 28E/2027591	SP.91/L							Clip, hose (Alt. R60/91—Mod. 5102)		—	C	
26632	E.B6.75.287A							Cover, outer	1	L.44	C	21/16
26633	E.B6.75.289A							Cover, outer	1	L.44	C	21/17
16558	E.B6.75.239							PIPE, assembly, from mixing valve to wheel well bay connection	1	T.26	C	20/15
								Attaching parts for E.B6.75.239:—				
R 28E/9129562	AGS.605/3 or							Clip, hose (Pre-Alt. R60/91—Mod. 5102)	4	—	C	21/18
R 28E/2027591	SP.91/L							Clip, hose (Alt. R60/91—Mod. 5102)		—	C	
26634	E.B6.75.295A							Cover, outer	1	L.44	C	21/19
26635	E.B6.75.297A							Cover, outer	1	L.44	C	21/20
16597	E.B6.75.631							Lagging, assembly	1	—	C	21/21
16598	E.B6.75.633							Lagging, assembly	1	—	C	21/22

Page ND6

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Fig. and Index
					M.R. L.M.	
		1 2 3 4 5 6 7				
13025	E.B6.75.231	PIPE, assembly, from non-return valve on inboard engine rib to tee piece at rib 3	1	T.26	C	20/16
28E/9129562	AGS.605/3	Attaching parts for E.B6.75.231:—	3	—	C	21/23
	or	Clip, hose (Pre-Alt. R60/91—Mod. 5102)				
28E/2027591	SP.91/L	Clip, hose (Alt. R60/91—Mod. 5102)	3	—	C	21/23
26367	E.B6.75.275A	Cover, outer	1	L.44	C	21/24
26367	E.B6.75.275A	Cover, outer	1	L.44	C	21/24
26366	E.B6.75.277A	Cover, outer	1	L.44	C	21/25
28F/8011895	AGS.1140/D	PLUG, nipple	1	—	C	21/26
28F/17675	AS.5402	RING, sealing, pipe flanges	8	—	C	21/27
28F/9439535	AGS.954/D	SLEEVE, outer	1	—	C	21/28
16560	E.B6.75.259	TEE-PIECE, mixing valve and hot air valve at rib 3	1	—	C	21/29
		Attaching parts for E.B6.75.259:—				
28D/9133011	A25/2C	Bolt, 2 BA hex. head	3	—	C	21/30
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	3	—	C	21/31
28W/9419402	SP.13/C	Washer, 2 BA plain	3	—	C	21/32
	E.B7.50.31	VALVE, HOT AIR, ASSEMBLY	1	—	—	20/17
		Consisting of:—				
5W/400	E.E. CO.	ACTUATOR	1	—	A	20/18
	B'FORD					
	TYPE 234					
27V/4282	TEDDINGTON	VALVE, hot air	1	—	A	20/19
	FKH/A/16					
		Attaching parts for E.B7.50.31:—				
12125	E.B6.75.443A	Cover, outer	1	—	C	21/33
12076	E.B6.75.445A	Cover, outer	1	—	C	21/34
28M/9480017	AGS.2001/E/1	Nut, stiff, 1/4" BSF	8	—	C	20/20
28M/9418921	SP.13/E	Washer, 1/4" BSF plain	8	—	C	20/21
28W/9416644	SP.47/E	Washer, 1/4" BSF spring	8	—	C	20/22
27KD/6	NORMALAIR	VALVE, non-return	1	—	A	20/23
	501670					
		Attaching parts for 501670:—				
28D/9436920	A25/1C	Bolt, 2 BA hex. head	4	—	C	20/24
28D/9133011	A25/2C	Bolt, 2 BA hex. head	2	—	C	20/25
28D/1200119	A25/4C	Bolt, 2 BA hex. head	6	—	C	20/26
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	6	—	C	20/27
28W/9419402	SP.13/C	Washer, 2 BA plain	6	—	C	20/28
28W/9416643	SP.47/C	Washer, 2 BA spring	6	—	C	20/29
	—	VALVE, 2-WAY MIXING, INSTALLATION (E.A3.04.10939)	—	—	—	19/10
		Spares for:—				
	E.B6.75.245	BRACKET, valve support, outboard	1	L.72	—	19/11
	E.B6.75.246	BRACKET, valve support, inboard	1	L.72	—	19/12
	E.B6.75.247	BRACKET, desynn transmitter	1	L.72	—	19/13

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN PORT WING

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EB6.75.649	. . .	ROD, ADJUSTING, 2-WAY MIXING VALVE DESYNN TRANSMITTER, ASSEMBLY Consisting of:—	1	—	19/14
AGS899/2	. . .	COLLAR, shackle pin	2	—	19/15
EB6.75.653	. . .	FORK-END	1	L64 or L65	19/16
EB6.75.655	. . .	FORK-END	1	L64 or L65	19/17
A27/CT	. . .	NUT, 2BA thin	1	—	19/18
A27/CTL	. . .	NUT, 2BA thin, LH	1	—	19/19
SP4Y/B4	. . .	PIN, shackle	2	—	19/20
SP90C7	. . .	PIN, split	2	—	19/21
EB6.75.651	. . .	ROD, screwed	1	L40	19/22
6A7002023	. . .	TRANSMITTER, desynn, type C Attaching parts for 6A/7002023:—	1	—	19/23
A25/1C	. . .	Bolt, 2BA hex head	2	—	19/24
AGS2001/C/1	. . .	Nut, stiff, 2BA	4	—	19/25
EEAS1/1C	. . .	Screw, 2BA 120° csk head	2	S96	19/26
EB7.75.103	. . .	VALVE, DOUBLE HOT AIR, ASSEMBLY Consisting of:—	1	—	19/27
EE CO B'FORD TYPE 233 TEDDINGTON FKH/A/15	. . .	ACTUATOR	1	—	19/28
	. . .	VALVE, hot air, 2"	1	—	19/29
	. . .	Attaching parts for EB7.75.103:—			
A25/4C	. . .	Bolt, 2BA hex head	6	—	19/30
AGS2001/C/1	. . .	Nut, stiff, 2BA	6	—	19/31
SP15/C	. . .	Washer, 2BA plain	6	—	19/32
	. . .	Attaching parts for EA3.04.10939:—			
EB6.75.299A	. . .	Cover, outer	1	L44	21/35
EB6.75.301A	. . .	Cover, outer	1	L44	21/36
EB6.75.635A	. . .	Lagging, assembly	1	L44	21/37
EB6.75.637A	. . .	Lagging, assembly	1	L44	21/38
	. . .	Attaching parts for EA3.04.10937:—			
EB6.75.509A	. . .	Lagging, assembly	1	L44	16/37
EB6.75.511A	. . .	Lagging, assembly	1	L44	16/38

A.P.101B—0418—3A

Page NE1

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN STARBOARD WING

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	CABIN PRESSURE AND COLD AIR SYSTEM IN STARBOARD WING, ASSEMBLY (E.A3.04.10941)							—	—	—	
		Spares for:—										
R	16559 E.B6.75.258	BRACKET, support, non-return valve							1	L.72	C	
	6119198 E.B6.75.1557	CLAMP, assembly, matched pairs							1	—	C	
		Attaching parts for E.B6.75.1557:—										
R	28D/1212313 A25/15E	Bolt, 1/4" BSF hex. head							2	—	C	
R	28M/10299 AGS.2001/E/2	Nut, stiff, 1/4" BSF							2	—	C	
R	28W/9418921 SP.13/E	Washer, 1/4" BSF plain							2	—	C	
	27UA/518 GODFREY 50270	CLAMP, pipe jointing (segmental) at Marston cooler							2	—	C	
	1707 E.A2.75.37	CLIP, pipe saddle at ribs 2 and 3							2	L.72	C	
		Attaching parts for E.A2.75.37:—										
	28D/9436920 A25/1C	Bolt, 2 BA hex. head							2	—	C	
	28M/1278190 AGS.2001/C/1	Nut, stiff, 2 BA							2	—	C	
	28W/9419402 SP.13/C	Washer, 2 BA plain							2	—	C	
	6990 E.B6.75.261	CONNECTOR, flanged, non-return valve and fitting							1	L.40	C	
	—	DUCTS AND AIR COOLER, ASSEMBLY (E.A3.75.642)							—	—	—	
		Spares for:—										
	32786 E.A3.75.640	DUCT, air inlet, assembly (Pre-Mod. 4858)							1	L.59	C	
	6101006 E.A3.75.5156	DUCT, air inlet, assembly (Mod. 4858)							1	—	—	24/43
		Attaching parts for E.A3.75.640 and E.A3.75.5156:—										
	1025 EEAS.1/1C	Screw, 2 BA 120° c'sk head							16	S.96	C	
	6623 E.B6.75.329	DUCT, air outlet, assembly							1	L.59	C	
		Attaching parts for E.B6.75.329:—										
	1025 EEAS.1/1C	Screw, 2 BA 120° c'sk head							2	S.96	C	
	—	MARSTON-COOLER, INSTALLATION (E.B6.75.318)							—	—	—	
		Spares for:—										
	12395 E.B6.75.344	BRACKET, bottom, support, assembly							2	DTD.124	C	
		Attaching parts for E.B6.75.344:—										
	28D/1011021 A25/16C	Bolt, 2 BA hex. head							2	—	C	
	28M/1278190 AGS.2001/C/1	Nut, stiff, 2 BA							2	—	C	
	AS.2809/4/139	Piece, distance							2	L.62	LM	
	28W/9419475 SP.15/C	Washer, 2 BA plain							2	—	C	
	12396 E.B6.75.346	BRACKET, top, support, assembly							1	L.72	C	
		Attaching parts for E.B6.75.346:—										
	28D/1011021 A25/16C	Bolt, 2 BA hex. head							3	—	C	
	28M/1278190 AGS.2001/C/1	Nut, stiff, 2 BA							3	—	C	
	AS.2809/4/139	Piece, distance							3	L.62	LM	
	28W/9419475 SP.15/C	Washer, 2 BA plain							3	—	C	

Page NE2

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN STARBOARD WING

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
27UA/492	MARSTON D.106/8A							COOLER, air, primary (E.B6.75.319)	1	—	A	24/17
								Attaching parts for D.106/8A:—				
28D/1011240	A25/5E							Bolt, 1/4" BSF hex. head	1	—	C	24/18
28W/9419405	SP.15/E							Washer, 1/4" BSF plain	1	—	C	24/19
6622	E.B6.75.351							Washer, felt	1	DTD.590	C	24/20
	E.B6.75.335							STRAP, JOINT, FOR ATTACHMENT OF AIR DUCTS TO MARSTON COOLER, ASSEMBLY Consisting of:—	2	—	—	24/21
28D/1011019	A25/8C							BOLT, 2 BA hex. head	2	—	C	24/22
28M/1278190	AGS.2001/C/1							NUT, stiff, 2 BA	2	—	C	24/23
12393	E.B6.75.339							STRAP, clamping	1	L.59	C	24/24
12392	E.B6.75.337							STRAP, joint	1	L.59	C	24/25
6992	E.A4.75.184							ELBOW, from engine connection to non-return valve	1	T.45	C	23/3
								Attaching parts for E.A4.75.184:—				
28D/9133011	A25/2C							Bolt, 2 BA hex. head	6	—	C	23/4
28M/1278190	AGS.2001/C/1							Nut, stiff, 2 BA	6	—	C	23/5
28W/9419402	SP.13/C							Washer, 2 BA plain	6	—	C	23/6
15205	E.A2.75.345							FAIRLEAD, half, pipe support rib 1	2	LFS.21	C	24/26
								Attaching parts for E.A2.75.345:—				
28D/9133012	A25/3C							Bolt, 2 BA hex. head	2	—	C	24/27
28M/1278190	AGS.2001/C/1							Nut, stiff, 2 BA	2	—	C	24/28
28W/9419402	SP.13/C							Washer, 2 BA plain	2	—	C	24/29
16448	E.B7.50.25							FITTING, end, for pipe connection to hot air valve	1	L.40	C	23/7
12078	E.B6.75.669							GASKET, non-return valve joint	2	Aero Permanite	C	23/8
12079	E.B6.75.675							GASKET, hot air valve joint	3	Aero Permanite	C	23/9
6770	E.B6.75.403							PIPE, assembly, from Marston cooler to engine and fuselage pipe tee piece	1	T.26	C	22/11
								Attaching parts for E.B6.75.403:—				
R 28E/9129562	AGS.605/3 or							Clip, hose (Pre-Alt. R60/91—Mod. 5102)	2	—	C	22/12
R 28E/2027591	SP.91/L							Clip, hose (Alt. R60/91—Mod. 5102)	2	—	C	22/12
26340	E.B6.75.427A							Cover, outer	1	L.44	C	22/13
26341	E.B6.75.429A							Cover, outer	1	L.44	C	22/14
6771	E.B6.75.405							PIPE, assembly, from wheel well bulkhead fitting to Marston air cooler	1	T.26	C	22/15
6772	E.B6.75.407							PIPE, assembly, from hot air valve end fitting to connection between ribs 2 and 3	1	T.26	C	22/16
								Attaching parts for E.B6.75.407:—				
R 28E/9129562	AGS.605/3 or							Clip, hose (Pre-Alt. R60/91—Mod. 5102)	4	—	C	22/17
R 28E/2027591	SP.91/L							Clip, hose (Alt. R60/91—Mod. 5102)	4	—	C	22/17
27094	E.B6.75.411A							Lagging, assembly	1	L.44	C	22/18
27093	E.B6.75.413A							Lagging, assembly	1	L.44	C	22/19
27134	E.B6.75.415A							Lagging, assembly	1	L.44	C	22/20
27135	E.B6.75.417A							Lagging, assembly	1	L.44	C	22/21

AP101B-0418-3A

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN STARBOARD WING

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
EB6.75.409	PIPE, assembly, from connection between ribs 2 and 3 to tee piece	1	T26	22/22
AGS605/3	Attaching parts for EB6.75.409:—			
or	Clip, hose (Pre—Alt. R60/91—Mod 5102)	5	—	22/23
SP91/L	Clip, hose (Alt. R60/91—Mod 5102)	5	—	22/23
EB7.75.189A	Cover, outer	2	L44	22/24
EB6.75.419A	Lagging, assembly	1	L44	22/25
EB6.75.421A	Lagging, assembly	1	L44	22/26
EB6.75.423A	Lagging, assembly	1	L44	22/27
EB6.75.425A	Lagging, assembly	1	L44	22/28
—	PIPE RUN IN STARBOARD WHEEL BAY, ASSEMBLY (EB6.75.20)	—	—	24/30
	Spares for:—			
EB6.75.401	ADAPTOR, bulkhead	1	L40	24/31
	Attaching parts for EB6.75.401:—			
A25/2C	Bolt, 2BA hex head	6	—	24/32
AGS2001/C/1	Nut, stiff, 2BA	6	—	24/33
EB6.75.647	Shim	1	Lam. Alum.	24/34
EEAS20/1/DR	Tab, locking	2	L72	24/35
AGS1115/13	Washer, plate	1	—	24/36
EB6.75.213	CLIP, pipe saddle, in wheel bay	2	L72	24/37
	Attaching parts for EB6.75.213:—			
A25/2C	Bolt, 2BA hex head	2	—	24/38
AGS2001/C/1	Nut, stiff, 2BA	2	—	24/39
SP15/C	Washer, 2BA plain	2	—	24/40
EB6.75.209	PIPE, assembly, from Marston cooler bulkhead elbow connection to pipe joint in wheel well bay	1	L56	24/41
EB6.75.615	PIPE, assembly, from pipe joint in wheel well bay to fuselage bulkhead connection	1	L56	24/42
AS5402	RING, sealing, type A	3	—	22/29
AGS1119/K	UNION, tee	1	—	22/30
	Attaching parts for AGS1119/K:—			
EB6.75.435A	Cover, outer	1	L44	22/31
EB6.75.437A	Cover, outer	1	L44	22/32
EB7.50.31	VALVE, HOT AIR, ASSEMBLY	1	—	23/10
	Consisting of:—			
EE CO	ACTUATOR	1	—	23/11
B'FORD				
TYPE 234				
TEDDINGTON	VALVE, hot air	1	—	23/12
FKH/A/16				
	Attaching parts for EB7.50.31:—			
EB6.75.443A	Cover, outer	1	L44	23/13
EB6.75.445A	Cover, outer	1	L44	23/14
A27/EP	Nut, 1/4" NSF plain	8	L44	23/15
SP47/E	Washer, 1/4" BSF spring	8	—	23/16

SERVICES
CABIN PRESSURE AND COLD AIR SYSTEM
IN STARBOARD WING

Part Number	Description	No. Off	Matl. Spec.	Plate No.
	1 2 3 4 5 6			
NORMALAIR 501670	. VALVE, non-return	1	—	
	Attaching parts for 501670:—			
A25/1C	. Bolt, 2BA hex head	4	—	
A25/2C	. Bolt, 2BA hex head	2	—	
A25/4C	. Bolt, 2BA hex head	6	—	
EB6.75.439A	. Cover, outer	1	L44	
EB6.75.441A	. Cover, outer	1	L44	
AGS2001/C/1	. Nut, stiff, 2BA	6	—	
SP13/C	. Washer, 2BA plain	6	—	
SP47/C	. Washer, 2BA spring	6	—	

A.P.101B—0418—3A

Page NF1

SERVICES
COLD AIR SUPPLY TO PILOT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
	—	COLD AIR SUPPLY TO PILOT, ASSEMBLY (E.G.9.74.19)						—	—	—	
		Spares for:—									
R	7240	E.A3.74.45	BRACKET, non-return valve mounting					1	L.72	C	25/1
	4965	EEAS.143/5	CLIP, pipe, 3/16" o/d (Pre-Alt. R60/91—Mod. 5102)					5	L.72	C	25/2
		or									
R	5K/1037287	AS.4525/3	CLIP, pipe (Alt. R60/91—Mod. 5102)					5	L.72	C	25/2
	8994	EEAS.143/15	CLIP, pipe, 1" o/d					6	L.72	C	25/3
	8995	E.A3.74.47	CLIP, non-return valve mounting					2	—	C	25/4
			Attaching parts for E.A3.74.47:—								
	28D/1013250	A61/15C	Bolt, 2 BA hex. head					2	—	C	25/5
	28W/9419475	SP.15/C	Washer, 2 BA plain					2	—	C	25/6
	8990	E.A3.74.53	COUPLING, drain pipe outlet					1	L.65	C	25/7
	8992	E.A3.74.63	HOSE, coupling, 1" i/d x 3" long, between air pipe connection					5	DTD.625	C	25/8
	8993	E.A3.74.67	HOSE, coupling, 3/16" i/d x 1-1/4" long, water trap to drain pipe					1	DTD.625	C	25/9
	5042	THERMO TANKS K.1259/43	LOUVRE, punkah, type DAR.2					1	—	B	25/10
	5632	E.A3.74.55	PIPE, cold air, from non-return valve to connection on frame 1					1	L.54	C	25/11
	5633	E.A3.74.111	PIPE, cold air, continuation, from hose coupling on frame 1, to hose coupling between frames 1 and 2					1	L.54	C	25/12
	5634	E.A3.74.113	PIPE, cold air, from hose connection between frames 1 and 2 to louvre					1	L.54	C	25/13
	5635	E.A3.74.115	PIPE, water drain, aft of frame 1					1	L.54	C	25/14
	8991	E.A3.74.51	RING, louvre mounting					1	—	C	25/15
	3681	E.A3.74.49	SCOOP, cold air					1	DTD.123	C	25/16
	981	EEAS.20/2/DR	TAB, locking, drain pipe coupling					1	L.72	C	25/17
		E.G.9.74.21	TRAP, water					1	L.54	C	25/18
	5638	E.A3.74.23	VALVE, NON-RETURN, GROUP					1	—	A	25/19
			Consisting of:—								
		E.A3.74.39	ADAPTOR					2	L.40	—	25/20
		E.A3.74.41	BODY, non-return valve					1	L.40	—	25/21
	5639	E.A3.74.25	PLUNGER, VALVE SEAL, ASSEMBLY					1	—	B	25/22
			Spares for:—								
	5640	E.A3.74.29	SEAT, valve					1	Hallprene 21	C	25/33
		E.A3.74.27	WASHER, valve seat					1	L.40	C	25/24
	5060	E.A3.74.35	SHIM, laminated					1	Lam. Alum.	C	25/25
	5059	E.A3.74.37	SPRING, compression					1	DTD.215	C	25/26
	5043	E.A3.74.33	WASHER, sealing					1	DTD.378A	C	25/27