

**ARMAMENT**  
**PILOT'S ATTACK SIGHT, MK. I, GUNSIGHT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	—	<b>GUNSIGHT, PILOT'S ATTACK SIGHT, MK. 1, ASSEMBLY (E.F2.98.1)</b>	—	—	—	21/1
	E.F2.98.69	<b>GUNSIGHT</b> , assembly ... .. Consisting of :—	1	—	—	21/2
10100	E.F2.98.67	<b>ADAPTOR</b> , drying cell... ..	1	—	C	21/3
6653	E.B2.98.2481	<b>BOLT</b> , special, P.A.S.I. display unit, attachment ...	1	BAC.M37	C	21/4
28F/9423226	AGS.1135/A	<b>BOLT</b> , banjo, drying cell, connection... ..	1	—	C	21/5
	E.B2.98.2863	<b>CELL</b> , P.A.S.I., display unit, drying, assembly ...	1	—	—	21/6
	E.B2.98.2857	Spares for :— <b>BRACKET</b> ... ..	1	—	—	21/7
8B/4239	FERRANTI	<b>CELL</b> , drying, Mk. 2 ... ..	1	—	B	21/8
	A/94/20520					
5L/9951282	†	<b>FILAMENT</b> , 28v. Osram ... ..	2	—	C	21/9
5L/9959118	†	<b>FILAMENT</b> , 28v. ... ..	1	—	C	21/10
	—	<b>HANDLE</b> , pull, rudder adjustment, installation (E.F2.45.127) Spares for :—	—	—	—	21/11
10101	E.B3.45.257	<b>BOLT</b> , special shouldered, cable, actuating lever to starboard gunsight beam, attachment	1	S1	C	21/12
10102	E.B3.45.259	<b>BOLT</b> , special shouldered, pull handle to cable actuating lever, attachment	1	S1	C	21/13
10103	E.B3.45.243	<b>CABLE</b> , assembly, rudder bar adjustment... ..	1	—	C	21/14
10104	E.B3.45.263	<b>EYE-BOLT</b> , cable lever return, spring anchor ...	1	S1	C	21/15
28M,1278189	AGS.2001/B/1	Attachments :— Nut, stiff, 4 BA ... ..	1	—	C	21/16
	E.F2.45.153	<b>HANDLE</b> , group ... .. Consisting of :—	1	—	C	21/17
19179	E.B3.45.273	<b>COLLAR</b> , stop ... .. Attachments :— Screw, set, 4 BA x 1/4" long ... ..	1	S95	—	21/18
	UNBRAKO SERIES S		1	—	—	21/19
19178	E.B3.45.411	<b>HANDLE</b> ... .. Attachments :— Nut, stiff, 1/4" BSF ... ..	1	—	C	21/20
28M/9480017	AGS.2001/E/1		1	—	C	21/21
	E.B3.45.301	<b>BLOCK</b> , bearing ... ..	1	L65	—	21/22
10106	E.F2.45.131	<b>ROD</b> , pull ... ..	1	L65	C	21/23
10107	E.F2.45.137	<b>SLEEVE</b> ... ..	1	L65	C	21/24
10108	E.F2.45.135	<b>TUBE</b> , pull rod guide ... ..	1	—	C	21/25
10109	E.F2.45.139	<b>LEVER</b> , cable, actuating ... ..	1	L73	C	21/26
10110	E.B3.45.247	<b>SPRING</b> , tension, cable lever return ... ..	1	DTD215	C	21/27
10111	E.B3.45.271	<b>WASHER</b> , special ... ..	1	S1	C	21/28
6654	E.B2.98.2859	<b>HOSE</b> , flexible, from drying cell to gunsight ...	1	Rubber	C	21/29
28F/9428452	AGS.1186/A	<b>SEAL</b> , bonded, drying cell, banjo union adaptor ...	2	—	C	21/30
7415	E.B2.10.17265	<b>SHIM</b> , mounting ... ..	1	—	C	21/31
8B/5048	†	<b>UNIT</b> , P.A.S., display ... ..	1	—	A	21/32
6655	E.B2.10.8117	<b>WASHER</b> , special, display unit, attachment bolt ...	1	L65	C	21/33

Ref. No.	Part No.	1 2 3 4 5 6 7	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

