

STARTER PIPES AT FRAME 25

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	—	PIPES, STARTER AT FRAME 25, ASSEMBLY .....							—	—	—	
		(E.F2.53.297) (MOD. 4477)										
		Spares for:—										
12869*	E.F3.53.111	CONNECTOR, pipe, at frame 25 .....							2	L65	C	161/1
	or											
10612	E.F2.53.181											
		Attachments:—										
28D/9133011	A25/2C	Bolt, 2 BA, hex. head .....							8	—	C	161/2
28M/9433473	AGS.2002/C/1	Nut, stiff, 2 BA .....							8	—	C	161/3
4851	EEAS.20/1/ER	Tab, locking .....							4	L72	C	161/4
10613	E.F2.53.179	FAIRLEAD, assembly .....							1	—	C	161/5
		Attachments:—										
28D/9419397	A25/12C	Bolt, 2 BA, hex. head .....							2	—	C	161/6
28W/9419475	SP15/C	Washer, 2 BA, plain .....							2	—	C	161/7
10438	E.F2.53.81	NIPPLE, coupling, body to pipe .....							4	BAS.M37	C	161/8
1504403	E.L2.53.87	PIPE, assembly, starter fuel, forward of frame 26 .....							1	L56	C	161/9
10615	E.F2.53.185	PIPE, assembly, starter air, forward of frame 26 .....							1	L56	C	161/10
30A/3055	†	WIRE, locking, 20 SWG .....							QR	DTD189	C	161/11



This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

