

**Internal Checks — *continued***

**T5 ONLY**

**Lower Left Side**

Canopy operating handle	Up
Ram air valve ... ..	CLOSED (fully down)
Demist lever ... ..	Operate over full range. Leave slightly open
Oxygen shut-off valves ...	Both open
Throttle servo ... ..	ENGAGE. Check spring release. Leave DISENGAGED
JPT controllers ... ..	AUTO (wired)
Emergency U/C ... ..	Fully down
IFF ... ..	SBY. Modes 1 and 3/A selected, mode 2 off. MIL selected. Codes as required
Emergency lights ... ..	Off (check function at night)
Flap selector ... ..	UP

**Upper Left Side**

Canopy jack release lever	Outboard (wired)
Frequency card lighting	Test at night
Accelerometer ▶◀ ...	Reset
Pressure override ...	OFF
Airmix control ... ..	Pulled out, light on; pushed in, light out
Throttles ... ..	Check full range, including reheat. Set at HP COCKS OFF

*(continued)*

This file was downloaded  
from the RTFM Library:

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

