

LAYOUT OF  
LIGHTNING T MK.5 AIRCRAFT

A.P.101B-1005-1A ]	...	...	...	...	General and technical information
A.P.101B-1005-1B ]					
A.P.101B-1005-2	...	...	...	...	General orders and modifications
A.P.101B-1005-3A	...	...	...	...	Schedule of spare parts
A.P.101B-1005-3B	...	...	...	...	Appendix 'A'
A.P.101B-1005-3C	...	...	...	...	Scales of unit equipment
A.P.101B-1005-3D	...	...	...	...	Scales of servicing spares
A.P.101B-1005-5	...	...	...	...	Opportunity servicing schedule
A.P.101B-1000-6	...	...	...	...	Repair and re-conditioning instructions
◀ A.P.101B-1005-10	...	...	...	...	Servicing Diagrams Manual
A.P.101B-1005-12	...	...	...	...	Ground handling notes
A.P.101B-1005-13	...	...	...	...	Modifications List ▶
A.P.101B-1005-14	...	...	...	...	Flight reference cards
A.P.101B-1005-15	...	...	...	...	Pilot's notes
A.P.101B-1003,5,6 - 15B	...	...	...	...	Aircrew manual - weapon system
A.P.101B-1005-16	...	...	...	...	Operating data