

RESTRICTED

A.P.101B-1202-1B, Cover 3, Sect. 10, Chap. 1
May, 69

CHAPTER I

CHAP

I

GENERAL INFORMATION

RESTRICTED

RESTRICTED

A.P.101B-1202-1B, Cover 3, Sect.10, Chap.1
A.L.15, Sep.81

F.S./1

Chapter 1 GENERAL INFORMATION

LIST OF CONTENTS

	Para
<i>Introduction</i>	1
<i>General</i>	2
<i>Servicing diagrams</i>	3
<i>Access doors and detachable panels</i>	4
<i>Modifications</i>	5

TABLE

	Table
<i>Circuit references</i>	1

RESTRICTED

RESTRICTED

Introduction

1. This Chapter only covers information peculiar to the armament installation on this aircraft. Further information of a general nature is in Cover 1, Sect. 6, Chap. 1. A list of circuit references is given in Table 1.

General

2. Conversion of the basic aircraft for operation in any of the armament roles, by the embodiment of the relevant special order only (SOO) modifications, is fully described in A.P.101B-1202-1A, Cover 1, Sect. 2, Chap. 5. The aircraft is equipped with most of the controls and electrical wiring, and it is the SOO modifications which introduce the necessary additional

equipment (bomb carriers, pylons, role panels etc) to convert the aircraft to the required role. The additional equipment for the various armament roles is fully described in A.P.101B-1202-1A, Cover 3, Sect. 5, Chap. 2 and 4. The term store is used to denote any item of armament or equipment which may be carried at any of the store stations on the aircraft.

Servicing diagrams

3. The servicing diagrams associated with this Chapter and information regarding the location of components complete with a list of associated Air Publications is contained in the relevant chapter of A.P.101B-1202-10B.

Access doors and detachable panels

4. The location of access doors and detachable panels is shown in Cover 1, Sect. 6, Chap. 1, the components to which each gives access being listed in the associated key. A number of access panels are provided in the cabin floor and details of these are in A.P.101B-1202-1A, Cover 1, Sect. 2, Chap. 4, fig 2.

Modifications

5. A modification state is given at the beginning of each chapter in this Section to indicate the standard to which that particular chapter conforms. Subsequent modifications will be incorporated in the relevant chapters, while information relating to the pre-modified state will be transferred into Appendixes to those chapters.

TABLE 1 Circuit references

Code	Service	Circuit Ref
A	ARMAMENT	
	Conventional bombing installation	A3
	Rocket projectiles installation	A4
	Shared services	A7
	Guided weapons installation	A8
	600 lb/950 lb bombing installation	A12
	Tandem carrier stores installation	A13
	Shared services	A15
	(Refer also to Cover 1, Sect.6, and Cover 2, Sect.7)	

RESTRICTED