Chapter 1 GENERAL INFORMATION

LIST OF CONTENTS

| | | | | | | Para | |
|-------------------------|--|-----|-------|-----|-----|------|--|
| Introduction | | | | ••• | | 1 | |
| Modifications | | ••• | • • • | ••• | ••• | 3 | |
| Access doors and panels | | | | | | 4 | |

Introduction

- 1. This Chapter only covers information peculiar to this aircraft and must, therefore, be read in conjunction with AP 101B-1202-1B, Cover 2, Sect 7, Chap 1 for information that is common to the basic Mk. 2 aircraft.
- 2. As there are slight changes in the cockpit layout, illustrations of the cockpit controls

and indicators are included in Sect 17 of the Servicing Diagrams Manual (SDM).

Modifications

3. The instrument systems described in succeeding chapters of this Section are to Mod 1188 standard. Subsequent modifications will be incorporated in the relevant chapters, while information relating to the

pre-modified state will be transferred into appendixes to those chapters.

Access doors and panels

4. Diagrams showing the locations of access doors and panels with an associated key listing the components to which they provide access, are in Sect 12, Chap 4.

UK RESTRICTED