

WEAPONS

SERVICING PROCEDURES
SERVICING DIAGRAMS
BUCCANEER S MK 2 SERIES


AP101B-1202-5A3B
Sect 3

LIST OF CONTENTS

	SP No.
Gauge Checking and Setting - MDC Plunger to Sear Clearance ...	271
Detonator Fitting/Removal Tool ...	272
Torque Wrench Adapter ...	273
Plug 'B' Transfer Tool ...	274
Not Allocated ...	275-280


GAUGE - CHECKING AND SETTING MDC PLUNGER TO SEAR CLEARANCES (SP 244)

(Material 3/8" Mild steel, case hardened).




DETONATOR FITTING/REMOVAL TOOL (SP 244)

(Material Mild steel with hardened steel pins).



TORQUE WRENCH ADAPTER (SP 244)

(Material 3/8" Mild steel plate, case hardened).



WEAPONS
SP 274
AL 11

SERVICING PROCEDURES
SERVICING DIAGRAMS
BUCCANEER S MK 2 SERIES


AP101B-1202-5A3B
Sect 3

PLUG 'B' TRANSFER TOOL (Sp's 229, 230, 233 and 234)



MATERIALS

No	SEC	RSF	DESCRIPTION	LENGTH
1	-	-	Local material	4"
2	32A	1250218	Kite cord	50"
3	5F	9400950	Insulating sheet	1/16" thick
4	64AE	36	Plastic tubing	12"
5	-	-	Flexible sleeving 0.125i.d.local material.	3 1/2"

PANEL 517
APERTURE



PANEL 494 APERTURE



SMS/12/STC