

SECTION 1 TURN ROUND SPARES

REF NO	PART NO	DESCRIPTION	DETAIL OR REMARKS	DENOM OF QTY	SPECIAL TASKS	SPECIALIST COMPONENT SERVICING BAYS					APPLICABILITY					
						TO SUPPORT 1-3AE	TO SUPPORT 12AE	TO SUPPORT 20AE	TO SUPPORT 35AE		F6	17	17A	T88	GA9	
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

RESTRICTED

AP 101B-1300-30

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5CW</u>														
6001		SWITCH FLOAT		Ea			2	2			X				X	
6159		SWITCH FLOAT		Ea			1	1			X				X	
6185		RELAY TYPER		Ea		1							X	X		
8000		SWITCH FLOAT		Ea			1	1			X	X			X	
9064		SOLENOID		Ea			1	1				X			X	
9065		SOLENOID		Ea			1	1				X				
4400028		SWITCH FUEL LEVEL		Ea			2	2			X	X			X	
4400051		SWITCH ALITUDE		Ea			1	1			X	X			X	
4400098		SWITCH TIME		Ea			2	2			X	X			X	
4400318		LEVER PRESSURE SWITCH CONTROL		Ea			1	1			X	X			X	
4400328		SWITCH		Ea		1							X	X		
4400579		SOLENOID		Ea			1	1			X	X			X	
4402866		SWITCH TIME		Ea		1	1	1				X	X	X		
4402893		ROTAX SWITCH THERMAL		Ea		1	1	1				X	X	X		
4402899		SWITCH THERMAL		Ea			1	1			X				X	
4405036		SWITCH PRESSURE		Ea			1	1			X				X	
4405062		SWITCH PRESSURE		Ea			2	2			X				X	
4405063		SWITCH PRESSURE		Ea			2	3			X				X	
4405065		SWITCH FLOAT		Ea		2	3	4			X	X	X	X	X	
4405069		SWITCH PRESSURE		Ea		1	1	1				X	X	X		
4405078		SWITCH PRESSURE		Ea			1	1			X	X			X	
4405097		SWITCH Time		Ea			1	1			X				X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5CW (CONTD)</u>														
4405115		SWITCH	Ea			1							X	X		
4405149		SWITCH Time	Ea				1	1							X	
4405184		SWITCH Pressure	Ea				1	1			X	X			X	
4408726		SWITCH	Ea			1							X	X		
4664472		SWITCH Push	Ea			1							X	X		
4680628		LEVER Press Switch Control	Ea				1	1			X	X			X	
4706417		SWITCH	Ea			1							X	X		
9729122		SWITCH Mag Relay	Ea				1	1			X				X	
9994686		SWITCH Micro	Ea			1							X	X		
		<u>SECTION 5CX</u>														
4330432		LAMP Anti Collision	Ea			1							X	X		
		<u>SECTION 5CY</u>														
4376060		CIRCUIT Breaker	Ea				1	1			X	X			X	
4376062		CIRCUIT Breaker	Ea				1	1			X				X	
4376082		CIRCUIT Breaker	Ea				1	1			X	X			X	
4376481		CIRCUIT Breaker	Ea				1	1			X	X			X	
4376491		CIRCUIT Breaker	Ea			2	2	2			X	X	X	X	X	

RESTRICTED

AP 101B - 1300 - 3D

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5CY (CONTD)</u>														
4376508		Cut Out Type 'A'		Ea		2	2	2			X	X	X	X	X	
		<u>SECTION 5CZ</u>														
1044107		FLASHER Unit		Ea			1	1				X				
1996659		HORN Electric		Ea			1	1				X				
4335560		AMPLIFIER		Ea			1	1			X				X	
4335604		AMPLIFIER		Ea		1	1	1				X	X	X	X	
4335685		AMPLIFIER		Ea			1	1			X				X	
4334686		AMPLIFIER		Ea		1	1	1				X	X	X	X	
4340133		UNIT Control		Ea			1	1			X	X			X	
6408943		CONTACTOR		Ea		2	4	4			X	X	X	X	X	
7001127		ELEMENT Sensing		Ea			1	1			X	X			X	
7001128		ELEMENT Sensing		Ea			2	2			X	X			X	
		<u>SECTION 5D</u>														
4341105		BOX Distribution		Ea			1	1			X				X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5J</u>														
6140-99-6546954		BATTERY (Post Mod 1436)		Ea			8	14				X			X	
1115903		BATTERY		Ea			5	9			X	X			X	
9105143		BATTERY		Ea		2	8	14			X	X	X	X	X	
9101806		BATTERY		Ea			3	5							X	
9496080		ACCUMULATOR		Ea		4	8				X		X	X		
		<u>SECTION 5UA</u>														
4357524		GENERATOR		Ea			2	2			X				X	
4357526		GENERATOR		Ea		2	1	1				X	X	X		
		<u>SECTION 5UB</u>														
4935		INVERTER		Ea		1	1	1			X	X	X	X	X	
4938		INVERTER		Ea			4	4			X	X			X	
6507		INVERTER		Ea		2							X	X		
4342262		INVERTER		Ea			2	2							X	
4342693		INVERTER		Ea		1							X	X		
4342865		INVERTER		Ea			1	1			X	X				
4343057		INVERTER		Ea			1	1			X				X	
4352384		TRAY		Ea		1							X	X		
4357513		INVERTER		Ea		1							X	X		

RESTRICTED

AP 101B-1300-3D

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5UC</u>														
4375157		REGULATOR		Ea			2	2			X	X			X	
4379019		REGULATOR		Ea			2	2			X	X			X	
4379154		CONTROL Panel		Ea		1							X	X		
4379166		REGULATOR		Ea		1	4	4			X	X	X	X	X	
4379240		CONTROL Panel		Ea			1	1			X	X				
4379475		RELAY		Ea			1	1			X	X				
6369631		CONTROL Panel		Ea			4	4			X	X				
		<u>SECTION 5UE</u>														
4407078		PUMP De-icing		Ea		1	1	1			X	X	X	X	X	
4412103		PUMP Fuel		Ea			1	1			X				X	
4412104		PUMP Fuel		Ea			1	1							X	
4412534		PUMP Fuel		Ea		1	1	1				X	X	X		
		<u>SECTION 5W</u>														
7283		ACTUATOR		Ea		1	2	2			X	X	X	X	X	
4511890		ACTUATOR		Ea			1	1			X	X			X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 5W (CONTD)</u>														
4511891		ACTUATOR		Ea			1	1			X				X	
4511892		ACTUATOR		Ea			1	1			X	X			X	
4511893		ACTUATOR		Ea		1	2	2			X	X	X	X	X	
4511896		ACTUATOR		Ea			1	1			X	X			X	
4511897		ACTUATOR		Ea			1	1				X				
4511961		ACTUATOR		Ea			2	2			X	X			X	
4520736		ACTUATOR		Ea		1	1	1				X	X	X		
4520750		ACTUATOR		Ea		1	2	2			X	X	X	X	X	
		<u>SECTION 6A</u>														
5546		INDICATOR T and S		Ea		1	1	1			X	X	X	X	X	
3953		INDICATOR T and S		Ea			1	1			X	X			X	
1048395		ARTIFICIAL Horizon		Ea		1							X			
1065724		HEAD Pressure Mk 10B		Ea		1	1	1			X		X	X	X	
1146374		ALTIMETER Mk 30A		Ea				2			X	X			X	
4333178		CLOCK Mk 4B		Ea			1	1			X				X	
4333224		INDICATOR AS		Ea			1	1			X	X			X	
4337798		ARTIFICIAL Horizon		Ea			1				X					
4676148		TACHOMETER		Ea			1	1			X	X			X	

RESTRICTED

AP 101B-1300-30

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A (Contd)</u>														
1170854		ALTIMETER Mk 28B		Ea				3				X				
4327995		METER Fatigue		Ea			1	1				X			X	
4332846		SWITCH Diff Mk 1E		Ea		2	1	1			X	X	X	X	X	
4332874		TRANSMITTER		Ea			1	1			X				X	
4333074		GAUGE Oil Press		Ea			1	1				X				
4333267		GAUGE Oil Press		Ea			1	1			X				X	
4333268		TRANSMITTER		Ea			1	1			X				X	
4333270		MACHMETER		Ea		1	1	1			X	X	X	X	X	
4333280		GENERATOR Mk 8C		Ea			1	1			X	X			X	
4333338		INDICATOR Flap		Ea			1	1							X	
4333339		INDICATOR Trim		Ea			1	1							X	
4333344		INDICATOR JPT		Ea			1	1				X			X	
4333422		TRANSMITTER		Ea			1	1							X	
4333728		GAUGE Fuel Contents		Ea			1	1			X				X	
4333735		BOX Relay		Ea			1	1			X				X	
4333736		BOX Relay		Ea			1	1			X				X	
4333788		GAUGE Fuel Contents		Ea			1	1				X				
4333789		BOX Relay		Ea			1	1				X				
4333790		BOX Relay		Ea			1	1				X				
4333791		BOX Cable Connection		Ea			1	1				X				
4333792		BOX Cable Connection		Ea			1	1				X				
4333796		AMPLIFIER		Ea		2	1	1			X	X	X	X	X	
4337752		GAUGE Brake Press		Ea			1	1			X	X			X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6A (Contd)</u>														
4337812		CONTROLLER Levelling		Ea			1	1			X				X	
4337983		THERMOCOUPLE		Ea			8	10			X	X			X	
4338293		ARTIFICIAL Horizon		Ea		1								X		
4338333		CONTROL Box		Ea		1						X	X	X		
4338386		HORIZON Artificial		Ea			1	1				X			X	
4338506		INDICATOR Tailplane		Ea			1	1			X				X	
4338810		HEAD Pressure		Ea			1	1				X			X	
4339155		INDICATOR Rate of Climb		Ea		1	1	1			X	X	X	X	X	
4339363		ALTIMETER		Ea			2	2			X	X			X	
4339830		ALTIMETER		Ea		1							X			
4339897		ALTIMETER Mk 22F		Ea			1	1				X				
4664239		METER Fatigue		Ea		1							X	X		
4685863		ALTIMETER		Ea		1							X	X		
4695406		ACCELEROMETER		Ea		1	1	1			X	X	X	X	X	
6201976		ALTIMETER Mk 29B		Ea				1				X				
6203321		PRESSURE Error Correction Unit		Ea			1	3			X	X			X	
6203327		CORRECTION Module		Ea			1	1			X	X			X	
6206302		ALTIMETER MK 30B		Ea		1	1	1				X	X	X		
7002023		TRANSMITTER		Ea		1	1	1			X	X	X	X	X	

RESTRICTED

AP 101B-1300-3D
SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6B</u>														
1048857		COMPASS Check Steering		Ea		1	1	1			X	X	X	X	X	
4343642		GYRO Unit		Ea			1	1			X				X	
4343643		VARIATION Control Panel		Ea			1	1				X			X	
4343646		AMPLIFIER Unit		Ea			1	1			X				X	
4343681		DETECTOR		Ea			1	1							X	
4343683		CORRECTOR Control Unit		Ea			1	1				X			X	
4343779		REPEATER Heading		Ea			1	1				X				
4343780		MASTER Unit		Ea			1	1				X				
		<u>SECTION 6D</u>														
1039710		REGULATOR Demand		Ea			1	1			X	X			X	
2204340		VALVE Oxygen NR		Ea			1	1			X				X	
2243015		EMERGENCY Oxygen Set		Ea			1	1			X				X	
2243017		EMERGENCY Oxygen Set		Ea			1	1				X				
2243027		EMERGENCY Oxygen Set		Ea			1	1			X				X	
2244063		GAUGE Press Oxygen		Ea			1	1			X	X			X	
2244070		VALVE Reducing		Ea			1	1			X	X			X	
2244774		VALVE Oxygen Charging		Ea			2	2			X	X	X	X	X	
9429894		CYLINDER Gas Oxygen		Ea			1	1			X				X	
9429896		CYLINDER Gas Oxygen		Ea			1	1				X				

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
4506304		<u>SECTION 6G</u> GYRO Unit		Ea		1							X	X		
4551413		<u>SECTION 6S</u> SERVOMOTOR Type B		Ea			1	1				X				
1041269		<u>SECTION 6TD</u> INDICATOR		Ea		1							X	X		
1042363		INDICATOR		Ea		1								X		
1046928		INDICATOR		Ea		1								X		
1048539		CONTROLLER Type B		Ea		1							X			
4550251		INDICATOR Attitude		Ea		1							X	X		
4550304		TRANSDUCER		Ea		1							X			
4550581		GYRO Control		Ea		1							X	X		
4550890		AMPLIFIER		Ea		1							X			
6196168		AMPLIFIER		Ea		1							X	X		
6204710		DISPLAY Nav		Ea		1							X	X		
6204873		COMPUTER		Ea		1							X			
6204874		DISPLAY		Ea		1							X			

RESTRICTED

AP 101B-1300-30

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 6TG</u>														
1148635		TRANSDUCER Static		Ea		1								X		
1139379		TRANSDUCER P-S		Ea		1								X		
1179643		COMPUTER Air Data		Ea		1								X		
		<u>SECTION 7R</u>														
928		CYLINDER Gas		Ea					1		X	X			X	
9638641		PLATE Bottom Feed Casing RH		Ea					1		X				X	
9638670		RECOIL Unit		Ea					5		X	X			X	
9640029		FIRING Unit Electric Mk 2		Ea					36		X	X			X	
9640061		GUN Aden Mk 4 RH		Ea			18	22			X				X	
9640062		GUN Aden Mk 4 LH		Ea			18	22			X	X			X	
9640504		ADAPTOR Cocking		Ea			2	3			X				X	
9640514		UNIT Cocking		Ea					34		X	X			X	
9640517		CRADLE Mk 1		Ea					1		X	X			X	
9640694		SLIDE Rear LH		Ea					11		X	X			X	
9640695		SLIDE Rear RH		Ea					13		X				X	
9640696		PLATE Bottom Feed Casing LH		Ea					1		X	X			X	
9640699		MECHANISM Feed RH Mk 2		Ea					8		X				X	
9640700		MECHANISM Feed LH Mk 2		Ea					8		X	X			X	
9640701		CASING Feed LH		Ea					3		X	X			X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
4177258	MRI-IRV-100	<u>SECTION 15A</u> PARACHUTE Back Mk 9		Ea			3	4			X				X	
4177424	MRI-IRV-431	PARACHUTE Back Mk 36		Ea			3	4			X				X	
4177489	MBEU-4026-PA	PARACHUTE Back Mk 41		Ea		3						X	X	X		
1060622	GQMRI-410	<u>SECTION 15D</u> PARACHUTE Type LB52 Mk 3		Ea			24	34			X	X			X	

RESTRICTED

AP 101B-1300-3D

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 26FX</u>														
543		PACKAGE, Gun Group		Ea			1	1			X				X	
6312		BOX Relay		Ea			1				X				X	
6336		EXTRACTOR Water		Ea			1	1			X	X			X	
6358		DUCT Side Port		Ea			1	1			X				X	
6359		DUCT Side STBD		Ea			1	1			X				X	
8954		BOX, Radio Relay		Ea			1	1				X				
9105		PYLON Inboard Port		Ea		1	1	1			X	X	X	X		
9106		PYLON Inboard STBD		Ea		1	1	1			X	X	X	X		
9364		RELEASE, EM No 1 Mk 1		Ea			2	2				X			X	
9519		FUEL Tank		Ea		2							X	X		
9636		PANEL Generator Control		Ea			1				X					
11751		DROP Tank 230 Gal		Ea				3			X				X	
11832		VALVE, Vapour Release Group		Ea			1	1			X	X			X	
4243528		BOX Radio Relay		Ea			1	1			X				X	
6098420		BOX Relay		Ea			1				X					
6098421		BOX Relay		Ea				1							X	
		<u>SECTION 27A</u>														
4560316		WHEEL Nose		Ea		1	2	2			X	X	X	X	X	
6478424		COVER Outer Nose		Ea		2	4	4			X	X	X	X	X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27A (Contd)</u>														
4560519		TUBE Inner Main		Ea		2	10	20			X	X	X	X	X	
4560810		COVER Outer Main		Ea		4	20	30			X	X	X	X	X	
4560996		WHEEL Main		Ea		4	12	14			X	X	X	X	X	
6502165		TUBE Inner, Nose		Ea		1	2	3			X	X	X	X	X	
		<u>SECTION 27C</u>														
4485199	MRI-RFD-387	PERSONAL Survival Pack Type R Mk 1		Ea		3						X	X	X		
4486078	MRI-RFD-386	PERSONAL Survival Pack Type R Mk 2		Ea			3	4			X				X	
		<u>SECTION 27G</u>														
4619009		MAXARET Unit (LAM)		Ea		1	2	2			X	X	X	X	X	
4618427		PLATE Friction		Ea		8	10	13			X	X	X	X	X	
4618471		PLATE		Ea		12	10	13			X	X	X	X	X	
4618475		PLATE Pressure		Ea		12	10	13			X	X	X	X	X	
4618476		PLATE Pressure		Ea		12	10	13			X	X	X	X	X	
4618754		CYLINDER Operating		Ea			1	1			X	X			X	
4618755		CYLINDER Operating		Ea			1	1			X	X			X	
4618756		CYLINDER Operating		Ea			1	1			X	X			X	

RESTRICTED

AP 101B - 1300 - 3D

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27G (Contd)</u>														
4618757		CYLINDER Operating		Ea			1	1			X	X			X	
4618814		CYLINDER Sub Assy		Ea			2	2			X	X			X	
4618815		CYLINDER Sub Assy		Ea			2	2			X	X			X	
6456466		MAXARET Unit (TCM)		Ea		1	2	2			X	X	X	X	X	
		<u>SECTION 27J</u>														
1502625		HANDLE Control		Ea			6				X					
1502626		HANDLE Control		Ea			6	6				X			X	
1502627		HANDLE Control		Ea		1	3	1				X	X	X		
		<u>SECTION 27KD</u>														
4631569		VALVE Unit		Ea			1	1			X	X			X	
		<u>SECTION 27KF</u>														
1445575		FILTER		Ea		1							X	X		
4542587		HYDROBOOSTER Aileron Port		Ea			1	1				X				
4542588		HYDROBOOSTER Aileron STBD		Ea			1	1				X				
4542600		HYDROBOOSTER Elevator		Ea			1	1			X	X			X	
4542609		UNIT Control Assy Port		Ea			1	1			X				X	
4542610		UNIT Control Assy STBD		Ea			1	1			X				X	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27N</u>														
4526466		EXTINGUISHER Fire		Ea			1	1			X	X			X	
4526467		EXTINGUISHER Fire		Ea			1	1			X				X	
4526464		SWITCH Inertia		Ea			1	1				X				
		<u>SECTION 27QM</u>														
4117882		VALVE, Emergency		Ea			1	1			X	X			X	
4117933		VALVE, Shuttle		Ea			1	1			X	X			X	
4117642		VALVE P/R		Ea			1	1			X	X			X	
4117906		VALVE Air Release		Ea			1	1			X	X			X	
4117955		VALVE Shuttle		Ea			1	1			X	X			X	
4118049		RESERVOIR		Ea			1	1			X				X	
4117993		ACCUMULATOR Group		Ea		1	1	1			X	X	X	X	X	
4117998		ACCUMULATOR Group		Ea		1	1	1			X	X	X	X	X	
4118079		JACK Flap STBD		Ea			1	1			X	X			X	

RESTRICTED

AP 101B-1300-3D

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 27QM (Contd)</u>														
4117762		VALVE Selector		Ea		1	1	1			X	X	X	X	X	
4117803		UNIT Control		Ea		1						X	X			
4117681		VALVE Sequence		Ea			1	1			X	X			X	
4118785		VALVE Recuperator		Ea			1				X					
4118786		VALVE Recuperator		Ea			1	1							X	
4118870		SHOCK Absorber		Ea		1	1	1			X	X	X			
4117840		UNIT Selector		Ea		1							X	X		
4117815		UNIT Selector		Ea		1							X			
1491378		MAIN U/C Port		Ea			1				X					
1491382		MAIN U/C STBD		Ea			1				X					
1491736		JACK U/C Port		Ea			2	2			X	X			X	
1491737		JACK U/C STBD		Ea			2	2			X	X			X	
		<u>SECTION 27UA</u>														
4612031		EXTRACTOR Water		Ea		1							X	X		
4612822		UNIT, Cold Air		Ea			1	1			X				X	
4612946		UNIT, Cold Air		Ea			1	1				X				

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
4604671		<u>SECTION 27V</u> VALVE Solenoid		Ea			1	1			X	X			X	
4625911		<u>SECTION 27VA</u> ACCUMULATOR		Ea			2	2			X	X			X	
4495776		<u>SECTION 27VB</u> VALVE Anti 'G'		Ea			2	2			X	X			X	
4497179		VALVE		Ea			1	1			X				X	
4497626		VALVE		Ea			1	1			X	X			X	
1409 or 4387626 or 4387755		<u>SECTION 37A</u> HE IGNITION Unit		Ea		2	2	2			X	X	X	X	X	

RESTRICTED

AP 101B-1300-30

SECTION 1

SEE SHEET NO 3 FOR COLUMN HEADINGS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
		<u>SECTION 37F</u>														
4380013		Starter		EA			2	2								x
4380014		Box Control		EA			2	2			x					x
4380018		HF Ignition Unit		EA			1	1								x
4380039		Pump		EA			1	1			x					x
4380040		Switch HP		EA			1	1			x					x
4380045		Switch Ignition		EA				1			x					x
4381282		Starter		EA			1	1				x				

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

