

Sheet 1

MASTER SERVICING SCHEDULE

AP101B-1300-5A1

AL32

HUNTER ALL MARKS

Section 1

LIST OF COMPONENTS/SUB-ASSEMBLIES REQUIRING RECORD/LOG CARDS

This list contains all items that require record/log cards (MOD Form 700 series/RAF Form 4800 series) in accordance with AP100A-01, Lft 330.

Sched Ident No./ Part No	Item	Form No	Sched Ident No./ Part No	Item	Form No
043803	ECU Mk 12201	479	37J/4602111	Hydraulic Pump	735A
044203	Starter	735	27G/4617745	Brake Control Valve	735A
044211	Starter	735A	043904	Jetpipe Mk 123	735A
044202	Starter	735A	015615	Jack, Hood Locking	735A
27KF/4542609	Aileron PFCU(Port)	735A or	27QM/4118485	Jack, Hood Operating	735A
27KF/4542610	Aileron PFCU(Starboard)	4805	27QM/4118332	Jack, Airbrake(Pre Mod 1363)	735A
27KF/4542600	Elevator PFCU	735A or	27QM/4118491	Jack, Airbrake(Mod 1363)	735A
26FX/12299	Port Mainplane(Mk 7)	4805	011603	Jack, Flap Synchronizing(Port)	735A
26FX/12300	Starboard Mainplane(Mk 7)	735A or	011603	(27QM/4118282)	735A
26FX/9338	Fin	4805	011602	Jack, Flap Synchronizing(Starboard)	735A
044104	HP Fuel Pump	735A	013118	(27QM/4681527)	735A
044105	HP Fuel Pump	735A	013118	Jack, Flap(2 off)	735A
044106	HP Fuel Pump	735A	013104	Jack, U/C Door(Port)	735A
27KF/1445575	Aileron and Elevator Micronic Filters (2 off)	735A	013104	(27QM/4118272)	735A
044108	A.C.U. and Metering Valve	735A	27QM/1446000	Jack, U/C Door(Starboard)	735A
044109	P.V. Ram	735A	27QM/1491373	(27QM/4118275)	735A
044110	Governor	735A	27QM/70028	Jack, Nose U/C(Pre Mod 1284)	735A
044111	B.C.V.U.	735A	27QM/70029	(27QM/4118208)	735A
044112	Anti-icing Valve	735A	27QM/1491378	Jack, Nose U/C(Mod 1284)	735A
044113	Anti-icing Actuator	735A	27QM/1491382	(27QM/4680126)	735A
044114	Fuel Filter De-icing Switch	735A	27QM/1448750	Leg, Nose U/C(Pre Mod 1401)	735A
044115	Gun Operated Air Bleed Valve GU	735A	27QM/1448752	Leg, Nose U/C(Mod 1401)	735A
044116	Gun Operated Fuel Dip Unit	735A	27QM/1491736	Leg, Main U/C Port(Pre Mod 1402)	735A
044117	T.T.C. Actuator	735A	27QM/1491737	Leg, Main U/C Starboard(Pre Mod 1402)	735A
044118	F.C.O.C.	735A		Leg, Main U/C Port(Post Mod 1402)	735A
044004	Oil Pressure Transmitter	735A		Leg, Main U/C Starboard(Post Mod 1402)	735A
044107	C.F.C.U.	735A		Jack, Main U/C Port(Pre Mod 1432)	735A
				Jack, Main U/C Starboard(Pre Mod 1432)	735A
				Jack, Main U/C Port(Post Mod 1432)	735A
				Jack, Main U/C Starboard(Post Mod 1432)	735A

SMS/88/8/2

MASTER SERVICING SCHEDULE

HUNTER ALL MARKS

AP1010-1000-5A1

(1st Edition)

List of Servicing Instructions incorporated in this schedule

IN PHASE												OUT OF PHASE								
Trade	Sched Ident No.	SI Title	Incorporated in									Trade	Sched Ident No.	SI Title	Incorporated in					
			5A1	5A2	5A3	5B1		5B2	5C	5D	5G				5A1	5A2	5A3	5F	5G	Asso AP
Airframe	015203	SI/Hunter/19	Yes		418			Yes				Airframe	010307	SI/Hunter/56A	Yes		407			
	010518	/23	Yes		428			Yes					010612	/119	Yes					
	010526	/133	Yes		450			Yes		Yes			010624	/119	Yes					
	010802	/40	Yes		403				Yes				015112	/76	Yes		415			
	015202	/51	Yes		405			Yes					011365	/101	Yes		434			
	013109	/54	Yes		406				Yes				013206	/106A	Yes		440			
	010614	/58	Yes		408			Yes					010811	/132A	Yes		447			
	010611	/130A	Yes		422			Yes	Yes											
	010622	/61	Yes		410				Yes											
	010606	/62	Yes			Yes														
	010605	/63	Yes					Yes												
	013022	/64A	Yes		411			Yes												
	011359	/65A	Yes		412			Yes												
	011347)	/68A	Yes					Yes												
	011348)																			
	011374	/33	Yes		401			Yes												
	010208	/71B	Yes		413			Yes												
	011607	/73	Yes					Yes												
	013030)	/138	Yes		415				Yes	Yes										
	013031)																			
	013101	/72D	Yes		135			Yes												
	012810)	/77	Yes		416				Yes											
	013215)																			
	012820)	/78B	Yes		417				Yes											
	012818)																			
	011320)	/82C	Yes		419				Yes											
	011334)																			
	011328)																			
	010305	/83A	Yes		420			Yes												
	010613	/84B	Yes		421			Yes												
	011316	/87B	Yes		423				Yes											
	013102	/88	Yes		432			Yes												
	013101	/99	Yes		433			Yes												
	011365	/101	Yes		434				Yes											
	010607	/103B	Yes		435			Yes												
	015207	/136B	Yes		448			Yes												

IN PHASE

IN PHASE											
Trade	Sched Ident No	SI Title	Incorporated in								
			5A1	5A2	5A3	5B1		5B2	5C	5D	5G
Airframe (Contd)	010220	SI/Hunter/105	Yes		409			Yes			
	015109	/107A	Yes		441			Yes	Yes		
	010625	/112A	Yes		443			Yes			
	010626	/121D	Yes		424				Yes		
	010627	/123	Yes		404					Yes	
	010601	/125	Yes		431				Yes		
	010807	/128B	Yes					Yes	Yes		
	013027	/129	Yes					Yes			
	016801	SI/Inst /19A	Yes			Yes					
	013101	/100A	Yes		436			Yes			
Weapons	020813	SI/Hunter/31	Yes			Yes					
	029007)	/49A	Yes		453			Yes			
	029193)										
	029305	/136B	Yes		448			Yes			
Electrical	036105	SI/Elect/24B	Yes		467				Yes		
	036102	/30	Yes		466				Yes		
	036811	/74A	Yes		469				Yes		
Propulsion	043904	SI/AVON/17	Yes						Yes		
	045210	SI/Hunter/29	Yes			Yes					
	045001)	/30C	Yes		477				Yes		
	045002)										
	046401	/48A	Yes			Yes					
	045302	/55B	Yes		482			Yes			
SMS/ 86/8/8A											

SMS/ 86/8/8A

OUT OF PHASE

OUT OF PHASE								
Trade	Sched Ident No.	SI Title	Incorporated in					
			5A1	5A2	5A3	5F	5G	Asso AP
Weapons	029304	SI/Hunter/44a	Yes		452			
	020816	SI/Eject Seat/20A	Yes		451			
	020825)	/27	Yes		52			
	020808)							
	020806	/37A	Yes		52			
	020829	/43	Yes		54			
029310	SI/Armament/45B	Yes		458				
Propulsion	044406	SI/Hunter/14A	Yes		481			
	044411	/32B	Yes		486			
	043814)	/46	Yes		483			
	043815)							
	045312	/104	Yes		81			
	044208	/117	Yes		488			

IN PHASE											OUT OF PHASE									
Trade	Sched Ident No.	SI Title	Incorporated in								Trade	Sched Ident No.	SI Title	Incorporated in						
			5A1	5A2	5A3	5B1	5B2	5C	5D	5G				5A1	5A2	5A3	5F	5G	Asso AP	
Propulsion (Contd)	045212	SI/Hunter/85A	Yes		479			Yes												
	045309	/91A	Yes		480		Yes	Yes												
	045303	/92A	Yes		478		Yes													
	045206	/113	Yes		489			Yes												
	045215	/134	Yes					Yes												
	043901	SI/AVON/ 40	Yes				Yes													
	045310	SI/MISC/ 101	Yes							Yes										
Air Radar	077505)	SI/Hunter/ 50	Yes			Yes														
	077506)																			
	077903	/115A	Yes				Yes													
	077706) 077703)	SI/Radar/ 15	Yes		506		Yes													
Air Comms	088402	SI/Rad Air/64B	Yes		511		Yes													
SE	130815	SI/Safety Equip/24C	Yes			Yes														
NDT	150301)	SI/Hunter/96A	Yes					Yes	Yes	ULT	NDT	153101)	SI/Hunter/102A	Yes				ULT		
	150302)											153102)					2C			
	150501	/135	Yes					Yes	Yes	MAG3 12A3		152801)	/111	Yes			ULT			
												152802)					5A			
	150601)	/124	Yes					Yes	Yes	EDD 4A		153001	/116	Yes			ULT			
	150602)																6A			
	152807)	SI/Hunter/122	Yes						Yes	Edd 6A		152803)	SI/Hunter/122	Yes			EDD			
	152808)											152804)					6A			
	152811)	/127	Yes						Yes	EDD 9		152809)	/127	Yes			EDD			
	152812)											152810)					9			
153103)	/131A	Yes				Yes														
153104)																				
152805)	/111	Yes							Yes	ULT 5A		153801	SI/Avon/74F	Yes						
152806)																				

SM 92/1365 (2)

MASTER SERVICING SCHEDULE
HUNTER ALL MARKS
CONTINGENCY OPERATIONS IN SCHEDULED SERVICING
PF 200

60 Hours		120 Hours		240 Hours		480 Hours		960 Hours		Out of Phase	
Operation	Sched Ident No	Operation	Sched Ident No	Operation	Sched Ident No	Operation	Sched Ident No	Operation	Sched Ident No	Operation	Sched Ident No
2	010512	2	013005	2	010621					14 days	076304
	010516	2	013006		011307					14 days	077502
	011704	2	013007		011309					14 days	088401
	011706	2	013008		011368					14 days	088601
2	011707	2	013010	2	012821						
2	011708	2	013017	2	044317						
2	011711	2	013027	2	044325						
	011705	2	013105	2	044326						
3	012810	2	010409		044304						
3	012811	2	010410								
3	012812	2	010411								
3	012817		010503								
3	012818	2	013018								
3	012820	2	013107								
2	013002		010621								
3	013015	2	012802								
	013022		012803								
2	019001	2	012804								
3	019002		012806								
	044214	3	012822								
	044215	2	013013								
	044216	2	013019								
		2	013023								
		2	013115								
		3	012823								
			012824								
			012825								
			012826								
			012827								
		2	013004								
		2	013016								
		2	013020								
			013024								
		2	013117								
			010615								
			010814								

AL 29 ▶ ◀

MASTER SERVICING SCHEDULE
HUNTER ALL MARKS
LIST OF SERVICING GROUPS OCCUPIED DURING SERVICING

AP101B-1300-5A1
(1st Edition)

01 Aircraft General	55 Fire Protection System	80 ILS Installation
02 Front Fuselage	56 Hood Operating System	81 I/C Installation
03 Centre Fuselage	57 Windscreen Wiper System	82 Telebriefing Installation
04 Rear Fuselage	58 Emergency Air System	83 Radio Compass Installation
05 Tail Unit	59 Anti-G System	84 UHF Installation
06 Mainplanes	60 Electrical Power Supplies and Distribution	85 Standby UHF Installation
08 Emergency Equipment	61 Internal and External Lighting	86 PTR 175 Installation
13 Flying Control Operating System	62 Electrical Armament Services	87 Master Reference Gyro
14 Trim Control Operating System	63 IFF/SSR Installation (If fitted)	88 Autostabilizer Mk 2 (If fitted)
15 Airbrake Operating System	64 Jet Pipe Temperature Control System	90 Gun Package Installation
16 Flap Operating System	65 Radar Supplies	91 Aden Gun Installation
17 Brake Parachute System	66 Flight Instruments	92 Rocket Installation (If fitted)
18 Arrestor Gear System	67 Oxygen System	93 Pylon Installation
28 Main Undercarriage	68 Pitot/Static System	94 Photographic Installation (If fitted)
30 Nose Undercarriage	69 Compass Installation	95 SNEB Rocket Installation
31 Undercarriage Operating System	70 Mk 5 Gunsight Installation (If fitted)	96 Airborne Towed Targets, Winches and Ancillary Equipment
32 Wheel Brake System	71 Mk 8 Gunsight Installation (If fitted)	
38 Basic Engine	72 Flight Instrument Supplies	
39 Jet Pipe	73 Air Data System	
40 Engine Oil System	74 Navigational Display System	
41 Engine Fuel System	75 Rebecca Mk 8 Installation	
42 Engine Starting and Ignition System	76 IFF Mk 10 Installation (SIF of Basic) (If fitted)	
43 Engine Control System	77 Radar Ranging Installation (If fitted)	
44 Ancillary Drives	78 VHF Installation	
50 Hydraulic Power System	79 Tacan Installation	
51 Cabin Pressurization and Air Conditioning System		
52 Aircraft Fuel System		
53 Fuel Pressurization System		

SMS/86/8/11

AL 29 ▶ ◀

MASTER SERVICING SCHEDULE
HUNTER ALL MARKS

AP101B-1300-5A1
(1st Edition)

CONTENTS

- Section 1 - Master Servicing List
- Section 2 - Component Replacement List
- Section 3 - Component Life Register
- Section 4 - Routine and Out of Phase
Servicing Register

SMS/86/8/12

AL29▶◀

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

List of Chapters																	Sheet No	No of Sheets
Chapter 1 - Airframe	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-39	39
Chapter 2 - Weapons	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-5	5
Chapter 3 - Electrical	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-15	15
Chapter 4 - Propulsion	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-11	11
Chapter 5 - Not Allocated	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	NIL	NIL
Chapter 6 - Flight Systems	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-4	4
Chapter 7 - Air Radar	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-3	3
Chapter 8 - Air Communication	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-4	4
Chapter 9 - Photographic	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-1	1
Chapter 10 - NBS	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	NIL	NIL
Chapter 11 - Painter and Finisher	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-1	1
Chapter 12 - ECM	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	NIL	NIL
Chapter 13 - Safety Equipment	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-1	1
Chapter 14 - General Engineering	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	NIL	NIL
Chapter 15 - NDT	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	...	1-3	3

SMS/86/8/13

Chapter 1 AIRFRAME
Sheet 8
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																			

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										QTY
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C	9		
010606	N/A	Pylon attachment bolts. (Pre Mod 964 and 965).	Ensure tight. (Introduced by SI/Hunter/62).		N/A	A/F									X	X	X	X	X	X	X			
010607	B015 B018	Pylon mounting brackets.	Look for cracks. (Introduced by SI/Hunter/103B).			Primary*		X	X	X		X				X					X			
010608	N/A	Aileron hinge attachment brackets.	Examine. (Ailerons removed).	Y		Major						X			X	X	X	X	X	X	X			
010625	A007 A010	Nose ribs H, J, K, L and N.	Examine. (SP 443). (Introduced by SI/Hunter/112A).		A93 A96	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X			
010626	A041 A042	Top skin between rib 'S' and outer aileron hinge rib.	Examine. (SP 424). (Introduced by SI/Hunter/124D).		A94 A95	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X			
010627	N/A	Pylon attachment bolts.	Replace. (Scrap).		A174 A175	Major						X	X		X	X	X	X	X	X	X			
010629	A008 A011	Upper and lower skin in an area approximately 5" x 5" centred on rear rocket launcher mounting post.	Examine.			Primary	X	X	X	X		X			X	X					X			
010631	N/A	Flap hinge attachments.	Examine. (Flap removed).		A316 A333	Major (2)						X			X	X	X	X	X	X	X			
010632	N/A	Fuel tank compartments.	Examine.		A321 A338	Major (2)						X			X	X	X	X	X	X	X			
010633	N/A	Leading edge detachable nosing.	Examine. (Removed).		A313 A330 A357 A368	Major (2)						X			X	X	X	X	X	X	X			
010634	N/A	Nose ribs 1, 2 and 3.	Examine.		A313 A330	Major (2)						X			X	X	X	X	X	X	X			
010641	N/A	FRONT LOWER SPAR BEAMS (Issue 1)	CARRY OUT CSDE/HUNTER/MAGEL (INTROD BY SI HUNTER 631)	Y	N/A	Every 6 FT.											X	X	X	X				
SMS/36/1/5A														Continued										

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY				
							P	P*	M	M*	MJ	MJ (2)				7	7A	8B	8C						
MAINPLANES - 06 (Port and Starboard) (Contd)																									
010609	CO37 CO40	Port and Starboard Aileron Assemblies Aileron.	Examine.	Y	N/A	Minor				X	X							X	X	X	X				
	N/A		Examine. (Removed).	Y	A17 A18 A22 A23 A150 A152	Major					X	X						X	X	X	X				
010610	A006 A009	Drainage holes.	Ensure clear.		A22 A23	Primary	X	X	X	X	X	X						X	X	X	X				
010635	N/A	Hinge attachment points.	Examine.		A315 A332	Major (2)						X						X	X	X	X				
010611	A007 A010	Centre hinge block.	Examine. (Introduced by SI/Hunter/130A).		N/A	Primary	X	X	X	X								X	X	X	X				
	N/A		Examine. (Removed). (SP 422). (Introduced by SI/Hunter/130A).		A22 A23	Major					X	X						X	X	X	X				
010612	N/A	Shackle. (Aileron Lever Group Mod 1133).	See CRL. (Introduced by SI/Hunter/119).		N/A													X	X	X	X				
010613	B045	Nose balance assembly.	Examine. (SP 421). (Introduced by SI/Hunter/84B).		A22 A23	Primary		X	X	X	X	X						X	X	X	X				
010624	N/A	Shackle.	See CRL. (Introduced by SI/Hunter/119).		N/A													X	X	X	X				
SMS/86/8/22																			Continued overleaf						

[illegible]

MASTER SERVICING LIST
HUNTER ALL MARKS

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9			
MAINPLANES - 05 (Port and Starboard)(Contd)																								
010621	B020 B022	<u>Port and Starboard Flap Assemblies (Contd)</u> Jack attachment pivot bolts.	Lubricate.		A151 A153	Primary*		X	X	X	X	X			X	X	X	X	X	X	X			
	N/A		See CRL.		N/A									X	X	X	X	X	X	X				
010637	N/A	Flap jack operating lever attachment bolt. (Pt No F170109).	Replace. (Scrap).		A364 A375	Major (2)					X			X	X	X	X	X	X	X				
010628	B020 B022	<u>Anchorage Shackles</u> Bolt flap jack.	Lubricate.		A151 A153	Primary*		X	X	X	X	X			X	X	X	X	X	X	X			
	N/A		See CRL.		N/A																			
010622	C041 C042	Rib to tubular spar attachment ferrules.	Ensure tight and locked. (Introduced by SI/Hunter/61).		A19 A20	Minor			X	X	X	X			X	X	X	X	X	X	X			
010623	N/A	<u>Port and Starboard Undercarriage Compartments</u> Structure.	Look for obvious damage.		N/A	T/R,A/F									X	X	X	X	X	X	X			
	C036 C038		Examine as far as possible.	Y	A113 A114	Minor			X	X	X				X	X	X	X	X	X	X			
	N/A		Examine.	Y	A328 A343	Major (2)						X			X	X	X	X	X	X	X			
Continued overleaf																								

SMS/86/5/6

SMS/86/5/6

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark									CTY		
							P	P*	M	MM	MJ	MJ (2)						6	6A	7	7A	8B		8C	9
010638	N/A	Internal skin.	Examine.		A328 A343	Major (2)						X				X	X	X	X	X	X	X			
010639	N/A	Mainplane Rib G.	Examine. (Leg removed).		A328 A343	Major (2)						X				X	X	X	X	X	X	X			
010640	N/A	Main undercarriage attachment points.	Examine. (Leg removed).		A328 A343	Major (2)						X				X	X	X	X	X	X	X			
AL37 010642		LEADING EDGE TAPE.	EXAMINE.		A145	PRIMARY	X	X	X	X	X	X					X	X	X	X					
AL41 010642	NA	AIRCROW HYDROBOOSTER PORT & SEED	APPLY PROTECTIVE COATING		N/A	28 DAYS											X	X	X	X	X				
EMERGENCY EQUIPMENT - 08																									
010801	N/A	Hood Jettison System System.	Blow test.		N/A	Each Ejection Seat Removal	Out of Phase (SP 51B)									X	X	X							
010802	BO08	Complete system.	Functional test.		A177	Primary*		X	X	X	X	X					X	X	X	X					
	CO13		Operate by using external emergency release handle. (Introduced by SI/Hunter/40).				Minor			X	X		X		X	X					X				
SMS/31/104																									
																							Continued		

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							QTY				
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A		8B	8C	9	
EMERGENCY EQUIPMENT - O8 (Contd)																									
010807	G101	Hood Jettison System (Contd) Hood jettison mechanism release unit.	Replace. (Bay Service). (Introduced by SI/Hunter/128B).		A108 A155	Minor			X	X	X	X					X	X	X	X					
	D015					Minor*				X	X	X			X	X					X				
010808	C013	Cables.	Examine.			Minor			X	X		X			X	X					X				
010803	N/A	Cockpit White headed shackle pins.	Ensure aligned with indicators.		N/A	B/F,T/R									X	X					X				
010804	B008 B010	Hood jettison mechanism.	Lubricate.		A155	Primary*		X	X	X	X	X			X	X	X	X	X	X	X			X	
010811	N/A	Hood jettison mechanism. connecting rod.	Examine. (Introduced by SI/Hunter/132A).		N/A	Each Scheduled Ejection Seat Removal	Out of Phase (SP 447)									X	X	X	X						
010812	N/A	Emergency screwdriver stowage.	Ensure stowed correctly.		N/A	A/F										X	X	X	X						
010806	N/A	First aid pack. (If fitted).	Ensure seal intact.		N/A	B/F										X	X	X	X						
	N/A		See CRL.													X	X	X	X						
010805	N/A	Ejection Seat Emergency oxygen set Mk 7A or 7B.	See CRL.													X	X	X	X						
010812	N/A	Emergency Oxygen Set Mk 7H	See CRL.												X	X					X				
SMS/ 62/ 10/77																			Continued overleaf						

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9				
010809	N/A	Emergency oxygen system.	Examine.		N/A	Each Scheduled Ejection Seat Removal										X	X						X				
			Operate.		N/A									X	X							X					
010810	N/A	Emergency oxygen system control cable.	Lubricate.		N/A												X	X						X			
FLYING CONTROL OPERATING SYSTEMS - 13																											
011301	N/A	<u>General</u> Aileron system.	Ensure pressure exhausted.		N/A	B/F,T/R A/F										X	X	X	X	X	X	X	X				
	C088		Test.		A165	Minor			X	X	X	X				X	X	X	X	X	X	X					
	N/A		Check range of movement.		A165	Major					X	X				X	X	X	X	X	X	X					
SMS/																											
Continued																											

Continued

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY			
							P	P*	M	M*	MJ	MJ (2)												
FLYING CONTROL OPERATING SYSTEMS - 13 (Contd)																								
011302	N/A	<u>General</u> (Contd) Elevator system.	Ensure pressure exhausted.		N/A	B/F,T/R A/F												X	X	X	X			
	C088		Test.		A165	Minor				X	X	X	X					X	X	X	X			
	N/A		Check range of movement.		A165	Major					X	X						X	X	X	X			
011303	N/A	Rudder system.	Check range of movement.		A165	Major					X	X						X	X	X	X			
011304	N/A	Tailplane system.	Operate.		N/A	A/F												X	X	X	X			
	N/A		Check range of movement.		A168	Major					X	X						X	X	X	X			
011305	N/A	<u>Cockpit</u> Control bearings.	Examine. (Removed).		A262	Major (2)						X						X	X	X	X			
			Lubricate.		A263	Major (2)						X						X	X	X	X			
011306	C043	Control column(s).	Examine.		A105	Minor				X	X	X	X					X	X	X	X			
011307	C043	Control column chains.	Check tension.		A105	Minor				X	X	X	X					X	X	X	X			
			Lubricate.		A154	Minor				X	X	X	X					X	X	X	X			X
011308	C043	Chain end connexions.	Ensure locked correctly.		A154	Minor				X	X	X	X					X	X	X	X			
011309	C043	Control column head joints and sprockets.	Examine.		A105	Minor				X	X	X	X					X	X	X	X			
			Lubricate.		A154	Minor				X	X	X	X					X	X	X	X			X
Continued overleaf																								

ONE 18619/125

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CT				
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C					
FLYING CONTROL OPERATING SYSTEMS - 13 (Contd)																									
011319	N/A	<u>Front Fuselage</u> (Contd) Control bearings.	Examine. (Removed). (SP 425).		A263	Major (2)						X						X	X	X	X				
			Lubricate. (Removed). (SP 425).		A263	Major (2)					X								X	X	X	X			
011320	CO44	Aileron, rudder and elevator control tubes. (Frame 11 to 18A).	Examine. (Introduced by SI/Hunter/82C).		A75	Minor				X	X	X	X					X	X	X	X				
011321	CO44	Aileron, rudder and elevator control mounting and idling links. (Frames 11 to 18A).	Examine.		A75	Minor				X	X	X	X					X	X	X	X				
011322	A026	Aileron two position jack flexible hose. (Pre Mod 1424).	Examine.		A77	Primary	X	X	X	X	X	X						X	X	X	X				
	N/A		See CRL.															X	X	X	X				
011384	AQ26	Aileron two position jack flexible hose. (Post Mod 1424).	Examine.		A77	Primary	X	X	X	X	X	X						X	X	X	X				
	N/A		Servicing deleted by AL 24.																						
011324	CO45	Aileron torque tube and universal joints.	Clean.		A105	Minor				X	X	X	X					X	X	X	X				
			Examine.		A105	Minor				X	X	X	X					X	X	X	X				
			Lubricate.		A154	Minor				X	X	X	X					X	X	X	X				
SMA/ 86/8/26															Continued overleaf										

Ident No	d No	Item	operation	Code	Major Card No.	Frequen	P*	M	M*	LJ	(2)				7	7A	8B	8C			QTY
011325	N/A	Aileron two position jack shuttle valve.	Replace. (Bay Service).		A80 A126	Major				X	X				X	X	X	X			
011323	N/A	Servicing deleted.	Servicing deleted by AL 6.																		
011326	CO45	Aileron two position jack.	Clean.		N/A	Minor		X	X						X	X	X	X			
	N/A		Replace. (Bay Service).		A80 A126	Major				X	X				X	X	X	X			
011327	N/A	<u>Centre Fuselage</u> Control bearings.	Examine. (Removed). (SP 426).		A263	Major (2)					X				X	X	X	X			
			Lubricate. (Removed). (SP 426).		A263	Major (2)					X				X	X	X	X			
011328	CO46	Aileron, rudder and elevator control tubes. (Frames 18B to 40A).	Examine. (SP 419). (Introduced by SI/Hunter/82G).		A88	Minor		X	X	X	X				X	X	X	X			
011329	CO46	Aileron, rudder and elevator control mounting and idling links. (Frames 18B to 40A).	Examine.		A88	Minor		X	X	X	X				X	X	X	X			
011330	CO46	Aileron, rudder and elevator control connecting and adjusting points. (Frames 18B and 40A).	Examine.		A88	Minor		X	X	X	X				X	X	X	X			
			Ensure locked correctly.		A88	Minor		X	X	X	X				X	X	X	X			
011331	A025	Elevator hydraulic flexible hoses. (Frame 40). (Pre Mod 1425).	Examine.		A86	Primary	X	X	X	X	X				X	X	X	X			
	N/A		See CRL.												X	X	X	X			

SMS/ 86/8/26 A

Continued

[illegible]

MASTER SERVICING LIST
HUNTER ALL MARKS

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9			
AIRCRAFT GENERAL - 01																								
010101	N/A	<u>Aircraft</u> External areas.	Look for obvious damage and signs of leaks.		N/A	B/F,T/R, A/F										X	X	X	X	X	X	X		
010102	C100	Mandatory markings.	Ensure legible.		A192	Minor			X	X	X	X				X	X	X	X	X	X	X		
010103	C100	Panel fastener locking markings.	Ensure legible and indicating locked position.		A192	Minor			X	X	X	X				X	X	X	X	X	X	X		
010104	A050	Aircraft.	Wash. (SP 437).		A199	Primary	X	X	X	X	X	X				X	X	X	X	X	X	X		
	N/A		Rig.		A250	Major (X2)					X				X	X	X	X	X	X	X			
	N/A		Check alignment.		A251 A384	Major (X2)					X				X	X	X	X	X	X	X			
010105	N/A	Link collector blisters.	Ensure secure.		N/A	B/F,T/R, A/F										X	X					X		
010106	N/A	<u>Cockpit</u> Surface finish.	Restore as necessary.		A354	Major (X2)						X				X	X	X	X	X	X	X		
010107	N/A	Instructional notices.	Ensure legible.		A354	Major (X2)						X				X	X	X	X	X	X	X		
SMS/86/5/2														Continued overleaf										

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9		
FRONT FUSELAGE - 02																									
010201	N/A	<u>Main Structure</u> Skin.	Remove soot deposits. (After gun firing).		N/A	A/F											X	X	X	X	X	X	X		
	CO20		Examine.	Y	A97	Minor			X	X	X	X			X	X	X	X	X	X	X				
	N/A		Examine particularly in vicinity of nose jacking position. (Leg removed).	Y	A255	Major (2)						X			X	X	X	X	X	X	X				
010228	N/A	Frame 1C.	Examine and particularly for cracks in vicinity of equipment mounting brackets.		A254	Major (2)						X				X	X								
010202	A016	Drainage holes.	Ensure clear.		A97	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X				
010203	B012	Step hinges and spring.	Lubricate.		A125	Primary*		X	X	X	X	X			X	X	X	X	X	X	X				
	N/A		Examine.		A258	Major (2)					X			X	X	X	X	X	X	X					
010204	N/A	Nose undercarriage compartment structure.	Look for obvious damage.		N/A	T/R,A/F									X	X	X	X	X	X	X				
	B012		Examine.	Y	A99	Primary*		X	X	X	X	X			X	X	X	X	X	X	X				
010229	N/A	Nose undercarriage attachment points.	Examine. (Leg removed).		A255	Major (2)						X			X	X	X	X	X	X	X				
010218	C008	Frame 3 - starboard stiffener. (Pt No B174470).	Examine and particularly for cracks.		A99	Minor			X	X	X	X			X	X	X	X	X	X	X				
010223	A017	Frames 3, 4, 5 and 6 starboard.	Examine and particularly for cracks.		A100	Primary	X	X	X	X	X	X					X								
010205	C018	Internal structure.	Examine as far as possible.	Y	A99	Minor			X	X	X	X			X	X	X	X	X	X					
010206	CO24	Frames 6, 7 and 8 attachments to nosewheel landing.	Examine. (Blast tube removed).	Y		Minor			X	X		X			X	X					X				
Continued																									

SMS/86/5/2A

MASTER SERVICING LIST
HUNTER ALL MARKS

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C	9			
FRONT FUSELAGE - O2 (Contd)																									
010230	N/A	Main Structure (Contd) Frames 3, 4 and 5.	Examine.		A255	Major (2)							X				X	X	X	X	X	X	X		
010231	N/A	Frames 6, 7 and 8.	Examine.		A255	Major (2)							X				X	X	X	X	X	X	X		
010207	C024	Frame 11 below cockpit floor.	Examine.	Y		Minor			X	X		X				X	X					X			
010208	B011	Rudder inboard bearing lever mounting.	Examine. (SP 413). (Introduced by SI/Hunter/71B).		A6	Primary*		X	X	X	X	X			X	X					X				
010209	C023	Ram air inlet orifice.	Examine.		A97	Minor			X	X	X	X			X	X	X	X	X	X	X				
010219	C019	Inverter type 206 mounting brackets.	Examine.		A99	Minor			X	X	X	X			X	X					X				
010220	C022	Nose undercarriage up stop bracket.	Look for cracks. (SP 409). (Introduced by SI/Hunter/105).		A100	Minor			X	X	X	X					X	X	X						
010232	N/A	Member edge.. (Port and Starboard).	Examine.		A255	Major (2)						X			X	X	X	X	X	X					
010210	N/A	Blast tubes.	Look for cracks at welds.		N/A	A/F									X	X	X				X				
010216	C020	Radio/Gun compartment access panels.	Look for distortion of cartridge case ejection chutes.		A15	Minor			X	X	X	X			X	X	X	X	X	X	X				
010233	N/A	Radio/Gun compartment.	Examine.		A261	Major (2)						X					X	X	X	X					
SMS/ 11/13														Continued overleaf											

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9				
010246	N/A	Main battery tray.	Examine. (Batteries removed)		A 98	Major						X	X			X	X	X	X	X	X	X					
010247	N/A	Emergency battery tray.	Examine (Batteries removed)		A98	Major						X	X			X	X	X	X	X	X	X					
010248	N/A	UHF Standby battery tray. (If fitted).	Examine (Batteries removed)		A98	Major						X	X			X	X	X	X	X	X	X					
010224	N/A	Ballast weight support channels.	Examine and particularly for cracks and distortion.			Primary*		X	X	X		X				X											
010225	A017	Tacan mounting diaphragms and base. Pt Nos.C237131, C237132/1,C237133(If fitted)	Examine and particularly for cracking of diaphragms.		A97	Primary	X	X	X	X	X	X						X									
010226	A024	Gun bay forward access panel fasteners.	Examine and particularly for cracking.(SP 139).		A15	Primary	X	X	X	X	X	X				X	X	X	X	X	X	X					
010234	N/A	Gun front mounting bracket and adjacent structure.	Examine.		A259	Major (2)						X						X									
010235	N/A	Gun rear mounting bracket and adjacent structure.	Examine.		A259	Major (2)						X						X									
010236	N/A	Blast trough and landing.	Examine.		A259	Major(2)						X						X									
010237	N/A	Fixed blast tubes.	Examine.		A260	Major(2)						X				X						X					
010238	N/A	Gun package compartment.	Examine.		A260	Major(2)						X				X						X					
010239	N/A	Sidescreens over canopy lock controls.	Examine. (Removed)		A261 A382	Major (2)						X				X	X	X	X	X	X	X					
010240	N/A	Canopy lock control rods.	Examine.		A262	Major						X	X			X	X	X	X	X	X	X					
010249	N/A	Diaphragms D235535 and D235536. (Fitted between frames 14 and 15)	Ensure fitted.		N/A	B/F												X	X	X							
															(Mk 7 fitted with TACAN)												

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										QTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9		
FRONT FUSELAGE - 02 (Contd)																									
010211	N/A	<u>Cockpit</u> Floor.	Examine. (Ejection seat removed).	Y	N/A	6 monthly																			
	A025		Clean.		A195	Primary	X	X	X	X	X	X													
010217	N/A	Ejection seat pin stowage.	Ensure secure.		N/A	A/F																			
010241	N/A	Structure.	Examine as far as possible.	Y	A266	Major (2)						X													
010242	N/A	Pressure sealing.	Reseal. (As required).		A266	Major (2)						X													
010222	N/A	Edge frame.	Examine.	Y	A112	Major					X	X													
010212	N/A	<u>Transparencies</u>																							
	N/A	Windscreen.	Ensure clean.		N/A	B/F,T/R																			
	N/A		Look for damage.		N/A	T/R,A/F																			
	N/A		Clean.		N/A	A/F																			
	C015		Examine.	Y	A102	Minor			X	X	X	X													
010214	B009	Canopy seal.	Examine.		A101	Primary*		X	X	X	X	X													
	N/A		Replace. (Scrap).		A265 A381	Major (2)							X												
010245	N/A	Canopy seal bed.	Examine.		A265	Major (2)						X													
SMS/82/184/6																									
Continued overleaf																									

SMS/82/184/6

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9		
010213	N/A	Canopy.	Ensure clean.		N/A	B/F,T/R											X	X	X	X	X	X	X				
	N/A		Look for damage.		N/A	T/R,A/F											X	X	X	X	X	X	X				
	N/A		Clean.		N/A	A/F											X	X	X	X	X	X	X				
	B009		Examine.	Y	A102	Primary*		X	X	X	X	X					X	X	X	X	X	X	X				
010227	N/A	Hood external emergency release perspex window.	Ensure secure.		N/A	T/R,A/F											X	X	X	X	X	X	X				
	N/A		Examine and particularly for cracks.		N/A	T/R,A/F											X	X	X	X	X	X	X				
010225	N/A	Silica gel container.	Replace crystals if discoloured.		N/A	A/F											X	X	X	X	X	X	X				
010250	C015	SILICA GEL CONTAINER AND ASSOCIATED PIPELINES.	EXAMINE AND PARTICULARLY FOR FREE VENTING.			Minor			X	X	X	X							X	X	X	X					
CENTRE FUSELAGE - 03																											
010300	N/A	Centre fuselage.	See CRL.			100% FI											X	X	X	X	X	X	X				
010301	C026	Main Structure Skin.	Examine.	Y	A44	Minor			X	X	X	X					X	X	X	X	X	X	X				
010302	C026	Internal structure.	Examine as far as possible.	Y	A90	Minor			X	X	X	X					X	X	X	X	X	X	X				
SMS/82/184/6A																											
Continued																											

Chapter 1 AIRFRAME
Sheet 4
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AF101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9		
CENTRE FUSELAGE - O3 (Contd)																									
		Main Structure (Contd)																							
010303	A016	Drainage holes.	Ensure clear.		A44	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X				
010304	B044	Stub plane skin.	Look for loose rivets in vicinity of Diaphragm B.		A44	Primary*		X	X	X	X	X			X	X	X	X	X	X	X				
010305	A016	Air intake ducts.	Examine and particularly for cracks in pre-cooler and inter-cooler ducts.	Y	A85	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X				
010335	A016	Air intake skins.	Examine. (SP 420). (Introduced by SI/Hunter /83A).	Y	A85	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X				
010306	A015	Secondary air intake hinges.	Examine.			Primary.	X	X	X	X		X			X	X					X				
			Lubricate.			Primary	X	X	X	X		X			X	X					X				
010307	N/A	Turret drive arm top mounting brackets attachment bolts.	Look for loose bolts. (Introduced by SI/Hunter/56A).		N/A	Each Engine Removal									X	X					X				
010308		Mainplane front locating spigots. (Pre Mod 1327 and 1334).	Servicing deleted. (AL 2).																						
010316	C026	Aircraft slinging points. (4 off).	Clean.		A44	Minor			X	X	X	X			X	X	X	X	X	X	X				
			Examine.		A44	Minor			X	X	X	X			X	X	X	X	X	X	X				
			Lubricate.		A44	Minor			X	X	X	X			X	X	X	X	X	X	X				
010309	N/A	2BA bolts, nuts and washers (8 off) on flanges at rear of top and bottom drag members. (Frame 32).	Replace. (Fatigue).		A121	Major					X	X			X	X	X	X	X	X					
SMS/ 86/5/4																Continued overleaf									

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9				
010318	N/A	Top and bottom drag members. (Port and Starboard).	Examine as far as possible.		A280 A285	Major (2)						X				X	X	X	X	X	X	X					
010317	BO44	<u>Front Transport Joint</u> (Frame 18). Attachment bolts and rivets.	Ensure secure.		A115	Primary*		X	X	X	X	X				X	X	X	X	X	X	X					
010310	N/A	<u>Front Transport Joint</u> (Frame 19). Top spigots. (Pre Mod 943 or 1032).	Servicing deleted. (AL 2).		N/A																						
010311	N/A	Special nuts. (Pre Mod 943 or 1032).	Servicing deleted. (AL 2).		N/A																						
010312	N/A	Attachment bolts. (25 off). (Post Mod 1014).	Replace. (Fatigue).			Major					X					X	X					X					
010313	N/A	<u>Rear Transport Joint</u> (Frame 40). Fuselage attachment spigot nuts.	Ensure tight and repeen if necessary.	Y	N/A	Each rear Fuselage Removal										X	X	X	X	X	X	X					
010314	N/A	<u>Mainplane Attachment Joints</u> Main spar split taper bushes.	Replace. (Fatigue).		A120	Major					X	X				X	X	X	X	X	X	X					
010315	N/A	Rear spar split taper bushes.	Replace. (Fatigue).		A120	Major					X	X				X	X	X	X	X	X	X					
010319	N/A	<u>Main Structure</u> Front spar; wing pick up points. (Port and Starboard).	Examine.		A279 A284	Major (2)						X				X	X	X	X	X	X	X					
010335	A017	Frames 18A and 18B	Examine and particularly for cracks (SP 435)	Y	A115	Primary	x	x	x	x	x	x							x	x	x	x	x				
SMS/ 10/1/45																											
Continued																											

Continued

SMS 15

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark								CTY
							P	P*	M	M*	MJ	MJ (2)						7	7A	8B	8C				
010334	N/A	Main Structure Centre fuel tank compartments.	Examine.		A297	Major (2)						X						X	X	X	X				
REAR FUSELAGE - 04																									
		Rear Structure																							
010401	C028	Skin.	Examine.	Y	A116	Minor			X	X	X	X						X	X	X	X				
010402	C027	Internal structure.	Examine as far as possible.	Y	A116	Minor			X	X	X	X						X	X	X	X				
010403	A016	Drainage holes.	Ensure clear.		A116	Primary	X	X	X	X	X	X						X	X	X	X				
SMS/89/6/3A																									
																		Continued							

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C	9		
REAR FUSELAGE - 04 (Contd)																								
010404	B014	<u>Main Structure</u> (Contd) Tail cone.	Examine. (Removed).	Y	A116	Primary*		X	X	X	X	X			X	X	X	X	X	X	X			
010405	B014	Tailplane forward lower rubbing strips. (Frame 52).	Examine.		A116	Primary*		X	X	X	X	X			X	X	X	X	X	X	X			
010406	C032	Skin securing flanges below tailplane. (Frame 55).	Look in vicinity of flanges for loose rivets.	Y	A116	Minor			X	X	X	X			X	X	X	X	X	X	X			
010412	N/A	Tail bumper pad and adjacent structure.	Examine.		A305	Major (2)						X			X	X	X	X	X	X	X			
010413	N/A	Fin attachment points and bolts.	Examine. (Fin removed).		A312	Major (2)						X			X	X	X	X	X	X	X			
010414	N/A	Tailplane attachment points and bolts.	Examine. (Tailplane removed).		A312	Major (2)						X			X	X	X	X	X	X	X			
010415	N/A	Rear fuel tank support panels.	Examine. (Removed).		A298 A353	Major (2)						X			X	X					X			
010416	N/A	Rear fuel tank compartments.	Examine.		A301	Major (2)						X			X	X					X			
010407	C010	<u>Airbrake Assembly</u> Airbrake fairing.	Examine.	Y	A33	Minor			X	X	X	X			X	X	X	X	X	X	X			
010408	A016	Drainage holes.	Ensure clear.		A33	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X			
SMS/82/184/9																								
Continued overleaf																								

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9		
010409	B002	Airbrake hinges.	Examine.	Y	A33	Primary*		X	X	X	X	X					X	X	X	X	X	X	X				
	B002		Lubricate.		A132	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			X	
010410	B002	Jack top attachment.	Examine.	Y	A33	Primary*		X	X	X	X	X					X	X	X	X	X	X	X				
	B002		Lubricate.		A132	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			X	
010411	B002	Jack bottom attachments.	Examine.	Y	A33	Primary*		X	X	X	X	X					X	X	X	X	X	X	X				
	B002		Lubricate.		A132	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			X	
010417	N/A	Airbrake.	Examine. (Removed).		A302 A304	Major (2)						X				X	X	X	X	X	X	X					
010418	N/A	<u>Main Structure</u> Airbrake attachment points.	Examine. (Airbrake removed).		A303	Major (2)						X				X	X	X	X	X	X	X					

Continued

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY						
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B		8C					
TAIL UNIT - 05		(Contd)																										
010504	A014	<u>Tailplane Assembly</u> (Contd) Drainage holes.	Ensure clear.		A39	Primary	X	X	X	X	X	X						X	X	X	X							
010505	B014	Tailplane.	Examine and particularly for transverse movement.	Y	A39	Primary*		X	X	X	X	X						X	X	X	X							
	N/A		Examine. (Removed).		A309 A355	Major (2)						X						X	X	X	X							
010521	N/A	Tailplane attachment points.	Examine. (Tailplane removed).		A310	Major (2)						X						X	X	X	X							
010506	C031	<u>Fin Assembly</u> Skin.	Examine.	Y	A38	Minor			X	X	X	X						X	X	X	X							
010507	C029	Internal structure.	Examine as far as possible.	Y	A38	Minor			X	X	X	X						X	X	X	X							
010508	A014	Drainage holes.	Ensure clear.		A38	Primary	X	X	X	X	X	X						X	X	X	X							
010509	N/A	Rudder hinge bracket and supporting structure.	Examine. (Rudder removed).	Y	A38	Major					X	X						X	X	X	X							
010522	N/A	Rudder attachment points.	Examine. (Rudder removed).		A307	Major (2)						X						X	X	X	X							
010518	B013	Inter spar Rib A.	Look for loose rivets. (SP 428). (Introduced by SI/Hunter/23).		A38	Primary*		X	X	X	X	X						X	X	X	X							
010519	B014	Fin.	Examine.	Y	A38	Primary*		X	X	X	X	X						X	X	X	X							
	N/A		Examine. (Removed).	Y	A306 A356	Major (2)						X						X	X	X	X							
010523	N/A	Fin attachment points.	Examine. (Fin removed).		A307	Major (2)						X						X	X	X	X							
SMS/86/8/90																		Continued overleaf										

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY
							P	P*	M	M*	MJ	MJ (2)							7	7A	
FLYING CONTROL OPERATING SYSTEM - 13 (Contd)																					
011385	A025	Centre Fuselage (Contd) Elevator hydraulic flexible hoses. (Frame 40). (Post Mod 1425).	Examine.		A86	Primary	X	X	X	X	X	X				X	X	X	X		
	N/A		Servicing deleted by AL 24.																		
011332	N/A	Servicing deleted.																			
011333	N/A	Rear Fuselage Control bearings.	Examine. (Removed). (SP 429).		A263	Major (2)						X				X	X	X	X		
			Lubricate. (Removed). (SP 429).		A263	Major (2)						X				X	X	X	X		
011334	C047	Rudder and elevator control tubes. (Frames 40B to 52).	Examine. (SP 419). (Introduced by SI/Hunter/820).		A37	Minor				X	X	X	X			X	X	X	X		
011335	C047	Rudder and elevator connecting and adjusting points. (Frames 40B to 52).	Examine.		A37	Minor				X	X	X	X			X	X	X	X		
			Ensure locked correctly.		A39	Minor				X	X	X	X			X	X	X	X		
011336	C047	Rudder and elevator control mounting and idling links. (Frmaes 40B to 52).	Examine..		A37	Minor				X	X	X	X			X	X	X	X		
SMS/86/8/27														Continued overleaf							

Chapter 1 AIRFRAME
Sheet 15
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark								CTY	
							P	P*	M	M*	MJ	MJ (2)									7	7A	8B	8C		
FLYING CONTROL OPERATING SYSTEMS - 13 (Contd)																										
011346	C049	Tail Unit (Contd) Elevator feel unit anchorage.	Examine.		A29	Minor				X	X	X	X						X	X	X	X				
			Lubricate.		A127	Minor				X	X	X	X						X	X	X	X				
011347	N/A	Elevator Control unit assembly. (Post Mod FHB 118 and Pre Mod FHB 156).	Servicing deleted by AL 9.		N/A																					
011348	N/A	Elevator control unit assembly. (Pre Mod FHB 118).	Servicing deleted by AL 9.		N/A																					
011349	A012	Elevator control unit assembly.	Examine and particularly for signs of leaks.		A30	Primary	X	X	X	X	X	X						X	X	X	X					
	N/A		See CRL.		N/A													X	X	X	X					
011385	N/A	Extension end fitting. (BH 18011).	Deleted by AL 15.		N/A																					
011386	N/A	Output lever. (BH 30379).	See CRL.		N/A													X	X	X	X					
011387	N/A	Jack body. (AH 30225).	See CRL.		N/A													X	X	X	X					
011350	N/A	Micronic filter.	Ensure tell-tale device is flush		N/A	A/F												X	X	X	X					
	N/A		See CRL.		N/A													X	X	X	X					
SMS/86/8/28																										
Continued overleaf																										

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C				
FLYING CONTROL OPERATING SYSTEMS - 13 (Contd)																										
011359	B024	<u>Tail Unit (Contd)</u> Datum actuator linkage. (Post Mod 597 and 629).	Ensure freedom of movement. (SP 412). (Introduced by SI/Hunter/65A).		A171	Primary*		X	X	X	X	X						X	X	X	X					
011360	B023	Datum actuator top and bottom attachments.	Lubricate.		A31	Primary*		X	X	X	X	X						X	X	X	X					
011361	N/A	Elevator accumulator.	Check air pressure.		N/A	B/F,T/R A/F												X	X	X	X					
011362	A012	Elevator Hydrobooster flexible hoses. (Pre Mod 1417).	Examine.		A35	Primary	X	X	X	X	X	X						X	X	X	X					
	N/A		See CRL.		N/A													X	X	X	X					
011383	A012	Elevator Hydrobooster flexible hoses. (Post Mod 1417).	Examine.		A35	Primary	X	X	X	X	X	X						X	X	X	X					
	N/A		Servicing deleted by AL 24.																							
011363	N/A	<u>Port and Starboard Mainplanes</u> Aileron control bearings.	Examine. (Removed). (SP 427).		A322 A339	Major (2)						X						X	X	X	X					
	N/A		Lubricate. (Removed). (SP 427).		A322 A339	Major (2)						X						X	X	X	X					
SMS/ 86/8/29																					Continued overleaf					

Chapter 1 AIRFRAME
Sheet 17
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C	
FLYING CONTROL OPERATING SYSTEMS - 13 (Contd)																					
011370	N/A	Port and Starboard Mainplanes (Contd) Aileron control unit assembly. (Pre Mod FBH 117).	Servicing deleted by AL 9.		N/A																
011371	N/A	Aileron control unit assembly. (Post Mod 117 and Pre Mod 157).	Servicing deleted by AL 9.		N/A																
011372	A006 A009	Aileron control unit assembly.	Examine and particularly for signs of leaks.		A49 A71	Primary	X	X	X	X	X	X					X	X	X	X	
	N/A		See CRL.		N/A												X	X	X	X	
011388	N/A	Jack body. (AH 23057 or AH 33203).	See CRL.		N/A												X	X	X	X	
011389	N/A	Jack body. (AH 25995).	See CRL.		N/A												X	X	X	X	
011373	A006 A009	Aileron hydrobooster flexible hoses. (Pre Mod 1424).	Examine.		A49 A71	Primary	X	X	X	X	X	X					X	X	X	X	
	N/A		See CRL.		N/A											X	X	X	X		
SMS/86/8/30																Continued overleaf					

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY					
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C						
<u>TRIM CONTROL OPERATING SYSTEM - 14</u>																												
011401	CO89	<u>General</u> Complete system.	Operate.		A169	Minor				X	X	X	X						X	X	X	X						
	N/A		Check range of movement.		A169	Major						X	X					X	X	X	X							
<u>AIRBRAKE OPERATING SYSTEM - 15</u>																												
011501	CO87	<u>General</u> Complete system.	Test. (SP 128).		A172	Minor				X	X	X	X					X	X	X	X							
011506	N/A	<u>Centre Fuselage</u> Flexible hose. (Qty 2).	Examine.		N/A	Each Engine Removal	Out of Phase (SP81)												X	X	X	X						
	N/A		Replace. (Scrap).		A82	Major						X	X					X	X	X	X							
SMS. 86/4/31																												
																							Continued overleaf					

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	DIVISION						PLAN				CTY					
								P*	M	M*	MJ	MJ (2)					7		7A	8B	8C		
011502	C003	<u>Rear Fuselage</u> Rigid pipelines.	Examine.		A33	Minor				X	X	X	X					X	X	X	X		
011503	C005	Flexible hose. (Qty 2).	Examine.		N/A	Minor				X	X							X	X	X	X		
	N/A		Replace. (Scrap).		A122	Major						X	X					X	X	X	X		
011504	C003	Operating jack.	Examine.		A33	Minor				X	X	X	X					X	X	X	X		
011505	C003	Microswitch.	Examine.		A33	Minor				X	X	X	X					X	X	X	X		
<u>FLAP OPERATING SYSTEM - 16</u>																							
011601	C087	<u>General</u> Complete system.	Test. (SP 127).		A166	Minor				X	X	X	X					X	X	X	X		
SMS/86/8/31A																		Continued					

Sched Ident No	Card No.	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark								QTY	
							P	P*	M	M*	MJ	MJ (2)								7	7A	8B	8C			
FLAP OPERATING SYSTEM - 16 (Contd)																										
011602	DO08 DO14	<u>Port and Starboard Mainplane</u> Operating jack.	Examine.		A47 A73	Minor*					X	X	X						X	X	X	X				
011603	DO08 DO14	Synchronizing jack.	Examine.		A47 A73	Minor*					X	X	X						X	X	X	X				
011604	DO08 DO14	Rigid pipelines.	Examine.		A47 A73	Minor*					X	X	X						X	X	X	X				
011605	N/A	Pressure release valve.	See CRL.		N/A														X	X	X	X				
011608	N/A	Flap jack operating level attachment bolt.	See CRL.		N/A														X	X	X	X				
011606	BO20	<u>Port Mainplane</u> Drum switch control rod attachment pivots.	Lubricate.		A146	Primary*		X	X	X	X	X	X						X	X	X	X				
011607	BO20	Flaps down pipeline in vicinity of cleat at Rib F1.	Look for signs of chafing. (Introduced by SI/Hunter/73).		A 47	Primary*		X	X	X	X	X	X						X	X	X	X				
SMS/96/8/32																										
Continued overleaf																										

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY	
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B
ARRESTER GEAR SYSTEM - 18																						
011801	N/A	<u>Cockpit</u> Arrester gear selector switches. (If fitted).	Ensure set to off.		N/A	B/F,T/R A/F												X	X	X	X	
011802	A019	<u>Rear Fuselage</u> Main assembly and hook. (If fitted).	Examine.		A28	Primary	X	X	X	X	X	X						X	X	X	X	
011803	A037	Damper strut. (If fitted).	Check pressure.		A128	Primary	X	X										X	X	X	X	
	C033 C034		Replace. (Bay Service).		A28 A128	Minor			X	X	X	X						X	X	X	X	
011804	A019	Arrester hook pivot. (If fitted).	Lubricate.		A131	Primary	X	X	X	X	X	X						X	X	X	X	
011805	A019	Leaf spring slides. (If fitted).	Lubricate.		A131	Primary	X	X	X	X	X	X						X	X	X	X	
011806	C033	Bell crank pivot. (If fitted).	Lubricate.		A131	Minor			X	X	X	X						X	X	X	X	
011807	C033	Microswitch shaft. (If fitted).	Lubricate.		A131	Minor			X	X	X	X						X	X	X	X	
SMS/89/6/4A																		Continued				

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY							
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B	8C					
MAIN UNDERCARRIAGE - 28																												
012801	N/A	Port and Starboard Main Assemblies Structure.	Look for obvious damage.		N/A	T/R,A/F													X	X	X	X						
012802	B025	Leg.	Examine.		A56 A64	Primary*		X	X	X	X	X							X	X	X	X						
	B026		Lubricate.		A134 A137	Primary*		X	X	X	X	X							X	X	X	X						
	N/A		Examine. (Removed).		A270 A275 A365 A376	Major (2)						X							X	X	X	X						
012803	B025	Attachment pivots.	Lubricate.		A134 A137	Primary*		X	X	X	X	X							X	X	X	X						
	N/A		Examine.		A250 A275	Major (2)						X							X	X	X	X						
012804	A037	Torque links.	Examine.		A56 A64	Primary	X	X	X	X	X	X							X	X	X	X						
	A038		Lubricate.		A134 A137	Primary	X	X	X	X	X	X								X	X	X	X					
012805	A020 A021	Operating jack pivots.	Lubricate.		A134 A137	Primary	X	X	X	X	X	X							X	X	X	X						
	N/A		Examine.		A270 A275	Major (2)						X							X	X	X	X						
SMS/86/8/34																						Continued overleaf						

Chapter 1 AIRFRAME
Sheet 22
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY		
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B	8C
MAIN UNDERCARRIAGE - 28 (Contd)																							
012811	B025 B026	<u>Port and Starboard Main Assemblies (Contd)</u> Recuperator spindle. (If fitted).	Clean.		A56 A64	Primary*		X	X	X	X	X						X	X	X	X		
			Examine.		A56 A64	Primary*		X	X	X	X	X						X	X	X	X		
	A037 A038		Lubricate.		A134 A137	Primary	X	X	X	X	X	X						X	X	X	X		X
012812	A022 A023	Recuperator lever operating shaft. (If fitted).	Clean.		A56 A64	Primary	X	X	X	X	X	X						X	X	X	X		
			Examine.		A56 A64	Primary	X	X	X	X	X	X						X	X	X	X		
			Lubricate.		A134 A137	Primary	X	X	X	X	X	X						X	X	X	X		X
012813	N/A	Shock absorber strut.	Look for signs of leaks.		N/A	B/F,T/R A/F												X	X	X	X		
			Ensure extension is normal.		N/A	B/F,T/R A/F												X	X	X	X		
			Examine.		A270 A275	Major (2)						X						X	X	X	X		
012814	C107 C106	<u>Port and Starboard Door and Leg Fairing</u> Wheel door.	Examine.		A51 A63	Minor			X	X	X	X						X	X	X	X		
SMS/DL 10/1-15																							
Continued overleaf																							

SMS/OL 10/1-15

Continued overleaf

[illegible]

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing						Mark						CTY					
							P	P*	M	M*	MJ	MJ (2)					7	7A		8B	8C			
MAIN UNDERCARRIAGE - 28 (Contd)																								
012820	A035 A036	Port and Starboard Door and Leg Fairing (Contd) Leg fairing locks.	Clean.		N/A	Primary	X	X									X	X	X	X				
			Examine.		N/A	Primary	X	X									X	X	X	X				
			Lubricate.		N/A	Primary	X	X									X	X	X	X				X
		C054 C055		Examine. (Removed). (SP 417). (Introduced by SI/Hunter/78B).		A55 A59	Minor			X	X	X	X				X	X	X	X				
012821	C103 C104	Door operating levers.	Clean.		A51 A63	Minor			X	X	X	X					X	X	X	X				
			Examine.		A51 A63	Minor			X	X	X	X					X	X	X	X				
			Lubricate.		A136 A139	Primary*		X	X	X	X	X					X	X	X	X				X
012822	B027 B028	Stop rod.	Clean.		A51 A63	Primary*		X	X	X	X	X					X	X	X	X				
			Examine.		A51 A63	Primary*		X	X	X	X	X					X	X	X	X				
			Lubricate.		A136 A139	Primary*		X	X	X	X	X					X	X	X	X				X
Continued overleaf																								

[illegible]

Chapter 1 AIRFRAME
Sheet 24
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

[illegible]

Chapter 1 AIRFRAME
Sheet: 34
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

[illegible]

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	
<u>HOOD OPERATING SYSTEM - 56</u>																					
015601		<u>General</u> Complete system.	Deleted. (AL 3).																		
	C094		Test. (SP 136).		A177	Minor			X	X	X	X					X	X	X	X	
	C093		Operate.			Minor			X	X		X			X	X					X
015602	B039	<u>Cockpit</u> Operating chain.	Lubricate.			Primary*		X	X	X		X			X	X					X
	C070		Check tension.			Minor			X	X		X			X	X					X
				Examine.			Minor			X	X		X			X	X				
015603	B039	Sprockets.	Lubricate.			Primary*		X	X	X		X			X	X					X
015604	B039	Microswitch plungers.	Lubricate.			Primary*		X	X	X		X			X	X					X
015605	B039	Hood locks.	Lubricate.			Primary*		X	X	X		X			X	X					X
015606	B039	Lock joints.	Lubricate.			Primary*		X	X	X		X			X	X					X
015607	B039	Lock springs.	Ensure intact.			Primary*		X	X	X		X			X	X					X
015608	C070	Operating mechanism.	Examine.			Minor			X	X		X			X	X					X
015609	C070	Operating shaft and sprocket.	Examine.			Minor			X	X		X			X	X					X
015610	C016	Canopy rails.	Examine. (Canopy removed).			Minor			X	X		X			X	X					X
015611	C016	Canopy rollers.	Examine. (Rails removed).			Minor			X	X		X			X	X					X
			Lubricate.			Minor			X	X		X			X	X					X
SMS/5. 1/5/1984																					
Continued																					

Chapter 1 AIRFRAME
Sheet 35
AL29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

[illegible]

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	REVISIONS										7	7A	8B	8C		CTY																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
								P*	M	M*	MJ	MJ (2)																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																
WINDSCREEN WIPER SYSTEM - 57																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																												
015701	A031	<u>Front Fuselage</u> Windscreen wiper mechanism.	Examine.		A103	Primary	X	X	X	X	X	X						X	X	X	X																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							</

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY				
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B	8C		
EMERGENCY AIR SYSTEM - 58 (Contd)																									
015804	N/A	<u>Undercarriage and Flaps</u> (Contd) Emergency air bottles. (Qty 2).	Replenish.		N/A	B/F												X	X	X	X				
	CO71		Examine as far as possible.		A112	Minor				X	X	X	X					X	X	X	X				
	N/A		See CRL.		N/A													X	X	X	X				
015805	N/A	<u>Port and Starboard</u> <u>Undercarriage Compartment</u> Sequence valve.	See CRL.		N/A													X	X	X	X				
015811	N/A	Pipelines.	Examine.		A326 A342	Major (2)						X						X	X	X	X				
015806	N/A	<u>Port Undercarriage</u> <u>Compartment</u> Flap shuttle valve.	Replace. (Bay Service).		A54 A133	Major						X	X					X	X	X	X				
015807	N/A	<u>Starboard Undercarriage</u> <u>Compartment</u> Main undercarriage shuttle valve.	Replace. (Bay Service).		A66 A140	Major						X	X					X	X	X	X				
015809	CO64	Pipe. (Pt No C189161/277).	Examine.		A67	Minor				X	X	X	X					X	X	X	X				
015810	CO64	Pipe. (Pt No C189161/218).	Examine.		A67	Minor				X	X	X	X					X	X	X	X				
CME/86/2/1,9																									
Continued overleaf																									

SME/84/2/119

Continued overleaf

Chapter 1 AIRFRAME
 Sheet 37
 AL29

MASTER SERVICING LIST
 HUNTER ALL MARKS

AP101B-1300-5A1
 Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY			
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B	8C	9
ANTI-G SYSTEM - 59 (Contd)																								
015904	N/A	Cockpit Anti-G air bottles.	Replenish.		N/A	B/F,T/R												X	X	X	X	X		
	CO71	(4 off) MK9 (2 off)	Examine as far as possible.		A110	Minor			X	X	X	X						X	X	X	X	X		
	N/A		See CRL.		N/A													X	X	X	X	X		

SMS/AL 10/57

Continued overleaf

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9			
OXYGEN SYSTEM - 67 (Contd)																										
016707	N/A	Cockpit Regulator emergency toggle switch.	Ensure central.		N/A	T/R											X	X	X	X	X	X	X			
016708	CO72	Regulator rubber cuff.	Examine.		A107	Minor			X	X	X	X					X	X	X	X	X	X	X			
016709	BO40	Quick release connexion.	Check throat wear.		A107	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			
016710	N/A	Regulator ON/OFF cock.	Ensure at 'ON' position.		N/A	B/F,T/R											X	X	X	X	X	X	X			
		Examine restraint wire and ensure intact.			N/A	B/F,T/R											X	X	X	X	X	X	X			
016712	N/A	High pressure pipelines.	Examine.		A257	Major (2)						X					X	X	X	X	X	X	X			
016713	N/A	Medium pressure pipelines.	Examine.		A257	Major (2)						X					X	X	X	X	X	X	X			
016714	N/A	Low pressure pipelines.	Examine.		A257	Major (2)						X					X	X	X	X	X	X	X			
016715	N/A	Oxygen charging valve (6D 2244774)	Replace (Fatigue)			960 Hrs																				
Continued overleaf																										

SMS/ 30/5/14

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark								CTY	
							P	P*	M	MM	MJ	MJ (2)							6	6A	7	7A	8B	8C		9
PITOT/STATIC SYSTEM - 68																										
016801	N/A	<u>Port Mainplane</u> Pressure head.	Look for obvious damage. (Introduced by SI/Inst/19A).		N/A	T/R,A/F												X	X	X	X	X	X	X		
	C038		Examine.		A60	Minor				X	X	X	X					X	X	X	X	X	X	X		
016805	N/A	Pipelines.	Examine as far as possible.		A324	Major (2)							X					X	X	X	X	X	X	X		
016802	B049	System pipelines and elbow joint adjacent to aileron power control unit and adjacent to aileron bellcrank assembly between ribs L and M.	Ensure secure.		A60	Primary*		X	X	X	X	X	X					X	X	X	X	X	X	X		
016803	B011	System pipelines and connexions between Frames 7 and 8.	Ensure the lay of the pipes and connexions lie outboard of a line between the inboard edge of Frames 7 and 8.		A106	Primary*		X	X	X	X	X	X					X	X					X		
016804	N/A	<u>Centre Fuselage</u> System pipelines and connexions. (Frames 19 to 25).	Examine.		A89	Major						X	X					X	X	X	X	X	X	X		
016806	N/A	<u>Front Fuselage</u> Pipelines.	Examine.		A256	Major (2)							X					X	X	X	X	X	X	X		
016807	N/A	<u>Port Stub Wing</u> Pipelines.	Examine. (Mainplane removed).		A282	Major (2)							X					X	X	X	X	X	X	X		
016808	N/A	<u>Port Undercarriage Compartment</u> Pipelines.	Examine.		A327	Major (2)							X					X	X	X	X	X	X	X		
SMS/ 11/1/78																										
Continued																										

Chapter 1 AIRFRAME
Sheet 39
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

[illegible]

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY					
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B	8C			
NOSE UNDERCARRIAGE - 30 (Contd)																										
013009	N/A	<u>Main Assembly</u> (Contd) Shock absorber strut.	Look for signs of leaks.		N/A	B/F,T/R A/F												X	X	X	X					
			Ensure extension is normal.		N/A	B/F,T/R A/F													X	X	X	X				
			Examine.		A252	Major (2)						X							X	X	X	X				
013010	B029	Shock absorber lower attachments.	Examine.		A79	Primary*		X	X	X	X	X						X	X	X	X					
			Lubricate.		A124	Primary*		X	X	X	X	X							X	X	X	X				X
013011	N/A	Shock absorber bottom fixing pin stud.	See CRL.		N/A													X	X	X	X					
013012	N/A	<u>Front Door</u> Door.	Look for obvious damage.		N/A	T/R,A/F												X	X	X	X					
	A024		Examine.		A76	Primary	X	X	X	X	X	X						X	X	X	X					
013013	B030	Hinges.	Examine.		A76	Primary*		X	X	X	X	X						X	X	X	X					
			Lubricate.		A123	Primary*		X	X	X	X	X							X	X	X	X				X
013014	N/A	Wire pin. (4 off). (Lock operating rods to attachment pins).	See CRL.		N/A													X	X	X	X					

Continued overleaf

Sched Ident. No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	Revising						Main				CTY						
								P*	M	M*	MJ	MJ (2)					7		7A	8B	8C			
013028	N/A	Doorlock spigots.	Clean.		N/A	A/F											X	X	X	X				
			Lubricate.		N/A	A/F											X	X	X	X				
	BO48		Examine and particularly for flat spots and scoring.		A79	Primary*		X	X	X	X	X					X	X	X	X				
013015	A024	Locks.	Clean.		N/A	Primary	X	X									X	X	X	X				
			Examine.		N/A	Primary	X	X									X	X	X	X				
			Lubricate.		N/A	Primary	X	X									X	X	X	X				X
	CO56		Examine. (Removed). (SP 14).		A76	Minor			X	X	X	X					X	X	X	X				
013016	BO30	Jack attachment.	Examine.		A76	Primary*		X	X	X	X	X					X	X	X	X				
			Lubricate.		A123	Primary*		X	X	X	X	X						X	X	X	X			
013017	BO30	Lock operating rods.	Examine.		A76	Primary*		X	X	X	X	X					X	X	X	X				
			Lubricate.		A123	Primary*		X	X	X	X	X						X	X	X	X			
013018	BO30	Lock operating levers.	Examine.		A76	Primary*		X	X	X	X	X					X	X	X	X				
			Lubricate.		A123	Primary*		X	X	X	X	X						X	X	X	X			
013027	BO30	Operating jack attachment bolt. (Frame 3).	Examine. (Removed). (Introduced by SI/Hunter/129).		A76	Primary*		X	X	X	X	X					X	X	X	X				
			Lubricate. (Introduced by SI/Hunter/129).		A123	Primary*		X	X	X	X	X						X	X	X	X			
013019	BO30	Cross shaft brackets.	Examine.		A76	Primary*		X	X	X	X	X					X	X	X	X				
			Lubricate.		A123	Primary*		X	X	X	X	X						X	X	X	X			
SMS/ 86/8/38A		Continued.																						

Continued.

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY	
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C		
NOSE UNDERCARRIAGE - 30 (Contd)																						
013020	B030	<u>Front Door</u> (Contd) Jack pivots.	Examine.		A76	Primary*		X	X	X	X	X					X	X	X	X		
			Lubricate.		A123	Primary*		X	X	X	X	X					X	X	X	X		X
013021	N/A	<u>Rear Door</u> Door.	Look for obvious damage.		N/A	T/R,A/F										X	X	X	X			
			Ensure secure.		N/A	T/R,A/F										X	X	X	X			
	AO24		Examine.		A76	Primary	X	X	X	X	X	X					X	X	X	X		
013022	AO43	Hinge bolts.	Lubricate.		A123	Primary	X	X	X	X	X	X					X	X	X	X		X
	CO56		Examine. (Removed). (SP 411). (Introduced by SI/Hunter/64A).		A76	Minor			X	X	X	X					X	X	X	X		
013023	B030	Operating rod.	Examine.		A76	Primary*		X	X	X	X	X					X	X	X	X		
			Lubricate.		A123	Primary*		X	X	X	X	X					X	X	X	X		X
013024	B030	Operating rod springs.	Lubricate.		A123	Primary*		X	X	X	X	X					X	X	X	X		X

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	P*	M	MM	MJ	MJ (2)				7	7A	8B	8C				CTY
013025	N/A	<u>Nosewheel Assembly</u> Nosewheel.	Look for obvious damage.		N/A.	B/F, T/R, A/F										X	X	X	X				
			Replace. (Bay Service).		A252 A380	Major (2)						X				X	X	X	X				
			See CRL.		N/A											X	X	X	X				
013026	N/A	Tyre.	Check pressure.		N/A	B/F										X	X	X	X				
			Examine.		N/A	B/F, T/R, A/F										X	X	X	X				
013030	B029	Pivot Pin	Examine and particularly for fretting and corrosion. (SP415). (Introduced by SI/Hunter/138).		A76	Primary*		X	X	X	X	X				X	X	X	X				
013031	B029	Pivot Pin Bracket	Examine and particularly for fretting and corrosion. (SP415). (Introduced by SI/Hunter/138).		A76	Primary*		X	X	X	X	X				X	X	X	X				
<u>UNDERCARRIAGE OPERATING SYSTEM - 31</u>																							
013101	C085	<u>General</u> Complete system.	Functional test. (SP 129).		A167	Minor			X	X	X	X				X	X	X	X				
SMS/86/8/39A																							

Continued

Continued

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY				
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C					
UNDERCARRIAGE OPERATING SYSTEM - 31 (Contd)																									
013132	C108	General (Contd) Hydraulic components.	Bleeding and functional check. (SP 433). (Introduced by SI/Hunter/99).		A158	Minor				X	X	X	X				X	X	X	X					
013133	B041	Undercarriage door mechanism.	Settling in and backlash check. (SP 135 and SP 436). (Introduced by SI/Hunter/72D and SI/Hunter/100A).		A182	Primary*		X	X	X	X	X					X	X	X	X					
			N/A	On receipt from storage or assisted servicing													X	X	X	X					
	C054 C055 C056		Adjustment check. (SP 414).		A159 A160 A161	Minor				X	X	X	X					X	X	X	X				
013102	B041	Leg fairing lock mechanism clamping bolt con micro switch operating lever.	Examine. (SP 432). (Introduced by SI/Hunter/88).		A51 A63	Primary*		X	X	X	X	X					X	X	X	X					
013103	C058	Front Fuselage Nose door operating jack.	Examine.		A79	Minor				X	X	X	X				X	X	X	X					

Continued on next page

Chapter 1 AIRFRAME
Sheet 28
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CT	
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B
UNDERCARRIAGE OPERATING SYSTEM - 31 (Contd)																						
013113	C060 C062	Port and Starboard Undercarriage Compartments																				
		Main undercarriage operating jack.	Examine.		A58 A62	Minor				X	X	X	X					X	X	X	X	
013114		Main undercarriage operating jack. (Post Mod Dowty AC 3907).	Servicing deleted by AL 10.																			
013115	B033 B036	Up lock sequence valve mechanism.	Examine.		A58 A62	Primary*		X	X	X	X	X					X	X	X	X		
			Lubricate.		A136 A139	Primary*		X	X	X	X	X					X	X	X	X		X
013116	C016 C063	Associated pipelines.	Examine.		A58 A62	Minor			X	X	X	X					X	X	X	X		
013117	B033 B036	Down lock sequence valve mechanism.	Examine.		A58 A62	Primary*		X	X	X	X	X					X	X	X	X		
			Lubricate.		A136 A139	Primary*		X	X	X	X	X					X	X	X	X		X
013118	C061 C063	Door operating jack.	Examine.		A58 A62	Minor			X	X							X	X	X	X		
	N/A		See CRL.													X	X	X	X			
013119	N/A	Sequence valve.	See CRL.														X	X	X	X		

Continued overleaf

[illegible]

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark						CTY
							P	P*	M	M*	MJ	MJ (2)				7	7A	8B	8C		
<u>WHEEL BRAKE SYSTEM - 32</u>																					
013201	N/A	<u>General</u> Complete system.	Ensure pressure exhausted.		N/A	B/F										X	X	X	X		
	C086		Operate.		A162	Minor			X	X	X	X				X	X	X	X		
013202	C065	<u>Cockpit</u> Brake cable.	Examine as far as possible.		A105	Minor			X	X	X	X				X	X	X	X		
	N/A		Lubricate.		A155	Minor			X	X	X	X				X	X	X	X		
			See CRL:													X	X	X	X		
013203	C065	Brake lever pivot(s).	Lubricate.		A155	Minor			X	X	X	X				X	X	X	X		
013204	N/A	<u>Front Fuselage</u> Accumulators.	Replenish.		N/A	B/F										X	X	X	X		
SMS/SL/S/42																					

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								QTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	
WHEEL BRAKE SYSTEM - 32 (Contd)																							
013213	B033 B036	Port and Starboard Undercarriage (Contd) Maxaret lower pivot block spring. (Post Mod 516).	Examine.		A56 A64	Primary*		X	X	X	X	X			X	X	X	X	X	X			
			Lubricate.		A135 A138	Primary*		X	X	X	X	X			X	X	X	X	X	X			
013214	N/A	Brake unit.	Servicing deleted by AL 24.																				
			Servicing Deleted by AL 28																				
013215	CO76 CO77	Ends of maxaret unit return pipe and end fittings. (Post Mod 197 and 198).	Renew colour coding. (SP 416). (Introduced by SI/Hunter/77).		A117 A118	Minor			X	X	X	X			X	X	X	X	X	X			
013216	A022 A023	Rigid pipelines.	Examine.		A56 A64	Primary	X	X	X	X	X	X			X	X	X	X	X	X			
SMS/86/5/10																							
Continued overleaf																							

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9		
HYDRAULIC POWER SYSTEM - 50																											
015001	N/A	<u>Centre Fuselage</u> Reservoir.	Check oil level.		N/A	B/F,A/F											X	X	X	X	X	X	X				
015002	C081	Filter element.	Replace. (Fatigue).		A82	Minor			X	X	X	X					X	X	X	X	X	X	X				
015004	C082	Hydraulic pipe. (Pt No 205179/111).	Examine and particularly for signs of chafing.			Minor			X	X		X					X	X					X				
015005	C082	Hydraulic pipe-return EDP to Union. (Pt No C205179/45).	Examine and particularly for signs of chafing.			Minor			X	X		X					X	X					X				
			Ensure secure.			Minor			X	X		X						X	X					X			
015006	N/A	Reservoir flexible suction pipe assembly.	Examine. (Removed).		A82 A144	Major					X	X					X	X	X	X	X	X	X				
015007	C009 C081	Main system Non Return Valve. (Pre Mod Dowty AC 3655).	Replace. (Bay Service).		A82 A144	Minor			X	X	X	X					X	X	X	X	X	X	X				
015003	N/A	<u>Engine Compartment</u> Hydraulic pump.	See CRL.														X	X	X	X	X	X	X				
015008	N/A	<u>Centre Fuselage and Stub Wing</u> Rigid pipelines between frames 25 and 32.	Examine as far as possible.		A12	Major					X	X					X	X	X	X	X	X	X				
015009	N/A	<u>Port and Starboard Mainplanes</u> Flap synchronising jack rigid pipelines rear of rear spar.	Examine.		A323 A340	Major (2)						X					X	X	X	X	X	X	X				
SMS/SL 3/4A																											
Continued																											

SMS/ST/3/4PA

MASTER SERVICING LIST

HUNTER ALL MARKS

AP101B-1300-5A1

Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY		
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C			
HYDRAULIC POWER SYSTEM - 50 (Contd)																							
015010	N/A	<u>Port and Starboard Undercarriage Compartment</u> Rigid pipelines.	Examine.		A325 A341	Major (2)							X					X	X	X	X		
015011	C083A	<u>General</u> System	Sample. (SP 446).		A161B	Minor				X	X	X	X					X	X	X	X		
	N/A		Bleed. (ASM).		A383	Major (2)							X					X	X	X	X		
015012	C082	<u>CENTRE FUSELAGE</u> RIGID PIPELINES BETWEEN FRAMES 18B AND 40A.	EXAMINE AS FAR AS POSSIBLE		A82	minor				X	X	X						X	X	X	X		
CABIN PRESSURIZATION AND AIR CONDITIONING SYSTEM - 51																							
015101	C095	<u>General</u> Complete system.	Test. (SP 132).		A178	Minor				X	X	X	X					X	X	X	X		

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C				CTY
015102	C069	Cockpit Air extractor valve.	Examine.		A112	Minor			X	X	X	X					X	X	X	X				
015103	C069	Extractor valve outlet hole.	Ensure clear.		A112	Minor			X	X	X	X					X	X	X	X				
015104	C069	Spray pipe holes.	Ensure clear.		A112	Minor			X	X	X	X					X	X	X	X				
015105	C069	Punkah louvres.	Examine.		A112	Minor			X	X	X	X					X	X	X	X				
015106	N/A	Pipelines.	Examine.		A112	Major					X	X					X	X	X	X				
015107	N/A	Front Fuselage Water extractor.	Ensure drain is clear.		N/A	B/F,A/F											X	X	X	X				
	C012 C083		Replace. (Bay Service).		A80 A81	Minor			X	X	X	X					X	X	X	X				
015108	N/A	Pipelines.	Examine.		A102	Major					X	X					X	X	X	X				
015118	N/A	Pipeline lagging and attachment clips.	Examine.		A267	Major (2)						X					X	X	X	X				
015109	N/A	Centre Fuselage Pre-cooler.	Drain.		N/A	30 Hours											X	X	X	X				
	C069		Test for leaks. (SP 441). (Introduced by SI/Hunter/107A).		A84	Minor			X	X	X	X					X	X	X	X				
015110	N/A	Inter-cooler.	Drain.		N/A	30 Hours											X	X	X	X				
015111	N/A	Cold air unit.	Check oil level.		N/A	B/F,A/F											X	X	X	X				
015112	N/A	Pipes. (Pre Mod 1073).	Deleted by AL 12.		N/A																			
015113	N/A	Pipes. (Cold air unit to inter-cooler).	Examine. (Removed).		A84 A144	Major					X	X					X	X	X	X				
SMS/86/8/44A																					Continued			

Continued

Chapter 1 AIRFRAME
Sheet 32
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	
CABIN PRESSURIZATION AND AIR CONDITIONING SYSTEM - 51 (Contd)																						
015114	A027	<u>Cockpit</u> Windscreen spray drain container. (If fitted).	Drain. (Removed).			Primary	X	X	X	X		X								X		
			Ensure vent holes clear.			Primary	X	X	X	X		X									X	
015115	N/A	Servicing deleted.			N/A																	
015116	A027	Hood spray drain container. (If fitted).	Drain. (Removed).			Primary	X	X	X	X		X								X		
			Ensure vent holes clear.			Primary	X	X	X	X		X									X	
015117	N/A	Servicing deleted.			N/A																	
SMS/ 56/5/11																						
Continued overleaf																						

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9		
AIRCRAFT FUEL SYSTEM - 52																											
015201	A202	<u>Port and Starboard Mainplane</u> 100 gallon drop tanks. (If fitted).	Check crutching load. (EMRU pylons). (Weapons).		W18	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X				
			Check crutching load. (ERU Pylons). (Weapons).		W18	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X				
	N/A		Look for signs of leaks and obvious damage.		N/A	T/R,A/F											X	X	X	X	X	X	X				
			Ensure secure. (Tank empty).		N/A	T/R,A/F											X	X	X	X	X	X	X				
	N/A		See CRL.		N/A												X	X	X	X	X	X	X				
015202	A029 A030	100 gallon drop tank stabilizing fin top and bottom surfaces.	Examine. (SP 405). (Introduced by SI/Hunter/51).		A3 A4	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X				
015203		<u>Front Fuselage</u> Internal vent heads. (Pre Mod 458).	Deleted by AL 15.		N/A																						
015204	N/A	<u>Port and Starboard Mainplanes</u> 230 gallon drop tanks. (If fitted).	Look for signs of leaks and damage.		N/A	T/R,A/F												X					X				
			Ensure secure. (Tank empty).		N/A	T/R,A/F												X					X				
	A201		Check crutching load. (Weapons).		W19	Primary	X	X									X						X				
	N/A		See CRL.		N/A												X						X				
SMS/ 31.5/ 27A																	Continued										

MASTER SERVICING LIST
HUNTER ALL MARKS

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C	9			
AIRCRAFT FUEL SYSTEM - 52 (Contd)																									
015205	N/A	Port and Starboard Mainplanes (Contd) 230 gallon drop tank bracing strut.	Ensure secure.		N/A	T/R,A/F											X						X		
	C098 C099		Examine.		A70	Minor				X	X	X	X				X						X		
015206	C098 C099	230 gallon drop tank suspension lug.	Look for cracks. (Ardrox).		A70	Minor				X	X	X	X				X						X		
015207		Inboard Pylon Type B. Port.	Deleted by AL 15.																						
015208		Inboard Pylon Type B. Starboard.	Deleted by AL 15.																						
015209	N/A	No 1 fuel tank.	Examine. (Removed).		A317 A334 A359 A370	Major (2)						X				X	X	X	X	X	X	X			
			Test. (Removed).		A317 A334	Major (2)						X			X	X	X	X	X	X	X				
015210	N/A	No 2 fuel tank.	Examine. (Removed).		A318 A335 A360 A371	Major (2)						X				X	X	X	X	X	X	X			
			Test. (Removed).		A318 A335	Major (2)						X			X	X	X	X	X	X	X				
SMS/80/5/152																		Continued overleaf							

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9				
015211	N/A	No 3 fuel tank.	Examine. (Removed).		A319 A336 A361 A372	Major (2)							X			X	X	X	X	X	X	X			
			Test. (Removed).		A319 A336	Major (2)							X			X	X	X	X	X	X	X			
015212	N/A	No 4 fuel tank.	Examine. (Removed).		A320 A337 A362 A373	Major (2)							X			X	X	X	X	X	X	X			
			Test. (Removed).		A320 A337	Major (2)							X			X	X	X	X	X	X	X			
015213	N/A	<u>Centre Fuselage</u> Front fuel tank. (Port).	Examine. (Removed).		A289 A345	Major (2)							X			X	X	X	X	X	X	X			
			Test. (Removed).		A289	Major (2)							X			X	X	X	X	X	X	X			
015214	N/A	Front fuel tank. (Starboard).	Examine. (Removed).		A290 A346	Major (2)							X			X	X	X	X	X	X	X			
			Test. (Removed).		A290	Major (2)							X			X	X	X	X	X	X	X			
015215	N/A	Centre fuel tank. (Port).	Examine. (Removed).		A295 A348	Major (2)							X					X	X	X	X				
			Test. (Removed).		A295	Major (2)							X					X	X	X	X				
015216	N/A	Centre fuel tank. (Starboard).	Examine.		A296 A349	Major (2)							X					X	X	X	X				
			Test. (Removed).		A296	Major (2)							X					X	X	X	X				
SMS/ 0077/ 42 A		Continued																							

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C	
AIRCRAFT GENERAL - 01																						
020101		Aircraft Aircraft.	Deleted. (AL 2).																			
EMERGENCY EQUIPMENT - 08																						
020801	N/A	Ejection Seat Installation Ejection seat.	See CRL.		N/A												X	X	X	X	X	X
020802	N/A	Seat cartridges.	See CRL.		N/A												X	X	X	X	X	X
020823	N/A	Canopy cartridges.	See CRL.		N/A												X	X				X
020824	N/A	Canopy and guillotine Cartridges	See CRL.		N/A														X	X	X	X
020803	N/A	Top latch plunger.	Ensure held in full engagement by safety pin.		N/A	A/F											X	X	X	X	X	X
020804	N/A	Barostatic time release unit static line.	Ensure secure to anchorage.		N/A	A/F											X	X	X	X	X	X
020805	N/A	Barostatic time release unit primary plunger cap.	Ensure secure.		N/A	A/F											X	X				X
020835	N/A	Anti-G flexible hose and connections.	Examine.		N/A	Each Ejection Seat Fitting	Out of Phase										X	X	X	X	X	X
SMS/83/51614																						
Continued overleaf																						

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9			
020825	N/A	<u>Ejection Seat Installation</u> (Contd) Barostatic time release static rod fork end shackle.	Examine. (SI/Ejection Seat/27).		N/A	Each seat refit.											X	X	X	X	X	X	X			
020806	N/A	Drogue gun release plunger.	Ensure cocked correctly. (Mk 6, 6A & 9 - SP52A). (Mk 7, 7A & 8B - SP 52B). (Introduced by SI/Ejection Seat/37)		N/A	Each drogue gun arming											X	X	X	X	X	X	X			
020807	N/A	Drogue gun static rod.	Ensure secure to anchorage bracket.		N/A	A/F											X	X	X	X	X	X	X			
020808	N/A	Drogue gun static rod fork end shackle.	Examine. (Introduced by SI/Ejection Seat/ 27).		N/A	Each seat refit											X	X	X	X	X	X	X			
020809	N/A	Drogue withdrawal line.	Ensure routed correctly.		N/A	A/F											X	X	X	X	X	X	X			
020810	N/A	Drogue gun shackle.	Ensure secure to piston.		N/A	A/F											X	X	X	X	X	X	X			
020811	N/A	Drogue container flap pin safety tie.	Ensure intact.		N/A	A/F											X	X	X	X	X	X	X			
020812	N/A	Drogue link line.	Ensure routed outside parachute restraint straps and through jaws of guillotine unit.		N/A	A/F													X	X	X	X				
020830	N/A	Seat raising handle.	Ensure level with seat pan rim.		N/A	B/F, T/R, A/F													X	X	X	X				
020813	N/A	Seat pan firing cable eye end tie. (Applicable 3H seat only).	Ensure secure. (Introduced by SI/Ejection Seat/ 31).		N/A	A/F											X	X					X			
			Replace.		N/A	6 Months or each seat refit.											X	X					X			
020826	N/A	Scissor shackle safety tie.	Ensure intact.		N/A	A/F											X	X	X	X	X	X	X			
020827	N/A	Canopy jettison linkage.	Ensure connected to canopy firing unit sear.		N/A	A/F													X	X	X	X				
020828	N/A	Manual separation handles.	Ensure locked down.		N/A	B/F, T/F, A/F													X	X	X	X				
SMS/83/516/4A																										
Continued																										

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CT	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9		
020814	N/A	<u>Ejection Seat Installation</u> (Contd) Leg restraint cords.	Ensure secure to anchor brackets.		N/A	A/F										X	X	X	X	X	X	X			
020815	N/A	Anti 'G' tube blanking plug.	Ensure secure.		N/A	T/R, A/F										X	X	X	X	X	X	X			
020816	N/A	Low pressure oxygen hose.	Ensure secure to manifold.		N/A	A/F										X	X	X	X	X	X	X			
			Ensure disconnects freely. (Introduced by SI/Ejection Seat/ 20).		N/A	Each Ejection Seat Fitting	Out of Phase (SP 451)								X	X	X	X	X	X					
020829	N/A	Parachute restraint strap loose ends.	Ensure routed correctly. (Introduced by SI/Ejection Seat/ 43).		N/A	Each Safety Equip. Fitting.	Out of Phase								X	X	X	X	X	X					
020831	N/A	Top latch.	Ensure correctly engaged or Ensure securing pin correctly fitted.		N/A	B/F										X	X		X	X	X				
020817	N/A	Mic/Tel connectors.	Ensure connected correctly.		N/A	A/F										X	X	X	X	X	X				
020818	N/A	Firing cable thread tie. (Mk 3H seats only).	Ensure intact.		N/A	B/F, T/R										X	X				X				
020819	N/A	Canopy jettison jacks.	See CRL.		N/A											X	X	X	X	X	X				
020820	N/A	Lap Straps.	Ensure at least 6 inches of free strap protruding from end of buckle.		N/A	B/F, T/R										X	X				X				
020821	N/A	Emergency oxygen system stirrup quick release connections.	Ensure connected.		N/A	B/F										X	X	X	X	X	X				
020822	N/A	Emergency oxygen bottle tell-tale wire.	Ensure intact.		N/A	B/F, T/R A/F										X	X	X	X	X	X				
SMS/83/516/5																									

Continued overleaf

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9				
020823	N/A	<u>Ejection Seat Installation</u> (Contd) Emergency oxygen system upper rubber tubing.	Examine..		N/A	B/F, T/R A/F										X	X	X	X	X	X	X			
020824	N/A	Emergency oxygen system upper rubber tubing sealing washer.	Ensure present.		N/A	B/F, T/R A/F										X	X	X	X	X	X	X			
020832	N/A	Parachute harness sticker strap lugs (2).	Ensure correctly engaged in seat pan clips.		N/A	B/F										X	X	X	X	X	X	X			
020833	N/A	Parachute pack restraining straps (2).	Ensure correctly engaged in pack container clips.		N/A	B/F										X	X					X			
020834	N/A	Face screen and ejection gun safety pin.	Ensure gap between legs is not excessive and pin is held firmly in position (Annex 1).		N/A	A/F										X	X					X			
020836	N/A	Droque gun static rod quick release pins.	Pull-off load check. (Introduced by SI/ES/45A). (SP 52A).		N/A	Each seat refit										X	X	X	X	X	X	X			
020837	N/A	Barostatic time release unit static rod quick release pins.	Pull-off load check. (Introduced by SI/ES/45A). (SP 52A).		N/A	Each seat refit										X	X	X	X	X	X	X			
020838	N/A	Reaction Cord (2 off).	See CRL.		N/A																				
SMS/83/516/5A																									
																							Continued		

Continued

AP101B-1300-5A1
Section 1

SMS 15

Sch. Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C					
<u>FIRE PROTECTION SYSTEM - 55</u>																											
		<u>Centre Fuselage</u>																									
025501	N/A	Fire extinguisher cartridges.	See CRL.		N/A														X	X	X	X					
025502	N/A	Fire extinguisher.	See CRL.		N/A														X	X	X	X					
<u>ELECTRICAL WEAPONS SERVICES - 62</u>																											
		<u>Weapons Systems</u>																									
026201	N/A	Selector switches.	Ensure set to 'SAFE'.		N/A	B/F, T/R, A/F													X	X	X	X					
SMS/89/6/6A																		Continued									

MASTER SERVICING LIST
HUNTER ALL MARKS

Sched Ident No.	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9	
GUN PACKAGE INSTALLATION - 90																						
		<u>Front Fuselage</u>																				
029001	N/A	Gun package.			N/A		X									X	X				X	
029002	N/A	Gun barrels.	Sec CRL		N/A											X	X				X	
029003	N/A	Main supply lead.	Ensure stowed during non-firing sorties.		N/A	B/F										X	X				X	
029004	C025	Blast tubes.	Clean.			Minor			X	X		X				X	X				X	
			Examine.			Minor			X	X		X					X	X			X	
029005	B201	Blast deflectors.	Clean.			Primary*		X	X	X		X				X	X				X	
			Examine.			Primary*		X	X	X		X					X	X			X	
029006	C205	Barrel support assemblies.	Clean. (Removed).			Minor			X	X		X				X	X				X	
			Examine. (Removed).			Minor			X	X		X					X	X			X	
			Lubricate. (Removed).			Minor			X	X		X					X	X			X	
	C207		Centralize.			Minor			X	X		X					X	X			X	
029007	B203	Gun compartment ventilator actuator mechanism.	Examine. (Introduced by SI/Hunter/49A). (SP 453).			Primary*		X	X	X		X				X	X				X	
029008	B201	Gun package attachment and locking guides. (Aircraft portion).	Examine.			Primary*		X	X	X		X				X	X				X	
			Lubricate.			Primary*		X	X	X		X					X	X			X	
029009	C205- C207	Ballast. (If fitted).	Replace. (Bay Service).			Minor			X	X		X				X	X				X	
SMS/56/-/16														Continued overleaf								

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9		
<u>ADEN GUN INSTALLATION - 91</u>																											
029101	N/A	<u>Centre Fuselage</u> Aden Gun.	Inhibit. (If fired).		N/A	A/F														X							
			See CRL.		N/A															X							
029102	N/A	Gun barrel.	See CRL.		N/A															X							
029103	B204	Gun compartment ventilator actuating mechanism.	Examine. (SI/Hunter/49A). (SP 453).		W12	Primary*		X	X	X	X	X								X							
029104	C206	Blast tube seal assembly.	Clean.		W12	Minor			X	X	X	X								X							
			Examine. (Removed).		W12	Minor			X	X	X	X								X							
			Lubricate.		W12	Minor			X	X	X	X								X							
029105	C208	Gun and ammunition compartments.	Examine.		W13	Minor			X	X	X	X								X							
029106	C208	Gun and ammunition tank pulleys.	Examine.		W13	Minor			X	X	X	X								X							
			Lubricate.		W13	Minor			X	X	X	X								X							
029107	C208	Ammunition tank cables.	Examine.		W13	Minor			X	X	X	X								X							
029108	C208	Barrel steady bearing.	Examine. (Removed).		W13	Minor			X	X	X	X								X							
			Lubricate.		W13	Minor			X	X	X	X								X							
029109	B204	Blast deflector.	Clean.		W12	Primary*		X	X	X	X	X								X							
			Examine.		W12	Primary*		X	X	X	X	X								X							
029110	C208	Ammunition tank.	Examine. (Removed).		W13	Minor			X	X	X	X								X							
SMS/11/11/11																											
																				Continued							

Continued

Chapter 2 WEAPONS
Sheet 5
AL 32

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							QTY
							P	P*	M	M*	MJ	MJ (2)									
<u>PYLON INSTALLATION - 93</u>																					
029301		Port and Starboard EMRU Pylons (If fitted) Pylon bomb carrier type A.	See CRL			6 Months											X	X	X	X	
029302	N/A	EMRU No. 1 Mk 1.	Ensure cocked correctly.		N/A	T/R,A/F											X	X	X	X	
029303			See CRL.		N/A												X	X	X	X	
029304	N/A	Pylon hanger bolts.	Deleted by AL30																		
			Examine. (Introduced by SI/Hunter/44A).		N/A	6 Months											X	X	X	X	
SMS/88/8/6															Continued overleaf						

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark					CTY	
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B		8C
<u>PYLON INSTALLATION - 93 (Contd)</u>																							
029305		<u>Port and Starboard</u> <u>ERU Pylons (If fitted)</u> Pylon bomb carrier type B.	See CRL			6 Months													X	X	X	X	
029306	N/A	Ejector release unit.	See CRL.		N/A														X	X	X	X	
029307	N/A	Practice/Normal switches.	Ensure in correct position.		N/A	B/F													X	X	X	X	
029308	N/A	ERU cartridges.	See CRL.		N/A														X	X	X	X	
029309	N/A	ERU shear rivets. (Pylons Pre Mod DL 94).	See CRL. (Introduced by SI/Armament/45B).		N/A														X	X	X	X	
029310	N/A	Carrier Bomb Light Stores. (C.B.L.S.)	Fuzing and release checks.		N/A	Every CBLS Fit.													X				
029311	N/A	Housing fuzing and release unit	Examine.		N/A	6 Month													X	X	X	X	
<u>SNED ROCKET INSTALLATION (IF FITTED) - 95</u>																							
029501	N/A	<u>Mainplanes</u> <u>(Port and Starboard)</u> Outboard pylons.	Examine.		N/A	A/F													X	X			
SMS/88/8/6A																							

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9					
AIRCRAFT GENERAL - 01																										
030101	N/A	<u>General</u> Aircraft.	Check bonding. (SP 191)		E50	Major												X	X	X	X	X	X	X		
030102	B312	<u>Starter and Generator Access Compartments</u> Cables and connectors.	Examine as far as possible.		E25	Primary*		X	X	X	X	X						X	X	X	X	X	X	X		
	N/A		Examine (Cambric tape removed).		E130	Major (2)						X						X	X	X	X	X	X	X		
030103	N/A	<u>Radio Compartment</u> Generator panel supporting chain.	Ensure fitted and stowed correctly.			B/F												X	X	X	X	X	X	X		
030105	N/A	Cables and connectors.	Examine.		E128	Major (2)						X						X	X	X	X	X	X	X		
030104	N/A	<u>Centre Fuselage</u> Fatigue meter.	Record readings.			A/F												X	X	X	X	X	X	X		
			See CRL.															X	X	X	X	X	X	X		
030106	N/A	Cables and connectors.	Examine.		E129	Major (2)						X						X	X	X	X	X	X	X		
SMS/82/184/48														Continued overleaf												

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY	
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9			
<u>AIRCRAFT GENERAL - 01 (Contd)</u>																								
		<u>Cockpit</u>																						
030107	N/A	Port and starboard throttle flexible cables.	Examine.		E119	Major (2)						X						X	X	X	X			
030108	N/A	Port and starboard control column flexible cables.	Examine.		E119	Major (2)						X						X	X	X	X			
030109	N/A	Port and starboard instrument panel anti- vibration mountings.	Examine.		E120	Major (2)						X			X	X	X	X	X	X	X	X		
030110	N/A	Cables and connectors.	Examine.		E119	Major (2)						X			X	X	X	X	X	X	X	X		
030111	N/A	HP cock cables.	Examine.		E119	Major (2)						X			X	X	X	X	X	X	X	X		
030112	N/A	Control column cables.	Examine.		E119	Major (2)									X	X						X		
030113	N/A	Throttle lever cables.	Examine.		E119	Major (2)						X			X	X						X		
		<u>Front Fuselage</u>																						
030114	N/A	Cables and connectors.	Examine.		E121	Major (2)						X			X	X	X	X	X	X	X	X		
		<u>Rear Fuselage</u>																						
030115	N/A	Cables and connectors.	Examine (Cambric tape removed).		E125	Major (2)						X			X	X	X	X	X	X	X	X		
SMB/82/184/48A															Continued									

Chapter 3 ELECTRICAL
Sheet 2
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

[illegible]

Chapter 3 ELECTRICAL
Sheet 3
AL40

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No.	Card No.	Item	Operation	C O D E	Major Card No.	Frequency	Servicing								Mark										CTY
							P	P*	M	M*	MJ	MJ (2)													
FLYING		CONTROL OPERATING SYSTEM - 13	(Contd)																						
031308	C308	<u>Cockpit</u> Standby switch box assembly.	Operate.		E55	Minor				X	X	X	X							X	X	X	X		
031309	D310 D325	Control handle(s).	Replace. (Bay Service).		E13 E41	Minor*				X	X	X								X	X	X	X		
031311	N/A	<u>Starboard Undercarriage Compartment</u> Aileron accumulator pressure gauge.	Replace. (Bay Service).		E109 E141	Major (2)						X								X	X	X	X		

SM 92/0372 (2)

Continued overleaf

Sched Ident No.	Card No.	Item	Operation	C O D E	Major Card No.	Frequency	Servicing								Mark						
P	P*	M	M*	MJ	MJ (2)										7	7A	8B	8C			CTY
<u>AIRBRAKE OPERATING SYSTEM - 15</u>																					
031501	N/A	Rear Fuselage Airbrake pressure switch.	Replace. (Bay Service).	E109 E141	Major (2)					X					X	X	X	X			

SM 92/0372 (2A)
Continued

Chapter 3 ELECTRICAL
Sheet 4
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY		
							P	P*	M	M*	MJ	MJ (2)		6	6A	7	7A	8B	8C	9				
<u>BRAKE PARACHUTE SYSTEM - 17</u>																								
031701	N/A	<u>Tail Cone Break</u> <u>(Frame 47)</u> Plug R37 and socket R38.	Examine.			Each Tail Cone Removal.											X	X	X	X	X	X		
031702	N/A	<u>Rear fuselage</u> Brake parachute test switch.	Operate.			B/F,T/R A/F													X	X	X	X		
<u>ARRESTER GEAR SYSTEM - 18</u>																								
031801	B305	<u>Rear Fuselage</u> Microswitches. (If fitted).	Examine and particularly associated wiring for correct routing.		E23	Primary*		X	X	X	X	X							X	X	X			
5-75/86/5/18														Continued overleaf										

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY					
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B		8C	9			
<u>MAIN UNDERCARRIAGE - 28</u>																										
032801	B305	<u>Port Undercarriage</u> Micro switches.	Examine and particularly associated wiring for correct routing.		E22	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			
032802	B307	<u>Starboard Undercarriage</u> Micro switches.	Examine and particularly associated wiring for correct routing.		E22	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			
<u>NOSE UNDERCARRIAGE - 30</u>																										
033001	B308	<u>Nose Undercarriage</u> Micro switches.	Examine and particularly associated wiring for correct routing.		E22	Primary*		X	X	X	X	X					X	X	X	X	X	X	X			
033002	B303	Cable assembly. F35.	Examine and particularly in vicinity of nose cone lower fastener.			Primary*		X	X	X		X					X	X					X			
			Ensure routed correctly.			Primary*		X	X	X		X					X	X					X			
			Ensure bound with PVC tape.			Primary*		X	X	X		X					X	X					X			
5015/86/5/18A																										
Continued																										

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY						
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B	8C				
<u>WHEEL BRAKE SYSTEM - 32</u>																											
033201	N/A	<u>Cockpit</u> Brake and main accumulator air pressure gauge.	Replace (Bay Service).		E105 E138	Major (2)							X					X	X	X	X						
<u>BASIC ENGINE - 38</u>																											
033801	N/A	<u>Cockpit</u> Tachometer.	Replace (Bay Service).		E14 E42	Major						X	X					X	X	X	X						
033802	N/A	<u>Engine Compartment</u> Deleted. (AL 2).																									
033803	N/A	Suppressors.	Clean.			Each engine removal								(Out of Phase) (SP 81B)				X	X	X	X						
			Examine.			Each engine removal									(Out of Phase) (SP 81B)				X	X	X	X					

Sche Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark				CTY	
							P	P*	M	M*	MJ	MJ (2)							7	7A		8B
BASIC ENGINE - 38 (Contd)																						
033804	N/A	<u>Engine Compartment</u> Air supply valve actuator.	Clean.			Each Engine Removal												X	X	X	X	
			Examine.			Each Engine Removal												X	X	X	X	
ENGINE OIL SYSTEM - 40																						
034001	N/A	<u>Cockpit</u> Oil pressure gauge.	Replace (Bay Service).		E106 E137	Major (2)							X					X	X	X	X	
SMS/86/8/62A																		Continued				

Chapter 3 ELECTRICAL
Sheet 6
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		8C	9																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
ENGINE STARTING AND IGNITION SYSTEM - 42																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
034201	N/A	<u>Centre Fuselage</u> Overspeed relay cable.	Test			Each Engine Removal												X	X																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY	
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C		9
<u>HYDRAULIC POWER SYSTEM - 50</u>																						
035001	N/A	<u>Front Fuselage</u> Hydraulic pressure switch.	Replace (Bay Service).		E107 E139	Major (2)						X					X	X	X	X		
035002	N/A	<u>Gun Pack Compartment</u> Hydraulic pressure switch.	Replace (Bay Service).		E108 E140	Major (2)						X		X	X					X		
<u>CABIN PRESSURISATION AND AIR CONDITIONING SYSTEM - 51</u>																						
035101	B311	<u>Cockpit</u> Combined valve unit inlet grid. (2 off).	Ensure clear.		E19	Primary*		X	X	X	X	X		X	X	X	X	X	X	X		X
035102	D314	Controller.	Examine as far as possible.		E10	Minor*				X	X			X	X	X	X	X	X	X		
	D329		Test.		E57	Minor*				X	X			X	X	X	X	X	X			
	N/A		Replace. (Bay Service).		E102 E132	Major (2)						X		X	X	X	X	X	X			
03/10/1975														Continued								

Chapter 3 ELECTRICAL
Sheet 7
AL 16

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C		9		
CABIN PRESSURISATION AND AIR CONDITIONING SYSTEM -51 (Contd)																									
035103	N/A	Cockpit Combined valve unit(s)	Replace. (Bay Service).		E102 E132	Major (2)							X				X	X	X	X	X	X	X		
035104	N/A	Combined valve unit, valve to aircraft mounting seals.	Replace. (Scrap).		E102 E132	Major (2)							X				X	X	X	X	X	X	X		
AIRCRAFT FUEL SYSTEM - 52																									
035201	C331	General Complete system.	Zero. (SP 193).		E59	Prim * Minor		X	X	X	X	X					X	X	X	X	X	X	X		
035202	C401	Centre Fuselage Fuel pressure warning switch.	Replace. (Propulsion). (Bay Service).		E12 E38	Minor			X	X	X	X					X	X	X	X	X	X	X		
SMS/82/184/54														Continued overleaf											

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9	
<u>AIRCRAFT FUEL SYSTEM - 52 (Contd)</u>																								
035203	N/A	<u>Port and Starboard Mainplanes</u> Fuel contents system co-axial cables and connectors.	Examine as far as possible (Mainplane removed).		E124	Major (2)							X			X	X	X	X	X	X	X		
035204	N/A	<u>Centre Fuselage</u> Fuel contents system co-axial cables and connectors.	Examine as far as possible.		E131	Major (2)							X			X	X	X	X	X	X	X		
035205	N/A	<u>Rear Fuselage</u> Fuel contents system co-axial cables and connectors.	Examine as far as possible.		E126	Major (2)							X			X	X					X		
<u>FIRE PROTECTION SYSTEM - 55</u>																								
035501	C330	<u>General</u> Complete system.	Test. (SP 198).		E49	Minor				X	X	X	X			X	X	X	X	X	X	X		
035502	N/A	<u>Engine Compartment</u> Firewire elements.	Examine.			Each Engine Removal										X	X	X	X			X		
SMS/82/184/54A														Continued										

Chapter 3 ELECTRICAL
Sheet 8
AL 23

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							QTY
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	
<u>FIRE PRECAUTION SYSTEM - 55 (Contd)</u>																					
035504	N/A	<u>Engine Compartment (Contd)</u>																			
		Detection system.	Test.	N/A	Each Engine Removal	(Out of Phase) (SP 81)													X	X	
035505	N/A	Flame switches.	Examine.		N/A	Each Engine Removal	(Out of Phase) (SP 81)												X	X	
			See CRL	N/A															X	X	
035503		<u>Radio Bay and Gun Bay Frame 12</u>																			
		Inertia switch.	Servicing deleted by AL 3.	N/A																	
035506	N/A	Inertia switch.	See CRL.		N/A																
035507	N/A	<u>REAR FUSELAGE</u> Firewire elements	Examine		N/A	Each Rear Fuselage Removal	(Out of Phase) (SP1)							X	X	X	X			X	
SMS/84/179/5														Continued overleaf							

SMS/84/179/5

Chapter 3 ELECTRICAL
Sheet 9
AL 28

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9					
<u>ANTI - G SYSTEM - 59</u>																										
035901	N/A	<u>Cockpit</u> Pressure gauge.	Replace. (Bay Service).		E105 E138	Major (2)									X			X	X	X		X	X	X		
036017	N/A	MAIN BATTERIES SEALED LEAD ACID. (SLAB)	CHECK VOLTAGE			B/F												X								
			LOOK FOR SIGNS OF LEAKS AND OBVIOUS DAMAGE.			A/F												X								
			SEE CRL															X								
<u>ELECTRICAL POWER SUPPLIES AND DISTRIBUTION - 60</u>																										
036001	N/A	<u>Radio Compartment</u> Main batteries Type 'J'.	Check voltage.			B/F												X	X	X	X	X	X	X		
			Look for signs of leaks and obvious damage.			A/F												X	X	X	X	X	X	X		
			See CRL.															X	X	X	X	X	X	X		
036018	N/A	MAIN BATTERY QUICK DISCONNECT (20A)	EXAMINE (SP 469)			EVERY MAIN BATT CK.												X	X	X	X	X	X	X		
501/20/5/20														Continued overleaf												

AL43

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark									CTY						
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9								
ELECTRICAL POWER SUPPLIES AND DISTRIBUTION - 60 (Contd)																													
036002	N/A	<u>Radio Compartment (Contd)</u>																											
		Emergency batteries.	Replace (If used). (Bay Service)			On Condition									X	X	X	X	X	X	X								
			See CRL.											X	X	X	X	X	X	X									
036003	N/A	UHF Standby battery. (If fitted).	Test.			Every Battery Change								X	X	X	X	X	X	X									
			See CRL.											X	X	X	X	X	X	X									
036004	B302	<u>General</u> Generator control system.	Test. (SP 192).		E60	Primary*		X	X	X	X	X		X	X	X	X	X	X	X									
036005	B301	<u>Radio Compartment</u> Main battery tray.	Check bond resistance. (Pre SEM/HUNTER/O11TC only).			Primary*		X	X	X		X		X	X					X									
	N/A		Deleted (AL 12).																										
036006	N/A	Emergency battery tray.	Deleted (AL 12).																										
036007	N/A	UHF Standby battery tray (If fitted).	Deleted (AL 12).																										
036008	D401 D402	<u>Engine Compartment</u> Generator. (2 off).	Replace. (Propulsion). (Bay Service).		E11 E37	Minor*				X	X	X		X	X	X	X	X	X	X									
036009	N/A	Cables and connectors.	Examine.			Each Engine removal								X	X	X	X	X	X	X									
000/00/0/200																					Continued								

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CT
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9	
ELECTRICAL POWER SUPPLIES AND DISTRIBUTION - 60 (Contd)																								
		<u>Undercarriage Compartments (Port, Starboard and Nose)</u>																						
036010	B304	Cables and connectors.	Examine.		E21	Primary*		X	X	X	X	X			X	X	X	X	X	X	X			
036011	N/A	<u>Rear Fuselage</u> Cables and connectors.	Examine.			Each Jet Pipe Removal								(Out of Phase)		X	X	X	X	X	X	X		
036012	N/A	<u>Cockpit</u> Voltage regulator. (Pre Mod 1247).	See CRL.													X	X	X	X	X	X	X		
036014	N/A	Main trunking junction box. (2 off).	Examine.			Each Scheduled Ejection Seat Removal								(Out of Phase) (SP 470)				X	X	X	X			
036013	N/A	<u>Generator Control Panel</u> Terminal stud and nut. (Carrying cable F52 to bus-bar).	Examine.		E28	Major					X	X			X	X	X	X	X	X	X			
036015	C309	<u>Centre Fuselage</u> <u>Frames 17A to JBI Starter Bay</u> Cable loom C16.	Examine and particularly for chafing.		E26	Minor				X	X	X	X		X	X	X	X	X	X	X			
036016	N/A	<u>Centre Fuselage</u> JB1.	Examine internally.		E139	Major (2)									X	X	X	X	X	X	X			
SMS/86/5/21																								
Continued overleaf																								

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	
INTERNAL AND EXTERNAL LIGHTING																					
036101	N/A	<u>Lighting Systems</u>	Operate. (If night flying intended).			B/F, T/R															
036102	C325	<u>Cockpit</u> Cockpit lamps Type C.	Examine. (Introduced by SI/ ELECT/30).		E18	Minor				X	X	X	X				X	X	X	X	
036103	C326	Cockpit lamps Type B.	Examine.			Minor				X	X		X				X	X			
036104	N/A	Emergency lighting.	Operate.			Prior to Emergency Battery Removal											X	X			
						(Out of Phase)											X	X	X	X	
036105	C342	Bridge and pillar lamps. (Pre Mod Elect F324).	Examine. (Introduced by SI/ELECT/24B). (SP 467).		E18	Minor				X	X	X	X				X	X	X	X	
ms/86/5/21A																					
Continued																					

505/86/3/21A

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9				
<u>ELECTRICAL ARMAMENT SERVICES - 62</u>																									
036201	N/A	<u>Radio Compartment</u>	Check voltage output.			Major (2)																			
036202	C327	Arm JB1	Examine.		E27	Minor			X	X	X	X		X	X	X	X	X	X	X	X				
036203	C327	Arm JB1 plugs and sockets.	Examine. (Disconnected).		E27 E39	Minor			X	X	X	X		X	X	X	X	X	X	X	X				
<u>JET PIPE TEMPERATURE CONTROL SYSTEM - 64</u>																									
036401	N/A	<u>General</u>	Test. (SP 194).		E151	Major (2)								X			X	X	X	X	X	X	X		
		Each Engine Removal				(Out of Phase) (SP 81)							X	X	X	X	X	X	X	X					
036402	N/A	<u>Jet Pipe</u>	Examine.			Each Jet Pipe Removal	(Out of Phase) (SP 1)							X	X	X	X	X	X	X	X				
5ms/86/8/22														Continued overleaf											

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9			
JET PIPE TEMPERATURE CONTROL SYSTEM - 64 (Contd)																								
036403	N/A	<u>Engine Compartment</u> Thermocouple leads.	Examine.		E131	Major (2)						X			X	X	X	X	X	X	X			
036404	N/A	<u>Rear Fuselage</u> Thermocouple extension leads.	Examine.		E126	Major (2)						X			X	X	X	X	X	X	X			
RADAR SUPPLIES - 65																								
036501		<u>Radio Compartment</u> Inverter Type 200. (If fitted).	Deleted AL 16.																					
036502	D321	<u>Nosewheel Compartment</u> Inverter Type 206.	Examine.		E8	Minor*					X	X	X		X	X	X	X	X	X	X			
540/56/5/22A														Continued										

Chapter 3 ELECTRICAL Sheet 12 AL 26	MASTER SERVICING LIST HUNTER ALL MARKS	AP101B-1300-5A1 Section 1
---	---	------------------------------

Chapter 3 ELECTRICAL Sheet 12 AL 26	MASTER SERVICING LIST HUNTER ALL MARKS	AP101B-1300-5A1 Section 1
---	---	------------------------------

Chapter 3 ELECTRICAL Sheet 12 AL 26	MASTER SERVICING LIST HUNTER ALL MARKS	AP101B-1300-5A1 Section 1
---	---	------------------------------

Chapter 3 ELECTRICAL			MASTER SERVICING LIST			AP101B-1300-5A1																				
Sheet 12			HUNTER ALL MARKS			Section 1																				
AL 26																										
Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY					
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A		8B	8C	9		
<u>RADAR SUPPLIES - 65 (Contd)</u>																										
<u>Nosewheel Compartment (Contd)</u>																										
036503	D321	Control Panel Type 38.	Examine		E8	Minor*					X	X	X				X	X	X	X	X	X	X			
036504	N/A	<u>Lower Front Fuselage</u> Inverter Type 108.	Examine		E5	Major						X	X				X	X	X	X	X	X				
<u>FLIGHT INSTRUMENTS - 66</u>																										
036601	N/A	<u>Cockpit</u> Turn and slip indicator(s)	Ensure operates on emergency supplies.			Prior to Emergency Battery Removal											X	X	X	X	X	X	X			
	N/A		Replace. (Bay Service).		E14 E42	Major					X	X					X	X	X	X	X	X				
036602	N/A	Accelerometer.	Observe reading.			T/R,A/F											X	X	X	X	X	X				
			Reset.			T/R,A/F												X	X	X	X	X	X			
SMS/64/12/10						Continued overleaf																				

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9			
FLIGHT INSTRUMENTS - 66 (Contd)																										
		<u>Cockpit</u>																								
036603	N/A	Artificial horizon.	Ensure operates on emergency supplies.			Prior to Emergency Battery Removal															X	X	X			
036604	N/A	Artificial horizon(s) (1 off 6 and 9) (2 off 7 and 8)	Replace. (Bay Service).		E103 E104 E133 E134 E135	Major (2)						X				X	X	X	X	X	X	X	X			
036605	N/A	Artificial horizon cables and connectors. (1 off 6 and 9) (2 off 7 and 8)	Examine.		E120	Major (2)						X				X	X	X	X	X	X	X	X			
036606	N/A	Artificial horizon levelling control unit (Post Mod 654).	Replace. (Bay Service).		E104 E133	Major (2)						X				X	X						X			
SMS/64/12/10A																										
Continued																										

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C		9		
<u>OXYGEN SYSTEM - 67</u>																									
036701	N/A	<u>Cockpit</u> Contents gauge.	Replace. (Bay Service).		E105 E138	Major (2)							X				X	X	X	X	X	X	X		
<u>PITOT/STATIC SYSTEM AND INSTRUMENTS - 68</u>																									
036801	B310	<u>General</u> Complete system.	Leak test. (SP 195).		E58	Primary*		X	X	X	X	X				X	X	X	X	X	X	X			
036802		<u>Cockpit</u> Altimeter Mk 19F, 24 or 29B.	Deleted (AL 3).																						
036803		Altimeter Mk 30B.	Deleted (AL 3).																						
036804		Airspeed indicator(s)	Deleted (AL 3).																						
036805	C316 C317	Instrument panel anti-vibration mountings.	Examine.		E15	Minor			X	X	X	X				X	X	X	X	X	X	X			
SMS/83/5/6/ 7																									
Continued overleaf																									

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										QTY
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9		
PITOT/STATIC SYSTEM AND INSTRUMENTS - 68 (Contd)																											
036806	B049	<u>Centre Fuselage</u> Drain traps.....	Examine. (Airframe)		A106	Primary*		X	X	X	X	X					X	X	X	X	X	X	X				
	B310		Drain.		E30	Primary*		X	X	X	X	X					X	X	X	X	X	X	X				
036807	C312	<u>Port Mainplane</u> Drain traps.	Drain.		E31	Minor			X	X	X	X					X	X	X	X	X	X	X				
036808	N/A	Pressure head heater.	Operate.			B/F											X	X	X	X	X	X	X				
036809		<u>Cockpit</u> Airspeed indicator. (Standby).	Deleted (AL 3)																								
036810	C318	Flexible tubing.	Ensure positioned above cross bracing strut.		E16	Minor			X	X	X	X							X								
036811	G021	<u>Starboard Panel</u> Pitot/Static pipes. (Post Mod 779).	Examine.(Airframe) (Introduced by SI/Hunter/74A).		A106	Minor			X	X	X	X							X								
036812	C314	<u>Nose Cone</u> Drain traps.	Drain.		E31	Minor			X	X	X	X								X	X	X					
036813	N/A	<u>Cockpit</u> Cabin altimeter.	Replace. (Bay Service).		E106 E137	Major (2)						X					X	X	X	X	X	X	X				
036814	N/A	Rate of climb indicator.	Replace. (Bay Service).		E104 E133	Major (2)						X					X	X					X				
036815	N/A	Machmeter.	Replace. (Bay Service).		E104 E133	Major (2)						X					X	X					X				
SMS/83/516/7A																											
Continued																											

Chapter 3 ELECTRICAL
Sheet 14
AL 24

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										GT
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9	
PITOT/STATIC SYSTEM AND INSTRUMENTS - 68 (Contd)																								
036816	N/A	<u>Cockpit</u> Amplifier altimeter Mk 1A.	Replace. (Bay Service).		E104 E133	Major (2)						X		X	X					X				
036817	N/A	Altimeter Mk 22.	Replace. (Bay Service).		E104 E133	Major (2)						X		X	X					X				
036818	N/A	<u>Pupils Instrument Panel</u> Rate of climb indicator.	Replace. (Bay Service).		E103 E135	Major (2)						X				X		X	X					
036819	N/A	Machmeter.	Replace. (Bay Service).		E103 E135	Major (2)						X				X		X	X					
036820	N/A	<u>Starboard Instrument Panel</u> Rate of climb indicator.	Replace. (Bay Service).		E103 E134	Major (2)						X			X	X	X	X						
036821	N/A	Machmeter.	Replace. (Bay Service).		E103 E134	Major (2)						X			X	X	X	X						
036822	C305 C306	<u>Port Instrument Panel</u> Indicating Accelerometer.	Replace. (Bay Service).		E14	Minor			X	X	X	X		X	X	X	X	X						
Continued overleaf																								

Sched Ident	Card No	Item	Operation	Code	Major Card No.	Frequency	P	P*	M	M*	MJ	MJ	Mark	Qty
FLIGHT INSTRUMENT SUPPLIES - 72														
037201	A303	General Complete system.	Test. (SP 197).		E53	Primary	X	X	X	X	X	X	X	
037202	N/A	Cockpit Inverter Type 100A and control panel Type 12. (2 off - 6, 6A and 9). (4 off - 7).	Replace. (Bay Service).		E7	Major					X	X	X	
037203	N/A	Gun Compartment Inverter Type 105A. (2 off).	Replace. (Bay Service).		E6	Major					X	X	X	
037301	N/A	AIR DATA SYSTEM-73 Front Fuselage Airstream detection probe.	(1) Look for damage. (II) Ensure free to rotate.		N/A	BF TR AF								
					N/A	BF TR AF								

Continued

Chapter 3 ELECTRICAL
 Sheet 15
 AL 23

MASTER SERVICING LIST
 HUNTER ALL MARKS

AP101B-1300-5A1
 Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C		9
<u>GUN PACKAGE INSTALLATION - 90</u>																								
039001	N/A	<u>General</u>	Gun firing circuit.	Test.		6 Months																		
		(Out of Phase) (SP 199A)																						
<u>ADEN GUN INSTALLATION - 91</u>																								
039101	N/A	<u>General</u>	Gun firing circuit.	Test.		6 Months																		
		(Out of Phase) (SP 199B)																						
SMS/84/179/6																								
Continued overleaf																								

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY				
							P	P*	M	M*	MJ	MJ (2)						6	6A	7		7A	8B	8C	9
<u>PYLON INSTALLATION - 93</u>																									
039301	N/A	<u>General</u> Practice bomb release circuit.	Test.			6 Months												X	X	X				X	
039302	N/A	Bomb fuzing. ERU Circuits.	Test.			6 Months or Pylon Replace- ment												X	X	X	X	X			
039303	N/A	Bomb fuzing. ERU Circuits.	Test.			6 Months or Pylon Replace- ment.																	X		
039304	N/A	TYPE "B" Pylons Jettison Lines.	Test.			6 Months or Pylon Replace- ment.																			
<u>SNEB ROCKET INSTALLATION - 95</u>																									
039501	N/A	<u>Launcher Matra 155</u> Aircraft circuit.	Deleted by AL 15.																						
039502	N/A	Circuit.	Deleted by AL 15.																						
SNV/84/179/6A																									

SHS/84/179/6A

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY				
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9					
AIRCRAFT GENERAL - 01																										
040101	A401	<u>Engine</u> Engine.	Test. (SP 211)		P1 P39	Primary	X	X	X	X	X	X						X	X	X	X					
	B406		Test. (SP 211)		P1 P39	Primary*		X	X	X	X	X			X	X						X				
CENTRE FUSELAGE - 03																										
040301	N/A	<u>Stub Wings</u> Main air intakes.	Look for damage without entering intake.		N/A	B/F, T/R A/F									X	X	X	X	X	X	X					
040302	N/A	Secondary air intakes.	Look for broken springs.		N/A	B/F, T/R A/F									X	X						X				
040303	N/A	Boundary bleeds.	Ensure clear.		N/A	B/F									X	X	X	X	X	X	X					
			Examine as far as possible.		N/A	A/F							X	X	X	X	X	X								
SMS/8610/23																			Continued overleaf							

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9				
040304	N/A	<u>Stub Wings (Contd)</u> Boundary bleed spacers.	Ensure secure.		N/A	B/F, T/R A/F											X	X	X	X	X	X	X				
040305	N/A	<u>Fuselage (External)</u> Engine access panels.	Ensure secure.		N/A	B/F, T/R A/F											X	X	X	X	X	X	X				
			Look for damage.		N/A	T/R, A/F											X	X	X	X	X	X	X				
	C402		Examine.		P7	Minor			X	X	X	X					X	X	X	X	X	X	X				
040306	N/A	Engine bleed valve ducting and louvres.	Look for damage.		N/A	T/R, A/F											X	X	X	X	X	X	X				
	N/A		Ensure unobstructed.		N/A	T/R, A/F											X	X	X	X	X	X	X				
	N/A		Examine.		P11	Major					X	X					X	X	X	X	X	X	X				
040307	N/A	<u>Engine Compartment</u> Compressor vent outlet ducts and lower vent brackets.	Look for cracks and corrosion.		N/A	Each Engine Removal											X	X					X				
	N/A		Examine.			Major						X					X	X					X				
SMS/30/5/93A																											

Continued

HUNTER ALL MARKS

Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								QTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	
BASIC ENGINE - 38																							
043801	N/A	<u>Engine</u> Avon 207 ECU. (Post Mod 2704, 3003, 3447, 3469, 3478 and 3579).	See CRL.		N/A											X	X				X		
043802	N/A	Avon 207 ECU. (Post Mod 2704, 3003, 3469 and 3190).	Servicing deleted by AL 8.		N/A																		
043803	N/A	Avon 12201 ECU. (Post Mod 5274, 5300, 5310 or 5073, 5315, 5351, 5407 and 5460).	See CRL.		N/A													X	X	X	X		
043804	N/A	<u>Centre Fuselage</u> ECU combined overboard fuel drain.	Ensure fuel was ejected on engine run down.		N/A	T/R, A/F										X	X	X	X	X	X		
			Look for leaks.		N/A	A/F										X	X	X	X	X	X		
043805	N/A	<u>Air Intakes</u> Intake guide vanes.	Look for damage without entering intake.		N/A	T/R, A/F										X	X	X	X	X	X		
	A405		Examine. (SP 476)		P5	Primary	X	X	X	X	X	X				X	X	X	X	X	X		
043806	N/A	Compressor blades.	Look for damage without entering intake.		N/A	T/R, A/F										X	X	X	X	X	X		
	A405		Examine as far as possible.		P5	Primary	X	X	X	X	X	X				X	X	X	X	X	X		
043807	A405	Compressor.	Ensure free to rotate in both directions.		P5	Primary	X	X	X	X	X	X				X	X	X	X	X	X		
SMS 153/187/6																							
Continued overleaf																							

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9					
043808	N/A	<u>Engine Compartment</u> Engine.	Look for signs of gas leakage.		N/A	Each Engine Removal											X	X	X	X	X	X	X			
043809	A404	Intake guide vane ram.	Look for signs of leaks.		P5	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X			
	N/A		Check operation.		N/A	At 20+5 hrs (1) Post manufac- ture repair/ recondi- tioning. (2) PV ram change.											X	X					X			
	N/A		Check operation.		N/A	Each Engine Install- ation												X	X					X		
	B407		Check operation. (SP 211).		N/A	Primary*			X	X	X							X	X					X		
043811	A405	<u>Jet Pipe Compartment</u> Exhaust unit.	Examine.		P5	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X			
			Look for rippling of inner skin.		P5	Primary	X	X	X	X	X	X							X	X	X	X	X	X		
043812	N/A	LP turbine blades.	Look for damage without entering jet pipe.		N/A	T/R, A/F											X	X	X	X	X	X	X			
043813	A404	LP turbine blades.	Examine.		P5	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X			
043814	N/A	Nozzle box/LP nozzle guide vanes. (Post mod Avon 5430).	Servicing deleted by AL 19.																							
SMS/83/187/6A																										
Continued																										

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		9C	9	
043815	N/A	<u>Jet Pipe Compartment</u> (Contd) Nozzle box/LP nozzle guide vanes. (Post Mod Avon 5455, Pre Mod Avon 5351 and 5460).	Servicing deleted by AL 19.																						
043810	N/A	LP turbine blades. (Avon Mk 207 Post Mode 2704, 3003, 3469 and 3190).	Examine using a strong light source.		N/A	Initially 400 hrs. Subseque- ntly 15 hrs.	Out of Phase							X	X						X				
<u>JET PIPE - 39</u>																									
043901	A402	<u>Rear Fuselage</u> Jet pipe inner skin.	Examine and particularly for cracking. (Introduced by SI/Avon/40).		P6	Primary	X	X	X	X	X	X		X	X	X	X	X	X	X					
SMS/84/327/10																									

Continued overle.

Sched Ident No	Card No	Item	Operation	Code No.	Major Card	Frequency	P	P*	M	M*	MJ	MI	Mark	Qty
043902	N/A	Jet pipe casing.	Look for cracks and wear caused by chafing against jet pipe structure. (Removed).	P6	Major						X	X	6 6A	
043903	N/A	Jet pipe and rear fuselage.	Look for loose pieces of Alitol Jet pipe lagging in rear fuselage compartment.	N/A	A/F						X	X	7 7A	
043904	C413	Jet pipe final nozzle assembly. (Type JP 123 Pre Mod JP 113).	Examine. (Introduced by SI/Avon/17A).	P6	Minor				X	X	X	X	7 7A	
043905	N/A	Jet pipe thermocouple.	Look for damage.	N/A	T/R, A/F						X	X	6 6A	
ENGINE OIL SYSTEM - 40														
044001	A404	Engine Compartment System.	Look for signs of leaks.	P5	Primary		X	X	X	X	X	X	6 6A	
044002	N/A	Sump.	Check contents. Replenish.	N/A	T/R						X	X	7 7A	
SMS/47/321/10A														
Continued														

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		8C	9	
044003	N/A	<u>Engine Compartment</u> (Contd) Oil pressure filter element.	Examine. (Removed).		N/A	Each Engine Removal	Out of Phase									X	X	X	X	X	X	X			
	G414	Minor							X	X	X	X			X	X	X	X	X	X					
044004	N/A	OIL PRESSURE TRANSMITTER L82/P6/SB.	SEE CRL		N/A												X	X	X	X					
<u>ENGINE FUEL SYSTEM - 41</u>																									
044101	N/A	<u>Engine Compartment</u> System.	Look for signs of leaks.		N/A	A/F											X	X	X	X	X	X			
	A404		Examine.		P5	Primary	X	X	X	X	X	X					X	X	X	X	X	X			
044102	A404	LP fuel filter.	Carry out water/sediment check.			Primary	X	X	X	X	X	X					X	X	X	X	X	X			
044103	N/A	Fuel Control unit RTC 119. 36LL/6427406.	See CRL.		N/A												X	X				X			
044104	N/A	HP Fuel Pump MGTD 53/6R 36LL/7547	See CRL.		N/A												X	X				X			
SMS/38/5/24																									
																	Continued overleaf								

Sche- Ident No	Card No	Item	Operation	Code	Major Card No	Frequency	Servicing										Mark				CTY		
							P	P*	M	M*	MJ	MJ (2)							7	7A		8A	8C
044105	N/A	<u>Engine Compartment</u> (Cont'd) HP Fuel Pump.	See CRL.		N/A														X	X	X	X	
044106	N/A	HP Fuel Pump.	See CRL.		N/A														X	X	X	X	
044107	N/A	Combined Fuel Control Unit	See CRL.		N/A														X	X	X	X	
044108	N/A	Acceleration Control Unit and Metering Unit.	See CRL.		N/A														X	X	X	X	
044109	N/A	Pressure Variable Ram.	See CRL.		N/A														X	X	X	X	
044110	N/A	Governor Pump.	See CRL.		N/A														X	X	X	X	
044111	N/A	Bleed Valve Control Unit.	See CRL.		N/A														X	X	X	X	
044112	N/A	Anti-icing Valve.	See CRL.		N/A														X	X	X	X	
044113	N/A	Anti-icing Actuator.	See CRL.		N/A														X	X	X	X	
044114	N/A	Fuel Filter De-icing Switch.	See CRL.		N/A														X	X	X	X	
044115	N/A	Gun Operated Air Bleed Valve Control Unit.	See CRL.		N/A														X	X	X	X	
044116	N/A	Gun Operated Fuel Dip Unit.	See CRL.		N/A														X	X	X	X	
5m6/81/8/4A																							
Continued																							

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY					
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9						
																				<u>Engine Compartment (Contd)</u>									
044105	N/A	HP Fuel Pump GTD 17/1A 36LL/3506	See CRL.		N/A													X	X	X	X								
044106	N/A	HP Fuel Pump GTD 42/1A 36LL/5484	See CRL.		N/A													X	X	X	X								
																				<u>ENGINE STARTING AND IGNITION SYSTEMS - 42</u>									
044201	A407	<u>General</u> IPN system.	Carry out fuel drainage check. (SP 215).			Primary	X	X	X	X		X			X	X						X							
044202	N/A	<u>Engine Compartment</u> BTH turbo starter Mk 2.	See CRL.		N/A													X	X	X	X								
044203	N/A	IPN starter LTSA 150 Group E.	Examine and particularly for signs of cracking at rear bearing housing attachment lug. (6 off).		N/A	Every ECU fit.									X	X	X	X	X	X	X								
			See CRL																										
044204	A403 A406	HE ignition leads and terminals.	Examine as far as possible.		P14 P15	Primary	X	X	X	X	X	X			X	X	X	X	X	X	X								
SMS/ 11/11/11																				Continued									

Chapter 4 PROPULSION

Sheet 5

AL 28

AL 31. NOT INCORP ON THIS SHEET

FOR DETAILS SEE ALL MARKS. DELETION OF SIN 06-13

MASTER SERVICING LIST

HUNTER ALL MARKS

AP101B-1300-5A1

Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY	
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B	8C		9
ENGINE STARTING AND IGNITION SYSTEMS - 42																							
044205	N/A	Engine Starter Compartment IPN Tank.	Replenish.		N/A	T/R, A/F										X	X					X	
	B403		Flush.			Primary*		X	X	X		X				X	X					X	
	C405		Look for internal corrosion. (Drained)		N/A	Minor			X	X						X	X					X	
	N/A		Examine.		P15	Major					X	X				X	X					X	
044206	A403	IPN pipelines and joints.	Look for signs of leaks.		P35	Primary	X	X	X	X	X	X				X	X					X	
044207	A403	Starter fairing drain pipe.	Ensure clear.		P16	Primary	X	X	X	X	X	X				X	X					X	
044208	A403	Starter exhaust pipe D284941. (Post Mod 1324).	Examine.		P16	Primary	X	X	X	X	X	X				X	X					X	
	N/A		Examine. (Introduced by SI/Hunter/117).		N/A	Each Engine Install ation	Out of Phase (SP 488)							X	X						X		
	N/A		See CRL.		N/A											X	X					X	
044209	N/A	Starter air flexible pipe. (750/1/00893).	See CRL.		N/A											X	X					X	
044210	N/A	Starter fuel flexible pipe. (750/1/00892).	See CRL.		N/A											X	X					X	
044212	N/A	Starter fuel pump/blower unit air inlet filter gauze.	Clean. (Removed).		N/A	Each Starter Exhaust Pipe Change	Out of Phase (SP 86)							X	X							X	

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY				
							P	P*	M	M*	MJ	MJ (2)				6	6A	7	7A	8B		8C	9		
044213	A407	<u>Engine Starter Compartment</u> (Contd) Starter fuel tank filler drain pipe.	Ensure clear.			Primary	X	X	X	X		X		X	X					X					
			Examine and particularly for leaks. (SP 217)			Primary	X	X	X	X		X		X	X						X				
044214	N/A	BTH turbo starter breeches.	Fit cartridges.		N/A	B/F										X	X	X	X						
			Replenish.		N/A	T/R								X	X	X	X								
			Unload.		N/A	A/F								X	X	X	X								
	A406	Remove carbon residue.		P14	Primary	X	X	X	X	X	X					X	X	X	X					X	
044215	A406	BTH turbo starter breech caps.	Clean. (Removed).		P14	Primary	X	X	X	X	X	X				X	X	X	X					X	
			Examine. (Removed).		P14	Primary	X	X	X	X	X	X					X	X	X	X					X
044216	A406	BTH turbo starter breech cap internal threads.	Clean. (Removed).		P14	Primary	X	X	X	X	X	X				X	X	X	X					X	
			Examine. (Removed).		P14	Primary	X	X	X	X	X	X					X	X	X	X					X
			Lubricate. (Removed).		P14	Primary	X	X	X	X	X	X					X	X	X	X					X
																								</	

Continued

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY								
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		8C	9						
ENGINE CONTROL SYSTEM - 43																														
044301	N/A	<u>Cockpit</u> Throttle and HP cock control.	Examine.			Major(2)										X	X													
			Lubricate.					Major(2)									X	X												
			Ensure movement is full and free.					Major(2)								X	X													
044302	N/A	Throttle control.	Examine.		P26	Major					X	X						X	X	X	X									
			Lubricate.		P27	Major						X	X					X	X	X	X									
			Ensure movement is full and free.		P30	Major						X	X					X	X	X	X									
044303	N/A	HP cock gate.	Examine.			Major(2)						X			X	X														
044304	N/A	HP cock control trigger.	Examine and particularly for bowing.			Major(2)						X			X	X														
			Ensure movement is full and free.			Major(2)						X		X	X															
044327	N/A	HP cock control lever assembly.	Examine.		P27	Major					X	X						X	X	X	X									
			Lubricate. (Removed).		P30	Major						X	X					X	X	X	X									
044305	N/A	HP cock control trigger joints and linkage.	Lubricate.			Major(2)						X			X	X														
044306	N/A	Throttle and HP cock joints and linkage.	Examine.			Major(2)						X			X	X														
			Lubricate.			Major(2)						X		X	X															
044307	N/A	Throttle control end fittings.	Examine.		P27	Major					X	X						X	X	X	X									
			Lubricate.		P30	Major						X	X					X	X	X	X									
044308	N/A	LP cock control lever assembly.	Examine.		P27	Major					X	X			X	X	X	X	X	X	X	X								
			Lubricate. (Removed).			Major(2)						X		X	X	X	X	X	X	X	X									
SMS/86/5/26																														

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)									6	6A	7	7A	8B	8C		9
044309	N/A	<u>Cockpit to Engine Compartment</u> Throttle control conduit.	Examine.		P26	Major							X	X			X	X	X	X	X	X	X					
044310	N/A	LP cock control conduit.	Examine.		P26	Major							X	X			X	X	X	X	X	X	X					
044311	N/A	HP cock control conduit.	Examine.		P26	Major							X	X					X	X	X	X						
044312	N/A	Throttle and HP cock control cable and break rod assemblies. C36424.	See CRL.		N/A												X	X										
044313	N/A	<u>Cockpit to Radio Compartment</u> LP and HP cock control cable and break rod assemblies. C36424.	See CRL.		N/A														X	X	X	X						
044314	N/A	Throttle control cable and break rod assembly. (Throttle group). C3642 .	See CRL.		N/A														X	X	X	X						
044315	N/A	<u>Centre Fuselage</u> Throttle and HP cock control Teleflex break unit. C36706.	See CRL.		N/A												X	X					X					
044316	N/A	Throttle and HP cock control and break rod assembly. C36437	See CRL.		N/A												X	X					X					
044317	C407	<u>Engine Compartment</u> Throttle and HP cock control joints and linkage.	Examine.		P25	Minor				X	X	X	X				X	X					X			X		
	C407		Lubricate.		P25	Minor				X	X	X	X				X	X					X			X		
044318	N/A	<u>Centre Fuselage</u> Throttle control Teleflex break unit.	See CRL.		N/A														X	X	X	X						
SMS/ 3.15/2611																			Continued									

Continued

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Trade	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9				
044319	N/A	<u>Centre Fuselage to Engine Compartment</u> Throttle control Teleflex inner core.	Examine.		P26 P30	Major					X	X							X	X	X	X					
			Lubricate. (Removed)		P26 P30	Major					X	X							X	X	X	X					
044320	N/A	HP cock control Teleflex inner core.	Examine.		P26 P30	Major					X	X							X	X	X	X					
			Lubricate. (Removed).		P26 P30	Major					X	X							X	X	X	X					
044321	N/A	LP cock control Teleflex inner core.	Examine.		P26 P30	Major					X	X							X	X	X	X					
			Lubricate. (Removed).		P26 P30	Major					X	X							X	X	X	X					
044322	N/A	<u>Engine Compartment</u> Throttle control Teleflex control box.	Examine.		P29	Major					X	X							X	X	X	X					
			Lubricate.		P29	Major					X	X							X	X	X	X					
044323	N/A	HP cock control Teleflex control box.	Examine.		P29	Major					X	X							X	X	X	X					
			Lubricate.		P29	Major					X	X							X	X	X	X					
044324	N/A	LP cock control Teleflex control box.	Examine.		P29	Major					X	X							X	X	X	X					
			Lubricate.		P29	Major					X	X							X	X	X	X					
044325	C408	Throttle control joints and linkage.	Examine.		P29	Minor			X	X	X	X							X	X	X	X					
			Lubricate.		P29	Minor			X	X	X	X							X	X	X	X				X	
044326	C408	HP cock control joints and linkage.	Examine.		P26	Minor			X	X	X	X							X	X	X	X					
			Lubricate.		P26	Minor			X	X	X	X							X	X	X	X				X	

SMS/86/5/27

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY	
							P	P*	M	M*	MJ (2)					6	6A	7	7A	8B		8C
ANCILLARY DRIVES - 44																						
044401	N/A	<u>Engine Compartment</u> Auxilliary gear box. Type TG5/5.	Replenish.		N/A	A/F										X	X				X	
			See CRL.		N/A								X	X						X		
044402	N/A	Auxiliary gear box. Type TG5/8.	Replenish. (CHECK CONTENTS)		N/A	A/F (TR)											X	X	X	X		
			See CRL.		N/A									X	X	X	X					
044403	N/A	Drive transfer arm. Type GA7/1.	See CRL.		N/A										X	X					X	
044404	N/A	Drive transfer arm. Type GA7/2.	See CRL.		N/A										X	X					X	
044405	N/A	Drive transfer arm oil jet (Pre Mod GB 823) (GB 823 included in Group Mod GB 1947)	Ensure clear. (Introduced by SI/Hunter/14A).		N/A	Each Engine Removal	Out of Phase (SP 481)							X	X						X	
044406	N/A	Auxiliary gear box oil jet. (Pre Mod GB 823). (GB 823 included in group Mod GB 1019).	Ensure clear. (Introduced by SI/Hunter/14A).		N/A	Each Engine Removal	Out of Phase (SP 481)							X	X						X	
044407	N/A	Turret drive transfer arm oil sump.	Replenish.		N/A	A/F									X	X					X	
	A403		Check oil for discolouration.			Primary	X	X	X	X		X			X	X					X	
044408	N/A	Gearbox drive. (Engine to Drive transfer arm. (Type GD 9/37)).	Lubricate.		N/A	Each Engine Removal	Out of Phase (SP 81)							X	X						X	
			See CRL.		N/A									X	X						X	
044409	C403	Gearbox drive. (Engine to Drive transfer arm). Type GD 9/100 (Post Mod GB 1053).	Lubricate. (Removed).			Minor			X	X		X			X	X					X	
	N/A		See CRL.		N/A									X	X					X		
044410	N/A	Gearbox drive. (Engine to Drive transfer arm). Type GD 9/33 (Pre Mod GB 1053).	Lubricate.		N/A	Each Engine Removal	Out of Phase (SP 81)							X	X						X	
			See CRL.		N/A										X	X					X	
SHS/ 10/13/54																						
Continued																						

SMS/ 10/10/10

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C		9		
044411	N/A	Engine Compartment (Contd) Gearbox drive. Type GD 9/44.	Examine. (Removed). (Introduced by SI/Hunter/32B).		N/A	Each Engine Removal	Out of Phase (SP 486)																			
			Lubricate. (Removed). (Introduced by SI/Hunter/32B).		N/A	Each Engine Removal	Out of Phase (SP 486)																			
			See CRL.		N/A																					
044412	N/A	Engine coupling. Type EC 2/3 (Pre Mod GB 1053).	Lubricate.			Major (2)																				
	N/A		See CRL.		N/A																					
044413	N/A	Engine coupling. Type EC 2/5.	Lubricate.		N/A	Each Engine Removal	Out of Phase (SP 486)																			
	N/A		See CRL.		N/A																					
044411	N/A	Balanced Engine Drive and Eng. Coupling. Type GD9/107 (Post MOD GB 2633)	Examine. (Removed)		N/A	Each Engine Removal	Cut of Phase (SP486)																			
044413	N/A		Lubricate.		N/A	Each Engine Removal	Out of Phase (SP486)																			

Sms/86/5/28

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C		9
<u>HYDRAULIC POWER SYSTEM - 50</u>																								
045001	C406	<u>Engine Compartment</u> Hydraulic pump drive shaft.	Examine. (Removed). (Introduced by SI/Hunter/300).		P12	Minor				X	X	X	X			X	X	X	X	X	X	X		
			Lubricate. (Removed). (Introduced by SI/Hunter/300).		P12	Minor				X	X	X	X			X	X	X	X	X	X	X		
045002	C406	Hydraulic pump quill drive.	Examine. (Removed). (Introduced by SI/Hunter/300).		P12	Minor				X	X	X	X			X	X	X	X	X	X	X		
			Lubricate. (Removed). (Introduced by SI/Hunter/300).		P12	Minor				X	X	X	X			X	X	X	X	X	X	X		
<u>AIRCRAFT FUEL SYSTEM - 52</u>																								
045201	N/A	<u>System</u> Complete system.	Look for leaks (Aircraft externally).		N/A	B/F, T/R A/F										X	X	X	X	X	X	X		
	N/A		Replenish.		N/A	T/R, A/F										X	X	X	X	X	X	X		
	N/A		Carry out flow check.		P37	Major						X	X				X	X	X	X	X	X	X	
045202	A404	Tanks.	Carry out water/sediment check.		N/A	Primary	X	X	X	X	X					X	X	X	X	X	X	X		
			Servicing deleted by AL 4.																					
045203	N/A	Fuel tank transfer and engine feed pipelines.	Test. (SP 212).		P36	Major					X	X				X	X	X	X	X	X	X		
SMS/26/07/28A																		Continued						

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								QTY						
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		8C	9				
<u>AIRCRAFT FUEL SYSTEM - 52 (Contd)</u>																												
045204	N/A	<u>Mainplanes</u> Fuel pipes.	Examine.		P22	Major												X	X	X	X	X	X	X				
045205	C409	<u>Mainwheels Compartment</u> Fuel pipes.	Examine as far as possible.		P23	Minor				X	X	X	X					X	X	X	X	X	X	X				
045207	N/A	<u>Centre Fuselage</u> Fuel pipes.	Examine as far as possible.		P22	Major						X	X					X	X	X	X	X	X	X				
045208	N/A	King couplings.	Examine.		P22	Major						X	X					X	X	X	X	X	X	X				
045209	A403	Recuperators (2 off).	Carry out water/sediment check.		N/A	Primary	X	X	X	X	X							X	X					X				
045215	D403	Fuel supply pipe at Frame 32. (C 188051/13).	Look for signs of chafing. (Cleats removed). (Introduced by SI/Hunter/134).		P20	Minor*				X	X	X								X	X	X	X					
045210	N/A	Recuperator bags. (2 off).	Test. (Introduced by SI/Hunter/29).		N/A	T/R, A/F												X	X					X				
045211	N/A	Fuel flow proportioner. Type FTP 2/2.	Replace. (Recondition).		P60 P91	Major (2)						X						X	X	X	X	X	X	X				
045212	C404	Vapour release valves. (Pre Mod 1263). (2 off).	Examine. (SP 479). (Introduced by SI/Hunter/85A).		P18	Minor			X	X	X	X						X	X	X	X	X	X	X				
045213	N/A	Fuel tank vent pipes.	Examine and particularly for leaks.		P1	Major						X	X					X	X	X	X	X	X	X				
SHS/36/1/74																												
Continued overleaf																												

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY					
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		8C	9			
045214	N/A	<u>Centre Fuselage</u> (Contd) Fuel pressure switch pipe. C209866/1.	Ensure aligned correctly.		N/A	After each pipe recon- nection											X	X									
	N/A		See CRL.		N/A												X	X							X		
045206	C410	Fuel transfer pipes at Frames 35 and 36. (Port and starboard).	Look for signs of chafing. (SP 489). (Introduced by SI/Hunter/113).			Minor				X	X		X				X	X							X		
<u>FUEL PRESSURIZATION SYSTEM - 53</u>																											
045301	N/A	<u>System</u> Fuel system air supply pipelines.	Test. (SP 213).		P36	Major						X	X				X	X	X	X	X	X	X				
045302	B403	<u>Centre Fuselage</u> Hymatic reducing valve. Type 48/B.	Test. (SP 482). (Introduced by SI/Hunter/55B).			Primary*			X	X	X		X				X	X							X		
	N/A		See CRL.		N/A												X	X							X		
SMS/																											
Continued																											

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)							6	6A	7	7A	8B	8C	9			
045303	B402	<u>Centre Fuselage</u> (Contd) Hymatic reducing valve. Type 48/12. (Qty 2).	Test. (SP 478). (Introduced by SI/Hunter/92A).		P39	Primary*		X	X	X	X	X					X	X	X	X	X	X	X					
	N/A		Replace. (Recondition).		P9 P31	Major					X	X					X	X	X	X	X	X	X					
045304	C401 C409	Palmer air filter.	Replace. (Bay Service).		P7 P23	Minor			X	X	X	X					X	X	X	X	X	X	X			X		
045305	N/A	SPE Non-return valves. (Pre Mod 1184).	Servicing deleted by AL 7.																									
045312	N/A	Air transfer pipe. (26FX/8387).	Examine. (Introduced by SI/Hunter/104).		N/A	Each Engine Removal	Out of Phase (SP 81)												X	X	X							
045306	N/A	SPE Non-return valve. (Between engine and Palmer air filter).	Check integrity. (SP 485).		N/A	Each Engine Removal	Out of Phase												X	X	X	X	X	X	X			
045311	B404	Fuel system pressurization pipe. (26FX/9403).	Examine and particularly attachment flange for security.			Primary*		X	X	X		X					X	X				X						
045307	N/A	<u>Mainplanes</u> Air pipes.	Examine.		P22	Major					X	X					X	X	X	X	X	X	X					
045308	C409	<u>Mainwheel Compartments</u> Air pipes.	Examine as far as possible.		P23	Minor			X	X	X	X					X	X	X	X	X	X	X					
045309	B401	Wing tank relief valves. (2 off).	Test. (SP 480). (Introduced by SI/Hunter/91A).		P36	Primary*		X	X	X	X	X					X	X	X	X	X	X	X					
SMS/SL/5/30																	Continued overleaf											

SMS/SL/5/30

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																								
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C		9																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							
<u>FUEL PRESSURIZATION SYSTEM - 53 (Contd)</u>																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																															
045310	N/A	<u>Port Mainwheel Compartment</u>	Check for wear using GO/NO GO Gauge. (Introduced by SI/Misc/101).		P17	Major																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																									
		Pressure fuelling connection unit.					X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							

Chapter 4 PROPULSION
Sheet 11
AL 16

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

[illegible]

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY							
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A		8B	8C	9				
AIRCRAFT GENERAL - 01																												
060101	C506	<u>Aircraft</u> Aircraft.	Harmonize. (Mk 7 ac SP 249). (Mk 6, 6A and 9 ac SP 250).		F13	Minor				X	X	X	X			X	X	X							X			
COMPASS INSTALLATION - 69																												
066901	N/A	<u>G4 System</u> Complete system.	Test. (SP 247).		F18	Major						X	X			X	X	X							X			
066902	C503	<u>Cockpit</u> Amplifier tray anti-vibration mountings.	Examine.		F1	Minor			X	X	X					X	X	X			X	X						
	N/A		Examine. (Amplifier removed).		F32 F46	Major (2)						X				X	X	X			X	X						
066904	N/A	Master unit mountings.	Examine. (Master unit removed).		F33 F47	Major (2)						X				X	X	X			X	X						
066905	N/A	Cables and connectors.	Examine as far as possible.		F35	Major (2)						X				X	X	X			X	X						
SMS/SL/5/31																			Continued overleaf									

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C	9			
COMPASS INSTALLATION - 69 (Contd)																										
066906	D501	E2B Compass.	Pivot friction test. (SP 246).		F1	Minor *					X	X	X					x	x	X		X	X			
						Prior to compass swing									(Out of Phase)					X	X	X		X	X	
066907	N/A	<u>Tailplane</u> Detector unit. (Post Mod Inst B134).	Examine. (Removed).		F1 F4	Major						X	X					x	x	X			X	x		
066907	N/A	<u>Centre Fuselage</u> Cables and connectors.	Examine as far as possible.		F42	Major(2)								X				X		X			x	x		
066908	N/A	<u>Rear Fuselage</u> Cables and connectors.	Examine as far as possible.		F43	Major (2)								X				x	x	X			X	x		
Mk 5 GUNSIGHT INSTALLATION - 70 (IF FITTED)																										
067001		<u>General</u> Complete system.	Check voltage input.			Minor					x	x		x				x	x							
	N/A		Test (ASM)			Major (2)								x				x	x							
SMS/89/6/9A															Continued											

Sms/89/6/9A

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY	
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B	8C		9
MK 5	GUNSIGHT INSTALLATION - 70 (IF FITTED)(Contd)																							
067002	A501	<u>Cockpit</u> Control unit Type RA, silica gel.	Examine.			Primary	X	X	X	X		X			X	X								
067003	A501	Control unit Type RM, silica gel.	Examine.			Primary	X	X	X	X		X			X	X								
067004	N/A	Sighting head Mk 5	Examine.		N/A	B/F									X	X								
	N/A		Operate GGSR		N/A	B/F									X	X								
	C502 C503		Replace. (Bay Service).			Minor			X	X		X			X	X								
067005	A501	Sighting head silica gel.	Examine.			Primary	X	X	X	X		X			X	X								
067006	A501	Sunscreen.	Examine.			Primary	X	X	X	X		X			X	X								
067007	C508	Sunscreen mechanism and masking lever.	Lubricate			Minor			X	X		X			X	X								
067008	N/A	Control unit Type AL Mk 1	Replace. (Bay Service).			Major (2)						X			X	X								
067009	C507	Retractable mounting (Mk 2A Type 7). Emergency release.	Operate.			Minor			X	X		X			X	X								

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								QTY
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C	
MK 8 GUNSIGHT INSTALLATION - 71 (IF FITTED) (Contd)																							
067103	A502	Cockpit Sighting head(s) silica gel.	Examine.		F12	Primary	X	X	X	X	X	X							X				
067104	A502	Control unit(s) Type RA silica gel.	Examine.		F12	Primary	X	X	X	X	X	X						X					
067105	A502	Control unit(s) Type RM silica gel.	Examine.		F12	Primary	X	X	X	X	X	X						X					
067106	N/A	Control unit Type AL Mk 1. (2 off).	Replace (Bay Service).		F2 F10	Major					X	X						X					
067107	B501 B502	Control unit(s) Type RA Mk 2.	Replace. (Bay Service).		F2 F10	Primary Star		X	X	X	X	X						X					
067108	N/A	Anti-topple unit anti- vibration mounting.	Examine. (Anti-topple unit removed).		F34 F45	Major (2)						X						X			X		
067109	N/A	Cables and connectors.	Examine as far as possible.		F35	Major (2)						X						X			X		
067110	N/A	Radar manual ranging control unit anti- vibration mountings.	Examine. (Radar manual ranging unit removed).		F34 F48	Major (2)						X						X			X		
067111	N/A	Relay amplifier anti- vibration mountings.	Examine. (Relay amplifier removed).		F34 F48	Major (2)						X						X			X		
SMS/26/8/86																							
Continued overleaf																							

Sch/ Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	Servicing						Mark						CTY						
								P*	M	M*	MJ	MJ (2)					7	7A	8B		8C					
<u>AIR DATA SYSTEM - 73</u>																										
067301	C510	<u>General</u> Complete system.	Test. (SP 254)		F15	Minor				X	X	X	X						X	X						
067302	N/A	<u>Cockpit</u> Height and VSI displays.	Check zero setting.		N/A	A/F													X	X						
067303	N/A	Cables and connectors.	Examine as far as possible.		F37	Major (2)							X						X	X						
067304	N/A	<u>Nose Cone</u> Cables and connectors.	Examine as far as possible.		F39	Major (2)							X						X	X						
067305	N/A	<u>Front Fuselage</u> Static transducer and mounting.	Examine as far as possible.		F40	Major (2)							X						X	X						
067306	N/A	Cables and connectors.	Examine as far as possible.		F40	Major (2)							X						X	X						
<u>NAVIGATION DISPLAY SYSTEM - 74</u>																										
067401	C511	<u>General</u> Complete system.	Test. (SP 252, 253)		F14	Minor				X	X	X	X						X	X						
SWS/86/8/86A																					Continued					

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)								7	7A	8B	8C				
NAVIGATION DISPLAY SYSTEM - 74 (Contd)																											
067402	N/A	<u>Cockpit</u> Navigational display amplifier and mounting.	Examine as far as possible.		F36	Major (2)							X							X	X						
067403	N/A	MRG distribution box and mounting.	Examine as far as possible.		F41	Major (2)							X							X	X						
067404	N/A	Cables and connectors	Examine as far as possible.		F41	Major (2)							X							X	X						
067405	N/A	<u>Gun Compartment</u> MRG Protection unit and mounting.	Examine as far as possible.		F41	Major (2)							X							X	X						
067406	N/A	Cables and connectors.	Examine as far as possible.		F41	Major (2)							X							X	X						
067407	N/A	<u>Centre Fuselage</u> Cables and connectors.	Examine as far as possible.		F42	Major (2)							X							X	X						
067408	N/A	<u>Rear Fuselage</u> Cables and connectors.	Examine as far as possible.		F43	Major (2)							X							X	X						
067409	N/A	<u>Tailplane (Port)</u> Detector unit.	Examine. (Removed).		F44 F52	Major (2)							X							X	X						
SMS/		6	Continued overleaf																								

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	MM	MJ	MJ (2)								7	7A	8B	8C				
<u>MASTER REFERENCE GYRO - 87</u>																											
068701	B503	<u>Gun Compartment</u> Master reference gyro.	Check starting cycle.		N/A	Primary *		X																			
	C509		Test. (SP 251).		F14	Minor				X	X	X	X														
068703	N/A	Master reference gyro mounting.	Examine. (MRG removed).		F41 F52	Major (2)							X														
068702	N/A	<u>Radio and Electrical Equipment Bay</u> Master reference gyro	Deleted by AL 34.																								
	N/A	ON/OFF switch (Mod 1264).																									
<u>AUTOSTABILIZER MK 2 - 88</u>																											
068801	N/A	<u>Fin</u> Trim actuator unit.	Replace. (Bay Service)		F7 F8	Major						X	X				X	X	X	X	X	X	X				
068802	N/A	Servo unit mounting cradle.	Examine. (Removed).		F5 F6	Major						X	X				X	X	X	X	X	X	X				
SMS/		CA																									

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark									
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C		
AIRCRAFT GENERAL - 01																								
070101	N/A	<u>Cockpit</u> Cables and connectors.	Examine as far as possible.		R30	Major (2)							X					X	X	X	X		X	
070102	N/A	<u>Nose Compartment</u> Cables and connectors.	Examine as far as possible.		R31	Major (2)							X					X	X	X	X		X	
070103	N/A	<u>Nose Wheel Bay</u> Cables and connectors.	Examine as far as possible.		R32	Major (2)							X					X	X	X	X		X	
070104	N/A	<u>Radio Compartment</u> Cables and connectors.	Examine as far as possible.		R33	Major (2)							X					X	X	X	X		X	
Continued overleaf																								

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1
(1st Edition)

Sched Ident No	Card No	Item	Operation	Code	Majdr Card No.	Frequency	Servicing										Mark												
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B			9		CTY			
		<u>IFF/SSR INSTALLATION - 63</u> <u>(IF FITTED)</u>																											
076301	N/A	<u>Upper Fuselage</u> Aerial Type 100A or 100B.	Visually ensure intact.		N/A	A/F												X	X	X			X						
	N/A		Examine.		R9	Major					X	X						X	X	X			X						
076302	N/A	<u>Lower Fuselage</u> Aerial Type 100A or 100B.	Visually ensure intact.		N/A	A/F												X	X	X			X						
	N/A		Examine.		R9	Major					X	X						X	X	X			X						
076303	A603	<u>General</u> Complete installation.	Test. (Abridged). (SP 259).		R16	Primary	X	X										X	X	X			X						
	C602		Full test. (SP 260).		R15	Minor			X	X	X	X						X	X	X			X						
076304	N/A	<u>Radio Compartment</u> TR 16928.	Pressurize.		N/A	14 days	Out of Phase															X	X	X			X		
SMS/		7																											
																				Continued overleaf									

Continued overleaf

Sched Ident No	Card No	Item	Operation	Code	Major Card No	Frequency	Servicing										Mark					CTY
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C	9	
REBECCA MK 8 INSTALLATION-75 (IF FITTED)																						
077501	N/A	<u>Cockpit</u>	Deleted by AL34																			
		Range and Heading meter.																				
077502	N/A	<u>Radio Compartment</u>	Deleted by AL34																			
		TR 8193																				
077503	B601	TR Desiccator.	Deleted by AL34																			
077504	N/A	Switch unit Type 514.	Deleted by AL34																			
077505	N/A	<u>Port Air Intake</u>	Deleted by AL34																			
	B605 B606	Aerial.																				
077506	N/A	<u>Starboard Air Intake</u>	Deleted by AL34																			
	B607 B608	Aerial.																				
077507	N/A	<u>Engine Access Doors</u>	Deleted by AL34																			
	C601	Tx Aerial.																				
077508	N/A	Omni Aerial.	Deleted by AL34																			
	C601																					
077509	A602	Connectors.	Deleted by AL 34																			
SMS/		7A																			Continued	

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1
(1st Edition)

Sched Ident No.	Card No.	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY
							P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C	
RADAR RANGING INSTALLATION - 77 (IF FITTED)																					
077701	A601	<u>Nose Compartment</u> Radar head Type 2A.	Ensure secure.		N/A	Primary	X	X	X	X							X				
077702		Radar head desiccator.	Servicing deleted by AL 1.																		
077703	A601	Radar head anti-vibration mountings.	Examine. (SP 506). (Introduced by SI/Radar/ Airborne/15).		R5	Primary	X	X	X	X	X	X					X				
077704	A601	<u>Nose Wheel Compartment</u> Ranging unit.	Ensure secure.		N/A	Primary	X	X	X	X							X				
077705		Ranging unit desiccator.	Servicing deleted by AL 1.																		
077706	A601	Ranging unit anti-vibration mountings.	Examine. (SP 506). (Introduced by SI/Radio/ Airborne/15).		R5	Primary	X	X	X	X	X	X					X				
TACAN INSTALLATION - 79																					
077901	C603	<u>Nose Wheel Compartment</u> Air filter Type 9753.	Examine.		N/A	Minor			X	X							X	X			
			Replace. (Bay Service).		R4 R11	Major				X	X						X	X			
SMS/30/8/90																					
Continued overleaf																					

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P*	M	M*	MJ	MJ (2)				7	7A	8B	9C			CTY
TACAN INSTALLATION - 79 (Contd)																					
077902	N/A	<u>Forward Fuselage</u> Aerial Type 100A.	Visually ensure intact.	N/A	A/F										X	X	X	X			
	N/A		Examine.	R9	Major					X	X				X	X	X	X			
077903	B603	TR Mounting tray. Type 9274 (10AJ 6241595)	Examine. (Removed). (Introduced by SI/Hunter/115A).	R4 R11	Primary* and after every heavy landing.		X	X	X	X	X				X			X			

SMS/ 18/90A

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C		9			
<u>AIRCRAFT GENERAL - 01</u>																											
		<u>Cockpit</u>																									
080101	N/A	Cables and connectors.	Examine as far as possible.		C30	Major (2)							X					X	X	X	X	X					
		<u>Radio Compartment</u>																									
080102	N/A	Cables and connectors.	Examine as far as possible.		C31	Major (2)							X					X	X	X	X	X					
		<u>Centre Fuselage</u>																									
080103	N/A	Cables and connectors.	Examine as far as possible.		C32	Major (2)							X					X	X	X	X	X					
<u>VHF (ARI 18064) - 78</u>																											
		<u>Port and Starboard Mainplanes</u>																									
087801	N/A	Cables and connectors.	Examine as far as possible.		C33 C34	Major (2)							X					X	X	X	X	X					
SMS/86/8/91																											
Continued overleaf																											

Chapter 8 AIR COMMS
Sheet 2
AL 29

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C	
<u>ILS INSTALLATION - 80</u>																							
		<u>Engine Starter Access Door</u>																					
088001	N/A	Marker aerial Type 237.	Examine.		C11	Major					X	X						X	X	X			
088002	N/A	<u>Starboard Wing Tip</u> Glidepath aerial. Type 238.	Examine.		C9	Major					X	X						X	X	X			
088003	N/A	<u>Port Wing Tip</u> Localiser aerial. Type 239.	Examine.		C9	Major					X	X						X	X	X			
088004	N/A	<u>Nose Compartment</u> Voltage regulator T60.	Replace. (Bay Service).		C7 C12	Major					X	X						X	X	X			
088005	N/A	<u>Engine Starter Access Door</u> Aerial cable	Ensure sufficient length for free movement of door.		C11	Major					X							X	X	X			
SMS/ 40/8/92																		Continued overleaf					

Sche Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	IDENTIFYING										SERIAL				CTY		
							P	P*	M	M*	MMJ	(2)							7	7A		8B	8C
TELEBRIEF INSTALLATION-82																							
088201	A703	<u>General</u> Complete installation.	Test. (SP 272)		C22	Primary	X	X	X	X	X	X						X	X	X	X	✓	
	N/A		Test. (SP 272)		N/A	Each Engine Removal	(Out of Phase- SP 81)											X	X	X	X	✓	
088202	N/A	<u>Rear Fuselage</u> Plug Type 3570.	Look for obvious damage.		N/A	A/F												X	X	X	X		
088203	N/A	Cables and connectors.	Examine as far as possible.		C35	Major (2)					X							X	X	X	X		
10/18/92A																		Continued					

18/92A

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing										Mark										CTY		
							P	P*	M	M*	MJ	MJ (2)								6	6A	7	7A	8B	8C	9			
RADIO COMPASS INSTALLATION - 83																													
088301	C702	<u>General</u> Complete Installation.	Test. (SP 273).		C21	Minor				X	X	X	X																
088302	N/A	<u>Cockpit</u> Drive gears.	Examine.			Major (2)							X																
			Lubricate.				Major (2)						X																
088303	N/A	Flexible drive cable.	Examine.			Major (2)						X																	
			Lubricate.				Major (2)					X																	
088306	N/A	Bearing Indicator (If fitted).	Replace (Bay Service).		C36 C37	Major (2)							X																
088304	N/A	<u>Lower Fuselage</u> Loop Aerial Type 8280.	Examine.		C11	Major						X	X																
088305	N/A	Sense aerial rod.	Visually ensure intact.		N/A	A/F																							
	N/A		Examine.		C11	Major						X	X																
SMS/ 18/5/ 35																													
Continued overleaf																													

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)						6	6A	7	7A	8B	8C		9
<u>UHF INSTALLATION - 84</u> <u>(IF FITTED)</u>																									
		<u>Radio Compartment</u>																							
088401	N/A	TR5/ARC - 52.	Pressurize.		N/A	14 days																			X
		<u>Upper Fuselage</u>																							
088402	N/A	Wideband aerial.	Visually ensure intact.		N/A	A/F																			
	A702		Examine and particularly the protective finish. (SP 511). (Introduced by SI/Rad/Air/64B).		C8	Primary	X	X	X	X	X	X													
<u>STANDBY UHF INSTALLATION - 85</u>																									
		<u>General</u>																							
088501	A701	Complete installation.	Test. (SP 275).		C20	Primary	X	X	X	X	X	X													
		<u>Starboard Wing Outer</u>																							
088502	N/A	Aerial rod.	Visually ensure intact.		N/A	A/F																			
	C701		Examine.		C9	Minor			X	X	X	X													
SMS/ S. J. / 18 A																									

Continued

MASTER SERVICING LIST
HUNTER ALL MARKS

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY		
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C			
<u>STANDBY UHF INSTALLATION - 85 (Contd)</u>																									
		<u>Starboard Wing Outer (Contd)</u>																							
088503	C701	Aerial Base.	Examine.		C9	Minor				X	X	X	X					X	X	X	X				
088504	C701	<u>Radio Compartment</u> Transmitter - Receiver.	Examine.		C4	Minor				X	X	X	X					X	X	X	X				
088505	C701	Supply dropping resistor.	Examine.		C4	Minor				X	X	X	X					X	X	X	X				
088506	C705	VHF Aerial Grommet.	Examine.		C9	Minor				X	X	X	X					X	X	X	X				
<u>PTR 175 INSTALLATION - 86 (IF FITTED)</u>																									
		<u>Radio Compartment</u>																							
088601	N/A	PTR 175 TR unit.	Pressurize.		N/A	14 days				Out of Phase								X	X	X	X				X
SMS/ 8																									
Continued overleaf																									

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark										CTY	
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C	9				
<u>PHOTOGRAPHIC INSTALLATION - 94</u> (IF FITTED)																									
099401	N/A	<u>Cockpit</u> GGS recorder.	Fit.		N/A	B/F											X	X	X				X		
			Load/Operate.		N/A	B/F, T/R								X	X	X						X			
			Operate/Unload.		N/A	T/R, A/F								X	X	X						X			
099402	N/A	GGS recorder cable.	Stow.		N/A	B/F, T/R											X	X	X				X		
099403	N/A	<u>Front Fuselage</u> G90 camera.	Load/Operate.		N/A	B/F, T/R											X	X	X	X	X	X	X		
			Operate/Unload.		N/A	T/R, A/F								X	X	X	X	X	X	X	X				
099404	A024	G90 camera mounting.	Examine. (Airframe).		A102	Primary	X	X	X	X	X	X					X	X	X	X	X	X	X		
099405	N/A	G90 optical flat.	Look for obvious damage.		N/A	B/F, T/R A/F											X	X	X	X	X	X	X		
			Clean.		N/A	B/F, T/R								X	X	X	X	X	X	X					
099406	N/A	<u>Nose Cone and Front Fuselage</u> F95 camera. (Post COM/MOD 0160 STC only).	Examine.		N/A	B/F, T/R A/F																	X		
			Load/operate.		N/A	B/F, T/R																	X		
			Operate/Unload.		N/A	T/R, A/F																	X		
099407	N/A	<u>Nose Cone</u> F95 optical flat. (Post COM/MOD 0160 STC only).	Look for obvious damage.		N/A	B/F, T/R, A/F																	X		
			Clean.		N/A	B/F, T/R																	X		
SMS/86/3/36																									

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
							P	P*	M	M*	MJ	MJ (2)					6	6A	7	7A	8B		8C	9																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		

AP101E-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark								CTY				
							P	P*	M	M*	MJ	MJ (2)						7	7A	8B	8C					
		<u>AIRCRAFT GENERAL - 01</u>																								
110101	N/A	<u>Front Fuselage</u> Radio/Gun compartment.	Restore surface finish.		T12	Major (2)						X						X	X	X	X					
110102	N/A	<u>Centre Fuselage</u> Internal structure..	Restore surface finish.		T12	Major (2)						X						X	X	X	X					
110103	N/A	Front fuel tank compartments.	Restore surface finish.		T10	Major (2)						X						X	X	X	X					
110104	N/A	Centre fuel tank compartments.	Restore surface finish.		T10	Major (2)						X						X	X	X	X					
110105	N/A	<u>Rear Fuselage</u> Internal structure.	Restore surface finish.		T12	Major (2)						X						X	X	X	X					
110106	N/A	Rear fuel tank compartments.	Restore surface finish.		T11	Major (2)						X						X	X	X	X					
110107	N/A	<u>Tailplane Assembly</u> Elevator recess.	Restore surface finish.		T13	Major (2)						X						X	X	X	X					
110108	N/A	<u>Fin</u> Rudder recess.	Restore surface finish.		T13	Major (2)						X						X	X	X	X					
110109	N/A	<u>Tail Unit</u> Tailplane recess.	Restore surface finish.		T13	Major (2)						X						X	X	X	X					
																		Continued overleaf								

SMS/86/8/96

Sched Ident No.	Card No.	Item	Operation	Code	Major Card No.	Frequency	P	P*	M	M*	MJ	MJ (2)					7	7A	8B	8C				CTY
110110	N/A	<u>Port and Starboard Mainplanes</u> Aileron shroud.	Restore surface finish.		T14 T15	Major (2)						X					X	X	X	X				
110111	N/A	Flap shroud.	Restore surface finish.		T14 T15	Major (2)						X					X	X	X	X				
110112	N/A	Fuel tank compartments.	Restore surface finish.		T14 T15	Major (2)						X					X	X	X	X				
110113	N/A	<u>Port and Starboard Undercarriage Compartments</u> Undercarriage compartments	Restore surface finish.		T16	Major (2)						X					X	X	X	X				
110113	N/A	<u>Nose Undercarriage Compartment</u> Undercarriage compartment.	Restore surface finish.		T16	Major (2)						X					X	X	X	X				

SMS/86/8/96A

SIN 130815 Deleted by AL34.

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing							Mark							CTY					
							P	P*	M	M*	MJ	MJ (2)			6	6A	7	7A	8B	8C		9				
EMERGENCY EQUIPMENT - 08																										
130801	N/A	<u>Parachute and Liferaft Assembly</u> Parachute and liferaft pack(s).	Examine. (Weapons).		N/A	A/F											X	X	X	X	X	X	X			
			Look for contamination. (Weapons).		N/A	A/F												X	X	X	X	X	X	X		
			Ensure fitted correctly. (Weapons).		N/A	A/F												X	X	X	X	X	X	X		
130802	N/A	Parachute assembly.	See CRL.		N/A												X	X	X	X	X	X	X			
130803	N/A	Personal survival pack(s). Type R.	Ensure lowering line protruding does not exceed 6 inches. (Weapons).		N/A	B/F,T/R											X	X	X	X	X	X	X			
			See CRL.		N/A													X	X	X	X	X	X	X		
130804	N/A	Slide disconnect safety tie.	Ensure intact. (Weapons).		N/A	A/F											X	X	X	X	X	X	X			
130805	N/A	Rip cord safety tie.	Ensure intact. (Weapons).		N/A	A/F											X	X					X			
130815	N/A	Rip pin safety tie. (Pre Mod PA 443).	Examine. (Introduced by SI/Safety Equipment/24C).		N/A	B/F													X	X	X	X				
130806	N/A	Parachute withdrawal line.	Ensure connected to link line. (Weapons).		N/A	B/F											X	X	X	X	X	X	X			
130816	N/A	Parachute withdrawal line alignment ring release pins. (Post Mod PA 443).	Ensure fitted correctly. (Weapons).		N/A	B/F											X	X	X	X	X	X	X			
SMS/82/184/87														Continued overleaf												

Sched Ident No	Card No	Item	Operation	Code	Trade	Frequency	Servicing										Mark					CTY
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	
CENTRE FUSELAGE - 03																						
150301	C951	Port Mainplane Nose locating spigot.	Carry out NDT Technique/ Hunter/ULT/3. (Introduced by SI/HUNT/96A).		X6	Minor			X	X	X	X						X	X	X	X	
			Carry out NDT Technique/ CSDE/HUNTER/MAG/6. (Mainplane removed).			Every Mainplane Removal												X	X	X	X	
150302	C951	Starboard Mainplane Nose locating spigot.	Carry out NDT Technique/ Hunter/ULT/3. (Introduced by SI/HUNT/96A).		X6	Minor			X	X	X	X						X	X	X	X	
			Carry out NDT Technique/ CSDE/HUNTER/MAG/6. (Mainplane removed).			Every Mainplane Removal												X	X	X	X	
150302	A953	FRAMES 18A AND 18B (PRE REPAIR CL9433 ONLY)	CARRY OUT NDT TECHNIQUE HUNT /EDD/13 (SP 530)		X8	PRIMARY	X	X	X	X	X	X						X	X	X	X	
TAIL UNIT - 05																						
150501	B953	Fin Rear attachment fitting (Port and Starboard).	Carry out NDT Technique Hunter/MAG/2A. (Introduced by SI/HUNT/135).		N/A	Primary*			X	X	X							X	X	X	X	
	B954		Carry out NDT Technique Hunter/MAG/3. (Introduced by SI/HUNT/135).		N/A	Primary*			X	X	X							X	X	X	X	
	N/A		Carry out NDT Technique Hunter/MAG/1. (SP 526) (Introduced by SI/HUNT/135).		X7	Major						X	X					X	X	X	X	
																			Continued overleaf			
SM5/89/6/10																						

SMS/89/6/10

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	P	P*	M	M*	MJ	MJ 2							7	7A	8H	8C						CTY
MAINPLANES - 06																												
150601	A952	<u>Port Undercarriage Compartment</u> Undercarriage pivot group.	Carry out NDT/Technique/ Hunter/EDDY/4A. (Introduced by SI/Hunt/124).		X4	Primary		X	X	X		X	X	X					X	X	X	X						
150602	A952	<u>Starboard Undercarriage Compartment</u> Undercarriage pivot group.	Carry out NDT/Technique/ Hunter/EDDY/4A. (Introduced by SI/Hunt/124).		X4	Primary		X	X	X		X	X	X					X	X	X	X						
SMS/89/6/10A																												

Continued

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No	Card No	Item	Operation	Code	Major Card No.	Frequency	Servicing								Mark								CTY			
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C				
MAIN UNDERCARRIAGE - 28																										
152801	N/A	<u>Port Assembly</u> Main fitting. (Pre Mod/Hunter/1402).	Carry out NDT technique Hunter/ULT/5A. (Introduced by SI/Hunter/11).		N/A	3 Months or 150 Landings (which- ever is sooner).													X	X	X	X				
152803	N/A	Main fitting. (Pre Mod/Hunter/1402).	Carry out NDT technique Hunter/EDD/6A. (Introduced by SI/Hunter/122).		N/A	3 Months or 150 Landings (which- ever is sooner).													X	X	X	X				
152805	N/A	Main fitting. (Post Mod/Hunter/1402).	Carry out NDT technique Hunter/ULT/5A) (Introduced by SI/Hunter/111).		X2	Major					X	X							X	X	X	X				
152807	N/A	Main fitting. (Post Mod/Hunter/1402).	Carry out NDT technique Hunter/EDD/6A (Introduced by SI/Hunter/122).		X2	Major					X	X							X	X	X	X				
152809	N/A	Main fitting. (Pre Mod/Hunter/1402).	Carry out NDT technique Hunter/EDD/9. (Introduced by SI/Hunter/127).		N/A	3 Months or 150 Landings (which- ever is sooner).													X	X	X	X				
152811	N/A	Main fitting. (Post Mod/Hunter/1402).	Carry out NDT technique Hunter/EDD/9. (Introduced by SI/Hunter/127).		X2	Major					X	X							X	X	X	X				
SMS/86/8/99																		Continued overleaf								

MASTER SERVICING LIST
HUNTER ALL MARKS

AP101B-1300-5A1
Section 1

Sched Ident No.	Card No.	Item	Operation	C O D E	Major Card No.	Frequency	Servicing								Mark								CTY		
							P	P*	M	M*	MJ	MJ (2)							7	7A	8B	8C		9	
<u>NOSE UNDERCARRIAGE - 30</u>																									
153001	N/A	<u>Main Assembly</u> Leg. (pre Mod/Hunter/1401).	Carry out NDT technique Hunter/ULT/6A. (Introduced by SI/Hunter/116).		N/A	3 Months or 150 Landings (which- ever is sooner).												X	X	X	X	X			
153002	N/A	Leg. (Post Mod/Hunter/1401).	Carry out NDT technique/Hunter/ULT/6A. (Introduced by SI/Hunter/116).		X1	Major					X	X						X	X	X	X	X			
<u>UNDERCARRIAGE OPERATING SYSTEM - 31</u>																									
153103	A951	<u>Port Undercarriage Compartment</u> Main undercarriage operating jack. (Post Mod 1348, Pre Mod 1432).	Carry out NDT technique/Hunter/ULT/10. (Introduced by SI/Hunter/131A).		X5	Primary	X	X	X	X	X	X						X	X	X	X	X			
153104	A951	<u>Starboard Undercarriage Compartment</u> Main undercarriage operating jack. (Post Mod 1348, Pre Mod 1432).	Carry out NDT technique/Hunter/ULT/10. (Introduced by SI/Hunter/131A).		X5	Primary	X	X	X	X	X	X						X	X	X	X	X			

SM 92/1365 (3)

Continued overleaf

Sched Ident No.	Card No.	Item	Operation	C O D E	Major Card No.	Frequency	Servicing							Mark										
							P	P*	M	M*	MJ	MJ (2)				7	7A	8B	8C	q				CTY
► BASIC ENGINE - 38																								
153801	N/A	<u>Intake Guide Vanes</u> Air intake guide vane master operating lever. (Pre Mod Avon 5540).	Examine (Removed). (CSDE/UNIVERSAL/PFD8). (Introduced by SI AVON 74F).			Each engine removal.										X	X	X	X	X				

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

