

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Pre Mod. 378)

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Score	Plate No.
		1 2 3 4 5				
	C.205773	INSTRUMENT PANELS, ASSEMBLY	—	—	—	
		(Pre Mod. 378)				
31	6A/4695406	Accelerator, Mk. 2	1	—	A.	
	F.215196	Angle, support, for accelerometer	1	L.72		
		(Make from 30B/9611215)				
	8428 A.188487	Bracket, mounting, stand-by compass	1	DTD.610	C.	
	8235 A.212857	Bracket, for R.P. selector panel	1	L.72	MR/C	
	12214 A.217775	Bracket, mounting for fuel level warning lights	1	—	C.	
		(Mod. 496)				
	6354 F.208961	Clip, half, for accelerometer	2	L.72	C.	FC.1
31	6B/4343605	Compass, stand-by, type E2A	1	—	A.	
	5L/9951273	Lamp, filament 28V. 3.5W (Mod. 496)	2	—	B.	
31	5CX/4330112	Lamp, warning, type "B" (Mod. 496)	2	—	A.	
	D.187863	MOUNTING PANEL, ASSEMBLY	—	—		
	5384 DTD.487/13E	Bolt, for "Lord" mountings	4	DTD.487	C.	
	5372 A.203163	Bracket, top centre panel mounting	2	—	C.	FC.1
	5373 A.203162	Bracket, bottom centre panel mounting	2	—	C.	FC.1
31	F.203235	Clip, for cross tube	2	S.510	—	FC.1
	1538 Std.1285/388	Connector, earthing	4	—	C.	4
	1539 Std.1285/300	Connector, earthing	4	—	C.	4
31	27H/4605580	Mounting	4	—	C.	
31	27H/4605586	Mounting, "Lord"	4	—	C.	
	1542 F.187614	Plate, support	2	DTD.610	C.	FC.1
	1543 F.187864	Strut, support, port	1	T.4	C.	FC.1
	3867 F.195815	Strut, support, starboard (Pre Mod. 654)	1	T.4	C.	FC.1
	F.230565	Strut, support, starboard (Mod. 654)	1	—		
	12474 A.203240	Tube, cross	1	L.72	C.	FC.1
	3797 Std.1509/24/080	Tube, distance, 3/8" o/d x 17 S.W.G. x .80"	2	T.4	MR/C	4
		long				
	3798 Std.1509/24/034	Tube, distance, 3/8" o/d x 17 S.W.G. x .34"	4	T.4	MR/C	4
		long				
31	2724 A.185592	Washer	2	L.168	C.	FC.1
	3868 F.168524	Washer, at "Lord" mounting	4	DTD.610	C.	FC.1
	D.205774	PANEL, CENTRE, ASSEMBLY	—	—		
31	6A/4685863	Altimeter, Mk. 19F (AS.1150/30)	1	—	A.	
	9834 B.215803	Bracket, for push button switches (Mod. 502)	1	—	MR/C	
	A.260494	Cable, HW.4, group (See Cable Chart)	1	—	—	
31	5CW/4400277	Lamp, warning indicator	1	—	C.	
	C.750/C5					
31	5CW/4405619	Cap (Sea Grey)	1	—	C.	
31	5CW/4405620	Clip (Sea Grey) (Mod. 452)	1	—	C.	
	3735 Std.840/16	Clip, 7/16" wide x 22 S.W.G. x 1.6" long	2	DTD.610	MR/C	4
	3971 Std.840/19	Clip, 7/16" wide x 22 S.W.G. x 1.9" long	2	DTD.610	MR/C	4
31	6A/1061012	Connector, static and pressure	2	—	C.	
31	5CW/1039477	Guard, switch (Mod. 488)	1	—	C.	
31	10A/4689944	Indicator, D.M.E. magnetic	1	—	A.	
31	6A/4339155	Indicator, rate of climb, Mk. 3 (Q)	1	—	A.	
	6A/5546	Indicator, turn and slip, Mk. 3	1	—	A.	
31	6A/4338386	Indicator, artificial horizon, Mk. 4	1	—	A.	
		(Pre Mod. 654)				
31	6A/4337798	Indicator, artificial horizon, Mk. 4A (Mod. 654)	1	—	A.	
31	6A/4333224	Indicator, air speed, Mk. 12A	1	—	A.	
	6A/4337748	Indicator, tail plane position (Mod. 406)	1	—	A.	
31	6A/4333338	Indicator, flap position	1	—	A.	
31	5CZ/4340381	Indicator, magnetic (Mod. 452)	1	—	C.	
	C.5165Y Mk. 2					
	11998 F.262476	Label	1	L.72	C.	
31	6A/4333270	Machmeter, Mk. 3A	1	—	A.	

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Pre Mod. 378)Hunter F. Mk. 6
Issued with A/L No. 31

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Score	Plate No.
		1	2	3	4	5				
	D.234160	Panel, group (Mod. 686)					1	—		
3597	A.191177/1	Pipe, static, rate of climb indicator A.S.I.					1	T.9	C.	
3598	A.191177/2	Pipe, static A.S.I. to machmeter					1	T.9	C.	
3599	A.191177/3	Pipe, static machmeter to altimeter					1	T.9	C.	
3601	A.191177/5	Pipe, pressure A.S.I. to machmeter					1	T.9	C.	
11085	A.191177/14	Pipe, static, tee union on altimeter to static connector (Mod. 1155)					1	T.9	C.	
8485	A.191177/11	Pipe, pressure, tee union on machmeter to pitot connector (Mod. 502)					1	T.9	C.	
1178	Std.1606/44/B12	Screw, round head, 4 B.A.					2	Brass	C.	5
1720	Std.1606/44/B24	Screw, round head, 4 B.A.					4	—	C.	5
3857	Std.1606/33/C24	Screw, round head, 2 B.A.					6	Brass	C.	5
9447	Std.1606/44/C28	Screw, round head, 2 B.A.					2	Brass	C.	5
4661	Std.1606/45/B12	Screw, countersunk, 4 B.A.					4	Brass	C.	5
4660	Std.1606/45/B14	Screw, countersunk, 4 B.A.					4	Brass	C.	5
1943	Std.1606/45/B16	Screw, countersunk, 4 B.A.					2	Brass	C.	5
3861	Std.1606/45/B24	Screw, countersunk, 4 B.A.					4	Brass	C.	5
4114	Std.1606/45/B32	Screw, countersunk, 4 B.A.					8	Brass	C.	5
4115	Std.1606/45/C20	Screw, countersunk, 4 B.A.					4	Brass	C.	5
3863	Std.1606/45/C24	Screw, countersunk, 2 B.A.					4	Brass	C.	5
4116	Std.1606/45/C28	Screw, countersunk, 2 B.A.					2	Brass	C.	5
3865	Std.1606/45/C32	Screw, countersunk, 2 B.A.					4	Brass	C.	5
9952	Std.2095/208/B24	Screw, c/s, unified thread)					8	—	C.	
9954	Std.2095/208/B32	Screw, c/s, unified thread) For use only when					8	—	C.	
9955	Std.2095/208/D24	Screw, c/s, unified thread) instruments have					1	—	C.	
9956	Std.2095/208/D28	Screw, c/s, unified thread) unified threads					2	—	C.	
9957	Std.2095/208/D32	Screw, c/s, unified thread) (AS.2790/61)					4	—	C.	
9959	Std.2095/209/D28	Screw, panhead, unified thread)					2	—	C.	
10894	Std.1948/11	Sleeve, marker					QR	—	C.	5
6B/2575	—	Shield, magnetic					1	—	B.	
5F/9454141	NY.18007A	Strapping					QR	—	C.	
5F/9138822	NY.3342	Stud					QR	—	C.	
31	5CW/6209279	Switch, S.P., change-over no "OFF" position					1	—	C.	
31	5CW/1047697	Switch, D.P., no "centre" position (Mod. 1040)					2	—	C.	
31	6A/4676148	Tachometer, engine speed Mk. 10A					1	—	A.	
31	6B/4343642	Unit, gyro, type "A"					1	—	A.	
31	6A/4338811	Unit, vibrator (Mod. 1054)					1	—	A.	
4162	Std.915/B22	Washer, 4 B.A.					4	DTD.610	C.	4
	B.192073	PANEL, PORT, ASSEMBLY					—	—		
31	5CW/4405620	Cable, F.13 (See Cable Chart)					1	—	—	
	3738	Cap, sea grey (Mod. 452)					1	—	C.	
	3951	Clip, 7/16" wide x 22 S.W.G. x 2.9" long (Make from 30B/1734)					1	L.72	MR/C	4
31	5CX/4330148	Clip, 7/16" wide x 22 S.W.G. x 2.6" long					1	DTD.610	C.	4
	5L/9951286	Disc, hydraulic pressure warning lamp					1	—	C.	4
	5L/9951273	Filament, 28V., 2.5W					9	—	C.	
31	5CX/4330226	Filament, 28V., 3.5W					2	—	C.	
31	5CZ/4340381	Indicator, undercarriage position, type D.1					1	—	C.	
	Dowty C.5165Y Mk. 2	Indicator, magnetic, aileron and elevator					1	—	C.	
31	5CZ/4340340	Indicator, magnetic air brake					1	—	C.	
	Dowty C.5165Y Mk. 1									

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Pre Mod. 378)

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Score	Plate No.
		1	2	3	4	5				
31	5CX/4330099	—				Lamp, undercarriage warning, Iris type	1	—	C.	
31	5CX/1085815	—				Lamp, hydraulic pressure warning, type B	1	—	C.	
	12543	A.217498				Panel, group (Mod. 452)	1	—	B.	FC.1
		A.208107				Bracket, undercarriage position indicator	1	L.72		
31		A.192562				Bracket, undercarriage control switch	1	S.510		
		F.217564				Collar (Mod. 452)	1	—		
		B.217444				Panel (Mod. 452)	1	DTD.610		
	3837	Std.1606/44/B10				Screw, round head, 4 B.A.	2	Brass	C.	5
	1637	Std.1606/44/B14				Screw, round head, 4 B.A.	2	Brass	C.	5
	3839	Std.1606/44/B16				Screw, round head, 4 B.A.	2	Brass	C.	5
	1720	Std.1606/44/B24				Screw, round head, 4 B.A.	4	Brass	C.	5
	3859	Std.1606/45/B10				Screw, countersunk, 4 B.A.	2	Brass	C.	5
31	5CW/4400332	Dowty C.5182Y				Switch, undercarriage push button	1	—	A.	
		Mk. 3D								
31	5CW/4680628	Dowty C.1223Y				Switch, flap lever (Mod. 1352)	1	—	A.	
		Mk. 27								
31	5CW/1047697	—				Switch, D.P. (Mod. 1040)	1	—	C.	
	5767	Std.1509/12/030				Tube, distance	1	T.4	MR/C	4
		B.205775				PANEL, STARBOARD, ASSEMBLY	—	—		
31	6A/1983016	SA-22055-1234				Adaptor, flange for Mk. 21 altimeter	1	—	C.	
31	6A/1037854	Negretti & Zambra M1707				Altimeter, cabin, Mk. 21 (AS.790/94)	1	—	A.	
	—	B.205851				Cable, F.11 (See Cable Chart)	1	—	—	
	—	A.215942				Cable, F.118 (See Cable Chart)	1	—	—	
31	5CW/4405619	Hellermann HV.3711				Cap, sea grey (Mod. 503)	2	—	C.	
		F.233731				Cover, switch safety (AS.790/94)	1	—		
31	5CX/4330149	Std.1512/29				Disc, warning lamp	1	—	C.	4
	5L/9951273	—				Filament, 28V., 3.5W	2	—	C.	
31	10AE/4689944	—				Indicator, D.M.E.	1	—	B.	
	100/61	Sangamo Weston S.114-1-1A				Indicator	1	—	A.	
31	5CX/1085815	—				Lamp, warning, type B (with night screen)	1	—	C.	
	1940	Std.1231/1				Lug, locking	1	—	C.	4
	957	C.187694				Panel (Mod. 503) (Pre Mod. 561)	1	DTD.610	C.	
	9624	C.230151				Panel (Mod. 561)	1	DTD.310	C.	FC.1
	4179	Std.1606/44/B20				Screw, round head	4	Brass	C.	5
	3858	Std.1606/45/B8				Screw, countersunk, 4 B.A.	4	Brass	C.	5
	4661	Std.1606/45/B12				Screw, countersunk, 4 B.A.	1	Brass	C.	5
	3860	Std.1606/45/B20				Screw, countersunk, 4 B.A.	4	Brass	C.	5
	3861	Std.1606/45/B24				Screw, countersunk, 4 B.A.	4	Brass	C.	5
31	5CW/1047691	—				Switch, S.P., 3-way	1	—	C.	
31	5CW/1047692	—				Switch, S.P., "On-off" (Spring return to centre off)	1	—	C.	
31	5CW/6209280	—				Switch, S.P., "On-off" (upright off)	1	—	C.	
31	6A/433344	—				Thermometer, exhaust gas (Mod. 691)	1	—	B.	
	7152	Std.1509/12/036				Tube, distance, 1/4" o/d x 20 S.W.G. x 36" long	4	T.4	MR/C	4
31	5CW/4405563	—				Transfer, "Out"	1	—	C.	
31	5CW/4405561	—				Transfer, "Bright"	1	—	C.	
31	5CW/4405560	—				Transfer, "Dim"	1	—	C.	
31	5CW/1055545	—				Transfer, "Off" (Mod. 715)	1	—	C.	
	8234	B.212856				Panel, R.P. selector (Mod. 465)	1	L.72	MR/B	
		F.215200				Packing, for accelerometer mounting	QR	L.72		
	1637	Std.1606/44/B14				Screw, for compass mounting	4	Brass	C.	5
	3837	Std.1606/44/B10				Screw, round head	2	Brass	C.	5
	1178	Std.1606/44/B12				Screw, round head	1	Brass	C.	5
	1720	Std.1606/44/B24				Screw, round head	3	Brass	C.	5
31	5D/4341029	—				Switch	1	—	B.	
	5CW/1047693	—				Switch (Mod. 1041)	1	—	C.	
	5CW/1102662	Rotax D.0701				Switch	1	—	C.	
	921	Std.915/B12				Washer	2	DTD.610	C.	4

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Mod. 378)

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Place No.
—	C.275466	INSTRUMENT PANELS, ASSEMBLY	—	—	—	—
		(ASH.1290/67)				
8543	F.218495	Mounting, for panels	12	Rubber	C.	FC.1
—	D.263351	MOUNTING, PANEL, ASSEMBLY (Mod. 1015)	—	—	—	—
5384	DTD.487/13E	Bolt, for "Lord" mountings	4	DTD.487	C.	—
5372	A.203163	Bracket, top centre panel mounting	2	—	C.	FC.1
	A.261856	Bracket, bottom mounting (Mod. 1015)	1	—	—	—
	5373 A.203162	Bracket, bottom centre panel mounting	1	—	—	FC.1
31	F.203235	Clip, for cross tube	2	S.510	C.	FC.1
31	27H/4605580	Mounting	4	—	C.	—
31	27H/4605586	Mounting, "Lord" (Alternative to F.211782)	4	—	C.	—
31	F.211792	Mounting, A.V. (Alternative to 27H/4605586)	4	—	—	—
	F.261845	Plate, support (Mod. 1015)	1	L.72	—	FC.1
	F.260316	Strut, support, port (Mod. 1015)	1	T.4	—	FC.1
	F.230565	Strut, support, starboard (Mod. 654)	1	—	—	FC.1
	12474 A.203240	Tube, cross	1	L.72	C.	FC.1
	3797 Std.1509/24/080	Tube, distance, 3/8" o/d x 17 S.W.G. x .80" long	2	T.4	MR/C	4
	3798 Std.1509/24/034	Tube, distance, 3/8" o/d x 17 S.W.G. x .34" long	4	T.4	MR/C	4
31	2724 A.185592	Washer	2	L.168	C.	FC.1
	3868 F.168524	Washer, at "Lord" mounting	12	DTD.610	C.	FC.1
—	D.314135	PANEL, CENTRE, ASSEMBLY (Mod. 1375)	—	—	—	—
6A/6206302	Kollsman	Altimeter, Mk. 30B (Mod. 1375)	1	—	A.	—
	L.83261-04-020					
12946	F.260752	Block, packing	1	L.65.C	C.	—
	F.260318	Bracket, for static connectors	1	L.72	—	—
—	D.206282	Cable, F.12, group (See Cable Chart)	1	—	—	—
—	A.221368	Cable, F.139, group (See Cable Chart)	1	—	—	—
—	A.260494	Cable, H.W.4, group (See Cable Chart)	1	—	—	—
31	5CW/4400277	Lamp, warning, indicator	1	—	C.	—
—	B.226184	Cable, PC.12, group (See Cable Chart)	1	L.65.C	—	—
	3735 Std.840/16	Clip, 7/16" wide x 22 S.W.G. x 1.6" long	2	DTD.610	MR/C	4
	3971 Std.840/19	Clip, 7/16" wide x 22 S.W.G. x 1.9" long	2	DTD.610	MR/C	4
31	6A/1061012	Connector, static and pressure	2	—	C.	—
31	5CW/1039477	Guard, switch	1	—	C.	—
	6A/4339155	Indicator, rate of climb, Mk. 3(O) (Mod. 1233)	1	—	A.	—
	6A/5546	Indicator, turn and slip, Mk. 3	1	—	A.	—
31	6A/4337798	Indicator, artificial horizon, Mk. 4A (Mod. 654)	1	—	A.	—
31	6A/4333224	Indicator, air speed, Mk. 12A	1	—	A.	—
31	6A/4338506	Indicator, tail plane position (Mod. 841)	1	—	A.	—
	6A/4333338	Indicator, flap position	1	—	A.	—
31	5CZ/4340381	Indicator, magnetic (Mod. 452)	2	—	C.	—
	C.5165Y Mk. 2					
	9833 A.216336	Label	1	—	C.	—
	10856 F.236168	Label	1	—	C.	—
31	6A/4333270	Machmeter, Mk. 3A	1	—	A.	—
	D.314136	Panel, group (Mod. 1375)	1	—	—	FC.1
	11720 A.191177/12	Pipe, static, rate of climb indicator A.S.I. (Mod. 1233)	1	T.9	C.	—
	3598 A.191177/2	Pipe, static A.S.I. to machmeter	1	T.9	C.	—
	3601 A.191177/5	Pipe, pressure A.S.I. to machmeter	1	T.9	C.	—
	11565 A.191177/15	Pipe, pressure, tee union on machmeter to pitot connector	1	T.9	C.	—
—	A.191177/22	Pipe, static, machmeter to altimeter (Mod. 1375) (Make from 30B/1054948)	1	—	L.M.	—
	A.191177/23	Pipe, static, machmeter to static connector (Mod. 1375)	1	—	—	—

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Mod. 378)Hunter F. Mk. 6
Issued with A/L No. 31

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
6A/6204138	A.236242/12 Kollsman L.84380-00-100					Pipe, tee union for altimeter	1	T.9		
						Plate, mooring, altimeter, Mk. 30B	1	—	C.	
1178	Std.1606/44/B12					Screw, round head, 4 B.A.	2	Brass	C.	5
1720	Std.1606/44/B24					Screw, round head, 4 B.A.	4	Brass	C.	5
3840	Std.1606/44/B28					Screw, round head, 4 B.A.	3	Brass	C.	5
5385	Std.1606/44/B44					Screw, round head, 4 B.A.	4	Brass	C.	5
3857	Std.1606/44/C24					Screw, round head, 2 B.A.	6	Brass	C.	5
9447	Std.1606/44/C28					Screw, round head, 2 B.A.	2	Brass	C.	5
4660	Std.1606/45/B14					Screw, countersunk, 4 B.A.	4	Brass	C.	5
1943	Std.1606/45/B16					Screw, countersunk, 4 B.A.	2	Brass	C.	5
3861	Std.1606/45/B24					Screw, countersunk, 4 B.A.	4	Brass	C.	5
4114	Std.1606/45/B32					Screw, countersunk, 4 B.A.	4	Brass	C.	5
4115	Std.1606/45/C20					Screw, countersunk, 4 B.A.	6	Brass	C.	5
3863	Std.1606/45/C24					Screw, countersunk, 2 B.A.	4	Brass	C.	5
4116	Std.1606/45/C28					Screw, countersunk, 2 B.A.	2	Brass	C.	5
3865	Std.1606/45/C32					Screw, countersunk, 2 B.A.	4	Brass	C.	5
9952	Std.2095/208/B24					Screw, c/s unified thread)	8	—	C.	
9954	Std.2095/208/B32					Screw, c/s, unified thread) For use only	4	—	C.	
9955	Std.2095/208/D24					Screw, c/s unified thread) when	1	—	C.	
9956	Std.2095/208/D28					Screw, c/s unified thread) instruments	2	—	C.	
9957	Std.2095/208/D32					Screw, c/s, unified thread) have	4	—	C.	
	Std.2095/209/B24					Screw, p/hd., unified thread) unified threads	4	—		
10154	Std.2095/209/D24					Screw, p/hd., unified thread) (AS.790/61)	2	—	C.	
9959	Std.2095/209/D28					Screw, p/hd., unified thread)	2	—	C.	
31 27QA/1011352	SP.900-9					Seal, "O" ring	1	—	C.	
	10894 Std.1948/11					Sleeve, marker	QR	—	C.	
	6B/2575 —					Shield, magnetic	1	—	B.	
	5F/9454141 NY.18007A					Strapping	QR	—	C.	
	5F/9138822 NY.3342					Stud	QR	—	C.	
	5CW/1047693 —					Switch, S.P., change over no "OFF" position	1	—	C.	
	5CW/1047697 —					Switch, D.P., no "centre" position (Mod. 1040)	1	—	C.	
31 6A/4676148	—					Tachometer, engine speed Mk. 10A	1	—	A.	
	6A/4333344 —					Thermometer, exhaust gas	1	—	A.	
	4042 Std.1509/23/030					Tube, distance	4	T.4	C.	4
31 6B/4343642	—					Unit, gyro, type "B"	1	—	A.	
	4162 Std.915/B22					Washer, 4 B.A.	4	DTD.610	C.	4
	— B.192073					PANEL, PORT, ASSEMBLY	—	—	—	
	— D.205498					Cable, F.13 (See Cable Chart)	1	—	—	
31 5CW/4405620	—					Cap. sea grey (Mod. 452)	1	—	C.	
	3738 Std.840/29					Clip, 7/16" wide x 22 S.W.G. x 2.9" long	1	L.72	MR/C	4
						(Make from 30B/9611222)				
	3951 Std.840/26					Clip, 7/16" wide x 22 S.W.G. x 2.6" long	1	DTD.610	C.	4
31 5CX/4330148	Std.1512/28					Disc, hydraulic pressure warning lamp	1	—	C.	4
	5L/9951286 —					Filament, 28V., 2.5W.	9	—	C.	
	5L/9951273 —					Filament, 28V., 3.5W.	2	—	C.	
31 5CX/4330226	—					Indicator, undercarriage position, type D.1	1	—	C.	
31 5CZ/4340381	Dowty					Indicator, magnetic, aileron and elevator	1	—	C.	
	C.5165Y Mk. 2									
	5CZ/4335566 Dowty					Indicator, magnetic, air brake	1	—	C.	
	C.5165Y Mk. 1									
31 5CX/4330099	Smiths 38 CFP					Lamp, undercarriage warning, Iris type	1	—	C.	
31 5CX/1085815	—					Lamp, hydraulic pressure warning, type "B"	1	—	C.	
	12543 A.217498					Panel, group	1	—	B.	FC.1
	A.208107					Bracket, undercarriage position indicator	1	L.72	—	FC.1
31 6098187	B.192562					Bracket, undercarriage control switch	1	S.510	C.	FC.1
	F.217564					Collar	1	—		
	F.217444					Panel	1	DTD.610		

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Mod. 378)

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Place No.
		1	2	3	4	5				
	3837	Std.1606/44/B10				Screw, roundhead, 4 B.A.	2	Brass	C.	5
	1637	Std.1606/44/B14				Screw, roundhead, 4 B.A.	2	Brass	C.	5
	3839	Std.1606/44/B16				Screw, roundhead, 4 B.A.	2	Brass	C.	5
	1720	Std.1606/44/B24				Screw, roundhead, 4 B.A.	4	Brass	C.	5
	6356	Std.1606/44/B32				Screw, roundhead, 4 B.A. (AS.770/80)	1	Brass	C.	5
	3859	Std.1606/45/B10				Screw, countersunk, 4 B.A.	2	Brass	C.	5
	5CW/4400332	Dowty C.5182Y				Switch, undercarriage push button (Mod. 991)	1	—	A.	
		Mk. 3D								
31	5CW/4680628	Dowty C.1223Y				Switch, flap lever (Mod. 1352)	1	—	A.	
		Mk. 27								
	5CW/1047697	—				Switch, D.P. changeover (Mod. 686)	1	—	C.	
	5767	Std.1509/12/030				Tube, distance	1	T.4	MR/C	4
	—	B.284257				PANEL, STARBOARD, ASSEMBLY (ASH.1290/67)	—	—	—	
31	6A/1983016	SA-22055-1234				Adaptor, flange, for Mk. 21 altimeter	1	—	C.	
	6A/1037854	Negretti & Zambra M1707				Altimeter, cabin, Mk. 21	1	—	A.	
	—	B.227763				Cable, F.11, assembly (See Cable Chart)	1	—	—	
	—	A.215942				Cable, F.118, assembly (See Cable Chart)	1	—	—	
	—	F.233731				Cover, switch, safety (Use 26FX/10410)	1	—	—	FC.1
31	5CX/4330149	Std.1512/29				Disc, warning lamp	1	—	C.	4
31	10AE/4689944	—				Indicator, D.M.E. magnetic	1	—	B.	
	100/61	Sangamo Weston				Indicator, S.114-1-1A	1	—	A.	
	5L/9951273	—				Lamp, filament, 28V., 3.5W	2	—	C.	
31	5CX/1085815	—				Lamp, warning, type "B" (with night screen)	1	—	C.	
	1940	Std.1231/1				Lug, locking	1	—	C.	4
	9624	C.230151				Panel, group (Mod. 561)	1	DTD.610	B.	FC.1
		F.233814				Label, I.P. fuel warning	1	L.16	—	
	13011	Std.1606/44/B48				Screw, roundhead, 4 B.A.	4	Brass	C.	5
	3858	Std.1606/45/B8				Screw, roundhead, 4 B.A.	4	Brass	C.	5
	4661	Std.1606/45/B12				Screw, countersunk, 4 B.A.	1	Brass	C.	5
	3860	Std.1606/45/B20				Screw, countersunk, 4 B.A.	4	Brass	C.	5
	3861	Std.1606/45/B24				Screw, countersunk, 4 B.A.	4	Brass	C.	5
	5CW/1047691	—				Switch, S.P., 3-way	1	—	C.	
	5CW/1047690	—				Switch, S.P., "ON-OFF"	1	—	C.	
	26VA/6039016	Std.1509/23/064				Tube, distance	4	T.4	C.	4
	5731	Std.1509/12/025				Tube, distance	4	T.4	MR/C	4
31	5CW/4405563	—				Transfer, "OUT"	1	—	C.	
31	5CW/4405561	—				Transfer, "BRIGHT"	1	—	C.	
	5CW/4405560	—				Transfer, "DIM"	1	—	C.	
	5CW/1055545	—				Transfer, "OFF"	1	—	C.	
	—	C.263353				PANEL, TOP AND GLARE SHIELDS, ASSEMBLY (Mod. 1015)	—	—	—	
		F.262358				Angle	1	L.72	—	
		F.214593/1				Clip, mounting, top	2	L.72	—	
		F.214593/2				Clip, mounting, bottom	2	L.72	—	
	5L/9951286	—				Filament, 28V., 2.5 amp.	1	—	C.	
	—	B.215625				PANEL, TOP PORT, ASSEMBLY (Mod. 378)	—	—	—	
		F.215611				Angle	1	L.72	—	
		F.215612				Angle	1	L.72	—	
		A.215609				Bracket, support	1	—	—	
	8706	F.214078				Cover, spring, "inboard stores"	1	—	C.	
	8707	F.214079				Cover, spring, "outboard stores"	1	—	C.	
	8708	F.214077				Flap, for switch	1	—	C.	
	9558	F.215627				Guard, locking	1	—	C.	FC.1
		B.215598				Panel	1	L.72	—	

EQUIPMENT AIRCRAFT — INSTRUMENT PANELS
(Mod. 378)Hunter F. Mk. 6
Issued with A/L No. 31

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
31	5830	Std.1606/45/A14				Screw, 6 B.A.	8	Brass	C.	5
		Std.1606/45/A16				Screw, 6 B.A.	12	Brass	C.	5
	3838	Std.1606/44/B8				Screw, 4 B.A.	2	Brass	C.	5
	1638	Std.1606/45/B6				Screw, 4 B.A.	4	Brass	C.	5
	5CW/1047696	—				Switch, D.P. change-over	1	—	C.	
	5CW/1047693	—				Switch, S.P. change-over	1	—	C.	
	5CW/1102662	Rotax D.0701				Switch, D.P. push	2	—	C.	
	5CW/936	—				Switch, rotary 3-way type "B"	1	—	C.	
	5CW/1055544	—				Transfer, "ON"	3	—	C.	
	751	Std.915/A/20				Washer, 6 B.A.	4	DTD.610	C.	4
	—	B.263354				PANEL, TOP STARBOARD, ASSEMBLY (Mod. 1015)	—	—	—	
31	6A/4695406	—				Accelerometer, Mk. 2	1	—	A.	
	6A/4339363	—				Altimeter, Mk. 19F	1	—	A.	
		A.262357				Bracket, support	1	L.72		
	5CX/1143217	—				Bridge light, type "F"	1	—	C.	
	26VA/6042328	Std.2045/16/24				Clip, securing cable	1	—	C.	6
	5L/9959118	—				Filament, 28V., .04 amp.	2	—	C.	
		B.260315				Panel (Mod. 1015)	1	L.72		
	13011	Std.1606/44/B48				Screw	3	—	C.	5
	1943	Std.1606/45/B16				Screw	1	—	C.	5
		Std.1606/45/C16				Screw	2	—	—	5
31	9953	Std.2095/208/B28				Screw	2	—	C.	
		Std.2095/209/B36				Screw	2	—		
	5CY/4376512	—				Socket, type "R"	1	—	C.	
	7181	Std.1509/12/068				Tube, distance	3	—	MR/C	4
	4162	Std.915/B/22				Washer	3	—	C.	4
		A.216817				Shield, centre, lower, group	1	L.72		
	10275	B.216818				Shield, centre, upper, group	1	—	B.	
	28R/1061088	AS.4573/1				Ring, retaining (AS.840/56)	2	—	C.	
	10768	D.215634				Shield, glare, port, group	1	—	B.	
	11217	C.263352				Shield, glare, starboard, group (Mod. 1015)	1	—	B.	
31		D.215634/3				Beading (Make from 28FX/3882)	1	—	—	
		F.262010				Bracket, for extinguisher switch	1	L.72		
	5CW/4405748	EL.37711				Switch, push, fire warning	1	—	C.	
	5CW/1047690	—				Switch, S.P. "on-off"	1	—	C.	
	5CW/1055544	—				Transfer, "on"	1	—	C.	
	5CW/1055545	—				Transfer, "off"	1	—	C.	
	3815	Std.1547/20/14				Washer, packing, at mounting clip	8	—	MR/C	4
	5CW/11817	—				Window, "red"	1	—	C.	
	1637	Std.1606/44/B14				Screw, for compass mounting	4	Brass	C.	5
	10930	Std.1509/3/026				Tube, distance, at port and starboard panel mounting (Mod. 761)	6	T.4	C.	4
		Std.1509/3/076				Tube, distance, at port and starboard panel mounting (Mod. 761)	6	T.4		4
	9777	F.231121				Washer, at port and starboard panel mounting (Mod. 761)	6	DTD. 5509/D	C.	FC.1

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

