


Ref. No.	Part No.	Description					No. On	Material Specification	M.R. Class of Store	Plate No.	
		1	2	3	4	5					
5CZ/1053794	D.233619	METER, FATIGUE, ASSEMBLY					—	—	C.		
	—	Block, terminal					1	—			
	B.221106	Cable, FM 1, group (See Cable Chart)					1	—			
	B.216904	Cable, FM 2, group (See Cable Chart)					1	—			
	F.216906	Bracket, fuseholder					1	L.72			
	A.216906	Cable, FM 3, group (See Cable Chart)					1	—			
6A/4664239	B.233682	Landing, for access panel assembly					—	—	A.		
	B.233766	Landing					1	—			
	—	Meter, fatigue Mk. 14 (Mod. 951)					1	—			
	10087	A.233683	Panel, access					1			L.72
	1919	Std.1341/3	Stud, earthing, point					1			—
	4613	Std.1335/C/18	Washer					1			L.4, L.34 or L.17
	4659	Std.1335/C/22	Washer					1	L.4, L.34 or L.17	C.	4
	10666	Std.2008/C/325	Washer, tab (Mod. 951)					2	S.84	C.	6



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.