


SERVICES -- FUEL SYSTEM REAR FUSELAGE

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
		1 2 3 4 5				
	D.202256	FUEL SYSTEM, REAR FUSELAGE, ASSEMBLY	—	—		
	2727 F.195128	Block, clamp, for pressure pipe	3	LFS.21	MR/C	NP.1
	421 A.185593	Clamp, for twin gate and suction relief valves, group	3	—	C.	NP.1
	2723 F.184931	Belt, eye	1	S.94.B	C.	NP.1
31	6526 F.213079	Nut, special	1	S.154	C.	
	2724 F.185592	Washer	1	DTD.364	C.	NP.1
	4764 Std.840/21	Clip, support, 7/16" wide x 22 S.W.G.	1	DTD.610	MR/C	4
	Std.851/38	Clip, support, 7/16" wide x 22 S.W.G.	3	DTD.610		5
31	Std.853/51	Clip, vent pipe seat	3	S.510		4
	F.210152	Clip, support, for pressure pipe	2	—		NP.1
31	1385 F.190242	Collar, at vent pipe connection	1	L.168	C.	
31	422 A.186347	Extension, for twin gate valve	2	L.168	C.	NP.1
	2095 F.194603	Fairlead, for pressure pipes	4	LFS.21	C.	NP.1
	3895 A.189935	Fairlead, for pressure pipes	4	LFS.21	C.	NP.1
	2725 F.195096	Fairlead, for pressure pipes	2	LFS.21	MR/C	NP.1
	2028 B.195140/1	Pipe, fuel, valve to connection, port	1	DTD.253	C.	NP.1
	2029 B.195140/2	Pipe, fuel, valve to connection, starboard	1	DTD.253	C.	NP.1
	437 B.184767/4	Pipe, fuel, pressure reducing valve to diaphragm, port	1	DTD.253	C.	NP.1
	438 B.184767/5	Pipe, fuel, pressure reducing valve to diaphragm, starboard	1	DTD.253	C.	NP.1
	1879 B.184767/6	Pipe, fuel, diaphragm to filter	2	DTD.253	C.	NP.1
	6261 B.202258/1	Pipe, fuel, coupling to coupling, port	1	DTD.253	B.	NP.1
	6262 B.202258/2	Pipe, fuel, coupling to coupling, starboard	1	DTD.253	B.	NP.1
	6263 B.202258/3	Pipe, fuel, relief valve to coupling, port	1	DTD.253	B.	NP.1
	6264 B.202258/4	Pipe, fuel, relief valve to coupling, starboard	1	DTD.253	C.	NP.1
	6266 B.202258/6	Pipe, pressure, coupling to coupling	2	DTD.253	C.	NP.1
	6267 C.213400	Pipe, vent, branch	1	DTD.253	B.	NP.1
	8515 A.216508	Pipe, vent	1	DTD.253	C.	NP.1
	8514 B.216544*	Pipe, vent, extension (Mod. 545) (Pre Mod. 716)	1	DTD.253	C.	
	9587 B.228306	Pipe, vent, extension (AS.710/86) (Pre Mod. 716)	1	T.26	C.	NP.1
	9083 A.217436	Pipe, vent, between frames 46 and 51	1	DTD.253	C.	NP.1
31	27QA/4534527 Dowty Seals	Ring, sealing, "O" type, at twin gate valve	4	—	C.	
	GD.1308/2					
	8519 F.217013	Seat, pipe, vent at frames 47, 50 and 52	3	LFS.21	C.	NP.1
	1659 Std.1744/10	Sleeve, at vent pipe connection, frames 50 and 51	1	Rubber	C.	5
	D.201057	TANK INSTALLATION, ASSEMBLY	—	—		
31	6A/4333733 Smiths JM.14	Box, terminal	2	—	B.	
	A.219025	Conductor	2	L.65		NP.1
31	425 A.186493	Conductor	2	L.168	C.	NP.1
	8478 D.218734	Pipe, outlet, port	1	—	C.	NP.1
	8479 D.218735	Pipe, outlet, starboard	1	—	C.	NP.1
	8471 F.217756	Seal, "O," at float switch	2	Rubber	C.	
	8476 B.218973	Support, outlet pipe, port	1	—	C.	
	8477 B.218974	Support, outlet pipe, starboard	1	—	C.	
31	5CW/4405085 Flight Refuelling	Switch, float Mk. 4	2	—	A.	
	C.3504100/38					
31	5CW/4400028 Smiths 1696FG	Switch, fluid level	2	—	A.	
	—	TANKS (See SECTION Q)	—	—		

SERVICES—FUEL SYSTEM REAR FUSELAGE

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
	9647	F.226366				Washer, sealing	2	DTD.1177 & L.72	C.	
	9648	F.226367				Washer, sealing	2	DTD.1177 & L.72	C.	
31	8474	F.218936				Washer, sealing at outlet pipe	4)	E.75 or	C.	
31	8475	F.218937				Washer, sealing, float switch	2)	DTD.560P	C.	
	1130	F.189006				Washer, sealing, at terminal box (for use with fireproof tanks) (Pre F.P. Mod. 144)	2	DTD.762	C.	
31	6268	F.189045*				Washer, sealing	4	22.L72/33/2/	C.	
	9712	F.226374								
	1129	F.189043				Washer, sealing (for use with fireproof tanks) (Pre F.P. Mod. 144)	2	DTD.762	C.	NB.3
	4601	F.203207				Tube, spacer at vent pipe connection	1	DTD.253	C.	
31	27FS/4524662	Saunders 812.BR.03				Valve, gate	1	—	A.	
	7049	B.125824				Valve, suction and pressure relief, group	2	—	B.	NP.1
31	2726	A.195020				Adaptor, union	1	L.168	C.	NP.1
31	428	F.184477				Adjuster, valve	1	L.168	C.	NB.2
31	429	A.184476				Cap, valve	1	L.168	C.	NB.2
	430	F.184480				Collar, valve	1	—	C.	NB.2
31	6200	F.209640				Collar, valve	2	L.168	C.	NP.1
31	1882	F.195019				Plug	1	L.168	C.	NB.2
31	27QA/4534531	Dowty Seals GD.1308/8				Ring, sealing, "Q" type	1	—	C.	NP.1
	431	A.184478				Ring, cap	1	L.168	C.	NB.2
	432	F.184482				Screw, adaptor, attachment to body	4	—	C.	NP.1
	433	F.186042				Screw, adaptor, attachment to body	2	—	C.	NP.1
31	27QA/4534424	Dowty Seals BD.1307/23				Seal, bonded, between cap and ring	1	—	C.	NB.2
31	27QA/8043262	Dowty Seals GD.1307/G				Seal, bonded, between plug and adaptor	1	—	C.	NP.1
31	27QA/4534417	Dowty Seals GD.1307/6				Seal bonded	2	—	C.	NP.1
31	434	F.184473				Seat, valve	2	L.168	C.	NP.1
	8127	F.217607				Spring (Mod. 504)	1	DTD.239	C.	NP.1
	6199	F.209155				Spring, at valve seat	2	Phos. Br.	C.	NP.1
31	441	A.184484				Valve	1	L.168	C.	NB.2
31	7050	F.215727				Valve	2	L.168	C.	NP.1
		Dowty Seals GD.1288				Washer, between body and cap ring	1	—	C.	NP.1
	4666	F.201931				Washer, between main spring and adjuster	1	DTD.610	C.	NB.2
	7051	F.215989				Washer	2	—	C.	
	4124	Std.821/35				Washer, for twin gate valve extension	2	L.4	C.	4
	9855	F.233552				Washer, sealing, at vent pipe extension (AS.790/65)	2	DTD.762	C.	
		Std.1547/16/12				Washer, at vent pipe attachment clips	3	—		4
3812		Std.1547/22/14				Washer, at vent pipe attachment clips	3	—	MR/C	4



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

