


UNDERCARRIAGE—NOSE WHEEL DOOR OPERATING GEAR

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Place No.
	B.208488	NOSE-WHEEL DOOR OPERATING GEAR, ASSEMBLY	—	—		
	1531 F.152672	Bolt, jack attachment to frame 3	1	S.2	C.	RE.1
	1533 F.156330	Bolt, jack attachment to lever	1	S.2	C.	RE.1
	8975 F.216171	Bracket, for cross-shaft, port, group	1	—	C.	RE.1
23	12914 F.216173	Bush	1	BSS.369 or BS.2874	C.	RE.1
	8976 F.216172	Bracket, for cross-shaft, starboard, group	1	—	C.	RE.1
	12914 F.216173	Bush	1	BSS.369	C.	RE.1
23	27QM/4118214 Dowty	Jack, door	1	—	A.	
	C.07584Y-A.02					
	8977 A.218521	Rod, connecting, group	2	—	B.	RE.1
23	28R/4706463 AGS.589/3/PB	Ball (Alt. to RJB9R)	2	—	C.	
	Rose Bearings RJB9R	Ball (Alt. to 28R/4706463)	2	—		
	5859 F.208205	Locknut, L.H.	1	S.1	C.	RE.1
	5860 F.208206	Locknut, R.H.	1	S.1	C.	RE.1
	5862 F.204656	Pin	1	S.95 or S.95.B	C.	RE.1
	5863 F.204657	Pin	1	S.96.B or S.95.B	C.	RE.1
	28P/942619 SP.9.C5	Pin, split	2	—	C.	
	8103 A.218085	Rod, end, complete	1	S.1	C.	RE.1
	8102 F.218084	Turnbuckle	1	S.1	C.	RE.1
	8104 F.218070	Washer, locking	1	S.1	C.	RE.1
28W/1200106	SP.42.C	Washer, tab	2	S.3	C.	
	8124 B.215854	Shaft and lever, group	1	—	B.	RE.1
	124 Std.532/15	Ferrule	8	S.95.B or S.96.B	C.	4
	125 A.178907	Lever, for door connection	1	Stamping 1699	C.	RE.1
	126 A.178908	Lever, for door and jack	1	Stamping 1700	C.	RE.1
	A.178909	Shaft	1	T.50		
	F.168113	Spigot	2	S.1		
12501	Std.1208/105/56/10	Shim, between bush and cross-shaft bracket	QR	—	C.	4
		(max. 0.03")				



NOSE UNDERCARRIAGE

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

