

PART 6

CHAPTER 1 — ILLUSTRATIONS

(Completely revised by AL6)

Contents


	Fig
Hunter T Mk 8C Cockpit	1
Hunter T Mk 8B Cockpit	2

Key to Fig 1

1 Cabin pressure warning test switch	41 Elevator power switch and MI	83 RPM indicator	126 Oxygen flow MI
2 Canopy override switch	42 Stores jettison buttons	84 Altimeter normal/standby power switch	127 Aileron and elevator power MI (two)
3 Landing gear emergency air pressure gauge	43 'Clear aircraft' switch bar	85 Turn and slip indicator	128 Stbd instrument panel lighting dimmer switch
4 Flap emergency air pressure gauge	44 Bomb fuze switch	86 Turn and slip normal/emergency switch	129 Oxygen regulator
5 Brake parachute test switch and c/b	45 Bomb/RP selector switch	87 Throttle	130 Rudder pedal adjustment control
6 Engine relight button	46 Brake parachute switch	88 Engine anti-icing switch and indicator	131 Altimeter
7 HP fuel cock	47 RP selector switch	89 Inverter indicators (two)	132 Machmeter
8 Cabin pressurisation switches	48 Arrestor hook switch	90 Centre pedestal lighting switch	133 Artificial horizon
9 Port shelf lighting dimmer switch	49 Tailplane indicator	91 UHF mute switch	134 VSI
10 RT/MIX/BEAC switch	50 ASI	92 Engine starter c/b	135 Compass repeater
11 LP fuel cock	51 Machmeter	93 Inverter normal/standby switches	136 Turn and slip indicator
12 HP pump isolating switch and warning light (red)	52 Altimeter	94 Anti-g cock	137 Turn and slip normal/emergency switch
13 Aileron and rudder trim control	53 Flap indicator	95 Anti-g test button	138 Flap selector
14 Top temperature control switch	54 Windscreen wiper control	96 Canopy jettison handle	139 Landing gear selector
15 Throttle damper	55 Rudder pedal adjustment control	97 Airbrake test switch	140 Power control override switches
16 Safety pins stowage (port seat and canopy jettison pins)	56 Engine oil pressure gauge	98 Standby compass lighting dimmer	141 Anti-g air supply pressure gauge
17 Canopy lock indicator	57 Engine starter button	99 Standby compass lighting switch	142 GGS controls (not used)
18 Throttle	58 Starter master bar	100 UHF control unit	143 Auto tone cancel switch
19 Aileron and rudder trim indicators	59 Aileron spring feel control	101 Tacan indicator	144 Tailplane main trim c/b
20 Tailplane standby control	60 Battery master switch	102 Cabin altimeter	145 Canopy lock indicator
21 Airbrake control	61 Pressure head heater switch	103 Tailplane interconnection switch	146 Stbd shelf lighting dimmer switch
22 Press-to-transmit button	62 Engine master switch	104 Tacan power supplies reset button	147 Safety pins stowage (stbd seat)
23 GGS controls (not used)	63 Ignition switch	105 Tacan power supplies failure MI	148 Anti-g test button
24 Telebriefing button and light (amber)	64 Generator warning lights (red)	106 Brake parachute switch	149 Aileron and rudder trim indicators
25 Landing gear emergency lowering control	65 G4FT compass	107 Booster pump warning lights (amber)	150 Aileron trim control
26 Wheelbrake accumulator pressure gauge	66 Artificial horizon	108 Booster pump switches (two)	151 Intercom switches (two)
27 Hydraulic triple pressure gauge	67 Port instrument panel lighting dimmer switches	109 Arrestor hook light	152 Oxygen regulator
28 Airbrake MI	68 Standby inverter MI	110 Arrestor hook switch	153 Inverter c/b (four)
29 Landing gear warning light (red)	69 Stick centring white spot	111 Outboard drop tank MI (two)	154 Booster pump ground test switch and ammeter socket
30 Landing gear indicator	70 IFF/SSR control unit	112 Fuel transfer pressure failure MI (two)	155 Butt test switch (not used)
31 Communications switch panel	71 IFF/SSR failure warning light (amber)	113 Fuel LP warning light (red)	156 GGS recorder camera stowage (not used)
31A Inboard/outboard pylon selector switch (not all aircraft)	72 Brake parachute STREAM caption	114 Fuel contents gauges (two)	157 Map stowage
32 Auto tone cancel switch	73 GGS master switch (not used)	115 Standby compass	
33 UHF aerial selector switch	74 Accelerometer	116 Booster pump c/b (two)	
34 Grimes light switch and light (white)	75 Canopy lock indicator	117 Fuel contents check switch	
35 Canopy jettison servicing pin stowage	76 Engine fire warning light (red) and extinguisher button	118 Centre panel lighting dimmer switches	
36 Landing gear selector	77 Fire warning light test button	119 Cabin pressure warning light (red)	
37 Flap selector	78 Emergency lighting switch	120 Hydraulic failure audio warning cut-out switch	
38 Flap emergency lowering control	79 Canopy control switch	121 Navigation lights switch	
39 Hydraulic failure warning light (red)	80 Tacan control unit	122 Oxygen contents gauge	
40 Aileron power switch and MI	81 VSI	123 Stick centering white spot	
	82 JPT gauge	124 Autostabiliser switch	
		125 ASI	

Control Column Handle

158 Bomb/RP release button and safety flap
159 Trigger release safety flap
160 Camera button
161 Trigger (stowed position)
162 Tailplane trim switch
163 Wheelbrake lever
164 Wheelbrake lever parking lock




6-1 Fig 1 Hunter T Mk8C Cockpit

Key to Fig 2

1 Cabin pressure warning test switch	44 Stores jettison buttons	87 Standby compass	131 GGS
2 Canopy override switch	45 'Clear aircraft' switch bar	88 Booster pump c/b (two)	132 ASI
3 Brake parachute test switch and c/b	46 Bomb fuze switch	89 Fuel contents gauges (two)	133 Stbd instrument panel lighting dimmer switch
4 Engine relight button	47 Bomb/RP switch	90 Fuel LP warning light (red)	134 Aileron and elevator power MI (two)
5 HP fuel cock	48 Brake parachute switch	91 Fuel transfer pressure failure MI (two)	135 Oxygen flow MI
6 Cabin pressurisation switches	49 Angle of attack indicator	92 Outboard drop tank MI (two)	136 VSI
7 Port shelf lighting dimmer switch	50 ADD approach index	93 Booster pump switches (two)	137 Artificial horizon
8 RT/MIX/BEAC switch	51 Brake parachute STREAM caption	94 Booster pump warning lights (amber)	138 Machmeter
9 LP fuel cock	52 GGS	95 Arrestor hook light	139 Altimeter
10 HP pump isolating switch and warning light (red)	53 RP selector switch	96 Arrestor hook switch	140 Compass repeater
11 Top temperature control switch	53A RP ripple/salvo/SNEB switch	97 Tailplane interconnection switch	141 Turn and slip indicator
12 Throttle damper	54 Arrestor hook switch	98 Cabin pressure warning light (red)	142 Flap selector
13 Aileron and rudder trim control	55 Windscreen wiper control	99 Brake parachute switch	143 Landing gear selector
14 Aileron and rudder trim indicators	56 Windscreen instrument lighting dimmer switch	100 JPT gauge	144 Cabin altimeter
15 Tailplane standby control	57 Speed display	101 RPM indicator	145 Power control override switches
16 Airbrake control	58 Tacan offset computer	102 DI/AH normal/emergency switch	146 Anti-g air supply pressure gauge
17 Press-to-transmit button	59 Navigation display	103 UHF control unit	147 GGS controls
18 Throttle	60 Attitude indicator	104 Throttle	148 Tailplane main trim c/b
19 GGS manual ranging twistgrip	61 Altitude and vertical speed display	105 Engine anti-icing switch and indicator	149 Canopy lock indicator
20 Safety pins stowage (port seat and canopy jettison pins)	62 MRG fast erection button	106 Inverter indicators (two)	150 Stbd shelf lighting dimmer switch
21 Canopy lock indicator	63 Rudder pedal adjustment control	107 UHF mute switch	151 Anti-g test button
22 Telebriefing button and light (amber)	64 Engine oil pressure gauge	108 Main inverters changeover switch	152 Aileron and rudder trim indicators
23 GGS control unit	65 Engine starter button	109 Airbrake test switch	153 Aileron trim control
24 Landing gear emergency lowering control	66 Starter master bar	110 Anti-g cock	154 Safety pin stowage (stbd seat)
25 Wheelbrake accumulator pressure gauge	67 Aileron spring feel control	111 Anti-g test button	155 Intercom switches (two)
26 Airbrake MI	68 Battery master switch	112 Canopy jettison handle	156 MASB test switch and light (amber)
27 Hydraulic triple pressure gauge	69 Pressure head heater switch	113 Engine starter c/b	157 Landing gear emergency air pressure gauge
28 Flap indicator	70 Engine master switch	114 Standby inverter switch	158 Flap emergency air pressure gauge
29 Landing gear warning light (red)	71 Ignition switch	115 Centre pedestal lighting switch	159 Booster pump ground test switch and ammeter socket
30 Landing gear indicator	72 Generator warning lights (red)	116 Standby compass lighting dimmer	160 Oxygen regulator
31 Communications switch panel	73 IFIS lighting dimmer switch	117 Standby compass lighting switch	161 MRG fast erection button
32 Inboard/outboard pylon selector switch	74 Standby DI	118 IFF/SSR control unit	162 Butt test switch
33 ADD master switch	75 Standby artificial horizon	119 IFF/SSR failure warning light (amber)	163 GGS recorder camera stowage
34 ADD control unit	76 Standby altimeter	120 IFF/SSR control unit lighting switch	164 Map stowage
35 Landing gear selector	77 Standby ASI	121 Rudder pedal adjustment control	
36 Flap selector	78 Tacan control unit	122 Oxygen regulator	
37 Flap emergency lowering control	79 GGS master switch	123 Oxygen contents gauge	
38 Port panel lighting dimmer switch	80 Accelerometer	124 Anti-collision lights switch	
39 Canopy jettison servicing pin stowage	81 Canopy control switch	125 Stick centring white spot	
40 Aileron power switch and MI	82 Emergency lighting switch	126 Navigation lights switch	
41 Elevator power switch and MI	83 Canopy locked light (green)	127 Hydraulic failure audio warning cut-out switch	
42 Hydraulic failure warning light (red)	84 Engine fire warning light (red) and extinguisher button	128 Centre panel lighting dimmer switches	
43 Tailplane indicator	85 Fire warning light test button	129 Fuel contents check switch	
	86 GGS air-to-ground range drive panel	130 GGS recorder camera	

Control Column Handle

165 Bomb/RP release button and safety flap
166 Trigger release safety flap
167 Camera button
168 Trigger (stowed position)
169 Tailplane trim switch
170 Wheelbrake lever
171 Wheelbrake lever parking lock



6-1 Fig 2 Hunter T Mk8B Cockpit

Intentionally Blank

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

