


POWER INSTALLATION—GEARBOX AND ACCESSORIES


Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
	D.187592	ACCESSORY DRIVE FOR GEARBOX AND EQUIPMENT ASSEMBLY					—	—		
412	F.187588	Block, clamp (in halves)					—	DTD.364	C.	LB.1
414	F.187781	Bolt, special, for securing hydraulic pump					4	S.94.B	C.	LB.1
415	F.187782	Bolt, special					2	S.94.B	C.	LB.1
420	F.188684	Bolt, "U", supporting driving shaft at frame 34					1	S.1	C.	LB.1
	F.260908	Bracket, for clip					2	S.510 or S.511		
6395	F.188685	Channel, stop					1	DTD.610	C.	
	Std.2046/49/20	Clip					2	—		6
37L/4521650	—	Gearbox, accessories drive, type T.G.5/8					1	—	A.	
416	A.187589	Eye-ehd, supporting generators					1	Stamping	C.	LB.1
417	A.197590	Fork-end, at stringer "K", supporting generators					1	S.94.B	C.	LB.1
5UA/4357526	—	Generator, type 515A					2	—	A.	
418	F.188834	Nut, lock, for generator support, at stringer "K"					1	S.1	C.	LB.1
6104	F.209992	Piece, distance, between gear box and spar					1	DTD.610	C.	
37J/4602111	Dowty	Pump, hydraulic, type A8003.Y/R.H./3000					1	—	A.	
22 37L/300	—	Shaft, drive and engine coupling paired units GD.9/107 (Mod. 1445)					1		A.	
4559208	Std.1509/23/075	Tube, distance at "U" bolt					2	T.4		4
	Std.914/J/14	Washer, at generator lug					1	S.1		4
5781	Std.915/E/20	Washer					2	DTD.610	C.	4
3953	Std.915/E/22	Washer (shim)					1	DTD.610	MR/C	4

POWER INSTALL.

POWER INSTALLATION—GEARBOX AND ACCESSORIES

[illegible]





This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.