

CONTENTS

Note - For Contents see overleaf

RESTRICTED

CONTENTS

Leading particulars

Introduction

BOOK 1

Section 1 - Controls and exits	Chapter 1—Pilot's controls and equipment 2—Crew's controls and equipment (<i>Not applicable</i>) 3—Emergency controls, equipment and exit
Section 2—Ground handling and preparation for flight	Chapter 1—Ground handling 2—Preparation for flight 3—Loading and C.G. data 3A—Aircraft weighing 4—General servicing 5—Change of role (<i>Not applicable</i>) 6—Procedure following hazardous incidents
Section 3—Airframe	Chapter 1—Fuselage 2—Main planes 3—Tail unit 4—Flying controls 5—Landing gear 6—Hydraulic system 7—Pneumatic system (<i>Not applicable</i>) 8—Air conditioning system 9—De-icing system (<i>Not applicable</i>) 10—Oxygen system 11—Emergency system 12—Vacuum system (<i>Not applicable</i>) 13—Anti-'G' system
Section 4—Power unit installation	Chapter 1—Power unit 2—Fuel system 3—Oil system (<i>Not applicable</i>) 4—Cooling system (<i>Not applicable</i>) 5—Fire protection system

(Continued overleaf)

CONTENTS (Continued)

BOOK 2

Section 5—Electrical system and instrument installation

Chapter 1—Electrical system

Group A—General information

- A.1. System details*
- A.2. Removal of junction boxes, panels and shelves.*
- A.3. Location of equipment.*

Group B—Power supply services

- B.1. Generators and batteries.*

Group C—Engine services

- C.1. Engine starting*
- C.2. Fire warning and extinguisher*
- C.3. Tank pumps, failure warning and pressure refuelling*
- C.4. Engine anti-icing*
- C.5. Fuel filter de-icing*
- C.6. Emergency fuel pump*

Group D—Flying services

- D.1. Rudder and aileron trim controls.*
- D.2. Elevator and aileron power controls.*
- D.3. Tail plane control.*
- D.4. Flap control*
- D.5. Hood control*
- D.6. Cabin pressurization and temperature control*
- D.7. Landing gear and airbrake control.*
- D.8. Parachute brake.*
- ◀ *D.9. Autostabilizer. (pre Mod.1376 only)* ▶
- D.10. Arresting hook control*

Group E—Instrument services

- E.1. A.C. supplies and control*

Group F—Lighting services

- F.1. Cabin lighting*
- F.2. Navigation lamps*
- F.3. Servicing lamps*

Group G—Armament services

- G.1. Armament supplies and control*

Group H—Radio and radar services

- H.1. Radio and radar supplies*

CONTENTS (Continued)

BOOK 2	Section 5 - Electrical system and instrument installation (Continued)	Chapter 2—Instrument installation
		Group 1—General information
		1.A. Installation details
		1.B. Removal of instrument panels
		1.C. Location of equipment
		Group 2—Engine instruments
		2.A. Fuel content gauges and fuel pressure warning.
		2.B. Exhaust gas thermometer and top temperature control.
		2.C. Oil pressure gauge and tachometer.
		Group 3—Flying instruments
BOOK 1		3.A. Integrated flight instrument system (full) with Tacan and standby instruments.
		3.B. Electrically operated flight instruments.
		3.C. Air pressure operated flight instruments.
		3.D. Mechanically operated flight instruments.
		Group 4—Armament instruments
		4.A. Gyro gun sight and camera recorder.
		Group 5—Miscellaneous instruments
		5.A. Gauges and indicating instruments.
	Section 6— Radio installation	Chapter 1—Wireless installation
		2—Radar installation
BOOK 1	Section 7 —Armament installation	Chapter 1—Pyrotechnics
		2—R.P. equipment
		3—Guns (Not applicable)
		4—Bombing equipment (Not applicable)

Note . . . The List of Chapters following each Section marker card indicates the contents of the Section.

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

