


GROUPS B & C

## POWER SUPPLY AND ENGINE SERVICES

*Note - A list of Groups is given overleaf*



## GROUPS B & C

# POWER SUPPLY AND ENGINE SERVICES

### LIST OF GROUPS

*Group*

**B.1** Generators and batteries (Code GA)

**C.1** Engine starting (Code SA)

**C.2** Fire warning and extinguisher (Code FW and FE)

**C.3** Tank pumps, failure warning and pressure refuelling  
(Code BP, PF and PR)

**C.4** Engine anti-icing (Code EA)

**C.5** Fuel filter de-icing (Code EFD)

**C.6** Emergency fuel pump (Code EF)

**Note . . .**

*A detailed list of contents appears at the beginning of each Group*

**RESTRICTED**



This file was downloaded  
from the RTFM Library.  
Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

