

GROUPS B & C

POWER SUPPLY AND ENGINE SERVICES

LIST OF GROUPS

Group

- B.1** Generators and batteries (Code GA)

- C.1** Engine starting (Code SA)

- C.2** Fire warning and extinguisher (Code FW and FE)

- C.3** Tank pumps, failure warning and pressure refuelling (Code BP, PF and PR)

- C.4** Engine anti-icing (Code EA)

- C.5** Fuel filter de-icing (Code EFD)

- C.6** Emergency fuel pump (Code EF)

Note . . .

A detailed list of contents appears at the beginning of each Group

RESTRICTED

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

