

EQUIPMENT AIRCRAFT—FATIGUE METER INSTALLATION

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
	D.239870	METER, FATIGUE, ASSEMBLY					—	—		
10	5CZ/1053794	Block, terminal, type B, 2-way					1	—	B.	
10	F.215678	Bolt, special					2	S.154		
	F.215679	Bolt, special					1	S.154		
	—	Cable, F.M.1, group (See Cable Chart)					1	—	—	
	—	Cable, F.M.2, group (See Cable Chart)					1	—	—	
	F.216906	Bracket, fuseholder					1	L.72		
	—	Cable, F.M.3, group (See Cable Chart)					1	—	—	
	7154	Clip, securing cable					1	DTD.610	MR/C	4
10	6A/4664239	Meter, structure fatigue, Mk. 14 (Mod. 912)					1	—	A.	
	F.215681	Nut, special					3	S.62.8		
	F.215682	Piece, distance					3	L.65		
	A.215660	Plate, mounting					1	L.72		
	1919	Stud, earthing point					1	—	C.	4
	F.205630	Tube, retaining					2	S.62.8		
	F.215680	Tube, retaining					2	S.62.8		
	3767	Washer					1	DTD.610	C.	4
	4150	Washer					4	DTD.610	C.	4
	4613	Washer					1	—	C.	4
	4659	Washer					1	—	C.	4
	10666	Washer, tab					2	—	C.	6

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

